

# Service Manual

ORIGINAL VERSION

**SUPRA<sup>®</sup>**

MODEL : STV 1400N

14" COLOUR TELEVIDEO

**Supra (Japan) Ltd.,**  
11F La Vertu Shinjuku, 28-8 Shinjuku 6-Chome  
Shinjuku-ku, Tokyo 160, Japan

Specifications are subject to change without notice.

# SAFETY PRECAUTIONS

**WARNING :** BEFORE SERVICING THIS CHASSIS, READ THE "X-RAY RADIATION PRECAUTIONS", SAFETY INSTRUCTIONS" AND "PRODUCT SAFETY NOTICE" DESCRIBED BELOW.

## X-RAY RADIATION PRECAUTIONS

1. Excessive high voltage can produce potentially hazardous X-RAY RADIATION. To avoid such hazards, the high voltage must not be above the specified limit. The nominal value of the high voltage of this receiver is 24KV at Zero beam current (minimum brightness) under specified power source. The high voltage must not, under any circumstances, exceed 25KV. Each time a receiver requires servicing, the high voltage should be checked. It is recommended the reading of the high voltage be recorded as a part of the service record. It is important to use an accurate and reliable high voltage meter.
2. The only source of X-RAY RADIATION in this TV receiver is the picture tube. For continued X-RAY RADIATION protection, the replacement tube must be exactly the same type tube as specified in the parts list.
3. Some parts in this receiver have special safety-related characteristics for X-RAY RADIATION protection. For continued safety, parts replacement should be undertaken only after referring to the PRODUCT SAFETY NOTICE below.

## SAFETY INSTRUCTIONS


1. Potential as high as 20,000-24,000 volts is present when this receiver is operating. Operation of the receiver outside the cabinet or with the back cover removed involves a shock hazard from the receiver.
  - (1) Servicing should not be attempted by anyone who don't know the precautions necessary through and through when working on high-voltage equipment.
  - (2) Always discharge the picture tube anode to the CHASSIS GROUND to reduce the shock hazard before removing the anode cap.
  - (3) Perfectly discharge the high potential of the picture tube before handling.  
(WARNING: Risk of implosion. Handle with care.)
2. If any fuse in this TV receiver is blown, replace it with the FUSE specified in the chassis parts list only.
3. When replacing parts or circuit boards, wind the lead wires around terminals before soldering.
4. When replacing a high wattage resistor (oxide metal film resistor) in circuit board, keep the resistor 10 mm away from circuit board.
5. Keep wires away from high voltage or high temperature components.
6. Before returning the set to the customer, always perform an AC leakage current check on the exposed metallic parts of the cabinet, such as antennas, terminals, screwheads, metal overlays, control shafts, etc., to be sure the set is safe to operate without danger of electrical shock. Since this TV has AVC (Automatic Voltage Control) circuit, it may be operated nonadjustably within the voltage area indicated in the label

attached at back cover. (Do not use a line isolation transformer during this check).

Use an AC voltmeter having 1000 ohms per volt or more sensitivity in the following manner.

Connect a 1000 ohm resistor between a known good earth ground, (water pipe, conduit, etc.) and the exposed metallic parts, one at a time. Measure the AC voltage across the combination of 1000 ohm resistor. Reverse the AC plug at the AC outlet and repeat AC voltage measurements for each exposed metallic part. Voltage measured must not exceed 1 volt RMS. This corresponds to 1 mA. AC. Any value exceeding this limit constitutes a potential shock hazard and must be corrected immediately.

### AC Leakage Test




## PRODUCT SAFETY NOTICE


Many electrical and mechanical parts in this chassis have special safety-related characteristics. These characteristics are often passed without being noticed by a visual inspection and the X-RAY RADIATION protection afforded by some of them cannot necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified by  $\Delta$  marks on the schematic diagram and the replacement parts list. Before replacing any of these components, read the parts list in this manual carefully. The use of substitute replacement parts which do not have the same safety characteristics as specified in the parts list may create X-RAY RADIATION.

# CONTROLS LOCATION

## FRONT PANEL




## INSIDE CONTROL DOOR




## FEATURES

- Television and VCR in One Set
- PAL, MESECAM, NTSC 4.43(VCR Playback only), Auto system
- 8 Event / 1Month Programmable Timer with everyday Recording
- Quick Start Recording (QSR) with standby
- Voltage Synthesized Tuning
- On-Screen Display shows operation and time
- Playback up to 4 hours with E-240 tape in SP mode
- Full Function Infrared Remote Control
- Automatic Rewind at the end of the video Cassette Tape
- Convenient Front Loading System
- Direct Access Channel Selection from Remote Control
- Freeze Function(STILL Frame)
- 120 Min Sleep Timer
- Auto Operations System

## REAR PANEL



# REMOTE CONTROL UNIT



## CONTROL DESCRIPTIONS

### 1. NUMERICAL BUTTONS

To select the desired program NO., use these buttons.

### 2. UNIT BUTTON

To select the one(-) or two(--) digit program No.mode, use this button.

### 3. SETUP BUTTON

Press this button to select the SETUP mode.

### 4. MENU BUTTON

Press this button to select the MENU mode.

### 5. TV/AV MODE SELECTION BUTTON

Press this button to select the TV or AV mode.

### 6. PP BUTTON

To select the memorized picture states, press this button.

### 7. VISS (Video Index Search System) BUTTON

To enter the VISS function mode, press this button.

### 8. +/- BUTTON

To adjust desired level, use this button.

### 9. MEMORY BUTTON

For setting desired play position, use this button.

### 10. RESET BUTTON

To reset cassette tape counter to 0:00:00, press this button.

### 11. TV ON/OFF BUTTON

To turn the unit ON or OFF, press this button.

### 12. CLEAR/MONITOR BUTTON

During playback, to press this button and then the set is changed to normal TV mode. To enter the playback mode, press this button again. Also, the CLEAR function is operated with this button.

### 13. MUTE BUTTON

To mute a sound immediately, press this button. To obtain the former volume level, press it again.

### 14. DISPLAY BUTTON

Press this button to display the program No., date and clock, tape state.

### 15. SLEEP BUTTON


To set the sleep time, use this button.

### 16. ADD/DELETE BUTTON

To store or clear a selected program No., use this button.

### 17. BAND SELECTION (TV only)

In the manual search mode, press this button repeatedly and then BAND is changed as below.



### 18. TRACKING CONTROL BUTTONS

To minimize noise in playback. May also used during visual search to move the noise bars up or down on the screen.

### 19. AUTO TRACKING BUTTON

When playback is started, the auto tracking function operates normally even if this button is not pressed. When this button is pressed after tracking has been adjusted manually, auto tracking operates again.

**A. POWER BUTTON**

This button is sub power button.  
This button is used the unit on /off.

**NOTE: AUTO POWER ON SYSTEM**

Power is turned on automatically when the cassette tape is loaded.

If you load the cassette without the safety tab in place, you can enjoy the video program automatically. (FULL AUTO PLAY)

**B. PICTURE BUTTON**

To select the desired picture mode, press this button.  
And then picture mode is changed as below.

- In PAL/SECAM, MESECAM (TV, VCR) mode

CONTRAST → BRIGHTNESS → COLOR →  
↑  
PICTURE MEMORY (PUSH + BUTTON) ←

- In NTSC (VCR only) mode

CONTRAST → BRIGHTNESS → COLOR → TINT →  
↑  
PICTURE MEMORY (PUSH + BUTTON) ←

**C. RECORD BUTTON**

Press both the RECORD and PLAY buttons at the same time to start video and audio recording.

**D. STOP BUTTON**

Press this button to stop playback mode.

**E. REWIND/REVIEW BUTTON**

Press this button to rewind a cassette tape on stop mode.  
Press this button to play the unit backward rapidly on playback mode.

**F. PROGRAM +(UP)/-(DOWN) BUTTONS (TV ONLY)**

Press the program +(up) button to switch one program up.  
Press the program -(down) button to switch one program down.

**G. VOLUME +(UP)/-(DOWN) BUTTONS**

To increase the volume level, press the volume +(up) button.  
To decrease the volume level, press the volume -(down) button.

**H. VIDEO SYSTEM BUTTON (VCR mode only)**

To select the desired system mode, press this button repeatedly and system mode is changed as below.

AUTO → PAL → MESECAM → NTSC4.43  
↑

**I. PAUSE/STILL BUTTON**

- In the record mode, press this button to stop the recording.  
To start recording, press this button again.
- In play mode, press this button to stop the play mode. To enter the playback mode, press the PLAY button.

**J. FAST FORWARD/CUE BUTTON**


On the stop mode, press this button to wind the video tape forward rapidly. On the playback mode, press this button to paly the unit forward rapidly.

**K. PLAY BUTTON**


Press this button to make the VCR playback mode.

# ALIGNMENT/TEST POINT LOCATION GUIDE

## 1. Monitor Main Board




## 2. SMPS Board



MONITOR

# BLOCK DIAGRAM






# TROUBLESHOOTING CHARTS


## 1. Monitor Circuit

A.

**DEAD SET  
(No Raster / No Sound)**




## No PICTURE



MONITOR


## ON SCREEN DISPLAY OPERATION CHECK



## 2. SMPS Circuit


A.

### NO POWER SUPPLY




## 1. Monitor Main Schematic Diagram

## PC-32A SCHEMATIC DIAGRAM



# SCHEMATIC DIAGRAMS

## SCHEMATIC DIAGRAM (PAL/SECAM/N4.43)



The components marked  $\Delta$  conform to VDE or IEC guidelines and are essential for safe operation of the set while those marked  $\Delta$  are required for correct operation. Use specified parts only when replacing.

### NOTICE

Since this is a basic schematic diagram, The value of components and some partical connection are subject to change for improvement.

### OBSERVATION OF VOLTAGES AND WAVEFORMS

1. Voltages read with VTVM from point shown to chassis ground, line voltages 220 Volts, colour bar signal.
2. Voltages reading may very  $\pm 20\%$ .
3. The schematic shown is representative only.
4. All waveforms are taken using a wide band oscilloscope and a low capacity probe.
5. Check FINE TUNING < AGC < BRIGHTNESS, CONTRAST and COLOUR controls for best picture, make sure that CONTRAST and COLOUR controls are in mid position and BRIGHTNESS controls is almost in maximum position.
6. Waveforms are taken using a standard colour bar signal.

### VALUE OF RESISTOR, CAPACITOR AND INDUCTOR


1. Resistances are shown in ohm, K = 1,000 M = 1,000,000.
2. Unless otherwise noted in schematic, all capacitor values less than 1 are expresses in mfd and the values more than 1 in pF.
3. Unless otherwise noted in schematic, all coil values more than 1 are expressed in uH, and the values less than 1 in H.

### TABLE OF INCH CONVERSION

| NO | CIRCUIT NO | 14"   | 19" | 21"   | REMARKS                |
|----|------------|-------|-----|-------|------------------------|
| 1  | R572       | 620   |     | 820   | RESISTOR, FIX 1/6W     |
| 2  | R702       | 75K   |     | 36K   | RESISTOR, FIXED 1/4W   |
| 3  | R703       | 75K   |     | 36K   |                        |
| 4  | FR705      | 0.68  |     | 1.4   | RESISTOR FUSIBLE 2W    |
| 5  | FR707      | 9.1   |     | 9.1   | RESISTOR, FUSIBLE 1W   |
| 6  | C312       | 0.47  |     | 0.88  | CAPACITOR, CE 50V      |
| 7  | C413       | 394   |     | 624   | CAPACITOR, MPP 200V    |
| 8  | C418       | 822   |     | 822   | CAPACITOR, MPP 16KV    |
| 9  | C419       | 471   |     | -     | CAPACITOR, CERAMIC 2KV |
| 10 | L403       | 224Q  |     | -1590 | COIL, INERTITY (50-)   |
| 11 | T701       | -207A |     | -207F | FBT(154-)              |
| 12 |            |       |     |       |                        |
| 13 |            |       |     |       |                        |
| 14 |            |       |     |       |                        |
| 15 |            |       |     |       |                        |
| 16 |            |       |     |       |                        |

P/N: 484-874A  
DATE: JUL. 5, 1993


RD



P/N : 484-874A

DATE: JUL. 5, 1993

## 2. SMPS Schematic Diagram



## 1. Front Loading Mechanism Assembly (Fig. A-1-1)

- 1) Remove the Top and Bottom Covers and the Front panel.
- 2) Unplug the connector.
- 3) Remove two screws(A).
- 4) Lift up the Front Loading Mechanism in the direction of arrow(C).

### \* NOTE

- 1) When disassembling and reassembling
  - ① Give special attention to removal, because two tabs(D) are engaged.

- ② Make sure that Bosses of Bracket(L),(R) are properly engaged in the holes of the chassis.
- ③ To reassemble Front Loading Mechanism, the Drive Gear Assembly should be turned in a counterclockwise as shown in Fig. A-1-2 so that the Rack Gear N.D of Front Loading Mechanism Assembly is meshed into Rack Gear F.L of Deck Mechanism Assembly correctly as shown in Fig. A-1-1.(B).




Fig. A-1-1 Front Loading Mechanism




Fig. A-1-2 Carrier Bracket Assembly





## 10. Pinch Gear

- 1) Remove one Nut(A) and then remove the Dew Bracket.
- 2) Remove the Pinch Lever Assembly by lifting it up.
- 3) Remove the Loading Motor Assembly.
- 4) Remove the Take Up Lever.
- 5) Remove the Pinch Gear Assembly.

### \* NOTE

- 1) When reassembling, align the hole(A) of Pinch Gear with the hole of chassis, and the hole(C) of Pinch Gear with the groove(D) of the P.C.Gear. Hole(E) of chassis should be aligned with the hole of P.C.Gear.



## 11. FE(Full Erase) Head Assembly(Fig. B-11)


- 1) Unplug the connector.
- 2) Remove one screw(A), and then remove the FE Head.

### \* NOTE

- 1) When disassembling and reassembling
  - ① Do not touch the Video Head Tip with fingers or tools.

## 12. P1 Assembly(Fig. B-11)

- 1) Remove the Adjust P1.
- 2) Remove the Guide 17.
- 3) Remove the Roller.
- 4) Remove the Sleeve.
- 5) Remove the Guide 17.
- 6) Remove the Spring.




## 13. Tension Arm Assembly(Fig. B-13)

- 1) Remove one screw(C).
- 2) Remove the Tension Spring.
- 3) Remove the Tension Arm Assembly by pushing hooks outward with the Deck Mechanism Assembly turned over.
- 4) Remove the Tension Band Assembly from the Tension Arm by pushing Hooks of Holder(A).

### \* NOTE

- 1) When disassembling and reassembling, give special attention to the disassembling and reassembling of Tension Arm Assembly, because the Tension Band is interposed between the Supply Reel and the Soft Brake.




### 17. Idler Gear(A), (B)(Fig. B-16)

- 1) After removing the Supply Reel, and supply Main Brake Assembly, remove the washer(C) and remove the Idler Gear(A).
- 2) Remove the Washer(D) and remove the Idler Gear(B).


### 18. Pulley Gear Assembly(Fig. B-18)

- 1) Turn over the Deck Mechanism Assembly.
- 2) Remove the Capstan Belt.
- 3) Remove the washer(A) and lift up the Pulley Gear.



### 19. Bracket Bottom Assembly(Fig. B-19)

- 1) Remove one screw(A).
- 2) Remove one Hexagonal Nut, and then lift up the Bracket Bottom Assembly.
- 3) Remove one Washer, and lift up the Ratchet Gear 1.




- 4) Remove the washer, and then remove Ratchet Gear 3 from the Bottom Bracket.

### 20. Junction PCB(Printed Circuit Board) Assembly (Fig. B-20-1)

- 1) Remove the Bottom Bracket Assembly.
- 2) Remove two screws(A),(B) and then remove the Junction P.C.B Assembly.
- 3) Remove the Mode Switch from the Junction P.C.B Assembly.
- 4) Remove the Reel Sensors, Sensor LEDS and each holder from the Junction P.C.B(Fig. B-20-2).

#### \* NOTE

- 1) When reassembling the Mode Switch, the groove(V) and (U) of Mode Switch should be at their original place in the Eject Mode.



## 23. Ratchet Lever Assembly(Fig. B-23)

- 1) Remove the Function Plate.
- 2) Remove the Junction P.C.B Assembly.
- 3) Remove the Washer(A) and then remove the Ratchet Lever Assembly.
- 4) Remove the Ratchet Spring.
- 5) Remove the Ratchet Lever from the Ratchet 17 by lifting it up when the hook of it is aligned with the hole of Ratchet 17 while rotating it counterclockwise direction.
- 6) Remove the Washer(B), and turn over the Ratchet 17 and then remove the Slant Pin, Spring F, Lever.




Fig. B-23 Ratchet Lever Assembly

## 24. Cam Gear/Rack Gear T/Rack Gear FL(Fig. B-24-2)

- 1) Remove the washer(A) and remove the Ratchet Lever Assembly. (Fig. B-24-1).
- 2) Remove the washer(B), and then remove the Cam Gear (Fig. B-24-2).
- 3) Remove the Rack Gear F.L.(Fig. B-24-3)
- 4) Remove the Rack Gear T.(Fig. B-24-3)

### \* NOTE

- 1) When reassembling
  - ① Align the Projection of Rack Gear T with the hole of Loading Gear.
  - ② Drive the Rack Gear F.L in the direction of arrow(D).
  - ③ Hole of Cam should be aligned with the hole of chassis, and the groove(■) of Cam Gear should be aligned with the hole of PC Gear(Fig. B-25)




Fig. B-24-1 Lever Ratchet Assembly




Fig. B-24-2 CAM/PC Gear




Fig. B-24-3 Rack Gear F.L/Rack Gear T




Fig. B-24-4 Rack Gear F.L/Rack Gear T/CAM Gear

## PC Gear(Fig. B-25)

- 1) Remove the washer(C).
- 2) Remove the P.C Gear by lifting it up.

### • NOTE

- 1) When reassembling
- 2) The Groove of PC Gear should be aligned with the groove of Cam Gear, and another hole of it should be aligned with the hole of chassis(Fig. B-25).




Fig. B-25 PC Gear

## P2 and P3 Slant Assembly(Fig. B-26)

- 1) After finishing the disassembly of Drum Assembly, remove the P2 and P3 Slant Assembly by turning the Loading Gear(L) in the clockwise direction.(Loading direction)
- 2) Remove the set screws.
- 3) Remove the Roller Guide from the Slant Base.




Fig. B-26 Slant Assembly

### \* NOTE

- 1) When disassembling and reassembling
- ① Use a Hexagonal wrench to remove set screw.
- ② Take notice that the P2 and P3 Slant Assembly should not be changed from their original place.

## 27. Loading Gear Assembly(L),(R) (Fig. B-27)

- 1) Remove the Cam Gear, Rack-T.
- 2) Remove the P2 and P3 Slant Assembly by turning the Loading Gear(L),(R) in the Loading direction
- 3) Lift up the Loading Gear Assembly(L),(R) from the Deck Mechanism Assembly.
- 4) Remove the Spring Load(L),(R).
- 5) Separate the Loading Gear(L), (R) from Lever Load(L),(R).

### \* NOTE

- 1) When reassembling
- ① Make sure that the Loading Gear(L) and (R) should not be changed from their original place.
- ② Align the groove of Loading Gear(L),(O) with the groove of Gear(R),(O).




Fig. B-27 Loading Gear Assembly




Fig. B-28 Tension Lever Assembly

## 28. Tension Lever Assembly(Fig. B-28)

- 1) Remove the Function Plate.
- 2) Remove the Tension Lever Assembly by pushing hook inward.

### \* NOTE

- 1) When reassembling
  - ① Set the part(A) of Tension Lever Assembly in the groove of Lower part of Function Plate.
  - ② After reinstalling the Tension Lever Assembly, adjust the Tension Post and the Tension with a Tension Cassette.

## 29. Clutch Gear Assembly(Fig. B-29)

- 1) Remove the Pulley Gear.
- 2) Remove the Plate Function.
- 3) Remove the washer(A), and then remove the Clutch Gear Assembly.

### \* NOTE

- 1) When reassembling
  - ① Do not disassemble the Clutch Gear Assembly any further, because Torque adjustment can't be adjustable.




Fig. B-29 Gear Clutch Assembly

## 30. Take Up Reel Assembly(Fig. B-16)

- 1) Remove the TMB(Fig. B-14)
- 2) Lift up the Take-up Reel Assembly from the Deck Mechanism Assembly.
- 3) Separate the Reel Cap and Spring from the Take-Up Reel by releasing Hooks(S).

# 1. Mechanism State Switch(Mode Switch) Check

**Purpose:**To detect accurately the mechanism state and prevent the mechanism from malfunction.

| Test Equipment/Fixture | VCR State                               | Check Point                                       |
|------------------------|---|---|
| ● Blank tape           | ● Eject Mode<br>(with cassette ejected) | ● Mechanism state switch<br>(Mode Switch and Cam) |



## Check Procedure

- 1) Turn the VCR on and eject the tape by pressing eject button.
- 2) Remove the Cabinet Top and Main P.C.Board, and then turn the Cam so as to align the hole of chassis with the hole of Cam and Pinch Gear, and Holes of Pinch Gear and P.C Gear with each other.
- 3) Remove the Bottom Cover and then check that the grooves(V) and (O) of Mode S/W are at their original place.

- 4) If the above alignment are not obtained, adjust as follows.


- (1) Remove the Bracket Assembly Bottom and the Capstan Belt in the state of power off.
- (2) Remove the P.C.B Assembly, make the grooves (V) and (O) of mode switch at their original place, and then reassemble the P.C.B Assembly.
- (3) Turn the power on and perform the various operations to check that the loading and the unloading are correct.


## Check Diagram



# MECHANISM TROUBLESHOOTING GUIDE


## 1. Deck Mechanism






VCR






D.




VCR

## 2. Front Loading Mechanism


A.



B.




C.




# ELECTRIAL ADJUSTMENT INSTRUCTIONS

## 1. Adjustment Parts Location

### 1-1. Main Board



(COMPONENT SIDE)



# TROUBLESHOOTING CHARTS

## POWER CIRCUIT

**12VA IS NOT OUTPUT (SER. SYS)**

Is the pin 1 of IC102 12V?

NO

Check SMPS and P6T01

YES

Change IC102

**6VA is not output**

Is the pin 1 of IC101 12VA?

NO

Check SMPS and P6T01

YES

Change IC101

**12V is not output (Y/C, TIMER, AUDIO)**

Is 40V output to P6T01 pin 5?

NO

Check SMPS

YES

Is the Base of Q106 13V?

NO

Check ZD103 and R107-9, Q103

YES

Is the collector of Q106 17V?



NO

Check SMPS

YES

Check Q106 and circumference circuit

VCR




VCR

## 2. IF CIRCUIT

A.

**NO SOUND, NO PICTURE  
(RASTER OK)**




VCR




### 3. AUDIO CIRCUIT


A



VCR




C



VCR


# Y/C CIRCUIT



VCR


B

# **LUMINANCE SIGNAL DOESN'T APPEAR AT THE SCREEN WHEN PB MODE**




VCR


C

**CHROMA PB MODE**

VCR




VCR






## 5. SYSCON CIRCUIT

A




B




VCR

## 6. SERVO CIRCUIT




VCR

B


**DRUM MOTOR STOP**

VCR


C




## 7. TIMER CIRCUIT



VCR




C

**NO/PICTURE, VOLUME, CONTROL**


VCR


## 1.Main System (System &amp; Servo) Block Diagram






## BLOCK DIAGRAM








## 2. Audio Block Diagram




### 3. Power Block Diagram









#### 4.Timer & Key Block Diagram




## 5.Y/C Block Diagram









# SCHEMATIC DIAGRAM




## 1. Power Schematic Diagram




## 2. Servo Schematic Diagram






## 2-1. Servo Oscilloscope Waveform




IC201 Pin①  
TRK TRIGGER




IC201 Pin⑥  
PG M.M




IC201 Pin⑦  
DRUM P.G




IC201 Pin⑨  
DRUM F.G



IC201 Pin②⑦  
SLOW CONTROL




IC201 Pin②⑨  
REC CTL



IC201 Pin③⑩  
REC CTOL



IC201 Pin③⑤  
REC CTL




IC201 Pin③⑦  
CAPSTAN F.G




IC201 Pin③⑨  
CLOCK CTL




IC201 Pin④⑤  
SW30




IC201 Pin④⑧  
DV. SYNC




IC201 Pin⑤⑩  
COMPOSITE SYNC




IC201 Pin⑤③ 90  
SERIAL DATA



IC201 Pin⑤④  
SERIAL CLOCK



IC201 Pin⑤⑤  
CFG C.D



IC201 Pin⑤⑥  
CTL C.D

**\* Servo IC voltage sheet**

**IC201**

|    |     |     |
|----|-----|-----|
| 1  | 2.5 | 3.8 |
| 2  | 0   | 0   |
| 3  | 0   | 0   |
| 4  | 5   | 5   |
| 5  | 0   | 0   |
| 6  | 0   | 0   |
| 7  | 2   | 2   |
| 8  | 0   | 0   |
| 9  | 2.8 | 2.8 |
| 10 | 2.7 | 2.7 |
| 11 | 5   | 5   |
| 12 | 1.4 | 1.4 |
| 13 | 2.5 | 2.5 |
| 14 | 2.5 | 2.5 |
| 15 | 2.5 | 2.5 |
| 16 | 2.5 | 2.5 |
| 17 | 2.5 | 2.5 |
| 18 | 2.5 | 2.5 |
| 19 | 0   | 0   |
| 20 | 2.5 | 2.5 |
| 21 | 2.5 | 2.5 |
| 22 | 2.5 | 2.5 |
| 23 | 2.5 | 2.5 |
| 24 | 2.5 | 2.5 |
| 25 | 2.5 | 2.5 |
| 26 | 2.8 | 2.8 |
| 27 | 2.8 | 2.8 |
| 28 | 5   | 5   |
| 29 | 2.5 | 2.2 |
| 30 | 2.5 | 3.0 |
| 31 | 0   | 0   |
| 32 | 2.5 | 2.5 |
| 33 | 2.5 | 2.5 |
| 34 | 2.5 | 2.5 |
| 35 | 2.5 | 2.5 |
| 36 | 2.5 | 2.5 |
| 37 | 2.8 | 2.8 |
| 38 | 5   | 5   |
| 39 | 0   | 3.8 |
| 40 | 5   | 5   |
| 41 | 0   | 0   |
| 42 | 2.6 | 2.6 |
| 43 | 2.6 | 2.6 |
| 44 | 0   | 2.6 |
| 45 | 2.6 | 2.6 |
| 46 | 2.6 | 0   |
| 47 | 2.6 | 2.6 |
| 48 | 0   | 0   |
| 49 | 0   | 0   |
| 50 | 0.6 | 0.6 |
| 51 | 5   | 5   |
| 52 | 5   | 5   |
| 53 | 0.8 | 0.8 |
| 54 | 1.0 | 1.0 |
| 55 | 2.5 | 2.6 |
| 56 | 2.2 | 5   |


**IC202**


|   | PB  | REC |
|---|-----|-----|
| 1 | 0   | 0   |
| 2 | 0   | 0   |
| 3 | 0   | 0   |
| 4 | 0   | 0   |
| 5 | 2.5 | 2.5 |
| 6 | 2.5 | 2.5 |
| 7 | 2.5 | 2.5 |
| 8 | 5   | 5   |






### 3. Key/Timer Schematic Diagram






## 4. Tuner/IF Schematic Diagram




## 5. Audio Schematic Diagram




| IC PIN  | 11    | 17   | 24  |
|---------|-------|------|-----|
| 0 - 1   | LINE  | MUTE | EE  |
| 2.2-2.7 | TUNER |      |     |
| 4.3-7.0 | PB    | MUTE | REC |





## 6. Y/C Schematic Diagram




## 6-1. Main Analog(Y/C, Audio, Pre-Amp & Transcoder) Waveform

①




IC 303 Pin 37  
EE/REC MODE  
VIDEO SIGNAL

②




IC 303 Pin 3  
EE/REC MODE  
7MHz LPF OUTPUT  
SIGNAL

③




IC303 Pin 4  
EE/REC MODE  
3MHz LPF OUTPUT  
SIGNAL

④



IC303 Pin 5  
EE/REC MODE  
MAIN EMPHASIS  
OUTPUT SIGNAL

⑤



IC303 Pin 40  
EE/REC MODE  
VIDEO FM OUTPUT  
SIGNAL

⑥



IC303 Pin 34  
EE/REC MODE  
VIDEO OUTPUT  
SIGNAL

⑦




IC303 Pin 15  
EE/REC 3.58MHz  
MAIN CONVERTER  
OUTPUT SIGNAL

⑧



IC303 Pin 39  
PB MODE FM AGC  
OUTPUT SIGNAL

⑨



IC303 Pin 3  
PB MODE 3M LPF  
OUTPUT SIGNAL

⑩




IC303 Pin 10  
PB MODE 1H DELAY  
OUTPUT SIGNAL

⑪




IC303 Pin 34  
PB MODE VIDEO  
OUTPUT SIGNAL

⑫




IC303 Pin 15  
PB MODE 629KHz  
COLOR INPUT  
SIGNAL

⑬




IC303 Pin 25  
PB MODE 3.5MHz  
MAIN CONVERTER  
OUTPUT SIGNAL

⑭



IC303 Pin 27  
PB MODE COMB  
FILTER OUTPUT  
SIGNAL

⑮



IC303 Pin 29  
PB MODE 3.58MHz  
COLOR SIGNAL



**\* Y/C, pre-Amp Transsorder Voltage sheet.**

**IC 304**

| Mode<br>Pin No. | STOP | PB   | REC  |
|-----------------|------|------|------|
| 1               | 0    | 0.08 | 0.04 |
| 2               | 0.5  | 2.22 | 0.58 |
| 3               | 2.35 | 2.89 | 2.36 |
| 4               | 2.74 | 2.43 | 2.72 |
| 5               | 2.67 | 4.55 | 2.65 |
| 6               | 2.67 | 4.55 | 2.65 |
| 7               | 4.59 | 4.56 | 4.57 |
| 8               | 2.30 | 2.43 | 2.32 |
| 9               | 2.20 | 3.09 | 2.23 |
| 10              | 2.20 | 2.22 | 2.23 |
| 11              | 0    | 0.00 | 0.0  |
| 12              | 2.04 | 2.01 | 2.04 |
| 13              | 2.55 | 2.51 | 2.54 |
| 14              | 1.26 | 2.30 | 1.64 |
| 15              | 3.06 | 2.97 | 3.06 |
| 16              | 2.47 | 2.26 | 2.46 |
| 17              | 2.16 | 2.13 | 2.15 |
| 18              | 3.72 | 3.66 | 3.71 |
| 19              | 2.53 | 2.50 | 3.27 |
| 20              | 1.19 | 2.29 | 1.18 |
| 21              | 4.57 | 4.52 | 4.57 |
| 22              | 0.03 | 0.03 | 0    |
| 23              | 3.26 | 3.26 | 3.26 |
| 24              | 3.26 | 3.27 | 3.27 |
| 25              | 2.46 | 2.44 | 2.45 |
| 26              | 1.88 | 1.99 | 2.01 |
| 27              | 4.65 | 1.96 | 1.97 |
| 28              | 5.02 | 4.96 | 4.99 |
| 29              | 0.04 | 0.04 | 0.04 |
| 30              | 4.14 | 4.14 | 4.14 |
| 31              | 2.59 | 2.65 | 2.59 |
| 32              | 0.52 | 0.53 | 0.52 |
| 33              | 0.05 | 0.06 | 0.06 |
| 34              | 0.01 | 0.01 | 1.96 |
| 35              | 5.02 | 4.97 | 4.99 |
| 36              | 0.54 | 0.54 | 0.54 |
| 37              | 3.21 | 3.20 | 3.19 |
| 38              | 1.37 | 1.44 | 1.36 |
| 39              | 3.29 | 3.28 | 3.29 |
| 40              | 3.13 | 3.67 | 3.11 |
| 41              | 0.09 | 0.72 | 0.73 |
| 42              | 2.43 | 2.73 | 2.40 |

**IC301**

| Mode<br>Pin No. | STOP | PB   | REC  |
|-----------------|------|------|------|
| 1               | 3.67 | 3.64 | 3.65 |
| 2               | 0    | 0    | 0    |
| 3               | 0    | 0    | 0    |
| 4               | 3.67 | 3.64 | 3.65 |
| 5               | 4.60 | 4.58 | 4.59 |
| 6               | 0    | 0    | 0.0  |
| 7               | 4.48 | 4.45 | 4.46 |
| 8               | 0    | 0    | 0    |
| 9               | 3.11 | 3.09 | 3.10 |
| 10              | 0.01 | 0.01 | 0.01 |
| 11              | 3.58 | 3.60 | 3.57 |
| 12              | 0    | 0.24 | 0.01 |
| 13              | 0.02 | 3.61 | 3.58 |
| 14              | 0    | 0.22 | 0    |
| 15              | 0    | 0    | 0    |
| 16              | 0    | 0    | 0    |
| 17              | 5.09 | 5.06 | 5.07 |
| 18              | 5.09 | 5.06 | 5.07 |

**IC302**

| Mode<br>Pin No. | STOP | PB   | REC  |
|-----------------|------|------|------|
| 1               | 0.04 | 4.98 | 0.04 |
| 2               | 0.00 | 0.00 | 0.00 |
| 3               | 0.04 | 4.98 | 0.04 |
| 4               | 0.05 | 3.48 | 0.05 |
| 5               | 0.15 | 2.09 | 0.25 |
| 6               | 0.55 | 2.03 | 1.3  |
| 7               | 0.00 | 2.54 | 0.0  |
| 8               | 0.04 | 8.63 | 0.04 |


**IC304**

| Mode<br>Pin No. | STOP  | PB    | REC   |
|-----------------|-------|-------|-------|
| 1               | 12.41 | 12.41 | 12.40 |
| 2               | 8.16  | 8.15  | 8.15  |
| 3               | 0.07  | 0     | 0     |
| 4               | 7.47  | 7.46  | 7.45  |
| 5               | 0     | 0     | 0     |
| 6               | 0     | 0     | 0     |
| 7               | 8.11  | 8.11  | 8.11  |
| 8               | 0     | 0     | 0     |

**\* Audio Circuit Voltage Sheet**

**IC401**

| Mode<br>Pin No. | EE   | REC  | PB   | EE   | REC  | PB   |
|-----------------|------|------|------|------|------|------|
| 1               | 0    | 0    | 0    | 0    | 0    | 0    |
| 2               | 8.5  | 11.2 | 11.2 | 11.4 | 8.5  | 9    |
| 3               | 0    | 0    | 0    | 0    | 0    | 0    |
| 4               | 2    | 2    | 2    | 2    | 2    | 2    |
| 5               | 2    | 2    | 2    | 2    | 2    | 2    |
| 6               | 0    | 0    | 0    | 0    | 0    | 0    |
| 7               | 2    | 2    | 2    | 2    | 2    | 2    |
| 8               | 2    | 2    | 2    | 2    | 2    | 2    |
| 9               | 0    | 0    | 0    | 0    | 0    | 0    |
| 10              | 0    | 0    | 0    | 0    | 4.8  | 4.6  |
| 11              | 0    | 0    | 0    | 0    | 0    | 0    |
| 12              | 0.4  | 0.4  | 0.3  | 0.4  | 0    | 0    |
| 13              | 9.5  | 9.6  | 9.6  | 10   | 9.5  | 9.5  |
| 14              | 6    | 6    | 6    | 6    | 6    | 5.8  |
| 15              | 6    | 6    | 6    | 6    | 6    | 5.8  |
| 16              | 6    | 6    | 5.8  | 6    | 6    | 5.8  |
| 17              | 6    | 6    | 6    | 6    | 6    | 5.8  |
| 18              | 0    | 0    | 0    | 0    | 0    | 0    |
| 19              | 0    | 0    | 0    | 5    | 0    | 5    |
| 20              | 0    | 0    | 0    | 0    | 0    | 0    |
| 21              | 0    | 0    | 0    | 0    | 0    | 0    |
| 22              | 0    | 0    | 0    | 0    | 0    | 0    |
| 23              | 0.5  | 0.6  | 0.6  | 0.6  | 0.5  | 0.5  |
| 24              | 0    | 0    | 5    | 0    | 5    | 5    |
| 25              | 5.5  | 5.8  | 5.8  | 5.8  | 5.8  | 5.8  |
| 26              | 0    | 5    | 5    | 5    | 5    | 5    |
| 27              | 0    | 12   | 12   | 12   | 12   | 12   |
| 28              | 0    | 11.5 | 11.5 | 11.5 | 11.5 | 11.5 |
| 29              | 12   | 12   | 12   | 12   | 12.4 | 12.2 |
| 30              | 12   | 12   | 12   | 12   | 12.2 | 12.1 |
| 31              | 11.4 | 11.4 | 11.4 | 11.4 | 11.4 | 11.5 |
| 32              | 0    | 0    | 0    | 0    | 0    | 0    |



## 7. Pre-Amp Schematic Diagram

