

Mode Name	Item	FL Display	Key Operation
	Description		Front Key
Service Mode	To enter into Service Mode		<p>In CD Mode:</p> <ol style="list-style-type: none"> 1.Press and hold [■] button on main unit for 2 secs. 2.Do not release [■] button, press and hold [▶/▶▶] on the remote control for 2 secs. 3.To exit, press [⏏/I] button on main unit.
Error Code History	<p>Checking the records for Error Code.</p> <p>If there's no error code.Display will remain as [T]</p>		<p>In Service Mode:</p> <ol style="list-style-type: none"> 1.Press button [1] on remote control. 2.To clear history,press & hold [0] for 5 seconds or more
Software Display Version.	<p>To check for following:</p> <p>1)System Version.</p> <p>2)Jupiter Micro-processor Version.</p> <p>3) Opecon Version.</p>	<p style="text-align: center;">↓</p> <p style="text-align: center;">↓</p>	<p>In Service Mode:</p> <ol style="list-style-type: none"> 1.Press button [2] on remote control. 2.Press button [2] on remote control. 3.Press button [2] button on remote control.
Display of AD value of main body key	To check the AD input value	<p>XX: AN2 input value (2 hexadecimal value digits) --> KEY1 YY: AN3 input value (2 hexadecimal value digits) --> KEY2 ZZ: AN4 input value (2 hexadecimal value digits) --> KEY3</p>	<p>In Service Mode:</p> <ol style="list-style-type: none"> 1.Press button [4] on remote control for 2 secs.
USB Error Code History	To check for USB error Codes.	<p style="text-align: center;">History number</p>	<p>In Service Mode:</p> <ol style="list-style-type: none"> 1.Press button [5] on remote control. 2.To clear history,press & hold [0] for 5 seconds or more.