



Refer to the numbers in parentheses for chapter references.

- 1 Standby/on switch** [⏻], [⏻/⏻]
Press to switch the unit from on to standby mode or vice versa. In standby mode, the unit is still consuming a small amount of power.
- 4 Select source**
[MEMORY, USB]: Select internal memory or USB
[MEMORY]: Select internal memory
[USB]: Select USB
[CD]: Select disc
[RADIO, EXT-IN]: Select radio, USB, music port or AUX
- 5 Basic operation**
[▶/⏸]: Playback or pause operation
[■]: Stop playback or recording
[⏮], [⏭]: Skip track
Select preset radio station
[⏮], [⏭]: Search track
Tune in to the radio station
[⏮/⏮], [⏭/⏭]: Skip and search track
Select preset radio station
- 9 Recording operation for USB and internal memory**
[CD HI-SPEED REC]: CD high-speed recording
[●/⏸, USB REC]: USB recording
[●/⏸, MEMORY REC]: Internal memory recording
[REC MODE]: Set the record mode
- 14 Adjust the volume of the system**
- 20 USB port** (🔌)
- 21 Music port**

- 22 Headphones jack** (🎧)
Plug type: Ø 3.5 mm stereo (not included)
 - Avoid listening for prolonged periods of time to prevent hearing damage.
 - Excessive sound pressure from earphones and headphones can cause hearing loss.
 - Listening at full volume for long periods may damage the user's ears. Be sure to use the supplied or recommended headphones or earphones.
- 23 Remote control sensor**
- 24 Display panel**
- 25 Set Super Woofer function**
- 26 Set D.Bass function**
- 27 Set the Manual EQ effect**
- 28 Browse tracks or albums**

CD

 Turn the knob to browse track.
 Press [▶/⏸] to start playback from the selection.

MP3

 Press [ALBUM/TRACK] to select album or track and then turn the knob to browse.
 Press [▶/⏸] to start playback from the selection.
- 29 Open or close the disc tray**
- 30 Disc tray**
- 31 Microphone jack**
- 32 Adjust the volume of the microphone**