

1170 ~ 1250	H	350
1260 ~ 1450	L	301
1460 ~ 1540	H	350
1550 ~ 1710	L	301

**Table 4: F HOP Control during 10 kHz Step**

Note: During activating, the 3 control pins namely MUTE\_F, MUTE\_A and MODE\_DA must be used to cover the “Pop” sound cause by F-HOP switching.