

Service  
Service  
**Service**



# Service Manual

## TABLE OF CONTENTS

	Page
Location of pc boards & Version variations .....	1-2
Technical Specifications .....	1-3
Measurement setup .....	1-4
Service Aids, Safety Instruction, etc. ....	1-5
Disassembly Instructions & Service positions .....	2
Service Test Programs .....	3-1
Set Block diagram .....	4-1
Set Wiring diagram .....	5-1
Power Board .....	6
Key Board .....	7
Main Board .....	8
Display Board .....	9
Set Mechanical Exploded view & parts list .....	10



© Copyright 2003 Philips Consumer Electronics B.V. Eindhoven, The Netherlands  
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form or by any means, electronic, mechanical, photocopying, or otherwise without the prior permission of Philips.

Published by SL 0427 Service Audio Printed in The Netherlands Subject to modification

**CLASS 1  
LASER PRODUCT**




3141 785 30020

**Version 1.0**



**PHILIPS**

## LOCATION OF PRINTED CIRCUIT BOARDS




VERSION VARIATIONS:

[illegible]




## MEASUREMENT SETUP

### Tuner FM



Use a bandpass filter to eliminate hum (50Hz, 100Hz) and disturbance from the pilotone (19kHz, 38kHz).


### Tuner AM (MW,LW)



To avoid atmospheric interference all AM-measurements have to be carried out in a Faraday's cage.  
Use a bandpass filter (or at least a high pass filter with 250Hz) to eliminate hum (50Hz, 100Hz).


### CD

Use Audio Signal Disc SBC429 4822 397 30184  
(replaces test disc 3)



### Recorder

Use Universal Test Cassette **CrO2** SBC419 4822 397 30069  
or Universal Test Cassette **Fe** SBC420 4822 397 30071



## SERVICE AIDS

### Service Tools:

Universal Torx driver holder .....	4822 395 91019
Torx bit T10 150mm .....	4822 395 50456
Torx driver set T6 - T20 .....	4822 395 50145
Torx driver T10 extended .....	4822 395 50423

### Cassette:

SBC419 Test cassette CrO2 .....	4822 397 30069
SBC420 Test cassette Fe .....	4822 397 30071
MTT150 Dolby level 200nWb/M .....	4822 397 30271






### Compact Disc:

SBC426/426A Test disc 5 + 5A .....	4822 397 30096
SBC442 Audio Burn-in Test disc 1kHz .....	4822 397 30155
SBC429 Audio Signals disc .....	4822 397 30184
Dolby Pro-logic Test Disc .....	4822 395 10216

### ESD Equipment:

Anti-static table mat - large 1200x650x1.25mm ...	4822 466 10953
Anti-static table mat - small 600x650x1.25mm .....	4822 466 10958
Anti-static wristband .....	4822 395 10223
Connector box (1M $\Omega$ ) .....	4822 320 11307
Extension cable (to connect wristband to conn. box) .....	4822 320 11305
Connecting cable (to connect table mat to conn. box) .....	4822 320 11306
Earth cable (to connect product to mat or box) ....	4822 320 11308
Complete kit ESD3 (combining all above products) .....	4822 320 10671
Wristband tester .....	4822 344 13999

## HANDLING CHIP COMPONENTS



**GB WARNING**

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically.

When repairing, make sure that you are connected with the same potential as the mass of the set via a wrist wrap with resistance.

Keep components and tools also at this potential.

**ESD****NL WAARSCHUWING**

Alle IC's en vele andere halfgeleiders zijn gevoelig voor electrostatische ontladingen (ESD).

Onzorgvuldig behandelen tijdens reparatie kan de levensduur drastisch doen verminderen.

Zorg ervoor dat u tijdens reparatie via een polsband met weerstand verbonden bent met hetzelfde potentiaal als de massa van het apparaat.

Houd componenten en hulpmiddelen ook op hetzelfde potentiaal.

**F ATTENTION**

Tous les IC et beaucoup d'autres semi-conducteurs sont sensibles aux décharges statiques (ESD).

Leur longévité pourrait être considérablement écourtée par le fait qu'aucune précaution n'est prise à leur manipulation.

Lors de réparations, s'assurer de bien être relié au même potentiel que la masse de l'appareil et enfiler le bracelet serti d'une résistance de sécurité.

Veiller à ce que les composants ainsi que les outils que l'on utilise soient également à ce potentiel.

**D WARNUNG**

Alle ICs und viele andere Halbleiter sind empfindlich gegenüber elektrostatischen Entladungen (ESD).

Unvorsichtige Behandlung im Reparaturfall kann die Lebensdauer drastisch reduzieren.

Veranlassen Sie, dass Sie im Reparaturfall über ein Pulsarmband mit Widerstand verbunden sind mit dem gleichen Potential wie die Masse des Gerätes.

Bauteile und Hilfsmittel auch auf dieses gleiche Potential halten.

**I AVVERTIMENTO**

Tutti IC e parecchi semi-conduttori sono sensibili alle scariche statiche (ESD).


La loro longevità potrebbe essere fortemente ridatta in caso di non osservazione della più grande cauzione alla loro manipolazione.

Durante le riparazioni occorre quindi essere collegato allo stesso potenziale che quello della massa dell'apparecchio tramite un braccialetto a resistenza.

Assicurarsi che i componenti e anche gli utensili con quali si lavora siano anche a questo potenziale.


**GB**

Safety regulations require that the set be restored to its original condition and that parts which are identical with those specified, be used

Safety components are marked by the symbol .


**NL**

Veiligheidsbepalingen vereisen, dat het apparaat bij reparatie in zijn oorspronkelijke toestand wordt teruggebracht en dat onderdelen, identiek aan de gespecificeerde, worden toegepast.

De Veiligheidsonderdelen zijn aangeduid met het symbool .

**F**

Les normes de sécurité exigent que l'appareil soit remis à l'état d'origine et que soient utilisées les pièces de rechange identiques à celles spécifiées.

Les composants de sécurité sont marqués .

**D**

Bei jeder Reparatur sind die geltenden Sicherheitsvorschriften zu beachten. Der Originalzustand des Geräts darf nicht verändert werden; für Reparaturen sind Original-Ersatzteile zu verwenden.

Sicherheitsbauteile sind durch das Symbol  markiert.

**I**

Le norme di sicurezza esigono che l'apparecchio venga rimesso nelle condizioni originali e che siano utilizzati i pezzi di ricambio identici a quelli specificati.

Componenti di sicurezza sono marcati con .

**GB**

After servicing and before returning set to customer perform a leakage current measurement test from all exposed metal parts to earth ground to assure no shock hazard exist. The leakage current must not exceed 0.5mA.

**GB Warning !**

Invisible laser radiation when open.  
Avoid direct exposure to beam.

**S Varning !**

Osynlig laserstrålning när apparaten är öppnad och spärren är urkopplad. Betrakta ej strålen.

**SF Varoitus !**

Avatussa laitteessa ja suojalukituksen ohitettaessa olet alttiina näkymättömälle laserisäteilylle. Älä katso säteeseen!


**DK Advarse !**

Usynlig laserstråling ved åbning når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

**F**

"Pour votre sécurité, ces documents doivent être utilisés par des spécialistes agréés, seuls habilités à réparer votre appareil en panne".

## Preparations



### Rear connections

The type plate is located at the rear of the system.

#### (A) Power

Before connecting the AC power cord to the wall outlet, ensure that all other connections have been made.

— If your system is equipped with a Voltage Selector, set the VOLTAGE SELECTOR to the local power line voltage.

#### WARNING!


- For optimal performance, use only the original power cable.
- Never make or change any connections with the power switched on.

To avoid overheating of the system, a safety circuit has been built in. Therefore, your system may switch to Standby mode automatically under extreme conditions. If this happens, let the system cool down before reusing it (not available for all versions).

### (B) Antennas Connection


Connect the supplied MW loop antenna and FM antenna to the respective terminals. Adjust the position of the antenna for optimal reception.

#### MW Antenna



Position the antenna as far as possible from a TV, VCR or other radiation source.

### FM Antenna



For better FM stereo reception, connect an outdoor FM antenna to the FM AERIAL (FM ANTENNA) terminal.

#### (C) Speakers Connection

##### Front Speakers

Connect the speaker wires to the SPEAKERS terminals, right speaker to "RIGHT" and left speaker to "LEFT", colored (marked) wire to "+" and black (unmarked) wire to "—".



Fully insert the stripped portion of the speaker wire into the terminal as shown.

#### Notes:

- For optimal sound performance, use the supplied speakers.
- Do not connect more than one speaker to any one pair of + / — speaker terminals.
- Do not connect speakers with an impedance lower than the speakers supplied. Please refer to the SPECIFICATIONS section of this manual.

### Optional connection

The optional equipment and connecting cords are not supplied. Refer to the operating instructions of the connected equipment for details.

#### Connecting other equipment to your system

Connect the audio left and right OUT terminals of a TV, VCR, Laser Disc player, DVD player or CD Recorder to the AUX-IN terminals.

#### Note:


- If you are connecting equipment with a mono output (a single audio out terminal), connect it to the AUX left terminal. Alternatively, you can use a "single to double" cinch cable (the output sound still remain mono).

## PREPARATIONS AND CONTROLS

## Preparations


### Before using the remote control

- 1 Pull out the plastic protective sheet.
- 2 Select the source you wish to control by pressing one of the source select keys on the remote control (for example CD, TUNER).
- 3 Then select the desired function (for example ►II, ►I, ►, ►).



### Replacing battery (lithium CR2025) into the remote control

- 1 Pull out the knob (A) slightly to the left.
- 2 Pull out the battery compartment (B).
- 3 Replace a new battery and fully insert the battery compartment back to the original position.



#### CAUTION!

Batteries contain chemical substances, so they should be disposed off properly.

# PREPARATIONS AND CONTROLS

## Controls


### Controls on the system and remote control

- ① **STANDBY-ON/ ECO POWER**
  - switches the system on or to Eco Power standby.
- ② **Display**
  - shows the status of the system.
- ③ **OPEN • CLOSE ▲**
  - opens/ closes the CD door.
- ④ **IR**
  - remote sensor
- ⑤ **VOLUME (▲ / ▼) (+ / -)**
  - adjusts the volume level.
- ⑥ **CD Door**
- ⑦ **Mode Selection**
- ⑧ **SEARCH/TUNE (◀ / ▶)**
  - for TUNER ..... tunes to a station
  - for CD ..... fast searches back and forward within a track/ CD.
- ⑨ **STOP ■** ..... stops CD playback or erase a CD programme.
- ⑩ **PLAY ▶ II** ..... starts or interrupts playback.
- ⑪ **PRESET (◀ / ▶)**
  - for TUNER ..... selects a preset radio station.
  - for CD ..... skips to the beginning of a current track/ previous/ subsequent track

- ⑧ **DBB (Dynamic Bass Boost)**
  - enhances the bass.
- ⑨ **BAND**
  - selects a waveband.
- ⑩ **PROGRAM**
  - for CD ..... programmes tracks and reviews the programme.
  - for TUNER ..... programmes tuner stations.
- ⑪ **SOURCE**
  - selects the respective sound source for CD/ TUNER/ AUX.
- ⑫ **CLOCK SET**
  - sets the clock function.
  - views the clock.
- ⑬ **TIMER**
  - activates/ deactivates or sets the timer function
- ⑭ **SLEEP**
  - activates/deactivates or selects the sleeper time.
- ⑮ **DSC (Digital Sound Control)**
  - selects sound characteristics: ROCK/ JAZZ/ POP/ CLASSIC.

### Notes for remote control:

- First select the source you wish to control by pressing one of the source select keys on the remote control (for example CD, TUNER).
- Then select the desired function (for example ▶ II, ◀, ▶).



PREPARATIONS AND CONTROLS

**Important notes for users in the U.K.**

**Mains plug**  
This apparatus is fitted with an approved 13 Amp plug. To change a fuse in this type of plug proceed as follows:

1

Remove fuse cover and fuse.

2

Fix new fuse which should be a BS1362 5 Amp, A.S.T.A. or BSI approved type.

3

Refit the fuse cover:

If the fitted plug is not suitable for your socket outlets, it should be cut off and an appropriate plug fitted in its place.

If the mains plug contains a fuse, this should have a value of 5 Amp. If a plug without a fuse is used, the fuse at the distribution board should not be greater than 5 Amp.

**Note:** *The severed plug must be disposed of to avoid a possible shock hazard should it be inserted into a 13 Amp socket elsewhere.*

**How to connect a plug**  
The wires in the mains lead are coloured with the following code: blue = neutral (N), brown = live (L).

●

As these colours may not correspond with the colour markings identifying the terminals in your plug, proceed as follows:

- Connect the blue wire to the terminal marked N or coloured black.
- Connect the brown wire to the terminal marked L or coloured red.
- Do not connect either wire to the earth terminal in the plug, marked E (or  $\text{⏏}$ ) or coloured green (or green and yellow).

Before replacing the plug cover, make certain that the cord grip is clamped over the sheath of the lead - not simply over the two wires.

**Copyright in the U.K.**  
Recording and playback of material may require consent. See Copyright Act 1956 and The Performer's Protection Acts 1958 to 1972.

**Italia**

**DICHIARAZIONE DI CONFORMITA'**  
Si dichiara che l'apparecchio MC230, MC235 Philips risponde alle prescrizioni dell'art. 2 comma 1 del D.M. 28 Agosto 1995 n. 548.  
Fatto a Eindhoven

Philips Consumer Electronics  
Philips, Glaslaan 2  
5616 JB Eindhoven, The Netherlands

**Norge**

Typeskilt finnes på apparatens underside.

**Observer:** *Nettbryteren er sekundert innkoplet. Den innebygde nettdelen er derfor ikke frakoplet nettet så lenge apparatet er tilsluttet nettkontaktene.*

For å redusere faren for brann eller elektrisk støt, skal apparatet ikke utsettes for regn eller fuktighet.

**CAUTION**  
*Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.*

**VAROITUS**  
*Muiden kuin tässä esitettyjen toimintojen säädön tai asetusten muutto saattaa altistaa vaaralliselle säteilylle tai muille vaarallisille toiminnoille.*

**WARNING**  
Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair. If you are unable to remedy a problem by following these hints, consult your dealer or Philips for help.

Problem	Solution
<b>CD OPERATION</b> "NO DISC" is displayed.	<ul style="list-style-type: none"><li>- Insert a disc.</li><li>- Check if the disc is inserted upside down.</li><li>- Wait until the moisture condensation at the lens has cleared.</li><li>- Replace or clean the disc, see "Maintenance".</li><li>- Use a finalised CD-RW or CD-R.</li></ul>
<b>RADIO RECEPTION</b> Radio reception is poor.	<ul style="list-style-type: none"><li>- If the signal is too weak, adjust the antenna or connect an external antenna for better reception.</li><li>- Increase the distance between the Micro HiFi System and your TV or VCR.</li></ul>
<b>GENERAL</b> The system does not react when buttons are pressed. Sound cannot be heard or is of poor quality. The left and right sound outputs are reversed. The remote control does not function properly. The timer is not working. The Clock/Timer setting is erased.	<ul style="list-style-type: none"><li>- Remove and reconnect the AC power plug and switch on the system again.</li><li>- Adjust the volume.</li><li>- Disconnect the headphones.</li><li>- Check that the speakers are connected correctly.</li><li>- Check if the stripped speaker wire is clamped.</li><li>- Check the speaker connections and location.</li><li>- Select the source (CD or TUNER, for example) before pressing the function button (▶■, ◀■, ▶I).</li><li>- Reduce the distance between the remote control and the system.</li><li>- Insert the battery with its polarities (+/- signs) aligned as indicated.</li><li>- Replace the battery.</li><li>- Point the remote control directly toward IR sensor on the front of the system.</li><li>- Set the clock correctly.</li><li>- Press TIMER to switch on the timer.</li><li>- Power has been interrupted or the power cord has been disconnected. Reset the clock/timer.</li></ul>

## DISMANTLING INSTRUCTIONS

### *Dismantling of the Rear Portion*

- 1) Remove 11 screws A and B as indicated to remove the Rear Cabinet.
- 2) Remove 2 screws C as indicated to loosen the Speaker Wire Holder.
- 3) Remove 2 screws D as indicated to loosen the Speaker Board .
- 4) Remove 2 screws E as indicated to loosen the AUX IN jack.




Figure 1




Figure 2

### *Dismantling of the Front Boards and CD Door*

- 1) Loosen 3 screws G each to remove the CD Mechanism Holder Bracket.
- 2) Loosen 7 screws F1 and F2 as indicated to remove the Main Board.
- 3) Remove 3 screws H as indicated to loosen the Gear Motor Module.
- 4) Loosen 4 screws I (see Figure 3) to remove the Key\_C Board.
- 5) Loosen 2 screws J (see Figure 3) to remove the Display Board.




Figure 3

- 6) Loosen 4 screws K (see Figure 3) to remove the Key\_B Board.
- 7) Loosen 8 screws L (see Figure 3) to remove the Key\_A Board.
- 8) Loosen 8 screws M (see Figure 3) to remove the Door Eject Lever Bracket Right/Left, then remove CD door.

## DISMANTLING INSTRUCTIONS

### *Repair Hints & Service Positions*

Note: The flex cables are very fragile, care should be taken not to damage them during repair. After repair, be very sure that the flex cables are inserted properly into the flex sockets before encasing, otherwise faults may occur.

#### Service position A



Figure 4

#### Service position B




Figure 5

#### Service position C





Figure 6

SERVICE TEST PROGRAM




Main Set Key	DISPLAY
STANDBY-ON	32
OPEN*CLOSE	29
SOURCE-	11
DBB	17
BAND	10
PROGRAM	14
▶▶	18
◀◀	19
PLAY	20
VOLUME+	24
VOLUME-	23
PREVIOUS(◀ )	12
NEXT (▶ )	13


Table 1

Note : In Key test mode, if a key on the remote control is pressed, the display shows its corresponding code in track area.

SET BLOCK DIAGRAM



SET WIRING DIAGRAM



---

# POWER BOARD


---

**TABLE OF CONTENTS**


Circuit Diagram .....6-2

PCB Layout .....6-3


CIRCUIT DIAGRAM



LAYOUT DIAGRAM - POWER BOARD  
COMPONENT SIDE



LAYOUT DIAGRAM - POWER BOARD  
SMD SIDE



---

# KEY BOARD

---

**TABLE OF CONTENTS**

Circuit Diagram ..... 8-2


Layout Diagram-Component ..... 8-3

Layout Diagram-SMD ..... 8-3


Layout Diagram-Component ..... 8-4

Layout Diagram-SMD ..... 8-4


## CIRCUIT DIAGRAM - FRONT BOARD




### LAYOUT DIAGRAM - KEY\_A BOARD COMPONENT SIDE




### LAYOUT DIAGRAM - KEY\_A BOARD SMD SIDE




### LAYOUT DIAGRAM - KEY\_B BOARD COMPONENT SIDE




### LAYOUT DIAGRAM - KEY\_B BOARD SMD SIDE



# LAYOUT DIAGRAM - KEY\_C BOARD COMPONENT SIDE



# LAYOUT DIAGRAM - KEY\_C BOARD SMD SIDE



MAIN BOARD

TABLE OF CONTENTS

IC Block Diagram.....8-1

Circuit Diagram-Main Part .....8-2

Component Layout - Main PCB .....8-3

SMD Layout - Main PCB .....8-4

Layout - Headphone PCB .....8-5

IC Block Diagram.....8-5

BLOCK DIAGRAM






Fig.1 Block diagram.





MODEL: MC230 (PLCC)  
MC230/22 MAIN PCB 94V0  
MC230/22/V1.5A



## HEADPHONE PCB - TOP LAYOUT



## HEADPHONE PCB - BOTTOM LAYOUT

FLASH MICROCONTROLLER  
P89C60X2/P89C61X2--BLOCK DIAGRAM

---

# DISPLAY BOARD

---

**TABLE OF CONTENTS**

Circuit Diagram ..... 9-2


Layout Diagram-Component ..... 9-3

Layout Diagram-SMD ..... 9-3

CIRCUIT DIAGRAM - DISPLAY BOARD

9-2

9-2




D

C


B

A

LAYOUT DIAGRAM - DISPLAY BOARD  
COMPONENT SIDE




LAYOUT DIAGRAM - DISPLAY BOARD  
SMD SIDE



EXPLODED DRAWING

10-1

10-1



MC230 SCREW LIST

72	SELF-TAPPING SCREW TB/KH 3x8 HD 5mm	2
71	HARDEN SCREW BTTB 3x8mm AB	9
69	HARDEN SCREW TT/PH 3x4	2
63	SELF-TAPPING SCREW TA/WH 3x10mm(H D:10mm)	4
61	MACHINE SCREW MS/KH 3x8mm HD 5mm	2
59	NUT ID:3 OD:5.5 T:2.3mm	2
51	SCREW TA/BWH 3x10mm (HD:12mm)	1
48	SELF-TAPPING SCREW TA/WH 3x12mm	2
43	HARDEN SCREW BTTB 3x12 AB	14
41	MACHINE SCREW MS/BH 3x4 mm	2
38	SELF-TAPPING SCREW TA/WH 2.6x6 mm	1
36	SELF-TAPPING SCREW TB/WH 3x6mm	1
28	HARDEN SCREW BTTB 2.6x8mm MC	19
19	HARDEN SCREW BTTB 2x8 MC	17
12	SELF-TAPPING SCREW TA/KH 2.6x8mm	8
5	SELF-TAPPING SCREW TA/KH 1.4x3.5 mm	6
ITEM	DESCRIPTION	QTY

**MECHANICAL & ACCESSORIES PARTSLIST**

001	9940 000 00303	CD DOOR LENS /22/25	031	9940 000 00243	AM/FM ANT ASS'Y /21/22/25/30
001	9940 000 00595	CD DOOR LENS /21/30	031	9940 000 00308	AM/FM ANT ASS'Y /37
001	9940 000 00599	CD DOOR LENS /37	△	9940 000 00512	AC CORD BS PLUG 2M /25
002	9940 000 00292	CD DOOR COVER -LEFT	△	9940 000 00593	AC CORD SAA APP 2M /30
003	9940 000 00293	CD DOOR COVER -RIGHT		9940 000 00246	REMOTE CONTROL UNIT
004	9940 000 00304	CONTROL PANEL LENS /22/25/37		9940 000 00247	SPEAKER BOX UNIT (LEFT)
004	9940 000 00596	CONTROL PANEL LENS /21/30		9940 000 00309	SPEAKER BOX UNIT (LEFT) /37
006	9940 000 00289	FRONT CABINET /22/25		9940 000 00248	SPEAKER BOX UNIT (RIGHT)
006	9940 000 00318	FRONT CABINET /37		9940 000 00311	SPEAKER BOX UNIT (RIGHT)/37
006	9940 000 00591	FRONT CABINET /21/30	△	9940 000 00282	AC CORD VDE APP 2M /21/22
007	9940 000 00305	SENSOR LENS	△	9940 000 00317	AC CORD CUL APP 6FT /37
008	9940 000 00297	POW CD OPEN BUTT /22/25			
008	9940 000 00321	POW CD OPEN BUTT /21/30/37			
009	9940 000 00298	VOL +/- BUTTON /22/25			
009	9940 000 00322	VOL +/- BUTTON /21/30/37			
011	9940 000 00279	CD MECHANISM TPP381			
012	9940 000 00287	SHOCK ABSORBER			
013	9940 000 00288	SHOCK ABSORBER			
014	9940 000 00302	FUNCTION BUTTON /22/25			
014	9940 000 00324	FUNCTION BUTTON /21/30/37			
016	9940 000 00299	FUNC BUTTON S/P /22/25			
016	9940 000 00323	FUNC BUTTON S/P /21/30/37			
017	9940 000 00589	DRIVE BELT (DIA:38X1MM)			
018	9940 000 00296	DRIVER PULLEY GEAR			
019	9940 000 00295	IDLER GEAR			
021	9940 000 00294	DRIVING GEAR			
022	9940 000 00286	MOTOR 5V			
023	△ 9940 000 00278	TRANSFORMER 230V /22/25			
023	△ 9940 000 00316	TRANSFORMER 120V /37			
023	△ 9940 000 00597	H/TRANSFORMER 120/230V /21			
023	△ 9940 000 00598	H/TRANSFORMER 240V /30			
024	9940 000 00284	RUBBER FOOT			
026	9940 000 00291	REAR CABINET /22/25/30			
026	9940 000 00319	REAR CABINET (94V2) /37			
026	9940 000 00592	REAR CABINET /21			
027	9940 000 00283	SPEAKER HOLDER			
028	9940 000 00307	SPEAKER WIRE HOLDER			
029	9940 000 00306	STAND UNIT			

**Note: Only these parts mentioned in the list are normal normal service parts.**

**ELECTRICAL PARTSLIST**

AUX	9940 000 00281	RCA JACK BD 2P	U601	9940 000 00366	IC TEA6321
CF1	9940 000 00245	BAND PASS FILTER	U602	9940 000 00249	IC (ROHM) BA4558F
D407	9940 000 00312	VARICAP DIODE /21/30/37	U603	9940 000 00367	IC (PHILIPS) TFA9842J
D408	9940 000 00312	VARICAP DIODE /21/30/37	VC402	9940 000 00314	TRIMMER 10PF 6MM
FS300	9940 000 00588	GLASS FUSE T800MA/250V/21	VC403	9940 000 00254	TRIMMER 10PF 6MM (WH)
FS301	△ 9940 000 00258	CERAMIC FUSE /22/25/37	VR401	9940 000 00313	SEMI FIXED VRB100K 6MM
FS301	△ 9940 000 00585	CERAMIC FUSE 2A/250V /21/30	X201	9940 000 00255	CER RESONATOR 8.4672MHz
FS302	△ 9940 000 00259	CERAMIC FUSE /22/25/37		9940 000 00587	SWITCH /21M
FS302	△ 9940 000 00586	GLASS FUSE 3.15A/250V /21/30			
FS303	△ 9940 000 00263	SUBMINIATURE FUSE 100MA/250V			
IC1	9940 000 00277	IC (LIBERAL) LM78L05			
JK401	9940 000 00275	RCA PIN JACK #RCA-125			
JK601	9940 000 00257	PHONE JACK MSJ-2000(ST)			
JK602	9940 000 00276	SPK JACK (R/B/R/B)			
LCD501	9940 000 00268	LCD DISPLAY			
LED501	9940 000 00266	LED LAMP 3MM (BLUE)			
LED502	9940 000 00267	LED LAMP 5MM (BLUE)			
LED503	9940 000 00265	LED LAMP (MICRO)			
RF1	9940 000 00256	TUNER (MITSUMI) FE450-G01			
RL301	9940 000 00264	RELAY			
S501	9940 000 00274	TACT SWITCH TSA-064301-100			
S502	9940 000 00274	TACT SWITCH TSA-064301-100			
S503	9940 000 00274	TACT SWITCH TSA-064301-100			
S504	9940 000 00274	TACT SWITCH TSA-064301-100			
S505	9940 000 00274	TACT SWITCH TSA-064301-100			
S506	9940 000 00274	TACT SWITCH TSA-064301-100			
S507	9940 000 00274	TACT SWITCH TSA-064301-100			
S508	9940 000 00274	TACT SWITCH TSA-064301-100			
S509	9940 000 00274	TACT SWITCH TSA-064301-100			
S510	9940 000 00274	TACT SWITCH TSA-064301-100			
S511	9940 000 00274	TACT SWITCH TSA-064301-100			
S512	9940 000 00274	TACT SWITCH TSA-064301-100			
S513	9940 000 00274	TACT SWITCH TSA-064301-100			
S514	9940 000 00274	TACT SWITCH TSA-064301-100			
SR501	9940 000 00272	OPTIC SENSOR /22			
SR501	9940 000 00325	OPTIC SENSER /21/30/37			
SW601	9940 000 00273	MICRO SWITCH 1120B			
SW602	9940 000 00273	MICRO SWITCH 1120B			
T302	△ 9940 000 00262	TRANSF. EI-28 AC230V /22/25			
U101	9940 000 00253	IC (SAMSUNG) KA7808			
U102	9940 000 00244	IC P89C60X2BBD /22/25			
U102	9940 000 00368	IC P87C58X2BBD /21/30/37			
U103	9940 000 00251	IC (ROHM) BR24L04			
U201	9940 000 00365	IC (PHILIPS) SAA7379HL CD-18			
U202	9940 000 00252	IC MOTOR DRIVER D9259			
U301	9940 000 00261	IC (LIBERAL) LM78L05			
U401	9351 772 20557	IC SM TEA5762H/V1 (PHSE) Y			
U501	9940 000 00269	IC ET1621 COB LCD DRIVER			

**Note: Only these parts mentioned in the list are normal normal service parts.**