



■ Self-Diagnostic Display Function

■ Self-diagnostic display

This unit is equipped with a self-diagnostic display function which, if a problem occurs, will display an error code corresponding to the problem.

Use this function when performing maintenance on the unit.

■ How to enter the Self-Diagnostic Function



■ Cassette Mechanism Test (For error code H01, H02, H03, F01, F02)

1. Press "TAPE, DECK 1/2" to select Deck 2.
2. Load a cassette tape with the erasure prevention tab, remove from left side only and close the cassette holder.
3. Press "▶▶▶▶ MEMORY" (Tape will be stop after 2 seconds).
4. Load a cassette tape with the erasure prevention tab, remove from right side only and close the cassette holder.
5. Press "◀◀◀◀ FM MODE/BP" (Tape will be stop after 2 seconds).
6. Load a pre-recorded tape with both side record tabs intact and close the cassette holder.
7. Press "▶ TUNE/TIME ADJ ^" (After TPS function, tape will stop automatically).
8. Press "•REC/STOP" (Tape will not move).
9. Press "■ TUNING MODE" to indicate Error code.
 - If several problem exist, error code will change each time when "■ TUNING MODE" is pressed. (e.g. H01 H03 F01 etc.)
10. Press "TAPE, DECK 1/2" to select Deck 1.
11. Repeat step 2 to 9 to test Deck 1. (Tape Deck 1 will not check H02 because of no recording function)

■ CD Mechanism Test (F15, F16, F25 ~ F28, F75)

1. Press "CD".
2. Press "NEXT OPEN".
3. Press "■ TUNING MODE" to indicate Error Code.
 - If several problem exist, error code will change each time when "■ TUNING MODE" is pressed. (e.g. F15 F16 F25 etc.)

■ To clear all Error code

1. Press "■ TUNING MODE" button for 5 seconds.
2. FL indicator shows "CLEAR" for 1 second and change to "T".

■ How to get out from Self-Diagnostic function

1. Press "POWER" button OFF.

■ Power Amplifier Failure (F61)

1. When power amplifier fail, F61 will indicate automatically.

■ Description of Error Code

(1) Error detection for Cassette Mechanism block

No.	Error	Error Display	Problem condition
1	MODE SW detection error	H01	Faulty operation of cassette mechanism. Faulty contact or short-circuit of mechanism mode switch (S951, S971).
2	REC INH SW detection error	H02	Recording not possible. Faulty contact or short-circuit of REC INH switch (S974, S975).
3	HALF SW detection error	H03	Playback can not perform. Faulty contact or short-circuit of HALF switch (S952, S972).
4	Reel Pulse detection error	F01	The tape advances slightly and then stops. Faulty reel pulse, faulty hole detect IC (IC951, IC971).
5	TPS abnormal	F02	Cassette deck will not perform TPS function. Faulty playback EQ/recording amplifier IC (IC101).

(2) Error detection for CD/Changer block

No.	Error	Error Display	Problem condition
1	REST SW detection error	F15	CD does not function. This error occurs when the Optical Pick Up REST SW (S701) is not detected within the specified time (about 8 seconds)
2	Transmission error between CD servo LSI and micon	F26	CD does not function. This error occurs when the POWER is ON for the CD block and an error is detected after the transmission has started.
3	CD power error	F75	CD does not function. Check if CDRST is H for SELECTOR at CD. If it is not H after 1 second, it shall be memorised as an error. (IC702)



(3) Power Supply related error detection

No.	Error	Error Display	Problem condition
1	POWER AMP output abnormal	F61	When POWER is switched on, power become off automatically. During normal operation, if DC DET become L, PCNT shall become L and the error display on the left shall be displayed. (IC501)

■ CD Test Mode Function

This CD test mode is provided to check CD unit without connecting to changer loading mechanism. This mode shall operate CD PLAY with CD unit being connected only and CD Automatic Alignment result is shown on FL display.

■ How to set CD test mode



■ CD Automatic Alignment result indication

This function provided indication of error code as the result of Automatic Alignment of CD (Tracking, Focus, Offset, etc.). Based on these error codes, the faulty area can be located .

■ Error code Explanation

- The unit is satisfactory if the error code is E00
- Before testing, make sure that the test disc is free of scratches, dirt and that the optical pick up lens is clean.

Error code	E00	E01	E02	E03	E04	E05	E06	E07	E08	E09	E0A	E0B	E0C	E0D	E0E	E0F
Focus offset	○	✖	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Tracking offset	○	✖	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Focus Gain (Rough)	○	✖	○	○	○	○	○	○	○	○	○	○	○	○	○	○
Tracking Gain(Rough)	○	-	○	✖	○	✖	○	✖	○	✖	○	✖	○	✖	○	✖
Tracking balance	○	-	✖	✖	○	○	✖	✖	○	○	✖	✖	○	○	✖	✖
Focus balance	○	-	○	○	✖	✖	✖	✖	○	○	○	○	✖	✖	✖	✖
Tracking or Focus Gain (Fine)	○	-	○	○	○	○	○	○	✖	✖	✖	✖	✖	✖	✖	✖

○ Satisfy

✖ Fault

✖ Fault either items)