

TROUBLESHOOTING

NOTICE:

When replacing the internal mechanism (computer part) of the audio system, be careful that no part of your body or clothing comes in contact with the terminals of the leads from the IC, etc. of the replacement part (spare part).

HINT:


This inspection procedure is a simple troubleshooting which should be carried out on the vehicle during system operation and was prepared on the assumption of system component troubles (except for the wires and connectors, etc.).

Always inspect the trouble taking the following items into consideration.


- Open or short circuit of the wire harness
- Connector or terminal connection fault

	Problem	No.
Radio	No power coming in.	1
	Power coming in, but radio not operating.	2
	Noise present, but AM – FM not operating.	3
	Either speaker does not work.	4
	Either AM or FM does not work.	5
	Reception poor (Volume faint).	5
	Few preset tuning bands.	5
	Sound quality poor.	6
	Cannot set station select button.	7
	Preset memory disappears.	7
Tape Player	Cassette tape cannot be inserted.	8
	Cassette tape inserts, but no power.	9
	Power coming in, but tape player not operating.	10
	Either speaker does not work.	11
	Sound quality poor (Volume faint).	12
	Tape jammed, malfunction with tape speed or auto–reverse.	13
	Cassette tape will not eject.	14
CD Player	CD cannot be inserted.	15
	CD inserts, but no power.	16
	Power coming in, but CD player not operating.	17
	Sound jumps.	18
	Sound quality poor (Volume faint).	19
	Either speaker does not work.	20
	CD will not eject.	21
Amplifier	No power coming in.	22
	Either speaker does not work.	23
Noise	Noise produced by vibration or shock while driving.	24
	Noise produced when engine starts.	25
	Noise occurs	26


1	Radio	NO POWER COMING IN
----------	--------------	---------------------------



2	Radio	POWER COMING IN, BUT RADIO NOT OPERATING
----------	--------------	---




3	Radio	NOISE PRESENT, BUT AM-FM NOT OPERATING
----------	--------------	---




V06272


4	Radio	EITHER SPEAKER DOES NOT WORK
----------	--------------	-------------------------------------




5	Radio	EITHER AM OR FM DOES NOT WORK, RECEPTION POOR (VOLUME FAINT), FEW PRESET TUNING BANDS
----------	--------------	--




6	Radio	SOUND QUALITY POOR
----------	--------------	---------------------------




6-A.




7	Radio	CANNOT SET STATION SELECT BUTTON, PRESET MEMORY DISAPPEARS
----------	--------------	---




8	Tape Player	CASSETTE TAPE CANNOT BE INSERTED
----------	--------------------	---




9	Tape Player	CASSETTE TAPE INSERTS, BUT NO POWER
----------	--------------------	--




10	Tape Player	POWER COMING IN, BUT TAPE PLAYER NOT OPERATING
-----------	--------------------	---




11	Tape Player	EITHER SPEAKER DOES NOT WORK
----	-------------	-------------------------------------




12	Tape Player	SOUND QUALITY POOR (VOLUME FAINT)
-----------	--------------------	--




13	Tape Player	TAPE JAMMED, MALFUNCTION WITH TAPE SPEED OR AUTO-REVERSE
-----------	--------------------	---




14	Tape Player	CASSETTE TAPE WILL NOT EJECT
-----------	--------------------	-------------------------------------




15	CD Player	CD CANNOT BE INSERTED
-----------	------------------	------------------------------




16	CD Player	CD INSERTS, BUT NO POWER
-----------	------------------	---------------------------------




17	CD Player	POWER COMING IN, BUT PLAYER NOT OPERATING
-----------	------------------	--




17-A.




17-B.




18	CD Player	SOUND JUMPS
-----------	------------------	--------------------




19	CD Player	SOUND QUALITY POOR (VOLUME FAINT)
----	-----------	-----------------------------------




20	CD Player	EITHER SPEAKER DOES NOT WORK
-----------	------------------	-------------------------------------




20-A



21	CD Player	CD WILL NOT EJECT
-----------	------------------	--------------------------




22	Amplifier	NO POWER COMING IN
-----------	------------------	---------------------------




V06285

23	Amplifier	EITHER SPEAKER DOES NOT WORK
-----------	------------------	-------------------------------------



24	Noise	NOISE PRODUCED BY VIBRATION OR SHOCK WHILE DRIVING
-----------	--------------	---



25	Noise	NOISE PRODUCED WHEN ENGINE STARTS
-----------	--------------	--

