



SLIDING ROOF ON-VEHICLE INSPECTION

B000X-01

INSPECT SLIDING ROOF GLASS ALIGNMENT

- (a) Start the engine and check the operation time of the sliding roof.

Operation Time: Approx. 5 sec.

- (b) Check for abnormal noise or binding during operation.
(c) With the sliding roof fully closed, check for water leakage.
(d) Check for a difference in level between the sliding roof weatherstrip and roof panel.

Front End:

-0.5 ± 1.5 mm (-0.020 ± 0.059 in.)

Center Line:

0 ± 1.5 mm (0 ± 0.059 in.)

Rear End:

0.5 ± 1.5 mm (0.020 ± 0.059 in.)