


INSPECTION

1. INSPECT RHEOSTAT LIGHT CONTROL VOLUME OPERATION

Connect the positive (+) lead from the battery to terminal 4 and negative (-) lead to terminal 9, and check that the warning light lights up.

If operation is not as specified, replace the rheostat light control volume.

2. INSPECT RHEOSTAT LIGHT CONTROL VOLUME CIRCUIT (See page BE-62)




3. INSPECT HORN OPERATION

Connect positive (+) lead to terminal 1 and negative (-) lead to terminal 2 of theft deterrent horn connector, and that the theft deterrent horn blows.

If operation is not as specified, replace the horn.

4. INSPECT HORN CIRCUIT (See page DI-717)




5. LUGGAGE COMPARTMENT DOOR KEY LOCK AND UNLOCK SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
Not turned	-	No continuity
UNLOCK	1 - 2	Continuity

If continuity is not as specified, replace the switch.

If continuity is as specified, inspect the switch circuit.

6. LUGGAGE COMPARTMENT DOOR KEY LOCK AND UNLOCK SWITCH CIRCUIT (See page DI-711)

**7. ENGINE HOOD COURTESY SWITCH CONTINUITY**

Switch position	Tester connection	Specified condition
LOCK	-	No continuity
UNLOCK	1 - 2	Continuity

If continuity is not as specified, replace the switch.

If continuity is as specified, inspect the switch circuit.

8. ENGINE HOOD COURTESY SWITCH CIRCUIT
(See page [DI-707](#))