

## INSTALLATION

### NOTICE:

- Never use SRS parts from another vehicle. When replacing parts, replace them with new ones.
- Never reuse the side airbag sensor assembly involved in a collision when the airbag has deployed.
- Never repair a sensor in order to reuse it.

### 1. INSTALL SIDE AIRBAG SENSOR

- (a) Using a torx wrench, install the side airbag assembly with 3 screws.

**Torx wrench: T40 (Part No.09042-00020 or locally manufactured tool)**

**Torque: 21 N·m (210 kgf·cm, 15 ft·lbf)**

- (b) Connect the side airbag sensor connector.

### NOTICE:

- Installation of the connector is done with the sensor assembly installed. Make sure the sensor assembly is installed with the specified torque.
- If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.
- When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.
- After installation, shake the sensor assembly to check that there is no looseness.

### 2. INSTALL FRONT SEAT OUTER BELT RETRACTOR (See page [BO-126](#))


- (a) Install the retractor with 2 bolts.

**Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)**

**Upper bolt: 7.4 N·m (75 kgf·cm, 65 in.-lbf)**

**Lower bolt: 41 N·m (420 kgf·cm, 30 ft·lbf)**

- (b) Connect the retractor switch connector.



H02184

- (c) Connect the pretensioner connector.

### 3. INSTALL THESE PARTS:

- (a) Center pillar lower garnish  
(b) Front door scuff plate  
(c) Rear door scuff plate