



REMOVAL

1. REMOVE OIL PAN PROTECTOR
2. REMOVE ENGINE UNDER COVER
3. DISCONNECT CRANKSHAFT POSITION SENSOR CONNECTOR
4. REMOVE CRANKSHAFT POSITION SENSOR

Remove the bolt and crankshaft position sensor.

Torque: 6.5 N·m (65 kgf·cm, 58 in.-lbf)