



REMOVAL

1. REMOVE V-BANK COVER
2. REMOVE BATTERY CLAMP COVER
3. REMOVE AIR CLEANER INLET
4. DRAIN ENGINE COOLANT (See page [CO-2](#))
5. DISCONNECT RADIATOR HOSE
6. REMOVE NO.3 TIMING BELT COVER
(See page [EM-15](#))
7. DISCONNECT CAMSHAFT POSITION SENSOR CONNECTOR
8. REMOVE CAMSHAFT POSITION SENSOR
Remove the bolt, stud bolt and camshaft position sensor.