



ADJUSTMENT

ADJUST FRONT SEAT ADJUSTER

- (a) Adjust the seat track screw shaft.
Fully hand-tighten the screw shafts of the outer and inner seat tracks.
- (b) Adjust the front vertical sub-assembly.
Align the match marks of outer and inner front vertical sub-assemblies.