



## INSPECTION

### INSPECT FUEL TANK AND LINE

- (a) Inspect the fuel lines and connections for cracks, leakage or deformation.
- (b) Inspect the fuel tank vapor vent system hoses and connections for looseness, kinks or damage.
- (c) Inspect the fuel tank for deformation, cracks, fuel leakage or tank band looseness.
- (d) Check the filter neck for damage or fuel leakage.
- (e) Hose and tube connections are as shown in the illustration.

If the problem is found, repair or replace the parts as necessary.

