

INSPECTION

1. INSPECT AIR INLET SERVOMOTOR CIRCUIT
(See page [DI-982](#))
2. INSPECT AIR INLET DAMPER POSITION SENSOR CIRCUIT
(See page [DI-982](#))
3. INSPECT AIR MIX SERVOMOTOR CIRCUIT
(See page [DI-997](#))
4. INSPECT AIR MIX DAMPER POSITION SENSOR CIRCUIT
(See page [DI-997](#))
5. COOL AIR BYPASS DAMPER CONTROL SERVOMOTOR CIRCUIT
Driver Side: (See page [DI-985](#))
Passenger Side: (See page [DI-988](#))
6. INSPECT AIR OUTLET SERVOMOTOR CIRCUIT
(See page [DI-991](#))
7. INSPECT AIR OUTLET DAMPER POSITION SENSOR CIRCUIT
(See page [DI-994](#))
8. INSPECT WATER VALVE CONTROL SERVOMOTOR CIRCUIT
(See page [DI-991](#))