


FRONT WHEEL HUB BOLT REPLACEMENT


1. REMOVE FRONT WHEEL
2. REMOVE BRAKE CALIPER AND DISC
 - (a) Place matchmarks on the disc and axle hub.
 - (b) Remove the 2 bolts and brake caliper.
 - (c) Support the brake caliper securely.
 - (d) Remove the 2 screws and disc.



3. REMOVE HUB BOLT

Using SST, remove hub bolt.

SST 09628-10011



4. INSTALL HUB BOLT

Install washer and nut to the hub bolt as shown in the illustration, and install the hub bolt with torquing the nut.

5. INSTALL DISC AND BRAKE CALIPER

- (a) Align the matchmarks on the axle hub and disc.
- (b) Install the disc and 2 screws.

Torque: 5.0 N·m (55 kgf·cm, 48 in.-lbf)

- (c) Install the brake caliper and 2 bolts.

Torque: 118 N·m (1,200 kgf·cm, 87 ft·lbf)

6. INSTALL FRONT WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)