



CIRCUIT


1. WIRING DIAGRAMS




Connector "A"





Connector "B"




Connector "C"



BODY ELECTRICAL - COMBINATION METER




Circuit Plate




I03269


2. CONNECTOR DIAGRAMS



BODY ELECTRICAL - COMBINATION METER




I03273



103270

BODY ELECTRICAL - COMBINATION METER



I03271

No.	Wire Harness Side (terminal name or HINT)	No.	Wire Harness Side (terminal name or HINT)
A	1 ODO/TRIP switch	E	1 Headlight or Taillight Warning Light
	2 TRIP RESET switch		2 Tachometer (SIN-)
	5 Light Control Rheostat (TC)		3 Tachometer (SIN+)
	6 Light Control Rheostat (TR)		4 Tachometer (COS-)
	8 Passenger seat belt warning		5 Tachometer (COS+)
12 ODO/TRIP switch (Ground)	6 TRAC Warning Light		
B	1 GAUGE Fuse		7 Window Washer Level Warning Light
	3 Igniter		8 Multifunction Indicator Light
	4 Steering switch		9 DIM+ terminal
	5 Fuel Sender Gauge (FE)		10 TRAC OFF Warning Light
	6 Signal Earth		11 ABS Warning Light
	7 DOME Fuse		12 DIM- terminal
	8 MPX-B Fuse		13 HEIGHT HI Indicator Light
	9 Light Failure Relay		14 ECT SNOW Indicator Light
	10 Speed Control Unit		16 ECT PWR Indicator Light
	11 ABS, TRAC and VSC ECU (SPDM)		17 Engine Coolant Temperature Receiver Gauge (SIN+)
	12 Fuel Sender Gauge (FR)		18 Engine Coolant Temperature Receiver Gauge (COS-)
13 Fuel Sender Gauge (FV)	19 Engine Coolant Temperature Receiver Gauge (COS+)		
15 Headlight Leveling Control ECU	20 Engine Coolant Temperature Receiver Gauge (SIN-)		
16 Body Ground	F		1 Speedometer (SIN-)
C		1 ABS, TRAC and VSC ECU (TRAC)	2 Speedometer (SIN+)
		2 Turn Signal Switch (Left)	3 Speedometer (COS-)
		3 Headlights	4 Speedometer (COS+)
		4 Headlight Dimmer Switch	5 A/T Shift Indicator Light (2)
		5 Turn Signal Switch (Right)	6 A/T Shift Indicator Light (L)
		6 ECM	7 A/T Shift Indicator Light (3)
		7 AIRSUS ECU	8 A/T Shift Indicator Light (4)
		8 ABS, TRAC and VSC ECU (TRAC OFF)	9 A/T Shift Indicator Light (D)
		9 ABS, TRAC and VSC ECU (ABS)	10 A/T Shift Indicator Light (N)
		10 Airbag Sensor Assembly	11 A/T Shift Indicator Light (R)
		11 Low Oil Pressure Warning Switch	12 A/T Shift Indicator Light (P)
		12 Multiplex Communication Circuit (MPX1)	14 DOME-B terminal
	13 Multiplex Communication Circuit (MPX2)	15 Hi-Beam Indicator Light (+)	
	14 Window Washer Level Warning Switch	16 Hi-Beam Indicator Light (-)	
	15 ABS, TRAC and VSC ECU (VSC)	17 Right Turn Indicator Light	
	16 Light Failure Relay	18 Turn Indicator Light (-)	
	17 Brake Fluid Level Warning Switch	19 Left Turn Indicator Light (-)	
	18 Brake Pad Sensor	20 Front Fog Light Indicator Light	

BODY ELECTRICAL - COMBINATION METER

No.	Wire Harness Side (terminal name or HINT)	No.	Wire Harness Side (terminal name or HINT)	
G	1 Fuel Receiver Gauge (SIN-)	J	1 Speedometer Needle (FXG)	
	2 Fuel Receiver Gauge (SIN+)		2 Speedometer Needle (FXG)	
	3 Fuel Receiver Gauge (COS-)	K	1 Tachometer Needle (FXG)	
	4 Fuel Receiver Gauge (COS+)		2 Tachometer Needle (FXG)	
	5 CRUISE MAIN Indicator Light	L	1 Fuel Receiver Gauge Needle (FXG)	
	6 Discharge Warning Light		2 Fuel Receiver Gauge Needle (FXG)	
	7 Seat Belt Warning Light	M	1 Engine Coolant Temperature Receiver Gauge Needle (FXG)	
	8 Fuel Level Warning Light		2 Engine Coolant Temperature Receiver Gauge Needle (FXG)	
	9 Open Door Warning Light	O	1 LED+ terminal	
	11 DOME-B terminal		2 LED- terminal	
	13 Airbag Warning Light		3 HEAT- terminal	
	14 Airbag Warning terminal (+)		4 TH- terminal	
	15 Brake Fluid Level Warning Light		5 TH+ terminal	
	16 IG+ terminal		6 LCDTH- terminal	
	17 IG+ terminal		7 LCDTH+ terminal	
			8 HEAT+ terminal	
			12 C/C terminal	
	16 C/C terminal			
H	1 Multi Information Display and ODO/TRIP Display (VDISP)	P	1 HEAT+ terminal	
	2 Multi Information Display and ODO/TRIP Display (5V IG)		2 TH21 terminal	
	3 Multi Information Display and ODO/TRIP Display (BLK)		3 TH22 terminal	
	4 Multi Information Display and ODO/TRIP Display (POR)		5 C/C (TA) terminal	
	5 Multi Information Display and ODO/TRIP Display (SCK)		7 C/C (TA) terminal	
	6 Multi Information Display and ODO/TRIP Display (SI)		9 HEAT- terminal	
	7 Multi Information Display and ODO/TRIP Display (A/D)		Q	1 HEAT+ terminal
	8 Multi Information Display and ODO/TRIP Display (LATCH)			3 C/C (SP) terminal
	9 Multi Information Display and ODO/TRIP Display (PTC)			5 C/C (SP) terminal
	10 Multi Information Display and ODO/TRIP Display (BLKOD)	7 HEAT- terminal		
	11 Multi Information Display and ODO/TRIP Display (LAT)	W	1 FCC11V terminal	
	12 Multi Information Display and ODO/TRIP Display (CLK)		2 FXG11V terminal	
	13 Multi Information Display and ODO/TRIP Display (DIN)		3 FCC+ terminal	
14 Multi Information Display and ODO/TRIP Display (CLIN)	4 FXG+ terminal			
15 Ground	5 FCC DIM terminal			
16 Ground	8 C/C C terminal			
17 Ground	9 C/C DIM terminal			
18 Ground	10 C/C M terminal			
19 Ground	11 TH terminal			
20 Ground	12 E1 terminal			

No.	Wire Harness Side
X	1 HEAT+ terminal 2 THLCD+ terminal 3 C/C+ terminal 4 THLCD- terminal 5 HEAT- terminal 8 SW d+B terminal 9 9.1 V terminal 10 LED- terminal 11 E2 terminal 12 E2 terminal
W	1 FCC11V terminal 2 FXG11V terminal 3 FCC+ terminal 4 FXG+ terminal 5 FCC DIM terminal 8 C/C C terminal 9 C/C DIM terminal 10 C/C M terminal 11 TH terminal 12 E1 terminal
Z	1 HEAT+ terminal 2 THLCD+ terminal 3 C/C+ terminal 4 THLCD- terminal 5 HEAT- terminal 8 SW d+B terminal 9 9.1 V terminal 10 LED- terminal 11 E2 terminal 12 E2 terminal