

INSTALLATION

Installation is in the reverse order of removal (See page [SA-46](#)).

AFTER INSTALLATION, CHECK ABS SPEED SENSOR SIGNAL (See page [DI-307](#)) AND FRONT WHEEL ALIGNMENT (See page [SA-5](#))