



## INSTALLATION

### 1. CHECK TORQUE CONVERTER CLUTCH INSTALLATION

Using calipers and a straight edge, measure from the installed surface of the torque converter clutch to the front surface of the transmission housing.

**Correct distance: More than 17.1 mm (0.673 in.)**

If the distance is less than the standard, check for an improper installation.

### 2. INSTALL TRANSMISSION

Installation is in the reverse order of removal.

(See page [AT-17](#))

HINT:

After installation, check and inspect items as follows.

- Adjust the shift lever position. (See page [DI-173](#))
- Check fluid level. (See page [DI-173](#))
- Do the road test. (See page [DI-173](#))