

REPLACEMENT

REPLACEMENT REQUIREMENT

In the following cases, replace the side airbag sensor assembly.

- If the side airbag sensor assembly has been deployed in a collision.
- If the side airbag sensor assembly has been found to be faulty in troubleshooting.
- If the side airbag sensor assembly has been dropped.

CAUTION:

For removal and installation of the side airbag sensor assembly, see page [RS-59](#) and [RS-62](#).

Be sure to follow the correct procedure.