



INSPECTION

INSPECTION TRANSPONDER KEY COIL CONTINUITY

Check that there is continuity between terminal 1 and 2.

If continuity is not as specified, replace the coil.