



INSPECTION

INSPECT OIL CONTROL VALVE OPERATION

Connect positive \oplus lead to terminal 1 of connector and negative \ominus lead to terminal 2, then check the movement of the valve.

When battery positive voltage is applied.	Valve moves in  direction.
When battery positive voltage is cut off.	Valve moves in  direction.

If operation is not as specified, replace the oil control valve.