

DISASSEMBLY

1. REMOVE DOOR LOCK

- (a) Disconnect the control link.
- (b) Remove the 2 bolts and lock.

Torque: 5.5 N·m (56 kgf·cm, 49 in.-lbf)

2. REMOVE KEY CYLINDER

Remove the 2 bolts and key cylinder.

Torque: 5.5 N·m (56 kgf·cm, 49 in.-lbf)

3. REMOVE THESE PARTS:

- (a) Rear lamp assembly
- (b) Licence light plate