

INSPECTION

1. **INSPECT SOLAR SENSOR CIRCUIT**
Driver Side : (See page [DI-970](#))
Passenger Side : (See page [DI-962](#))
2. **INSPECT ROOM TEMP. SENSOR CIRCUIT**
(See page [DI-944](#))
3. **INSPECT AMBIENT TEMP. SENSOR CIRCUIT**
(See page [DI-947](#))
4. **INSPECT EVAPORATOR TEMPERATURE SENSOR CIRCUIT**
(See page [DI-950](#))
5. **INSPECT DUCT SENSOR CIRCUIT**
Driver Side : (See page [DI-953](#))
Passenger Side : (See page [DI-956](#))
6. **INSPECT SMOG VENTILATION SENSOR CIRCUIT**
(See page [DI-959](#))