



## INSPECTION

### INSPECT BALL JOINT FOR ROTATION CONDITION

- (a) Flip the ball joint stud back and forth 5 times before installing the nut.
- (b) Using a torque wrench, turn the nut continuously one turn every 2–4 seconds and take the torque reading on the 5th turn.

#### Torque (turning):

**1.0 – 3.4 N·m (10 – 35 kgf·cm, 9 – 30 in.-lbf)**