













# SUSPENSION AND AXLE








## SST (Special Service Tools)

PPOIX-02

	09223-15020	Oil Seal & Bearing Replacer	Rear axle
	09223-46011	Crankshaft Front Oil Seal Replacer	Rear differential
	09223-56010	Crankshaft Rear Oil Seal Replacer	Rear differential
	09229-55010	Oil Cooler Relief Valve Wrench	Rear differential
	09240-00020	Wire Gauge Set	Rear drive shaft
	(09242-00080)	Wire Gauge	
	09255-10012	Crankshaft Rear Bearing Remover & Replacer	Rear differential
	09308-00010	Oil Seal Puller	Front axle Rear axle Rear differential
	09309-36010	Transmission Rear Bearing Replacer	Rear drive shaft
	09316-12010	Transfer Bearing Replacer	Rear differential
	09316-60011	Transmission & Transfer Bearing Replacer	Front suspension Rear differential
	(09316-00011)	Replacer Pipe	





	(09316-00041) Replacer "C"	
	09325-40010 Transmission Oil Plug	Rear differential
	09330-00021 Companion Flange Holding Tool	Rear differential
	09502-12010 Differential Bearing Replacer	Rear drive shaft Rear differential
	09502-24010 Bearing Replacer	Rear differential
	09520-24010 Differential Side Gear Shaft Puller	Rear differential
	09521-24010 Drive Shaft Boot Clamping Tool	Rear drive shaft
	09527-17011 Rear Axle Shaft Bearing Remover	Rear axle Rear differential
	09570-22011 Differential Mounting Cushion Remover & Replacer	Rear differential
	09570-24010 Differential Mounting Cushion Remover & Replacer	Rear differential
	09608-04031 Front Hub Inner Bearing Cone Replacer	Rear differential
	09608-06041 Front Hub Inner Bearing Cone Replacer	Front axle
	09608-32010 Steering Knuckle Oil Seal Replacer	Front axle Rear axle Rear differential

## PREPARATION - SUSPENSION AND AXLE

	09610-20012	Pitman Arm Puller	Front axle Front suspension
	09628-10011	Ball Joint Puller	Front wheel hub bolt Rear wheel hub bolt Rear suspension
	09628-62011	Ball Joint Puller	Front suspension
	09710-26011	Front Suspension Bushing Tool Set	Front suspension
	(09710-05081)	Rear Base	
	09710-30050	Suspension Arm Bushing Replacer	Rear differential
	09726-12023	Lower Suspension Arm Bushing Remover & Replacer	Rear drive shaft
	(09726-01031)	Spacer	
	09727-30021	Coil Spring Compressor	Front suspension Rear suspension
	09843-18020	Diagnosis Check Wire	Diagnosis trouble code check
	09922-10010	Variable Open Wrench	Rear differential
	09950-00020	Bearing Remover	Front axle Rear axle Rear differential
	09950-00030	Bearing Remover Attachment	Rear axle

	<p>09950-40011 Puller B Set</p>	<p>Front axle Rear axle Rear differential</p>
	<p>(09951-04020) Hanger 200</p>	
	<p>(09952-04010) Slide Arm</p>	
	<p>(09953-04020) Center Bolt 150</p>	
	<p>(09953-04030) Center Bolt 200</p>	
	<p>(09954-04010) Arm 25</p>	
	<p>(09955-04051) Claw No.5</p>	
	<p>(09955-04061) Claw No.6</p>	
	<p>(09957-04010) Attachment</p>	
	<p>(09958-04011) Holder</p>	
	<p>09950-60010 Replacer Set</p>	<p>Front axle Rear axle Rear differential</p>
	<p>(09951-00430) Replacer 43</p>	
	<p>(09951-00450) Replacer 45</p>	

PREPARATION - SUSPENSION AND AXLE

	<p>(09951-00510) Replacer 51</p>	
	<p>(09951-00560) Replacer 56</p>	
	<p>09950-60020 Replacer Set No.2</p>	<p>Front axle Rear axle Rear differential</p>
	<p>(09951-00710) Replacer 71</p>	
	<p>(09951-00720) Replacer 72</p>	
	<p>(09951-00780) Replacer 78</p>	
	<p>(09951-00810) Replacer 81</p>	
	<p>(09951-00890) Replacer 89</p>	
	<p>(09951-01030) Replacer 103</p>	
	<p>09950-70010 Handle Set</p>	<p>Rear axle Rear differential</p>
	<p>(09951-07100) Handle 100</p>	
	<p>(09951-07150) Handle 150</p>	