



INSPECTION

1. INSPECT FOG LIGHT RELAY CONTINUITY

| Condition | Tester connection | Specified condition |
|-------------------------------------|-------------------|---------------------|
| Constant | 1 - 2 | Continuity |
| Apply B+ between terminals 1 and 2. | 3 - 4 | Continuity |

If continuity is not as specified, replace the relay.

2. INSPECT FOG LIGHT RELAY CIRCUIT (See page [BE-23](#))