



DISASSEMBLY

REMOVE SUSPENSION SUPPORT AND COIL SPRING

- (a) Using SST, compress the coil spring until there is a clearance on both ends.
SST 09727-30021

NOTICE:

Do not use an impact wrench. It will damage the SST.

- (b) Remove the suspension support nut.
(c) Remove the suspension support, insulator and coil spring.
(d) Remove the insulator and spring bumper from the suspension support.