

# IDLE SPEED

## INSPECTION

EM09K-02

### 1. INITIAL CONDITIONS

- (a) Engine at normal operating temperature
- (b) Air cleaner installed
- (c) All pipes and hoses of air induction system connected
- (d) All accessories switched OFF
- (e) All vacuum lines properly connected

#### HINT:

All vacuum hoses should be properly connected.

- (f) SFI system wiring connectors fully plugged
- (g) Ignition timing set correctly
- (h) Transmission in neutral position
- (i) Air conditioning switched OFF

### 2. CONNECT LEXUS HAND-HELD TESTER OR OBD II SCAN TOOL (See page [EM-9](#))

### 3. INSPECT IDLE SPEED

- (a) Race the engine speed at 2,500 rpm for approx. 90 seconds.
- (b) Check the idle speed.

**Idle speed: 750 ± 50 rpm**

If the idle speed is not as specified, check the air intake system.

### 4. DISCONNECT LEXUS HAND-HELD TESTER OR OBD II SCAN TOOL