



DISASSEMBLY

1. REMOVE REAR END COVER

(a) Remove the nut and terminal insulator.




(b) Remove the 3 nuts, bolt, plate terminal and rear end cover.




2. REMOVE BRUSH HOLDER AND VOLTAGE REGULATOR

- (a) Remove the brush holder cover from the brush holder.
- (b) Remove the 5 screws, brush holder and voltage regulator.
- (c) Remove the seal plate from the rectifier end frame.



3. REMOVE RECTIFIER HOLDER

- (a) Remove the nut and cord clip.
- (b) Remove the 4 screws and rectifier holder.
- (c) Remove the 4 rubber insulators.




4. REMOVE PULLEY

- (a) Hold SST (A) with a torque wrench, and tighten SST (B) clockwise to the specified torque.

SST 09820-63010

Torque: 39 N·m (400 kgf·cm, 29 ft·lbf)

- (b) Check that SST (A) is secured to the rotor shaft.



- (c) As shown in the illustration, mount SST (C) in a vise, and install the generator to SST (C).
- (d) To loosen the pulley nut, turn SST (A) in the direction shown in the illustration.



NOTICE:

To prevent damage to the rotor shaft, do not loosen the pulley nut more than one-half of a turn.

- (e) Remove the generator from SST (C).
- (f) Turn SST (B), and remove SST (A and B).
- (g) Remove the pulley nut and pulley.

5. REMOVE RECTIFIER END FRAME

- (a) Remove the 3 nuts and cord clip.



- (b) Using SST, remove the rectifier end frame.
SST 09286-46011
- (c) Remove the generator washer.

6. REMOVE ROTOR FROM DRIVE END FRAME