



INSTALLATION

1. BEFORE INSTALLING PARTS, COAT LOCK WITH MP GREASE

Apply MP grease to the sliding surface of the lock.

2. INSTALL HOOD LOCK CONTROL CABLE

- (a) Push the rear side cable through the grommet.
- (b) Using a screwdriver, push the cable stopper into the grommet.

HINT:

- Tape the screwdriver tip before use.
 - Do not damage the grommet with the screwdriver.
- (c) Clamp the front side cable to the junction block.
 - (d) Pass the front side cable through the upper radiator support.

3. INSTALL HOOD LOCK RELEASE LEVER

4. CHECK HOOD LOCK CONTROL FOR PROPER OPERATION

After checking for proper operation, tighten the nut and 2 bolts to install the lock.

5. INSTALL THESE PARTS:

- (a) Headlight
- (b) Clearance light
- (c) Front bumper cover
- (d) Front fender liner
- (e) Front fender moulding
- (f) Radiator support opening cover
- (g) Engine under cover