





# AUTOMATIC TRANSMISSION

## SST (Special Service Tools)

PP0N4-01

	09032-00100	Oil Pan Seal Cutter	Oil pan
	09308-00010	Oil Seal Puller	Extension housing rear oil seal
	09309-37010	Transmission Bearing Replacer	Extension housing rear oil seal
	09350-30020	TOYOTA Automatic Transmission Tool Set	
	(09351-32020)	Stator Stopper	
	09950-60010	Replacer Set	
	(09951-00350)	Replacer 35	
	09950-70010	Handle Set	
	(09951-07100)	Handle 100	
	09992-00095	Automatic Transmission Oil Pressure Gauge Set	
	(09992-00231)	Adaptor C	
	(09992-00271)	Gauge Assy	