


INSPECTION

1. PRETENSIONER IS NOT ACTIVATED

- (a) Perform a diagnostic system check.
(See page [DI-459](#))
- (b) Perform a visual check which includes the following items with the front seat outer belt removed from the vehicle.
 - Check for cuts and cracks in, or marked discoloration of the center pillar lower garnish.
 - Check for cuts and cracks in wire harnesses, and for chipping in connectors.
 - Check for deformation of the center pillar.



CAUTION:

For removal and installation of the front seat outer belt, see page [BO-118](#) and [BO-126](#).

Be sure to follow the correct procedure.

2. PRETENSIONER IS ACTIVATED

- (a) Perform a diagnostic system check.
(See page [DI-459](#))
- (b) Perform a visual check which includes the following items with the front seat outer belt removed from the vehicle.
 - Check for deformation of the center pillar.
 - Check for damage on the connector and wire harness.

