

REMOVAL

1. FRONT:

REMOVE FRONT RIGHT WHEEL AND FENDER LINER

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

2. REAR:

REMOVE LUGGAGE COMPARTMENT TRIM FRONT COVER (See page [BO-31](#))

3. REMOVE HEIGHT CONTROL VALVE

HINT:

At the time of installation, after installation, check for air leakage (See page [SA-123](#)).

(a) Remove the connector.

(b) Remove the air tube.

(1) Remove the holder.

(2) Spread the clip and pull the air tube out straight and slowly.

NOTICE:

Do not get scratches or foreign particles on the O-ring, O-ring seal and flare section.

HINT:

At the time of installation, please refer to the following items.

- If replacing O-ring, coat it with MP grease.
- Push the air tube in straight to correct it until the clip makes "click" sound.

(3) Remove the clip.

(c) Remove the 2 nuts and the height control valve.

Torque: 5.4 N·m (55 kgf·cm, 48 in·lbf)

4. REMOVE BUSHING, CUSHION AND SPACER