



INSTALLATION

1. INSTALL GENERATOR

- (a) Install the generator with the bolt and nut.
Torque: 39 N·m (400 kgf·cm, 29 ft·lbf)
- (b) Connect the generator connector.
- (c) Connect the generator wire with the nut and rubber cap.
- (d) Install the generator wire clamp to the cord clip on the generator.
- (e) Install the heated oxygen sensor wire clamp to the cord clip on the generator.

2. INSTALL PS PUMP

(See page [EM-82](#))

3. INSTALL PS OIL COOLER PIPE

4. INSTALL GENERATOR DRIVE BELT

Install the belt by turning the belt tensioner counterclockwise.

HINT:

The pulley bolt for the belt tensioner has a left – hand thread.

5. PERFORM ON-VEHICLE INSPECTION

(See page [CH-2](#))

6. INSTALL ENGINE UNDER COVER

7. INSTALL OIL PAN PROTECTOR

8. INSTALL AIR CLEANER INLET

9. INSTALL BATTERY CLAMP COVER