



INSPECTION

INSPECT BALL JOINT FOR ROTATION CONDITION

- (a) Flip the ball joint stud back and 4–5 times before installing the nut.
- (b) Using a torque wrench, turn the nut continuously one turn every 2–4 seconds and take the torque reading on the 5th turn.

Torque (turning):

1.0 – 2.5 N·m (1 – 25 kgf·cm, 9 – 21.7 in.-lbf)