



REMOVAL

1. REMOVE V-BANK COVER
2. REMOVE BATTERY CLAMP COVER
3. REMOVE AIR CLEANER INLET
4. REMOVE INTAKE AIR CONNECTOR
5. DISCONNECT IGNITION COIL CONNECTORS
6. REMOVE IGNITION COILS FROM SPARK PLUGS

Remove the 8 bolt and 8 ignition coils.

Torque: 7.5 N·m (80 kgf·cm, 66 in.-lbf)