

## REPLACEMENT

### REPLACEMENT REQUIREMENTS

In the following cases, replace the steering wheel pad, steering wheel or spiral cable.

- If the airbag has been deployed.
- If the steering wheel pad or spiral cable has been found to be faulty in troubleshooting.
- If the steering wheel pad, steering or spiral cable has been found to be faulty during checking items (See page [RS-16](#))
- If the steering wheel pad has been dropped.

### CAUTION:

For removal and installation of the steering wheel pad, see page [SR-12](#) and [SR-23](#), and be sure to follow the correct procedure.