


SERVOMOTOR REMOVAL

1. REMOVE AIR INLET SERVOMOTOR


- (a) Remove the blower unit.
(See page [AC-31](#))



- (b) Remove the air inlet servomotor.
(1) Disconnect the connector.
(2) Remove the screw and servomotor.

2. REMOVE AIR MIX SERVOMOTOR

- (a) Driver Side:
Remove the air mix servomotor.
(1) Remove these parts:
- No. 1 under cover
 - No. 1 safety pad
 - No. 2 heater to register duct




- (2) Disconnect the connector.
(3) Remove the 3 screws and servomotor.

HINT:

Be careful not to pull out the pulley, when removing servomotor.

- (b) Passenger Side:
Remove the air mix servomotor.
(1) Remove the blower unit.
(See page [AC-31](#))




- (2) Disconnect the connector.
(3) Remove the 3 screws and servomotor.

HINT:

Be careful not to pull out the pulley, when removing servomotor.

3. REMOVE AIR OUTLET SERVOMOTORS

- (a) Remove the A/C unit.
(See page [AC-24](#))



- (b) Remove the air outlet servomotors
(1) Disconnect the connectors.
(2) Remove the 6 screws and both servomotors.

HINT:


Be careful not to pull out the pulley, when removing servomotor.

4. REMOVE COOL AIR BY-PASS DAMPER CONTROL SERVOMOTOR

(a) Driver Side:

Remove the cool air by-pass damper control servomotor.

- (1) Remove the instrument panel.
(See page [BO-83](#))




- (2) Disconnect the connector.
- (3) Disconnect the cool air by-pass damper control cable.
- (4) Remove the 2 screws and servomotor.

(b) Passenger Side:

Remove cool air by-pass damper control servomotor.


- (1) Remove the blower unit.
(See page [AC-31](#))



- (2) Disconnect the connector.
- (3) Disconnect the cool air by-pass damper control cable.
- (4) Remove the 2 screws and servomotor.

5. REMOVE WATER VALVE CONTROL SERVOMOTOR

- (a) Remove these parts:
- (1) No. 1 under cover
 - (2) No. 1 safety pad
 - (3) No. 2 heater to register duct
(See page [BO-83](#))



- (b) Remove the servomotor.
- (1) Disconnect the connector.
 - (2) Disconnect the control cable
 - (3) Remove the 2 screws and servomotor.