

DISASSEMBLY

1. REMOVE WIRE HARNESS

2. REMOVE BLOWER MOTOR

Remove the 3 screws and blower motor.

3. REMOVE BLOWER MOTOR CONTROL RELAY

- (a) Disconnect the connectors.
- (b) Remove the screw and blower motor control relay.

4. REMOVE AIR INLET SERVOMOTOR

- (a) Disconnect the connector.
- (b) Remove the 2 screws and servomotor.

5. REMOVE CLEAN AIR FILTER

- (a) Disconnect the 3 claw and remove the filter cover.
- (b) Pull out the filter case.
- (c) Remove the clean air filter from the case.