

## REPLACEMENT

### REPLACEMENT REQUIREMENTS

In the following cases, replace the front passenger airbag assembly, instrument panel or instrument panel reinforcement.

- If the airbag has been deployed.
- If the front passenger airbag assembly has been found to be faulty in troubleshooting.
- If the front passenger airbag assembly, instrument panel or instrument panel reinforcement has been found to be faulty during checking items. (See page [RS-30](#))
- If the front passenger airbag assembly has been dropped.

### CAUTION:

**For replacement of the front passenger airbag assembly, see page [RS-29](#) and [RS-39](#).  
Be sure to follow the correct procedure.**