

Z08737


INSPECTION

1. INSPECT STOP LIGHT SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
Switch pin free	1 – 2	Continuity
Switch pin pushed in	3 – 4	Continuity

If continuity is not as specified, replace the switch.

Wire Harness Side



eg-4-1

Z08738


2. INSPECT STOP LIGHT SWITCH CIRCUIT

Disconnect the connector from the switch and inspect the connector on the wire harness side, as shown.

Tester connection	Condition	Specified condition
2 – Ground	Constant	Battery positive voltage

If circuit is not as specified, inspect the power source or wire harness.

Wire Harness Side



e-16-1-A

I03418

3. INSPECT LIGHT FAILURE SENSOR CIRCUIT

Disconnect the connector from the sensor and inspect the connector on the wire harness side, as shown.

Tester connection	Condition	Specified condition
2 – Ground	Constant	* Continuity
3 – Ground	Constant	* Continuity
4 – Ground	Constant	* Continuity
6 – Ground	Constant	* Continuity
7 – Ground	Constant	* Continuity
11 – Ground	Constant	Continuity
16 – Ground	Constant	* Continuity
1 – Ground	Stop light switch position OFF	No voltage

BODY ELECTRICAL – STOP LIGHT SYSTEM

1 – Ground	Stop light switch position ON	Battery positive voltage
8 – Ground	Stop light switch position OFF	No voltage
8 – Ground	Stop light switch position ON	Battery positive voltage
9 – Ground	Ignition switch position LOCK or ACC	No voltage
9 – Ground	Ignition switch position ON	Battery positive voltage
14 – Ground	Ignition switch position LOCK or ACC	No voltage
14 – Ground	Ignition switch position ON	Battery positive voltage
16 – Ground	Light control switch position OFF	No voltage
16 – Ground	Light control switch position TAIL or HEAD	Battery positive voltage

*: There is resistance because this circuit is grounded through the bulb.

If circuit is as specified, try replacing the sensor with a new one.

If the circuit is not as specified, inspect the circuits connected to other parts.