


## REAR WHEEL HUB BOLT REPLACEMENT

SAQJW-01


1. REMOVE REAR WHEEL
2. REMOVE BRAKE CALIPER AND DISC
  - (a) Remove the 2 bolts and brake caliper.
  - (b) Support the brake caliper securely.
  - (c) Place matchmarks on the disc and axle hub.
  - (d) Remove the 2 screws and disc.



### 3. REMOVE HUB BOLT

Using SST, remove the hub bolt.

SST 09628-10011



### 4. INSTALL HUB BOLT

Install washer and nut to the hub bolt as shown in the illustration, and install the hub bolt with torquing the nut.

### 5. INSTALL DISC AND BRAKE CALIPER

- (a) Align the matchmarks on the disc and axle hub.
- (b) Install the brake disc and 2 screws.

**Torque: 5.0 N·m (55 kgf·cm, 48 in.-lbf)**

- (c) Install the brake caliper and 2 bolts.

**Torque: 104 N·m (1,065 kgf·cm, 77 ft·lbf)**

### 6. INSTALL REAR WHEEL

**Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)**