


REMOVAL

1. DISCONNECT LEVEL WARNING SWITCH CONNECTOR
2. DRAW OUT FLUID WITH SYRINGE

NOTICE:

Do not let brake fluid remain on a painted surface. Wash it off immediately.




3. DISCONNECT BRAKE LINES

- (a) Using SST, disconnect the 2 brake lines from the master cylinder.

SST 09023-00100

Torque: 15 N·m (155 kgf-cm, 11 ft-lbf)

- (b) Disconnect the brake hose from the reservoir.



4. REMOVE MASTER CYLINDER

- (a) Remove the 2 nuts.

Torque: 13 N·m (130 kgf-cm, 9 ft-lbf)

- (b) Pull out the master cylinder and gasket from the brake booster.