

# SECTION **EXL**

## EXTERIOR LIGHTING SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

### CONTENTS

<b>HALOGEN TYPE</b>	
<b>PRECAUTION</b> .....	<b>HEADLAMP AIMING CONTROL (MANUAL)</b> .....12
5	HEADLAMP AIMING CONTROL (MANUAL) :
<b>PRECAUTIONS</b> .....	System Description .....
5	12
Precaution for Supplemental Restraint System	<b>FRONT FOG LAMP SYSTEM</b> .....
(SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	12
5	FRONT FOG LAMP SYSTEM : System Diagram....
Precaution Necessary for Steering Wheel Rotation after Battery Disconnect .....	FRONT FOG LAMP SYSTEM : System Description .....
5	13
<b>SYSTEM DESCRIPTION</b> .....	FRONT FOG LAMP SYSTEM : Fail-Safe .....
7	13
<b>COMPONENT PARTS</b> .....	<b>REAR FOG LAMP SYSTEM</b> .....
7	13
Component Parts Location .....	REAR FOG LAMP SYSTEM : System Diagram .....
7	14
Component Description .....	REAR FOG LAMP SYSTEM : System Description....
8	14
Light & Rain Sensor .....	<b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM</b> .....
8	14
<b>SYSTEM</b> .....	TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram .....
9	14
<b>HEADLAMP SYSTEM</b> .....	TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description .....
9	14
HEADLAMP SYSTEM : System Diagram .....	<b>PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL)</b> .....
9	15
HEADLAMP SYSTEM : System Description .....	PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : System Diagram .....
9	15
HEADLAMP SYSTEM : Fail-Safe .....	PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : System Description .....
10	15
<b>AUTO LIGHT SYSTEM (WITHOUT DTRL)</b> .....	PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : Fail-Safe .....
10	16
AUTO LIGHT SYSTEM (WITHOUT DTRL) : System Diagram .....	<b>PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL)</b> .....
10	16
AUTO LIGHT SYSTEM (WITHOUT DTRL) : System Description .....	PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : System Diagram .....
10	16
<b>AUTO LIGHT SYSTEM (WITH DTRL)</b> .....	PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : System Description .....
11	16
AUTO LIGHT SYSTEM (WITH DTRL) : System Diagram .....	PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : Fail-Safe .....
11	17
AUTO LIGHT SYSTEM (WITH DTRL) : System Description .....	<b>EXTERIOR LAMP BATTERY SAVER SYSTEM (WITHOUT DTRL)</b> .....
11	17
<b>DAYTIME RUNNING LIGHT SYSTEM</b> .....	
12	
DAYTIME RUNNING LIGHT SYSTEM : System Diagram .....	
12	
DAYTIME RUNNING LIGHT SYSTEM : System Description .....	
12	

EXTERIOR LAMP BATTERY SAVER SYSTEM (WITHOUT DTRL) : System Diagram .....	17	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	43
EXTERIOR LAMP BATTERY SAVER SYSTEM (WITHOUT DTRL) : System Description .....	17	Work Flow .....	43
<b>EXTERIOR LAMP BATTERY SAVER SYSTEM (WITH DTRL)</b> .....	18	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	45
EXTERIOR LAMP BATTERY SAVER SYSTEM (WITH DTRL) : System Diagram .....	18	<b>HEADLAMP (HI) CIRCUIT</b> .....	45
EXTERIOR LAMP BATTERY SAVER SYSTEM (WITH DTRL) : System Description .....	18	Component Function Check .....	45
		Diagnosis Procedure .....	45
<b>DIAGNOSIS SYSTEM (BCM) (WITH INTELLI- GENT KEY SYSTEM)</b> .....	19	<b>HEADLAMP (LO) CIRCUIT</b> .....	47
<b>COMMON ITEM</b> .....	19	Component Function Check .....	47
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	19	Diagnosis Procedure .....	47
<b>HEADLAMP</b> .....	20	<b>HEADLAMP GROUND CIRCUIT</b> .....	49
HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP) .....	20	Diagnosis Procedure .....	49
<b>FLASHER</b> .....	22	<b>DAYTIME RUNNING LIGHT RELAY CIRCUIT</b> .....	50
FLASHER : CONSULT-III Function (BCM - FLASHER) .....	22	Component Function Check .....	50
		Diagnosis Procedure .....	50
		Component Inspection .....	51
<b>DIAGNOSIS SYSTEM (BCM) (WITHOUT IN- TELLIGENT KEY SYSTEM)</b> .....	24	<b>HEADLAMP AIMING SYSTEM (MANUAL)</b> .....	53
<b>COMMON ITEM</b> .....	24	Component Inspection .....	53
COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM) .....	24	<b>FRONT FOG LAMP CIRCUIT</b> .....	54
<b>HEADLAMP</b> .....	24	Component Function Check .....	54
HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP) .....	25	Diagnosis Procedure .....	54
<b>FLASHER</b> .....	26	<b>REAR FOG LAMP CIRCUIT</b> .....	56
FLASHER : CONSULT-III Function (BCM - FLASHER) .....	26	Component Function Check .....	56
		Diagnosis Procedure .....	56
<b>DIAGNOSIS SYSTEM (IPDM E/R) (WITH IN- TELLIGENT KEY SYSTEM)</b> .....	28	<b>PARKING LAMP CIRCUIT</b> .....	58
Diagnosis Description .....	28	<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM</b> ...	58
CONSULT-III Function (IPDM E/R) .....	30	WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check .....	58
		WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure .....	58
<b>DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)</b> .....	33	<b>WITH DAYTIME RUNNING LIGHT SYSTEM</b> .....	59
Diagnosis Description .....	33	WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check .....	59
CONSULT-III Function (IPDM E/R) .....	35	WITH DAYTIME RUNNING LIGHT SYSTEM : Di- agnosis Procedure .....	60
<b>ECU DIAGNOSIS INFORMATION</b> .....	38	<b>TAIL LAMP CIRCUIT</b> .....	61
<b>BCM, IPDM E/R</b> .....	38	<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM</b> ...	61
List of ECU Reference .....	38	WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check .....	61
<b>WIRING DIAGRAM</b> .....	39	WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure .....	61
<b>EXTERIOR LIGHTING SYSTEM</b> .....	39	<b>WITH DAYTIME RUNNING LIGHT SYSTEM</b> .....	62
Wiring Diagram .....	39	WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check .....	62
<b>BASIC INSPECTION</b> .....	43	WITH DAYTIME RUNNING LIGHT SYSTEM : Di- agnosis Procedure .....	63
		<b>LICENSE PLATE LAMP CIRCUIT</b> .....	65

<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM .... 65</b>	<b>BOTH SIDE FRONT FOG LAMPS ARE NOT</b>	
WITHOUT DAYTIME RUNNING LIGHT SYSTEM	<b>TURNED ON ..... 82</b>	A
: Component Function Check ..... 65	Description ..... 82	
WITHOUT DAYTIME RUNNING LIGHT SYSTEM	Diagnosis Procedure ..... 82	
: Diagnosis Procedure ..... 65	<b>PERIODIC MAINTENANCE ..... 83</b>	B
<b>WITH DAYTIME RUNNING LIGHT SYSTEM ..... 65</b>	<b>HEADLAMP AIMING ADJUSTMENT ..... 83</b>	C
WITH DAYTIME RUNNING LIGHT SYSTEM :	<b>LHD ..... 83</b>	
Component Function Check ..... 66	LHD : Description ..... 83	
WITH DAYTIME RUNNING LIGHT SYSTEM : Di-	LHD : Aiming Adjustment Procedure ..... 84	D
agnosis Procedure ..... 66	<b>RHD ..... 85</b>	
<b>LIGHT &amp; RAIN SENSOR ..... 67</b>	RHD : Description ..... 85	E
Component Function Check ..... 67	RHD : Aiming Adjustment Procedure ..... 86	
Diagnosis Procedure ..... 67	<b>FRONT FOG LAMP AIMING ADJUSTMENT ... 88</b>	F
<b>TURN SIGNAL LAMP CIRCUIT ..... 69</b>	Description ..... 88	
Component Function Check ..... 69	Aiming Adjustment Procedure ..... 88	
Diagnosis Procedure ..... 69	<b>REMOVAL AND INSTALLATION ..... 89</b>	G
<b>HAZARD SWITCH ..... 72</b>	<b>HEADLAMP ..... 89</b>	
Component Function Check ..... 72	Exploded View ..... 89	H
Diagnosis Procedure ..... 72	Removal and Installation ..... 89	
<b>SYMPTOM DIAGNOSIS ..... 74</b>	Replacement ..... 90	I
<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS... 74</b>	Disassembly and Assembly ..... 90	J
<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM .... 74</b>	<b>FRONT COMBINATION LAMP ..... 91</b>	
WITHOUT DAYTIME RUNNING LIGHT SYSTEM	Exploded View ..... 91	K
: Symptom Table ..... 74	Removal and Installation ..... 91	
<b>WITH DAYTIME RUNNING LIGHT SYSTEM ..... 75</b>	Replacement ..... 92	
WITH DAYTIME RUNNING LIGHT SYSTEM :	Disassembly and Assembly ..... 92	
Symptom Table ..... 75	<b>FRONT FOG LAMP ..... 93</b>	
<b>BOTH SIDE HEADLAMPS (HI) ARE NOT</b>	Exploded View ..... 93	
<b>TURNED ON ..... 78</b>	Removal and Installation ..... 93	
Description ..... 78	Replacement ..... 93	
Diagnosis Procedure ..... 78	<b>LIGHT &amp; RAIN SENSOR ..... 95</b>	EXL
<b>BOTH SIDE HEADLAMPS (LO) ARE NOT</b>	Exploded View ..... 95	
<b>TURNED ON ..... 79</b>	Removal and Installation ..... 95	M
Description ..... 79	<b>LIGHTING &amp; TURN SIGNAL SWITCH ..... 96</b>	
Diagnosis Procedure ..... 79	Removal and Installation ..... 96	
<b>PARKING, LICENSE PLATE AND TAIL</b>	<b>HAZARD SWITCH ..... 97</b>	N
<b>LAMPS ARE NOT TURNED ON ..... 80</b>	Exploded View ..... 97	
<b>WITHOUT DAYTIME RUNNING LIGHT SYSTEM .... 80</b>	Removal and Installation ..... 97	
WITHOUT DAYTIME RUNNING LIGHT SYSTEM	<b>SIDE TURN SIGNAL LAMP ..... 98</b>	O
: Description ..... 80	Exploded View ..... 98	
WITHOUT DAYTIME RUNNING LIGHT SYSTEM	Removal and Installation ..... 98	
: Diagnosis Procedure ..... 80	Replacement ..... 98	P
<b>WITH DAYTIME RUNNING LIGHT SYSTEM ..... 80</b>	<b>HEADLAMP AIMING SWITCH ..... 99</b>	
WITH DAYTIME RUNNING LIGHT SYSTEM : De-	Exploded View ..... 99	
scription ..... 80	Removal and Installation ..... 99	
WITH DAYTIME RUNNING LIGHT SYSTEM : Di-	<b>REAR COMBINATION LAMP ..... 100</b>	
agnosis Procedure ..... 80	Exploded View ..... 100	

---

Removal and Installation .....	100	<b>REAR FOG LAMP .....</b>	<b>104</b>
Replacement .....	101	Exploded View .....	104
<b>HIGH-MOUNTED STOP LAMP .....</b>	<b>102</b>	Removal and Installation .....	104
Exploded View .....	102	Replacement .....	105
Removal and Installation .....	102	<b>SERVICE DATA AND SPECIFICATIONS</b>	
<b>LICENSE PLATE LAMP .....</b>	<b>103</b>	<b>(SDS) .....</b>	<b>106</b>
Exploded View .....	103	<b>SERVICE DATA AND SPECIFICATIONS</b>	
Removal and Installation .....	103	<b>(SDS) .....</b>	<b>106</b>
Replacement .....	103	Bulb Specifications .....	106

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006466719

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

The vehicle may be equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate for certain types of collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.
- The vehicle may be equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate for certain types of collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000006466721

**NOTE:**

- Before removing and installing any control units, first turn the ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O

P

< PRECAUTION >

---

## OPERATION PROCEDURE

1. Connect both battery cables.

**NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.
5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000006451687



- |   |  |  |
|---|--|--|
| 1. Hazard switch  | 2. Parking lamp  | 3. Front turn signal lamp                          |
| 4. Front fog lamp* <sup>1</sup>   | 5. Headlamp  | 6. ECM<br>Refer to <a href="#">EC-461. "ECM"</a> . |
| 7. IPDM E/R<br>Refer to <a href="#">PCS-5. "Component Parts Location"</a> . | 8. BCM<br>Refer to <a href="#">BCS-6. "BODY CONTROL SYSTEM : Component Parts Location"</a> . | 9. Combination switch                              |
| 10. Combination meter   | 11. Light & rain sensor* <sup>2</sup>  | 12. Side turn signal lamp                          |
| 13. Headlamp aiming switch  | 14. Front door switch (driver side)  | 15. Rear turn signal lamp                          |
| 16. Tail lamp   | 17. Rear fog lamp  | 18. License plate lamp                             |
| 19. Daytime running light relay* <sup>3</sup>                               | 20. Aiming motor   |  |
| A. Engine room (RH)   | B. Headlamp (back)   |  |

\*<sup>1</sup>: With front fog lamp models

\*<sup>2</sup>: With auto light system

\*<sup>3</sup>: With daytime running light system

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# COMPONENT PARTS

[HALOGEN TYPE]

< SYSTEM DESCRIPTION >

## Component Description


INFOID:000000006452117

Part	Description
BCM	Controls the exterior lighting system.
ECM	Transmits engine status signal to BCM. (via CAN communication)
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (via CAN communication).
Combination meter	<ul style="list-style-type: none"> <li>Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (via CAN communication).</li> <li>Turns the tail lamp indicator lamp, high beam indicator lamp, front fog lamp indicator lamp and rear fog lamp indicator lamp ON according to the request from BCM (via CAN communication).</li> </ul>
Light & rain sensor	Refer to <a href="#">EXL-8. "Light &amp; Rain Sensor"</a> .
Head lamp aiming motor	The headlamp levelizer adjusts the headlamp light axis upward and downward with the aiming motor integrated in the headlamp.
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9. "COMBINATION SWITCH READING SYSTEM : System Description"</a> .
Headlamp aiming switch	Adjusts height of headlamp aiming.
Door switch	Refer to <a href="#">DLK-22. "Component Description"</a> .
Hazard switch	Inputs the hazard switch signal to BCM.

## Light & Rain Sensor

INFOID:000000006452116


- The light & rain sensor detects the outside ambient light level, forward light level and sensor conditions.
- Based on ambient light level (day/night detection), forward light level (tunnel detection) and sensor conditions it judges ON/OFF condition for exterior lamps.
- And it transmits exterior lamp ON/OFF request to the BCM by the light & rain sensor serial link.
- BCM controls each function depending on the signals. And it detects the light & rain sensor serial link error and the light & rain sensor malfunction.



## SYSTEM

## HEADLAMP SYSTEM

## HEADLAMP SYSTEM : System Diagram



## HEADLAMP SYSTEM : System Description

INFOID:000000006451690

## OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

## HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R using CAN communication according to the headlamp (LO) ON condition.

## Headlamp (LO) ON condition

- Lighting switch 2ND
- Lighting switch AUTO (auto light function ON judgment)
- Lighting switch AUTO, with the front fog lamp switch ON and the ignition switch ON
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp ON according to the low beam request signal.

## HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter using CAN communication according to the headlamp (HI) ON condition. At this time, BCM stops to transmit low beam request signal.

## Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND or AUTO (auto light function ON judgment)
- Lighting switch PASS
- Lighting switch AUTO, with the front fog lamp switch ON, the ignition switch ON and lighting switch HI.
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.

## FOLLOW ME HOME FUNCTION

When the driver is moving to the house entrance from the own vehicle, headlamp is kept still ON by the follow me home function of BCM.

- When BCM detects the input of lighting switch PASS while all of following conditions satisfied, it transmits the low beam request signal for a period of time to IPDM E/R through CAN communication.

## Follow me home ON condition

- Ignition switch OFF
- Lighting switch OFF

# SYSTEM

[HALOGEN TYPE]

## < SYSTEM DESCRIPTION >

- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp ON according to the low beam request signal.
- When in any of following conditions, follow me home function can be cancelled while follow me home function is operating.

Follow me home OFF condition

- Ignition switch is turned from OFF→ACC or ON
- Lighting switch is turned from OFF→ON

### NOTE:

- Flash-to-pass operation illumination time for 1 time can be extended to approximately 30 seconds during operation of follow me home function.
- Flash-to-pass operation can be illuminated continuously for approximately 60 seconds (flash-to-pass operation, 2 times), approximately 90 seconds (flash-to-pass operation, 3 times), and a maximum of approximately 120 seconds (flash-to-pass operation, 4 times).
- Follow me home function activating time can be set by CONSULT-III. Refer to [EXL-20, "HEADLAMP : CONSULT-III Function \(BCM - HEAD LAMP\)"](#)(with Intelligent Key), [EXL-25, "HEADLAMP : CONSULT-III Function \(BCM - HEAD LAMP\)"](#)(without Intelligent Key).

## HEADLAMP SYSTEM : Fail-Safe

INFOID:00000000696679

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.


If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp high relay OFF</li> </ul>

## AUTO LIGHT SYSTEM (WITHOUT DTRL)

### AUTO LIGHT SYSTEM (WITHOUT DTRL) : System Diagram

INFOID:000000006451832



### AUTO LIGHT SYSTEM (WITHOUT DTRL) : System Description

INFOID:000000006451833

#### OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function

Control by IPDM E/R

< SYSTEM DESCRIPTION >

- Relay control function
- Auto light function turns the exterior lamps\* ON/OFF automatically according to the outside brightness.  
\*: Headlamp (LO/HI), parking, license plate and tail lamps (Headlamp HI depends on the combination switch condition.) license plate lamp

AUTO LIGHT FUNCTION


- BCM detects the combination switch condition with the combination switch reading function.
- BCM detects the engine condition by the engine status signal received from ECM via CAN communication.
- BCM receives exterior lamp ON/OFF requests from the light & rain sensor by light & rain sensor serial link.
- BCM judges the ON/OFF status of the exterior lamp according to ON/OFF requests from light & rain sensor and the vehicle condition.
- BCM transmits each request signal to IPDM E/R via CAN communication according to ON/OFF condition by the auto light function.

NOTE:

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT-III. Refer to [EXL-20, "HEADLAMP : CONSULT-III Function \(BCM - HEAD LAMP\)"](#).

AUTO LIGHT SYSTEM (WITH DTRL)

AUTO LIGHT SYSTEM (WITH DTRL) : System Diagram



AUTO LIGHT SYSTEM (WITH DTRL) : System Description

INFOID:000000006451835

OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function
- Auto light function

Control by IPDM E/R

- Relay control function
- Auto light function turns the exterior lamps\* ON/OFF automatically according to the outside brightness.  
\*: Headlamp (LO/HI), parking lamp, tail lamp (Headlamp HI depends on the combination switch condition.)

AUTO LIGHT FUNCTION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM detects the engine condition by the engine status signal received from ECM via CAN communication.
- BCM receives exterior lamp ON/OFF requests from the light & rain sensor by light & rain sensor serial link.
- BCM judges the ON/OFF status of the exterior lamp according to ON/OFF requests from light & rain sensor and the vehicle condition.
- BCM transmits each request signal to IPDM E/R via CAN communication according to ON/OFF condition by the auto light function.

NOTE:

# SYSTEM


< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT-III. Refer to [EXL-20, "HEADLAMP : CONSULT-III Function \(BCM - HEAD LAMP\)"](#).

## DAYTIME RUNNING LIGHT SYSTEM

### DAYTIME RUNNING LIGHT SYSTEM : System Diagram



### DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000006451837

#### OUTLINE

- Turns the following exterior lamps ON as the daytime running light.
  - Headlamp (LO)
  - Parking, license plate and tail lamps.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

#### DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects vehicle condition depending on the following signals.
  - Engine status signal (received from ECM via CAN communication)
- BCM transmits the low beam request signal and daytime running light request signal to IPDM E/R via CAN communication according to the daytime running light ON condition.

Daytime running light ON condition

- Engine running
- Lighting switch OFF
- Auto light switch is ON, front fog lamp switch and rear fog lamp switch are OFF, and auto light judgement is OFF.
- IPDM E/R turns the integrated headlamp low relay and daytime running light relay ON according to the low beam request signal and daytime running light request signal. And it turns each lamps ON.

## HEADLAMP AIMING CONTROL (MANUAL)

### HEADLAMP AIMING CONTROL (MANUAL) : System Description

INFOID:000000006451692

The headlamp levelizer adjusts the headlamp light axis upward and downward with the aiming motor integrated in the front combination lamp.

## FRONT FOG LAMP SYSTEM


# SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

## FRONT FOG LAMP SYSTEM : System Diagram

INFOID:000000006460640



## FRONT FOG LAMP SYSTEM : System Description

INFOID:000000006460641

### OUTLINE

Front fog lamp is controlled by combination switch reading function and front fog lamp control function of BCM, and relay control function of IPDM E/R.

### FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog lights request signal to IPDM E/R and the combination meter via CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition

- Front fog lamp switch ON and any of the followings.

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO and the ignition switch ON

IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog lights request signal.

Combination meter turns the front fog lamp indicator lamp ON according to the front fog lights request signal.

## FRONT FOG LAMP SYSTEM : Fail-Safe

INFOID:000000006696680

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.


If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Front fog lamp	Front fog lamp relay OFF

## REAR FOG LAMP SYSTEM

## REAR FOG LAMP SYSTEM : System Diagram

INFOID:000000006451696



## REAR FOG LAMP SYSTEM : System Description

INFOID:000000006451697

### OUTLINE

Rear fog lamp is controlled with the combination switch reading function and the rear fog lamp control function of BCM.

### REAR FOG LAMP OPERATION

- BCM detects the condition of the combination switch by the combination switch reading function.
- BCM supplies voltage to rear fog lamp according to the rear fog lamp ON condition.

Rear fog lamp switch is turned from OFF to ON with any of following condition.


- Lighting switch 2ND
- Lighting switch AUTO and the ignition switch ON
- Front fog lamp ON

- BCM transmits the rear fog lamp status signal to the combination meter using CAN communication.
- Combination meter turns the rear fog lamp indicator lamp ON according to the rear fog lamp status signal.

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram

INFOID:000000006451698



### TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:000000006451699

### OUTLINE

# SYSTEM

## < SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Turn signal lamp and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

### TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

### HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is ON. BCM blinks the hazard warning lamp.

### TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL OPERATION

- BCM transmits the turn signal indicator lamp signal to the combination meter using CAN communication while the turn signal lamp and the hazard warning lamp are operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn signal indicator lamp signal.

### 3-TIME FLASHER FUNCTION

- By a short touch of the turn signal lever, BCM blinks the turn signal lamps 3 times in the selected direction.
- Cancel the operation when short touch of the turn signal lever in the reverse direction during the 3-time flasher function operating.

### HIGH FLASHER OPERATION


- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while operating the hazard warning lamp.

## PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL)

### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : System Diagram



### PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : System Description

INFOID:000000006452107

#### OUTLINE

Parking, license plate and tail lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

#### PARKING, LICENSE PLATE AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the ON/OFF condition of the parking, license plate and tail lamps.

< SYSTEM DESCRIPTION >

Parking, license plate and tail lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- Lighting switch AUTO, with the front fog lamp switch ON and the ignition switch ON
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking, license plate and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

**PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITHOUT DTRL) : Fail-Safe**

INFOID:00000000669681

**CAN COMMUNICATION CONTROL**

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.


If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Illumination</li> <li>• Tail lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>

**PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL)**

**PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : System Diagram**

INFOID:000000006452109



**PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : System Description**

INFOID:000000006452110

**OUTLINE**

Parking, license plate and tail lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

**PARKING, LICENSE PLATE AND TAIL LAMPS OPERATION**

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the ON/OFF condition of the parking, license plate and tail lamps.

Parking, license plate and tail lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment

# SYSTEM

## < SYSTEM DESCRIPTION >

[HALOGEN TYPE]

- Lighting switch AUTO, with the front fog lamp switch ON and the ignition switch ON
- IPDM E/R turns the daytime running light relay ON and turns the parking, license plate and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

## PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM (WITH DTRL) : Fail-Safe

INFOID:000000006696742

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.


If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Illumination</li> <li>• Tail lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>

## EXTERIOR LAMP BATTERY SAVER SYSTEM (WITHOUT DTRL)

### EXTERIOR LAMP BATTERY SAVER SYSTEM (WITHOUT DTRL) : System Diagram

INFOID:000000006452112



### EXTERIOR LAMP BATTERY SAVER SYSTEM (WITHOUT DTRL) : System Description

INFOID:000000006452113

#### OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

#### Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

#### Control by IPDM E/R

- Relay control function
- BCM turns the exterior lamps\* OFF after a period of time to prevent the battery from over-discharge when the ignition switch is turned OFF with the exterior lamps ON.

\*: Headlamp (LO/HI), parking lamp, tail lamp, license plate lamp, front fog lamp and rear fog lamp

#### EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM turns the exterior lamps OFF (battery saver is activated) when all of following condition.

< SYSTEM DESCRIPTION >

- Exterior lamps ON
- When any of the following conditions is satisfied.
  - Driver side door switch is turned from OFF to ON while ignition switch is OFF.
  - Ignition switch is turned from ON to OFF while driver side door switch is ON.

**NOTE:**


When following condition (after the exterior lamp battery saver is activated), exterior lamps can be turned ON.

- Lighting switch ON → OFF → ON

## EXTERIOR LAMP BATTERY SAVER SYSTEM (WITH DTRL)

### EXTERIOR LAMP BATTERY SAVER SYSTEM (WITH DTRL) : System Diagram

INFOID:000000006452114



### EXTERIOR LAMP BATTERY SAVER SYSTEM (WITH DTRL) : System Description

INFOID:000000006452115

#### OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

#### Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

#### Control by IPDM E/R

- Relay control function
  - BCM turns the exterior lamps\* OFF after a period of time to prevent the battery from over-discharge when the ignition switch is turned OFF with the exterior lamps ON.
- \*: Headlamp (LO/HI), parking lamp, tail lamp, license plate lamp, front fog lamp and rear fog lamp

#### EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM turns the exterior lamps OFF (battery saver is activated) when all of following condition.

- Exterior lamps ON
- When any of the following conditions is satisfied.
  - Driver side door switch is turned from OFF to ON while ignition switch is OFF.
  - Ignition switch is turned from ON to OFF while driver side door switch is ON.

**NOTE:**

When following condition (after the exterior lamp battery saver is activated), exterior lamps can be turned ON.

- Engine running
- Lighting switch ON → OFF → ON

# DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

## DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM) COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000000696671

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
<ul style="list-style-type: none"> <li>Automatic A/C</li> <li>Manual A/C</li> </ul>	AIR CONDITONER		x	x*2
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
NVIS - NATS	IMMU	x	x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door open	TRUNK		x	
Theft warning alarm	THEFT ALM	x	x	x
—	RETAINED PWR*1		x	
Signal buffer system	SIGNAL BUFFER		x	x

#### NOTE:

- \*1: This item is displayed, but not used.
- \*2: For models with automatic A/C, this diagnosis mode is not used.

### FREEZE FRAME DATA (FFD)

# DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT-III.

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK")
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC	While turning power supply position from "LOCK" to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK".) to low power consumption mode
	LOCK	Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)
	OFF	Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	<p>The number of times that ignition switch is turned ON after DTC is detected</p> <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>

## HEADLAMP

### HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)

INFOID:000000006452198

### WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Service item	Setting item	Setting
CUSTOM A/LIGHT SETTING*1	MODE 1*2	Normal
	MODE 2	More sensitive setting than normal setting (Turns ON earlier than normal operation.)
	MODE 3	More sensitive setting than MODE 2 (Turns ON earlier than MODE 2.)
	MODE 4	Without twilight ON custom & less sensitive setting than normal setting (Turns ON later than normal operation.)
BATTERY SAVER SET	On*2	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function
HEAD LIGHT TIMER	MODE 1	10 sec.
	MODE 2*2	30 sec.
		Sets follow me home function activating time

\*1: For models is without auto light system, this item is displayed but work support is not operated.

\*2: Factory setting

## DATA MONITOR

Monitor item [Unit]	Description	
PUSH SW [On/Off]	The switch status input from push-button ignition switch	
ENGINE STATE [Stop/Stall/Crank/Run]	The engine status received from ECM via CAN communication	
VEH SPEED 1 [km/h]	The value of the vehicle speed received from combination meter via CAN communication	
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function	
TURN SIGNAL L [On/Off]		
TAIL LAMP SW [On/Off]		
HI BEAM SW [On/Off]		
HEAD LAMP SW1 [On/Off]		
HEAD LAMP SW2 [On/Off]		
PASSING SW [On/Off]		
AUTO LIGHT SW* [On/Off]		
FR FOG SW [On/Off]		
RR FOG SW [On/Off]		
DOOR SW-DR [On/Off]		The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]		The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH	
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH	

# DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Monitor item [Unit]	Description
DOOR SW-BK [On/Off]	The switch status input from back door switch
OPTICAL SENSOR* [On/Off/NG]	The sensor condition received from light & rain sensor
OPTI SEN (DTCT) [V]	<b>NOTE:</b> The item is indicated, but not monitored
OPTI SEN (FILT) [V]	

\*: For models without auto light system, this is not displayed.

## ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	Transmits the position light request signal to IPDM E/R via CAN communication to turn the tail lamp ON.
	Off	Stops the tail lamp request signal transmission.
HEAD LAMP	Hi	Transmits the high beam request signal via CAN communication to turn the headlamp (HI).
	Lo	Transmits the low beam request signal via CAN communication to turn the headlamp (LO).
	Off	Stops the high & low beam request signal transmission.
FR FOG LAMP	On	Transmits the front fog lights request signal to IPDM E/R via CAN communication to turn the front fog lamp ON.
	Off	Stops the front fog lights request signal transmission.
RR FOG LAMP	On	<ul style="list-style-type: none"> <li>Outputs voltage to turn the rear fog lamp ON.</li> <li>Transmits the rear fog lights request signal to combination meter via CAN communication to turn the rear fog lamp indicator lamp ON.</li> </ul>
	Off	<ul style="list-style-type: none"> <li>Stops the voltage to turn the rear fog lamp OFF.</li> <li>Stops the rear fog lamp status signal transmission.</li> </ul>
DAYTIME RUNNING LIGHT*	On	Transmits the daytime running light request signal via CAN communication to turn the parking, license plate and tail lamps ON.
	Off	Stop the daytime running light request signal transmission.

\*: For models without daytime running light system, this item is not displayed.

## FLASHER

### FLASHER : CONSULT-III Function (BCM - FLASHER)

INFOID:000000006452199

## WORK SUPPORT

Service item	Setting item	Setting
HAZARD ANSWER BACK	Lock Only	With locking only
	Unlk Only	With unlocking only
	Lock&Unlk*	With locking/unlocking
	Off	Without the function
		Sets the hazard warning lamp answer back function when the door is lock/unlock with the door request switch and Intelligent Key.

\*: Factory setting

## DATA MONITOR

# DIAGNOSIS SYSTEM (BCM) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from the request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from the request switch (passenger side)
PUSH SW [On/Off]	The switch status input from the push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch status that BCM detects from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch
RKE-LOCK [On/Off]	Lock signal status received from the remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from the remote keyless entry receiver
RKE-PANIC [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored

## ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	Outputs the voltage to blink the right side turn signal lamps.
	LH	Outputs the voltage to blink the left side turn signal lamps.
	Off	Stops the voltage to turn the turn signal lamps OFF.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

## DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM) COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000006696674

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM. Refer to CONSULT-III operation manual.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp control	INT LAMP	×	×	×
Remote keyless entry system	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER		×	×
<ul style="list-style-type: none"> <li>Automatic A/C</li> <li>Manual A/C</li> <li>Manual heater</li> </ul>	AIR CONDITONER		×	×*2
Combination switch	COMB SW		×	
Body control system	BCM	×		
NATS	IMMU	×		×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door open	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
—	RETAINED PWR*1		×	×
Signal buffer system	SIGNAL BUFFER		×	×
—	PANIC ALARM*1			×

• \*1: This item is displayed, but is not used.

• \*2: For models with automatic A/C, this mode is not used.

### HEADLAMP

# DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

## HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)

INFOID:000000006466728

### WORK SUPPORT

Service item	Setting item	Setting	
CUSTOM A/LIGHT SETTING*1	MODE 1*2	Normal	
	MODE 2	More sensitive setting than normal setting (Turns ON earlier than normal operation.)	
	MODE 3	More sensitive setting than MODE 2 (Turns ON earlier than MODE 2.)	
	MODE 4	Without twilight ON custom & less sensitive setting than normal setting (Turns ON later than normal operation.)	
BATTERY SAVER SET	On*2	With the exterior lamp battery saver function	
	Off	Without the exterior lamp battery saver function	
HEAD LIGHT TIMER	MODE 1	10 sec.	Sets follow me home function activating time
	MODE 2*2	30 sec.	

\*1: For models is without auto light system, this item is not displayed.

\*2: Factory setting

### DATA MONITOR

Monitor item [Unit]	Description
IGN ON SW [On/Off]	Ignition switch (ON) status judged from IGN signal (ignition power supply)
ACC SW [On/Off]	Ignition switch (ACC) status judged from ACC signal (ACC power supply)
VEH SPEED [km/h]	The value of the vehicle speed received from combination meter with CAN communication
HI BEAM SW [On/Off]	Each switch status that BCM judges from the combination switch reading function
HEAD LAMP SW1 [On/Off]	
HEAD LAMP SW2 [On/Off]	
PASSING SW [On/Off]	
FR FOG SW*1 [On/Off]	
AUTO LIGHT SW*2 [On/Off]	
RR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH
BACK DOOR SW [On/Off]	The switch status input from back door switch

# DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

[HALOGEN TYPE]

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
KEY ON SW [On/Off]	The switch status input from key on switch
KEYLESS LOCK [On/Off]	Lock signal status received from remote keyless entry receiver (integrated in the BCM)
PKB SW [On/Off]	The parking brake switch status received from combination meter with CAN communication
ENGINE RUN [On/Off]	The engine status received from ECM with CAN communication
LIG SEN COND [On/Off/NG]	The sensor condition received from light & rain sensor

\*1: Only models with front fog lamp can be monitored.

\*2: Only models with auto light system can be monitored.

## ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	Transmits the position light request signal to IPDM E/R with CAN communication to turn the tail lamp ON.
	Off	Stops the tail lamp request signal transmission.
HEAD LAMP	Hi	Transmits the high beam request signal with CAN communication to turn the headlamp (HI).
	Lo	Transmits the low beam request signal with CAN communication to turn the headlamp (LO).
	Off	Stops the high & low beam request signal transmission.
FR FOG LAMP*1	On	Transmits the front fog lights request signal to IPDM E/R with CAN communication to turn the front fog lamp ON.
	Off	Stops the front fog lights request signal transmission.
RR FOG LAMP	On	<ul style="list-style-type: none"> <li>Outputs the voltage to turn the rear fog lamp ON.</li> <li>Transmits the rear fog lamp status signal to the combination meter with CAN communication to turn the rear fog lamp indicator lamp ON.</li> </ul>
	Off	<ul style="list-style-type: none"> <li>Stops the voltage to turn the rear fog lamp OFF.</li> <li>Stops the rear fog lamp status signal transmission.</li> </ul>
DAYTIME RUNNING LIGHT*2	On	Transmits the daytime running light request signal via CAN communication to turn the parking, license plate and tail lamps ON.
	Off	Stop the daytime running light request signal transmission.

\*1: For models without front fog lamp, this item is displayed but active test is not operated.

\*2: For models without daytime running light system, this item is not displayed.

## FLASHER

### FLASHER : CONSULT-III Function (BCM - FLASHER)

INFOID:000000006451709

## DATA MONITOR

# DIAGNOSIS SYSTEM (BCM) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Monitor item [Unit]	Description
IGN ON SW [On/Off]	Ignition switch (ON) status judged from IGN signal (ignition power supply)
TURN SIGNAL R [On/Off]	Each switch status that BCM detects from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch

## ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	Outputs the voltage to blink the right side turn signal lamps.
	LH	Outputs the voltage to blink the left side turn signal lamps.
	Off	Stops the voltage to turn the turn signal lamps OFF.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

## DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

### Diagnosis Description

INFOID:000000006696675

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp (only for K9K engine models)
- Rear window defogger
- Front wiper motor
- Parking lamp
- License plate lamp
- Tail lamp
- Front fog lamp
- Headlamp (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

##### Operation Procedure

##### **CAUTION:**

**Wiper arm interferes with food when wiper is operated while wiper arm is in the raised position. Always perform auto active test without setting wiper arm in the raised position. Always pour water on front windshield glass in advance to auto active test so that damage on front windshield glass surface is prevented.**

1. Turn the ignition switch OFF.
2. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

##### **CAUTION:**

**Close passenger door.**

3. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.

##### **CAUTION:**

**Engine starts when ignition switch is turned ON while brake pedal is depressed.**

4. Oil pressure warning lamp starts blinking when the auto active test starts\*. (only for K9K engine models)  
\*: Except for K9K engine models, oil pressure warning lamp turn ON when auto active test start.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

##### **NOTE:**

- When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-87, "Component Function Check"](#) (with super lock) or [DLK-258, "Component Function Check"](#) (without super lock).

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.

Operation sequence	Inspection location	Operation
1	Oil pressure warning lamp	Blinks continuously during operation of auto active test <b>NOTE:</b> Except for K9K engine models, turn ON continuously during operation of auto active test.
2	Rear window defogger	10 seconds
3	Front wiper motor	LO for 5 seconds → HI for 5 seconds
4	<ul style="list-style-type: none"><li>• Parking lamp</li><li>• License plate lamp</li><li>• Tail lamp</li><li>• Front fog lamp</li></ul>	10 seconds
5	Headlamp	LO for 10 seconds → HI ON ↔ OFF 5 times


# DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Operation sequence	Inspection location	Operation
6	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
7	Cooling fan	<ul style="list-style-type: none"> <li>LO for 5 seconds → HI for 5 seconds (Except for MR16DDT models)</li> <li>50% duty for 5 seconds → 100% duty for 5 seconds (For MR16DDT models)</li> </ul>

Concept of auto active test



\*: Only for models with MR16DDT engine

- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents		Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> <li>Rear window defogger</li> <li>Rear window defogger ground circuit</li> <li>Harness or connector between IPDM E/R and rear window defogger</li> <li>IPDM E/R</li> </ul>
Any of the following components do not operate • Parking lamp • License plate lamp • Tail lamp • Front fog lamp • Headlamp (HI, LO) • Front wiper motor	Perform auto active test. Does the applicable system operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> <li>Lamp or motor</li> <li>Lamp or motor ground circuit</li> <li>Harness or connector between IPDM E/R and applicable system</li> <li>IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES	<ul style="list-style-type: none"> <li>A/C amp. signal input circuit</li> <li>CAN communication signal between A/C amp. and ECM</li> <li>CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>Magnet clutch</li> <li>Harness or connector between IPDM E/R and magnet clutch</li> <li>IPDM E/R</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Symptom	Inspection contents	Possible cause
Oil pressure warning lamp does not operate (only for K9K engine models)	Perform auto active test. Does the oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and combination meter</li> <li>• Combination meter</li> </ul>
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and cooling fan motor</li> <li>• Harness or connector between IPDM E/R and cooling fan control module. (Only for models with MR16DDT engine)</li> <li>• Harness or connector between cooling fan control module and cooling fan motor (Only for models with MR16DDT engine)</li> <li>• Cooling fan motor</li> <li>• Cooling fan control module (Only for models with MR16DDT engine)</li> <li>• IPDM E/R</li> </ul>

## CONSULT-III Function (IPDM E/R)

INFOID:000000006696676

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-25, "DTC Index"](#).

### DATA MONITOR

Monitor item

# DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

[HALOGEN TYPE]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIGNALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication. <b>NOTE:</b> This item is displayed only for vehicle with MR16DDT engine.
MOTOR FAN REQ [1/2/3/4]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication. <b>NOTE:</b> This item is displayed only for vehicle without MR16DDT engine.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the ignition power supply (M/T models) or shift position (CVT models) judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ ST ON/INHI ON/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the CVT shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		Displays the status of the steering lock relay signal received from BCM via CAN communication.
S/L STATE [LOCK/UNLK/UNKWN]		Displays the status of the steering lock judged by IPDM E/R.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R. <b>NOTE:</b> This item is monitored only K9K engine models.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DIAGNOSIS SYSTEM (IPDM E/R) (WITH INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Monitor Item [Unit]	MAIN SIGNALS	Description
HL WASHER REQ [Off/On]		Displays the status of the headlamp washer request signal received from BCM via CAN communication.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		<b>NOTE:</b> The item is indicated, but not monitored.

## ACTIVE TEST

Test item

Test item	Operation	Description	
HORN	On	Operates horn relay for 20 ms.	
REAR DEFOGGER	Off	OFF	
	On	Operates the rear window defogger relay.	
FRONT WIPER	Off	OFF	
	Lo	Operates the front wiper relay.	
	Hi	Operates the front wiper relay and front wiper high relay.	
MOTOR FAN	For MR16DDT engine	1	OFF
		2	Transmits 50% pulse duty signal (PWM signal) to the cooling fan control module.
		3	Transmits 75% pulse duty signal (PWM signal) to the cooling fan control module.
		4	Transmits 100% pulse duty signal (PWM signal) to the cooling fan control module.
	Except for MR16DDT engine	1	OFF
		2	Operates the cooling fan relay (LO operation).
		3	Operates the cooling fan relay (HI operation).
		4	
HEAD LAMP WASHER	On	Operates the headlamp washer relay for 1 second.	
EXTERNAL LAMPS	Off	OFF	
	TAIL	Operates the tail lamp relay.	
	Lo	Operates the headlamp low relay.	
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.	
	Fog	Operates the front fog lamp relay.	

# DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

## DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

### Diagnosis Description

INFOID:00000000696677

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp (only for K9K engine models)
- Rear window defogger
- Front wiper motor
- Parking lamp
- License plate lamp
- Tail lamp
- Front fog lamp
- Headlamp (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan

##### Operation Procedure

##### **CAUTION:**

**Wiper arm interferes with food when wiper is operated while wiper arm is in the raised position. Always perform auto active test without setting wiper arm in the raised position. Always pour water on front windshield glass in advance to auto active test so that damage on front windshield glass surface is prevented.**

1. Turn the ignition switch OFF.
2. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

##### **CAUTION:**

**Close passenger door.**

3. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.

##### **CAUTION:**

**Engine starts when ignition switch is turned ON while brake pedal is depressed.**

4. Oil pressure warning lamp starts blinking when the auto active test starts\*. (only for K9K engine models)  
\*: Except for K9K engine models, oil pressure warning lamp turn ON when auto active test start.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

##### **NOTE:**

- When auto active test mode has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-397, "Component Function Check"](#) (with super lock) or [DLK-522, "Component Function Check"](#) (without super lock).

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.

Operation sequence	Inspection location	Operation
1	Oil pressure warning lamp	Blinks continuously during operation of auto active test <b>NOTE:</b> Except for K9K engine models, turn ON continuously during operation of auto active test.
2	Rear window defogger	10 seconds
3	Front wiper motor	LO for 5 seconds → HI for 5 seconds
4	<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> <li>• Front fog lamp</li> </ul>	10 seconds


# DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Operation sequence	Inspection location	Operation
5	Headlamp	LO for 10 seconds → HI ON ↔ OFF 5 times
6	A/C compressor (magnet clutch)	ON ↔ OFF 5 times
7	Cooling fan	<ul style="list-style-type: none"> <li>• LO for 5 seconds → HI for 5 seconds (Except for MR16DDT models)</li> <li>• 50% duty for 5 seconds → 100% duty for 5 seconds (For MR16DDT models)</li> </ul>

## Concept of auto active test



\*: Only for models with MR16DDT engine

- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

## Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> <li>• Rear window defogger</li> <li>• Rear window defogger ground circuit</li> <li>• Harness or connector between IPDM E/R and rear window defogger</li> <li>• IPDM E/R</li> </ul>
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> <li>• Front fog lamp</li> <li>• Headlamp (HI, LO)</li> <li>• Front wiper motor</li> </ul>	Perform auto active test. Does the applicable system operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES	<ul style="list-style-type: none"> <li>• A/C amp. signal input circuit</li> <li>• CAN communication signal between A/C amp. and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Symptom	Inspection contents	Possible cause
Oil pressure warning lamp does not operate (only for K9K engine models)	Perform auto active test. Does the oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and combination meter</li> <li>• Combination meter</li> </ul>
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and cooling fan motor</li> <li>• Harness or connector between IPDM E/R and cooling fan control module. (Only for model with MR16DDT engine)</li> <li>• Harness or connector between cooling fan control module and cooling fan motor (Only for model with MR16DDT engine)</li> <li>• Cooling fan motor</li> <li>• Cooling fan control module (Only for model with MR16DDT engine)</li> <li>• IPDM E/R</li> </ul>

## CONSULT-III Function (IPDM E/R)

INFOID:000000006696678

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-55, "DTC Index"](#).

### DATA MONITOR

Monitor item

# DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Monitor Item [Unit]	MAIN SIG- NALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication. <b>NOTE:</b> This item is displayed only for vehicle with MR16DDT engine
MOTOR FAN REQ [1/2/3/4]	×	Displays the value of the cooling fan speed request signal received from ECM via CAN communication. <b>NOTE:</b> This item is displayed only for vehicle without MR16DDT engine
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the shift position (CVT models) judged by IPDM E/R.
ST RLY REQ [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R. <b>NOTE:</b> This item is monitored only K9K engine models.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off/On]		Displays the status of the headlamp washer request signal received from BCM via CAN communication.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.

## ACTIVE TEST

Test item

Test item	Operation	Description
HORN	On	Operates horn relay for 20 ms.
REAR DEFOGGER	Off	OFF
	On	Operates the rear window defogger relay.

# DIAGNOSIS SYSTEM (IPDM E/R) (WITHOUT INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

[HALOGEN TYPE]

Test item	Operation	Description	
FRONT WIPER	Off	OFF	
	Lo	Operates the front wiper relay.	
	Hi	Operates the front wiper relay and front wiper high relay.	
MOTOR FAN	For MR16DDT engine	1	OFF
		2	Transmits 50% pulse duty signal (PWM signal) to the cooling fan control module.
		3	Transmits 75% pulse duty signal (PWM signal) to the cooling fan control module.
		4	Transmits 100% pulse duty signal (PWM signal) to the cooling fan control module.
	Except for MR16DDT engine	1	OFF
		2	Operates the cooling fan relay (LO operation).
		3	Operates the cooling fan relay (HI operation).
		4	
HEAD LAMP WASHER	On	Operates the headlamp washer relay for 1 second.	
EXTERNAL LAMPS	Off	OFF	
	TAIL	Operates the tail lamp relay.	
	Lo	Operates the headlamp low relay.	
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.	
	Fog	Operates the front fog lamp relay.	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# ECU DIAGNOSIS INFORMATION

## BCM, IPDM E/R

### List of ECU Reference

INFOID:000000006451714

#### WITH INTELLIGENT KEY

ECU	Reference
BCM	<a href="#">BCS-41, "Reference Value"</a>
	<a href="#">BCS-64, "Fail-safe"</a>
	<a href="#">BCS-66, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-67, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-17, "Reference Value"</a>
	<a href="#">PCS-24, "Fail-Safe"</a>
	<a href="#">PCS-25, "DTC Index"</a>

#### WITHOUT INTELLIGENT KEY


ECU	Reference
BCM	<a href="#">BCS-125, "Reference Value"</a>
	<a href="#">BCS-140, "Fail-safe"</a>
	<a href="#">BCS-140, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-141, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-48, "Reference Value"</a>
	<a href="#">PCS-54, "Fail-Safe"</a>
	<a href="#">PCS-55, "DTC Index"</a>



# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]




JCLWA4238GB

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]



JCLWA4239GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[HALOGEN TYPE]



JCLWA4240GB


**BASIC INSPECTION**

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006451716

OVERALL SEQUENCE



DETAILED FLOW

**1. INTERVIEW FOR MALFUNCTION**

Interview the symptom to the customer.

# DIAGNOSIS AND REPAIR WORKFLOW

[HALOGEN TYPE]

< BASIC INSPECTION >

---

>> GO TO 2.

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

---

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

---

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

# HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## DTC/CIRCUIT DIAGNOSIS

### HEADLAMP (HI) CIRCUIT

#### Component Function Check

INFOID:000000006451718

#### 1. CHECK HEADLAMP (HI) OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (HI) is turned ON.

**Hi** : Headlamp (HI) ON  
**Off** : Headlamp (HI) OFF

##### NOTE:

ON/OFF is repeated 1 second each.

##### Is the inspection result normal?

- YES >> Headlamp (HI) circuit is normal.  
NO >> Refer to [EXL-45, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000006451719

#### 1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn ignition switch OFF.
2. Disconnect headlamp connector.
3. Turn ignition switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		Terminal	(-)	Test item	Voltage (Approx.)		
IPDM E/R							
Connector							
RH	E15	49	Ground	EXTERNAL LAMPS	Hi	Battery voltage	
						Off	0 V
LH		50				Hi	Battery voltage
						Off	0 V

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and headlamp harness connector.

IPDM E/R		Headlamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E45	1	Existed
LH		50		

##### Is the inspection result normal?

- YES >> Replace headlamp bulb.  
NO >> Repair or replace harness.

# HEADLAMP (HI) CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## 3. CHECK HEADLAMP (HI) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (RH)	IPDM E/R	#51	10 A
Headlamp HI (LH)		#52	

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> GO TO 4.

## 4. CHECK HEADLAMP HIGH (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R			Ground	Continuity
Connector		Terminal		
RH	E15	49	Not existed	
LH		50		

Is the inspection result normal?

YES >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

NO >> Repair or replace harness. And then replace the fuse.

# HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## HEADLAMP (LO) CIRCUIT

### Component Function Check

INFOID:000000006451720

#### 1.CHECK HEADLAMP (LO) OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (LO) is turned ON.

**Lo** : Headlamp (LO) ON

**Off** : Headlamp (LO) OFF

Is the inspection result normal?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-47, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006451721

#### 1.CHECK HEADLAMP (LO) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn ignition switch OFF.
2. Disconnect headlamp connector.
3. Turn ignition switch ON.
4. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
5. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Test item	Voltage (Approx.)	
IPDM E/R					
Connector	Terminal				
RH	E15	Ground	EXTERNAL LAMPS	Lo	Battery voltage
				52	Off
LH	51			Lo	Battery voltage
					Off

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2.CHECK HEADLAMP (LO) OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and headlamp harness connector.

IPDM E/R		Headlamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E15	E45	3	Existed
LH		51		

Is the inspection result normal?

YES >> Replace headlamp bulb.

NO >> Repair or replace harness.

#### 3.CHECK HEADLAMP (LO) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not fusing.

# HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

Unit	Lotion	Fuse No.	Capacity
Headlamp LO (RH)	IPDM E/R	#54	15 A
Headlamp LO (LH)		#53	

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> GO TO 4.

## 4. CHECK HEADLAMP (LO) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E15	52	Not existed
LH		51	

Is the inspection result normal?

YES >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

NO >> Repair or replace harness. And then replace the fuse.

# HEADLAMP GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## HEADLAMP GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000006451722

#### 1. CHECK HEADLAMP GROUND OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect headlamp connector.
3. Check continuity between headlamp harness connector and ground.

Headlamp		Ground	Continuity
Connector	Terminal		
RH	E45	2	Existed
LH	E26		

Is the inspection result normal?

- YES >> Headlamp ground circuit is normal.  
NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT RELAY CIRCUIT

### Component Function Check

INFOID:000000006452120

#### 1. CHECK DAYTIME RUNNING LIGHT OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test item, check that parking lamp, tail lamp and license plate lamp are turned ON.

**TAIL : Parking lamp, tail lamp and license plate lamp ON**  
**Off : Parking lamp, tail lamp and license plate lamp OFF**

##### Is the inspection result normal?

- YES >> Daytime running light relay circuit is normal.  
NO >> Refer to [EXL-50. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006452121

#### 1. CHECK DAYTIME RUNNING LIGHT RELAY FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not fusing.

##### Gasoline engine models

Unit	Fuse No.	Capacity
Daytime running light relay	#24	10 A
	#25	
	#26	

##### Diesel engine models

Unit	Fuse No.	Capacity
Daytime running light relay	#17	10 A
	#31	
	#33	

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the fuse after repairing the applicable circuit.

#### 2. CHECK DAYTIME RUNNING LIGHT RELAY POWER SUPPLY

1. Remove daytime running light relay.
2. Check voltage between daytime running light relay harness connector and ground.

(+)		(-)	Voltage (Approx.)
Daytime running light relay			
Connector	Terminal	Ground	Battery voltage
E82	1		
	3		
	6		

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3. CHECK DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-51. "Component Inspection"](#).

##### Is the inspection result normal?

- YES >> GO TO 4.

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace daytime running light relay.

## 4.CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL OUTPUT

### CONSULT-III ACTIVE TEST

1. Install daytime running light relay.
2. Turn ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test item, check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Test item		Voltage (Approx.)
IPDM E/R					
Connector	Terminal				
E13	28	Ground	EXTERNAL LAMPS	TAIL	0 V
				Off	Battery voltage

Is the inspection result normal?

YES >> Daytime running light relay circuit is OK.

Fixed at 0 V >>GO TO 5.

Fixed at battery voltage >>Replace IPDM E/R.

## 5.CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Disconnect IPDM E/R harness connector.
4. Check continuity between IPDM E/R harness connector and daytime running light relay harness connector.

IPDM E/R		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E13	28	E82	2	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

## 6.CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E13	28		Not existed

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace harness.

## Component Inspection

INFOID:000000006452122

## 1.CHECK DAYTIME RUNNING LIGHT RELAY

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Apply battery voltage to daytime running light relay between terminals 1 and 2.
4. Check continuity of daytime running light relay.

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

Daytime running light relay		Condition		Continuity
Terminal				
3	5	Voltage	Apply	Existed
			Not Apply	Not existed
6	7		Apply	Existed
			Not Apply	Not existed

Is the inspection result normal?

YES >> Daytime running light relay is normal.

NO >> Replace daytime running light relay.

## HEADLAMP AIMING SYSTEM (MANUAL)


### Component Inspection

INFOID:000000006451723

#### 1. CHECK HEADLAMP AIMING SWITCH

1. Remove headlamp aiming switch.
2. Check resistance among each headlamp aiming switch terminal.

Headlamp aiming switch		Condition	Resistance (Approx.)
Terminal		Switch position	
1	2	0	A: 160 Ω
		1	B: 300 Ω
		2	C: 392 Ω
		3	D: 499 Ω
	3	—	E: 390 Ω



**Is the inspection result normal?**

- YES >> Headlamp aiming switch is normal.  
 NO >> Replace the headlamp aiming switch.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# FRONT FOG LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## FRONT FOG LAMP CIRCUIT

### Component Function Check

INFOID:000000006452123

#### 1.CHECK FRONT FOG LAMP OPERATION

##### ⓅCONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the front fog lamp is turned ON.

**Fog** : Front fog lamp ON  
**Off** : Front fog lamp OFF

##### Is the measurement normal?

- YES >> Front fog lamp circuit is normal.  
NO >> Refer to [EXL-54, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006452124

#### 1.CHECK FRONT FOG LAMP FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#50	15 A

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK FRONT FOG LAMP SHORT CIRCUIT

1. Disconnect front fog connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E12	19	Not existed
LH		20	

##### Is the inspection result normal?

- YES >> Replace fuse. (Replace IPDM E/R if the fuse is fusing again.)  
NO >> Repair or replace harness. And then replace the fuse.

#### 3.CHECK FRONT FOG LAMP BULB

Check the applicable lamp bulb.

##### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Replace bulb.

#### 4.CHECK FRONT FOG LAMP OUTPUT VOLTAGE

##### ⓅCONSULT-III ACTIVE TEST

1. Disconnect front fog lamp connector.
2. Turn ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check the voltage between IPDM E/R harness connector and ground.

# FRONT FOG LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Test item	Voltage (Approx.)	
IPDM E/R					
Connector	Terminal				
RH	E12	Ground	EXTERNAL LAMPS	Fog	Battery voltage
				19	Off
LH	20			Fog	Battery voltage
				Off	0 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R.

## 5. CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front fog lamp harness connector.

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E12	E48	1	Existed
LH		19		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

## 6. CHECK FRONT FOG LAMP GROUND CIRCUIT OPEN CIRCUIT

Check continuity between front fog lamp harness connector and ground.

Front fog lamp		Ground	Continuity
Connector	Terminal		
RH	E48		2
LH	E30		

Is the inspection result normal?

YES >> Refer to [GI-42. "Intermittent Incident"](#).

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# REAR FOG LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## REAR FOG LAMP CIRCUIT

### Component Function Check

INFOID:000000006451728

#### 1. CHECK REAR FOG LAMP OPERATION

##### ⓅCONSULT-III ACTIVE TEST

1. Select "RR FOG LAMP" of BCM (HEAD LAMP) active test item.
2. With operating the test items, check that the rear fog lamp is turned ON.

**On** : Rear fog lamp ON

**Off** : Rear fog lamp OFF

Is the inspection result normal?

- YES >> Rear fog lamp circuit is normal.  
 NO >> Refer to [EXL-56, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006451729

#### 1. CHECK REAR FOG LAMP BULB

Check applicable lamp bulb.

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Replace bulb.

#### 2. CHECK REAR FOG LAMP OUTPUT VOLTAGE

##### ⓅCONSULT-III ACTIVE TEST

1. Turn ignition switch OFF.
2. Disconnect rear fog lamp connector.
3. Turn ignition switch ON.
4. Select "RR FOG LAMP" of BCM (HEAD LAMP) active test item.
5. With operating the test items, check voltage between rear fog lamp harness connector and ground.

(+)		(-)	Test item	Voltage (Approx.)	
Rear fog lamp					
Connector	Terminal				
B85	1	Ground	RR FOG LAMP	On	12 V
			Off	0 V	

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> GO TO 3.

#### 3. CHECK REAR FOG LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear fog lamp harness connector.

BCM		Rear fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
B9*1 B10*2	51*1 52*2	B85	1	Existed

\*1: Without Intelligent Key

\*2: With Intelligent Key

Is the inspection result normal?

- YES >> GO TO 4.

# REAR FOG LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

## 4.CHECK REAR FOG LAMP SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
B9*1	51*1		Not existed
B10*2	52*2		

\*1: Without Intelligent Key

\*2: With Intelligent Key

Is the inspection result normal?

YES >> Check bulb socket for internal short circuit, and if check result is normal, replace BCM. Refer to [BCS-93. "Removal and Installation"](#) (with Intelligent Key), [BCS-161. "Removal and Installation"](#) (without Intelligent Key).

NO >> Repair or replace harness.

## 5.CHECK REAR FOG LAMP GROUND OPEN CIRCUIT

Check continuity between rear fog lamp harness connector and ground.

Rear fog lamp		Ground	Continuity
Connector	Terminal		
B85	2		Existed

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## PARKING LAMP CIRCUIT

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check

INFOID:000000006452125

#### 1.CHECK PARKING LAMP OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

**TAIL : Parking lamp ON**  
**Off : Parking lamp OFF**

Is the inspection result normal?

YES >> Parking lamp circuit is normal.

NO >> Refer to [EXL-60, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000006452126

#### 1.CHECK PARKING LAMP FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Parking lamp	IPDM E/R	#46	10 A

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

#### 2.CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect the following connectors.
  - IPDM E/R
  - Parking lamp
  - Rear combination lamp (RH)
  - License plate lamp
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E14	37		Not existed
	38		

Is the inspection result normal?

YES >> Replace fuse. (Replace IPDM E/R if fusing is found again.)

NO >> Repair or replace harness. And then replace the fuse.

#### 3.CHECK PARKING LAMP BULB

Check applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace bulb.

#### 4.CHECK PARKING LAMP OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Disconnect parking lamp connector.

# PARKING LAMP CIRCUIT

[HALOGEN TYPE]

## < DTC/CIRCUIT DIAGNOSIS >

2. Turn ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Test item		Voltage (Approx.)
IPDM E/R					
Connector	Terminal				
E14	37	Ground	EXTERNAL LAMPS	TAIL	Battery voltage
				Off	0 V

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Replace IPDM E/R.

## 5.CHECK PARKING LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and parking lamp harness connector.

IPDM E/R		Parking lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	E43	1	Existed
LH		E24		

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair or replace harness.

## 6.CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between parking lamp harness connector and ground.

Parking lamp		Ground	Continuity
Connector	Terminal		
RH	E43	2	Existed
LH	E24		

Is the inspection result normal?

- YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.  
NO >> Repair or replace harness.

## WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check INFOID:000000006452127

## 1.CHECK PARKING LAMP OPERATION

### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

**TAIL : Parking lamp ON**  
**Off : Parking lamp OFF**

Is the inspection result normal?

- YES >> Parking lamp circuit is normal.  
NO >> Refer to [EXL-60. "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

# PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000006452128

### 1. CHECK PARKING LAMP BULB

Check applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

### 2. CHECK PARKING LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Disconnect parking lamp connector.
4. Check continuity between daytime running light relay harness connector and parking lamp harness connector.

Daytime running light relay		Parking lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E82	E43	1	Existed
LH		E24		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect the following connectors.
  - Rear combination lamp (RH)
  - License plate lamp
2. Check continuity between daytime running light relay harness connector and ground.

Daytime running light relay		Ground	Continuity
Connector	Terminal		
E82	5		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4. CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between parking lamp harness connector and ground.

Parking lamp		Ground	Continuity
Connector	Terminal		
RH	E43	2	Existed
LH	E24		

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

# TAIL LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## TAIL LAMP CIRCUIT

WITHOUT DAYTIME RUNNING LIGHT SYSTEM

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check

INFOID:000000006452129

### 1. CHECK TAIL LAMP OPERATION

#### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

**TAIL** : Tail Lamp ON  
**Off** : Tail lamp OFF

Is the inspection result normal?

YES >> Tail lamp circuit is normal.

NO >> Refer to [EXL-61, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000006452130

### 1. CHECK TAIL LAMP BULB

Check the applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

### 2. CHECK PARKING LAMP OPERATION

Check that the parking lamp is turned ON.

Is the inspection result normal?

YES-1 (When tail lamp (RH) does not turn ON.)>>GO TO 6.

YES-2 (When tail lamp (LH) does not turn ON.)>>GO TO 3.

NO >> Check parking lamp circuit. Refer to [EXL-58, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

### 3. CHECK TAIL LAMP (LH) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Tail lamp (LH)	IPDM E/R	#47	10 A

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

### 4. CHECK TAIL LAMP (LH) OUTPUT VOLTAGE

#### CONSULT-III ACTIVE TEST

1. Disconnect rear combination lamp (LH) connector.
2. Turn ignition switch ON.
3. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
4. With operating the test items, check voltage between IPDM E/R harness connector and ground.

# TAIL LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Test item		Voltage (Approx.)
IPDM E/R					
Connector	Terminal				
E14	44	Ground	EXTERNAL LAMPS	TAIL	Battery voltage
				Off	0 V

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace IPDM E/R.

## 5. CHECK TAIL LAMP (LH) SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and rear combination lamp (LH) connector.
3. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E14	44		Not existed

Is the inspection result normal?

YES >> Replace fuse. (Replace IPDM E/R if fusing is found again.)

NO >> Repair or replace harness. And then replace the fuse.

## 6. CHECK TAIL LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and rear combination lamp connector.
3. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14		38	Existed
LH			44	
		B59	2	
		B80		

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace harness.

## 7. CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B59		3
LH	B80		

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

## WITH DAYTIME RUNNING LIGHT SYSTEM

WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check INFOID:000000006478922

## 1. CHECK TAIL LAMP OPERATION

Ⓟ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

# TAIL LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

**TAIL** : Tail Lamp ON  
**Off** : Tail lamp OFF

Is the inspection result normal?

YES >> Tail lamp circuit is normal.

NO >> Refer to [EXL-63, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

## WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000006478923

### 1. CHECK TAIL LAMP BULB

Check the applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

### 2. CHECK PARKING LAMP OPERATION

Check that the parking lamp is turned ON.

Is the inspection result normal?

YES-1 (When tail lamp (RH) does not turn ON.)>>GO TO 4.

YES-2 (When tail lamp (LH) does not turn ON.)>>GO TO 3.

NO >> Check parking lamp circuit. Refer to [EXL-59, "WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

### 3. CHECK TAIL LAMP (LH) SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Disconnect rear combination lamp (LH) connector.
4. Check continuity between daytime running light relay harness connector and ground.

Daytime running light relay		Ground	Continuity
Connector	Terminal		
E82	7		Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4. CHECK TAIL LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Disconnect rear combination lamp connector.
4. Check continuity between daytime running light relay harness connector and rear combination lamp harness connector.

Daytime running light relay		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E82	B59	2	Existed
LH		7		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

### 5. CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between rear combination lamp harness connector and ground.

# TAIL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

Rear combination lamp		Ground	Continuity
Connector	Terminal		Existed
RH	B59	3	Existed
LH	B80		

Is the inspection result normal?

- YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.
- NO >> Repair or replace harness.

# LICENSE PLATE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## LICENSE PLATE LAMP CIRCUIT WITHOUT DAYTIME RUNNING LIGHT SYSTEM

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check

INFOID:000000006452133

#### 1. CHECK TAIL LAMP (RH) OPERATION

Check that the tail lamp (RH) is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-61, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

#### 2. CHECK LICENSE PLATE LAMP OPERATION

 CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the lighting switch, check that the license plate lamp is turned ON.

**TAIL : License plate lamp ON**

**Off : License plate lamp OFF**

Is the inspection result normal?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-65, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000006452134

#### 1. CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

#### 2. CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and back door opener switch connector.
3. Check continuity between IPDM E/R harness connector and back door opener switch harness connector.

IPDM E/R		Back door opener switch		Continuity
Connector	Terminal	Connector	Terminal	
E14	38	D107	5	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

#### 3. CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between back door opener switch harness connector and ground.

Back door opener switch		Ground	Continuity
Connector	Terminal		
D107	6		Existed

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

### WITH DAYTIME RUNNING LIGHT SYSTEM

# LICENSE PLATE LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check INFOID:000000006478924

## 1. CHECK TAIL LAMP (RH) OPERATION

Check that the tail lamp (RH) is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-62, "WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"](#).

## 2. CHECK LICENSE PLATE LAMP OPERATION

④CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.

2. With operating the lighting switch, check that the license plate lamp is turned ON.

**TAIL : License plate lamp ON**

**Off : License plate lamp OFF**

Is the inspection result normal?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-66, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"](#).

WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000006478925

## 1. CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace bulb.

## 2. CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.

2. Remove daytime running light relay.

3. Disconnect back door opener switch connector.

4. Check continuity between daytime running light relay harness connector and back door opener switch harness connector.

Daytime running light relay		Back door opener switch		Continuity
Connector	Terminal	Connector	Terminal	
E82	5	D107	5	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

## 3. CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between back door opener switch harness connector and ground.

Back door opener switch		Ground	Continuity
Connector	Terminal		
D107	6		Existed

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

# LIGHT & RAIN SENSOR

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

## LIGHT & RAIN SENSOR

### Component Function Check

INFOID:000000006452196

#### 1. CHECK LIGHT & RAIN SENSOR

1. Clean light & rain sensor detection area of windshield fully.
2. Turn ignition switch ON.
3. Turn lighting switch AUTO.
4. With the light & rain sensor illuminating, check the auto light function.

Light & rain sensor	Condition	Auto light function
	When illuminating	Not operating
	When shutting off light	Operating

Is the inspection result normal?

- YES >> Light & rain sensor is normal.  
NO >> Refer to [EXL-67, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006452197

#### 1. CHECK LIGHT & RAIN SENSOR FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not fusing.

Unit	Fuse No.	Capacity
Light & rain sensor	#7	10 A

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the fuse after repairing the applicable circuit.

#### 2. CHECK LIGHT & RAIN SENSOR POWER SUPPLY

1. Disconnect light & rain sensor connector.
2. Check voltage between light & rain sensor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Light & rain sensor			
Connector	Terminal	Ground	Battery voltage
R5	1		

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness.

#### 3. CHECK LIGHT & RAIN SENSOR GROUND CIRCUIT

Check continuity between light & rain sensor harness connector and ground.

Light & rain sensor		Ground	Continuity
Connector	Terminal		Existed
R5	3		

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness.

#### 4. CHECK LIGHT & RAIN SENSOR SIGNAL


1. Connect light & rain sensor connector.
2. Turn ignition switch ON.

# LIGHT & RAIN SENSOR

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

3. Check signal between BCM harness connector and ground with oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M65*1 M68*2	14*1 11*2	Ground	Ignition switch ON	

\*1: Without Intelligent Key

\*2: With Intelligent Key

Is the inspection result normal?

YES >> Replace light & rain sensor.

NO >> GO TO 5.

## 5. CHECK LIGHT & RAIN SENSOR SIGNAL CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM connector and light & rain sensor connector.
3. Check continuity between BCM harness connector and light & rain sensor harness connector.

BCM		Light & rain sensor		Continuity
Connector	Terminal	Connector	Terminal	
M65*1 M68*2	14*1 11*2	R5	2	Existed

\*1: Without Intelligent Key

\*2: With Intelligent Key

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

## 6. CHECK LIGHT & RAIN SENSOR SIGNAL CIRCUIT FOR SHORT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M65*1 M68*2	14*1 11*2		Not existed

\*1: Without Intelligent Key

\*2: With Intelligent Key

Is the inspection result normal?

YES >> Refer to [BCS-93. "Removal and Installation"](#) (with Intelligent Key), [BCS-161. "Removal and Installation"](#) (without Intelligent Key).

NO >> Repair or replace harness.

# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## TURN SIGNAL LAMP CIRCUIT

### Component Function Check

INFOID:000000006451732

#### 1. CHECK TURN SIGNAL LAMP

##### CONSULT-III ACTIVE TEST

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamps is turned ON.

- LH** : Turn signal lamps (LH) ON
- RH** : Turn signal lamps (RH) ON
- Off** : Turn signal lamps OFF

Is the inspection result normal?

- YES >> Turn signal lamp circuit is normal.
- NO >> Refer to [EXL-69. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006451733

#### 1. CHECK TURN SIGNAL LAMP BULB



Check the applicable lamp bulb.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Replace bulb.

#### 2. CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect front turn signal lamp connector, side turn signal lamp connector and rear combination lamp connector.
3. Turn ignition switch ON.
4. With operating the turn signal switch, check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
BCM					
Connector	Terminal				
B9*1 M69*2	49*1 60*2	Ground	Turn signal switch	LH	 <p style="text-align: right; font-size: small;">PKID0926E</p>
				OFF	0 V
	48*1 61*2			RH	 <p style="text-align: right; font-size: small;">PKID0926E</p>
				OFF	0 V

\*1: Without Intelligent Key

\*2: With Intelligent Key

# TURN SIGNAL LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 4.

## 3. CHECK TURN SIGNAL LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and front turn signal lamp, side turn signal lamp or rear combination lamp harness connector.

Front turn signal lamp

BCM			Front turn signal lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	B9*1 M69*2	48*1 61*2	E46	1	Existed
LH		49*1 60*2	E27		

Side turn signal lamp

BCM			Side turn signal lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	B9*1 M69*2	48*1 61*2	E40	1	Existed
LH		49*1 60*2	E23		

Rear turn signal lamp

BCM			Rear combination lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	B9*1 M69*2	48*1 61*2	B59	5	Existed
LH		49*1 60*2	B80		

\*1: Without Intelligent Key

\*2: With Intelligent Key

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM			Ground	Continuity
Connector		Terminal		
RH	B9*1 M69*2	48*1 61*2		Not existed
LH		49*1 60*2		

\*1: Without Intelligent Key

\*2: With Intelligent Key

Is the inspection result normal?

# TURN SIGNAL LAMP CIRCUIT

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

YES >> Check each bulb socket for internal short circuit, and if check result is normal, replace BCM. Refer to [BCS-93, "Removal and Installation"](#) (with Intelligent Key), [BCS-161, "Removal and Installation"](#) (without Intelligent Key).

NO >> Repair or replace harness.

## 5. CHECK TURN SIGNAL LAMP GROUND OPEN CIRCUIT

Check continuity between BCM harness connector and front turn signal lamp, side turn signal lamp or rear combination lamp and ground.

Front turn signal lamp

Front turn signal lamp			Ground	Continuity
Connector		Terminal		Existed
RH	E46	2		
LH	E27			

Side turn signal lamp

Side turn signal lamp			Ground	Continuity
Connector		Terminal		Existed
RH	E40	2		
LH	E23			

Rear turn signal lamp

Rear combination lamp			Ground	Continuity
Connector		Terminal		Existed
RH	B59	3		
LH	B80			

Is the inspection result normal?

YES >> Check corresponding bulb socket and harness. Repair or replace if necessary.

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN TYPE]

## HAZARD SWITCH

### Component Function Check

INFOID:000000006451734

#### 1.CHECK HAZARD SWITCH SIGNAL BY CONSULT-III

##### CONSULT-III DATA MONITOR

1. Turn the ignition switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.  
 NO >> Refer to [EXL-72, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006451735

#### 1.CHECK HAZARD SWITCH SIGNAL INPUT

1. Turn ignition switch OFF.
2. Disconnect hazard switch connector.
3. Check voltage between hazard switch connector and ground.

(+)		(-)	Voltage (Approx.)
Hazard switch			
Connector	Terminal	Ground	12 V
M45	2		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 2.

#### 2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between hazard switch harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M45	2	M65 <sup>*1</sup> M68 <sup>*2</sup>	29	Existed

\*1: Without Intelligent Key

\*2: With Intelligent Key

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M45	2		Not existed

Is the inspection result normal?

# HAZARD SWITCH

[HALOGEN TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace BCM. Refer to [BCS-93. "Removal and Installation"](#) (with Intelligent Key) or [BCS-161. "Removal and Installation"](#) (without Intelligent Key).
- NO >> Repair or replace harness.

## 4.CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		Existed
M45	1		

Is the inspection result normal?

- YES >> Replace hazard switch.
- NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS WITHOUT DAYTIME RUNNING LIGHT SYSTEM

#### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Symptom Table

INFOID:000000006451740

**CAUTION:**

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb</li> <li>• Harness between IPDM E/R and headlamp</li> <li>• Harness between headlamp and ground</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-45, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-78, "Diagnosis Procedure"</a> .	
High beam indicator lamp is not turned ON. [Headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "HI-BEAM IND"</li> <li>• BCM (HEADLAMP)</li> <li>• Active test "HEADLAMP"</li> </ul>
Headlamp (LO) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb</li> <li>• Harness between IPDM E/R and headlamp</li> <li>• Harness between headlamp and ground</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-47, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-79, "Diagnosis Procedure"</a> .	
Headlamp is not turned OFF.	When ignition switch is turned ON.	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-79, "Diagnosis Procedure"</a> .	
	When ignition switch is turned OFF.	IPDM E/R	—
Headlamp HI and LO are not turned ON.		<ul style="list-style-type: none"> <li>• Harness between headlamp and ground</li> <li>• Halogen bulb</li> </ul>	Headlamp ground circuit Refer to <a href="#">EXL-49, "Diagnosis Procedure"</a> .
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Front fog lamp bulb</li> <li>• Harness between front fog lamp relay and front fog lamp</li> </ul>	Front fog lamp circuit Refer to <a href="#">EXL-54, "Component Function Check"</a> .
	Both side	<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-82, "Diagnosis Procedure"</a> .	
Front fog lamp is not turned OFF.		<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-82, "Diagnosis Procedure"</a> .	
Parking lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Parking lamp bulb</li> <li>• Harness between IPDM E/R and parking lamp</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-58, "WITHOUT DAY-TIME RUNNING LIGHT SYSTEM : Component Function Check"</a> .
Tail lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Tail lamp bulb</li> <li>• Harness between IPDM E/R and rear combination lamp</li> <li>• IPDM E/R</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-61, "WITHOUT DAY-TIME RUNNING LIGHT SYSTEM : Component Function Check"</a> .
License plate lamp is not turned ON.		<ul style="list-style-type: none"> <li>• License plate lamp bulb</li> <li>• Harness between IPDM E/R and license plate lamp</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-65, "WITHOUT DAY-TIME RUNNING LIGHT SYSTEM : Component Function Check"</a> .

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Symptom	Possible cause	Inspection item
<ul style="list-style-type: none"> <li>Parking lamp, tail lamp and license plate lamp are not turned ON.</li> <li>Parking lamp, tail lamp and license plate lamp are not turned OFF.</li> </ul> (Each illumination is turned ON/OFF.)	<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-80, "WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"</a> .	
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> <li>Harness between BCM and each turn signal lamp</li> <li>Turn signal lamp bulb</li> </ul> Turn signal lamp circuit Refer to <a href="#">EXL-69, "Component Function Check"</a> .
	Indicator lamp is included.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul> Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Turn signal indicator lamp does not blink. (Turn signal indicator lamp is normal.)	One side	Combination meter  —
	Both sides (Always)	<ul style="list-style-type: none"> <li>Turn signal indicator lamp signal - BCM</li> <li>Combination meter</li> </ul> <ul style="list-style-type: none"> <li>Combination meter Data monitor "TURN IND"</li> <li>BCM (FLASHER) Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with the ignition switch OFF.)	<ul style="list-style-type: none"> <li>Combination meter power supply and ground circuit</li> <li>Combination meter</li> </ul> Combination meter Power supply and ground circuit Refer to <a href="#">MWI-51, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>Hazard warning lamp does not activate.</li> <li>Hazard warning lamp continues activating.</li> </ul> (Turn signal is normal.)	<ul style="list-style-type: none"> <li>Hazard switch</li> <li>Harness between hazard switch and BCM</li> <li>BCM</li> </ul> Hazard switch Refer to <a href="#">EXL-72, "Component Function Check"</a> .	
Rear fog lamp is not turned ON.	Rear fog lamp indicator lamp is normal.	<ul style="list-style-type: none"> <li>Harness between BCM and rear fog lamp</li> <li>Rear fog lamp bulb</li> <li>BCM</li> </ul> Rear fog lamp circuit Refer to <a href="#">EXL-56, "Component Function Check"</a> .
	Rear fog lamp indicator lamp is included.	<ul style="list-style-type: none"> <li>Combination switch</li> <li>Harness between combination switch and BCM</li> <li>BCM</li> </ul> Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Rear fog lamp indicator lamp is not turn ON. (Rear fog lamp turns ON)	<ul style="list-style-type: none"> <li>Rear fog lamp status signal</li> <li>Combination meter</li> <li>BCM</li> </ul>	<ul style="list-style-type: none"> <li>Combination meter Data monitor "RR FOG IND"</li> <li>BCM (HEAD LAMP) Active test "RR FOG LAMP"</li> </ul>

## WITH DAYTIME RUNNING LIGHT SYSTEM

### WITH DAYTIME RUNNING LIGHT SYSTEM : Symptom Table

INFOID:000000006479243

**CAUTION:**

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb</li> <li>• Harness between IPDM E/R and headlamp</li> <li>• Harness between headlamp and ground</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-45, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-78, "Diagnosis Procedure"</a> .	
High beam indicator lamp is not turned ON. [Headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "HI-BEAM IND"</li> <li>• BCM (HEADLAMP) Active test "HEADLAMP"</li> </ul>
Headlamp (LO) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb</li> <li>• Harness between IPDM E/R and headlamp</li> <li>• Harness between headlamp and ground</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-47, "Component Function Check"</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-79, "Diagnosis Procedure"</a> .	
Headlamp is not turned OFF.	When ignition switch is turned ON.	IPDM E/R	—
	When ignition switch is turned OFF.		
Headlamp HI and LO are not turned ON.		<ul style="list-style-type: none"> <li>• Harness between headlamp and ground</li> <li>• Halogen bulb</li> </ul>	Headlamp ground circuit Refer to <a href="#">EXL-49, "Diagnosis Procedure"</a> .
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Front fog lamp bulb</li> <li>• Harness between front fog lamp relay and front fog lamp</li> </ul>	Front fog lamp circuit Refer to <a href="#">EXL-54, "Component Function Check"</a> .
	Both side	<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-82, "Diagnosis Procedure"</a> .	
Front fog lamp is not turned OFF.			
Parking lamp is not turned ON.	Daytime running light relay		Daytime running light relay circuit Refer to <a href="#">EXL-50, "Component Function Check"</a> .
	<ul style="list-style-type: none"> <li>• Parking lamp bulb</li> <li>• Harness between parking lamp and daytime running relay</li> <li>• IPDM E/R</li> </ul>		Parking lamp circuit Refer to <a href="#">EXL-59, "WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"</a> .
Tail lamp is not turned ON.	Daytime running light relay		Daytime running light relay circuit Refer to <a href="#">EXL-50, "Component Function Check"</a> .
	<ul style="list-style-type: none"> <li>• Tail lamp bulb</li> <li>• Harness between daytime running relay and rear combination lamp</li> </ul>		Tail lamp circuit Refer to <a href="#">EXL-62, "WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"</a> .
License plate lamp is not turned ON.	Daytime running light relay		Daytime running light relay circuit Refer to <a href="#">EXL-50, "Component Function Check"</a> .
	<ul style="list-style-type: none"> <li>• License plate lamp bulb</li> <li>• Harness between daytime running relay and license plate lamp</li> </ul>		License plate lamp circuit Refer to <a href="#">EXL-66, "WITH DAYTIME RUNNING LIGHT SYSTEM : Component Function Check"</a> .

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Symptom	Possible cause	Inspection item
<ul style="list-style-type: none"> <li>• Parking lamp, tail lamp, lamp and the license plate lamp are not turned ON.</li> <li>• Parking lamp, tail lamp, lamp and license plate lamp are not turned OFF.</li> </ul>	Each illumination is turned ON/OFF	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between IPDM E/R and the daytime running light relay</li> <li>• Daytime running light relay</li> <li>• IPDM E/R</li> </ul> Daytime running light relay circuit Refer to <a href="#">EXL-50, "Component Function Check"</a> .
	Each illumination is not turned ON/OFF	<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-80, "WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure"</a> .
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> <li>• Harness between BCM and each turn signal lamp</li> <li>• Turn signal lamp bulb</li> </ul> Turn signal lamp circuit Refer to <a href="#">EXL-69, "Component Function Check"</a> .
	Indicator lamp is included.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Turn signal indicator lamp does not blink. (Turn signal indicator lamp is normal.)	One side	Combination meter  —
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn signal indicator lamp signal - BCM</li> <li>• Combination meter</li> </ul> <ul style="list-style-type: none"> <li>• Combination meter Data monitor "TURN IND"</li> <li>• BCM (FLASHER) Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with the ignition switch OFF.)	<ul style="list-style-type: none"> <li>• Combination meter power supply and ground circuit</li> <li>• Combination meter</li> </ul> Combination meter Power supply and ground circuit Refer to <a href="#">MWI-51, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate.</li> <li>• Hazard warning lamp continues activating. (Turn signal is normal.)</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch</li> <li>• Harness between hazard switch and BCM</li> <li>• BCM</li> </ul> Hazard switch Refer to <a href="#">EXL-72, "Component Function Check"</a> .	
Rear fog lamp is not turned ON.	Rear fog lamp indicator lamp is normal.	<ul style="list-style-type: none"> <li>• Harness between BCM and rear fog lamp</li> <li>• Rear fog lamp bulb</li> <li>• BCM</li> </ul> Rear fog lamp circuit Refer to <a href="#">EXL-56, "Component Function Check"</a> .
	Rear fog lamp indicator lamp is included.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-92, "Symptom Table"</a> .
Rear fog lamp indicator lamp is not turn ON. (Rear fog lamp turns ON)	<ul style="list-style-type: none"> <li>• Rear fog lamp status signal</li> <li>• Combination meter</li> <li>• BCM</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "RR FOG IND"</li> <li>• BCM (HEAD LAMP) Active test "RR FOG LAMP"</li> </ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

### Description

INFOID:000000006451741

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:000000006451742

#### 1.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

##### ⓅCONSULT-III DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	ON
		LO	OFF

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-93, "Removal and Installation"](#) (with Intelligent Key), [BCS-161, "Removal and Installation"](#) (without Intelligent Key).

#### 3.HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-45, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

# BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:000000006451743

Both side headlamps (LO) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000006451744

#### 1. CHECK COMBINATION SWITCH

Check the combination switch. Refer to [BCS-92, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

 CONSULT-III DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R data monitor item.

2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
HL LO REQ	Lighting switch	2ND ON
		OFF OFF

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-93, "Removal and Installation"](#) (with Intelligent Key), [BCS-161, "Removal and Installation"](#) (without Intelligent Key).

#### 3. HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-47, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON WITHOUT DAYTIME RUNNING LIGHT SYSTEM

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:000000006451745

The parking, license plate, tail lamps and each illumination are not turned ON in any condition.

### WITHOUT DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000006451746

#### 1.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-92. "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

##### ⓅCONSULT-III DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL & CLR REQ	Lighting switch	1ST	ON
		OFF	OFF

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Replace BCM. Refer to [BCS-93. "Removal and Installation"](#) (with Intelligent Key), [BCS-161. "Removal and Installation"](#) (without Intelligent Key).

## WITH DAYTIME RUNNING LIGHT SYSTEM

### WITH DAYTIME RUNNING LIGHT SYSTEM : Description

INFOID:000000006452140

The parking, license plate, tail lamps and each illumination are not turned ON in any condition.

### WITH DAYTIME RUNNING LIGHT SYSTEM : Diagnosis Procedure

INFOID:000000006452141

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92. "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

##### ⓅCONSULT-III DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-93. "Removal and Installation"](#) (with Intelligent Key), [BCS-161. "Removal and Installation"](#) (without Intelligent Key).

#### 3.DAYTIME RUNNING LIGHT RELAY CIRCUIT INSPECTION

# PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Check the daytime running light relay circuit. Refer to [EXL-50. "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

### Description

INFOID:000000006451747

The front fog lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000006451748

#### 1.CHECK FUSE

Check that the following fuse is fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	Fuse and fusible link block	#50	15 A

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the applicable circuit. And then replace the fuse.

#### 2.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-92. "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning part.

#### 3.CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

##### ⓅCONSULT-III DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R data monitor item.
2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR FOG REQ	Front fog lamp switch (with lighting switch 1ST)	ON	ON
		OFF	OFF

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Replace BCM. Refer to [BCS-93. "Removal and Installation"](#) (with Intelligent Key), [BCS-161. "Removal and Installation"](#) (without Intelligent Key).

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]

## PERIODIC MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### LHD

#### LHD : Description

INFOID:000000006451749

#### PREPARATION BEFORE ADJUSTING

##### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)


##### NOTE:

- Do not remove the temporary tire, jack and on-vehicle tool.
- Wipe out dirt on the headlamp.

##### CAUTION:

- **Never use organic solvent (thinner, gasoline etc.)**
- Ride alone on the driver seat.

#### AIMING ADJUSTMENT SCREW



A. Headlamp RH (INSIDE/OUTSIDE) adjustment screw

B. Headlamp RH (UP/DOWN) adjustment screw

C. Headlamp LH (INSIDE/OUTSIDE) adjustment screw

D. Headlamp LH (UP/DOWN) adjustment screw

↔ : Vehicle center

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]

Adjustment screw		Screw driver rotation	Facing direction
A	Headlamp RH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
B	Headlamp RH (INSIDE/OUTSIDE)	Clockwise	INSIDE
		Counterclockwise	OUTSIDE
C	Headlamp LH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
D	Headlamp LH (INSIDE/OUTSIDE)	Clockwise	INSIDE
		Counterclockwise	OUTSIDE

## LHD : Aiming Adjustment Procedure

INFOID:00000006451750

1. Place the screen.

**NOTE:**

- Stop the vehicle at the perpendicular angle to the wall.
- Set the screen so that it is perpendicular to a level load surface.

2. Face the vehicle squarely toward the screen and make the distance between the headlamp center and the screen 10 m (32.8 ft).

3. Start the engine and illuminate the headlamp (LO).

**NOTE:**

Block light from the headlamp that is not being adjusted with a thick fabric or another object, so that it does not reach the adjustment screen.


**CAUTION:**

**Do not cover lens surface with tape, etc. because it is made from plastic.**

4. Use the aiming adjustment screw to adjust the elbow point projected by the low beams on the screen, so that it is within the aiming adjustment area.

Low beam distribution on the screen


- A. Aiming adjustment area
- B. Elbow point
- C. Headlamp center
- H. Horizontal center line of headlamp
- V. Vertical center line of headlamp



# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]



- C. Vertical center line of headlamp    H. Horizontal center line of headlamp    L. Distance from headlamp center to screen  
 X. Aiming adjustment area (lateral)    Y. Aiming adjustment area (Vertical)

**Distance from headlamp center to screen (L) : 10 m (32.8 ft)**

Unit: mm (in)

Aiming adjustment area		
Vertical direction (Y) (Lower side from headlamp center height)		Lateral direction (X) (Right side from headlamp center line)
Highest light axis	100 (3.94)	0 - 100 (3.94)
Target light axis	100 (3.94)	
Lowest light axis	130 (5.12)	

## RHD

### RHD : Description

INFOID:000000006451751

### PREPARATION BEFORE ADJUSTING

#### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

#### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the headlamp.

#### CAUTION:

**Never use organic solvent (thinner, gasoline etc.)**


- Ride alone on the driver seat.

### AIMING ADJUSTMENT SCREW

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]



- A. Headlamp RH (INSIDE/OUTSIDE) adjustment screw      B. Headlamp RH (UP/DOWN) adjustment screw      C. Headlamp LH (INSIDE/OUTSIDE) adjustment screw
- D. Headlamp LH (UP/DOWN) adjustment screw
- ↔ : Vehicle center

Adjustment screw		Screw driver rotation	Facing direction
A	Headlamp RH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
B	Headlamp RH (INSIDE/OUTSIDE)	Clockwise	INSIDE
		Counterclockwise	OUTSIDE
C	Headlamp LH (INSIDE/OUTSIDE)	Clockwise	DOWN
		Counterclockwise	UP
D	Headlamp LH (UP/DOWN)	Clockwise	INSIDE
		Counterclockwise	OUTSIDE

## RHD : Aiming Adjustment Procedure

INFOID:000000006451752

- Place the screen.
 

**NOTE:**

  - Stop the vehicle at the perpendicular angle to the wall.
  - Set the screen so that it is perpendicular to a level load surface.
- Face the vehicle squarely toward the screen and make the distance between the headlamp center and the screen 10 m (32.8 ft).
- Start the engine and illuminate the headlamp (LO).
 

**NOTE:**

Block light from the headlamp that is not being adjusted with a thick fabric or another object, so that it does not reach the adjustment screen.

**CAUTION:**

# HEADLAMP AIMING ADJUSTMENT

[HALOGEN TYPE]



< PERIODIC MAINTENANCE >

**Do not cover lens surface with tape, etc. because it is made from plastic.**

4. Use the aiming adjustment screw to adjust the elbow point projected by the low beams on the screen, so that it is within the aiming adjustment area.

Low beam distribution on the screen

- A. Aiming adjustment area
- B. Elbow point
- C. Headlamp center
- H. Horizontal center line of headlamp
- V. Vertical center line of headlamp



- C. Vertical center line of headlamp
- H. Horizontal center line of headlamp
- L. Distance from headlamp center to screen
- X. Aiming adjustment area (lateral)
- Y. Aiming adjustment area (Vertical)

**Distance from headlamp center to screen (L) : 10 m (32.8 ft)**

Unit: mm (in)

Aiming adjustment area		
Vertical direction (Y) (Lower side from headlamp center height)		Lateral direction (X) (Left side from headlamp center line)
Highest light axis	100 (3.94)	0 - 100 (3.94)
Target light axis	100 (3.94)	
Lowest light axis	130 (5.12)	

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN TYPE]

## FRONT FOG LAMP AIMING ADJUSTMENT

### Description

INFOID:000000006451753

### PREPARATION BEFORE ADJUSTING

#### NOTE:

For details, refer to the regulations in your own country.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

#### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the headlamp.

#### CAUTION:

**Never use organic solvent (thinner, gasoline etc.)**

- Ride alone on the driver seat.

### AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: DOWN

B: UP

- For the position and direction of the adjusting screw, refer to the figure.

#### NOTE:

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



### Aiming Adjustment Procedure

INFOID:000000006451754

1. Place the screen.

#### NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the engine. Illuminate the front fog lamp.

#### CAUTION:

**Never cover the lens surface with a tape etc. The lens is made of resin.**

#### NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 200 mm (7.87 in).

Front fog lamp light distribution on the screen


A : Cutoff line

B : High illuminance area

H : Horizontal center line of front fog lamp

V : Vertical center line of front fog lamp

X : Cutoff line height



# HEADLAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]


## REMOVAL AND INSTALLATION

### HEADLAMP

Exploded View

INFOID:000000006466834

#### REMOVAL




1. Headlamp assembly

2. EPT sealer [2.8 mm (0.110 in)]

⊗ : Do not reuse

🔧 : N·m (kg·m, in·lb)

#### DISASSEMBLY



1. Back cover

2. Halogen bulb

3. Headlamp housing assembly

4. Retaining spring

5. EPT sealer [2.8 mm (0.110 in)]

⊗ : Do not reuse

#### Removal and Installation

INFOID:000000006466835

**CAUTION:**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

**Disconnect the battery negative terminal or the fuse.**

## REMOVAL

1. Remove front bumper fascia. Refer to [EXT-13, "Removal and Installation"](#).
2. Remove headlamp mounting bolts.
3. Pull out the headlamp assembly forward the vehicle, and then disconnect the connector before removing the headlamp assembly.

## INSTALLATION

Note the following item, and then install in the reverse order of removal.

### **CAUTION:**

**After installation, perform aiming adjustment. Refer to [EXL-83, "LHD : Description"](#).**

## Replacement

INFOID:000000006466836

### **CAUTION:**

- **Disconnect the battery negative terminal or remove the fuse.**
- **After installing the bulb, install the resin cap and the bulb socket securely for watertightness.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

## HEADLAMP BULB

1. Disconnect headlamp bulb connector.
2. Remove back cover.
3. Remove retaining spring lock, and then remove bulb from the headlamp housing assembly.

## Disassembly and Assembly

INFOID:000000006466837

### DISASSEMBLY

1. Remove back cover.
2. Remove retaining spring lock, and then remove bulb from the headlamp housing assembly.

### ASSEMBLY

Note the following item, and then assemble in the reverse order of disassembly.

### **CAUTION:**

**After installing the bulb, install the resin cap and the bulb socket securely for watertightness.**

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN TYPE]

## FRONT COMBINATION LAMP

Exploded View

INFOID:000000006466838


### REMOVAL



1. Front combination lamp

 : N·m (kg-m, in-lb)

### DISASSEMBLY



1. Parking lamp bulb

2. Parking lamp bulb socket

3. Front turn signal lamp bulb socket

4. Front turn signal lamp bulb

5. Front combination lamp housing

### Removal and Installation

INFOID:000000006466839

**CAUTION:**  
Disconnect the battery negative terminal or remove the fuse.

### REMOVAL

1. Remove front bumper fascia. Refer to [EXT-13, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT COMBINATION LAMP

[HALOGEN TYPE]

## < REMOVAL AND INSTALLATION >

2. Remove front combination lamp mounting bolts and nut.
3. Pull out front combination lamp assembly forward the vehicle, and then disconnect the connector before removing the headlamp assembly.

### INSTALLATION

Note the following items, and then install in the reverse order of removal.

#### **CAUTION:**

**Interference of front combination lamp lens with front fender may cause intrusion of water into front combination lamp or rusting of fender due to damage of painted surface. Be careful to operate without allowing parts to interfere with each other.**

### Replacement

INFOID:000000006466840

#### **CAUTION:**

- **Disconnect the battery negative terminal or remove the fuse.**
- **After installing the bulb, install the resin cap and the bulb socket securely for watertightness.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

### PARKING LAMP BULB

1. Rotate the parking lamp bulb socket counterclockwise and unlock it.
2. Remove parking lamp bulb from the bulb socket.

### FRONT TURN SIGNAL LAMP BULB

1. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
2. Remove front turn signal lamp bulb from the front turn signal lamp bulb socket.

### Disassembly and Assembly

INFOID:000000006466841

### DISASSEMBLY

1. Rotate the parking lamp bulb socket counterclockwise and unlock it.
2. Remove parking lamp bulb from the bulb socket.
3. Rotate the front turn signal lamp bulb socket counterclockwise and unlock it.
4. Remove front turn signal lamp bulb from the front turn signal lamp bulb socket.

### ASSEMBLY

Note the following item and then, install in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install the resin cap and the bulb socket securely for watertightness.**

# FRONT FOG LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## FRONT FOG LAMP

Exploded View

INFOID:000000006483048



- |                            |               |                              |
|----------------------------|---------------|------------------------------|
| 1. Front fog lamp assembly | 2. Metal clip | 3. Front fog lamp bulb       |
| 4. Front fog lamp bracket  | 5. U nut      | 6. Front bumper fascia lower |

 : Pawl

 : N·m (kg·m, in·lb)

## Removal and Installation

INFOID:000000006483049

**CAUTION:**  
Disconnect the battery negative terminal or remove the fuse.

### REMOVAL

1. Remove front fender protector. Keep the service area. Refer to [EXT-22. "Removal and Installation"](#).
2. Disconnect front fog lamp harness connector.
3. Remove front fog lamp bracket.
4. Remove front fog lamp mounting bolt, and then remove front fog lamp from front fog lamp bracket.

### INSTALLATION

Note the following item, and then installation is the reverse order of removal.

#### NOTE:

After installation, perform aiming adjustment. Refer to [EXL-88. "Description"](#)

## Replacement

INFOID:000000006483050

#### CAUTION:

- Disconnect the battery negative terminal or remove the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### FRONT FOG LAMP BULB


1. Remove fender protector. Keep the service area. Refer to [EXT-22. "Removal and Installation"](#).

## FRONT FOG LAMP

### < REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

2. Remove front fog lamp bulb connector (1).
3. Rotate the bulb (2) counterclockwise and unlock it.



# LIGHT & RAIN SENSOR

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## LIGHT & RAIN SENSOR


### Exploded View

INFOID:000000006658845

#### CAUTION:

When the light & rain sensor is removed from windshield, the light & rain sensor cannot be re-used.

#### REMOVAL



1. Light & rain sensor bracket
2. Mirror base
3. Light & rain sensor
4. Inside mirror assembly

 : Pawl

 : Do not reuse

### Removal and Installation

INFOID:000000006658846

#### REMOVAL

1. Remove inside mirror assembly. Refer to [MIR-41, "Removal and Installation"](#).
2. Disconnect light & rain sensor connector.
3. Disengage both sides of metal spring clips, and remove the light & rain sensor from the windshield.

#### INSTALLATION

Note the following items, and the install in the reverse order of removal.

#### CAUTION:

- Surface of windshield should be cleaned.
- Never touch gel/adhesive of new part.
- Lock the metal spring clips and install the light & rain sensor securely.

## LIGHTING & TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

---

### LIGHTING & TURN SIGNAL SWITCH

#### Removal and Installation

INFOID:000000006466844

#### REMOVAL

Remove light & turn signal switch. Refer to [BCS-94. "Removal and Installation"](#).

#### INSTALLATION

Install in the reverse order of removal.

# HAZARD SWITCH


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## HAZARD SWITCH

Exploded View

INFOID:000000006466845



- 1. Instrument panel assembly
- 2. Hazard switch

 : Pawl

## Removal and Installation

INFOID:000000006466846

### REMOVAL

1. Remove Audio unit. Refer to [AV-38, "Removal and Installation"](#).
2. Disengage fixing pawls, and then remove hazard switch from instrument panel inside to outside.

### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# SIDE TURN SIGNAL LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## SIDE TURN SIGNAL LAMP

Exploded View

INFOID:000000006466847



1. Side turn signal lamp bulb
2. Side turn signal lamp housing

## Removal and Installation

INFOID:000000006466848

**CAUTION:**  
Disconnect battery negative terminal or remove the fuse.


### REMOVAL

1. Remove the side turn signal lamp in numerical order shown in the figure.
2. Rotate the bulb socket counterclockwise and unlock it.

**NOTE:**

Support side turn signal lamp harness with tape so that it won't fall into the front fender.

- ← : Vehicle front (side turn signal lamp LH)  
→ : Vehicle rear (side turn signal lamp RH)



### INSTALLATION

1. Rotate the bulb socket clockwise and lock it.
2. Fix the pawl-side behind the side turn signal lamp housing first, then push the resin clip-side.

## Replacement

INFOID:000000006466849

**CAUTION:**

- Disconnect the battery negative terminal or the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### SIDE TURN SIGNAL LAMP BULB

1. Remove side turn signal lamp. Refer to [EXL-98, "Removal and Installation"](#).
2. Remove bulb from the bulb socket.

# HEADLAMP AIMING SWITCH


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## HEADLAMP AIMING SWITCH

Exploded View

INFOID:000000006466850



1. Headlamp aiming switch
2. Instrument lower panel assembly LH

 : Pawl

## Removal and Installation

INFOID:000000006466851

### REMOVAL

1. Remove instrument lower panel (LH/RH). Refer to [IP-13, "Removal and Installation"](#).
2. Remove headlamp aiming switch fixing clips, and then remove headlamp aiming switch from instrument lower panel (LH/RH).

### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN TYPE]

## REAR COMBINATION LAMP

Exploded View

INFOID:000000006466852

### REMOVAL



1. Grommet


2. Grommet

3. Rear combination lamp

○ : Clip

□ : N·m (kg-m, in-lb)

### DISASSEMBLY



1. Rear combination lamp housing assembly

2. Back-up lamp bulb

3. Harness connector

4. Rear turn signal lamp bulb

5. Stop/tail lamp bulb

### Removal and Installation

INFOID:000000006466853

#### CAUTION:

- Disconnect the battery negative terminal or the fuse.
- When removing, always use a remover tool that is made of plastic.

### REMOVAL

1. Full open back door.

# REAR COMBINATION LAMP

[HALOGEN TYPE]

## < REMOVAL AND INSTALLATION >

2. Remove luggage side lower finisher. Refer to [INT-31, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#). A
3. Remove rear combination lamp mounting bolts.
4. Insert a remover tool into the rear combination lamp rear fender to disengage the clips.
5. Pull up rear combination lamp, and then remove rear combination lamp. B
6. Disconnect rear combination lamp connector.

## INSTALLATION

Install in the reverse order of removal. C

## Replacement

INFOID:000000006466854

### CAUTION:

- Disconnect the battery negative terminal or the fuse.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned off.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one. D

## STOP/TAIL LAMP BULB

1. Remove rear combination lamp assembly. Refer to [EXL-100, "Removal and Installation"](#). E
2. Rotate stop/tail lamp bulb socket counterclockwise, and then remove stop/tail lamp bulb socket. F
3. Remove stop/tail lamp bulb from stop/tail lamp bulb socket. G

## REAR TURN SIGNAL LAMP BULB

1. Remove rear combination lamp assembly. Refer to [EXL-100, "Removal and Installation"](#). H
2. Rotate rear turn signal lamp bulb socket counterclockwise, and then remove rear turn signal lamp bulb socket. I
3. Remove rear turn signal lamp bulb from rear turn signal lamp bulb socket.

## BACK-UP LAMP BULB

1. Remove rear combination lamp assembly. Refer to [EXL-100, "Removal and Installation"](#). J
2. Rotate back-up lamp bulb socket counterclockwise, and then remove back-up lamp bulb socket.
3. Remove back-up lamp bulb from back-up lamp bulb socket. K

EXL

M

N

O

P

# HIGH-MOUNTED STOP LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:000000006466855



1. High-mounted stop lamp

2. Seal packing

 : N·m (kg·m, in·lb)

## Removal and Installation

INFOID:000000006466856

### CAUTION:

**Disconnect battery negative terminal or remove the fuse.**

### REMOVAL

1. Remove blind seal from back door inside.

### CAUTION:

**Be careful not to damage the blind seal, so that it can be reused.**

2. Remove high-mounted stop lamp mounting nuts and connector.

3. Pull high-mounted stop lamp toward vehicle upside, and then remove high-mounted stop lamp.

### INSTALLATION

Note the following item and then, install in the reverse order of removal.

### CAUTION:

**Seal packing cannot be reused.**

# LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## LICENSE PLATE LAMP

Exploded View

INFOID:000000006466857



1. License plate lamp housing assembly      2. Bulb      3. License plate lamp bulb socket

 : Pawl

## Removal and Installation


INFOID:000000006466858

### CAUTION:

**Disconnect battery negative terminal or remove the fuse.**

### REMOVAL

1. While pressing the license plate lamp to direction right side, pull it to direction outside and then remove it.
2. Disconnect license plate lamp connector.



### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000006466859

### CAUTION:

- **Disconnect the battery negative terminal or the fuse.**
- **Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.**
- **Never touch bulb by hand while it is lit or right after being turned off.**
- **Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

### LICENSE PLATE LAMP BULB

1. Remove license plate lamp.
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove the bulb from the socket.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR FOG LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN TYPE]

## REAR FOG LAMP

Exploded View


INFOID:000000006466759

### REMOVAL



1. Rear fog lamp

### DISASSEMBLY



1. Rear fog lamp housing
2. Rear fog lamp bulb
3. Rear fog lamp bulb socket

### Removal and Installation

INFOID:000000006482932

#### **CAUTION:**

**Disconnect battery negative terminal or remove the fuse.**

#### REMOVAL

1. Insert any appropriate tool into the gap between the rear fog lamp housing. And pull off the rear fog lamp from the vehicle.
2. Disconnect the rear fog lamp connector.

#### INSTALLATION

Installation is the reverse order of removal.

# REAR FOG LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN TYPE]

## Replacement

INFOID:000000006482933

### **CAUTION:**

**Disconnect battery negative terminal or remove the fuse.**

### REAR FOG LAMP BULB

1. Remove rear fog lamp.
2. Rotate the bulb socket counterclockwise and unlock it.
3. Remove bulb from its socket.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[HALOGEN TYPE]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:000000006451782

Item	Type	Wattage (W)
Headlamp (HI/LO)	H4	60/55
Front combination lamp	Front turn signal lamp	PY21W (Amber)
	Parking lamp	W5W
Front fog lamp	H8	35
Side turn signal lamp	WY5W (Amber)	5
Rear combination lamp	Stop lamp/Tail lamp	W21/5W
	Rear turn signal lamp	W21W
	Back-up lamp	W16W
License plate lamp	W5W	5
High-mounted stop lamp	LED	—
Rear fog lamp	W21W	21