

# SECTION MWI

## METER, WARNING LAMP & INDICATOR

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

### CONTENTS

|  |    |   |    |
|--|----|---|----|
| <b>PRECAUTION</b> .....  | 3  | SEAT BELT WARNING LAMP : System Description .....     | 13 |
| <b>PRECAUTIONS</b> .....   | 3  | <b>METER ILLUMINATION CONTROL</b> .....               | 14 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... | 3  | METER ILLUMINATION CONTROL : System Diagram .....     | 14 |
| <b>SYSTEM DESCRIPTION</b> .....  | 4  | METER ILLUMINATION CONTROL : System Description ..... | 14 |
| <b>COMPONENT PARTS</b> .....   | 4  | <b>METER EFFECT FUNCTION</b> .....                    | 15 |
| <b>METER SYSTEM</b> .....  | 4  | METER EFFECT FUNCTION : System Diagram .....          | 15 |
| METER SYSTEM : Component Parts Location .....  | 4  | METER EFFECT FUNCTION : System Description .....      | 15 |
| METER SYSTEM : Component Description .....   | 5  | <b>INFORMATION DISPLAY</b> .....                      | 16 |
| <b>SYSTEM</b> .....  | 7  | INFORMATION DISPLAY : System Diagram .....            | 16 |
| <b>METER SYSTEM</b> .....  | 7  | INFORMATION DISPLAY : System Description .....        | 16 |
| METER SYSTEM : System Diagram .....  | 7  | <b>OPERATION</b> .....                                | 21 |
| METER SYSTEM : System Description .....  | 7  | Switch Name and Function .....                        | 21 |
| METER SYSTEM : Fail-Safe .....   | 9  | <b>DIAGNOSIS SYSTEM (COMBINATION METER)</b> .....     | 22 |
| <b>SPEEDOMETER</b> .....   | 10 | On Board Diagnosis Function .....                     | 22 |
| SPEEDOMETER : System Diagram .....   | 11 | CONSULT-III Function .....                            | 23 |
| SPEEDOMETER : System Description .....   | 11 | <b>ECU DIAGNOSIS INFORMATION</b> .....                | 28 |
| <b>TACHOMETER</b> .....  | 11 | <b>COMBINATION METER</b> .....                        | 28 |
| TACHOMETER : System Diagram .....  | 11 | Reference Value .....                                 | 28 |
| TACHOMETER : System Description .....  | 11 | Fail-Safe .....                                       | 35 |
| <b>SHIFT POSITION INDICATOR</b> .....  | 11 | DTC Index .....                                       | 36 |
| SHIFT POSITION INDICATOR : System Diagram .....  | 11 | <b>IPDM E/R</b> .....                                 | 38 |
| SHIFT POSITION INDICATOR : System Description .....  | 11 | List of ECU Reference .....                           | 38 |
| <b>OIL PRESSURE WARNING LAMP</b> .....   | 12 | <b>WIRING DIAGRAM</b> .....                           | 39 |
| OIL PRESSURE WARNING LAMP : System Diagram .....   | 12 | <b>METER SYSTEM</b> .....                             | 39 |
| OIL PRESSURE WARNING LAMP : System Description .....   | 12 | Wiring Diagram .....                                  | 39 |
| <b>SEAT BELT WARNING LAMP</b> .....  | 13 | <b>BASIC INSPECTION</b> .....                         | 42 |
| SEAT BELT WARNING LAMP : System Diagram .....  | 13 |   |    |

MWI

|   |    |  |    |
|---|----|--|----|
| <b>DIAGNOSIS AND REPAIR WORKFLOW (METER SYSTEM)</b> ..... | 42 | <b>SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT (DRIVER SIDE)</b> .....          | 58 |
| Work flow .....   | 42 | Component Function Check .....   | 58 |
| <b>DTC/CIRCUIT DIAGNOSIS</b> .....                        | 44 | Diagnosis Procedure .....  | 58 |
| <b>U1000 CAN COMM CIRCUIT</b> .....                       | 44 | Component Inspection .....   | 59 |
| Description .....   | 44 | <b>SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT (PASSENGER SIDE)</b> .....       | 60 |
| DTC Logic .....   | 44 | Diagnosis Procedure .....  | 60 |
| Diagnosis Procedure .....                                 | 44 | Component Inspection (Seat Belt Buckle Switch)...                          | 60 |
| <b>U1010 CONTROL UNIT (CAN)</b> .....                     | 45 | Component Inspection (Occupant Detection Unit)...                          | 61 |
| Description .....   | 45 | <b>A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT</b> .....           | 62 |
| DTC Logic .....   | 45 | Diagnosis Procedure .....  | 62 |
| Diagnosis Procedure .....                                 | 45 | <b>PTC HEATER CONTROL UNIT CONNECTION RECOGNITION SIGNAL CIRCUIT</b> ..... | 63 |
| <b>B2205 VEHICLE SPEED</b> .....                          | 46 | Diagnosis Procedure .....  | 63 |
| Description .....   | 46 | <b>SYMPTOM DIAGNOSIS</b> .....   | 64 |
| DTC Logic .....   | 46 | <b>THE FUEL GAUGE INDICATOR DOES NOT OPERATE</b> .....                     | 64 |
| Diagnosis Procedure .....                                 | 46 | Description .....  | 64 |
| <b>B2267 ENGINE SPEED</b> .....                           | 47 | Diagnosis Procedure .....  | 64 |
| Description .....   | 47 | <b>THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON</b> .....                | 65 |
| DTC Logic .....   | 47 | Description .....  | 65 |
| Diagnosis Procedure .....                                 | 47 | Diagnosis Procedure .....  | 65 |
| <b>B2268 WATER TEMP</b> .....                             | 48 | <b>THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF</b> .....               | 66 |
| Description .....   | 48 | Description .....  | 66 |
| DTC Logic .....   | 48 | Diagnosis Procedure .....  | 66 |
| Diagnosis Procedure .....                                 | 48 | <b>THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT</b> .....                  | 67 |
| <b>B2321, B2322 OIL LEVEL SENSOR</b> .....                | 49 | Description .....  | 67 |
| Description .....   | 49 | Diagnosis Procedure .....  | 67 |
| DTC Logic .....   | 49 | <b>NORMAL OPERATING CONDITION</b> .....                                    | 68 |
| Diagnosis Procedure .....                                 | 49 | <b>INFORMATION DISPLAY</b> .....   | 68 |
| Component Inspection .....                                | 50 | INFORMATION DISPLAY : Description .....                                    | 68 |
| <b>POWER SUPPLY AND GROUND CIRCUIT</b> ....               | 51 | <b>REMOVAL AND INSTALLATION</b> .....                                      | 69 |
| <b>COMBINATION METER</b> .....                            | 51 | <b>COMBINATION METER</b> .....   | 69 |
| COMBINATION METER : Diagnosis Procedure ...               | 51 | Exploded View .....  | 69 |
| <b>FUEL LEVEL SENSOR SIGNAL CIRCUIT</b> .....             | 52 | Removal and Installation .....   | 69 |
| Component Function Check .....                            | 52 | Disassembly and Assembly .....   | 70 |
| Diagnosis Procedure .....                                 | 52 |  |    |
| Component Inspection .....                                | 54 |  |    |
| <b>OIL PRESSURE SWITCH SIGNAL CIRCUIT</b> ...             | 56 |  |    |
| Component Function Check .....                            | 56 |  |    |
| Diagnosis Procedure .....                                 | 56 |  |    |
| Component Inspection .....                                | 56 |  |    |

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006506714

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

The vehicle may be equipped with a passenger air bag deactivation switch. Because no rear seat exists where a rear-facing child restraint can be placed, the switch is designed to turn off the passenger air bag so that a rear-facing child restraint can be used in the front passenger seat. The switch is located in the center of the instrument panel, near the ashtray. When the switch is turned to the ON position, the passenger air bag is enabled and could inflate for certain types of collision. When the switch is turned to the OFF position, the passenger air bag is disabled and will not inflate. A passenger air bag OFF indicator on the instrument panel lights up when the passenger air bag is switched OFF. The driver air bag always remains enabled and is not affected by the passenger air bag deactivation switch.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.
- The vehicle may be equipped with a passenger air bag deactivation switch which can be operated by the customer. When the passenger air bag is switched OFF, the passenger air bag is disabled and will not inflate. When the passenger air bag is switched ON, the passenger air bag is enabled and could inflate for certain types of collision. After SRS maintenance or repair, make sure the passenger air bag deactivation switch is in the same position (ON or OFF) as when the vehicle arrived for service.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### METER SYSTEM

#### METER SYSTEM : Component Parts Location

INFOID:000000006412889



1. Fuel level sensor unit (main)
2. Front seat belt buckle switch (passenger side)
3. CVT shift selector assembly  
Refer to [TM-131, "CVT CONTROL SYSTEM : Component Parts Location"](#) (MR16DDT engine models).  
Refer to [TM-314, "CVT CONTROL SYSTEM : Component Parts Location"](#) (HR16DE engine models).
4. Occupant detection unit (Under the passenger seat cushion pad)
5. A/C auto amp.  
Refer to [HAC-12, "Component Parts Location"](#) (4WD models).  
Refer to [HAC-103, "AUTOMATIC AIR CONDITIONING SYSTEM : Component Parts Location"](#) (2WD models).
6. ECM  
Refer to [EC-455, "ENGINE CONTROL SYSTEM : Component Parts Location"](#) (HR16DE engine models).  
Refer to [EC-813, "Component Parts Location"](#) (K9K engine models).
7. IPDM E/R  
Refer to [PCS-5, "Component Parts Location"](#) (with I-KEY).  
Refer to [PCS-37, "Component Parts Location"](#) (without I-KEY).
8. Oil pressure switch  
Refer to [EM-103, "Exploded View"](#) (MR16DDT engine models).  
Refer to [EM-227, "Exploded View"](#) (HR16DE engine models).  
Refer to [LU-37, "Exploded View"](#) (K9K engine models).
9. Oil level sensor  
Refer to [EM-99, "Exploded View"](#) (MR16DDT engine models).  
Refer to [EM-222, "Exploded View"](#) (HR16DE engine models).  
Refer to [EM-330, "Disassembly and Assembly"](#) (K9K engine models).

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

- |  |  |  |                   |
|--|--|--|-------------------|
| <p>10. ECM<br/>Refer to <a href="#">EC-25, "ENGINE CONTROL SYSTEM : Component Parts Location"</a> (MR16DDT engine models).</p>   | <p>11. Ambient sensor<br/>Refer to <a href="#">HAC-12, "Component Parts Location"</a> (2WD models).<br/>Refer to <a href="#">HAC-103, "AUTOMATIC AIR CONDITIONING SYSTEM : Component Parts Location"</a> (4WD models).</p>                               | <p>12. ABS actuator and electric unit (control unit)<br/>Refer to <a href="#">BRC-97, "Component Parts Location"</a> (with ESP).<br/>Refer to <a href="#">BRC-9, "Component Parts Location"</a> (without ESP).</p> | <p>A</p> <p>B</p> |
| <p>13. TCM<br/>Refer to <a href="#">TM-131, "CVT CONTROL SYSTEM : Component Parts Location"</a> (for RE0F10B models)<br/>Refer to <a href="#">TM-314, "CVT CONTROL SYSTEM : Component Parts Location"</a> (for RE0F11A models)</p> | <p>14. BCM<br/>Refer to <a href="#">BCS-6, "BODY CONTROL SYSTEM : Component Parts Location"</a> (with intelligent key system)<br/>Refer to <a href="#">BCS-96, "BODY CONTROL SYSTEM : Component Parts Location"</a> (without intelligent key system)</p> | <p>15. Combination meter</p>   | <p>C</p> <p>D</p> |
| <p>16. Front seat belt buckle switch (driver side)<br/>A. Rear seat (bottom)</p>   | <p>17. Fuel level sensor unit (sub)</p>  |  | <p>E</p>          |

## METER SYSTEM : Component Description

INFOID:000000006412890

| Unit  | Description   |
|---|---|
| Combination meter                             | <ul style="list-style-type: none"> <li>Provides the driver with various kinds of vehicle information via the CAN communication line and the use of signals through the hard wire.</li> <li>Includes the signal buffer to transmit received signals to other units.</li> <li>For functions of the combination meter, refer to <a href="#">MWI-7, "METER SYSTEM : System Description"</a>.</li> </ul> |
| ECM   | Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> <li>Engine speed signal</li> <li>Engine coolant temperature signal</li> <li>Engine status signal</li> <li>Fuel consumption monitor signal</li> <li>Oil pressure warning lamp signal</li> </ul>   |
| ABS actuator and electric unit (control unit) | Transmits the vehicle speed signal to the combination meter via CAN communication.  |
| IPDM E/R (K9K engine models)                  | Transmits the oil pressure switch signal to the BCM via CAN communication.  |
| BCM   | Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> <li>Oil pressure switch signal (K9K engine models)</li> <li>Position light request signal</li> </ul>   |
| TCM   | Transmits the following signals to the combination meter. <ul style="list-style-type: none"> <li>Shift position signal</li> <li>Manual mode shift refusal signal</li> <li>Manual mode signal</li> <li>Non-manual mode signal</li> <li>Manual mode shift up signal</li> <li>Manual mode shift down signal</li> </ul>   |
| CVT shift selector (with manual mode)         | Transmits the following signals to the combination meter. <ul style="list-style-type: none"> <li>Manual mode signal</li> <li>Non-manual mode signal</li> <li>Manual mode shift up signal</li> <li>Manual mode shift down signal</li> </ul>  |
| Fuel level sensor unit                        | Transmits the fuel level sensor signal to the combination meter.  |
| Oil pressure switch (K9K engine models)       | Transmits the oil pressure switch signal to the IPDM E/R.   |
| Oil level sensor                              | Transmits the oil level sensor signal to the combination meter.   |
| Ambient sensor                                | Transmits the ambient sensor signal to the A/C auto amp. and the combination meter.   |
| PTC heater control unit                       | Transmits the PTC heater control unit connection recognition signal to the combination meter.   |
| A/C auto amp.                                 | Transmits the A/C auto amp. connection recognition signal to the combination meter.   |
| Seat belt buckle switch (driver side)         | Transmits the seat belt buckle switch signal (driver side) to the combination meter.  |

MWI

## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

| Unit                                     | Description  |
|--|--|
| Seat belt buckle switch (passenger side) | Transmits the seat belt buckle switch signal (passenger side) to the combination meter.  |
| Occupant detection unit                  | Transmits the occupant detection signal to the seat belt buckle switch (passenger side). |

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### METER SYSTEM

#### METER SYSTEM : System Diagram

INFOID:000000006412892



\*: K9K engine models

#### METER SYSTEM : System Description

INFOID:000000006412893

##### COMBINATION METER

- The combination meter receives necessary signals from each unit, switch, and sensor to control the following functions.
  - Measuring instruments
  - Shift position indicator
  - Warning lamps
  - Indicator lamps
  - Meter illumination control
  - Meter effect function
  - Information display
- The combination meter incorporates a buzzer function that sounds an audible alarm with the integrated buzzer device. Refer to [WCS-5. "Combination Meter"](#) for further details.
- The combination meter includes an on board diagnosis function.
- The combination meter can be diagnosed with CONSULT-III.

##### METER CONTROL FUNCTION LIST

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SYSTEM

## < SYSTEM DESCRIPTION >


| System                                |  | Description  | Reference   |
|---------------------------------------|--|--|---|
| Measuring instruments                 | Speedometer                                | Indicates vehicle speed.   | <a href="#">MWI-11. "SPEEDOMETER : System Description"</a>                |
|                                       | Tachometer                                 | Indicates engine speed.  | <a href="#">MWI-11. "TACHOMETER : System Description"</a>                 |
| Shift position indicator (CVT models) |  | Display shift position. (CVT models)   | <a href="#">MWI-11. "SHIFT POSITION INDICATOR : System Description"</a>   |
| Warning lamp/indicator lamp           | Oil pressure warning lamp                  | The warning lamp turns ON or turns OFF, according to engine hydraulic pressure.                                | <a href="#">MWI-12. "OIL PRESSURE WARNING LAMP : System Description"</a>  |
|                                       | Seat belt warning lamp                     | The warning lamp turns ON/OFF or blinks depending on vehicle speeds and conditions of the use of seat belts.   | <a href="#">MWI-13. "SEAT BELT WARNING LAMP : System Description"</a>     |
| Meter illumination control            | Meter illumination control function        | Switches back and forth between daytime mode and nighttime mode, according to a light switch position.         | <a href="#">MWI-14. "METER ILLUMINATION CONTROL : System Description"</a> |
|                                       | Meter illumination on/off control function | The meter illumination turns ON/OFF, according to the status of ignition switch and a cranking condition.      |   |
|                                       | Buck light illumination control function   | The operation of the illumination control switch allows the brightness adjustment of meter illumination.       |   |
| Meter effect function                 | Engine-start effect function               | Controls pointers of combination meter and meter illumination at engine start to produce illumination effects. | <a href="#">MWI-15. "METER EFFECT FUNCTION : System Description"</a>      |

# SYSTEM

## < SYSTEM DESCRIPTION >

| System              |   | Description   | Reference   |  |   |
|---------------------|---|---|---|--|---|
| Information display | Engine coolant temperature gauge            | Indicates engine coolant temperature.                                   | MWI-16. "INFORMATION DISPLAY : System Description"                                  |  |   |
|                     | Fuel gauge                                  | Indicates fuel level.   |   |  |   |
|                     | Odo/trip meter                              | Displays mileage.   |   |  |   |
|                     | Ambient temperature                         | Displays ambient temperature.   |   |  |   |
|                     | Trip computer                               | Current fuel consumption  |   | Displays current fuel consumption.                                     |   |
|                     |   | Average fuel consumption  |   | Displays average fuel consumption.                                     |   |
|                     |   | Distance to empty   |   | Displays distance to empty.  |   |
|                     |   | Travel time   |   | Displays travel time.  |   |
|                     |   | Torque distribution indicator   |   | Display torque distribution.   |   |
|                     | Interrupt indication                        | Low fuel warning  |   | Warns when being low on fuel.  |   |
|                     |   | Distance to empty   |   | Displays distance to empty when a low fuel warning starts.             |   |
|                     |   | Low ambient temperature (ICY)   |   | Causes an interrupt when ambient temperature reaches below 3°C (37°F). |   |
|                     |   | Maintenance   |   | Engine oil maintenance warning   | Causes an interrupt when exceeding randomly set distance. |
|                     |   |   |   | Oil level indicator  | Display engine oil level.                                 |
|                     |   | Meter illumination level  |   | Indicates the brightness of the meter illumination in stages.          |   |
|                     | Oil maintenance warning (K9K engine models) | Receives remaining distance signal and display oil maintenance warning. |   |  |   |
| Setting             | Maintenance                                 | Engine oil maintenance warning (except for K9K engine models)           | Setting values for engine oil maintenance can be adjusted to meet the user's needs. |  |   |

## ARRANGEMENT OF COMBINATION METER



- A. MR16DDT engine models with manual mode CVT      B. K9K engine models      C. RHD models with CVT

## METER SYSTEM : Fail-Safe

INFOID:000000006412894

### FAIL-SAFE

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

# SYSTEM

## < SYSTEM DESCRIPTION >

| Function                         |  | Specifications  |
|----------------------------------|--|---|
| Speedometer                      |  | Reset to zero by suspending communication.  |
| Tachometer                       |  |   |
| Engine coolant temperature gauge |  |   |
| Illumination control             |  | When suspending communication, changes to nighttime mode.   |
| Shift position indicator         | Shift position                               | When suspending communication, not indicate.  |
|                                  | S mode indicator lamp                        |   |
| Information display              | Instantaneous fuel consumption               | <ul style="list-style-type: none"> <li>• When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result.</li> <li>• When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.</li> </ul> |
|                                  | Average fuel consumption                     |   |
|                                  | Possible driving distance                    |   |
|                                  | Torque distribution 4WD                      |   |
| Buzzer                           |  | The buzzer turns OFF by suspending communication.   |
| Warning lamp/indicator lamp      | ABS warning lamp                             | The lamp turns ON by suspending communication.  |
|                                  | Malfunction indicator (Yellow)               |   |
|                                  | SLIP indicator lamp                          |   |
|                                  | EPS warning lamp                             |   |
|                                  | 4WD warning lamp                             |   |
|                                  | Brake warning lamp                           |   |
|                                  | VDC warning lamp                             | The lamp turns OFF by suspending communication.   |
|                                  | High beam indicator lamp                     |   |
|                                  | Turn signal indicator lamp                   |   |
|                                  | Door warning lamp                            |   |
|                                  | Light indicator lamp                         |   |
|                                  | Engine start operation indicator lamp        |   |
|                                  | Shift P warning lamp                         |   |
|                                  | Front fog lamp indicator lamp                |   |
|                                  | Rear fog lamp indicator lamp                 |   |
|                                  | Oil pressure warning lamp                    |   |
|                                  | Malfunction indicator (Red)                  |   |
|                                  | CRUISE indicator lamp                        |   |
|                                  | SET indicator lamp                           |   |
|                                  | Speed limiter indicator lamp                 |   |
|                                  | 4WD indicator lamp                           |   |
|                                  | 4WD LOCK indicator lamp                      |   |
|                                  | Key warning lamp                             |   |
|                                  | DPF (Diesel Particulate Filter) warning lamp |   |
|                                  | Glow indicator lamp                          |   |
| CVT indicator lamp               |  |   |
| Filter warning lamp              |  |   |


## SPEEDOMETER

# SYSTEM

< SYSTEM DESCRIPTION >

## SPEEDOMETER : System Diagram

INFOID:000000006412895



## SPEEDOMETER : System Description


INFOID:000000006412896

- The ABS actuator and electric unit (control unit) converts the rectangular wave signal provided by the wheel sensor to a vehicle speed signal and transmits it to the combination meter via CAN communication.
- The combination meter indicates the vehicle speed to the speedometer according to the vehicle speed signal received via CAN communication.

## TACHOMETER

## TACHOMETER : System Diagram

INFOID:000000006412897



## TACHOMETER : System Description


INFOID:000000006412898

- ECM converts the pulse signal provided by the crankshaft position sensor to an engine speed signal and transmits it to the combination meter via CAN communication.
- The combination meter indicates the engine speed to the tachometer according to the engine speed signal received via CAN communication.

## SHIFT POSITION INDICATOR

## SHIFT POSITION INDICATOR : System Diagram

INFOID:000000006468627



## SHIFT POSITION INDICATOR : System Description

INFOID:000000006468628

The combination meter receives the shift position signal from TCM via CAN communication, and displays the shift position to the shift position indicator.

WITH MANUAL MODE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

MWI

O  
P

# SYSTEM

## < SYSTEM DESCRIPTION >

### Manual Mode

- The combination meter receives the manual mode signal, non-manual mode signal, manual mode shift up signal, and manual mode shift down signal from CVT shift selector and transmits them to TCM via CAN communication.
- TCM recognizes the manual mode operation status according to the manual mode signal, non-manual mode signal, manual mode shift up signal, and manual mode shift down signal received via CAN communication and transmits the manual mode indicator signal to the combination meter via CAN communication.
- The combination meter indicates shift position according to the manual mode indicator signal received via CAN communication.

### Non-manual Mode

- TCM transmits the shift position signal to the combination meter via CAN communication.
- The combination meter indicates shift position according to the shift position signal received via CAN communication.

### Shift refusal warning and alarm

- TCM sends a manual mode shift refusal signal to the combination meter via CAN communication when shift-up and shift-down can not be operated in manual mode.
- The combination meter blinks the shift position indicator and sounds a buzzer according to a manual mode shift refusal signal received via CAN communication.

### WITHOUT MANUAL MODE


- TCM transmits the shift position signal to the combination meter via CAN communication.
- The combination meter indicates shift position according to the shift position signal received via CAN communication.

## OIL PRESSURE WARNING LAMP


### OIL PRESSURE WARNING LAMP : System Diagram

INFOID:000000006413639

#### K9K ENGINE MODELS



#### EXCEPT FOR K9K ENGINE MODELS



### OIL PRESSURE WARNING LAMP : System Description

INFOID:000000006413640

#### K9K ENGINE MODELS

- IPDM E/R reads the ON/OFF signals from the oil pressure switch and transmits the oil pressure switch signal to the combination meter via BCM with the CAN communication.
- The combination meter turns the oil pressure warning lamp ON (at the time of a reduction in hydraulic pressure)/OFF (except at the time of a reduction in hydraulic pressure) according to the oil pressure switch signal received via CAN communication.

# SYSTEM


## < SYSTEM DESCRIPTION >

### EXCEPT FOR K9K ENGINE MODELS

The combination meter turns the oil pressure warning lamp ON when receiving ECM to the oil pressure switch signal via CAN communication. For details, refer to [EC-41, "Engine Oil Pressure Sensor"](#) (MR16DDT) or [EC-462, "Engine Oil Pressure Sensor"](#) (HR16DE).

### SEAT BELT WARNING LAMP

#### SEAT BELT WARNING LAMP : System Diagram



#### SEAT BELT WARNING LAMP : System Description

- The combination meter turns ON the seat belt warning lamp when the following operating conditions are satisfied.

| Operating condition |   |
|---------------------|---|
| Ignition switch     | ON  |
| Seat belt           | Unfastened [driver side or passenger side (when getting in the passenger seat)] |
| Vehicle speed       | Less than approximately 15 km/h (9.3 MPH)                                       |

- The combination meter blinks the seat belt warning lamp when the following operating conditions are satisfied.

| Operating condition |   |
|---------------------|---|
| Ignition switch     | ON  |
| Seat belt           | Unfastened [driver side or passenger side (when getting in the passenger seat)] |
| Vehicle speed       | Approximately 15 km/h (9.3 MPH) or more   |

- The combination meter turns OFF the seat belt warning lamp when any of the following cancel condition is satisfied

| Cancel condition |  |
|------------------|--|
| Ignition switch  | OFF  |
| Seat belt        | Fastened [driver side and passenger side (when getting in the passenger seat)] |

#### NOTE:

If cancel conditions are not satisfied, the seat belt warning lamp continues blinking even when a vehicle speed becomes less than approximately 15 km/h (9.3 MPH).

#### SIGNAL PATH

The combination meter receives the following signals to control seat belt warning lamp.

| Signal name                                  | Signal path   |
|--|---|
| Ignition signal                              | —   |
| Seat belt buckle switch signal (driver side) | Seat belt buckle switch (driver side) → Combination meter |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P


# SYSTEM

## < SYSTEM DESCRIPTION >

| Signal name                                     | Signal path   |
|---|---|
| Seat belt buckle switch signal (passenger side) | Occupant detection unit → Seat belt buckle switch (passenger side) → Combination meter  |
| Vehicle speed signal                            | ABS actuator and electric unit (control unit)  → Combination meter |

## METER ILLUMINATION CONTROL

### METER ILLUMINATION CONTROL : System Diagram



### METER ILLUMINATION CONTROL : System Description

INFOID:000000006412908

#### METER ILLUMINATION CONTROL FUNCTION

- Combination meter controls meter illumination, based on the following signal.
  - Position light request signal
- The combination meter switches mode between Daytime mode and Nighttime mode, according to the following conditions.

| Condition                            |                     | Meter illumination |                |
|--------------------------------------|---------------------|--------------------|----------------|
| Combination switch (lighting switch) | 1ST or 2ND position | Nighttime mode     |                |
|                                      | AUTO POSITION       | Outdoor: Bright*   | Daytime mode   |
|                                      |                     | Outdoor: Dark*     | Nighttime mode |
|                                      | Off                 | Daytime mode       |                |

\*: For further information, refer to [INL-9. "ILLUMINATION CONTROL SYSTEM : System Description"](#).

#### BUCK LIGHT ILLUMINATION CONTROL FUNCTION

The operation of the illumination control switch allows the brightness adjustment of meter illumination.

| Meter illumination | The number of adjustable steps |
|--------------------|--------------------------------|
| Daytime            | 12 step                        |
| Nighttime          | 12 step                        |

#### METER ILLUMINATION ON/OFF CONTROL FUNCTION

- Combination meter turns ON meter illumination when the following condition is satisfied:
  - Ignition switch ON
- Combination meter turns OFF meter illumination when any of the following condition is satisfied:
  - During a crank with vehicle speed less than 1 km/h (0.6 MPH) and ACC power supply OFF
  - Ignition switch OFF or ACC power supply OFF
- The combination meter receives the following signals to control meter illumination.


# SYSTEM

## < SYSTEM DESCRIPTION >

| Signal name          | Signal path   |
|----------------------|---|
| Ignition signal      | —   |
| Engine status signal | ECM  Combination meter   |
| Vehicle speed signal | ABS actuator and control unit (control unit)  Combination meter |

## METER EFFECT FUNCTION

### METER EFFECT FUNCTION : System Diagram



### METER EFFECT FUNCTION : System Description

INFOID:000000006412910

#### ENGINE-START EFFECT FUNCTION

When recognizing an engine start, the combination meter controls the following items for producing the effect.

- Speedometer
- Tachometer
- Each meter pointer illumination
- Meter illumination
- Information display illumination
- Shift position indicator (CVT models)
- Start-up illumination (M/T models)

#### Meter and Illumination Operations During Engine-start Effect

The combination meter controls the following items during the engine-start effect.

| Control item                          | Operation  |
|---------------------------------------|--|
| Speedometer                           | Sweeps the pointer.  |
| Tachometer                            | Sweeps the pointer.  |
| Each meter pointer illumination       | Turns on the illumination at the effect level.                       |
| Meter illumination                    | Increases the brightness to the effect level in stages.              |
| Information display illumination      | Turns on the illumination at the normal brightness level.            |
| Shift position indicator (CVT models) | Turns ON at effect level brightness after staying OFF for 2 seconds. |
| Start-up illumination (M/T models)    | Turns ON/OFF in stages between OFF and the effect level brightness.  |

#### NOTE:

The pointers are stopped and illumination is turned off while cranking the engine.

#### Engine Start Judgement

The combination meter judges "engine-start" and activates the engine-start effect only once when the following operational conditions are all satisfied.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# SYSTEM

## < SYSTEM DESCRIPTION >

| Operational condition       |  |
|-----------------------------|--|
| Ignition switch             | ON position                                |
| Vehicle speed               | Less than 1 km/h (0.6 MPH)                 |
| Engine state                | Other than the time of cranking the engine |
|                             | 500 rpm or more                            |
| Shift position (CVT models) | "P" range                                  |

**NOTE:**

ENGINE-START EFFECT exits when any of the above operational conditions is cancelled during the engine-start effect.

**Signal Path**

The combination meter judges "engine-start", according to the following signals and activates the engine-start effect function.

| Signal name           | Signal source   |
|-----------------------|---|
| Ignition signal       | —   |
| Shift position signal | TCM  → Combination meter   |
| Engine speed signal   | ECM  → Combination meter   |
| Engine status signal  |   |
| Vehicle speed signal  | ABS actuator and electric unit (control unit)  → Combination meter |


**NOTE:**

The engine-start effect function ends if any one of the above conditions is lost during the activation of this function.

## INFORMATION DISPLAY

### INFORMATION DISPLAY : System Diagram

INFOID:000000006412911



### INFORMATION DISPLAY : System Description

INFOID:000000006412912

**DESCRIPTION**

- The combination meter receives signals necessary for controlling the operation of the information display from each unit, sensor and switch.
- The combination meter incorporates a trip computer that displays the warning/information according to the information received from each unit, sensor and switch.
- The combination meter shows the following functions on the information display.
  - Odo/trip meter

# SYSTEM

## < SYSTEM DESCRIPTION >

- Engine coolant temperature gauge
- Fuel gauge
- Trip computer
- Interrupt indication
- Setting
- Ambient temperature

A  
B

## ODO/TRIP METER

The combination meter calculates mileage, based on the following signals and displays the mileage on the information display.

C

| Signal name          | Signal path   |
|----------------------|---|
| Ignition signal      | —   |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  → Combination meter |

D  
E

## ENGINE COOLANT TEMPERATURE GAUGE

- ECM reads the engine coolant temperature signal from the engine coolant temperature sensor and transmits the signal to the combination meter via CAN communication.
- The combination meter indicates the engine coolant temperature to the water temperature gauge according to the engine coolant temperature signal received via CAN communication.

F  
G

| Signal name                       | Signal path   |
|-----------------------------------|---|
| Ignition signal                   | —   |
| Engine coolant temperature signal | ECM  → Combination meter |

H  
I

## FUEL GAUGE

### Control Outline

The combination meter reads the fuel level sensor signal from the fuel level sensor unit and indicates the fuel level to the fuel gauge.

J  
K

| Signal name              | Signal path  |
|--------------------------|--|
| Ignition signal          | —  |
| Fuel level sensor signal | Fuel level sensor unit  → Combination meter |

L  
M

### Refuel Control

The unit judges that the driver is refueling the vehicle and accelerates the fuel gauge segment movement if the fuel level changes by 15 ℓ (3 - 1/4 Imp gal) or more.

## AMBIENT TEMPERATURE

The combination meter calculates ambient temperature based on the following signals, and the calculated value is displayed on the information display.

MWI

| Signal name                                | Signal path   |
|--|---|
| Ignition signal                            | —   |
| Ambient sensor signal                      | Ambient sensor  → Combination meter                                  |
| A/C auto amp. recognition signal           | A/C auto amp.  → Combination meter                                   |
| PTC heater control unit recognition signal | PTC heater control unit  → Combination meter                         |
| Vehicle speed signal                       | ABS actuator and electric unit (control unit)  → Combination meter |

O  
P

# SYSTEM

## < SYSTEM DESCRIPTION >

### NOTE:

- The indicated temperature is corrected based on an ignition signal, ambient temperature detected by the ambient sensor, and vehicle speed signal. The indicated temperature is not raised under vehicle speed less than 20 km/h (12 MPH).
- The ambient sensor input value that is displayed on “Data Monitor” of CONSULT-III is the value before the correction. It may not match the indicated temperature on the information display.
- Depending on engine heat or heat on the road surfaces, an ambient temperature may be indicated higher than actual one.

### TRIP COMPUTER

#### Current Fuel Consumption

The combination meter calculates current fuel consumption based on the following signals, and the calculated value is displayed on the information display.

| Signal name                     | Signal path   |
|---------------------------------|---|
| Ignition signal                 | —   |
| Fuel consumption monitor signal | ECM  → Combination meter   |
| Vehicle speed signal            | ABS actuator and electric unit (control unit)  → Combination meter |

### NOTE:

- Current fuel consumption on the information display is updated approximately every 0.5 seconds.
- Current fuel consumption on the information display shows 0 l/100km (0 mpg) when vehicle speed is 0 km/h (0 MPH).

#### Average Fuel Consumption

The combination meter calculates average fuel consumption based on the following signals, and the calculated value is displayed on the information display.

| Signal name                     | Signal path   |
|---------------------------------|---|
| Ignition signal                 | —   |
| Fuel consumption monitor signal | ECM  → Combination meter   |
| Vehicle speed signal            | ABS actuator and electric unit (control unit)  → Combination meter |

### NOTE:

- Average fuel consumption on the information display is updated approximately every 30 seconds.
- Soon after a reset or when the ignition switch is turned ON right after battery removal and installation, “—” is displayed until after a travel of 30 seconds and approximately 500 m (0.31 mile).

#### Distance to Empty

The combination meter calculates distance to empty based on the following signals, and the calculated value is displayed on the information display.

| Signal name                     | Signal path   |
|---------------------------------|---|
| Ignition signal                 | —   |
| Fuel level sensor signal        | Fuel level sensor unit  → Combination meter                          |
| Fuel consumption monitor signal | ECM  → Combination meter   |
| Vehicle speed signal            | ABS actuator and electric unit (control unit)  → Combination meter |

### NOTE:

- Distance to empty on the information display is updated approximately every 30 seconds.
- When the ignition switch is turned ON right after battery removal and installation, “—” is displayed until after a travel of 30 seconds.

# SYSTEM

## < SYSTEM DESCRIPTION >

- The indicated values may not match each other when refueling with the ignition switch ON.

### Travel Time

The combination meter measures and displays travel time (ignition switch ON time).

### Torque Distribution Indicator

Refer to [DLN-18, "4WD SYSTEM : Torque Split Control"](#).

## INTERRUPT INDICATION

- The combination meter displays an interrupt regarding a warning, alert, and maintenance on the information display, based on signals received from each unit and switch.
- When conditions are satisfied, the normal screen switches to a warning screen to display an interrupt.

### Meter Illumination Level

The combination meter displays the illuminance level of the back light on the information display by turning the meter control switch.

### ICY Warning (low ambient air temperature)

- When the following operating condition is satisfied, the combination meter displays an ICY warning on the information display.

| Operating condition |                      |
|---------------------|----------------------|
| Ignition switch     | ON                   |
| Ambient temperature | 3 °C (37 °F) or less |

- The combination meter judges showing/hiding of "low ambient temperature", according to the signals below:

| Signal name           | Signal path  |
|-----------------------|--|
| Ignition signal       | —  |
| Ambient sensor signal | Ambient sensor  Combination meter |

### Low Fuel Warning

- When all the following operating conditions are satisfied, the combination meter displays a low fuel warning on the information display by an interrupt.

| Operating condition     |   |
|-------------------------|---|
| Ignition switch         | ON  |
| Fuel remaining quantity | Approximately 9.5 ℓ (2-1/8 Imp gal) or less<br>[1.5 ℓ (3/8 Imp gal) fuel residues included] |

- The combination meter judges showing/hiding of "low fuel warning", according to the signals below:

| Signal name              | Signal path   |
|--------------------------|---|
| Ignition signal          | —   |
| Fuel level sensor signal | Fuel level sensor  Combination meter |

### Distance to Empty

The combination meter calculates distance to empty based on the following signals, and the calculated value is displayed on the information display.

| Signal name              | Signal path  |
|--------------------------|--|
| Ignition signal          | —  |
| Fuel level sensor signal | Fuel level sensor unit  Combination meter |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

# SYSTEM

## < SYSTEM DESCRIPTION >

| Signal name                     | Signal path  |
|---------------------------------|--|
| Fuel consumption monitor signal | ECM  → Combination meter   |
| Vehicle speed signal            | ABS actuator and electric unit (control unit)  → Combination meter |

**NOTE:**

- Distance to empty on the information display is updated approximately every 30 seconds.
- When the ignition switch is turned ON right after battery removal and installation, “—” is displayed until after a travel of 30 seconds.
- The indicated values may not match each other when refueling with the ignition switch ON.

**Oil level Indicator**

The combination meter reads a resistance value of the oil level sensor when the following steps are completed and displays the oil level sensor indicator when the ignition switch is turned ON.

1. Ignition switch OFF
2. After a lapse of five minutes or more
3. The door on the front side is opened.

**Oil Maintenance Warning (Except For K9K Engine Models)**

- When all the following operating conditions are satisfied, the combination meter displays wrench symbol and distance to oil change information on the information display by an interrupt.

| Operating condition |                                      |
|---------------------|--------------------------------------|
| Ignition switch     | ON                                   |
| Mileage             | More than value set in setting range |

- The combination meter judges showing/hiding of “engine oil warning”, according to the signals below:

| Signal name          | Signal path  |
|----------------------|--|
| Ignition signal      | —  |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  → Combination meter |

**Oil Maintenance Warning (K9K Engine Models)**

- The combination meter receives remaining distance signal from the ECM with CAN communication line.
- The combination meter indicates oil change remaining distance when receiving remaining distance signal.
- The combination meter indicates oil maintenance warning judged with the remaining distance signal received from the ECM.

For details, refer to EC section.

## SETTING

Oil maintenance warning indication timing can be set.

**Maintenance**

Setting values for engine oil maintenance can be adjusted to meet the user's needs.

| Setting item                                   | Setting range   |
|--|---|
| Oil maintenance (except for K9K engine models) | No setting, 1000 km - 30,000 km<br>(No setting, 500 mile - 18,000 mile) |


# OPERATION

< SYSTEM DESCRIPTION >

## OPERATION

### Switch Name and Function

INFOID:000000006412913



| Switch name                     | Operation | Description   |
|---------------------------------|-----------|---|
| Illumination control switch (1) | Press     | An illuminance level of the back light of the combination meter can be adjusted.  |
| Meter control switch (2)        |           | <ul style="list-style-type: none"> <li>• The information display screen can be switched.</li> <li>• An indicated value of the trip computer can be reset by pressing and holding the meter control switch.</li> </ul> |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

MWI

O  
P

# DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (COMBINATION METER)

### On Board Diagnosis Function

INFOID:000000006412914


#### ON BOARD DIAGNOSIS ITEM

The combination meter allows the following diagnosis items with the on-board diagnosis function.

| Diagnosis item                     |   |
|------------------------------------|---|
| Drive circuit check                | <ul style="list-style-type: none"> <li>• Speedometer</li> <li>• Tachometer</li> </ul> |
| LCD (liquid crystal display) check | Information display   |

#### METHOD OF STARTING


1. Turn ignition switch ON, and switch the trip meter to "trip A" or "trip B".
2. Turn ignition switch OFF.
3. While pressing the meter control switch (1), turn ignition switch ON.
4. Make sure that the trip meter displays "0000.0".
5. Press the meter control switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON.)




6. The combination meter is turned to self-diagnosis mode. All of the segments of engine coolant temperature gauge, fuel gauge, odo/trip meter, shift position indicator (A) for CVT models and information display illuminate.

**NOTE:**

- Check combination meter power supply and ground circuit when the self-diagnosis mode of the combination meter does not start. Replace combination meter if power supply and ground circuit are normal.
- If any of the dots are not displayed, replace combination meter.
- For M/T models, start-up lamp (B) illuminate instead of shift position indicator.



7. Each meter activates by pressing the meter control switch.



# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

### NOTE:

- If any of the meters or gauges is not activated, replace combination meter.
- The figure is reference.

## CONSULT-III Function

INFOID:000000006412915

## CONSULT-III APPLICATION ITEMS

CONSULT-III can perform the following diagnosis modes via CAN communication and the combination meter.

| System    | Diagnosis mode         | Description  |
|-----------|------------------------|--|
| METER/M&A | Self Diagnostic Result | The combination meter checks the conditions and displays memorized errors. |
|           | Data Monitor           | Displays the combination meter input/output data in real time.             |
|           | Special function       | Lighting history of the warning lamp and indicator lamp can be checked.    |

## SELF DIAG RESULT

Refer to [MWI-36, "DTC Index"](#).

## DATA MONITOR

### Display Item List

X: Applicable

| Display item [Unit]         | MAIN SIGNALS | Description  |
|-----------------------------|--------------|--|
| SPEED METER<br>[km/h]       | X            | Value of vehicle speed signal received from ABS actuator and electric unit (control unit) via CAN communication.<br><b>NOTE:</b><br>655.35 is displayed when the malfunction signal is received.   |
| SPEED OUTPUT<br>[km/h]      | X            | Vehicle speed signal value transmitted to other units via CAN communication.<br><b>NOTE:</b><br>655.35 is displayed when the malfunction signal is received.   |
| ODO OUTPUT<br>[km/h or mph] |              | Odometer signal value transmitted to other units via CAN communication.  |
| TACHO METER<br>[rpm]        | X            | Value of the engine speed signal received from ECM via CAN communication.<br><b>NOTE:</b><br>8191.875 is displayed when the malfunction signal is received.  |
| FUEL METER<br>[L]           | X            | Fuel level indicated on combination meter.   |
| W TEMP METER<br>[°C]        | X            | Value of engine coolant temperature signal is received from ECM via CAN communication.<br><b>NOTE:</b><br>215 is displayed when the malfunction signal is input.   |
| FUEL CAP W/L<br>[Off]       |              | This item is displayed, but cannot be monitored.   |
| ABS W/L<br>[On/Off]         |              | Status of ABS warning lamp detected from ABS warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.   |
| VDC/TCS IND<br>[On/Off]     |              | Status of ESP OFF indicator lamp detected from ESP OFF indicator lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.   |
| SLIP IND<br>[On/Off]        |              | Status of ESP warning lamp detected from ESP warning lamp signal received from ABS actuator and electric unit (control unit) via CAN communication.  |
| BRAKE W/L<br>[On/Off]       |              | Status of brake warning lamp detected from brake warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication.<br><b>NOTE:</b><br>Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON. |
| DOOR W/L<br>[On/Off]        |              | Status of door open warning lamp detected from door switch signal received from BCM via CAN communication.   |

## DIAGNOSIS SYSTEM (COMBINATION METER)

### < SYSTEM DESCRIPTION >

| Display item [Unit]   | MAIN SIGNALS | Description   |
|---|--------------|---|
| HI-BEAM IND<br>[On/Off]   |              | Status of high beam indicator lamp detected from high beam request signal is received from BCM via CAN communication.   |
| TURN IND<br>[On/Off]  |              | Status of turn indicator lamp detected from turn indicator signal is received from BCM via CAN communication.   |
| FR FOG IND<br>[On/Off]  |              | Status of front fog light indicator lamp detected from front fog light request signal is received from BCM via CAN communication.   |
| RR FOG IND<br>[On/Off]  |              | Status of rear fog light indicator lamp detected from rear fog light request signal is received from BCM via CAN communication.   |
| LIGHT IND<br>[On/Off]   |              | Status of light indicator lamp detected from position light request signal is received from BCM via CAN communication.  |
| OIL W/L<br>[On/Off]   |              | <ul style="list-style-type: none"> <li>• Status of oil pressure warning lamp detected from oil pressure switch signal is received from BCM via CAN communication. (K9K engine models)</li> <li>• Status of oil pressure warning lamp detected from oil pressure switch signal is received from ECM via CAN communication. (except for K9K engine models)</li> </ul> |
| MIL<br>[On/Off]   |              | Status of malfunction indicator (yellow) detected from malfunctioning indicator lamp signal is received from ECM via CAN communication.   |
| GLOW IND<br>[On/Off]  |              | Status of glow indicator lamp detected from glow indicator lamp signal is received from ECM via CAN communication.  |
| C-ENG2 W/L<br>[On/Off]  |              | Status of malfunction indicator (red) detected from malfunctioning indicator lamp signal is received from ECM via CAN communication.  |
| CRUISE IND<br>[On/Off]  |              | Status of CRUISE indicator lamp detected from ASCD status signal is received from ECM via CAN communication.  |
| SET IND<br>[On/Off]   |              | Status of SET indicator lamp detected from ASCD status signal is received from ECM via CAN communication.   |
| O/D OFF IND<br>[On/Off]   |              | Status of S mode indicator lamp detected from S mode indicator lamp signal is received from TCM via CAN communication.  |
| CVT IND<br>[On/Off]   |              | Status of CVT indicator lamp detected from CVT status signal is received from TCM via CAN communication.  |
| 4WD W/L<br>[On/Off]   |              | Status of 4WD warning lamp judged from 4WD warning lamp signal received from 4WD control module with CAN communication line.  |
| 4WD LOCK IND<br>[On/Off]  |              | Status of 4WD lock indicator lamp judged from 4WD mode lamp signal received from 4WD control module with CAN communication line.  |
| FUEL W/L<br>[On/Off]  |              | Low fuel warning status detected by the identified fuel level.  |
| KEY G/Y W/L<br>[On/Off]   |              | Status of KEY warning lamp (G/Y) detected from KEY warning lamp signal is received from BCM via CAN communication.  |
| KEY KNOB W/L<br>[On/Off]  |              | Status of shift P warning lamp detected from shift P warning lamp signal is received from BCM via CAN communication.  |
| EPS W/L<br>[On/Off]   |              | Status of EPS warning lamp detected from EPS warning lamp signal is received from EPS control unit via CAN communication.   |
| DPF W/L<br>[On/Off]   |              | Status of Diesel Particulate Filter warning lamp detected from Diesel Particulate Filter warning lamp signal is received from ECM via CAN communication.  |
| FILTER W/L<br>[On/Off]  |              | Status of Filter warning lamp detected from Filter warning lamp signal is received from ECM via CAN communication.  |
| LCD<br>[B&P N, B&P I, SFT P, BATT, NO KY, LK WN] <sup>*1</sup><br>[C&P N, C&P I, SFT P, BATT, NO KY, LK WN] <sup>*2</sup> |              | Status of engine start operation indicator lamp, shift P warning lamp and KEY warning lamp, detected from engine start operation indicator lamp signal, shift P warning lamp signal and KEY warning lamp signal are received from BCM via CAN communication.  |
| SHIFT IND<br>[P, R, N, D, L] <sup>*3</sup><br>[P, R, N, D, M1, M2, M3, M4, M5, M6] <sup>*4</sup>                          |              | Status of shift position indicator judged from shift position signal received from TCM with CAN communication line.   |

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

| Display item [Unit]                               | MAIN SIGNALS | Description   |        |
|---|--------------|---|--------|
| O/D OFF SW<br>[On/Off]                            |              | Status of over drive control switch.  | A      |
| M RANGE SW<br>[On/Off]                            |              | Status of manual mode switch.   | B      |
| NM RANGE SW<br>[On/Off]                           |              | Status of non-manual mode switch.   | C      |
| AT SFT UP SW<br>[On/Off]                          |              | Status of manual mode shift up switch.  |        |
| AT SFT DWN SW<br>[On/Off]                         |              | Status of manual mode shift down switch.  | D      |
| COMP F/B SIG<br>[On/Off]                          |              | A/C compressor activation condition that ECM judges according to the engine coolant temperature and the acceleration degree.  | E      |
| PKB SW<br>[On/Off]                                |              | Status of parking brake switch.   |        |
| BUCKLE SW<br>[On/Off]                             |              | Status of seat belt buckle switch (driver side).  | F      |
| BRAKE SW<br>[On/Off]                              |              | Status of stop lamp switch.   | G      |
| BRAKE OIL SW<br>[On/Off]                          |              | Status of brake fluid level switch.   |        |
| A/C AMP CONN<br>[On/Off]                          |              | <ul style="list-style-type: none"> <li>Status of A/C auto amp. connection recognition signal.</li> <li>Status of PTC heater control unit connection recognition signal.</li> </ul>  | H      |
| PASS BUCKLE SW<br>[On/Off]                        |              | Status of seat belt buckle switch (passenger side).   | I      |
| DISTANCE<br>[km]                                  |              | Value of distance to empty calculated by combination meter.   |        |
| OUTSIDE TEMP<br>[°C or °F]                        |              | Ambient temperature value converted from ambient sensor signal received from ambient sensor.<br><b>NOTE:</b><br>This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.) | J<br>K |
| FUEL LOW SIG<br>[On/Off]                          |              | Status of fuel level low warning signal to output to AV control unit via CAN communication.   | L      |
| BUZZER<br>[On/Off]                                | X            | Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter.   | M      |
| ASCD SPD BLNK<br>[On/Off]                         |              | Blinking status of ASCD or speed limiter set vehicle speed that is judged by the ASCD status signal received from ECM via CAN communication.  |        |
| ASCD STATUS<br>[Off, ASCD, CRUISE, SL ON, SL SET] |              | Display status of ASCD and speed limiter status display judged by the ASCD status signal received from ECM via CAN communication.   | MWI    |
| ASCD REQ SPD<br>[km/h/Off]                        |              | ASCD or speed limiter set vehicle speed value that is judged by the ASCD status signal received from ECM via CAN communication.   | O      |
| E/O CHG TMNG<br>[km]                              |              | A value of ECM-judged remaining distance to the oil change time.  |        |
| E/O CHG TMNG RST<br>[On/Off]                      |              | Resetting of a remaining distance to the engine oil change time.  | P      |

- \*1: CVT models
- \*2: M/T models
- \*3: Without manual mode CVT
- \*4: With manual mode CVT

**NOTE:**

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

Some items are not available according to vehicle specification.

## SPECIAL FUNCTION

Special menu

| Display item   | Description   |
|----------------|---|
| W/L ON HISTORY | Lighting history of warning lamp and indicator lamp can be checked. |

### W/L ON HISTORY

- Stores histories when warning/indicator lamp is turned on.
- “W/L ON HISTORY” indicates the “TIME” when the warning/ indicator lamp is turned on.
- The “TIME” above is:
  - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
  - 1 - 39: The number of times the engine was restarted after the 0 condition.
  - NO W/L ON HISTORY: Stores NO (0) turning on history of warning/indicator lamp.

### NOTE:

- W/L ON HISTORY is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

### Display Item

| Display item  | Description  |
|---------------|--|
| ABS W/L       | Lighting history of ABS warning lamp.                    |
| VDC/TCS IND   | Lighting history of ESP OFF indicator lamp.              |
| SLIP IND      | Lighting history of ESP warning lamp.                    |
| BRAKE W/L     | Lighting history of brake warning lamp.                  |
| DOOR W/L      | Lighting history of door open warning.                   |
| TRUNK/GLAS-H  | This item is displayed, but cannot be monitored.         |
| OIL W/L       | Lighting history of oil pressure warning lamp.           |
| C-ENG W/L     | Lighting history of malfunction indicator lamp (orange). |
| C-ENG2 W/L    | Lighting history of malfunction indicator lamp (red).    |
| CRUISE IND    | Lighting history of CRUISE indicator lamp.               |
| SET IND       | Lighting history of SET indicator lamp.                  |
| CRUISE W/L    | This item is displayed, but cannot be monitored.         |
| BA W/L        | This item is displayed, but cannot be monitored.         |
| O/D OFF IND   | Lighting history of S mode indicator lamp.               |
| ATC/T-AMT W/L | This item is displayed, but cannot be monitored.         |
| ATF TEMP W/L  | This item is displayed, but cannot be monitored.         |
| CVT IND       | Lighting history of CVT indicator.                       |
| SPORT IND     | This item is displayed, but cannot be monitored.         |
| 4WD W/L       | Lighting history of 4WD warning lamp.                    |
| FUEL W/L      | Lighting history of low fuel level warning.              |
| WASHER W/L    | This item is displayed, but cannot be monitored.         |
| AIR PRES W/L  | This item is displayed, but cannot be monitored.         |
| KEY G/Y W/L   | Lighting history of KEY warning lamp (G/Y).              |
| KEY R W/L     | This item is displayed, but cannot be monitored.         |
| KEY KNOB W/L  | Lighting history of Shift P warning lamp.                |
| EPS W/L       | Lighting history of EPS warning lamp.                    |
| e-4WD         | This item is displayed, but cannot be monitored.         |

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

| Display item   | Description                                      |   |
|----------------|--|---|
| AFS OFF IND    | This item is displayed, but cannot be monitored. | A |
| 4WAS/RAS W/L   | This item is displayed, but cannot be monitored. |   |
| HDC W/L        | This item is displayed, but cannot be monitored. | B |
| SYS FAIL W/L   | This item is displayed, but cannot be monitored. |   |
| SFT POSI W/L   | This item is displayed, but cannot be monitored. |   |
| HV BAT W/L     | This item is displayed, but cannot be monitored. | C |
| HEV BRAKE W/L  | This item is displayed, but cannot be monitored. |   |
| SFT OPER W/L   | This item is displayed, but cannot be monitored. | D |
| LANE W/L       | This item is displayed, but cannot be monitored. |   |
| CHAGE W/L      | This item is displayed, but cannot be monitored. |   |
| OIL LEV LOW    | This item is displayed, but cannot be monitored. | E |
| DPF W/L        | Lighting history of DPF warning lamp.            |   |
| TRAILER IND    | This item is displayed, but cannot be monitored. | F |
| RUN FLAT W/L   | This item is displayed, but cannot be monitored. |   |
| E-SUS W/L      | This item is displayed, but cannot be monitored. |   |
| LAUNCH CNT W/L | This item is displayed, but cannot be monitored. | G |
| BSW W/L        | This item is displayed, but cannot be monitored. |   |
| FILTER W/L     | Lighting history of FILTER warning lamp.         | H |
| BRAKE PAD W/L  | This item is displayed, but cannot be monitored. |   |

I

J

K

L

M

MWI

O

P

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### COMBINATION METER

Reference Value

INFOID:000000006412916

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item                | Condition             |  | Value/Status   |
|-----------------------------|-----------------------|--|--|
| SPEED METER<br>[km/h]       | Ignition switch<br>ON | While driving  | Input value of vehicle speed signal<br>(CAN communication signal)<br><b>NOTE:</b><br>655.35 is displayed when the malfunction signal is received     |
| SPEED OUTPUT<br>[km/h]      | Ignition switch<br>ON | While driving  | Output value of vehicle speed signal<br>(CAN communication signal)<br><b>NOTE:</b><br>655.35 is displayed when the malfunction signal is received    |
| ODO OUTPUT<br>[km/h or mph] | Ignition switch<br>ON | —  | Output value of odometer signal (CAN communication signal)   |
| TACHO METER<br>[rpm]        | Ignition switch<br>ON | Engine running   | Input value of engine speed signal<br>(CAN communication signal)<br><b>NOTE:</b><br>8191.875 is displayed when the malfunction signal is received    |
| FUEL METER<br>[L]           | Ignition switch<br>ON | —  | Input value of fuel level sensor signal  |
| W TEMP METER<br>[°C]        | Ignition switch<br>ON | —  | Input value of engine coolant temperature signal (CAN communication signal)<br><b>NOTE:</b><br>215 is displayed when the malfunction signal is input |
| FUEL CAP W/L                | Ignition switch<br>ON | <b>NOTE:</b><br>This item is displayed, but cannot be monitored. | Off  |
| ABS W/L                     | Ignition switch<br>ON | ABS warning lamp ON  | On   |
|                             |                       | ABS warning lamp OFF   | Off  |
| VDC/TCS IND                 | Ignition switch<br>ON | ESP OFF indicator lamp ON  | On   |
|                             |                       | ESP OFF indicator lamp OFF                                       | Off  |
| SLIP IND                    | Ignition switch<br>ON | ESP warning lamp ON  | On   |
|                             |                       | ESP warning lamp OFF   | Off  |
| BRAKE W/L                   | Ignition switch<br>ON | Brake warning lamp ON  | On   |
|                             |                       | Brake warning lamp OFF   | Off  |
| DOOR W/L                    | Ignition switch<br>ON | Door open warning lamp ON  | On   |
|                             |                       | Door open warning lamp OFF                                       | Off  |
| HI-BEAM IND                 | Ignition switch<br>ON | High-beam indicator lamp ON                                      | On   |
|                             |                       | High-beam indicator lamp OFF                                     | Off  |
| TURN IND                    | Ignition switch<br>ON | Turn signal indicator lamp ON                                    | On   |
|                             |                       | Turn signal indicator lamp OFF                                   | Off  |
| FR FOG IND                  | Ignition switch<br>ON | Front fog lamp indicator lamp ON                                 | On   |
|                             |                       | Front fog lamp indicator lamp OFF                                | Off  |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition          |  | Value/Status |     |
|--------------|--------------------|--|--------------|-----|
| RR FOG IND   | Ignition switch ON | Rear fog lamp indicator lamp ON                      | On           | A   |
|              |                    | Rear fog lamp indicator lamp OFF                     | Off          |     |
| LIGHT IND    | Ignition switch ON | Tail lamp indicator lamp ON                          | On           | B   |
|              |                    | Tail lamp indicator lamp OFF                         | Off          |     |
| OIL W/L      | Ignition switch ON | Oil pressure warning lamp ON                         | On           | C   |
|              |                    | Oil pressure warning lamp OFF                        | Off          |     |
| MIL          | Ignition switch ON | Malfunction indicator (yellow) ON                    | On           | D   |
|              |                    | Malfunction indicator (yellow) OFF                   | Off          |     |
| GLOW IND     | Ignition switch ON | Glow indicator lamp ON                               | On           | E   |
|              |                    | Glow indicator lamp OFF                              | Off          |     |
| C-ENG2 W/L   | Ignition switch ON | Engine warning (red) ON                              | On           | F   |
|              |                    | Engine warning (red) OFF                             | Off          |     |
| CRUISE IND   | Ignition switch ON | CRUISE indicator lamp ON                             | On           | G   |
|              |                    | CRUISE indicator lamp OFF                            | Off          |     |
| SET IND      | Ignition switch ON | SET indicator ON                                     | On           | H   |
|              |                    | SET indicator OFF                                    | Off          |     |
| O/D OFF IND  | Ignition switch ON | S mode indicator lamp ON                             | On           | I   |
|              |                    | S mode indicator lamp OFF                            | Off          |     |
| CVT IND      | Ignition switch ON | CVT indicator ON                                     | On           | J   |
|              |                    | CVT indicator OFF                                    | Off          |     |
| 4WD W/L      | Ignition switch ON | 4WD warning lamp ON                                  | On           | K   |
|              |                    | 4WD warning lamp OFF                                 | Off          |     |
| 4WD LOCK IND | Ignition switch ON | 4WD LOCK indicator lamp ON                           | On           | L   |
|              |                    | 4WD LOCK indicator lamp OFF                          | Off          |     |
| KEY G/Y W/L  | Ignition switch ON | During Intelligent Key system malfunction indication | On           | M   |
|              |                    | Other than the above                                 | Off          |     |
| KEY KNOB W/L | Ignition switch ON | SHIFT P warning lamp ON                              | On           | MWI |
|              |                    | SHIFT P warning lamp OFF                             | Off          |     |
| EPS W/L      | Ignition switch ON | EPS warning lamp ON                                  | On           | O   |
|              |                    | EPS warning lamp OFF                                 | Off          |     |
| DPF W/L      | Ignition switch ON | DPF warning lamp ON                                  | On           | P   |
|              |                    | DPF warning lamp OFF                                 | Off          |     |
| FUEL W/L     | Ignition switch ON | During low fuel warning indication                   | On           |     |
|              |                    | Other than the above                                 | Off          |     |
| FILTER W/L   | Ignition switch ON | Filter warning lamp ON                               | On           |     |
|              |                    | Filter warning lamp OFF                              | Off          |     |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Monitor Item   | Condition                   |  | Value/Status |
|--|-----------------------------|--|--------------|
| LCD  | Ignition switch LOCK or ACC | Engine start operation indicator lamp ON (CVT models)        | B&P N        |
|  | Ignition switch ON          | Engine start operation indicator lamp ON (CVT models)        | B&P I        |
|  | Ignition switch LOCK or ACC | Engine start operation indicator lamp ON (M/T models)        | C&P N        |
|  | Ignition switch ON          | Engine start operation indicator lamp ON (M/T models)        | C&P I        |
|  | Ignition switch LOCK        | During P position warning lamp indication                    | SFT P        |
|  | Ignition switch LOCK        | During Intelligent Key low battery warning indication        | BATT         |
|  | Ignition switch ON          | During take away warning indication                          | NO KY        |
|  | Ignition switch ON          | During ACC warning indication                                | LK WN        |
| SHIFT IND  | Ignition switch ON          | Shift position indicator P display                           | P            |
|  |                             | Shift position indicator R display                           | R            |
|  |                             | Shift position indicator N display                           | N            |
|  |                             | Shift position indicator D display                           | D            |
|  |                             | Shift position indicator L display (without manual mode CVT) | L            |
|  |                             | Shift position indicator M1 display (with manual mode CVT)   | M1           |
|  |                             | Shift position indicator M2 display (with manual mode CVT)   | M2           |
|  |                             | Shift position indicator M3 display (with manual mode CVT)   | M3           |
|  |                             | Shift position indicator M4 display (with manual mode CVT)   | M4           |
|  |                             | Shift position indicator M5 display (with manual mode CVT)   | M5           |
| Shift position indicator M6 display (with manual mode CVT) | M6                          |  |              |
| O/D OFF SW   | Ignition switch ON          | S mode indicator switch ON                                   | On           |
|  |                             | S mode indicator switch OFF                                  | Off          |
| M RANGE SW   | Ignition switch ON          | Selector lever in manual mode position                       | On           |
|  |                             | Other than the above   | Off          |
| NM RANGE SW  | Ignition switch ON          | Selector lever in manual mode position                       | Off          |
|  |                             | Other than the above   | On           |
| AT SFT UP SW   | Ignition switch ON          | Selector lever in + position                                 | On           |
|  |                             | Other than the above   | Off          |
| AT SFT DWN SW  | Ignition switch ON          | Selector lever in – position                                 | On           |
|  |                             | Other than the above   | Off          |
| COMP F/B SIG   | Ignition switch ON          | A/C compressor activation condition                          | On           |
| PKB SW   | Ignition switch ON          | Parking brake switch ON                                      | On           |
|  |                             | Parking brake switch OFF                                     | Off          |

# COMBINATION METER


## < ECU DIAGNOSIS INFORMATION >

| Monitor Item               | Condition          |  | Value/Status  |
|----------------------------|--------------------|--|---|
| BUCKLE SW                  | Ignition switch ON | Driver seat belt not fastened  | On  |
|                            |                    | Driver seat belt fastened  | Off   |
| BRAKE SW                   | Ignition switch ON | Brake pedal is pressed   | On  |
|                            |                    | Other than the above   | Off   |
| BRAKE OIL SW               | Ignition switch ON | Brake fluid level switch ON  | On  |
|                            |                    | Brake fluid level switch OFF   | Off   |
| A/C AMP CONN               | Ignition switch ON | Other than the following   | On  |
|                            |                    | Receives A/C auto amp./PTC heater control unit connection recognition signal   | Off   |
| PASS BUCKLE SW             | Ignition switch ON | Passenger seat belt not fastened   | On  |
|                            |                    | <ul style="list-style-type: none"> <li>Passenger seat belt fastened</li> <li>When getting in the passenger seat</li> </ul> | Off   |
| DISTANCE [km]              | Ignition switch ON | —  | Distance to empty calculated by combination meter   |
| OUTSIDE TEMP [°C or °F]    | Ignition switch ON | —  | Input value of ambient sensor signal (CAN communication signal)<br><b>NOTE:</b><br>This may not match the indicated value on the information display. |
| FUEL LOW SIG               | Ignition switch ON | During low fuel warning indication   | On  |
|                            |                    | Other than above   | Off   |
| BUZZER                     | Ignition switch ON | Buzzer ON  | On  |
|                            |                    | Buzzer OFF   | Off   |
| ASCD SPD BLNK              | Ignition switch ON | Set vehicle speed indicator blinking   | On  |
|                            |                    | Set vehicle speed indicator not blinking   | Off   |
| ASCD STATUS                | Ignition switch ON | ASCD and speed limiter system OFF  | Off   |
|                            |                    | ASCD system ON   | ASCD  |
|                            |                    | ASCD set vehicle speed   | CRUISE  |
|                            |                    | Speed limiter system ON  | SL ON   |
|                            |                    | Speed limiter set vehicle speed  | SL SET  |
| ASCD REQ SPD [km/h or Off] | Ignition switch ON | While driving  | Same value as ASCD or speed limiter set vehicle speed   |
| E/O CHG TMNG               | Ignition switch ON | —  | A value of ECM-judged remaining distance to the oil change time.  |
| E/O CHG TMNG RST           | Ignition switch ON | Resetting of a remaining distance to the engine oil change time.   | On  |
|                            |                    | Other than above   | Off   |

### NOTE:

Some items are not available according to vehicle specification.



### TERMINAL LAYOUT



# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## PHYSICAL VALUES

| Terminal No.<br>(Wire color) |        | Description                       |                  | Condition                |   | Value<br>(Approx.)   |
|------------------------------|--------|-----------------------------------|------------------|--------------------------|---|--|
| +                            | -      | Signal name                       | Input/<br>Output |                          |   |  |
| 1<br>(L)                     | —      | CAN-H                             | —                | —                        | —   | —  |
| 2<br>(P)                     | —      | CAN-L                             | —                | —                        | —   | —  |
| 3<br>(GR)                    | Ground | Vehicle speed signal<br>(2-pulse) | Output           | Ignition<br>switch<br>ON | Speedometer operated<br>[When vehicle speed is ap-<br>prox. 40 km/h (25 MPH)] | <p><b>NOTE:</b><br/>The maximum voltage varies de-<br/>pending on the specification<br/>(destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0015GB</p>  |
| 4<br>(Y)                     | Ground | Vehicle speed signal<br>(8-pulse) | Output           | Ignition<br>switch<br>ON | Speedometer operated<br>[When vehicle speed is ap-<br>prox. 40 km/h (25 MPH)] | <p><b>NOTE:</b><br/>The maximum voltage varies de-<br/>pending on the specification<br/>(destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0012GB</p> |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Terminal No.<br>(Wire color)               |  | Description                                  |                  | Condition          | Value<br>(Approx.)                          |  |     |
|--|--|--|------------------|--------------------|---|--|-----|
| +  | -  | Signal name                                  | Input/<br>Output |                    |   |  |     |
| 6<br>(BR)                                  | Ground   | Fuel level sensor signal                     | Input            | Ignition switch ON | Resistance value corresponding to SEG 16/16 | <ul style="list-style-type: none"> <li>• On: 80 Ω / Off: 88 Ω (2WD)</li> <li>• On: 94 Ω / Off: 106 Ω (4WD)</li> </ul>    | A   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 15/16 | <ul style="list-style-type: none"> <li>• On: 87 Ω / Off: 99 Ω (2WD)</li> <li>• On: 105 Ω / Off: 123 Ω (4WD)</li> </ul>   | B   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 14/16 | <ul style="list-style-type: none"> <li>• On: 99 Ω / Off: 111 Ω (2WD)</li> <li>• On: 123 Ω / Off: 144 Ω (4WD)</li> </ul>  | C   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 13/16 | <ul style="list-style-type: none"> <li>• On: 110 Ω / Off: 122 Ω (2WD)</li> <li>• On: 144 Ω / Off: 153 Ω (4WD)</li> </ul> | D   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 12/16 | <ul style="list-style-type: none"> <li>• On: 121 Ω / Off: 133 Ω (2WD)</li> <li>• On: 152 Ω / Off: 164 Ω (4WD)</li> </ul> | E   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 11/16 | <ul style="list-style-type: none"> <li>• On: 133 Ω / Off: 144 Ω (2WD)</li> <li>• On: 163 Ω / Off: 173 Ω (4WD)</li> </ul> | F   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 10/16 | <ul style="list-style-type: none"> <li>• On: 144 Ω / Off: 155 Ω (2WD)</li> <li>• On: 173 Ω / Off: 182 Ω (4WD)</li> </ul> | G   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 9/16  | <ul style="list-style-type: none"> <li>• On: 154 Ω / Off: 166 Ω (2WD)</li> <li>• On: 182 Ω / Off: 192 Ω (4WD)</li> </ul> | H   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 8/16  | <ul style="list-style-type: none"> <li>• On: 166 Ω / Off: 177 Ω (2WD)</li> <li>• On: 191 Ω / Off: 200 Ω (4WD)</li> </ul> | I   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 7/16  | <ul style="list-style-type: none"> <li>• On: 177 Ω / Off: 188 Ω (2WD)</li> <li>• On: 200 Ω / Off: 211 Ω (4WD)</li> </ul> | J   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 6/16  | <ul style="list-style-type: none"> <li>• On: 188 Ω / Off: 199 Ω (2WD)</li> <li>• On: 211Ω / Off: 219 Ω (4WD)</li> </ul>  | K   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 5/16  | <ul style="list-style-type: none"> <li>• On: 199 Ω / Off: 216 Ω (2WD)</li> <li>• On: 219 Ω / Off: 228 Ω (4WD)</li> </ul> | L   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 4/16  | <ul style="list-style-type: none"> <li>• On: 215 Ω / Off: 232 Ω (2WD)</li> <li>• On: 227 Ω / Off: 236 Ω (4WD)</li> </ul> | M   |
|  |  |  |                  |                    | Resistance value corresponding to SEG 3/16  | <ul style="list-style-type: none"> <li>• On: 233 Ω / Off: 252 Ω (2WD)</li> <li>• On: 235 Ω / Off: 245 Ω (4WD)</li> </ul> |     |
|  |  |  |                  |                    | Resistance value corresponding to SEG 2/16  | <ul style="list-style-type: none"> <li>• On: 251 Ω / Off: 270 Ω (2WD)</li> <li>• On: 246 Ω / Off: 253 Ω (4WD)</li> </ul> |     |
| Resistance value corresponding to SEG 1/16 | <ul style="list-style-type: none"> <li>• On: 271 Ω / Off: 287 Ω (2WD)</li> <li>• On: 253 Ω / Off: 258 Ω (4WD)</li> </ul> |  |                  |                    |   |  |     |
| 7<br>(R)                                   | Ground   | Air bag signal                               | Input            | Ignition switch ON | Air bag warning lamp ON                     | 4 V  |     |
|  |  |  |                  |                    | Air bag warning lamp OFF                    | 0 V  |     |
| 8<br>(P)                                   | Ground   | Over drive control switch signal             | Input            | Ignition switch ON | Over drive control switch ON                | 4 V  | MWI |
|  |  |  |                  |                    | Over drive control switch OFF               | 0 V  |     |
| 9<br>(W)                                   | Ground   | Seat belt buckle switch signal (driver side) | Input            | Engine idling      | When driver seat belt is fastened.          | 12 V   | O   |
|  |  |  |                  |                    | When driver seat belt is unfastened.        | 0 V  | P   |
| 10<br>(SB)                                 | Ground   | Parking brake switch signal                  | Input            | Ignition switch ON | Parking brake applied.                      | 0 V  |     |
|  |  |  |                  |                    | Parking brake released.                     | 5 V  |     |
| 11<br>(G)                                  | Ground   | Brake fluid level switch signal              | Input            | Ignition switch ON | Brake fluid level is normal                 | 5 V  |     |
|  |  |  |                  |                    | Brake fluid level is less than LOW level    | 0 V  |     |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Terminal No.<br>(Wire color) |        | Description                                     |                  | Condition           |  | Value<br>(Approx.)   |
|------------------------------|--------|---|------------------|---------------------|--|--|
| +                            | -      | Signal name                                     | Input/<br>Output |                     |  |  |
| 14<br>(R)                    | Ground | Manual mode shift up signal                     | Input            | Ignition switch ON  | Selector lever UP operation  | 0 V  |
|                              |        |   |                  |                     | Other than the above   | 12 V   |
| 15<br>(L)                    | Ground | ACC power supply                                | Input            | Ignition switch ACC | —  | Battery voltage  |
| 16<br>(W)                    | Ground | Manual mode shift down signal                   | Input            | Ignition switch ON  | Selector lever DOWN operation  | 0 V  |
|                              |        |   |                  |                     | Other than the above   | 12 V   |
| 18<br>(R)                    | Ground | Security signal                                 | Input            | Ignition switch OFF | Security indicator lamp ON   | 0 V  |
|                              |        |   |                  |                     | Security indicator lamp OFF  | 12 V   |
| 19<br>(GR)                   | Ground | Ambient sensor signal                           | Input            | Ignition switch ON  | Changes depending to ambient temperature.  | <p style="text-align: center;">(V)</p> <p style="text-align: center;">-10 0 10 20 30 40 [°C]<br/>(14) (32) (50) (68) (86) (104) [°F]</p> <p style="text-align: right; font-size: small;">JSNIA0014GB</p> |
| 20<br>(R)                    | Ground | Ambient sensor ground                           | —                | Ignition switch ON  | —  | 0 V  |
| 21<br>(B)                    | Ground | Ground  | —                | Ignition switch ON  | —  | 0 V  |
| 22<br>(B)                    | Ground | Ground  | —                | Ignition switch ON  | —  | 0 V  |
| 23<br>(B)                    | Ground | Ground  | —                | Ignition switch ON  | —  | 0 V  |
| 24<br>(L)                    | Ground | Fuel level sensor ground                        | —                | Ignition switch ON  | —  | 0 V  |
| 25<br>(B)                    | Ground | ESP ground                                      | —                | Ignition switch ON  | —  | 0 V  |
| 27<br>(LG)                   | Ground | Battery power supply                            | Input            | Ignition switch OFF | —  | Battery voltage  |
| 28<br>(GR)                   | Ground | Ignition signal                                 | Input            | Ignition switch ON  | —  | Battery voltage  |
| 29<br>(V)                    | Ground | Seat belt buckle switch signal (passenger side) | Input            | Engine idling       | <ul style="list-style-type: none"> <li>• When getting in the passenger seat.</li> <li>• When passenger seat belt is fastened.</li> </ul>   | 12 V   |
|                              |        |   |                  |                     | <ul style="list-style-type: none"> <li>• When getting in the passenger seat.</li> <li>• When passenger seat belt is unfastened.</li> </ul> | 0 V  |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Terminal No.<br>(Wire color) |        | Description  |                  | Condition                |                                    | Value<br>(Approx.)  |
|------------------------------|--------|--|------------------|--------------------------|------------------------------------|---|
| +                            | -      | Signal name  | Input/<br>Output |                          |                                    |   |
| 30<br>(R)                    | Ground | Stop lamp switch signal  | Input            | Ignition<br>switch<br>ON | Brake pedal is depressed           | 12 V  |
|                              |        |  |                  |                          | Other than the above               | 0 V   |
| 31<br>(P)                    | Ground | A/C auto amp. /PTC heater<br>control unit connection rec-<br>ognition signal | Input            | Ignition<br>switch<br>ON | —                                  | 5 V   |
| 33<br>(B/R)                  | Ground | Filter warning signal  | Input            | Ignition<br>switch<br>ON | —                                  | —   |
| 36<br>(Y)                    | Ground | Manual mode signal   | Input            | Ignition<br>switch<br>ON | Selector manual mode po-<br>sition | 0 V   |
|                              |        |  |                  |                          | Other than the above               | 12 V  |
| 37<br>(G)                    | Ground | Non-manual mode signal   | Input            | Ignition<br>switch<br>ON | Selector manual mode po-<br>sition | 12 V  |
|                              |        |  |                  |                          | Other than the above               | 0 V   |
| 38<br>(P)                    | Ground | Alternator signal  | Input            | Ignition<br>switch<br>ON | Charge warning lamp ON             | 2 V   |
|                              |        |  |                  |                          | Charge warning lamp OFF            | 12 V  |
| 39<br>(Y)                    | Ground | Oil level sensor signal  | Input            | Ignition<br>switch<br>ON | —                                  | Refer to <a href="#">MWI-50, "Component Inspection"</a> . |
| 40<br>(SB)                   | Ground | Oil level sensor ground  | —                | Ignition<br>switch<br>ON | —                                  | 0 V   |

## Fail-Safe

INFOID:000000006412917

### FAIL-SAFE

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

| Function                         |                                | Specifications  |
|----------------------------------|--------------------------------|---|
| Speedometer                      |                                | Reset to zero by suspending communication.  |
| Tachometer                       |                                |   |
| Engine coolant temperature gauge |                                |   |
| Illumination control             |                                | When suspending communication, changes to nighttime mode.   |
| Shift position indicator         | Shift position                 | When suspending communication, not indicate.  |
|                                  | S mode indicator lamp          |   |
| Information display              | Instantaneous fuel consumption | <ul style="list-style-type: none"> <li>When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result.</li> </ul> |
|                                  | Average fuel consumption       |   |
|                                  | Possible driving distance      | <ul style="list-style-type: none"> <li>When reception time of an abnormal signal is more than two seconds, the last result calculated during normal condition is indicated.</li> </ul>    |
|                                  | Torque distribution 4WD        |   |
| Buzzer                           |                                | The buzzer turns OFF by suspending communication.   |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

|                             | Function                                     | Specifications                                  |
|-----------------------------|--|---|
| Warning lamp/indicator lamp | ABS warning lamp                             | The lamp turns ON by suspending communication.  |
|                             | Malfunction indicator (Yellow)               |   |
|                             | SLIP indicator lamp                          |   |
|                             | EPS warning lamp                             |   |
|                             | 4WD warning lamp                             |   |
|                             | Brake warning lamp                           |   |
|                             | VDC warning lamp                             | The lamp turns OFF by suspending communication. |
|                             | High beam indicator lamp                     |   |
|                             | Turn signal indicator lamp                   |   |
|                             | Door warning lamp                            |   |
|                             | Light indicator lamp                         |   |
|                             | Engine start operation indicator lamp        |   |
|                             | Shift P warning lamp                         |   |
|                             | Front fog lamp indicator lamp                |   |
|                             | Rear fog lamp indicator lamp                 |   |
|                             | Oil pressure warning lamp                    |   |
|                             | Malfunction indicator (Red)                  |   |
|                             | CRUISE indicator lamp                        |   |
|                             | SET indicator lamp                           |   |
|                             | Speed limiter indicator lamp                 |   |
|                             | 4WD indicator lamp                           |   |
|                             | 4WD LOCK indicator lamp                      |   |
|                             | Key warning lamp                             |   |
|                             | DPF (Diesel Particulate Filter) warning lamp |   |
|                             | Glow indicator lamp                          |   |
| CVT indicator lamp          |  |   |
| Filter warning lamp         |  |   |

## DTC Index

INFOID:000000006412918

| Display contents of CONSULT-III | Diagnostic item is detected when...  | Refer to  |
|---------------------------------|--|---|
| CAN COMM CIRCUIT<br>[U1000]     | When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more.                  | <a href="#">MWI-44.<br/>"Diagnosis Procedure"</a> |
| CONTROL UNIT (CAN)<br>[U1010]   | When detecting error during the initial diagnosis of the CAN controller of combination meter.                            | <a href="#">MWI-45.<br/>"Diagnosis Procedure"</a> |
| VEHICLE SPEED<br>[B2205]        | The abnormal vehicle speed signal is input from the ABS actuator and electric unit (control unit) for 2 seconds or more. | <a href="#">MWI-46.<br/>"Diagnosis Procedure"</a> |
| ENGINE SPEED<br>[B2267]         | If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.                                       | <a href="#">MWI-47.<br/>"Diagnosis Procedure"</a> |
| WATER TEMP<br>[B2268]           | If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.                        | <a href="#">MWI-48.<br/>"Diagnosis Procedure"</a> |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Display contents of CONSULT-III | Diagnostic item is detected when...   | Refer to   |
|---------------------------------|---|--|
| OIL LEV SEN OPEN<br>[B2321]     | Signal from oil level sensor is open (resistance value of oil level sensor is larger than 20 $\Omega$ ).    | <a href="#">MWI-49.</a><br><a href="#">"Diagnosis Procedure"</a> |
| OIL LEV SEN SHORT<br>[B2322]    | Signal from oil level sensor is shorted (resistance value of oil level sensor is smaller than 3 $\Omega$ ). | <a href="#">MWI-49.</a><br><a href="#">"Diagnosis Procedure"</a> |

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# IPDM E/R

< ECU DIAGNOSIS INFORMATION >

## IPDM E/R

### List of ECU Reference

INFOID:000000006412919

| ECU      | Reference  |
|----------|--|
| IPDM E/R | <a href="#">PCS-17, "Reference Value"</a> (with I-KEY), or <a href="#">PCS-48, "Reference Value"</a> (without I-KEY) |
|          | <a href="#">PCS-24, "Fail-Safe"</a> (with I-KEY), or <a href="#">PCS-54, "Fail-Safe"</a> (without I-KEY)             |
|          | <a href="#">PCS-25, "DTC Index"</a> (with I-KEY), or <a href="#">PCS-55, "DTC Index"</a> (without I-KEY)             |

# METER SYSTEM

< WIRING DIAGRAM >


## WIRING DIAGRAM

### METER SYSTEM

#### Wiring Diagram

INFOID:000000006412920

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12. "Connector Information/Explanation of Option Abbreviation"](#).



\*: This connector is not shown in "Harness Layout".

2010/07/07


JCNWA3294GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# METER SYSTEM


< WIRING DIAGRAM >



JCNWA3295GB

# METER SYSTEM

< WIRING DIAGRAM >



JCNWA3296GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# DIAGNOSIS AND REPAIR WORKFLOW (METER SYSTEM)

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW (METER SYSTEM)

Work flow

INFOID:000000006412922

#### OVERALL SEQUENCE



- Reference 1...[MWI-22, "On Board Diagnosis Function"](#).
- Reference 2...[MWI-36, "DTC Index"](#).
- Reference 3...[MWI-51, "COMBINATION METER : Diagnosis Procedure"](#).

#### DETAILED FLOW

##### 1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

##### 2.CHECK SYMPTOM

# DIAGNOSIS AND REPAIR WORKFLOW (METER SYSTEM)

## < BASIC INSPECTION >

---

- Check the symptom based on the information obtained from the customer.
- Check that any other malfunctions are present.

>> GO TO 3.

## 3.CHECK ON BOARD DIAGNOSIS OPERATION

---

Check that the on board diagnosis function operates. Refer to [MWI-22, "On Board Diagnosis Function"](#).

Does the on board diagnosis function operate normally?

YES >> GO TO 4.

NO >> GO TO 6.

## 4.CHECK CONSULT-III SELF-DIAGNOSIS RESULTS

---

Connect CONSULT-III and perform self-diagnosis. Refer to [MWI-36, "DTC Index"](#).

Are self-diagnosis results normal?

YES >> GO TO 5.

NO >> GO TO 8.

## 5.NARROW DOWN THE MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

---

Perform symptom diagnosis and narrow down the malfunctioning parts.

>> GO TO 8.

## 6.CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUITS

---

Check combination meter power supply and ground circuits. Refer to [MWI-51, "COMBINATION METER : Diagnosis Procedure"](#).

Is inspection result OK?

YES >> GO TO 7.

NO >> GO TO 8.

## 7.REPLACE COMBINATION METER

---

Replace combination meter.

>> GO TO 9.

## 8.REPAIR OR REPLACE MALFUNCTIONING PARTS

---

Repair or replace the malfunctioning parts.

### **NOTE:**

If DTC is displayed, erase DTC after repair or replace malfunctioning parts.

>> GO TO 9.

## 9.FINAL CHECK

---

Check that the combination meter operates normally.

Do they operate normally?

YES >> INSPECTION END

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:000000006412923

CAN (Controller Area Network) is a serial communication system for real time application. It is an on-vehicle multiplex communication system with high data communication speed and excellent error detectability. Many electronic control units are equipped onto vehicles, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-31, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

#### DTC Logic

INFOID:000000006412924

#### DTC DETECTION LOGIC

| DTC   | Display contents of CONSULT-III | Diagnostic item is detected when...   | Probable malfunction location |
|-------|---------------------------------|---|-------------------------------|
| U1000 | CAN COMM CIRCUIT                | When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more. | CAN communication system      |

#### Diagnosis Procedure

INFOID:000000006412925

#### 1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "METER/M&A".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).  
NO >> Refer to [GI-42, "Intermittent Incident"](#).

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000006412926

Initial diagnosis of combination meter.

### DTC Logic

INFOID:000000006412927

### DTC DETECTION LOGIC

| DTC   | Display contents of CONSULT-III | Diagnostic item is detected when...   | Probable malfunction location |
|-------|---------------------------------|---|-------------------------------|
| U1010 | CONTROL UNIT (CAN)              | When detecting error during the initial diagnosis of the CAN controller of combination meter. | Combination meter             |

### Diagnosis Procedure

INFOID:000000006412928

#### 1. REPLACE COMBINATION METER

When DTC "U1010" is detected, replace combination meter.

>> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# B2205 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

## B2205 VEHICLE SPEED

### Description

INFOID:000000006412929

Vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) via CAN communication to combination meter.

### DTC Logic

INFOID:000000006412930

### DTC DETECTION LOGIC

| DTC   | Display contents of CONSULT-III | Diagnostic item is detected when...  | Probable malfunction location  |
|-------|---------------------------------|--|--|
| B2205 | VEHICLE SPEED                   | An abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more | <ul style="list-style-type: none"><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul> |

### Diagnosis Procedure

INFOID:000000006412931

#### 1. PERFORM SELF-DIAGNOSIS OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform "Self Diagnostic Result" of "ABS", and repair or replace malfunctioning parts.

- >> • Refer to [BRC-131, "CONSULT-III Function"](#) (with ESP).
- Refer to [BRC-24, "CONSULT-III Function"](#) (without ESP).

# B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

## B2267 ENGINE SPEED

### Description

INFOID:000000006412932

The engine speed signal is transmitted from ECM to the combination meter via CAN communication.

### DTC Logic

INFOID:000000006412933

### DTC DETECTION LOGIC

| DTC   | Display contents of CONSULT-III | Diagnostic item is detected when...  | Probable malfunction location  |
|-------|---------------------------------|--|--|
| B2267 | ENGINE SPEED                    | ECM continuously transmits abnormal engine speed signals for 2 seconds or more | <ul style="list-style-type: none"><li>• Crankshaft position sensor (POS)</li><li>• ECM</li></ul> |

### Diagnosis Procedure

INFOID:000000006412934

#### 1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnostic Result" of "ENGINE", and repair or replace malfunctioning parts.

>> Refer to [EC-108, "DTC Index"](#) (MR16DDT), [EC-522, "DTC Index"](#) (HR16DE), or [EC-855, "DTC Index"](#) (K9K).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

## B2268 WATER TEMP

### Description

INFOID:000000006412935

The engine coolant temperature signal is transmitted from ECM to the combination meter via CAN communication.

### DTC Logic

INFOID:000000006412936

### DTC DETECTION LOGIC

| DTC   | Display contents of CONSULT-III | Diagnostic item is detected when...   | Probable malfunction location   |
|-------|---------------------------------|---|---|
| B2268 | WATER TEMP                      | ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more | <ul style="list-style-type: none"><li>• Engine coolant temperature sensor</li><li>• ECM</li></ul> |

### Diagnosis Procedure

INFOID:000000006412937

#### 1. PERFORM SELF-DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of "ENGINE", and repair or replace malfunctioning parts.

>> Refer to [EC-108. "DTC Index"](#) (MR16DDT), [EC-522. "DTC Index"](#) (HR16DE), or [EC-855. "DTC Index"](#) (K9K).

# B2321, B2322 OIL LEVEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## B2321, B2322 OIL LEVEL SENSOR

### Description

INFOID:000000006413654

The oil level sensor detects the level of engine oil, and then transmits the oil level signal to the combination meter.

### DTC Logic

INFOID:000000006413655

### DTC DETECTION LOGIC

| DTC   | Display contents of CONSULT-III | Diagnostic item is detected if...  | Probable malfunction location   |
|-------|---------------------------------|--|---|
| B2321 | OIL LEV SEN OPEN                | Oil level sensor signal circuit is open.<br>(Resistance value of oil level sensor exceeds 20 Ω)        | <ul style="list-style-type: none"> <li>Oil level sensor signal circuit</li> <li>Oil level sensor</li> </ul> |
| B2322 | OIL LEV SEN SHORT               | Oil level sensor signal circuit is shorted.<br>(Resistance value of oil level sensor is less than 3 Ω) |   |

#### NOTE:

When the following conditions are satisfied, the combination meter reads the resistance value of oil level sensor. The combination meter does not read the oil level sensor resistance value within 5 minutes after the previous reading of oil level sensor resistance value by the combination meter.

- Turn the ignition switch OFF.
- Wait for 5 minutes or more, then open the front door.

DTC (B2321: OIL LEV SEN OPEN, B2322: OIL LEV SEN SHORT) is also detected at the timing described above.

### Diagnosis Procedure

INFOID:000000006413656

#### 1. CHECK OIL LEVEL SENSOR SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect connectors of combination meter and oil level sensor.
- Check for continuity between combination meter harness connector and oil level sensor harness connector.

| Combination meter |          | Oil level sensor   |          | Continuity |
|-------------------|----------|--------------------|----------|------------|
| Connector         | Terminal | Connector          | Terminal |            |
| M34               | 39       | F103 <sup>*1</sup> | 1        | Existed    |
|                   |          | F104 <sup>*2</sup> |          |            |
|                   |          | F105 <sup>*3</sup> |          |            |

- \*1: HR16DE engine models
- \*2: MR16DDT engine models
- \*3: K9K engine models

- Check for continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity  |
|-------------------|----------|--------|-------------|
| Connector         | Terminal |        |             |
| M34               | 39       |        | Not existed |

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair harnesses or connectors.

#### 2. CHECK OIL LEVEL SENSOR GROUND CIRCUIT

Check for continuity between combination meter harness connector and oil level sensor harness connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

MWI

# B2321, B2322 OIL LEVEL SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

| Combination meter |          | Oil level sensor   |          | Continuity |
|-------------------|----------|--------------------|----------|------------|
| Connector         | Terminal | Connector          | Terminal |            |
| M34               | 40       | F103 <sup>*1</sup> | 2        | Existed    |
|                   |          | F104 <sup>*2</sup> |          |            |
|                   |          | F105 <sup>*3</sup> |          |            |

\*1: HR16DE engine models

\*2: MR16DDT engine models

\*2: K9K engine models

### Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harnesses or connectors.

## Component Inspection

INFOID:000000006413657

### 1. CHECK OIL LEVEL SENSOR

1. Turn ignition switch OFF.
2. Disconnect oil level sensor connector.
3. Check resistance between oil level sensor terminals 1 and 2.

| Terminal |   | Resistance value (Ω) |
|----------|---|----------------------|
| 1        | 2 | 3 - 20               |

### Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace oil level sensor.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

### COMBINATION METER : Diagnosis Procedure

INFOID:000000006412938

#### 1. CHECK FUSE

Check for blown fuses.

| Power source                | Fuse No.                     |
|-----------------------------|------------------------------|
| Battery                     | 11                           |
| Ignition switch ON or START | 5                            |
| Ignition switch ACC or ON   | 18 (Without intelligent key) |
|                             | 19 (With intelligent key)    |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

#### 2. CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector and ground.

| Terminals         |          | Ignition switch position | Voltage (Approx.) |
|-------------------|----------|--------------------------|-------------------|
| (+)               | (-)      |                          |                   |
| Combination meter |          | Ground                   | Battery voltage   |
| Connector         | Terminal |                          |                   |
| M34               | 27       |                          |                   |
|                   | 15       |                          |                   |
|                   | 28       |                          |                   |
|                   |          | OFF                      |                   |
|                   |          | ACC                      |                   |
|                   |          | ON                       |                   |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

#### 3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector and ground.

| Combination meter |               | Ground | Continuity |
|-------------------|---------------|--------|------------|
| Connector         | Terminal      |        |            |
| M34               | 21            | Ground | Existed    |
|                   | 22            |        |            |
|                   | 23            |        |            |
|                   | 25 (With ESP) |        |            |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FUEL LEVEL SENSOR SIGNAL CIRCUIT

### Component Function Check

INFOID:000000006412941

#### 2WD MODELS

##### 1.CHECK COMBINATION METER OUTPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and compare the "FUEL METER" monitor value with the fuel gauge reading on the combination meter.

| Fuel gauge indication position | Reference value of data monitor [L] |
|--------------------------------|-------------------------------------|
| 16/16                          | Approx. 44.7                        |
| 14/16                          | Approx. 43.4                        |
| 12/16                          | Approx. 40.0                        |
| 10/16                          | Approx. 35.4                        |
| 8/16                           | Approx. 29.8                        |
| 6/16                           | Approx. 23.7                        |
| 4/16                           | Approx. 17.3                        |
| 2/16                           | Approx. 8.3                         |
| 0/16                           | Approx. 1.2                         |

Does monitor value match fuel gauge reading?

YES >> INSPECTION END

NO >> Replace combination meter. Refer to [MWI-69, "Removal and Installation"](#).

#### 4WD MODELS

##### 1.CHECK COMBINATION METER OUTPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and compare the "FUEL METER" monitor value with the fuel gauge reading on the combination meter.

| Fuel gauge indication position | Reference value of data monitor [L] |
|--------------------------------|-------------------------------------|
| 16/16                          | Approx. 44.2                        |
| 14/16                          | Approx. 39.5                        |
| 12/16                          | Approx. 33.2                        |
| 10/16                          | Approx. 27.6                        |
| 8/16                           | Approx. 22.9                        |
| 6/16                           | Approx. 18.3                        |
| 4/16                           | Approx. 14.2                        |
| 2/16                           | Approx. 9.6                         |
| 0/16                           | Approx. 6.8                         |

Does monitor value match fuel gauge reading?

YES >> INSPECTION END

NO >> Replace combination meter. Refer to [MWI-69, "Removal and Installation"](#).

### Diagnosis Procedure

INFOID:000000006412942

##### 1.CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector and ground.

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

| Terminals         |          | Voltage<br>(Approx.) |
|-------------------|----------|----------------------|
| (+)               | (-)      |                      |
| Combination meter |          |                      |
| Connector         | Terminal | Ground               |
| M34               | 6        |                      |

Does it match fuel gauge reading?

YES >> GO TO 2.

NO >> Replace the combination meter. Refer to [MWI-69. "Removal and Installation"](#).

### 2. CHECK FUEL LEVEL SENSOR CIRCUIT

- Turn ignition switch OFF.
- Disconnect combination meter connector and fuel level sensor unit connector.
- Check continuity between combination meter harness connector terminal and fuel level sensor unit harness connector terminal.

| Combination meter |          | Fuel level sensor unit |          | Continuity |
|-------------------|----------|------------------------|----------|------------|
| Connector         | Terminal | Connector              | Terminal |            |
| M34               | 6        | B40 <sup>*1</sup>      | 3        | Existed    |
|                   |          | B46 <sup>*2</sup>      | 3        |            |

\*1: 2WD models

\*2: 4WD models

- Check continuity between combination meter harness connector terminal and ground.

| Combination meter |          | Ground | Continuity  |
|-------------------|----------|--------|-------------|
| Connector         | Terminal |        |             |
| M34               | 6        |        | Not existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT

Check continuity between fuel level sensor unit harness connector terminal and combination meter harness connector terminal.

| Fuel level sensor unit |          | Combination meter |          | Continuity |
|------------------------|----------|-------------------|----------|------------|
| Connector              | Terminal | Connector         | Terminal |            |
| B40 <sup>*1</sup>      | 1        | M34               | 24       | Existed    |
| B46 <sup>*2</sup>      | 1        |                   |          |            |

\*1: 2WD models

\*2: 4WD models

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## Component Inspection

INFOID:00000006412943

### 2WD MODELS

#### 1.REMOVE FUEL LEVEL SENSOR UNIT (MAIN)

Remove the fuel level sensor unit (main). Refer to [FL-6, "2WD : Removal and Installation"](#) (MR16DDT), [FL-33, "Removal and Installation"](#) (HR16DE), or [FL-51, "Removal and Installation"](#) (K9K).

>> GO TO 2.

#### 2.CHECK FUEL LEVEL SENSOR UNIT (MAIN)

Check the resistance between fuel level sensor unit and fuel pump.


| Terminals                        |   | Condition  | Resistance (Ω)<br>(Approx.) | Height [mm (in)] |
|----------------------------------|---|------------|-----------------------------|------------------|
| Fuel level sensor unit<br>(main) |   |            |                             |                  |
| 1                                | 3 | Full* (A)  | 51                          | 140.6 (7.02)     |
|                                  |   | Empty* (B) | 283                         | 13.9 (1.425)     |

\*: When float rod is contact with stopper.

Is inspection result OK?

YES >> INSPECTION END

NO >> Replace the fuel level sensor unit (main). Refer to [FL-6, "2WD : Removal and Installation"](#) (MR16DDT), [FL-33, "Removal and Installation"](#) (HR16DE), or [FL-51, "Removal and Installation"](#) (K9K).



### 4WD MODELS

#### 1.REMOVE FUEL LEVEL SENSOR UNIT (MAIN)

Remove the fuel level sensor unit (main). Refer to [FL-11, "4WD : Removal and Installation"](#).

>> GO TO 2.

#### 2.CHECK FUEL LEVEL SENSOR UNIT (MAIN)

Check the resistance between fuel level sensor unit and fuel pump.

| Terminals                        |   | Condition  | Resistance (Ω)<br>(Approx.) | Height [mm (in)] |
|----------------------------------|---|------------|-----------------------------|------------------|
| Fuel level sensor unit<br>(main) |   |            |                             |                  |
| 6                                | 1 | Full* (A)  | 25.5                        | 177 (7.33)       |
|                                  |   | Empty* (B) | 99.5                        | 24 (1.429)       |
| 4                                | 7 | —          | 0                           | —                |

\*: When float rod is contact with stopper.

Is inspection result OK?

YES >> GO TO 3.


NO >> Replace fuel level sensor unit (main). Refer to [FL-11, "4WD : Removal and Installation"](#).

#### 3.REMOVE FUEL LEVEL SENSOR UNIT (SUB)

Remove the fuel level sensor unit (sub). Refer to [FL-11, "4WD : Removal and Installation"](#).

>> GO TO 4.

#### 4.CHECK FUEL LEVEL SENSOR UNIT (SUB)



## FUEL LEVEL SENSOR SIGNAL CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

Check the resistance between fuel level sensor unit (sub).


| Terminals                       |   | Condition  | Resistance ( $\Omega$ )<br>(Approx.) | Height [mm (in)] |
|---------------------------------|---|------------|--------------------------------------|------------------|
| Fuel level sensor unit<br>(sub) |   |            |                                      |                  |
| 7                               | 6 | Full* (A)  | 25.5                                 | 180 (7.4)        |
|                                 |   | Empty* (B) | 183.5                                | 15 (1.24)        |

\*: When float rod is contact with stopper.

#### Is inspection result OK?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit (sub). Refer to [FL-11, "4WD : Removal and Installation"](#).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# OIL PRESSURE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## OIL PRESSURE SWITCH SIGNAL CIRCUIT

### Component Function Check

INFOID:000000006413644

#### 1. CHECK COMBINATION METER INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "OIL W/L" monitor value.

"OIL W/L"  
 Ignition switch ON : On  
 Engine running : Off

>> INSPECTION END

### Diagnosis Procedure

INFOID:000000006413645

#### 1. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and oil pressure switch connector.
3. Check continuity between IPDM E/R harness connector and oil pressure switch harness connector.

| Terminals |          |                     |          | Continuity |
|-----------|----------|---------------------|----------|------------|
| (+)       |          | (-)                 |          |            |
| IPDM E/R  |          | Oil pressure switch |          |            |
| Connector | Terminal | Connector           | Terminal |            |
| E13       | 24       | F64                 | 1        | Existed    |

4. Check continuity between IPDM E/R harness connector and ground.

| Terminals |          |        |  | Continuity  |
|-----------|----------|--------|--|-------------|
| (+)       |          | (-)    |  |             |
| IPDM E/R  |          | Ground |  |             |
| Connector | Terminal |        |  |             |
| E13       | 24       |        |  | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Repair harness or connector.


### Component Inspection

INFOID:000000006413646

#### 1. CHECK OIL PRESSURE SWITCH

Check continuity between oil pressure switch and ground.

| Condition      | Continuity  |
|----------------|-------------|
| Engine stopped | Existed     |
| Engine running | Not existed |



ELF0044D

Is the inspection result normal?

- YES >> INSPECTION END

## OIL PRESSURE SWITCH SIGNAL CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

NO >> Replace oil pressure switch. Refer to [LU-8, "Inspection"](#) (MR16DDT), [LU-25, "Inspection"](#) (HR16DE), or [LU-33, "Inspection"](#) (K9K).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

## SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT (DRIVER SIDE)

### Component Function Check

INFOID:000000006413648

#### 1. CHECK COMBINATION METER INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "BUCKLE SW" monitor value.

BUCKLE SW  
When driver seat belt is fastened : Off  
When driver seat belt is unfastened : On

>> INSPECTION END

### Diagnosis Procedure

INFOID:000000006413649

#### 1. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and seat belt buckle switch (driver side) connector.
3. Check continuity between combination meter harness connector and seat belt buckle switch (driver side) harness connector.

| Combination meter |          | Seat belt buckle switch (driver side) |          | Continuity |
|-------------------|----------|---------------------------------------|----------|------------|
| Connector         | Terminal | Connector                             | Terminal |            |
| M34               | 9        | B50 <sup>*1</sup>                     | 1        | Existed    |
|                   |          | B22 <sup>*2</sup>                     |          |            |

\*1: LHD models

\*2: RHD models

4. Check harness continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity  |
|-------------------|----------|--------|-------------|
| Connector         | Terminal |        |             |
| M34               | 9        |        | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) GROUND CIRCUIT

Check harness continuity between seat belt buckle switch (driver side) harness connector and ground.

| Seat belt buckle switch (driver side) |          | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| Connector                             | Terminal |        |            |
| B50 <sup>*1</sup>                     | 2        |        | Existed    |
| B22 <sup>*2</sup>                     |          |        |            |

\*1: LHD models

\*2: RHD models

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

# SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT (DRIVER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

## Component Inspection

INFOID:000000006413650

### 1. CHECK SEAT BELT BUCKLE SWITCH UNIT

1. Turn ignition switch OFF.
2. Disconnect the seat belt buckle switch (driver side) connector.
3. Check continuity between terminals.

| Terminal |   | Condition                           | Continuity  |
|----------|---|-------------------------------------|-------------|
| 1        | 2 | When driver seat belt is fastened   | Not existed |
|          |   | When driver seat belt is unfastened | Existed     |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the seat belt buckle (driver side). Refer to [SB-8. "SEAT BELT BUCKLE : Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

## SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT (PASSENGER SIDE)

### Diagnosis Procedure

INFOID:000000006413651

#### 1. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and seat belt buckle switch (passenger side) connector.
3. Check continuity between combination meter harness connector and seat belt buckle switch (passenger side) harness connector.

| Combination meter |          | Seat belt buckle switch (passenger side) |          | Continuity |
|-------------------|----------|--|----------|------------|
| Connector         | Terminal | Connector                                | Terminal |            |
| M34               | 29       | B23*1                                    | 1        | Existed    |
|                   |          | B51*2                                    |          |            |

\*1: RHD models

\*2: LHD models

4. Check harness continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity  |
|-------------------|----------|--------|-------------|
| Connector         | Terminal |        |             |
| M34               | 29       |        | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) GROUND CIRCUIT

Check harness continuity between seat belt buckle switch (passenger side) harness connector and ground.

| Seat belt buckle switch (passenger side) |          | Ground | Continuity |
|--|----------|--------|------------|
| Connector                                | Terminal |        |            |
| B23*1                                    | 2        |        | Existed    |
| B51*2                                    |          |        |            |

\*1: RHD models

\*2: LHD models

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

### Component Inspection (Seat Belt Buckle Switch)

INFOID:000000006413652

#### 1. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

1. Turn ignition switch OFF.
2. Disconnect the seat belt buckle switch (passenger side) connectors.
3. Check continuity between terminals.

| Terminal |   | Condition                              | Continuity  |
|----------|---|--|-------------|
| 1        | 3 | When passenger seat belt is fastened   | Not existed |
|          |   | When passenger seat belt is unfastened | Existed     |
| 2        | 4 | —                                      | Existed     |

# SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the seat belt buckle (passenger side). Refer to [SB-8. "SEAT BELT BUCKLE : Removal and Installation"](#).

Component Inspection (Occupant Detection Unit)

INFOID:000000006413653

## 1. CHECK OCCUPANT DETECTION UNIT

1. Turn ignition switch OFF.
2. Disconnect the occupant detection unit connector.
3. Check continuity between terminals.

| Terminal |   | Condition                          | Continuity  |
|----------|---|------------------------------------|-------------|
| 3        | 4 | When getting in the passenger seat | Existed     |
|          |   | Other than above                   | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the seat cushion trim and pad. Refer to [SE-21. "SEAT CUSHION : Disassembly and Assembly"](#) (2WD) or [SE-29. "SEAT CUSHION : Disassembly and Assembly"](#) (4WD).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:000000006413647

#### 1. CHECK A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector and ground.

| Terminals         |          | Voltage<br>(Approx.) |
|-------------------|----------|----------------------|
| (+)               | (-)      |                      |
| Combination meter |          | 5 V                  |
| Connector         | Terminal |                      |
| M34               | 31       |                      |

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> GO TO 2.

#### 2. CHECK A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and A/C auto amp. connector.
3. Check continuity between combination meter harness connector and A/C auto amp. harness connector.

| Combination meter |          | A/C auto amp.     |                 | Continuity |
|-------------------|----------|-------------------|-----------------|------------|
| Connector         | Terminal | Connector         | terminal        |            |
| M34               | 31       | M50 <sup>*1</sup> | 9 <sup>*1</sup> | Existed    |
|                   |          | M59 <sup>*2</sup> | 6 <sup>*2</sup> |            |

\*1: 4WD models

\*2: 2WD models

4. Check continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity  |
|-------------------|----------|--------|-------------|
| Connector         | Terminal |        |             |
| M34               | 31       |        | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Repair harness or connector.

# PTC HEATER CONTROL UNIT CONNECTION RECOGNITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## PTC HEATER CONTROL UNIT CONNECTION RECOGNITION SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:000000006498593

#### 1. CHECK PTC HEATER CONTROL UNIT CONNECTION RECOGNITION SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector and ground.

| Terminals         |          | Voltage<br>(Approx.) |
|-------------------|----------|----------------------|
| (+)               | (-)      |                      |
| Combination meter |          | 5 V                  |
| Connector         | Terminal |                      |
| M34               | 31       |                      |

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> GO TO 2.

#### 2. CHECK PTC HEATER CONTROL UNIT CONNECTION RECOGNITION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and PTC heater control unit connector.
3. Check continuity between combination meter harness connector and PTC heater control unit harness connector.

| Combination meter |          | PTC heater control unit |          | Continuity |
|-------------------|----------|-------------------------|----------|------------|
| Connector         | Terminal | Connector               | terminal |            |
| M34               | 31       | M25                     | 4        | Existed    |

4. Check continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity  |
|-------------------|----------|--------|-------------|
| Connector         | Terminal |        |             |
| M34               | 31       |        | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

MWI

O  
P

# THE FUEL GAUGE INDICATOR DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## SYMPTOM DIAGNOSIS

### THE FUEL GAUGE INDICATOR DOES NOT OPERATE

#### Description

INFOID:000000006412949

Fuel gauge will not indicate from a certain position.

#### Diagnosis Procedure

INFOID:000000006412950

#### 1. CHECK COMBINATION METER OUTPUT SIGNAL

---

1. Connect CONSULT-III.
2. Select the "Data Monitor" for the "METER/M&A" and compare the "FUEL METER" monitor value with the fuel gauge reading on the combination meter. Refer to [MWI-52. "Component Function Check"](#).

Does monitor value match fuel gauge reading?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-69. "Removal and Installation"](#).

#### 2. CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

---

Check the fuel level sensor signal circuit. Refer to [MWI-52. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3. CHECK FUEL LEVEL SENSOR UNIT

---

Perform a unit check for the fuel level sensor unit. Refer to [MWI-54. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace fuel level sensor unit (main or sub). Refer to [FL-6. "2WD : Removal and Installation"](#) (MR16DDT) (2WD), [FL-11. "4WD : Removal and Installation"](#) (MR16DDT) (4WD), [FL-33. "Removal and Installation"](#) (HR16DE), or [FL-51. "Removal and Installation"](#) (K9K).

#### 4. CHECK FLOAT INTERFERENCE

---

Check that the float arm interferes with or binds to other components in the fuel tank.

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-69. "Removal and Installation"](#).

NO >> Repair or replace malfunctioning parts.

# THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

## THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

### Description

INFOID:000000006412953

The oil pressure warning lamp stays off when the ignition switch is turned ON.

### Diagnosis Procedure

INFOID:000000006412954

#### 1.CHECK OIL PRESSURE WARNING LAMP

Perform auto active test. Refer to [PCS-12, "Diagnosis Description"](#) (with I-KEY) or [PCS-43, "Diagnosis Description"](#) (without I-KEY).

Is oil pressure warning lamp blinking?

YES >> GO TO 2.

NO >> GO TO 4.

#### 2.CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Check the oil pressure switch signal circuit. Refer to [MWI-56, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3.CHECK OIL PRESSURE SWITCH

Perform a unit check for the oil pressure switch. Refer to [MWI-56, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#) (with I-KEY) or [PCS-63, "Removal and Installation"](#) (without I-KEY).

NO >> Replace oil pressure switch. Refer to [EM-330, "Disassembly and Assembly"](#) (K9K).

#### 4.CHECK COMBINATION METER INPUT SIGNAL

Connect CONSULT-III and perform an input signal check for the combination meter. Refer to [MWI-56, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-69, "Removal and Installation"](#).

NO >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#) (with I-KEY) or [PCS-63, "Removal and Installation"](#) (without I-KEY).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

# THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

## THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

### Description

INFOID:000000006412957

The oil pressure warning lamp remains illuminated while the engine is running (normal oil pressure).

### Diagnosis Procedure

INFOID:000000006412958

#### 1. CHECK OIL PRESSURE WARNING LAMP

Perform auto active test. Refer to [PCS-12, "Diagnosis Description"](#) (with I-KEY) or [PCS-43, "Diagnosis Description"](#) (without I-KEY).

Is oil pressure warning lamp blinking?

YES >> GO TO 2.

NO >> GO TO 5.

#### 2. CHECK IPDM E/R OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect the oil pressure switch connector.
3. Turn ignition switch ON.
4. Check voltage between the oil pressure switch harness connector and ground.

| Terminals           |          | Voltage<br>(Approx.) |
|---------------------|----------|----------------------|
| (+)                 | (-)      |                      |
| Oil pressure switch |          | Ground               |
| Connector           | Terminal |                      |
| F64                 | 2        |                      |
|                     |          | 12 V                 |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 4.

#### 3. CHECK OIL PRESSURE SWITCH

Perform a unit check for the oil pressure switch. Refer to [MWI-56, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#) (with I-KEY) or [PCS-63, "Removal and Installation"](#) (without I-KEY).

NO >> Replace oil pressure switch. Refer to [EM-330, "Disassembly and Assembly"](#) (K9K).

#### 4. CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Check the oil pressure switch signal circuit. Refer to [MWI-56, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

#### 5. CHECK COMBINATION METER INPUT SIGNAL

Connect CONSULT-III and perform an input signal check for the combination meter. Refer to [MWI-56, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-69, "Removal and Installation"](#).

NO >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#) (with I-KEY) or [PCS-63, "Removal and Installation"](#) (without I-KEY).

# THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

< SYMPTOM DIAGNOSIS >

## THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

### Description

INFOID:000000006412969

- The displayed ambient air temperature is higher than the actual temperature.
- The displayed ambient air temperature is lower than the actual temperature.

### Diagnosis Procedure

INFOID:000000006412970

#### NOTE:

Check that the symptom is not applicable to the normal operating condition before starting diagnosis. Refer to [MWI-68, "INFORMATION DISPLAY : Description"](#).

#### 1.CHECK AMBIENT SENSOR SIGNAL CIRCUIT

Check the ambient sensor signal circuit. Refer to [HAC-56, "Diagnosis Procedure"](#) (4WD models) or [HAC-146, "Diagnosis Procedure"](#) (2WD models).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2.CHECK A/C AUTO AMP./PTC HEATER CONTROL UNIT CONNECTION RECOGNITION SIGNAL CIRCUIT

Check the A/C auto amp./PTC heater control unit connection recognition signal circuit. Refer to [MWI-62, "Diagnosis Procedure"](#) (A/C auto amp.) or [MWI-63, "Diagnosis Procedure"](#) (PTC heater control unit).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3.CHECK AMBIENT SENSOR

Perform the part check for the ambient sensor. Refer to [HAC-57, "Component Inspection"](#) (4WD models) or [HAC-147, "Component Inspection"](#) (2WD models).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-69, "Removal and Installation"](#).

NO >> Replace ambient sensor. Refer to [HAC-92, "Removal and Installation"](#) (4WD models) or [HAC-189, "Removal and Installation"](#) (2WD models).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
O  
P

MWI

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

---

### NORMAL OPERATING CONDITION INFORMATION DISPLAY

INFORMATION DISPLAY : Description

INFOID:000000006412971

#### AMBIENT TEMPERATURE

The displayed ambient temperature on the information display may differ from the actual temperature because it is a corrected value calculated from the ambient sensor signal by the combination meter. Refer to [MWI-16, "INFORMATION DISPLAY : System Description"](#) for details on the correction process.

#### DISTANCE TO EMPTY

The calculated distance to empty may differ from the actual distance to empty if the refueling amount is approximately 15 ℓ (4 US gal, 3-1/4 Imp gal) or less. This is because the refuel control (moves the fuel gauge needle quicker than normal judging that the driver is refueling the vehicle) is not performing.

# COMBINATION METER

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### COMBINATION METER


#### Exploded View

INFOID:000000006413665

#### REMOVAL

Refer to [IP-12, "Exploded View"](#).

#### DISASSEMBLY



1. Front cover

2. Unified meter control unit

#### Removal and Installation


INFOID:000000006413666

#### REMOVAL

1. Remove cluster lid A. Refer to [IP-13, "Removal and Installation"](#).
2. Remove the mounting screws of the combination meter.
3. Pull the combination meter straight to disengage resin clips. (The figure shows the clip positions on the back of the combination meter.)

**CAUTION:**

**Never damage the front cover.**



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P


# COMBINATION METER

## < REMOVAL AND INSTALLATION >

4. Turn the lower part of the combination meter in the direction of the arrow to remove the combination meter from the instrument panel assembly.

**CAUTION:**

**Never damage the front cover.**



5. Remove connector to remove the combination meter.

**CAUTION:**

**Never damage the front cover.**

## INSTALLATION

Install in the reverse order of removal.

## Disassembly and Assembly


INFOID:000000006413667

## DISASSEMBLY

1. Disengage the pawls (2 on the sides, 3 on the lower part) of the combination meter.
2. Insert the removal tool into the clearance (in the order of A, B) between the front cover and the meter control unit. Remove 4 pawls on the upper side of the front cover by turning the tool while increasing the clearance.

**CAUTION:**

**Wrap the removal tools with protective tape to prevent scratches.**



3. Pull the front cover straight to remove it from the meter control unit assembly.

**CAUTION:**

**Never damage the front cover.**

**Never touch the pointer and the crystalline liquid.**

## ASSEMBLY

Install the front cover straight to the meter control unit assembly and engage all the pawl.

**CAUTION:**

**Never damage the front cover.**