
LESLIE 147
POWER AMPLIFIER
CONSOLE LOAD
RESISTOR SWITCH
OPEN
8 OHMS
16 OHMS
TO CONSOLE PLUG
SLOW
LOWER
SLOW
UPPER
FAST
LOWER
FAST
UPPER
JUMPER PLUG
TREMOLO RELAY
FAST
SLOW
12AU7A
6550
6550
415 V.
415 V.
115 V.
310 V.
260 V.
10K 1W
470 Ω 1W
10 # 30
30 # 30
420 V.
420 V.
5U4
PLUG-IN
FILTER COND.
4 SECT. 475 V.
RECTIFIER
ASSEMBLY
25 V.
TO
DIVIDING
NETWORK
2 # 16 OHMS
6.3 VAC
FILS.
200
50 V.
150Ω 5W
GREEN
GREEN
RED
RED
SL-O-BLO
1 1/2 AMP
RESISTORS ARE HALF WATT 10%
UNLESS OTHERWISE NOTED
ORANGE
BLUE
.1 600V.
.1 600V.
.1 600V.
.1 600V.
.1 600V.
100 pf
1000 VDC
100 pf
1000 VDC
56K
56K
56K
56K
220 K
18K 5%
820Ω
4.5V
115 V
10K


LESLIE
4300 B KIT
4300-1B
CHASSIS
4300-3 ECHO SWITCH (2 USED)
RED
ECHO
BLACK
WHITE
MAIN
4300-2B
TREMOLO SWITCH
TREMOLO
OFF
SOCKET TREMOLO SWITCH
CHORALE
SOCKET TO
UPPER MANUAL
SPEAKERS
PLUG TO
UPPER MANUAL
AMPLIFIER
YELLOW
PURPLE
BLUE
ECHO SWITCH
SOCKET (UPPER)
TO LESLIE
SPEAKER
100Ω
3 W
220Ω
1/2 W
ECHO SWITCH SOCKET (LOWER)
SOCKET TO
LOWER MANUAL
SPEAKERS
PLUG TO
LOWER MANUAL
AMPLIFIER
GREEN
RED
BLACK
100Ω 3W
PW 3
220Ω
1/2W
5 AMP.
FUSE
A.C.
115C5T
BRAKE TUBE
PLUG
115C5T
SOCKET
PLUG
SOCKET
4300-6 BRAKE
195W3


LESLIE 5B
POWER RELAY
TO CONSOLE
PLUG
RELAY NORMALLY OPEN
117 VAC
CABLES
SOCKET
SOCKET
TO EXTRA CABINET
TO AMPLIFIER