



Parts List for FSD122K-2 Type 4

Item Number	Part Number	Description	Qty Required
2	5101752-00	WASHER	1
3	5101984-00	BEARING WASHER	1
4	311993-00	SCREW	4
5	486562-00	SCREW	1
6	330019-05	SCREW, PLASTITE	1
8	5100117-00	SPRING	1
9	5100115-00	BIT RELEASE RING	1
10	497927-02	RETAINING CLIP	1
11	5100776-00	HUB CAP	1
12	5100799-03	KEYLESS CHUCK	1
13	5100110-01	TOP PLATE	1
14	5100109-01	LEVEL	1
15	5100111-00	ACTUATOR FWR/REV	1
16	5100177-00	SWITCH	1
17	5100108-12	CLAMSHELL SET	1
18	5100184-06	MOTOR & GEARBOX	1
20	5100976-00	TERMINAL BLOCK	1
21	5100796-04	NAMEPLATE	1
22	5100101-03	ACTUATOR	1
23	5100153-00	SHIFTER WIRE	1
24	5100035-03	SPRING	1
846	5100977-00	HARDWARE BAG	1
861	497641-05	LATCH	2
861	5102001-01	KITBOX	1
866	FSB12	BATTERY	2
867	5102026-00	BATTERY CAP	2
871	5101181-01	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.