

Brand	model	chassis
	14MK142	ITC008
	CL2927HE	K55A
	CTV2044	CN12C
	CTV2136	E1 ??? (czy raczej M35-M36 ?)
	CTV3423	5N11
	CTV375-11	CTR-AB
	CTV551S_ve2	11AK10_Stereo
	CTV65051	10.3
	DPM14	E1 ?
	FFS55SVT	11AK19-5
	FL71BKST	14.1 (BEKO)
	GE20091	TX91
	GT8820	K6301
	HPIM2449	E12 Stereo
	JMBC.1499A	CCP3400ST
	JMBNO28WSS	PT92
	PF2591	CN18ED
	RF6685DVPL	C7 ?
	STV70-200ST	(40MN28MFV-K5C)
	TC21P3SE	PX2
	TV3004 Strato	L6B (BEKO)
	TV51MT	BC10E
ADYSON	CTV2144	K3714
ADYSON	CTV5149	K3720
ADYSON	FB3745	K3714
AEG	70169-100	PT100 (100Hz)
AEG	CTV2870	PT92
AEG	CTV3282	PT92 ?
AEG	CTV4802STVT	TV2KP
AEG	CTV4803ST/VT	(40G-STT28C-V5G)
AEG	CTV5521	PT90...
AEG	CTV70169FT N1	PT92-110 PBG-G
AEG	CTV82100	PT100 (100Hz)
AG	21-007SLIM	HL13M ? (HH06XA)
AG	BK1-28	TV4K ? (40H-28CTV5-0AA)

Brand	model	chassis
AG	BK2-20	TV2KM
AIWA	CTV2144	K3714
AIWA	TV-C1400KH	CP005
AIWA	TV-F21TS1B	BX1
AIWA	TV-F21TS1E	BX1
AIWA	TV-F21TS1K	BX1
AIWA	TV-F21TS1U	BX1
AIWA	TV-S2700	G5M-S27000
AIWA	TV-SE1430K	CP385
AIWA	TV-SE1430K	CP385
AIWA	TV-SE2130	CP385
AIWA	TV-SE2130K	CP385
AIWA	TV-SE2130K	CP385
AIWA	TV14MT11K	12.6 (BEKO)
AIWA	VX-D2120K	CP810-1 ?
AIWA	VX-D2150K	CP810-1
AIWA	VX-T1430KER	TM5340 ?
AIWA	VXG145K	(VMA230A)
AKAI	14CT01	SS2
AKAI	2802ST	7S2190
AKAI	CT-B204MTF-E1(S)	12.7
AKAI	CT-G140DT	CA2
AKAI	CT-G2111E	8821
AKAI	CT-G2122E	TV2K
AKAI	CT-G215	CA2
AKAI	CT-H29STAA	CN18EA (albo CN18ED)
AKAI	CT-R14MTUK(S)	TMA504A
AKAI	CT-W2855ENT	FW 16:9
AKAI	CT-W3257	FW 16:9
AKAI	CT-W3257UNT-DPL	FW 16:9
AKAI	CT1407	K9115 ?
AKAI	CT1407D	K9115 ?
AKAI	CT1419	B20
AKAI	CT1420F	S60SC1 (?)
AKAI	CT14WKDT	B20

Brand	model	chassis
AKAI	CT2007	K9115 ?
AKAI	CT2019D	B20
AKAI	CT20WKDT	B20
AKAI	CT2107	K9115
AKAI	CT2115UK	P58SC
AKAI	CT2119D	B20
AKAI	CT2125	P58SC
AKAI	CT2130	11AK03
AKAI	CT2158	E4A
AKAI	CT2159P	B20
AKAI	CT2159U	B20
AKAI	CT2160	E4A
AKAI	CT2161	STEREO PLUS2 (inaczej: SP2)
AKAI	CT2161UNT	STEREO PLUS
AKAI	CT2185	A5A
AKAI	CT2565	STEREO PLUS
AKAI	CT2565UNT	STEREO PLUS
AKAI	CT2567	STEREO PLUS
AKAI	CT2567UNT	STEREO PLUS
AKAI	CT2569	COMPACT D-E 110°
AKAI	CT2570	COMPACT D2
AKAI	CT2570E	COMPACT D2 !
AKAI	CT2570M	DIGITAL B 110°
AKAI	CT2570M2	B-E 110
AKAI	CT2571M	B-E 110
AKAI	CT2579E--5861 87 25	COMPACT D-E 110FST
AKAI	CT2579N	COMPACT D-E
AKAI	CT2585E	EUROSTEREO2
AKAI	CT2590E	B-E2
AKAI	CT2592	B-E2
AKAI	CT2599E	B-E2
AKAI	CT2820	COMPACT D2
AKAI	CT2862CK	K2928
AKAI	CT2865	STEREO PLUS
AKAI	CT2865	STEREO PLUS

Brand	model	chassis
AKAI	CT2865UNT	STEREO PLUS
AKAI	CT2867	STEREO PLUS
AKAI	CT2867	STEREO PLUS (inaczej SP)
AKAI	CT2867UNT	STEREO PLUS
AKAI	CT2867UNT DPL	STEREO PLUS
AKAI	CT2869	COMPACT D-E
AKAI	CT2870E	B110° FST
AKAI	CT2870M2	B-E 110
AKAI	CT2871E	B-E 110
AKAI	CT2872M	B-E 110
AKAI	CT2879N	COMPACT D2
AKAI	CT2879N	COMPACT D2
AKAI	CT2885E	EUROSTEREO2
AKAI	CT2890E	B-E2
AKAI	CT2892E	B-E2
AKAI	CT2895	FX
AKAI	CT2899E	B-E2
AKAI	CTB29CNTFP	20.2 (BEKO)
AKAI	CTB29CNTFPFE3S	20.2 (100Hz) (BEKO)
AKAI	CTLS21NS	3Y11
AKAI	CTS2550	K15C (?)
AKAI	CTW3257	FW16/9
AKAI	SN71Y2	STEREO PLUS2 (inaczej: SP2)
AKAI	SP71S1	STEREO PLUS
AKAI	ST271P1	MONO PLUS2
AKAI	TV1411	PT11
AKAI	TV1411SM	PM11
AKAI	TV1420 EURO	MONO PLUS2
AKAI	TV1420C	MONO PLUS2
AKAI	TV1420T EURO	MONO PLUS2
AKAI	TV1420T UK	MONO PLUS2
AKAI	TV1420UK	MONO PLUS2
AKAI	TV1421	MONO PLUS2
AKAI	TV1421T	MONO PLUS2
AKAI	TV1421T EURO	MONO PLUS2

Brand	model	chassis
AKAI	TV2020 EURO	MONO PLUS2
AKAI	TV2020CK	MONO PLUS2
AKAI	TV2020T UK	MONO PLUS2
AKAI	TV2020UK	MONO PLUS2
AKAI	TV2021	MONO PLUS2
AKAI	TV2021CK	MONO PLUS2
AKAI	TV2021T	MONO PLUS2
AKAI	TV2021T EURO	MONO PLUS2
AKAI	TV2111	PT11
AKAI	TV2111SM	PM11
AKAI	TV2120 EURO	MONO PLUS2
AKAI	TV2120CK	MONO PLUS2
AKAI	TV2120T EURO	MONO PLUS2
AKAI	TV2120T UK	MONO PLUS2
AKAI	TV2121	MONO PLUS2
AKAI	TV2121T	MONO PLUS2
AKAI	TV2121T EURO	MONO PLUS2
AKAI	TV2551	STEREO PLUS2 (inaczej: SP2)
AKAI	TV2817T	PT92 ?
AKAI	TV2817TN3	PT92 ? (99TA052D)
AKAI	TV2819T	PT92
AKAI	TV2835TUK	TV9.7
AKAI	TV2850TN	STEREO PLUS2 (inaczej: SP2)
AKAI	TV2851	STEREO PLUS2 (inaczej: SP2)
AKAI	TV2851TN	STEREO PLUS2 SN/SW
AKAI	TV2851TN UK	STEREO PLUS2 SN/SW
AKAI	TV2852	STEREO PLUS2 (inaczej: SP2)
AKAI	TV2861TN--MX71B6	MX/FX
AKAI	TV2881--STM SW72B2	STEREO PLUS2 (inaczej: SP2)
AKAI	TV2891T Multi 100Hz	MZ
AKAI	TV3291T Multi 100Hz	MZ
AKAI	TV3291T Multi 100Hz 3D/MGA/PiP	MZ
AKAI	TV3451T	STEREO PLUS2 (inaczej: SP2)
AKAI	WSB28CNTF	20.2 (BEKO)
AKAI	WSB28CNTFPFE3	20.2 (100Hz) (BEKO)

Brand	model	chassis
AKAI	WSB28CNTFSFE3S	20.2 (100Hz) (BEKO)
AKIRA		SS1
AKIRA	CT14DX9	SS1
AKIRA	CT14FES1	8803
AKIRA	CT14GT9	CN-ER
AKIRA	CT14HS9	3Y01
AKIRA	CT14JP9	SS1
AKIRA	CT14M9	3Y01
AKIRA	CT14NI9A	3Y01
AKIRA	CT14NK9R	3S10
AKIRA	CT14NX9R	3S10
AKIRA	CT14XJ9	CN9
AKIRA	CT2197MT	PRO21M
AKIRA	CT21DS9A	3Y01
AKIRA	CT21DS9CP	3Y01
AKIRA	CT21DS9CP(IKD)	3Y01
AKIRA	CT21DS9N	3Y01
AKIRA	CT21DS9R	3Y01
AKIRA	CT21FD15B	HD2
AKIRA	CT21NI9R	3S10
AKIRA	CT21TN9A	3S10
AKIRA	CT25DS9	5N11
AKIRA	CT29 NI9	5N11
AKIRA	CT29AZ9	S33
AKIRA	CT29FD9	H707V
AKIRA	GR29D41	H707V (5CB11707V02)
AKURA	ATPTV028WSS	(99TA015G)
AKURA	AV-TA028WSS	PT92
AKURA	AVTA028WSS	PT92
ALBA	14T1	CP370
ALBA	20T1	CP370
ALBA	21NC77	SC102
ALBA	21T1	CP370
ALBA	CTV100-1	TM0096L (ORION)
ALBA	CTV3409	11AK08

Brand	model	chassis
ALBA	CTV3451TXT	TMA504A
ALBA	CTV3459	11AK08
ALBA	CTV3482SIL	12.7 (G70.190-13) (BEKO)
ALBA	CTV4808	11AK19
ALBA	CTV4809	11AK19
ALBA	GTV147	11AK08-9A
ALBA	TVD3400	P1420 (PCB marked 0707-A20261-xx)
ALBA	TVD3400	P1430 (PCB marked 0707-A20296-xx).
ALBA	TVD3450XI	11AK46
ALBONA	TV8-70222/P/BLS	TV8
ALLSTAR	3751	GR1AX
ALTUS	? (28", 4:3/16/9)	14.1 (7SZ.190-19) (BEKO)
ALTUS	28T40SXS	C7-C8 czy? raczej 14.5 (ZX8.190-11)
ALTUS	A2811100	20.2 (100Hz) (BEKO)
ALTUS	AL21M12TXS	12.6 ?
ALTUS	ALM0114B	12.8 (G80.190) (BEKO)
ALTUS	ALM1021XB	12.8 (G80.190) (BEKO)
ALTUS	ALTL228NX	14.1 (BEKO)
AMCOL	2071	11AK19E3
AMCOL	2171	11AK19B1
AMCOL	21CX7T	TV2K
AMSTRAD	14TX SILVER	11AK36
AMSTRAD	CTV1414	K8214
AMSTRAD	CTV3014F	PT11
AMSTRAD	CTV3121F	PT11
AMSTRAD	CTV3128	SM2
AMSTRAD	CTV3128N	SM2
AMSTRAD	TV14M3	VE02
AMSTRAD	TVC10	P1420 ?
ANITECH	GT9313	GT9313
ANITECH	M3730	GR1AX
ANITECH	M3740	GR1AX
ANITECH	M3750	GR1AX
ANITECH	M3751	GR1AX
ANITECH	M3760	GR1AX

Brand	model	chassis
ANITECH	M51/TIDK02	PB2001VS
ANITECH	M51T	PB2001VS
ANITECH	M530	MFP5398
ANITECH	M5510	(60-A053982B)
ANSONIC	14A2P	PT92-5
APEX	14C13	EX1A4
APEX	14C27	EX1A4
APEX	AT1302	CN12C
APEX	AT1308	CN12C
APEX	AT2002	CN12C1
APEX	AT2002S	CN12C1
APEX	AT2008	CN12C1
APEX	AT2402	CH10C1
APEX	AT2402S	CH10C1S
APEX	AT2702	CH10C
APEX	AT3208S	CH10C3
APEX	GT2015	CN12C2
APEX	GT2415	CH10C2
APEX	GT2715	CH10C2
APEX	GT3215	CH10C2
ARCELIK	TV2470	20.2 (100Hz) (BEKO)
ARCELIK	TV2472	20.2 (100Hz) (BEKO)
ARCELIK	TV2482	20.2 (100Hz) (BEKO)
ARENA	70-100	TV17 (100Hz)
ARENA	CT70-100TV17.1-70241/P	TV17.1 (100Hz)
ARENA	CT7050	TV9 ?
ARENA	CTV70100	TV17.1 (100Hz)
ARISTONA	37TA1171	MD1.1E AA
ARISTONA	51 TR427	TVCR B
ARISTONA	52 NA2317	GR2.2
ARISTONA	52KV2523	G90AE
ARISTONA	52KV9537	G90B
ARISTONA	59KE3705	CP110
ARISTONA	63TA4415	L9.1E AA
ARISTONA	63TA4416	L01.1E AA

Brand	model	chassis
ARISTONA	63TA4416	L01.1E AA
ARISTONA	63TA7111	GR2.4
ARISTONA	70KD2723	D16
ARISTONA	70TA7216	EM2E
ARTECLINE	EC70602 CTI	SCC103 (ELBIT)
ARTECLINE	EC70606SAT	SCC103 (ELBIT)
ARTECLINE	EC70607	SCC103 (ELBIT)
ASBERG	4028 TEXT	3016
ASORA	FA2170	C41
ASORA	FA2170	C41M
ASTRA	AS2118	CN18EA
Audio Sonic	KT8871	11.1 ?
AUDIOSONIC	DTV2049ST	C520
AUDIOSONIC	KRB1570	K3910
AUDIOSONIC	KT8250	C41
AUDIOSONIC	KT8254	K3922
AUDIOSONIC	KT8351	K3922
Audiosonic	KT8771	10.3 (58G190-22)
AUDIOSONIC	KT9142MTX	128
AUDIOSONIC	KT9771MN	20.2 (BEKO)
AUDIOSONIC	KT9771MNSTX	20.2 (100Hz) (BEKO)
AUDIOSONIC	KT9785MN	20.2 (BEKO)
AUDIOSONIC	KT9785MNSTX	20.2 (100Hz) (BEKO)
AUDIOTON	T3602RM	C41
AUDIOTON	T5103RM	C41
AUDIOTON	T5104RM	C41
Autovox	AX14Q06	11AK30
AVEST	TC2101	GT21L2
AXXENT	7289	11AK16
AXXION	AX6020T	K9320
AXXION	AX6025	K9515
AXXION	AX6121T	K9115CT
AXXION	RC4221PST	RC4121A
AXXION	RC4421PST	RC4121A
B&O	3116	MX2000

Brand	model	chassis
B&O	3207	MONOPRINT A
B&O	3332A	8800
B&O	3701	S0202-832R
B&O	3714	PT92
B&O	3721	MONO PLUS2
B&O	3725	COMPACT 80R
B&O	3745	11AK20SE
B&O	3758	COMPACT 80R
B&O	3760	COMPACT D2
B&O	4000	M1
BAIRD	RR5190	E4A
Basic Line	3315NT	11AK19B1
Basic Line	BL2100NTD	11AK30-1
BASIC LINE	MEGSTM14	PT90J (03TA018G)
BEKO		10.2 (50S.190D...) (BEKO)
BEKO		10.3 (63Y.190...) (BEKO)
BEKO		10.4 (5FT00000--5FT110) (BEKO)
BEKO		10.4 (5FT110) (BEKO)
BEKO		10.4 (67D.190...) (BEKO)
BEKO		11.1 (5LZ.190...) (BEKO)
BEKO		11.2 (6SZ.190...) (BEKO)
BEKO		12.1 (6BZ.190...) (BEKO)
BEKO		12.3 (7LY.190-...) (BEKO)
BEKO		12.4/12.5 (A99.190...) (BEKO)
BEKO		12.6 (G99.190-...) (BEKO)
BEKO		12.7 (C71.190-02) (BEKO)
BEKO		12.7 (G70.190-...)
BEKO		12.8 (BEKO)
BEKO		12.8 (G80.190...)
BEKO		14.1 (7SZ.190-12)
BEKO		14.1 (7SZ.190...)
BEKO		14.2 (S99.190-08)
BEKO		14.2 (U99.190-07)
BEKO		14.2 (U99.190...)
BEKO		14.5? (ZX8.190-09)

Brand	model	chassis
BEKO		20.2 (100Hz) (UZ.190-07)
BEKO		22.1 (BEKO)
BEKO		22.2 (100Hz)
BEKO		C7-C8
BEKO		C7-C8 (ZX8.820)
BEKO	? (pł.gł 190-97)	20.2 (190-07) (100Hz)
BEKO	10214	AT2 (AT02)
BEKO	10502TCM	20.2 (100Hz) (BEKO)
BEKO	11225T	10.2 (BEKO)
BEKO	11225T	AT2 (AT02)
BEKO	12220T	AT2 (AT02)
BEKO	14213T	12.1 (BEKO)
BEKO	14242T	12.4
BEKO	14B7M03TXC	12.5 (BEKO)
BEKO	14EK3	12.7
BEKO	15225T	10.2 (BEKO)
BEKO	15225T	AT2 (AT02)
BEKO	16228T	10.2 (BEKO)
BEKO	16228T/NX	AT2 (AT02)
BEKO	16328	AT3
BEKO	17325	AT3 (10.3) ?
BEKO	1922 inx	AT2 (AT02)
BEKO	20B6M14	12.4
BEKO	20B7T01TXS	12.4 ?
BEKO	20C1T58TX	12.7 (?)
BEKO	20VC1	12.7
BEKO	210672	12.3 (7LY.190-04)
BEKO	210672	12.3 ?
BEKO	21B7T02	12.5 (BEKO)
BEKO	21B9T44S	12.6 (?)
BEKO	21B9T44TXS	12.6 (BEKO)
BEKO	21C1T44T	12.6 (G99.190-14)
BEKO	21GS7	12.7
BEKO	26414R	10.4
BEKO	26PLD500	L5A (?)

Brand	model	chassis
BEKO	27420	10.4
BEKO	2812 NX	11.1 (110°)
BEKO	28128NX	11.1 (BEKO)
BEKO	28328SX	10.3 ((TXT Pal 9/T 10.3 28" 83U110))
BEKO	28416ND	14.1 (BEKO)
BEKO	284216WNS	14.2 (BEKO)
BEKO	28426NDS	14.2 (BEKO)
BEKO	28B4T05	14.1 (?)
BEKO	28BCT05NTX	20.2 (100Hz) (BEKO)
BEKO	28BCT05NX	20.2 (BEKO)
BEKO	28BCT07NSX	20.2 (100Hz) (BEKO)
BEKO	28BCT22 NTX	20.2 (BEKO)
BEKO	28BCT22 NX	20.2 (100Hz) (BEKO)
BEKO	28BCT28NTX	20.2 (100Hz) (BEKO)
BEKO	28BCT28NX	20.2 (100Hz) (BEKO)
BEKO	28BCT28SXS	20.2 (100Hz) (BEKO)
BEKO	28BCTL2SX	20.2 (BEKO)
BEKO	28BCTL2SXS	20.2 (100Hz) (BEKO)
BEKO	28BCTL2SXS 100Hz	20.2 (100Hz) (BEKO)
BEKO	28C723IDW	C7
BEKO	28CZ10RX	14.2 (BEKO)
BEKO	28P1TL3NX	11.1 (BEKO)
BEKO	29BCT12 NTX	20.2 (BEKO)
BEKO	29BCT12 NXS	20.2 (100Hz) (BEKO)
BEKO	29BCT12S	20.2 (100Hz) (BEKO)
BEKO	29BCT12STP	20.2 (100Hz) (BEKO)
BEKO	29BCT17NTX	20.2 (100Hz) (BEKO)
BEKO	29BCT17NXS	20.2 (100Hz) (BEKO)
BEKO	29BCT23NXS	20.2 (100Hz) (BEKO)
BEKO	29BCT23ST	20.2 (100Hz) (BEKO)
BEKO	29BCT24NTX	20.2 (100Hz) (BEKO)
BEKO	29BCT25	20.2 (100Hz) (BEKO)
BEKO	29BCT25NSX	20.2 (100Hz) (BEKO)
BEKO	29BCT25NTX	20.2 (BEKO)
BEKO	29BZT17SXS	22.1 (?)

Brand	model	chassis
BEKO	29PFT12	20.2 (BEKO)
BEKO	32426NDS	14.2 (BEKO)
BEKO	32BCT10NTX	20.2 (100Hz) (BEKO)
BEKO	32BCT20NTX	20.2 (BEKO)
BEKO	32BCT20NXS	20.2 (100Hz) (BEKO)
BEKO	32BCT20STP	20.2 (100Hz) (BEKO)
BEKO	32BCT21	20.2 (100Hz) (BEKO)
BEKO	32BCT21NTX	20.2 (100Hz) (BEKO)
BEKO	32BCT35NX	20.2 (100Hz) (BEKO)
BEKO	32BCT42	20.2 (100Hz) (BEKO)
BEKO	32CZ10RX	14.2 (BEKO)
BEKO	33BCTL5NSX	20.2 (100Hz) (BEKO)
BEKO	33BCTL5NTX	20.2 (100Hz) (BEKO)
BEKO	33BCTL5NX	20.2 (100Hz) (BEKO)
BEKO	5025	16.1 (ZA4.190-1x)
BEKO	5025S	16.1 (ZA4.190-09)
BEKO	7SZ 190-09	14.1 (7SZ.190-09)
BEKO	CTV889	Satcom system
BEKO	E21T2XB	11.1? (6WL110)
BEKO	KK21M11TXS	12.6 (BEKO)
BEKO	KK21T44	12.6 (?)
BEKO	LW7190R2	L6E-PE
BEKO	N33TL5NTX	14.1 (BEKO)
BEKO	NR 28B4T07	14.1 (7SZ-190-17)
BEKO	NR P0625	14.1 (7SZ.190-12)
BEKO	NR PM1121X	12.1 (6BZ190-26)
BEKO	NR PM1121XB	12.6 ?
BEKO	NR PM1121XBS	12.6 (BEKO)
BEKO	NR14272R	12.7 ?
BEKO	NR14B9T46S	12.6 (BEKO)
BEKO	NR20B3M07	12.1 (BEKO)
BEKO	NR20B6T01	12.4
BEKO	NR21B6T02	12.4
BEKO	NR21C2TG1	12.8 (BEKO)
BEKO	NR21T44TXS	E1 (Z50.190-05)

Brand	model	chassis
BEKO	NR22421	10.4 ?
BEKO	NR22421T	10.4 (?)
BEKO	NR26114RDG	11.1 ?
BEKO	NR26414R	10.4
BEKO	NR28328SX	10.3
BEKO	NR28411ND	14.1 ?
BEKO	NR29BCT23	20.2 (100Hz) (BEKO)
BEKO	NR33BCTL5NSX	20.2 (BEKO)
BEKO	NR36233PD	11.2
BEKO	NR7KQ	11AK20M
BEKO	OK2937PSX1P	22.1 (ZA1.190-14)
BEKO	P0528NX	14.1 (BEKO)
BEKO	P0528NXS	14.1 ? (14.2?)
BEKO	P0625	14.1 (BEKO)
BEKO	P0625NX	14.1 (7SZ.190-16)
BEKO	PM0314XBS	12.6 ! (G99.190-07) (BEKO)
BEKO	PM1121XB	12.1 (BEKO)
BEKO	PM1121XB	12.8 (BEKO)
BEKO	PM1121XBS	12.5 ? (raczej 12.8) (G80.190...)
BEKO	PO625NX	14.1 (BEKO)
BEKO	PT1628NX	14.1 (BEKO)
BEKO	PT3421NX	12.3 (BEKO)
BEKO	PT3421NXS	12.3
BEKO	PVB5180	(6UZ.190-02) (BEKO)
BEKO	RF6682 (późniejszy model)	14.2 (BEKO)
BEKO	RF6682 (wcześniejszy model)	14.1 (BEKO)
BEKO	RF6683 (2003-2004r.)	11AK37
BEKO	RF6683 (2005r.)	11AK49
BEKO	RF6683VPL	11AK45
BEKO	RF6683VPL (2005)	11AK49
BEKO	RF6684 (2003-2004r.)	11AK37
BEKO	RF6684 (2005r.)	11AK45
BEKO	RF6685VPLSIL/C7	C7 (BEKO)
BEKO	RF6686 (2005r.)	11AK49
BEKO	RF6694 (2003r.)	11AK45

Brand	model	chassis
BEKO	SPACE MASTER	SASI11
BEKO	T570SX	20.2 (100Hz) (BEKO)
BEKO	T670VDNX	20.2 (100Hz) (BEKO)
BEKO	T684VDNX	20.2 (100Hz) (BEKO)
BEKO	T82	14.2 (BEKO)
BEKO	TCM10502	20.2 (BEKO)
BEKO	TG1 21NX	14.1 (BEKO)
BEKO	TV79R	10.3 ?
BEKO	TV79R0000003	10.3 (58G190-04)
BEKO	TVB10280S	22.1 (ZA1.190-07) (BEKO)
BEKO	TVB10540	14.2 (S99.190-07) (BEKO)
BEKO	TVB10772S	14.2 (S99.190-02)
BEKO	TVB1135S	E1
BEKO	TVB1332	10.2 (?)
BEKO	TVB2031	11.1 (BEKO)
BEKO	TVB2830	11.1 (BEKO)
BEKO	TVB3090 DOLBY	11.2 (6SZ.190-V7)
BEKO	TVB3130	11.1 (BEKO)
BEKO	TVB3201	11.1 (BEKO)
BEKO	TVB5180	20.1 (6UZ190-02 6UZ110) (100Hz)
BEKO	TVB5230	14.1 ! (7SZ.190-05)
BEKO	TVB5635	14.1 (7SZ.190-...)
BEKO	TVB9982S	20.2 (100Hz) (BEKO)
BEKO	TVC32BCT21PF	20.2 (100Hz) (BEKO)
BEKO	V30	14.2 (BEKO)
BEKO	WS6680SIL	14.2 (U99.190-07) (100Hz)
BEKO	WS6680SIL	14.5 (ZX8.190-13)
BEKO	YUGO 57Y (Satcom)	(Satcom)
BELSTAR	1465TM	11AK20SE2
BELSTAR	1465TM	E7
BELSTAR	1466TM	11AK36-2
BELSTAR	20A11T	11AK30-2
BELSTAR	2155	BC10E
BELSTAR	2196	E9
BELSTAR	2197	E9

Brand	model	chassis
BELSTAR	2197ST	E9
BELSTAR	2197T	E9A ?
BELSTAR	2197TSN	E9A
BELSTAR	2596	E9
BELSTAR	2597	E9
BELSTAR	2597TSN	E9A
BELSTAR	2896	E9
BELSTAR	2896TSN	E9 ? (BEL1679E/99)
BELSTAR	2897	E9
BELSTAR	2897TSN	E9A
BELSTAR	2897TSNP	E9A
BELSTAR	28A50	11AK37-11
BELSTAR	3497TSM	E9A
BEON	CTV2003	11AK19
BESTAR	5970	MN220
BESTAR	TV6000VT	F10 (Formenti)
BESTAR	TV7080VT	F8.01
BESTAR	TV8390	F9-01
BESTAR	TV8390	F9-01
BLACK DIAMOND	BDS1451LM	11AK36A6
Black Diamond	BDS2851WS	11AK19PRO (11AK19PS)
BLAUPUNKT	AS55-40VTM	FM500.30
BLAUPUNKT	AS5540VTM	FM500.30
BLAUPUNKT	BARBADOS SP45	FM100-30
BLAUPUNKT	BP37-06	FM251.00
BLAUPUNKT	BP70VT	FM310.32
BLAUPUNKT	BT63-25VTM	FM550.30
BLAUPUNKT	BT63-26VTM	FM550.20
BLAUPUNKT	BT63-27VTM	FM550.20
BLAUPUNKT	BT63-27VTM	FM550.20
BLAUPUNKT	BT6326VTM	FM550.20
BLAUPUNKT	BT6327VTM	FM550.20
BLAUPUNKT	BT70-125DIGITAL	FM651.40
Blaupunkt	BT70-125Digital Pro	FM651.40 ?
BLAUPUNKT	BT70-26VT	FM550.20

Brand	model	chassis
BLAUPUNKT	BT70-26VT	FM550.20
BLAUPUNKT	BT70125DIGITAL	FM651.40
BLAUPUNKT	BT7026VT	FM550.20
BLAUPUNKT	CASABLANKA SP45	FM100-30
BLAUPUNKT	COLUMBIA	FM100-30
BLAUPUNKT	CS70-103VT	FM529.70 ?
BLAUPUNKT	CS70-126DIGITAL	FM659.40
BLAUPUNKT	CS70-126DIGITAL	FM659.40
BLAUPUNKT	CS70-155DIGITAL PRO	FM659.40
BLAUPUNKT	CS70-156	FM659.40
BLAUPUNKT	CS82-100DIGITAL	FM600.71
BLAUPUNKT	CS82-108C	FM100-45
BLAUPUNKT	CS82-108VT	FM100-44
BLAUPUNKT	CS82-115DIGITAL	FM642.90
BLAUPUNKT	CS82-166DIGITAL	FM642.90
BLAUPUNKT	CS82-70VTM	FM500.50
BLAUPUNKT	CS82-78CVT	FM100-43
BLAUPUNKT	CS92-116	FM659.97
BLAUPUNKT	CTV6364 SP45	FM100-30
BLAUPUNKT	FC872	FM100-30
BLAUPUNKT	FC882	FM100-30
BLAUPUNKT	FC912	FM100-30
BLAUPUNKT	FC922	FM100-30
BLAUPUNKT	FC933	FM100-30
BLAUPUNKT	FS781	FM100-30
BLAUPUNKT	FS874	FM100-30
BLAUPUNKT	FS898	FM100-30
BLAUPUNKT	FS916	FM100-30
BLAUPUNKT	FS917	FM100-30
BLAUPUNKT	FS921	FM100-30
BLAUPUNKT	FS922	FM100-30
BLAUPUNKT	FS924	FM100-30
BLAUPUNKT	FS931	FM100-30
BLAUPUNKT	FS932	FM100-30
BLAUPUNKT	FS934	FM100-30

Brand	model	chassis
BLAUPUNKT	FV932	FM100-30
BLAUPUNKT	FV936	FM100-30
BLAUPUNKT	IM55-16	FM100-30S
BLAUPUNKT	IM63-16	FM100-30S
BLAUPUNKT	IM63-18	FM100-41
BLAUPUNKT	IM70-18	FM100-41
BLAUPUNKT	IS37-17DIGITAL	FM640.40
BLAUPUNKT	IS55-25VTM	FM451.20
BLAUPUNKT	IS55-28	FM100-42
BLAUPUNKT	IS55-31VT	FM311.22
BLAUPUNKT	IS55-46	FM100-30S
BLAUPUNKT	IS63-28VT	FM100-42
BLAUPUNKT	IS63-31VT	FM310.32
BLAUPUNKT	IS63-35VTM	FM550.30
BLAUPUNKT	IS63-39VT/NICAM	FM500.30
BLAUPUNKT	IS63-40VT/NICAM	FM502.30
BLAUPUNKT	IS63-41TT/NICAM	FM502.30
BLAUPUNKT	IS63-46	FM100-30S
BLAUPUNKT	IS63-49VT	FM500.30
BLAUPUNKT	IS63-49VT--7 669 530	FM500.30 !
BLAUPUNKT	IS63-51VT	FM312.32
BLAUPUNKT	IS63-53DIGITAL	FM640.40
BLAUPUNKT	IS63-55VTM	FM550.70
BLAUPUNKT	IS63-76	FM100-30S
BLAUPUNKT	IS63-78VT	FM100-40
BLAUPUNKT	IS6353 Digital	FM640-40
BLAUPUNKT	IS70-109VTM	FM500.60
BLAUPUNKT	IS70-132DIGITAL	FM651.40
BLAUPUNKT	IS70-135DIGITAL	FM651.40
BLAUPUNKT	IS70-28VT	FM100-42
BLAUPUNKT	IS70-31VT	FM310.32
BLAUPUNKT	IS70-35VTM	FM550.30
BLAUPUNKT	IS70-39VT	FM500.40
BLAUPUNKT	IS70-39VT/NICAM	FM502.40
BLAUPUNKT	IS70-40TT/NICAM	FM500.30

Brand	model	chassis
BLAUPUNKT	IS70-41 TT PIP	FM502.30
BLAUPUNKT	IS70-41TT/NICAM	FM502.30
BLAUPUNKT	IS70-43VT	FM310.32
BLAUPUNKT	IS70-45VT	FM550.40
BLAUPUNKT	IS70-46VT	FM550.40
BLAUPUNKT	IS70-47	FM100-40
BLAUPUNKT	IS70-49VT	FM502.30
BLAUPUNKT	IS70-51VTM	FM412.40
BLAUPUNKT	IS70-53DIGITAL	FM600.80
BLAUPUNKT	IS70-70DIGITAL PRO_Chassis F	FM600.50
BLAUPUNKT	IS70-76	FM100-30S
BLAUPUNKT	IS70-77VT	FM100-30S
BLAUPUNKT	IS70-78VT	FM100-40
BLAUPUNKT	IS72-155DIGITAL	FM640.40
BLAUPUNKT	IS72-176DIGITAL	FM640.40
BLAUPUNKT	IS72-53VTN	FM540.40
BLAUPUNKT	IS72-55VTM	FM550.70
BLAUPUNKT	KORSIKA SP55	FM100-30
BLAUPUNKT	MADAGASKAR	FM100-30
BLAUPUNKT	MANTUA SP55	FM100-30
BLAUPUNKT	MB70-26VT	FM550.20
BLAUPUNKT	MC63-40VT	FM502.30
BLAUPUNKT	MC70-40VT	FM502.30
BLAUPUNKT	MM63-13VT	FM240.00
BLAUPUNKT	MM63-14HT	FM240.00
BLAUPUNKT	MP45	FM100-30
BLAUPUNKT	MS55-76	FM100-30S
BLAUPUNKT	MS63-109VTM	FM500.60
BLAUPUNKT	MS63-109VTM	FM500.60
BLAUPUNKT	MS63-76	FM100-30
BLAUPUNKT	MS63-78	FM100-40
BLAUPUNKT	MS63-79	FM500.60
BLAUPUNKT	MS70-100DIGITAL	FM600.70
BLAUPUNKT	MS70-109VTH	FM500.60 (?)
BLAUPUNKT	MS70-109VTM	FM500.70

Brand	model	chassis
BLAUPUNKT	MS70-76VT	FM100-30S
BLAUPUNKT	MS70-78VT	FM100-40
BLAUPUNKT	MS70-79VT	FM500.70
BLAUPUNKT	MV70-78VT	FM100-30S
BLAUPUNKT	MV7078VT	FM100-30S
BLAUPUNKT	MX72-166DIGITAL	FM640.90
BLAUPUNKT	MX72-83DIGITAL	FM640.90
BLAUPUNKT	MX72-83DSP	CUC7861
BLAUPUNKT	PM36-05F	APOLLO
BLAUPUNKT	PM37-15VT	FM251.40
BLAUPUNKT	PM37-41	FM211.02
BLAUPUNKT	PM37-42	FM221.02
BLAUPUNKT	PM37-43OIRT	FM241.00
BLAUPUNKT	PM37-47	FM100-22
BLAUPUNKT	PM37-49	FM201.00
BLAUPUNKT	PM40-41	FM311.02
BLAUPUNKT	PM40-42	FM221.02
BLAUPUNKT	PM40-46	FM100-22
BLAUPUNKT	PM40-46	FM100-30S
BLAUPUNKT	PM40-48	FM100-22
BLAUPUNKT	PM40-49VT	FM311.02
BLAUPUNKT	PM42-47	FM100-22
BLAUPUNKT	PM42-47	FM100-30S
BLAUPUNKT	PM42-48	FM100-22
BLAUPUNKT	PM42-49	FM201.00
BLAUPUNKT	PM4249	FM201.00
BLAUPUNKT	PM45-15VT	FM251.40.
BLAUPUNKT	PM45-41VT	FM311.02
BLAUPUNKT	PM45-47	FM100-22
BLAUPUNKT	PM45-48	FM100-22
BLAUPUNKT	PM51-40VT`	FM311.02
BLAUPUNKT	PM55-15VT	FM251.40
BLAUPUNKT	PM55-15VT	FM351.40
BLAUPUNKT	PM55-40VT	FM201.00
BLAUPUNKT	PM55-41O	FM201.00

Brand	model	chassis
BLAUPUNKT	PM55-43	FM241.00
BLAUPUNKT	PM55-48	FM100-22
BLAUPUNKT	PS45-29VT	FM310.32
BLAUPUNKT	PS55-21VT	FM311.22
BLAUPUNKT	PS55-23VT	FM310.32
BLAUPUNKT	PS55-25VTM	FM451.20
BLAUPUNKT	PS55-28	FM100-42
BLAUPUNKT	PT37-46	FM100-30S
BLAUPUNKT	RIVERA	FM100-30
BLAUPUNKT	TOLEDO SP45	FM100-30
BLAUPUNKT	VALENCIA SP45	FM100-30
BLAUPUNKT	VALENCIA SP46	FM100-30
BLUE TECH	CT2118	PX20045
BLUESKY	28EGOEP	TV4KS (?)
BLUESKY	BF2103BE	12.7 (C71.190-02) (BEKO)
BLUESKY	BF7203B	11AK45B5 (16:9)
BLUESKY	BK14STX	11AK36-2
BLUESKY	BK36GR	12.7 (G70.190-10) (BEKO)
BLUESKY	BK51S	11AK30A11
BLUESKY	BK55PL	12.8 (BEKO)
BLUESKY	BS14TE	CTE-AA
BLUESKY	BST2104--21033	PT90
BLUESKY	BV2006	11AK30 !
BLUESKY	BX55S	11AK19
BLUESKY	CB3697	CP340
BLUESKY	CB381S	(WMB290A)
BLUESKY	CD855T	PT92DVD
BLUESKY	T51	PT90
BLUESKY	T51 FTN8PT90BSL	PT90 ?
BLUESKY	TD5598	11AK19-5
Bluesky	TK7000	14.1 (BEKO)
BLUESKY	TK7000ES	14.2 ? (14.1 ?) (BEKO)
BLUESKY	TK7000PL	14.2 (BEKO)
BLUESKY	TM20TXT	PT90(P) ?
BONDSTEC	BT2001	P2

Brand	model	chassis
BONDSTEC	BT2101	C40
BRANDT	16402T	ICC4
BRANDT	16452T	ICC4
BRANDT	18452T	ICC4
BRANDT	20454T	ICC4
BRANDT	22465T	ICC4
BRANDT	36100M	TX807
BRANDT	36200M	TX807
BRANDT	36289B	IKC2
BRANDT	36291T	IKC2
BRANDT	42232T	IKC2
BRANDT	44231	IKC2
BRANDT	46413T	ICC4
BRANDT	51203T	IKC2
BRANDT	52246T	ICC7
BRANDT	55100	TX807
BRANDT	55280P	IKC2
BRANDT	55281S	IKC2
BRANDT	55580PL	ICC5
BRANDT	5570MC	TX91
BRANDT	55766ST	ICC7
BRANDT	63258T	IKC2
BRANDT	63281S	IKC2
BRANDT	63730T	ICC7
BRANDT	63753T	ICC7
BRANDT	63892ST	ICC7
BRANDT	63PL860	ICC5
BRANDT	66381ST	ICC7
BRANDT	70210S2	ICC17V30
BRANDT	70759T	ICC7301
BRANDT	70765ST	ICC7
BRANDT	70772T	ICC7
BRANDT	70W212S2	ICC17V30
BRANDT	C36100C/F	EUROCOMBO2
BRANDT	C51100	EUROCOMBO2

Brand	model	chassis
BRANDT	F14VB12A	EUROCOMBO
BRANDT	S14VB12A	EUROCOMBO
BRANDT	S14VB22A	EUROCOMBO
BRANDT	S20VB12A	EUROCOMBO
BRANDT	S20VB22A	EUROCOMBO
BRANDT	T14VB12B	EUROCOMBO
BRANDT	T14VB12C	EUROCOMBO
BRANDT	T14VB22A	EUROCOMBO
BRANDT	VCA40F	IKC2
Brandt Thomson	10-801T	B3-B10
BRATZ	309321	(40-TD21S9-MAE1)
BRINKMANN	ST7097 TEXT	11AK18 (100Hz)
BROTHER	BR7821	(GUW7.820)
BROTHER	CBT2871E	PC12A
BUSH		11AK36
BUSH	1433	11AK20
BUSH	1470T	EC3A
BUSH	1473T	11AK08 ?
BUSH	1488TSILXI/E1	E1 (BEKO)
BUSH	1497ITV/3	11AK20S-M29
BUSH	14T1	CP370
BUSH	2038TSIL	12.7 (G70.190-10)
BUSH	20T1	CP370
BUSH	2163NTX	11AK10
BUSH	2178NTX SLI	16.1 (ZA4.190-09)
BUSH	21T1	CP370
BUSH	2550NTX	TV4
BUSH	2550NTX-A	TV8
BUSH	2571NTX	11AK19E3
BUSH	2850NTX	TV4
BUSH	2850NTX-A	TV8
BUSH	2863NTX	11AK12
BUSH	2866NTX	SM2
BUSH	2871	11AK19-3
BUSH	2871NTX	11AK19-3

Brand	model	chassis
BUSH	2874NTX	11AK19
BUSH	2874NTXSIL	11AK19 PRO
BUSH	2876NTX	PT92
BUSH	28ZKA WS6667	4400 PROFESSIONAL (PCB: 4410)
BUSH	3463NTX	4400 PROFESSIONAL (PCB: 4410)
BUSH	3472 NTX	4400 PROFESSIONAL (PCB: 4410)
BUSH	6693D	11AK45B5
BUSH	BTV17SIL/OVD7	(VMA230A)
BUSH	BTV18SIL VA	(VMB290A_C3)
BUSH	CTV3409	11AK08
BUSH	CTV3459	11AK08
BUSH	DVD142RC	11AK46
BUSH	DVD142TV	11AK46
BUSH	DVD660TVSIL/A	PT92DVD
BUSH	GTV147	11AK08-9A
BUSH	ITV8401	11AK20S
BUSH	RF2185NTXSIL	16.1 (ZA4.190-12) (BEKO)
BUSH	RF6682VPL	14.2 (U99.190-07)
BUSH	WS6667	4400 PROFESSIONAL (PCB: 4410)
BUSH	WS6671SIL	11AK19...
BUSH	WS6673SIL	11AK19P5
BUSH	WS6674	PT92
BUSH	WS7667	4400 PROFESSIONAL (PCB: 4410)
BUSH	WS767	11AK19
BUSH	WS7680	14.2 (BEKO)
BUSH	WST66	4400 PROFESSIONAL (PCB: 4410)
CASIO	EV510C	KX619B
CASIO	TV1400	KX336HA ?
CFK BRAND	TC374	(M9119A)
CHANGHONG	PF21300	CH13B
CHANGHONG	PF21E19	CN18EA
CHANGHONG	PF2939	CH(S) ?
CHANGHONG	SF2128K	CH13A
CHANGHONG	SF2129K	CH13A
CHANGHONG	SF2133K	CH13A

Brand	model	chassis
CHANGHONG	SF2166K	CH13A
CHANGHONG	ST29F55N	CN18ED
CHANGHONG	Telestar R0110NP	PE5
Chiny		CH007--9306-2002
Chiny		E5E
Chiny		E5F1
Chiny		E5G
Chiny		E5H1B
Chiny		E5H1C
Chiny		E5HB
Chiny		E5HC
Chiny		E5P1B
Chiny		E5P1C
Chiny		E5PB
Chiny		E5PC
Chiny		E5S1
CHINY		TV4KS (40MN28Q10)
Chiny	B276E5MAA	TDA12017H
Chiny	CT14XA9R	CN9EA
Chiny	FPE3705	LC37K7
CIE	FT55X	C500
CINEX	37511	PT90J
CINEX	37911	PT90
CINEX	51811	PT90 ?
CINEX	55720	PT90 ?
CINEX	HTS75691	PT92
Cinex	TFT82921	CTV100 (04TA065A) - Profilo-Telra
CINEX	TV37-911	PT92 (?)
CINEX	TV37511	PT90JEP
CINEX	TV37701	PT92J
CINEX	TV37911	PT90
CINEX	TV50511	PT90J
CINEX	TV50701T	PT92PB
CINEX	TV51711T	PT92
CINEX	TV51820A	PT90A-90

Brand	model	chassis
CINEX	TV55711	(TC16783A)
CINEX	TV70521	PT90
CINEX	TV70821	PT92-110
CINEX	TV70851	PT100 (100Hz)
CINEX	TV71651	PT100 (100Hz)
CLATRONIC	CTC2000VT	960
CLATRONIC	CTV115	K3714
CLATRONIC	CTV188	K3921
CLATRONIC	CTV204	K3922
CLATRONIC	CTV204/224DK	K3922WF
CLATRONIC	CTV207PS	K6913
CLATRONIC	CTV224	K3921
CLATRONIC	CTV225MST	K3922
CLATRONIC	CTV230	K9115
CLATRONIC	CTV246VT	K9321
CLATRONIC	CTV284VT	F10 (Formenti)
CLATRONIC	CTV285VT	F10 (Formenti)
CLATRONIC	CTV286VT	F10 (Formenti)
CLATRONIC	CTV2870	PT92
CLATRONIC	CTV287F	F16 (Formenti)
CLATRONIC	CTV287VT	F11 (Formenti)
CLATRONIC	CTV289VT/PIP	F11 (Formenti)
CLATRONIC	CTV290VT/PIP	F11 (Formenti)
CLATRONIC	CTV292	PL2
CLATRONIC	CTV305	PL2
CLATRONIC	CTV306	PL2
CLATRONIC	CTV312	PL2
CLATRONIC	CTV316VT	F10 (FORMENTI)
CLATRONIC	CTV317V	F11 (FORMENTI)
CLATRONIC	CTV322VT	F10
CLATRONIC	CTV323	F11
CLATRONIC	CTV324	F11
CLATRONIC	CTV325	F11
CLATRONIC	CTV343	P943
CLATRONIC	CTV345VT	F10 (?)

Brand	model	chassis
CLATRONIC	CTV349VT	F11
CLATRONIC	CTV350VT	F10 ?
CLATRONIC	CTV399	P943
CLATRONIC	CTV426VT-N	PT11 (?) (97TA012L)
CLATRONIC	CTV426VT-PN	PT92
CLATRONIC	CTV426VTN	PT92
CLATRONIC	CTV430ST/VT P	PT92
CLATRONIC	CTV431	SM2
CLATRONIC	CTV433	SM2
CLATRONIC	CTV443	PT92 (99TA052C)
CLATRONIC	CTV443ST	SM2
CLATRONIC	CTV49VT	F11
CLATRONIC	CTV517VT	12.8 (BEKO)
CLATRONIC	CTV519	12.3 ? (7LY.190-04)
CLATRONIC	CTV520ST/VT	14.2 ! (S99.190-08)
CLATRONIC	CTV521STVT	20.2 (100Hz) (BEKO)
CLATRONIC	CTV523ST/VT	20.2 (100Hz) (BEKO)
CLATRONIC	CTV523STVT	20.2 (100Hz) (BEKO)
CLATRONIC	CTV524ST/VT	20.2 (100Hz) (BEKO)
CLATRONIC	CTV524STVT	20.2 (100Hz) (BEKO)
CLATRONIC	CTV555ST	12.3?
CLATRONIC	CTV576	TV2K-TXT
CLATRONIC	CTV577	TV2K-TXT
CLATRONIC	CTV577VT	TV2K-TXT
CLATRONIC	CTV578	TV2K-TXT
CLATRONIC	CTV579ST	TV2K (?)
CLATRONIC	CTV579ST/VT	TV2K
CLATRONIC	CTV580	TV4KS
CLATRONIC	CTV6000	F10 ?
CLATRONIC	CTV6390	F8
CLATRONIC	CTV7090	F8
CLATRONIC	CTV7600	F8
CLATRONIC	CTV8000	F8
CLATRONIC	CTV8500	F8
CLATRONIC	CTV9000	F8

Brand	model	chassis
CLATRONIC	CTV9500	F8
CLATRONIC	CVT516VT	12.8 (?)
COLANI	TV553000	TV3000
COMET	1402 N1	PT92J
CONDOR	CA118	83P
CONDOR	CTV1437	DTV1400
CONDOR	CTV2154	MPF5398
CONDOR	CTV2702	F9-00
CONDOR	CTV2711	990
CONDOR	CTV2712	F9
CONDOR	CTV2870	PT92
CONDOR	CTV2880	F9-01
CONDOR	CTV2880	F9-01
CONDOR	CTV3715	PL2
CONDOR	CTV5115	PL2
CONDOR	CTV7010	990/991
CONDOR	DJ2801	F8
CONDOR	DJ2803	F9
CONDOR	DJ5167	F8
CONDOR	DJ7355	F9
CONDOR	DJ7360	F9
CONDOR	DJ7369	F8
CONDOR	DJ7371	F8
CONDOR	DJ7373	F8
CONDOR	DJ9182	F8
CONDOR	DJ9183	F9
CONDOR	DJ9360VT	F8
CONDOR	DJ9371	F9
CONDOR	DJ9373	F9
CONDOR	DJ9373VT	F9
CONDOR	NW479/87RO	F8
CONDOR	P5541RM	C500
CONTEC	KRB1570	K3910W
CONTEC	KT8250	C41
CONTEC	KTN5145	P51-05

Brand	model	chassis
CONTEC	MFP5398	P51-28 (60-A0539820-01)
CONTEC	MRV3766	P37-13
CONTEC	MV5182	P51-18
CONTEC	MV5198A	P51-28 (60-A0539820-01)
CONTI	TV14CTV ZX6 SILVER	12.8 (BEKO)
Continental	CT/ET2115	G1000
CONTINENTAL	CT1411	G1000 (Grundig)
CONTINENTAL	CT1412	G1000 (Grundig)
CONTINENTAL	CTV2180	MC97A
CONTINENTAL	CTV5490	MC97A
CONTINENTAL	CTV5679	MC97A
CONTINENTAL	CTV5950	MC97A
CONTINENTAL-EDISON	CE2825	E2000 (Grundig) (?)
Continents	32HRATR16RF100	8500 PROFESSIONAL (PCB8500) (Sinudyne Orion)
CORSO	L1411T	TV2KR
Crosley/Philips	CP5440 W102	PTV745 AH01
CROWN	1401/1	11AK20
CROWN	14L3	TV81
CROWN	14L3	TV83G (200-100-TV83 REV:A)
CROWN	14L3	TV84
CROWN	14L3	TV85
CROWN	14L4	TV3AM
CROWN	14L4	TV83
CROWN	14L5	TV2K
CROWN	14V2	11AK20
CROWN	14V2P	11AK20M
CROWN	2001/L	SM2 (?)
CROWN	20L2	CE10
CROWN	20L5	TV2K
CROWN	2196	E9
CROWN	25V5	11AK19
CROWN	2801	11AK12
CROWN	2801/1	11AK19
CROWN	2802VT ST	TV15
CROWN	2802VT ST/L	SM2

Brand	model	chassis
CROWN	2822T SILVER	TV4K (40G-STT28C-VSG)
CROWN	28B3	11.1 (BEKO)
CROWN	28B4STN	11.1 (BEKO)
CROWN	28V5	11AK19
CROWN	28V55TN	11AK19
CROWN	28V5STN	11AK19
CROWN	28V6	11AK19
CROWN	ACV2133	(HD-SY36A)
CROWN	B1332	10.3 albo 10.2 (BEKO)
CROWN	CF9528NFT	F11
CROWN	CF9633NFT	F11
CROWN	CRP2196CRP	SM1 MONO
CROWN	CRP21NT	SM1 MONO
CROWN	CRP21T	SM1 MONO
CROWN	CRT5159R	TELRA
CROWN	CRT5912RT	TELRA
CROWN	CRT9521R	TELRA
CROWN	CRT9551RT	TELRA
CROWN	CRT9655RT	11AK12
CROWN	CRT9655RTN	11AK10
CROWN	CRV37	11AK08
CROWN	CRV47	11AK08
CROWN	CRV72 NT	11AK12
CROWN	CTT3207W	17MB08 (?)
CROWN	CTV-B1131	AT3 (BEKO)
CROWN	CTV-B1332	10.3 (albo 10.2) (BEKO)
CROWN	CTV-B1715	AT3 (BEKO)
CROWN	CTV-B2016	AT3 (BEKO)
CROWN	CTV-B2132	AT3 (BEKO)
CROWN	CTV-B28B3	AT3 (BEKO)
CROWN	CTV-B5036	10.2 (50S.190C---SIESTA60Z110)
CROWN	CTV-B5051	10.2 (BEKO)
CROWN	CTV-B7270	AT3 (czy? raczej 10.3)
CROWN	CTV1672	11AK16A2
CROWN	CTV2001	SM2

Brand	model	chassis
CROWN	CTV2021	PT90A ?
CROWN	CTV2037	C41
CROWN	CTV2037VR	C41M
CROWN	CTV20C01TX	12.5 (BEKO)
CROWN	CTV20C01TX (czy? CTV20C01TX)	12.4/12.5
CROWN	CTV2802VTST	TV15 ?
CROWN	CTV3725	E1-14EK5 (BEKO)
CROWN	CTV5251	AT3 (BEKO)
CROWN	CTV5342	AT3 (BEKO)
CROWN	CTV54K	10.2 (BEKO)
CROWN	CTV5555	AT3 (BEKO)
CROWN	CTV5596	11AK10-18
CROWN	CTV5616	AT3 (BEKO)
CROWN	CTV5701	11.1 (BEKO)
CROWN	CTV5701	AT3 (BEKO)
CROWN	CTV5711	AT3 (BEKO)
CROWN	CTV5830	11.1 (BEKO)
CROWN	CTV5930	11.1 (5LZ190-32) (BEKO)
CROWN	CTV6030	11.1 (BEKO)
CROWN	CTV6040	11.1 (110°) (BEKO)
CROWN	CTV6263	E5
CROWN	CTV7511	12.1 (6BZ.190-06) (BEKO)
CROWN	CTV7711	AT3 ?
CROWN	CTV7831	14.1 ?
CROWN	CTV8136	11AK08-13
CROWN	CTV8954S	14.1 ?
CROWN	CTVB1131	AT3 (BEKO)
CROWN	CTVB1715	AT3 (BEKO)
CROWN	CTVB2016	AT3 (BEKO)
CROWN	CTVB2132	AT3 (BEKO)
CROWN	CTVB28B3	AT3 (BEKO)
CROWN	CTVB5051	10.2 SIESTA2 (BEKO)
CROWN	CTVB7270	AT3 (BEKO)
CROWN	CTVEL6151	E5
CROWN	CTVEL6255	E5

Brand	model	chassis
CROWN	CTVEL6270	E5
CROWN	CTVEL7051	E5
CROWN	HTV6955RTN	11AK10
CROWN	TC1491R	PW3034 ?
CS.ELEKTRONICS	14360113	K3915
CURTIS	14M1	M1
CURTIS	14M2	M2
CURTIS	2002VT	PC04A
CURTIS	20L2	CE10
CURTIS	20M1	M1
CURTIS	20M2	M2
CURTIS	21L2	CE10
CURTIS	21L2VT	CE10 (MC64A ?)
CURTIS	21M1	M1
CURTIS	21M2	M2
CURTIS	25M1	M1
CURTIS	25M1VT	M1
CURTIS	25M2	M2
CURTIS	28M1	M1
CURTIS	28M2	M2
CURTIS	CE1401VT	PC04A
CURTIS	CE1402VT	PC04A
CURTIS	CE2001VT	PC04A
CURTIS	CE2002VT	PC04A
CURTIS	CE2101VT	PC04A
CURTIS	CE2102VT	PC04A (111F30A)
CWR-TECH	CTV2137T	TV2KM
D-Vision	FC2000	PT11 (97TA012B)
D-VISION	FS2861N	SM2 ? (97TA010J)
DAEWOO		CP185G
DAEWOO		CP185L
DAEWOO		CP390
DAEWOO		CP885F/WP895F
DAEWOO	14A5	CP375
DAEWOO	14A5.T	CP375

Brand	model	chassis
DAEWOO	14A5T	CP375
DAEWOO	14C3	CP185
DAEWOO	14C3NTEG	CP185 ?
DAEWOO	14C3T	CP005
DAEWOO	14C4T	CP005
DAEWOO	14C5T	CP005
DAEWOO	14CB1T	E1 (BEKO) (Z50.190-07)
DAEWOO	14CB2T	E1
DAEWOO	14F8T1S	CP420
DAEWOO	14H3/14H4/20H3/20H4/21H4 T1/T2	CP082
DAEWOO	14Q1	CP370
DAEWOO	14Q1.T	CP375
DAEWOO	14Q1T	CP375
DAEWOO	14Q2	CP370
DAEWOO	14Q2.T	CP375
DAEWOO	14Q2T	CP375
DAEWOO	14Q3	CP370
DAEWOO	14Q3.T	CP375
DAEWOO	14Q3T	CP375
DAEWOO	14Q4	CP370
DAEWOO	14T1	CP370
DAEWOO	14T1.T	CP375
DAEWOO	14T1T	CP375
DAEWOO	14T2	CP370
DAEWOO	14T2.T	CP375
DAEWOO	14T2T	CP375
DAEWOO	14T3	CP370
DAEWOO	14T3	CP370
DAEWOO	20A05T	CP375 ?
DAEWOO	20A5.T	CP375
DAEWOO	20A5T	CP375
DAEWOO	20C4T	CP005
DAEWOO	20C5T	CP005
DAEWOO	20C7GTS	CP185G/GU
DAEWOO	20F8T1	CP420

Brand	model	chassis
DAEWOO	20H4T1	CP082
DAEWOO	20JS5FC	CN200A ?
DAEWOO	20K8MT	CP185N
DAEWOO	20Q1	CP370
DAEWOO	20Q1.T	CP375
DAEWOO	20Q1T	CP375
DAEWOO	20Q2	CP370
DAEWOO	20Q2.T	CP375
DAEWOO	20Q2MZ	CP185C
DAEWOO	20Q2T	CP375
DAEWOO	20Q3	CP370
DAEWOO	20Q3.T	CP375
DAEWOO	20Q3T	CP375
DAEWOO	20Q4	CP370
DAEWOO	20S2M	CP185C
DAEWOO	20T1	CP370
DAEWOO	20T1,T	CP375
DAEWOO	20T1ST	CP380
DAEWOO	20T2	CP370
DAEWOO	20T2.T	CP375
DAEWOO	20T2ST	CP380
DAEWOO	20T2T	CP375
DAEWOO	20T2T	CP375
DAEWOO	20T3	CP370
DAEWOO	20T3ST	CP380
DAEWOO	20T4	CP370
DAEWOO	20T9ST	CP380
DAEWOO	20V1GT	CP185G/GU
DAEWOO	20V1NT	CP185G
DAEWOO	21A5	CP375
DAEWOO	21A5.T	CP375
DAEWOO	21A5T	CP375
DAEWOO	21C6T	CP005
DAEWOO	21DA5T	CP375 (?)
DAEWOO	21F1T2	CP420

Brand	model	chassis
DAEWOO	21Q1	CP370
DAEWOO	21Q1.T	CP375
DAEWOO	21Q1T	CP375
DAEWOO	21Q1T	CP375L
DAEWOO	21Q2	CP370
DAEWOO	21Q2.T	CP375
DAEWOO	21Q2T	CP375
DAEWOO	21Q3	CP370
DAEWOO	21Q4	CP370
DAEWOO	21Q4.T	CP375
DAEWOO	21Q4T	CP375L ?
DAEWOO	21T1	CP370
DAEWOO	21T1.T	CP375
DAEWOO	21T1ST	CP380
DAEWOO	21T1T	CP375
DAEWOO	21T2	CP370
DAEWOO	21T2.T	CP375
DAEWOO	21T2ST	CP380
DAEWOO	21T2T	CP375
DAEWOO	21T3	CP370
DAEWOO	21T3ST	CP380
DAEWOO	21T4	CP370
DAEWOO	21T5T	CP375
DAEWOO	21T9ST	CP380
DAEWOO	2594ST	CP775
DAEWOO	25G1FS	CM870
DAEWOO	25G1FSP	CM870
DAEWOO	25G1FST	CM870
DAEWOO	25G3FS	CM870
DAEWOO	25G3FSP	CM870
DAEWOO	25G3FST	CM870
DAEWOO	2896ST	CP775
DAEWOO	2898ST	CP775
DAEWOO	28V2100D	CP810
DAEWOO	2961T	CP775

Brand	model	chassis
DAEWOO	29G1FS	CM870
DAEWOO	29G1FSP	CM870
DAEWOO	29G1FST	CM870
DAEWOO	29G3FS	CM870
DAEWOO	29G3FSP	CM870
DAEWOO	29G3FST	CM870
DAEWOO	29X5 PIP	CM910
DAEWOO	5582	CP350 ?
DAEWOO	AX21Q1T	CP375
DAEWOO	CT21A5T	H704V04A ?
DAEWOO	CTK2160	CM003
DAEWOO	CTV20A1	CP330
DAEWOO	DCS2011	C41
DAEWOO	DCS2011VR	C38
DAEWOO	DCS2034VR	C42M
DAEWOO	DCS2037VR	C41M
DAEWOO	DDQ20L6SCN	CN091
DAEWOO	DDT21H9S	CP093F
DAEWOO	DDT21H9S	CP099F
DAEWOO	DDT21H9ZZF	CP099F
DAEWOO	DDT21H9ZZR	CP099F
DAEWOO	DLP17D3	SL120P
DAEWOO	DLP17D3N	SL120P
DAEWOO	DLP20D3	SL120P
DAEWOO	DLP20D3N	SL120P
DAEWOO	DLP2612	SL210P
DAEWOO	DLP3212	SL210P
DAEWOO	DMQ-DTT2193	CP360
DAEWOO	DMQ1422	C41M
DAEWOO	DMQ1456	C50N
DAEWOO	DMQ1457TXT	CP776
DAEWOO	DMQ14A1	CP330
DAEWOO	DMQ2014	C600
DAEWOO	DMQ2044	C50
DAEWOO	DMQ2049	C500

Brand	model	chassis
DAEWOO	DMQ2053	C52 ?
DAEWOO	DMQ2072	CP330
DAEWOO	DMQ2072TXT	CP300 (?)
DAEWOO	DMQ2075XT	CP330
DAEWOO	DMQ2093	C500
DAEWOO	DMQ20A1	CP330
DAEWOO	DMQ20A5T	CP375
DAEWOO	DMQ2127	C50N (?)
DAEWOO	DMQ2141	C500
DAEWOO	DMQ2147	C500
DAEWOO	DMQ2158TXT	CP315
DAEWOO	DMQ2159	CP315
DAEWOO	DMQ2195 TXT	CP330
DAEWOO	DMQ2195T	CP330
DAEWOO	DMQ21A1TXT	CP330 ?
DAEWOO	DMQ21A5T	CP375
DAEWOO	DMQ21T5T	CP375
DAEWOO	DMQ2510TXT	CP765
DAEWOO	DMQ2594ST	CP775
DAEWOO	DMQ2595	CP760 ?
DAEWOO	DMQ2597	C1000
DAEWOO	DMQ29X5	CM910
DAEWOO	DMX21A1TXT	CP330
DAEWOO	DP42GM	SP115
DAEWOO	DP42GP	SP115
DAEWOO	DP42SM	SP115
DAEWOO	DP42SP	SP115
DAEWOO	DP42WM	SP115
DAEWOO	DP42WP	SP115
DAEWOO	DPN4274NHS	SP200N
DAEWOO	DPP4272 NHS	SP200P
DAEWOO	DSC30W60N	SC110
DAEWOO	DSC3210E	SC140
DAEWOO	DSC3220E	SC150
DAEWOO	DSC3220L	SC150

Brand	model	chassis
DAEWOO	DSC3261HA	CM921F
DAEWOO	DSC3270E	SC130
DAEWOO	DSC34W70	SC120
DAEWOO	DSC34W70N	SC120
DAEWOO	DSJ4710CRA	SJ112
DAEWOO	DSJ4720CHM	SJ114
DAEWOO	DSJ4720CRA	SJ112
DAEWOO	DSJ5510CRA	SJ112
DAEWOO	DSJ5520CRA	SJ112
DAEWOO	DSL20D1T	SL110P
DAEWOO	DSL20D3	SL110P
DAEWOO	DSN9070	SN500
DAEWOO	DSN9071	SN500
DAEWOO	DSP4210GM	SP110
DAEWOO	DT29G4	CP775L
DAEWOO	DTA1414VU	C600
DAEWOO	DTA1414VU	C600
DAEWOO	DTA1432VFP	C901
DAEWOO	DTA14C4TF	CP185
DAEWOO	DTA14C4TFF	CP185
DAEWOO	DTA14C4TFF	CP185
DAEWOO	DTA14V1TF	CP185
DAEWOO	DTA14V1TF	CP185
DAEWOO	DTA14V4MZ	CP185N
DAEWOO	DTA20C4TF	CP185
DAEWOO	DTA20C4TF	CP185S
DAEWOO	DTA20C6TFF	CP185
DAEWOO	DTA20T1	CP385
DAEWOO	DTA20T2	CP385
DAEWOO	DTA20T3	CP385
DAEWOO	DTA20T8	CP385
DAEWOO	DTA20V3VM	CP185M
DAEWOO	DTA21C6TF	CP185
DAEWOO	DTA21C6TFF	CP185
DAEWOO	DTA21T1	CP385

Brand	model	chassis
DAEWOO	DTA21T2	CP385
DAEWOO	DTA21T5	CP385
DAEWOO	DTA21T9	CP385
DAEWOO	DTA21Y1	CP385
DAEWOO	DTA21Y1P1	CP385 ?
DAEWOO	DTA21YP	CP385 (?)
DAEWOO	DTA29M2FS	CM021M
DAEWOO	DTA3220K	CP820
DAEWOO	DTA3220ZL	CP822F
DAEWOO	DTA3291E	CP770
DAEWOO	DTA32W9K	CP822F
DAEWOO	DTA32W9ZL	CP822F
DAEWOO	DTA32W9ZZ	CP822F
DAEWOO	DTB21D4T	CP185C
DAEWOO	DTB21U6	CP185F
DAEWOO	DTB21U7	CP485F
DAEWOO	DTB21U7S	CP485F
DAEWOO	DTC1472	CP320
DAEWOO	DTC14A1	CP325
DAEWOO	DTC14B1	CP325
DAEWOO	DTC14D1	CP320
DAEWOO	DTC14D9T	CP195L
DAEWOO	DTC14T2	CP370
DAEWOO	DTC14V1TM	CP002
DAEWOO	DTC14V3TM	CP002
DAEWOO	DTC14V4	CP002
DAEWOO	DTC14V5	CP002
DAEWOO	DTC15D1	CP320
DAEWOO	DTC2066	CP320
DAEWOO	DTC2072	CP320
DAEWOO	DTC20A1	CP325
DAEWOO	DTC20B1	CP325
DAEWOO	DTC20D1	CP320
DAEWOO	DTC20D9T	CP195L
DAEWOO	DTC20T2	CP520A

Brand	model	chassis
DAEWOO	DTC20T2	CP520A
DAEWOO	DTC20T6	CP390
DAEWOO	DTC20V1TM	CP002
DAEWOO	DTC20V3TM	CP002
DAEWOO	DTC20V4	CP002
DAEWOO	DTC20V5	CP002
DAEWOO	DTC2131TF	CP195L
DAEWOO	DTC2166	CP320
DAEWOO	DTC21D9T	CP195L
DAEWOO	DTC21V1TM	CP002
DAEWOO	DTC21V3TM	CP002
DAEWOO	DTC21V4	CP002
DAEWOO	DTC21V5	CP002
DAEWOO	DTC21Y1	CP520A
DAEWOO	DTC21Y1	CP520A
DAEWOO	DTC21Y2	CP520A
DAEWOO	DTC21Y2	CP520A
DAEWOO	DTC2570	CM805
DAEWOO	DTC25G1VM	CM900
DAEWOO	DTC25G3VMR	CM900
DAEWOO	DTC25G4VMS	CM900
DAEWOO	DTC25G7VM	CM900
DAEWOO	DTC2975	CM805
DAEWOO	DTC29G1VM	CM900
DAEWOO	DTC29G3VMR	CM900
DAEWOO	DTC29G4VMS	CM900
DAEWOO	DTC29G7VM	CM900
DAEWOO	DTC29M5ME	CM907/F
DAEWOO	DTC29M5MP	CM907/F
DAEWOO	DTC29M5MT	CM907/F
DAEWOO	DTC29M5MZ	CM907/F
DAEWOO	DTC29U1ME	CM907/F
DAEWOO	DTC29U1MP	CM907/F
DAEWOO	DTC29U1MT	CM907/F
DAEWOO	DTC29U1MZ	CM907/F

Brand	model	chassis
DAEWOO	DTC29U5ME	CM907/F
DAEWOO	DTC29U5MP	CM907/F
DAEWOO	DTC29U5MT	CM907/F
DAEWOO	DTC29U5MZ	CM907/F
DAEWOO	DTC29X5	CM910
DAEWOO	DTC29Z9	CM915
DAEWOO	DTC29Z9 PIP	CM915
DAEWOO	DTD1427	CP315
DAEWOO	DTD1447	CP315
DAEWOO	DTD1451	CP315
DAEWOO	DTD1457	CP315
DAEWOO	DTD1458	CP315
DAEWOO	DTD14A1	CP330 !
DAEWOO	DTD14D3ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD14D4	CM905F
DAEWOO	DTD14D4ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD14D6	CM905F
DAEWOO	DTD14D6ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD14D7	CM905F
DAEWOO	DTD14D7ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD14H9	CP093/F
DAEWOO	DTD2027	CP315
DAEWOO	DTD2046	CP315
DAEWOO	DTD2047	CP315
DAEWOO	DTD2051	CP315
DAEWOO	DTD2057	CP315
DAEWOO	DTD2058	CP315
DAEWOO	DTD2075S	C1000 ?
DAEWOO	DTD20D3	CM905F
DAEWOO	DTD20D3ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD20D4	CM905F
DAEWOO	DTD20D4ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD20D7	CM905F
DAEWOO	DTD20D7ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD2147	CP315

Brand	model	chassis
DAEWOO	DTD2148	CP315
DAEWOO	DTD2157	CP315
DAEWOO	DTD2158	CP315
DAEWOO	DTD2159	CP315
DAEWOO	DTD2159TXT	CP315
DAEWOO	DTD2169	CP315
DAEWOO	DTD21D3ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD21D3TP	CM905F
DAEWOO	DTD21D4	CM905F
DAEWOO	DTD21D4ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD21D6	CM905F
DAEWOO	DTD21D6ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD21D7	CM905F
DAEWOO	DTD21D7ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD21H9	CP093/F
DAEWOO	DTD21H9	CP093/F
DAEWOO	DTD21U6	CM905F
DAEWOO	DTD21U6ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD21U8	CM905F
DAEWOO	DTD21U8ME/MT/MP/MZ	CM905S/SF
DAEWOO	DTD2595	CP760 (?)
DAEWOO	DTD25G1 ME	CM905
DAEWOO	DTD25G1 MP	CM905
DAEWOO	DTD25G1 MT	CM905
DAEWOO	DTD25G1 MZ	CM905
DAEWOO	DTD25G4 ME	CM905
DAEWOO	DTD25G4 MP	CM905
DAEWOO	DTD25G4 MT	CM905
DAEWOO	DTD25G4 MZ	CM905
DAEWOO	DTD25G5 ME	CM905
DAEWOO	DTD25G5 MP	CM905
DAEWOO	DTD25G5 MT	CM905
DAEWOO	DTD25G5 MZ	CM905
DAEWOO	DTD29D3ME	CM920F
DAEWOO	DTD29D3ME/MT	CM920F

Brand	model	chassis
DAEWOO	DTD29G1 MEO	CM905
DAEWOO	DTD29G1 MPO	CM905
DAEWOO	DTD29G1 MTO	CM905
DAEWOO	DTD29G1 MZO	CM905
DAEWOO	DTD29G4 MEO	CM905
DAEWOO	DTD29G4 MPO	CM905
DAEWOO	DTD29G4 MTO	CM905
DAEWOO	DTD29G4 MZO	CM905
DAEWOO	DTD29G5 MEO	CM905
DAEWOO	DTD29G5 MPO	CM905
DAEWOO	DTD29G5 MTO	CM905
DAEWOO	DTD29G5 MZO	CM905
DAEWOO	DTD29M1 MEO	CM905
DAEWOO	DTD29M1 MPO	CM905
DAEWOO	DTD29M1 MTO	CM905
DAEWOO	DTD29M1 MZO	CM905
DAEWOO	DTD29M2 MEO	CM905
DAEWOO	DTD29M2 MPO	CM905
DAEWOO	DTD29M2 MTO	CM905
DAEWOO	DTD29M2 MZO	CM905
DAEWOO	DTD29U8ME	CM905F
DAEWOO	DTD29U9	CM916F
DAEWOO	DTD29U9ME	CM920F
DAEWOO	DTD29U9ME/MT	CM920F
DAEWOO	DTD29U9WP	CM916F
DAEWOO	DTD29U9WPT	CM916F
DAEWOO	DTD34Z9ME/MT	CM920F
DAEWOO	DTD34Z9MT	CM920F
DAEWOO	DTE21U6TH	CP785AF
DAEWOO	DTE25G5THS	CP785A
DAEWOO	DTE25G6	CP785
DAEWOO	DTE25G6K	CP785
DAEWOO	DTE25G7IC	CP785
DAEWOO	DTE25G7K	CP785
DAEWOO	DTE2896	CP785

Brand	model	chassis
DAEWOO	DTE2898	CP785
DAEWOO	DTE28A6	CP785
DAEWOO	DTE28A7	CP785
DAEWOO	DTE28B1	CP785
DAEWOO	DTE28B1S	CP785 ?
DAEWOO	DTE28G2	CP785
DAEWOO	DTE28G6	CP785
DAEWOO	DTE28G7	CP785
DAEWOO	DTE28G8	CP785
DAEWOO	DTE29G3S	CP795
DAEWOO	DTE29G5TH	CP785A
DAEWOO	DTF2950 GB100D	CP850FX
DAEWOO	DTF2950 GB100D	CP850FX (100Hz)
DAEWOO	DTF2950-100D	CP850FX
DAEWOO	DTF2950-100D	CP850FX (100Hz)
DAEWOO	DTF2950K100D	CP850FX
DAEWOO	DTF2950K100D	CP850FX (100Hz)
DAEWOO	DTF29U7K	WP895F/CP885F
DAEWOO	DTG2579	C1000
DAEWOO	DTG2596TK	C1000
DAEWOO	DTG2597TK	C1000
DAEWOO	DTG28A7	CP830 (?)
DAEWOO	DTG2993TK	C1000
DAEWOO	DTG2997TK	C1000
DAEWOO	DTH1450FS	CM530A
DAEWOO	DTH14Q1FS	CM537
DAEWOO	DTH14Q2FS	CM537
DAEWOO	DTH14Q3FS	CM537
DAEWOO	DTH14T1AS	CM537
DAEWOO	DTH14V1FS	CM003
DAEWOO	DTH14V1PS	CM003
DAEWOO	DTH14V3FS	CM003
DAEWOO	DTH14V3PS	CM003
DAEWOO	DTH14V4FS	CM003
DAEWOO	DTH14V4PS	CM003

Brand	model	chassis
DAEWOO	DTH2056FS	CM530
DAEWOO	DTH20D5FS	CN220B
DAEWOO	DTH20D5FSN	CM220N
DAEWOO	DTH20Q1FS	CM537
DAEWOO	DTH20Q2FS	CM537
DAEWOO	DTH20Q3FS	CM537
DAEWOO	DTH20T1AS	CM537
DAEWOO	DTH20T2AS	CM537
DAEWOO	DTH20T3AS	CM537
DAEWOO	DTH20V1FS	CM003
DAEWOO	DTH20V1PS	CM003
DAEWOO	DTH20V3FS	CM003
DAEWOO	DTH20V3PS	CM003
DAEWOO	DTH20V4FS	CM003
DAEWOO	DTH20V4PS	CM003
DAEWOO	DTH211F	CM403F
DAEWOO	DTH211F	CM403F
DAEWOO	DTH2166	CM565 ?
DAEWOO	DTH21D4FS	CM220B
DAEWOO	DTH21D4FSN	CM220N
DAEWOO	DTH21T5FS	CM570
DAEWOO	DTH21V1FS	CM003
DAEWOO	DTH21V1PS	CM003
DAEWOO	DTH21V3FS	CM003
DAEWOO	DTH21V3PS	CM003
DAEWOO	DTH21V4FS	CM003
DAEWOO	DTH21V4PS	CM003
DAEWOO	DTH25G1FST	CM870
DAEWOO	DTH2881	CP830F
DAEWOO	DTH2881-100D	CP830F
DAEWOO	DTH28W8	CP830F
DAEWOO	DTH28W9	CP830F
DAEWOO	DTH2930SSFV	CM405F
DAEWOO	DTH2930SSFV	CM405F
DAEWOO	DTH2947K100D	CP830FP

Brand	model	chassis
DAEWOO	DTH29G1FST	CM870
DAEWOO	DTH29G2K	CP830
DAEWOO	DTH29G3FST	CM870
DAEWOO	DTH29M2FS	CM012M
DAEWOO	DTH29U3K	CP830F
DAEWOO	DTH29U7K	CP830F
DAEWOO	DTH29U7K	CP831F
DAEWOO	DTH29U7K100D	CP830F
DAEWOO	DTH29U8	CP830F
DAEWOO	DTJ28A6	CP810
DAEWOO	DTJ28A7	CP810
DAEWOO	DTJ28A7-100D	CP810
DAEWOO	DTJ28B1	CP810
DAEWOO	DTJ28G6	CP810
DAEWOO	DTJ28G7	CP810
DAEWOO	DTJ28G8	CP810
DAEWOO	DTJ28xxx	CP810
DAEWOO	DTK1413VM	C50NA
DAEWOO	DTK1418VM	C50NA
DAEWOO	DTK1432	C52
DAEWOO	DTK1435	C52
DAEWOO	DTK1436	C52
DAEWOO	DTK2013VM	C50NA
DAEWOO	DTK2018VM	C50NA
DAEWOO	DTK2035	C52
DAEWOO	DTK2036	C52
DAEWOO	DTK2135	C52
DAEWOO	DTK2136	C52
DAEWOO	DTK29G2K100D	CP850F ?
DAEWOO	DTK29X5	CM910
DAEWOO	DTK29X5 PIP	CM910
DAEWOO	DTL25G2F	CP776
DAEWOO	DTL25G6F	CP776
DAEWOO	DTL25G7F	CP776
DAEWOO	DTL25G8F	CP776

Brand	model	chassis
DAEWOO	DTL28G2F	CP776
DAEWOO	DTL28G6F	CP776
DAEWOO	DTL28G7F	CP776
DAEWOO	DTL28G7K	CP776
DAEWOO	DTL28G8F	CP776
DAEWOO	DTL2950	CP650
DAEWOO	DTL2950 (K, GB)	CP650
DAEWOO	DTL2950 GB	CP650
DAEWOO	DTL2950K	CP650
DAEWOO	DTL29U8ZLP/ZZP	CP822F
DAEWOO	DTM21U7K	CP520 (?)
DAEWOO	DTM2930ME/MP/MT/MZ	CM650
DAEWOO	DTM2930ME/MP/MT/MZ	CM650
DAEWOO	DTM29U7K100D	CP810F
DAEWOO	DTP14C3	CP005
DAEWOO	DTP14C4	CP005
DAEWOO	DTP14C5	CP005
DAEWOO	DTP14V1	CP005
DAEWOO	DTP14V2	CP005
DAEWOO	DTP14V3	CP005
DAEWOO	DTP14V5	CP005
DAEWOO	DTP28G6K	WP895/CP885
DAEWOO	DTP28G7K	WP895 CP885 CP485
DAEWOO	DTP28G7KS	CP785
DAEWOO	DTQ 1446	CN100...
DAEWOO	DTQ1319V1FC	CN001G
DAEWOO	DTQ13V5FC	CN001N
DAEWOO	DTQ1423FC	CN100
DAEWOO	DTQ1427FS	CN52N
DAEWOO	DTQ1446FC	CN100
DAEWOO	DTQ1451FS	CN52N
DAEWOO	DTQ1456FN/FC	CN100
DAEWOO	DTQ1456FS	CN52N
DAEWOO	DTQ1458FS	CN52N
DAEWOO	DTQ1459FN/FC	CN100

Brand	model	chassis
DAEWOO	DTQ1459FS	CN52N
DAEWOO	DTQ1463	CN155
DAEWOO	DTQ1468	CN155
DAEWOO	DTQ14D3AS	CN201A
DAEWOO	DTQ14J4FCCM	CN001M
DAEWOO	DTQ14J4FCGG/FCCG	CN001G
DAEWOO	DTQ14J4FCGG/FCCG	CN001G
DAEWOO	DTQ14J4FCGM	CN001M
DAEWOO	DTQ14N3FC	CN115I
DAEWOO	DTQ14P2	CN001G
DAEWOO	DTQ14P2/P3FCG	CN001G
DAEWOO	DTQ14P2/V1FCWG/P2SCG	CN001G
DAEWOO	DTQ14P2/V1FCWG/P2SCG	CN001G
DAEWOO	DTQ14P2FCM	CN001M
DAEWOO	DTQ14P3FCM	CN001M
DAEWOO	DTQ14Q1FS	CN201A/B
DAEWOO	DTQ14Q2TS	CN201A/B
DAEWOO	DTQ14Q3FS	CN201A/B
DAEWOO	DTQ14T1AS	CN201A/B
DAEWOO	DTQ14T2FS	CN201A/B
DAEWOO	DTQ14U1F	CN001A
DAEWOO	DTQ14U1FS	CN001A
DAEWOO	DTQ14U1FS	CN001A
DAEWOO	DTQ14U1FSG/SSG/20U1FSG/S SG	CN001G
DAEWOO	DTQ14U1FSG/SSG/20U1FSG/S SG	CN001G
DAEWOO	DTQ14U1FSN/20U1FSN	CN001N
DAEWOO	DTQ14U1FSP	CN001A
DAEWOO	DTQ14U1FSP	CN001A
DAEWOO	DTQ14U1FSPN/20U1FSPN	CN001N
DAEWOO	DTQ14U1SSPM	CN001M
DAEWOO	DTQ14V1/V3/V4/V5/V8/V9SSG	CN001G
DAEWOO	DTQ14V1/V3/V4/V5/V8/V9SSG	CN001G
DAEWOO	DTQ14V1/V3/V5FSG	CN001G
DAEWOO	DTQ14V1/V3/V5FSG	CN001G
DAEWOO	DTQ14V1/V4/V5/U1SSPG	CN001G

Brand	model	chassis
DAEWOO	DTQ14V1/V4/V5/U1SSPG	CN001G
DAEWOO	DTQ14V1/V4/V5FSPG	CN001G
DAEWOO	DTQ14V1/V4/V5FSPG	CN001G
DAEWOO	DTQ14V1/V4/V8SSFG	CN001G
DAEWOO	DTQ14V1/V4/V8SSFG	CN001G
DAEWOO	DTQ14V1/V5FCG/V1/V4SCG	CN001G
DAEWOO	DTQ14V1/V5FCG/V1/V4SCG	CN001G
DAEWOO	DTQ14V1F	CN001A
DAEWOO	DTQ14V1FC	CN001A
DAEWOO	DTQ14V1FC	CN001A
DAEWOO	DTQ14V1FCM	CN001M
DAEWOO	DTQ14V1FCN/20V1FCN	CN001N
DAEWOO	DTQ14V1FS	CN001A
DAEWOO	DTQ14V1FS	CN001A
DAEWOO	DTQ14V1FSM	CN001M
DAEWOO	DTQ14V1FSN/20V1FSN	CN001N
DAEWOO	DTQ14V1FSP	CN001A
DAEWOO	DTQ14V1FSP	CN001A
DAEWOO	DTQ14V1FSPM	CN001M
DAEWOO	DTQ14V1FSPN/20V1FSPN	CN001N
DAEWOO	DTQ14V1SCM	CN001M
DAEWOO	DTQ14V1SSFM	CN001M
DAEWOO	DTQ14V1SSM	CN001M
DAEWOO	DTQ14V1SSPM	CN001M
DAEWOO	DTQ14V3	CN001M
DAEWOO	DTQ14V3F	CN001A
DAEWOO	DTQ14V3FS	CN001A
DAEWOO	DTQ14V3FS	CN001A
DAEWOO	DTQ14V3FSM	CN001M
DAEWOO	DTQ14V3FSN/20V3FSN	CN001N
DAEWOO	DTQ14V3SSM	CN001M
DAEWOO	DTQ14V4/20V4FCFG	CN001G
DAEWOO	DTQ14V4/20V4FCFG	CN001G
DAEWOO	DTQ14V4F	CN001A
DAEWOO	DTQ14V4FCFM	CN001M

Brand	model	chassis
DAEWOO	DTQ14V4FSPM	CN001M
DAEWOO	DTQ14V4SCM	CN001M
DAEWOO	DTQ14V4SSFM	CN001M
DAEWOO	DTQ14V4SSM	CN001M
DAEWOO	DTQ14V4SSPM	CN001M
DAEWOO	DTQ14V5F	CN001A
DAEWOO	DTQ14V5FC	CN001A
DAEWOO	DTQ14V5FC	CN001A
DAEWOO	DTQ14V5FCM	CN001M
DAEWOO	DTQ14V5FCN/20V4FCN	CN001N
DAEWOO	DTQ14V5FCNG/15U5SCG	CN001G
DAEWOO	DTQ14V5FCNG/15U5SCG	CN001G
DAEWOO	DTQ14V5FCNM	CN001M
DAEWOO	DTQ14V5FS	CN001A
DAEWOO	DTQ14V5FS	CN001A
DAEWOO	DTQ14V5FSM	CN001M
DAEWOO	DTQ14V5FSN/20V4FSN	CN001N
DAEWOO	DTQ14V5FSP	CN001A
DAEWOO	DTQ14V5FSP	CN001A
DAEWOO	DTQ14V5FSPM	CN001M
DAEWOO	DTQ14V5FSPN/20V4FSPN	CN001N
DAEWOO	DTQ14V5SSM	CN001M
DAEWOO	DTQ14V5SSPM	CN001M
DAEWOO	DTQ14V6FBBM	CN001M
DAEWOO	DTQ14V6FCBG/FCPG/FBBG/FP PG	CN001G
DAEWOO	DTQ14V6FCBG/FCPG/FBBG/FP PG	CN001G
DAEWOO	DTQ14V6FCBM	CN001M
DAEWOO	DTQ14V6FCPM	CN001M
DAEWOO	DTQ14V6FPBM	CN001M
DAEWOO	DTQ14V6NBG/NPG	CN001G
DAEWOO	DTQ14V6NBG/NPG	CN001G
DAEWOO	DTQ14V6NBM	CN001M
DAEWOO	DTQ14V6NBPM	CN001M
DAEWOO	DTQ14V6NBPM/NPPG	CN001G
DAEWOO	DTQ14V6NBPM/NPPG	CN001G

Brand	model	chassis
DAEWOO	DTQ14V6NPM	CN001M
DAEWOO	DTQ14V6NPPM	CN001M
DAEWOO	DTQ14V8SSM	CN001M
DAEWOO	DTQ14V9SSM	CN001M
DAEWOO	DTQ15U5SCM	CN001M
DAEWOO	DTQ15U5SSPG	CN001G
DAEWOO	DTQ15U5SSPG	CN001G
DAEWOO	DTQ15U5SSPM	CN001M
DAEWOO	DTQ19H1FS	CN081
DAEWOO	DTQ19P2FC	CN001N (?)
DAEWOO	DTQ2023	CN100A
DAEWOO	DTQ2023FC	CN100
DAEWOO	DTQ2033SC	CN230F
DAEWOO	DTQ2040FC	CN001B
DAEWOO	DTQ2046	CN52
DAEWOO	DTQ2046FC	CN100
DAEWOO	DTQ2056FN/FC	CN100
DAEWOO	DTQ2056FS	CN52N
DAEWOO	DTQ2059FN/FC	CN100
DAEWOO	DTQ2063	CN155
DAEWOO	DTQ2068	CN155
DAEWOO	DTQ20D3AS	CN201A
DAEWOO	DTQ20D4AS	CN220B/C
DAEWOO	DTQ20D4ASP	CN220B/C
DAEWOO	DTQ20D4SS	CN220B
DAEWOO	DTQ20D5FC	CN220B/C
DAEWOO	DTQ20D5FS	CN220B/C
DAEWOO	DTQ20D5FSP	CN220B/C
DAEWOO	DTQ20D7SSP	CN220F
DAEWOO	DTQ20P2/P3FCG/P2SCG	CN001G
DAEWOO	DTQ20P2/P3FCG/P2SCG	CN001G
DAEWOO	DTQ20P2FCM	CN001M
DAEWOO	DTQ20P2SCM	CN001M
DAEWOO	DTQ20P2SSG/15U5FSG/SSG/15U7SSG	CN001G
DAEWOO	DTQ20P2SSG/15U5FSG/SSG/15U7SSG	CN001G

Brand	model	chassis
DAEWOO	DTQ20P3FCM	CN001M
DAEWOO	DTQ20Q1FS	CN201A/B
DAEWOO	DTQ20Q2FS	CN201A/B
DAEWOO	DTQ20Q3FS	CN201A/B
DAEWOO	DTQ20S1SSFV	CN402FN
DAEWOO	DTQ20S1SSFV	CN402FN
DAEWOO	DTQ20T1AS	CN201A/B
DAEWOO	DTQ20T1FC	CN201A/B
DAEWOO	DTQ20T1FS	CN201A/B
DAEWOO	DTQ20T2AS	CN201A/B
DAEWOO	DTQ20T2FS	CN201A/B
DAEWOO	DTQ20T3FS	CN201A/B
DAEWOO	DTQ20U1F	CN001A
DAEWOO	DTQ20U1FS	CN001A
DAEWOO	DTQ20U1FS	CN001A
DAEWOO	DTQ20U1FSP	CN001A
DAEWOO	DTQ20U1FSP	CN001A
DAEWOO	DTQ20U1SSPM	CN001M
DAEWOO	DTQ20U4SC	CN230F
DAEWOO	DTQ20V1/V3/V4/U1SSPG	CN001G
DAEWOO	DTQ20V1/V3/V4/U1SSPG	CN001G
DAEWOO	DTQ20V1/V3/V4/V5/V8/V9SSG	CN001G
DAEWOO	DTQ20V1/V3/V4/V5/V8/V9SSG	CN001G
DAEWOO	DTQ20V1/V3/V4FSG	CN001G
DAEWOO	DTQ20V1/V3/V4FSG	CN001G
DAEWOO	DTQ20V1/V4/V5FCG	CN001G
DAEWOO	DTQ20V1/V4/V5FCG	CN001G
DAEWOO	DTQ20V1/V4/V8SSFG	CN001G
DAEWOO	DTQ20V1/V4/V8SSFG	CN001G
DAEWOO	DTQ20V1/V4FSPG	CN001G
DAEWOO	DTQ20V1/V4FSPG	CN001G
DAEWOO	DTQ20V1/V4SCG	CN001G
DAEWOO	DTQ20V1/V4SCG	CN001G
DAEWOO	DTQ20V1F	CN001A
DAEWOO	DTQ20V1FC	CN001A

Brand	model	chassis
DAEWOO	DTQ20V1FC	CN001A
DAEWOO	DTQ20V1FCM	CN001M
DAEWOO	DTQ20V1FS	CN001A
DAEWOO	DTQ20V1FSP	CN001A
DAEWOO	DTQ20V1FSP	CN001A
DAEWOO	DTQ20V1FSPM	CN001M
DAEWOO	DTQ20V1SCM	CN001M
DAEWOO	DTQ20V1SSFG	CN001G (?)
DAEWOO	DTQ20V1SSFM	CN001M
DAEWOO	DTQ20V1SSPM	CN001M
DAEWOO	DTQ20V3F	CN001A
DAEWOO	DTQ20V3FS	CN001A
DAEWOO	DTQ20V3FS	CN001A
DAEWOO	DTQ20V3SSPM	CN001M
DAEWOO	DTQ20V4F	CN001A
DAEWOO	DTQ20V4FC	CN001A
DAEWOO	DTQ20V4FC	CN001A
DAEWOO	DTQ20V4FCFM	CN001M
DAEWOO	DTQ20V4FCM	CN001M
DAEWOO	DTQ20V4FS	CN001A
DAEWOO	DTQ20V4FS	CN001A
DAEWOO	DTQ20V4FSP	CN001A
DAEWOO	DTQ20V4FSP	CN001A
DAEWOO	DTQ20V4SCM	CN001M
DAEWOO	DTQ20V4SSFM	CN001M
DAEWOO	DTQ20V4SSPM	CN001M
DAEWOO	DTQ20V5F	CN001A
DAEWOO	DTQ20V5FCM	CN001M
DAEWOO	DTQ2127FS	CN52N
DAEWOO	DTQ2130	CN402FN
DAEWOO	DTQ21D7	CN402FN
DAEWOO	DTQ21T1FS	CN201A/B
DAEWOO	DTQ21T2FS	CN201A/B
DAEWOO	DTQ21T5FS	CN201A/B
DAEWOO	DTQ21T9FS	CN201A/B

Brand	model	chassis
DAEWOO	DTQ21U6	CN402FN
DAEWOO	DTQ21U6SC	CN220F
DAEWOO	DTQ21U6SS	CN220F
DAEWOO	DTQ21U6SSP	CN220F
DAEWOO	DTQ21U6SSP	CN220F
DAEWOO	DTQ21U8SS	CN220F
DAEWOO	DTQ25G4FS	CN207A
DAEWOO	DTQ2605FC	CN600
DAEWOO	DTQ26S1FC/FS/FSP	CN200I
DAEWOO	DTQ26S1HC/HS/HSP	CN200A
DAEWOO	DTQ26S2	CN200A
DAEWOO	DTQ26S3FC	CN011
DAEWOO	DTQ26S3FC	CN011
DAEWOO	DTQ26S3FCM	CN011
DAEWOO	DTQ26S3FCM	CN011
DAEWOO	DTQ26S5FC	CN014
DAEWOO	DTQ27S3	CN001
DAEWOO	DTQ27U1SC	CN794N
DAEWOO	DTQ27U4SC	CN230F
DAEWOO	DTQ27U8SC	CN793N/F
DAEWOO	DTQ29G1	CM870
DAEWOO	DTQ29G4FS	CN207A
DAEWOO	DTQ29K1SSP	CN794N
DAEWOO	DTQ29M2FS	CN012N
DAEWOO	DTQ29M5SSFV	CN400N
DAEWOO	DTQ29S1FCN/FSN/FSP	CN200I
DAEWOO	DTQ29S1FS	CN200A
DAEWOO	DTQ29S1HC/HS/HSP	CN200A
DAEWOO	DTQ29S2	CN200A
DAEWOO	DTQ29S3FC	CN011
DAEWOO	DTQ29S3FC	CN011
DAEWOO	DTQ29S4FC	CN011N
DAEWOO	DTQ29S4SC	CN011N
DAEWOO	DTQ29S4SS	CN011N
DAEWOO	DTQ29S5FC	CN014

Brand	model	chassis
DAEWOO	DTQ29U1SC	CN794N (?)
DAEWOO	DTQ29U1SCSV	CN400FN
DAEWOO	DTQ29U1SCV	CN400FN
DAEWOO	DTQ29U1SSFV	CN400FN
DAEWOO	DTQ29U1SSP	CN794N
DAEWOO	DTQ29U4SCV	CN401FN
DAEWOO	DTQ29U5SC	CN794N (?)
DAEWOO	DTQ29U5SSFV	CN400FN
DAEWOO	DTQ29U8SS	CN793N
DAEWOO	DTQ29X7FS	CN777C CN778C
DAEWOO	DTQP3FCG	CN001G
DAEWOO	DTR14D3T	CP490
DAEWOO	DTR14D3TM	CP490
DAEWOO	DTR14D3VG	CP490
DAEWOO	DTR16D3T	CP490
DAEWOO	DTR16D3VG	CP490
DAEWOO	DTR20D3T	CP490
DAEWOO	DTR20D3TM	CP490
DAEWOO	DTR20D3VG	CP490
DAEWOO	DTR20D3VGW	CP490
DAEWOO	DTR21D3T	CP490
DAEWOO	DTR21D3TGW	CP490
DAEWOO	DTR21D3TMW	CP490
DAEWOO	DTR21D3VGW	CP490
DAEWOO	DTR29D3ME/MT	CM920FW
DAEWOO	DTR29M5ME/MP/MT/MZ	CM908/F
DAEWOO	DTR29M6ME/MP/MT/MZ	CM908/F
DAEWOO	DTR29M7ME/MP/MT/MZ	CM908/F
DAEWOO	DTR29U1ME/MP/MT/MZ	CM908/F
DAEWOO	DTR29U5ME/MP/MT/MZ	CM908/F
DAEWOO	DTR29U9ME/MT	CM920FW
DAEWOO	DTR34Z9ME/MT	CM920FW
DAEWOO	DTT2046	C50
DAEWOO	DTT2066C1	CP365
DAEWOO	DTT2072C1	CP365

Brand	model	chassis
DAEWOO	DTT2075C1	CP365
DAEWOO	DTT2166C1	CP365
DAEWOO	DTT2172C1	CP365
DAEWOO	DTT2193TU	CP360
DAEWOO	DTT2195C1	CP365
DAEWOO	DTT3250*-100	CP750
DAEWOO	DTT3250MT	CP750
DAEWOO	DTU14D3TM	CP371
DAEWOO	DTU14D3VG	CP371
DAEWOO	DTU14D4TM	CP371
DAEWOO	DTU14D4VG	CP371
DAEWOO	DTU14XX ME/MP/MT/MZ/BZ/AT	CM500S
DAEWOO	DTU16D3VG	CP371
DAEWOO	DTU20D3TM	CP371
DAEWOO	DTU20D3VG	CP371
DAEWOO	DTU20D4TM	CP371
DAEWOO	DTU20D4VG	CP371
DAEWOO	DTU20XX ME/MP/MT/MZ/BZ/AT	CM500S
DAEWOO	DTU21D3TM	CP371
DAEWOO	DTU21D3VG	CP371
DAEWOO	DTU21D4TM	CP371
DAEWOO	DTU21D4VG	CP371
DAEWOO	DTU21xx	CM500S
DAEWOO	DTU21XX ME/MP/MT/MZ/BZ/AT	CM500S
DAEWOO	DTU21XX MEF/MPF/MTE/MZF/BZF	CM500S
DAEWOO	DTV2082P	CP310
DAEWOO	DTV2159TFB	C520
DAEWOO	DTV25G6K S	CP520
DAEWOO	DTW2810F	WP811N
DAEWOO	DTW28W2F	WP811N
DAEWOO	DTW28W2K	WP811N
DAEWOO	DTW28W2K100D	CP810/WP811
DAEWOO	DTW28W2K100D	CP810/WP811
DAEWOO	DTW3300ST	DTV100 (Schneider 33424 1007)
DAEWOO	DTX14A1	CP330

Brand	model	chassis
DAEWOO	DTX14B1	CP330
DAEWOO	DTX14D1	CP330
DAEWOO	DTX2066	CP330
DAEWOO	DTX2072	CP330
DAEWOO	DTX2075	CP330
DAEWOO	DTX20A1	CP330
DAEWOO	DTX20B1	CP330
DAEWOO	DTX20C1	CP330
DAEWOO	DTX20D1	CP330
DAEWOO	DTX2166	CP330
DAEWOO	DTX2172	CP330
DAEWOO	DTX2195	CP330
DAEWOO	DTX21A1	CP330
DAEWOO	DTX21B1	CP330
DAEWOO	DTX21C1	CP330
DAEWOO	DTXT140	CP330
DAEWOO	DTXT142	CP330
DAEWOO	DTXT200	CP330
DAEWOO	DTXT202	CP330
DAEWOO	DTXT512	CP330
DAEWOO	DTY-T59 (UK)	E5
DAEWOO	DTY-T594	E5
DAEWOO	DTY21B4	CP520
DAEWOO	DTY21B4K	CP520
DAEWOO	DTY21B4S	CP520
DAEWOO	DTY21U7	CP520
DAEWOO	DTY21U7S	CP520
DAEWOO	DTY21U7S	CP520
DAEWOO	DTY2510T	CP765
DAEWOO	DTY2570	E5
DAEWOO	DTY2590	E5
DAEWOO	DTY2590WF	CP760
DAEWOO	DTY2594ST	CP775
DAEWOO	DTY2595	E5
DAEWOO	DTY2595WF	CP760

Brand	model	chassis
DAEWOO	DTY2599	E5
DAEWOO	DTY25G1ST	CP775
DAEWOO	DTY25G6	CP520
DAEWOO	DTY25G6KS	CP520
DAEWOO	DTY25G7KS	CP520
DAEWOO	DTY2880	CP520
DAEWOO	DTY2890WF	CP760
DAEWOO	DTY2895WF	CP760
DAEWOO	DTY2896ST	CP775
DAEWOO	DTY2898ST	CP775
DAEWOO	DTY28A6	CP520
DAEWOO	DTY28A7	CP520
DAEWOO	DTY28A7KS	CP520
DAEWOO	DTY28A8K	CP520
DAEWOO	DTY28AKS	PT45C
DAEWOO	DTY28G2ST	CP775
DAEWOO	DTY28W5	CP520
DAEWOO	DTY28W5/80	CP520
DAEWOO	DTY2980	E5
DAEWOO	DTY29G1	CP775
DAEWOO	DTY29XS	CM910
DAEWOO	DTY29Z9	CM915
DAEWOO	DTY29Z9 PIP	CM915
DAEWOO	DTZ2481	CP520F
DAEWOO	DTZ2881	CP520F
DAEWOO	DTZ28W8	CP520F
DAEWOO	DTZ29G2K	CP520F
DAEWOO	DTZ29U3	CP520F
DAEWOO	DTZ29U3K	CP520F
DAEWOO	DTZ29U7	CP520F
DAEWOO	DTZ29U7K	CP520F
DAEWOO	DUA3270 GB	CP770
DAEWOO	DUA3291GB	CP770
DAEWOO	DVN20F6N	CN140
DAEWOO	DVQ13H1FC	CN071

Brand	model	chassis
DAEWOO	DVQ13H1FCN	CN081
DAEWOO	DVQ13H2FC	CN071
DAEWOO	DVQ13H2FCN	CN081
DAEWOO	DVQ19H1FC	CN071
DAEWOO	DVQ19H1FCN	CN081
DAEWOO	DVQ19H2FC	CN071
DAEWOO	DVQ19H2FCN	CN081
DAEWOO	DVS1482DF	CP340
DAEWOO	DVS1482L	CP340
DAEWOO	DVS1483DF	CP340
DAEWOO	DVS1483L	CP340
DAEWOO	DVS14F4	CP340
DAEWOO	DVS14F4DF	CP340
DAEWOO	DVS14F4L	CP340
DAEWOO	DVS2082DF	CP340
DAEWOO	DVS2082L	CP340
DAEWOO	DVS2083DF	CP340
DAEWOO	DVS2083L	CP340
DAEWOO	DVS20F4	CP340
DAEWOO	DVS20F4DF	CP340
DAEWOO	DVS20F4L	CP340
DAEWOO	DVT1482DS	CP310
DAEWOO	DVT1482P	CP310
DAEWOO	DVT1483D	CP310
DAEWOO	DVT1484DS	CP310
DAEWOO	DVT1484N	CN135N
DAEWOO	DVT1484T	CP310
DAEWOO	DVT1485P	CP310
DAEWOO	DVT14F4P	CP350 Combi
DAEWOO	DVT14F6LA	CP420, K-Mecha Deck
DAEWOO	DVT14F6LA/PA/FA/DA/HA	CP420
DAEWOO	DVT14F8LA	CP420, K-Mecha Deck
DAEWOO	DVT14F8LA/PA/FA/DA/HA	CP420
DAEWOO	DVT14H1P(TP)	CP062
DAEWOO	DVT14H1T	CP062

Brand	model	chassis
DAEWOO	DVT14H2T	CP062
DAEWOO	DVT14H3T2	CP082
DAEWOO	DVT14H3UB	CP082
DAEWOO	DVT2082LA	CP310
DAEWOO	DVT2083DS	CP310
DAEWOO	DVT2084D	CP310
DAEWOO	DVT2084DS	CP310
DAEWOO	DVT2084N	CN135N
DAEWOO	DVT2085DF	CP310
DAEWOO	DVT2085DS	CP310
DAEWOO	DVT20F4FA	CP350
DAEWOO	DVT20F4LA	CP350
DAEWOO	DVT20F4PA	CP350
DAEWOO	DVT20F6LA	CP420
DAEWOO	DVT20F8LA	CP420
DAEWOO	DVT20H1T	CP062
DAEWOO	DVT20H2T	CP062
DAEWOO	DVT20H4UB	CP082
DAEWOO	DVT2182LA	CP310
DAEWOO	DVT2186DS	CP310
DAEWOO	DVT21F1LA	CP420R1
DAEWOO	DVT21F2FAF	CP420
DAEWOO	DVT21F2LA	CP420R1
DAEWOO	DVT21F4LA	CP350 Combi
DAEWOO	DVT21H4UB	CP082
DAEWOO	DWF28W8GB	CP885F
DAEWOO	DWL2881K100D	WP811F (?)
DAEWOO	DWL28W8	CP810F ?
DAEWOO	DWL28W8-100D	CP810F
DAEWOO	DWL28W8ZLF/ZZF	CP822F
DAEWOO	DWL28W8ZLP/ZZP	CP822F
DAEWOO	DWL28W8ZLS/ZZS	CP822F
DAEWOO	DWP28W2ZLF	WP795
DAEWOO	DWP28W2ZZF	WP795
DAEWOO	DWP28W8	WP795

Brand	model	chassis
DAEWOO	DWX28W5	WP895 ?
DAEWOO	F14H3/14H4/20H3/20H4/21H4 T1/T2	CP082
DAEWOO	FS59T90	CP785A
DAEWOO	FS68T90	CP785A
DAEWOO	GB14F7T1	CP420 ?
DAEWOO	GB14F8T1	CP420
DAEWOO	GB14H3/14H4/20H3/20H4/21H4 T1/T2	CP082
DAEWOO	GB20C5NTS	CP005 (albo CP185)
DAEWOO	GB21T5ST	CP375
DAEWOO	GB2898ST	CP775
DAEWOO	K14C3T	CP005 ?
DAEWOO	K14C4...	CP185
DAEWOO	K14C4G	CP185
DAEWOO	K14C4NS	CP185
DAEWOO	K14C4T	CP185
DAEWOO	K14C5GTS	CP185G
DAEWOO	K14C5N	CP185
DAEWOO	K14C5NT	CP185
DAEWOO	K14H3/14H4/20H3/20H4/21H4 T1/T2	CP082
DAEWOO	K14V1T	CP005 (?)
DAEWOO	K14V3GT	CP185G/GU
DAEWOO	K14V4T	CP005
DAEWOO	K20C4GT	CP185G/GU
DAEWOO	K20C4GTF	CP185G/GU
DAEWOO	K20C4NT	CP005
DAEWOO	K20C4NT	CP195
DAEWOO	K20C4T	CP005
DAEWOO	K20C5GT	CP185G
DAEWOO	K20C5GTS	CP185G
DAEWOO	K20C5NT	CP185G
DAEWOO	K20H4T1S	CP082
DAEWOO	K20V4T	CP005
DAEWOO	K21C6NT	CP185
DAEWOO	K21C6T	CP005
DAEWOO	K21H4T2	CP082

Brand	model	chassis
DAEWOO	K21V1GTS	CP185?
DAEWOO	K21V1NT	CP185
DAEWOO	K21V1T	CP185?
DAEWOO	K21V4T	CP005
DAEWOO	KR14E5	CP185C-N
DAEWOO	KR14E5/DTA-14V3VM	CP185M
DAEWOO	KR14U1T	CP185C-N
DAEWOO	KR14V1T	CP185C-N
DAEWOO	KR20E5	CP185C-N
DAEWOO	KR20E5/DTA-20V3VM	CP185M
DAEWOO	KR20U1T	CP185C-N
DAEWOO	KR20U2T	CP185C-N
DAEWOO	KR20V1T	CP185C-N
DAEWOO	KR20V4T	CP002 ?
DAEWOO	KR2134MT	CM908S
DAEWOO	KR21E5	CP185C-N
DAEWOO	KR21E5/DTA-21V3VM	CP185M
DAEWOO	KR21U1T	CP185C-N
DAEWOO	KR21U3T	CP185C-N
DAEWOO	KR21V1T	CP185C-N
DAEWOO	KR21V4T	CP185C-N
DAEWOO	KR25G5	CM905F
DAEWOO	KR29FL1	CM908F
DAEWOO	KR29M2	CM905
DAEWOO	KR29M5ME	CM907/F
DAEWOO	KR29M5MP	CM907/F
DAEWOO	KR29M5MT	CM907/F
DAEWOO	KR29M5MZ	CM907/F
DAEWOO	KR29U8	CM905F
DAEWOO	PDS4250	SP120
DAEWOO	PF51T30	CP785AF
DAEWOO	S14F8T1	CP420 ?
DAEWOO	T140	CP330
DAEWOO	T142	CP330
DAEWOO	T200	CP330

Brand	model	chassis
DAEWOO	T202	CP330
DAEWOO	T204	CP365
DAEWOO	T512	CP330
DAEWOO	T514	CP365
DAEWOO	T594	CP760
DAEWOO	T664	CP760
DAEWOO	T694	CP760
DAEWOO	WP811F	CP810F
DANTAX	28TLB1	14.2 (BEKO)
DANTAX	32PFB1	20.2 (100Hz) (BEKO)
Dantax	MND23A	TMX470
DANTAX	MND41	12.1 (BEKO)
DCE	D7110100ST	20.2 (100Hz) (BEKO)
DCE	D8201100	20.2 (100Hz) (BEKO)
DCE	D8201100ST	20.2 (BEKO)
DECCA	D21NAE5	A4 (TATUNG)
DECCA	D28NGH6S	G
DECCA/TATUNG	D28N440	4400 PROFESSIONAL (PCB: 4410)
DECCA/TATUNG	D28W440	4400 PROFESSIONAL (PCB: 4410)
DECCA/TATUNG	D28W441	4400 PROFESSIONAL (PCB: 4410)
DECCA/TATUNG	T21N421	4400 PROFESSIONAL (PCB: 4410)
DECCA/TATUNG	T32W440	4400 PROFESSIONAL (PCB: 4410)
DECCA/TATUNG	T32W441S	4400 PROFESSIONAL (PCB: 4410)
Deccacolour	D28WHH6S	H3N
DECCACOLOUR	L2165RFS	TV2KP (40-MNTV2KP-L1W) (Stereo)
DELTON	CTV5131	11AK19...
DENVER	TV21DVD	(E249001 CE04LVD0015)
DIGITAL	HT2162S	H704V
Disney	MD3722	code A
DORADA	SD1420	MC97A
DORADA	SD2014	MC97A
DORADA	SD2040	MC97A
Dual	29HDA TV RF72003G	8500 PROFESSIONAL (PCB8500)
Dual	7103GMST	8500 PROFESSIONAL (PCB8500) (Sinudyne Orion)
DUAL	CTV7028	TV4

Brand	model	chassis
DUAL	DRF2150	11AK30
DUAL	DRF2810	11AK45B5
DUAL	DTV2050	11AK36A15
DUAL	DTV3-70213/P	DTV3
DUAL	DTV3-8526	DTV3
DUAL	DTV3250	11AK37
DUAL	ST2850VT	DTV100
DUAL	ST32-050	11AK19PRO
DUAL	ST3350VT	DTV100 ?
DUAL	STV28100	TV17.1 (?)
DUAL	TV1155	DTV2
DUAL	TV1163	DTV2
DUAL	TV1170	DTV2
DUAL	TV150	DTV2
DUAL	TV160	DTV2
DUAL	TV170	DTV2
DUAL	TV3051	TV5.1
DUAL	TV3055	TV5.1 Mono
DUAL	TV3063	TV5.1
DUAL	TV3295 PIP	SCC113 (ELBIT)
DUAL	TV4155	DTV2
DUAL	TV4163	DTV2
DUAL	TV4170	DTV2
DUAL	TV4270	DTV2
DUAL	TV4570	DTV2
DUAL	TV4870	STV12
DUAL	TV524	TV4
DUAL	TV5504	TV4
DUAL	TV5504	TV7
DUAL	TV5507	TV7
DUAL	TV701	STV12
DUAL	TV724 SAT	TV4
DUAL	TVM4055	DTV1
DUAL	TVM4155	DTV2
DUAL	TVM4163	DTV2

Brand	model	chassis
DUAL	TVM4170	DTV2
DUAL	TVM4185	DTV2
DURABRAND	6628	PT90
Durabrand	CTV6821	PT90
Durabrand	DCT1481	(PCB9361 MAINCH02 or 9361 CRTCH02)
Durabrand	DCT1481	(PCB9361 MAINCH02 or 9361 CRTCH02)
DURABRAND	TV372	11AK36
Durabrand	TV373	11AK36
DURABRAND	TV702ST	14.2 (U99.190-06)
e:max	C1470T	TV2KM (40MNTV2KM-L7W)
EC	EC64303CTI	SCC103 (ELBIT)
EC	EC70203	SCC103 (ELBIT)
EC	EC70302	SCC103 (ELBIT)
EC	EC70303CTI	SCC103 (ELBIT)
EC	EC70403QT	SCC103 (ELBIT)
EC	EC70602 CTI	SCC103 (ELBIT)
EC	EC70606SAT	SCC103 (ELBIT)
EC	EC70607	SCC103 (ELBIT)
ELBE	1410	E15-2
ELBE	14T9101	14EK8R
ELBE	2110	E16
ELBE	2123	PC020
ELBE	2591MD	E14
ELBE	25S440	K110-7
ELBE	2824ST	BS990
ELBE	28S542	K110-7
ELBE	TVC1409	E12
ELBE	TVC1490	E12
ELBIT	41SCC113	SCC113 (ELBIT)
ELBIT	EC70-302	SM1
ELBIT	TV121	SCC121
ELDORADO	54TC6171	11AK19P4
Electric	CTV2007	11AK36A15
ELECTRIC	CTV2116RF	11AK30
ELECTRIC Co.	CTV1405STXT	11AK36

Brand	model	chassis
ELEFA	CT5120	P54HA ?
ELEKTA	CTR1452EMK	P37-18
ELEKTA	CTR2036EMK	C50
ELEKTA	CTR2039EMK	C50
ELEKTA	CTR20T39EMK	C520 ?
Elekta	DTV21F10	CN18EA
ELEKTRONIX	EX21S(GPL)	SQUAD v.2
ELEMIS	1855T	PT92
ELEMIS	1955T Prima	PT90A
ELEMIS	1955TN Prima	PT90A
ELEMIS	3751	GR1AX
ELEMIS	3855T	PT92
ELEMIS	3870TN Mira	PT92
ELEMIS	3955T	PT90BDK ?
ELEMIS	3955T MIRA	PT90BDK
ELEMIS	3970TN MIRA	PT90A (?)
ELEMIS	4237 PREMIUM	PT12
ELEMIS	5137T NOVA	PT11 ?
ELEMIS	5355TN (5355TN NOVA)	PT2
ELEMIS	5470TA	SM2
ELEMIS	5470TN	SM2
ELEMIS	5511	K9321BF
ELEMIS	5551	COMPACT D-E ???
ELEMIS	5837T NOVA	PT92J
ELEMIS	5870DW	PT92DVD
ELEMIS	5870WS NOVA	PT92 (pt.gł.: 99TA052G)
ELEMIS	5880DW Nova	PT92
ELEMIS	5937T NOVA	PT90J
ELEMIS	5955 TN NOVA	PT90BDK
ELEMIS	5955TN	PT90BDK
ELEMIS	6855T MEGA	PT92 (pt.gł.: 99TA052D)
ELEMIS	6863	PT92
ELEMIS	6870DW	PT92DVD (01TA011B)
ELEMIS	6970DW	PT90A 110°
ELEMIS	7970DH	PT90A

Brand	model	chassis
ELEMIS	8355 Smart	PT2 ? (raczej PT92)
ELEMIS	8855T	PT92BDK
ELEMIS	9470TN Croma	SM2
ELEMIS	C955 DWA	PT90A ?
ELEMIS	CD855TN Combi	PT92DVD
ELEMIS	Mega 929H	PT90A 110° (?)
ELEMIS	NOVA 914	PT90J
ELEMIS	Ruby 121N	PT90
ELEMIS	Ruby 332	PT90
ELEMIS	Ruby 515	PT90A (?)
ELEMIS	Ruby 929	PT90A 110° (?)
ELEMIS	Solaris 626D	CTV100 (04TA065A) - Profilo-Telra
ELEMIS	Solaris 642DXM	CTV100 (04TA065A) - Profilo-Telra
ELEMIS	TF72TNZ	PT100 (100Hz) ?
ELEMIS	TF872TN	PT92
ELENBERG	21F55T	3S10
ELENBERG	5561VT	11AK19P5
ELIN	7209	C41
ELIN	9249	D2
ELTA	2019	DTV1400
ELTA	2075	DTV111-6 (?)
EMERSON	EM2114TXT	PT90
EMERSON	EM2128N TXT	PT90A
ERISSON	14GX37A	TV84 ?
ERISSON	2103	E3701
ERISSON	2120	A3Y11
ERISSON	2120	A3Y11
ERISSON	21T179	3S10
ERISSON	S14	3Y11
ERRES	2680022EK	2A
ERRES	268102EK	2A
EUROCOLOR	CTV5561S-TXT	11AK19PRO
Eurocolor	CTV5571	11AK30-2
EUROLINE	2896	E9
EUROLINE	70100	20.2 (P36110) (100Hz)

Brand	model	chassis
EUROLINE	CTV14T	TV84
EUROPA	81FUTURA	F6 16/9
EUROPA	JMP2021T	PT1002
EUROPHON	21SM422	BS700
EUROPHON	21SM429	BS700
EVELUKS	TX816S24	E6
EVELUX	377M25	E7
EVELUX	S28AD	E10 (VALENJE)
EVELUX	S28AD0	E9 (VALENJE)
EVELUX	S28AD0T	E10
FERGUSON		11AK45
FERGUSON	2580B	TX92
FERGUSON	2880B	TX92
FERGUSON	51K4	ICC5
FERGUSON	51K5	ICC5
FERGUSON	51K7	ICC5
FERGUSON	51L3	ICC5
FERGUSON	51L7	ICC5
FERGUSON	59K4	ICC5
FERGUSON	59K5	ICC5
FERGUSON	59K7	ICC5
FERGUSON	59L7	ICC5
FERGUSON	59M5	ICC5
FERGUSON	68K4	ICC5
FERGUSON	68M5	ICC5
FERGUSON	7220ST/TXT	11AK19-8A
FERGUSON	C3615UT	EUROCOMBO2
FERGUSON	D51ND	ICC9
FERGUSON	D59F	ICC9
FERGUSON	D59N	ICC9
FERGUSON	D68N	ICC9
FERGUSON	D78N	ICC9C5GN
FERGUSON	F14VB12A	EUROCOMBO
FERGUSON	FG14CB12V	CP310
FERGUSON	FG20CB12V	CP310

Brand	model	chassis
FERGUSON	FTD1480	TMC574
FERGUSON	FTV150T	(PLC2147SQ; TMD601A)
Ferguson	FTV28FW1	11AK45B5
FERGUSON	FTVD1480	TMC574
FERGUSON	M3610U	TX807
FERGUSON	M3615UT	TX807
FERGUSON	M3616UT	TX807
FERGUSON	M3673GC	TX91
FERGUSON	M5115UT	TX807
FERGUSON	M5515UT	TX807
FERGUSON	M5518U	ICC17V30
FERGUSON	M6222U	ICC17V30
FERGUSON	M7022U	ICC17V30
FERGUSON	M8421U	ICC17
FERGUSON	M8422U	ICC17V30
FERGUSON	S59N	ICC9
FERGUSON	S68N	ICC9
FERGUSON	T10R	TX90
FERGUSON	T49F	TX91
FERGUSON	T5173GF	TX91
FERGUSON	T7021U	ICC17
FERGUSON	T7025UD	ICC17V30
FERGUSON	W70201	TV17
FERGUSON	W7022U	ICC17V30
FERGUSON	W7023U	ICC17
FERGUSON	W8122U	ICC17V30
FIDELITY	CTV3014F	PT11
FINLUX	14A1TX	MONO PLUS2
FINLUX	14B59	MONO PLUS
FINLUX	26FL745	17MB15E5
FINLUX	28W35	EURO-DIGI 16/9
FINLUX	3024F	3000
FINLUX	3029U	3000
FINLUX	32W32	EURO-DIGI 16/9
FINLUX	3624	AB537

Brand	model	chassis
FINLUX	4028D	4000
FINLUX	5021A20GR	5000
FINLUX	5021A65	5000
FINLUX	5021F12	5000
FINLUX	5021F12GR	5000
FINLUX	5025E17	5000
FINLUX	5025F12	5000
FINLUX	5025F12GR	5000
FINLUX	5025K10	5000
FINLUX	5025K10GR	5000
FINLUX	5025M14	5000
FINLUX	5025N65	5000
FINLUX	5028E17	5000
FINLUX	5028F12	5000
FINLUX	5028F12GR	5000
FINLUX	5028K10	5000
FINLUX	5028K10GR	5000
FINLUX	5028M14	5000
FINLUX	5028N65	5000
FINLUX	5029A65	5000
FINLUX	5128	5100
FINLUX	51A1TX	MONO PLUS2
FINLUX	55A1TX	MONO PLUS2
FINLUX	55A5 TX	K (TV2K)
FINLUX	55Y2	STEREO PLUS
FINLUX	6000	FS 100Hz
FINLUX	63U1	FS
FINLUX	63Y2	STEREO PLUS
FINLUX	63Z2	FS
FINLUX	71U1	FS
FINLUX	71U2	FX (100Hz)
FINLUX	71V50	STEREO PLUS2 SN/SW
FINLUX	71Y2	STEREO PLUS
FINLUX	71Z1	FS
FINLUX	71Z2	FS

Brand	model	chassis
FINLUX	72F101MC 100Hz	MC2 (Multi Concept 2)
FINLUX	72F101MC 100Hz	TZ
FINLUX	72GF50++	G3_GW Safety++
FINLUX	72GF55++	G3_GW Safety++
FINLUX	72GF58++	G3_GW Safety++
FINLUX	72GX60++	G3_GW Safety++
FINLUX	72R100	MC2B
FINLUX	72X100MC 100Hz	MC2 (Multi Concept 2)
FINLUX	72X110MC 100Hz	TZ
FINLUX	74U1	FX (100Hz)
FINLUX	74U2	FX (100Hz)
FINLUX	80D28	4000
FINLUX	82F100VGA/PIP	EURO-DIGI 16/9
FINLUX	82F110MC 100Hz	MC2 (Multi Concept 2)
Firstline	BK70ES	14.2 (?)
FIRSTLINE	FS30V	17MB11
FISHER	CE27LF1	UB4B (SANYO)
FISHER	FT954DK	097
FISHER	FTM954DK/TXT	097
FISHER	FTM963DK	097
FISHER	FTS770	TV1
FISHER	FTS777	TV2
FISHER	FTS863D	089
FISHER	FTS865D	089
FISHER	FTS870D	089
FISHER	PC-R20R2	3Y03
FISHER	PC1500	A7Z
FORMENTI	CTV Exquisit 7971	F11-R5
FRABA	83/16-603	SCC113
FRABA	EC63303CTI	SCC103 (ELBIT)
FRABA	EC64303CTI	SCC103 (ELBIT)
FRABA	EC70303CTI	SCC103 (ELBIT)
FRESING	2135	K3720
FRISLINE	DTV5615	DTV1
FRONTECH	M1452R/TX	INDIANA

Brand	model	chassis
FRONTECH	M1552R/TX	INDIANA
FRONTECH	M2032R/TX	INDIANA
FRONTECH	M2033R	INDIANA
FRONTECH	M2132TX	INDIANA
FUJITSU	CT281	BS665
FUJITSU	GENERAL CT282D	BS950
FUNAI	14A0810	11AK36
FUNAI	14A7010	11AK36
FUNAI	14D0810	11AK36
FUNAI	14D4610	11AK36A15
FUNAI	21D3718	11AK30A14 !
FUNAI	29D0528HS	11AK53 (?)
FUNAI	29D8128F	11AK37 (?)
FUNAI	32A5128	11AK30
GALACTIC	21G180N	TV2KR (?)
GALAXIS	APOLLO	TESI2
GALAXIS	BEAMER3795	TESI2
GALAXIS	BEAMER5590	TESI2
GALAXIS	BEAMER5595	TESI2
GALAXIS	BEAMER7010	TESI2
GALAXIS	CTV5595	TESI2
GALAXIS	CTV7000-2	990 (IMPERIAL, SELECO)
GALAXIS	CTV7095	TESI3
GALAXIS	GTV7095	TESI4
GARZA	GA14LUXE N TXT SILVER/E190	CTU-AA
GARZA	GA14LUXE N TXT SILVER/E190	CTU-AA
GE	14GP220A	TX805
GENERAL ELECTRIC	13GP241	TX826TB
GENERAL ELECTRIC	20GT420	CTC146E
GENERAL ELECTRIC	GE2900ST	ICC17
GENERAL ELECTRIC	GE2910ST	M34 (TCL - Chiny)
GERMINA	GTV28821	PT92
GIGATRON	FS2860N	SM2 ?
GOLDSTAR	20A80	MC14A
GOLDSTAR	CB14A80	PC31A

Brand	model	chassis
GOLDSTAR	CB14E22X	PC31A
GOLDSTAR	CB20A80	PC31A
GOLDSTAR	CB20A80G	PC31A
GOLDSTAR	CB20A86	PC53A
GOLDSTAR	CB20E40	PC53A
GOLDSTAR	CB20F80X	PC81A
GOLDSTAR	CB21A30X	PC42A
GOLDSTAR	CB21C22Q	PC42C
GOLDSTAR	CB21T40X	GW01B
GOLDSTAR	CB2570X	PC12A
GOLDSTAR	CB25C20X	PC33A
GOLDSTAR	CB25C22X	PC33B
GOLDSTAR	CB25H30	PC8KA
GOLDSTAR	CB25H40E	PC8KA
GOLDSTAR	CB2870X	PC12A
GOLDSTAR	CB28C20X	PC33A
GOLDSTAR	CB28C22X	PC33A
GOLDSTAR	CB28C22X	PC33A
GOLDSTAR	CB28H80	PC8KA ?
GOLDSTAR	CB29H30	PC8KA
GOLDSTAR	CB29H40E	PC8KA
GOLDSTAR	CBS4341	PC04X
GOLDSTAR	CBS4361	PC04X
GOLDSTAR	CBS4441	PC04X
GOLDSTAR	CBS4521	PC04X
GOLDSTAR	CBS6081	PC04X
GOLDSTAR	CBT2125M	PC08X2
GOLDSTAR	CBT2135M	PC08X2
GOLDSTAR	CBT2138M	PC08X2
GOLDSTAR	CBT2162M	PC08X2
GOLDSTAR	CBT2165M	PC08X2
GOLDSTAR	CBT2172	PC07X2
GOLDSTAR	CBT2172M	PC07X2
GOLDSTAR	CBT2191F	PC04A
GOLDSTAR	CBT2552M	PC08X2L

Brand	model	chassis
GOLDSTAR	CBT2555M	PC08X2L
GOLDSTAR	CBT2570X	PC12A
GOLDSTAR	CBT2571X	PC12A
GOLDSTAR	CBT2870X	PC12A
GOLDSTAR	CBT2871X	PC12A
GOLDSTAR	CBT2876X	PC12A
GOLDSTAR	CBT4202E	PC04A
GOLDSTAR	CBT4282	PC04X ?
GOLDSTAR	CBT4342	PC04X
GOLDSTAR	CBT4441	PC04X
GOLDSTAR	CBT4442	PC04X
GOLDSTAR	CBT4522	PC04X
GOLDSTAR	CBT4825E	PC91A
GOLDSTAR	CBT4902	PC04A
GOLDSTAR	CBT4905	PC04A
GOLDSTAR	CBT6082	PC04X
GOLDSTAR	CBT6102	PC04X
GOLDSTAR	CBT9175	PC11A
GOLDSTAR	CBT9225	PC04X
GOLDSTAR	CBT9282E	PC07X2
GOLDSTAR	CBT9328	PC04X
GOLDSTAR	CBT9502X	PC08X8
GOLDSTAR	CBT9562E	PC07X2
GOLDSTAR	CBT9565E	PC07X2
GOLDSTAR	CBT9595	PC07X2
GOLDSTAR	CBT9742E	PC91A
GOLDSTAR	CBT9745E	PC91A
GOLDSTAR	CBT9902	PC04A
GOLDSTAR	CBZ2172E	PC08X8
GOLDSTAR	CBZ4102E	PC02X
GOLDSTAR	CBZ9222	PCPC04X
GOLDSTAR	CE20J3BGX	MC009A
GOLDSTAR	CE21M64KEX	MC019A
GOLDSTAR	CE21M66KX	MC019A
GOLDSTAR	CE21Q20ET	PC99DA

Brand	model	chassis
GOLDSTAR	CE21Q26KEX	MC007A
GOLDSTAR	CE21Q66ET	MC007B
GOLDSTAR	CE21S18ET	MC00AA
GOLDSTAR	CE21T28ET	MC00AA
GOLDSTAR	CE28H86ST	MC007A
GOLDSTAR	CE29Q20ET	MC993A (100Hz)
GOLDSTAR	CF14E40	MC64A
GOLDSTAR	CF2021	MC84
GOLDSTAR	CF20B70B	MC41A
GOLDSTAR	CF20D16R	MC64A
GOLDSTAR	CF20D20X	MC64B
GOLDSTAR	CF20D29	MC64B
GOLDSTAR	CF20D30RX	MC64B
GOLDSTAR	CF20D70X	MC64A
GOLDSTAR	CF20E60X	MC64A
GOLDSTAR	CF20K49E	M994A
GOLDSTAR	CF21A20X	MC46A
GOLDSTAR	CF21A50	PC58B
GOLDSTAR	CF21C22X	MC46A
GOLDSTAR	CF21C28F	PC58B
GOLDSTAR	CF21D29	MC64B
GOLDSTAR	CF21D30RX	MC64B
GOLDSTAR	CF21D70DX	MC64A
GOLDSTAR	CF21D70X	MC64A
GOLDSTAR	CF21D73	MC84A
GOLDSTAR	CF21E60X	MC64A
GOLDSTAR	CF21G20X	MC64A
GOLDSTAR	CF21K40X	MC84A
GOLDSTAR	CF21K44X	PC81B ?
GOLDSTAR	CF21K49E	M994A
GOLDSTAR	CF21S14ET	MC84A
GOLDSTAR	CF21T20K	MC019A
GOLDSTAR	CF25A50F	PC58A
GOLDSTAR	CF25A50T	PC58A
GOLDSTAR	CF25A52L	PC58A

Brand	model	chassis
GOLDSTAR	CF25A56T	PC73A
GOLDSTAR	CF25A64DF	PC73A
GOLDSTAR	CF25A64T	PC73A
GOLDSTAR	CF25C10P	MC15A
GOLDSTAR	CF25C22F	PC33J
GOLDSTAR	CF25C44	MC51A
GOLDSTAR	CF25H40T	PC8KA
GOLDSTAR	CF25H41T	MC74A
GOLDSTAR	CF28A100L	PC63A ?
GOLDSTAR	CF28A50F	PC58A
GOLDSTAR	CF28A50I	PC58A
GOLDSTAR	CF28A50I	PC63A (100Hz)
GOLDSTAR	CF28A56T	PC73A
GOLDSTAR	CF28A60I	PC63A
GOLDSTAR	CF28A64DT	PC73A
GOLDSTAR	CF28A64T	PC73A
GOLDSTAR	CF28C22F	PC33J
GOLDSTAR	CF29C20T	PC33J
GOLDSTAR	CF29C42F	PC33J
GOLDSTAR	CF29H40T	PC8KA
GOLDSTAR	CF29Q10ET	MC991A
GOLDSTAR	CF29V10KT	MD66A
GOLDSTAR	CFZ2588	MC05A
GOLDSTAR	CI14E20F	PC53A
GOLDSTAR	CI20A90F	PC31A
GOLDSTAR	CI20C22F	PC42B
GOLDSTAR	CI20E20	PC53A
GOLDSTAR	CI21C22	PC42B
GOLDSTAR	CI21Q20ET	PC99DA
GOLDSTAR	CI21T20F	PC81B
GOLDSTAR	CI25H40E	PC8KA
GOLDSTAR	CI29H40E	PC8KA
GOLDSTAR	CIT2170F	PC12B
GOLDSTAR	CIT9742	PC91A
GOLDSTAR	CIT9745	PC91A

Brand	model	chassis
GOLDSTAR	CK14A80X	PC31A
GOLDSTAR	CK14J70	GW01A
GOLDSTAR	CK20A80X	PC31A
GOLDSTAR	CK20A90X	PC31A
GOLDSTAR	CK21A80X	PC31A
GOLDSTAR	CK21A90X	PC31A
GOLDSTAR	CK21C24X	MC56A
GOLDSTAR	CK21D10X	PC31A
GOLDSTAR	CK21D60X	MC64A
GOLDSTAR	CK21D62X	PC31A
GOLDSTAR	CK21K44EX	PC81B ?
GOLDSTAR	CK21Q20ET	PC99DA
GOLDSTAR	CK21Q20ET	PC99DA
GOLDSTAR	CK21T20X	PC81A
GOLDSTAR	CK21T24EX	PC81B
GOLDSTAR	CKT2128B	PC05X2
GOLDSTAR	CKT2135	PC08X8
GOLDSTAR	CKT2168X	PC04A
GOLDSTAR	CKT2172M	PC07X2
GOLDSTAR	CKT2570	PC12A
GOLDSTAR	CKT2871	PC12A
GOLDSTAR	CKT4442B	PC05X2
GOLDSTAR	CKT4742	PC91A
GOLDSTAR	CKT4822	PC91A
GOLDSTAR	CKT9322	PC08X8
GOLDSTAR	CKT9322B	PC05X2
GOLDSTAR	CKT9742	PC91A
GOLDSTAR	CKT9745	PC91A
GOLDSTAR	CKT9822	PC91A
GOLDSTAR	CKT9825	PC91A
GOLDSTAR	CL20A80	PC36A ?
GOLDSTAR	CL20D62X	PC53A
GOLDSTAR	CL21Q20ET	PC99DA
GOLDSTAR	CL28C22 N	MC56A
GOLDSTAR	CL29N32X	PC8KA

Brand	model	chassis
GOLDSTAR	CL29N42X	PC8KA
GOLDSTAR	CLT2190	PC09A
GOLDSTAR	CMS4841	NC91A
GOLDSTAR	CN14A41	NC12J
GOLDSTAR	CN20A30	NC4JA
GOLDSTAR	CN20A41	NC12J
GOLDSTAR	CN21B6Q	NC44A
GOLDSTAR	CN26B46	NC44A
GOLDSTAR	CN29D70	NC57A
GOLDSTAR	CNT2197	MC97A
GOLDSTAR	CNT4825	MC97A
GOLDSTAR	CNT4882	MC97A
GOLDSTAR	CNT4885	MC97A
GOLDSTAR	CNT9175	MC97A
GOLDSTAR	CNT9762	MC97A
GOLDSTAR	CNT9765	MC97A
GOLDSTAR	CNT9825	MC97A
GOLDSTAR	CNT9905	MC97A
GOLDSTAR	CNZ4172/5	MC14A (?)
GOLDSTAR	CNZ9172/5	MC14A (?)
GOLDSTAR	CP14D60H	MC58A
GOLDSTAR	CP20A82	MC14 (?)
GOLDSTAR	CP20D90	MC6GA
GOLDSTAR	CP20D90M	MC83A
GOLDSTAR	CP21A90	MC41A
GOLDSTAR	CT20F35	MC049B
GOLDSTAR	CT21D31KE	MC019A
GOLDSTAR	CT21Q45VE	MC049B
GOLDSTAR	CT21Q46ET	MC007A
GOLDSTAR	CT21Q47ET	MC007B
GOLDSTAR	CT21Q66KEX	MC019A
GOLDSTAR	CT21Q92KEX	MC019A
GOLDSTAR	CT25K90VE	M022A
GOLDSTAR	CT25K95VE	MC049A
GOLDSTAR	CT29Q46ET	MC007A

Brand	model	chassis
GOLDSTAR	CT29Q91RB	MC021A
GOLDSTAR	CTV2197	MC97A
GOLDSTAR	CY20B70Y	MC41A
GOLDSTAR	DT7060	PC63A
GOLDSTAR	GCT1904MN	NC4JA
GOLDSTAR	GCT1954M	NC36A
GOLDSTAR	GCT1954MN	NC4JA
GOLDSTAR	GCT2505M	NC44A
GOLDSTAR	GCT2515	MC44A ?
GOLDSTAR	GF29V10KT	MD66A
GOLDSTAR	KB14V30	MV55A
GOLDSTAR	KE14P21B	MV025A, DECK D33
GOLDSTAR	KE14U43	MV995A
GOLDSTAR	KE14U73	MV995A
GOLDSTAR	KE20U73	MV995A
GOLDSTAR	KF14U40	MV64A
GOLDSTAR	KF14U42	MV64A
GOLDSTAR	KF14U70	MV64A
GOLDSTAR	KF20U40	MV64A
GOLDSTAR	KF20U42	MV64A
GOLDSTAR	KF20U70	MV64A
GOLDSTAR	KF21U40	MV64A
GOLDSTAR	KF21U42	MV64A
GOLDSTAR	KF21U70	MV64A
GOLDSTAR	KK14V20	PC32A
GOLDSTAR	KK20V20	PC32A
GOLDSTAR	KK21V20	PC32A
GOLDSTAR	KKV2102	PS14A
GOLDSTAR	KKV9012	PG08X8
GOLDSTAR	KV14V3	MV55A
GOLDSTAR	MZ40PA10	MP00MB
GOLDSTAR	PE43A82T	MP015A
GOLDSTAR	PE48A82T	MP015A
GOLDSTAR	PE53A82T	MP015A
GOLDSTAR	PF42A20	MP87B

Brand	model	chassis
GOLDSTAR	PL43A82T	MP015A
GOLDSTAR	PL48A82T	MP015A
GOLDSTAR	PL53A82T	MP015A
GOLDSTAR	PT44NA41T	MP015A
GOLDSTAR	RE15LA30	MF004A
GOLDSTAR	RE28FZ10	MC017A
GOLDSTAR	RE29FA34RX	MC036A
GOLDSTAR	RF29FB51RQ	MC036A
GOLDSTAR	RT20CA75M	MC049B
GOLDSTAR	RT21CA60M	MC019A
GOLDSTAR	RT21CA70M	MC019A
GOLDSTAR	RT21FA76X	MC019A
GOLDSTAR	RT25FB30M	MC022A
GOLDSTAR	RT29FA30RU	MC022A
GOLDSTAR	RT44NA11T	MP015A
GOLDSTAR	RT49NA11T	MP015A
GOLDSTAR	RT54NA11T	MP015A
GOLDSTAR	RZ21FB55RX	MC049B
GOLDSTAR	TX29AD30C	MC52B
GOLDSTAR	WF32A12T	MC52C
GOLDSTAR	WF32A30D	MC75A
GOLDSTAR ART.B	CKT9742	PC91A
GOODMANS	1410	TX805
GOODMANS	1425RS	CP375
GOODMANS	1475TS	CP375
Goodmans	1476TS	CP005
GOODMANS	14T1	CP370
GOODMANS	2025RS	CP375
GOODMANS	2045TS	CP375
GOODMANS	2066TS	CP005
GOODMANS	20T1	CP370
GOODMANS	2145TS	CP375
GOODMANS	215N	CP365
GOODMANS	21T1	CP370
GOODMANS	255NS	CP775

Brand	model	chassis
Goodmans	2575	F11
Goodmans	2575H	F11
GOODMANS	285NS	CP775
GOODMANS	286NS	L6.3
GOODMANS	286NS SL6.3AA	L6.3AA
Goodmans	2875	F11
Goodmans	2875H	F11
GOODMANS	2880	ICC9
GOODMANS	2880	TX92
GOODMANS	289NS	CP785
GOODMANS	3045TS	CP375
GOODMANS	336NS	F16
Goodmans	3375	F11
Goodmans	3375-H	F11
GOODMANS	CTV3409	11AK08
GOODMANS	CTV3459	11AK08
GOODMANS	GD2500	TX92
GOODMANS	GTV147	11AK08-9A
GOODMANS	GTV148T	11AK08
GOODMANS	GTV14DVDXI	11AK46
GOODMANS	GTV34R3DVD	P1420
GOODMANS	GTV69W3	11AK19
GOODMANS	GTV76W3SIL	11AK37
Goodmans	GTV76W4SIL	11AK37
Goodmans	SAL428/3P200	F19
GOODMANS	TDG3B9RL	P1420
GOODMANS	TV-C1400	CP310
GOODMANS	TVC143TS	CP082
GOODMANS	TVC14VP	CP310
GOODMANS	TVG142T	12.6 (BEKO)
GOODMANS	W280NS	F16
GOODMANS	W288NS	F16 or F19 (depends on the year)
GOODMANS	W321NS	F16
GORENJE		BC10
GORENJE		E9 ?

Brand	model	chassis
GORENJE	630B/DX807C EX	TX807C EU
GORENJE	Art Line	E5
GORENJE	Mercury	E5
GORENJE	Sof Line	E5
GORENJE	Tip 630B/TX807C EX--TVC21MT	TX807C EU
GORENJE	TV856	E9
GORENJE	TVF29V15	11AK45
GORENJE	Voyager	E5
GORIZONT	51CTV664	11AK19S
GORIZONT	51CTV678	12.6 (BEKO)
GORIZONT	54CTV664	11AK19S
GORIZONT	54CTV730T1	SZC730
GORIZONT	54CTV732T	SZC730 ?
GRAETZ	2155VTEE	COMPACT D-E
GRAETZ	4207	MONOPRINT A
GRAETZ	4226	PICO S/3
GRAETZ	4319K	Corekit 2 NN
GRAETZ	4325	PICO S/3
GRAETZ	4568	COMPACT D S4 SQ
GRAETZ	4578	Digital B 110 FST
GRAETZ	4598	Digital B 110 FST
GRAETZ	761 Margraf 2541 54343171	CORE2 110° PS SVHS28KU
GRAETZ	AT37T	TV84
GRAETZ	BARONESS COLOR 4227	MONOPRINT B
GRAETZ	BT74SN	11AK19P4
GRAETZ	Burggraf Stereo 4878 Digivision	DIGITAL B 110°
GRAETZ	CT37	SM2 ?
GRAETZ	CTCAT37	TV84
GRAETZ	CTV-A63	patrz: Royal-Lux TV7199
GRAETZ	CTV-A63SN	11AK19P4
GRAETZ	CTV-A63SN	patrz: Royal-Lux TV7199
GRAETZ	CTV-A70	E5
GRAETZ	CTV-A70SN	11AK19
GRAETZ	CTV-A70SN	11AK19 !
GRAETZ	CTV-AT37T	TV84A

Brand	model	chassis
GRAETZ	CTV-AT37T	TV84A v. C
GRAETZ	CTV-BT55T	SM2 ?
GRAETZ	CTV-BT74SN	11AK19A ???
GRAETZ	CTV-BT74SN	11AK19P4
GRAETZ	CTV-CT37T	11AK20S-E ?
GRAETZ	CTV-CT37T	TV83
GRAETZ	CTV-GM72TS	11AK19 ?
GRAETZ	CTV-XM51T	11AK19PRO
GRAETZ	CTV-XM66M	11AK19E3
GRAETZ	CTV-XM72TS	11AK19E3
GRAETZ	CTV-XM72TS	11AK19P4
GRAETZ	CTV-XT55T	11AK19E3 ? (CP776 ?)
GRAETZ	CTVAT37T	TV84A
GRAETZ	CTVBT74SN	11AK19P4
GRAETZ	DIGIVISION Consul Stereo 4578I	DIGITAL B 110° FST
GRAETZ	DIGIVISION Kongress Stereo 4598	DIGITAL B 110° FST
GRAETZ	DIGIVISION Peer Stereo 4598	DIGITAL B 110° FST
GRAETZ	GR29PFT33	20.2 (100Hz) (BEKO)
GRAETZ	GR29T24S	20.2 (100Hz) (BEKO)
GRAETZ	GR32SFT26	20.2 (100Hz) (BEKO)
GRAETZ	GR32T21S	20.2 (100Hz) (BEKO)
GRAETZ	GR33B2/P	14.1 (BEKO)
GRAETZ	GR33TL6S	20.2 (100Hz) (BEKO)
GRAETZ	KOMTESS 4327	MONOPRINT B
GRAETZ	TVA70SN	11AK19P4 ?
GRANADA	C59HZ6	STB361 (SB1365B)
GRAND PRIX	STV70-205FST	PT200 ?
GRAND PRIX	STV710-16TF	TV2
GRAND PRIX	STV74-100TF	PT100 (100Hz)
GRANDIN	36CMM30	CTE-AA
Grandin	63BS94	K6301
GRANDIN	70BSA06	F19
GRANDIN	NR36MM	12.1 (BEKO)
GRANDIN	STV2820	K110
GRUNDIG	14GR3000	(VMC294B)

Brand	model	chassis
GRUNDIG	24FKA-WF56	PCB2550
GRUNDIG	28BKN T70-1020	4400 PROFESSIONAL (PCB: 4410)
GRUNDIG	28WF100	8500 PROFESSIONAL (PCB8500)
GRUNDIG	32EKH	2500 PROFESSIONAL
GRUNDIG	32LXW82-8695REF	D32IE11
GRUNDIG	32WF8000	2500 PROFESSIONAL
GRUNDIG	337-4204 TOP	12.5 (BEKO)
GRUNDIG	42PW110-5501 TOP	P6
GRUNDIG	42PW110-6611 TOP	PE
GRUNDIG	8145	GSC600
GRUNDIG	8245	GSC600
GRUNDIG	8445	GSC600
GRUNDIG	8445GB	GSC600
GRUNDIG	8645	GSC600
GRUNDIG	8845	GSC600
GRUNDIG	8945	GSC600
GRUNDIG	A6700/2/3/4	CUC220 Stereo
GRUNDIG	A6781/2	CUC220 Stereo
GRUNDIG	A7700/2/3 KT	CUC220 Stereo
GRUNDIG	A7701/2/3 W	CUC220 Stereo
GRUNDIG	A7710/2/3	CUC220 Stereo
GRUNDIG	AGANTO40 RPW102-6410/8 Top	PE5 (100Hz)
GRUNDIG	AGANTO43 RPW102-6410/8 Top	PE5 (100Hz)
GRUNDIG	Amalienburg 8276	GSC700
GRUNDIG	Amira 26LW68-7510	L6B (BEKO)
GRUNDIG	Amira 32LXW82-7515	L6B
GRUNDIG	Amira LW68-9410 TOP	L6B
GRUNDIG	Amira15--LCD38-7510 TOP	L5A (BEKO)
GRUNDIG	Amira17--LW45-7510 TOP	L5A (BEKO)
GRUNDIG	Amira20--LCD51-7510 TOP	L5A (BEKO)
GRUNDIG	Amira23--LW60-7510 TOP	L6B (BEKO)
GRUNDIG	Amira23--LW60-7510 TOP	L6B (BEKO)
GRUNDIG	Amira26--LW68-7505BS	L6B (BEKO)
GRUNDIG	Amira26--LW68-7510 TOP	L6B (BEKO)
GRUNDIG	Amira26--LW68-7510 TOP	L6B (BEKO)

Brand	model	chassis
GRUNDIG	AMIRA26--LW68-9410 TOP	L6B (BEKO)
GRUNDIG	Amira26--LXW68-7515REF	L6B (BEKO)
GRUNDIG	Amira32--LW82-7505BS	L6B (BEKO)
GRUNDIG	Amira32--LXW82-7510 TOP	L6B (BEKO)
GRUNDIG	Amira32--LXW82-7510 TOP	L6B (BEKO)
GRUNDIG	Amira32--LXW82-7512REF	L6B (BEKO)
GRUNDIG	Amira32--LXW82-7515REF	L6B (BEKO)
GRUNDIG	Apollo 42PW110-7505 TOP	P7 (Beko)
GRUNDIG	Apollo 42PW110-7510 TOP	P7 (Beko)
GRUNDIG	Apollo 42PW110-7605 TOP	P7 (Beko)
GRUNDIG	Apollo 42PXW110-7515 REF	P7 (Beko)
GRUNDIG	Arcance 55 Flat MF55-2502 IT/Ton	K1 (Beko)
GRUNDIG	Arcance 55 Flat MF55-2502 Top	K5 (KX1.190-09) (Beko)
GRUNDIG	Arcance 55 Flat MF55-2502/8 ER/Ton	K1 (Beko)
GRUNDIG	Arcance 55 Flat MF55-2502/8 Ton	K1 (Beko)
GRUNDIG	Arcance 55 Flat--MF55-2502 IT/Ton	K1 (Beko)
GRUNDIG	Arcance 55 Flat--MF55-2502 Top	K1 (Beko)
GRUNDIG	Arcance 55 Flat--MF55-2502/8 ER/Ton	K1 (Beko)
GRUNDIG	Arcance 55 Flat--MF55-2502/8 Ton	K1 (Beko)
GRUNDIG	ARCANCE 70 Flat MFW70- 2410/7 Dolby	22.1 (Beko)
GRUNDIG	ARCANCE 70 Flat MFW70- 2410/IT Dolby	22.1 (Beko)
GRUNDIG	Arcance 72 Flat	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ARCANCE 72 Flat MF72-2410/7 Ton	22.1 (Beko)
GRUNDIG	ARCANCE 72 Flat MF72-2410/IT Ton	22.1 (Beko)
GRUNDIG	ARCANCE 82 Flat MFW82- 2410/7 Dolby	22.1 (Beko)
GRUNDIG	ARCANCE 82 Flat MFW82- 2410/7 DOLBY	22.1 (Beko)
GRUNDIG	ARCANCE 82 Flat MFW82- 2410/IT Dolby	22.1 (Beko)
GRUNDIG	ARCANCE55 Flat MF55-2401 ER/Ton	16.1 (Beko)
GRUNDIG	ARCANCE55 Flat MF55-2401/7 TON	16.1 (Beko)
GRUNDIG	ARCANCE55 Flat MF55- 2401IT/Ton	16.1 (Beko)
GRUNDIG	ARCANCE55 Flat MF552401/5 TON	16.1 (Beko)
Grundig	Arganto 43 RP110-6410/8	PE5 (?)
GRUNDIG	ATHEN 1655 TEXT	CUC6300
GRUNDIG	ATHEN 455	CUC3400
GRUNDIG	ATHEN 555 TEXT	CUC4400

Brand	model	chassis
GRUNDIG	ATHEN 655 TEXT	CUC5301
GRUNDIG	ATHEN 755 TOP	CUC7300
GRUNDIG	ATLANTA SE7289 IDTV	CUC1826
GRUNDIG	ATLANTA SE7289 IDTV	CUC1826
GRUNDIG	ATLANTA ST1570PIP/TOP	CUC4511
GRUNDIG	ATLANTA72 IDTV	CUC1852M
GRUNDIG	ATLANTA72IDTV	CUC1852M
GRUNDIG	B7800/1/2/4/7 KT	CUC740
GRUNDIG	B7801/1/2/4 W KT	CUC740
GRUNDIG	B7881/1/3/4 KT	CUC740
GRUNDIG	B7890/3/4/8/9 KT	CUC740
GRUNDIG	B8800/2/4/7 KT	CUC740
GRUNDIG	B8801/2/4 W KT	CUC740
GRUNDIG	B8802/3/4 VC KT	CUC740
GRUNDIG	B8802W	CUC740
GRUNDIG	B8806	CUC740
GRUNDIG	B8810/2/4 KT	CUC740
GRUNDIG	B8820/2/4 KT	CUC740
GRUNDIG	B8830/2	CUC740
GRUNDIG	B8881/3/4 KT	CUC740
GRUNDIG	B8890/3/4/8/9 KT	CUC740
GRUNDIG	BERLIN SE7290 IDTV/LOG	CUC1822
GRUNDIG	BERLIN SE7290 IDTV/LOG	CUC1822
GRUNDIG	BOSTON SE7015 DOLBY	CUC1837 (DIGI100)
GRUNDIG	BOSTON SE7072/7 Dolby	22.1 (Beko)
GRUNDIG	BOSTON ST270 IDTV	CUC1825
GRUNDIG	BOSTON ST270 IDTV	CUC1825
GRUNDIG	C7400	CUC70
GRUNDIG	C7410	CUC70
GRUNDIG	C7460	CUC70
GRUNDIG	C8400	CUC70
GRUNDIG	C8402	CUC70
GRUNDIG	C8410	CUC70
GRUNDIG	C8420	CUC70
GRUNDIG	C8460	CUC70

Brand	model	chassis
GRUNDIG	C8510	CUC70
GRUNDIG	C8510	CUC70
GRUNDIG	C8802W	CUC741
GRUNDIG	Cinaro 26--LXW68-6612REF	LM
GRUNDIG	Cinaro 26--LXW68-6612REF	LM
GRUNDIG	Cinaro 32--LXW82-6612REF	LM
GRUNDIG	Cinaro 32--LXW82-6612REF	LM
GRUNDIG	CINARO 70 Flat MFW 70-5410/7 Dolby	22.1 (BEKO)
GRUNDIG	CINARO 70 Flat MFW70-5411/7 Dolby/PIP	22.1 (BEKO)
GRUNDIG	Cinaro 70--MFW70-5410/7	22.1 (BEKO)
GRUNDIG	CINARO 72 Flat MF72-5410 TOP	22.1 (BEKO)
GRUNDIG	CINARO 72 Flat MF72-5410/7 Ton	22.1 (BEKO)
GRUNDIG	CINARO 82 Flat MFW82-5410/7 DOLBY	22.1 (BEKO)
GRUNDIG	CINEMA 9060 MULTISYSTEM	CUC841
GRUNDIG	CINEMA 9080 MULTISYSTEM	CUC820
GRUNDIG	Cinemo32--LXW82-8735REF	LC32IEA2
GRUNDIG	COPENHAGEN ST763 TOP	CUC6360
GRUNDIG	Davio 14 P37-4501 FR/TEXT	E1 (BEKO)
GRUNDIG	Davio 14 T37-4501 TEXT	E1 (BEKO)
GRUNDIG	Davio 14 T37-4501/5 TEXT	E1 (BEKO)
GRUNDIG	DAVIO 14TVD2401	D5 ?
GRUNDIG	DAVIO 14TVD37-2401 TEXT	D5
GRUNDIG	Davio 20 T51-4501 TEXT	E1 (BEKO) (wg opisu na płycie: E4)
GRUNDIG	Davio 21 T55-4501 TEXT	E1 (BEKO)
GRUNDIG	Davio 21 T55-4501/5 TEXT	E1 (BEKO)
GRUNDIG	DAVIO 37	12.5 (BEKO)
GRUNDIG	Davio 37 P37-830 TEXT/1	CUC7303
GRUNDIG	Davio 37 P37-830/5 TEXT	CUC7303
GRUNDIG	DAVIO 70 ST70-2210 DOLBY	CUC1837 (DIGI100)
GRUNDIG	DAVIO 70 ST70-5210/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	Davio26--LW68-4501 TOP	L6B (BEKO)
GRUNDIG	DAVIO37 P37-2401 TEXT	E1 (Z50.190-05) (BEKO)
GRUNDIG	DAVIO37 P37-2401/5 TEXT	E1 (Z50.190-05) (BEKO)
GRUNDIG	DAVIO37 P37-4201 TOP	E1 (Z50.190-05) (BEKO)
GRUNDIG	DAVIO37 P37-4201/5 TOp	E1 (Z50.190-05) (BEKO)

Brand	model	chassis
GRUNDIG	DAVIO37 P37-4501 FR/TEXT	E1 (Z50.190-05) (BEKO)
GRUNDIG	DAVIO51 T51-2401 TEXT	E1 (Z50.190-05) (BEKO)
GRUNDIG	DAVIO51 T51-4201 TOP	E1 (Z50.190-05) (BEKO)
GRUNDIG	DAVIO51 T51-4201/5 TOp	E1 (Z50.190-05) (BEKO)
GRUNDIG	Davio55 T55-2401 TEXT	E1 (Z50.190-05) (BEKO)
GRUNDIG	Davio55 T55-4201 TOP	E1 (Z50.190-05) (BEKO)
GRUNDIG	Davio55 T55-4201/5 TOp	E1 (Z50.190-05) (BEKO)
GRUNDIG	E55-700 TOP	CUC6450
GRUNDIG	E63-911 IDTV	CUC1852
GRUNDIG	E72-170 IDTV	CUC1822
GRUNDIG	E72-611DPL	CUC7861
GRUNDIG	E72-911 IDTV	CUC1852
GRUNDIG	Einschaub-Super Color 8276	GSC700
GRUNDIG	Elegance 21 Flat TVD55-2401/5 Ton	D5
GRUNDIG	Elegance 21 Flat--TVD55-2502 FR/Ton	K5 (KX1.190)
GRUNDIG	Elegance 21 Flat--TVD55-2502/5 Ton	K5 (KX1.190)
GRUNDIG	Elegance 21 Flat--TVD55-2503/7 Ton	K5 (KX1.190)
GRUNDIG	Elegance 55 Flat MF55-2502 Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat MF55-2502/5 SK/Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat MF55-2502/5 Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat MF55-2502/8 FR/Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat MF55-2503/8 PI /Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat MF55-2503/8 Ton	K1 (BEKO)
GRUNDIG	ELEGANCE 55 Flat MF55-2501 TOP	16.1 (BEKO)
GRUNDIG	ELEGANCE 55 Flat MF55-2501/5 TOn	16.1 (BEKO)
GRUNDIG	ELEGANCE 55 Flat MF55-2501/7 TOn	16.1 (BEKO)
GRUNDIG	Elegance 55 Flat--MF55-2502 Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat--MF55-2502/5 SK/Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat--MF55-2502/5 Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat--MF55-2502/8 FR/Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat--MF55-2503/8 PI /Ton	K1 (BEKO)
GRUNDIG	Elegance 55 Flat--MF55-2503/8 Ton	K1 (BEKO)
GRUNDIG	ELEGANCE 63 ST63-305/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ELEGANCE 70	CUC2069N
GRUNDIG	ELEGANCE 70 ST70-305/8 DOLBY	CUC1837 (DIGI100)

Brand	model	chassis
GRUNDIG	Elegance 70 Flat	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ELEGANCE 70 FLAT	CUC2069N
GRUNDIG	ELEGANCE 70 FLAT MFW70-3210/8 DOLBY	CUC1934 (DIGI100)
GRUNDIG	ELEGANCE 70 Flat MFW70-2510/8 Dolby	22.1 (BEKO)
GRUNDIG	Elegance 72 Flat	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ELEGANCE 72 FLAT MF72-3115/8 DOLBY	CUC1838 (DIGI100)
GRUNDIG	ELEGANCE 72 Flat MF72-2510/8 Ton	22.1 (BEKO)
GRUNDIG	Elegance 82 Flat	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ELEGANCE 82 Flat MFW82-2510/8 Dolby	22.1 (BEKO)
GRUNDIG	ELEGANCE15Flat MF40-2501 ER/TEXT	E1 (Z50.190-05) (BEKO)
GRUNDIG	ELEGANCE15Flat MF40-2501 TEXT	E1 (Z50.190-05) (BEKO)
GRUNDIG	ELEGANCE15Flat MF40-2501/5 TEXT	E1 (Z50.190-05) (BEKO)
GRUNDIG	ELEGANCE70 ST70-900 DOLBY	CUC2032
GRUNDIG	Elegance72 Flat--MF72-2501/8	C8 ! (ZX8.190-09)
GRUNDIG	Eleganz 8275	GSC700
GRUNDIG	F3026	CUC70
GRUNDIG	GR1450	CA2
GRUNDIG	GR1455	CA2
GRUNDIG	GR2150	CA2
GRUNDIG	Greenville 7009/5 Top	C7-C8 (C7/C8) (BEKO)
GRUNDIG	Greenville7008/5 TOP	14.2 (BEKO)
GRUNDIG	GRENVILLE 37SP737 TEXT	CUC7350
GRUNDIG	GRENVILLE 55T5574 TOP	CUC7300
GRUNDIG	GRENVILLE 7002 TEXT	CUC6330
GRUNDIG	GRENVILLE 7003NIC	CUC2030
GRUNDIG	GRENVILLE 7004NIC	CUC2050
GRUNDIG	GRENVILLE 7004NIC/TOP	CUC2050N
GRUNDIG	GRENVILLE 7005 TOP	CUC2032
GRUNDIG	GRENVILLE 7006 DOLBY	CUC2032
GRUNDIG	GRENVILLE 7006DOLBY	CUC2032
GRUNDIG	GRENVILLE 7007 DOLBY	CUC2130
GRUNDIG	GRENVILLE 7007DOLBY	CUC2130
GRUNDIG	GRENVILLE SP737 TEXT	CUC7350
GRUNDIG	INDIA ST25-8210/6NT	CUC2040
GRUNDIG	INDIA ST28-8210/6NT	CUC2040

Brand	model	chassis
GRUNDIG	INSBRUCK 2426A	CUC2400
GRUNDIG	K15PF-2503 FR/TEXT	E1 (BEKO)
GRUNDIG	K21PFC2503 FR/Top	K5 (KX1.190)
GRUNDIG	K21PFC2602TXT	K21 ? (GML2200)
GRUNDIG	LEEMAXX 37	12.5 (BEKO)
GRUNDIG	LEEMAXX 37 P37-4201 TOP	12.5 (BEKO)
GRUNDIG	LEEMAXX 72 FLAT MF72-9115/8 DOLBY	CUC1838 (DIGI100)
GRUNDIG	Lenaro 27--LXW70-7731 IDTV	LM
GRUNDIG	Lenaro 27--LXW70-7731 IDTV	LM
GRUNDIG	Lenaro 27--LXW70-8630 IDTV	LM
GRUNDIG	Lenaro 27--LXW70-8630 IDTV	LM
GRUNDIG	Lenaro 32--LXW82-7615 Top	LM
GRUNDIG	Lenaro 32--LXW82-7615 Top	LM
GRUNDIG	Lenaro 32--LXW82-7731 IDTV	LM
GRUNDIG	Lenaro 32--LXW82-7731 IDTV	LM
GRUNDIG	Lenaro 32--LXW82-8630 IDTV	LM
GRUNDIG	Lenaro 32--LXW82-8630 IDTV	LM
GRUNDIG	Lenaro 70 Flat--MFW70-5610 REF	22.1 (BEKO)
GRUNDIG	Lenaro 72 Flat--MF72-5610 REF	22.1 (BEKO)
GRUNDIG	Lenaro 82 Flat--MFW82-5610 REF	22.1 (BEKO)
GRUNDIG	Lenaro 92 MFW92-6110/9 DVD	CUC1937
GRUNDIG	Lenaro26--LXW68-7731 IDTV	LM (Beko)
GRUNDIG	Lenaro26--LXW68-8720 DOLby	LE
GRUNDIG	LENARO27 LXW70-8620 DOLby	LE (LW7.190-...) (BEKO)
GRUNDIG	Lenaro27--LXW70-8620 DOLby	LE
GRUNDIG	Lenaro32--LXW82-7610 Top	L6B (BEKO)
GRUNDIG	Lenaro32--LXW82-8620 DOLby	LE
GRUNDIG	Lenaro32--LXW82-8720 DOLby	LE
GRUNDIG	LISSABON ST555 TEXT	CUC4500
GRUNDIG	LXW68-7512REF	L6B (BEKO)
GRUNDIG	M169-92 IDTV	CUC1891
GRUNDIG	M4041 CTI	CUC2401
GRUNDIG	M45-775 TOP	CUC5350
GRUNDIG	M50-775 TOP	CUC5350
GRUNDIG	M55-105 IDTV	CUC1800

Brand	model	chassis
GRUNDIG	M55-105IDTV	CUC1800
GRUNDIG	M55-280/8 IDTV	CUC1806
GRUNDIG	M55-280/8 IDTV	CUC1806
GRUNDIG	M55-280/8 IDTV/LOG	CUC1805
GRUNDIG	M55-290/8 IDTV	CUC1806
GRUNDIG	M55-355CTI	CUC3510
GRUNDIG	M55-420/8 DOLBY	CUC1807
GRUNDIG	M55-420/8 DOLBY	CUC1807
GRUNDIG	M55-4210 DOLBY	CUC1807
GRUNDIG	M55-4210 DOLBY	CUC1807
GRUNDIG	M55-575 TEXT	CUC5820
GRUNDIG	M55-575A TEXT	CUC4510
GRUNDIG	M55-675 TOP	CUC5360
GRUNDIG	M55-775 TOP	CUC5360
GRUNDIG	M55-911NIC	CUC4510
GRUNDIG	M61-1690 DPL	CUC6469
GRUNDIG	M61-1690 TOP/LOG	CUC6369
GRUNDIG	M63-105 IDTV	CUC1822
GRUNDIG	M63-105IDTV	CUC1822
GRUNDIG	M63-115 IDTV	CUC1822
GRUNDIG	M63-115IDTV	CUC1822
GRUNDIG	M63-270 CTI	CUC2600
GRUNDIG	M63-280 IDTV	CUC1825
GRUNDIG	M63-280 IDTV	CUC1825
GRUNDIG	M63-281 IDTV	CUC1826
GRUNDIG	M63-281 IDTV	CUC1826
GRUNDIG	M63-281 IDTV	CUC1836
GRUNDIG	M63-281 IDTV	CUC1836
GRUNDIG	M63-281 IDTV/LOG	CUC1826
GRUNDIG	M63-281 IDTV/LOG	CUC1836 ?
GRUNDIG	M63-281/8 IDTV/LOG	CUC1826
GRUNDIG	M63-370 CTI	CUC3600
GRUNDIG	M63-375CTI	CUC3600
GRUNDIG	M63-400/8	CUC1836
GRUNDIG	M63-400/8	CUC1836

Brand	model	chassis
GRUNDIG	M63-420/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	M63-420/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	M63-470 CTI	CUC3600
GRUNDIG	M63-475/9 TEXT	CUC3600
GRUNDIG	M63-475CTI	CUC3600
GRUNDIG	M63-476 NIC	CUC4620
GRUNDIG	M63-555	CUC4510
GRUNDIG	M63-575 NIC/TEXT	CUC5820
GRUNDIG	M63-575BL/TEXT	CUC4511
GRUNDIG	M63-670 TOP	CUC5361
GRUNDIG	M63-75CTI	CUC3600
GRUNDIG	M63-775 TOP	CUC5365
GRUNDIG	M63-776 TOP	CUC6365
GRUNDIG	M63-795 TOP	CUC7820
GRUNDIG	M70-100 IDTV	CUC1860
GRUNDIG	M70-100 IDTV	CUC1860
GRUNDIG	M70-100HDQ	CUC4890
GRUNDIG	M70-169/9 IDTV	CUC1951
GRUNDIG	M70-169/9 IDTV	CUC1951
GRUNDIG	M70-169/9 TOP	CUC7951
GRUNDIG	M70-1690 DPL	CUC6469
GRUNDIG	M70-1690 DPL/IDTV	CUC1961 (Digi 5)
GRUNDIG	M70-1690 DPL/IDTV/LOG	CUC1961 (Digi 5)
GRUNDIG	M70-1690 IDTV	CUC1961 (Digi 5)
GRUNDIG	M70-1690 TOP/LOG	CUC6369
GRUNDIG	M70-1690DPL/IDTV	CUC1961 (DIGI5)
GRUNDIG	M70-1690DPL/IDTV/LOG	CUC1961 (DIGI5)
GRUNDIG	M70-1690TOP/LOG	CUC6369 (Stereo)
GRUNDIG	M70-269/9	CUC1952 (Digi6)
GRUNDIG	M70-269PAL PLUS	CUC1962
GRUNDIG	M70-269PALplus	CUC1962
GRUNDIG	M70-280 IDTV	CUC1825
GRUNDIG	M70-280 IDTV	CUC1825
GRUNDIG	M70-281 IDTV	CUC1826
GRUNDIG	M70-281 IDTV	CUC1826

Brand	model	chassis
GRUNDIG	M70-281 IDTV	CUC1836
GRUNDIG	M70-281 IDTV	CUC1836
GRUNDIG	M70-281 IDTV/LOG	CUC1826
GRUNDIG	M70-281/8 IDTV/LOG	CUC1826
GRUNDIG	M70-282	CUC1836
GRUNDIG	M70-290 GB	CUC2800
GRUNDIG	M70-290/8 IDTV DAVIO70	CUC1836
GRUNDIG	M70-290/8IDTV DAVIO70	CUC1836
GRUNDIG	M70-2902 CTI	CUC2800
GRUNDIG	M70-295CTI	CUC2800
GRUNDIG	M70-298CTI	CUC2800
GRUNDIG	M70-300 DOLBY	CUC1837 (DIGI100)
GRUNDIG	M70-300 DOLBY	CUC1837 (DIGI100)
GRUNDIG	M70-3110 DOLBY	CUC1837 (DIGI100)
GRUNDIG	M70-3110 DOLBY	CUC1837 (DIGI100)
GRUNDIG	M70-359CTI	CUC3800
GRUNDIG	M70-390 CTI	CUC3800
GRUNDIG	M70-390/7 TEXT	CUC3870
GRUNDIG	M70-395CTI	CUC3800
GRUNDIG	M70-396 CTI	CUC3800
GRUNDIG	M70-459CTI	CUC3800
GRUNDIG	M70-490 NIC	CUC3800
GRUNDIG	M70-495/9S CTI	CUC3800
GRUNDIG	M70-580 IDTV	CUC1835
GRUNDIG	M70-580 IDTV	CUC1835
GRUNDIG	M70-590 NIC	CUC5860
GRUNDIG	M70-595 TOP	CUC5860
GRUNDIG	M70-681 IDTV	CUC1835
GRUNDIG	M70-681 IDTV	CUC1835
GRUNDIG	M70-690MTS	CUC6851
GRUNDIG	M70-691 IDTV	CUC1860
GRUNDIG	M70-691 IDTV	CUC1860
GRUNDIG	M70-691 IDTV	CUC1860
GRUNDIG	M70-695 TOP	CUC6851
GRUNDIG	M70-781 IDTV	CUC1821

Brand	model	chassis
GRUNDIG	M70-791 IDTV	CUC1851
GRUNDIG	M70-965 TOP	CUC6851
GRUNDIG	M72-100	CUC1826
GRUNDIG	M72-100/8A	CUC1830
GRUNDIG	M72-105 IDTV	CUC1852
GRUNDIG	M72-109MV/DOLBY	CUC1838
GRUNDIG	M72-115 IDTV	CUC1852
GRUNDIG	M72-2110 DOLBY	CUC1838A (DIGI100)
GRUNDIG	M72-2110MV/DOLBY	CUC1838
GRUNDIG	M72-215 IDTV	CUC1852
GRUNDIG	M72-215IDTV	CUC1852
GRUNDIG	M72-270 IDTV	CUC1826
GRUNDIG	M72-315 IDTV	CUC1852
GRUNDIG	M72-315/9	CUC1852
GRUNDIG	M72-400 XENTIA72	CUC1832
GRUNDIG	M72-410 REFERENCE	CUC1842 (Digi6)
GRUNDIG	M72-410 REFERENCE/PIP	CUC1842 (Digi6)
GRUNDIG	M72-410/9 REFERENCE	CUC1842 (Digi6)
GRUNDIG	M72-410/9 REFERENCE/PIP	CUC1842 (Digi6)
GRUNDIG	M72-420/8 DOLBY	CUC1838
GRUNDIG	M72-610/8 DOLBY	CUC1838 (DIGI100)
GRUNDIG	M72-795 TOP	CUC7851
GRUNDIG	M72-795/9	CUC7880
GRUNDIG	M72-798 DOLBY	CUC1838
GRUNDIG	M72-798 IDTV	CUC1830
GRUNDIG	M82-100 IDTV	CUC1880
GRUNDIG	M82-100 IDTV	CUC1880
GRUNDIG	M82-100/9 PAL PLUS	CUC1983 (Digi6)
GRUNDIG	M82-100/9 PALplus	CUC1983 (Digi6)
GRUNDIG	M82-101 IDTV	CUC1880
GRUNDIG	M82-101 IDTV	CUC1880
GRUNDIG	M82-102 IDTV	CUC1881
GRUNDIG	M82-102IDTV	CUC1881
GRUNDIG	M82-105/9 IDTV	CUC1881
GRUNDIG	M82-105/9 IDTV	CUC1881

Brand	model	chassis
GRUNDIG	M82-105/9 IDTV/PIP	CUC1882
GRUNDIG	M82-115/9 IDTV/PIP	CUC1882
GRUNDIG	M82-169/9 IDTV	CUC1982
GRUNDIG	M82-169/9 IDTV	CUC1982
GRUNDIG	M82-1690/9 TOP	CUC6368
GRUNDIG	M82-1690/9 TOP/LOG	CUC6368
GRUNDIG	M82-169PAL PLUS	CUC1981
GRUNDIG	M82-169PALplus	CUC1981
GRUNDIG	M82-210/8A IDTV	CUC1829
GRUNDIG	M82-269/9	CUC1984 (Digi6)
GRUNDIG	M82-269PAL PLUS	CUC1983 (Digi6)
GRUNDIG	M82-269PALplus	CUC1983 (Digi6)
GRUNDIG	M82-39519	CUC3840
GRUNDIG	M82-490 NIC	CUC3850
GRUNDIG	M82-495 NIC	CUC3840
GRUNDIG	M82-496/9STEXT	CUC3840
GRUNDIG	M82-795/9 TOP	CUC7851
GRUNDIG	M84-210/8 IDTV	CUC1827
GRUNDIG	M84-210/8A IDTV	CUC1829
GRUNDIG	M84-210/8AIDTV	CUC1829
GRUNDIG	M84-210/8IDTV	CUC1827
GRUNDIG	M84-211/8 IDTV	CUC1829
GRUNDIG	M84-211/8IDTV	CUC1829
GRUNDIG	M84-212/8 DOLBY	CUC1839
GRUNDIG	M84-212/8 DOLBY	CUC1839A (DIGI100)
GRUNDIG	M84-410/8 IDTV	CUC1827
GRUNDIG	M84-410/8IDTV	CUC1827
GRUNDIG	M85-5226	(TCL 40-2916MT-MA)
GRUNDIG	M90-490/9S	CUC3850
GRUNDIG	M95-100 IDTV	CUC1890
GRUNDIG	M95-100 IDTV	CUC1890
GRUNDIG	M95-101 IDTV	CUC1890
GRUNDIG	M95-101 IDTV	CUC1890
GRUNDIG	M95-102 IDTV	CUC1892
GRUNDIG	M95-102IDTV	CUC1892

Brand	model	chassis
GRUNDIG	M95-105/9 IDTV	CUC1892
GRUNDIG	M95-105/9 IDTV	CUC1892
GRUNDIG	M95-115/9 IDTV	CUC1893
GRUNDIG	M95-115/9 IDTV	CUC1893
GRUNDIG	M95-115/9 IDTV/PIP	CUC1893
GRUNDIG	M95-390 TEXT	CUC3850
GRUNDIG	M95-410/9REFERENCE	CUC1894 (Digi6)
GRUNDIG	M95-411/9REFERENCE	CUC1894 (Digi6)
GRUNDIG	M95-490 NIC	CUC3850
GRUNDIG	M95-575/9 PIP	CUC5891
GRUNDIG	M95-91 (M9591)	CUC3850
GRUNDIG	Megatron SE7250A PIP/Dolby	CUC1832 (100Hz)
GRUNDIG	MF3115/8	CUC1838
GRUNDIG	MF5310/8 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF55-2401/7 TOP ARCANCE	16.1 (BEKO)
GRUNDIG	MF55-2401/7 TOP ARCANCE 55 Flat	16.1 (BEKO)
GRUNDIG	MF55-2502/8 TOP	K1 (raczej K5) (KX1.190-06)
GRUNDIG	MF55-2502/8FR TOP	K1 (BEKO)
GRUNDIG	MF55-2503/8	K1 (BEKO)
GRUNDIG	MF55-5101NIC/DOLBY	CUC2036N
GRUNDIG	MF55-5201/8 DOLBY	CUC2136M
GRUNDIG	MF55-5201/8 DOLBY	CUC2136M
GRUNDIG	MF55-5501/8	K1 (BEKO)
GRUNDIG	MF55-5501/8 TOP	K1 (BEKO)
GRUNDIG	MF55-9101/8 DOLBY	CUC2136M
GRUNDIG	MF55-9101/8 DOLBY	CUC2136M
GRUNDIG	MF55-9201	CUC2121
GRUNDIG	MF55-9201/8	CUC2121M
GRUNDIG	MF55-9201/8 DOLBY	CUC2121M
GRUNDIG	MF55-9201/8 DOLBY	CUC2121M
GRUNDIG	MF70-2401	14.2 (?)
GRUNDIG	MF72-2015	22.2
GRUNDIG	MF72-2210 DOLBY	CUC1838 (DIGI100)
GRUNDIG	MF72-2310 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-2401/7 TOP	14.2 (BEKO)

Brand	model	chassis
GRUNDIG	MF72-2501/8 Top	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MF72-2501/8 Top	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MF72-2502 IT/Top	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MF72-2502/8 Top	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MF72-2510	22.1 (BEKO)
GRUNDIG	MF72-2510/8 Top	22.1 (BEKO)
GRUNDIG	MF72-258 DOLBY	CUC1838
GRUNDIG	MF72-258 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-3101/8 DOLBY	CUC2131M
GRUNDIG	MF72-3101/8 DOLBY	CUC2131M
GRUNDIG	MF72-3110 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-3110/8 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-3115/8 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-3119 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-3121	CUC2131
GRUNDIG	MF72-3131	CUC2131
GRUNDIG	MF72-430/8 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-490 DOLBY	CUC1832
GRUNDIG	MF72-490 DOLBY	CUC1832
GRUNDIG	MF72-5410/7 TOP	22.1 (ZA1.190-08) (BEKO)
GRUNDIG	MF72-620 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-620/8 DOLBY	CUC1838 (DIGI100)
GRUNDIG	MF72-6601/8 IDTV	C8IDTV (NW1.190-04) (BEKO)
GRUNDIG	MF72-9101/8 DOLBY	CUC2131M
GRUNDIG	MF72-9110/8 DOLBY	CUC1838A (DIGI100)
GRUNDIG	MF72-9115/8 DOLBY	CUC1838
GRUNDIG	MF74-430/8 DOLBY	CUC1838
GRUNDIG	MF74-430/8 DOLBY	CUC1838
GRUNDIG	MF84-6110/8 DOLBY	CUC1839
GRUNDIG	MF84-6110/8 DOLBY	CUC1839A (DIGI100)
GRUNDIG	MFW102-6110MV/AC3	--
GRUNDIG	MFW70-2401	14.2 (BEKO) (inaczej: GBC2400)
GRUNDIG	MFW70-2501 Dolby	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MFW70-2501/8 Dolby	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MFW70-2501/8 Dolby	C7-C8 (C7/C8) (BEKO)

Brand	model	chassis
GRUNDIG	MFW70-2510/8	22.1 (AZ1.190-12)
GRUNDIG	MFW70-3201NIC/DOLBY	CUC2069N
GRUNDIG	MFW70-3210/8 DOLBY	CUC1934
GRUNDIG	MFW70-3210/8 DOLBY	CUC1934
GRUNDIG	MFW70-430/8 DOLBY	CUC1934
GRUNDIG	MFW70-430/8 DOLBY	CUC1934
GRUNDIG	MFW70-490/8 DOLBY XENTIA70FI AT	CUC1930
GRUNDIG	MFW70-490/8 DOLBY XENTIA70FI AT	CUC1930
GRUNDIG	MFW70-5310 DOLBY	CUC1934A (DIGI100)
GRUNDIG	MFW70-5310/8 DOLBY	CUC1934A (DIGI100)
GRUNDIG	MFW70-5410	22.1 (BEKO)
GRUNDIG	MFW70-5410/7 Dolby	22.1 (BEKO)
GRUNDIG	MFW82-2310/8 TOP	CUC1935A (DIGI100)
GRUNDIG	MFW82-2501 Dolby	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MFW82-2501/8 Dolby	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MFW82-2501/8 Dolby	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MFW82-2510/8	22.1 (ZA1.190-10) (BEKO)
GRUNDIG	MFW82-3101NIC/DOLBY	CUC2068N
GRUNDIG	MFW82-3110/8 DOLBY	CUC1935
GRUNDIG	MFW82-3110MV/8 DOLBY	CUC1935
GRUNDIG	MFW82-3110MV/8 DOLBY	CUC1935
GRUNDIG	MFW82-3118 PIP/DOLBY	CUC1935A (DIGI100)
GRUNDIG	MFW82-430/8 DOLBY	CUC1935A (DIGI100)
GRUNDIG	MFW82-490/9 DOLBY XENTIA82FI AT	CUC1931
GRUNDIG	MFW82-5210/8 DOLBY	CUC1935
GRUNDIG	MFW82-5210/8 DOLBY	CUC1935A (DIGI100)
GRUNDIG	MFW82-530/9 DPL ARGANTO82FI AT	CUC1931
GRUNDIG	MFW82-530/9DVD ARGANTO	CUC1931
GRUNDIG	MFW82-5310 DOLBY	CUC1935A (DIGI100)
GRUNDIG	MFW82-5310/8 DOLBY	CUC1935A (DIGI100)
GRUNDIG	MFW82-620/8 DOLBY	CUC1935 (DIGI100)
GRUNDIG	MFW82-6210/9 DOLBY	CUC1935
GRUNDIG	MFW82-6211/9DVD	CUC1935
GRUNDIG	MFW82-710 9 DPL	CUC1931
GRUNDIG	MFW82-720 9DVD	CUC1931

Brand	model	chassis
GRUNDIG	MFW8253/8 DOLBY	CUC1935A (DIGI100)
GRUNDIG	MFW92-6110/9	CUC1937
GRUNDIG	Minerva T2658	CUC731
GRUNDIG	Monaco26--LXW68-8512DL	L6B (BEKO)
GRUNDIG	Monaco32--LXW82-8512DL	L6B (BEKO)
GRUNDIG	MONOLITH 66-190 MULTISYSTEM	CUC741
GRUNDIG	Montreal26--LW68-7472 TOP	(G.BB95-00=GBB9500)
GRUNDIG	MVW82-2510/08	22.1 (?) (BEKO)
GRUNDIG	MW70-100/8	CUC1828
GRUNDIG	MW70-150/8 DOLBY	CUC1934A (DIGI100)
GRUNDIG	MW70-2101 DOLBY	CUC2059
GRUNDIG	MW70-2101 NIC/DOLBY	CUC2059N
GRUNDIG	MW70-2201 NIC/DOLBY	CUC2069N
GRUNDIG	MW70-2203 NIC/DOLBY	CUC2069
GRUNDIG	MW70-2501	14.2 (BEKO)
GRUNDIG	MW70-2502/8 Dolby	C7-C8 (C7/C8) (BEKO)
GRUNDIG	MW70-2690 FR/TOP	CUC2059F
GRUNDIG	MW70-2690 NIC	CUC2059
GRUNDIG	MW70-2690 NIC/TOP	CUC2059N
GRUNDIG	MW70-2699 NIC	CUC2059
GRUNDIG	MW70-269PAL PLUS	CUC1952 (Digi6)
GRUNDIG	MW70-269PALplus	CUC1952 (Digi6)
GRUNDIG	MW70-2700 DPL	CUC2059
GRUNDIG	MW70-2700 NIC/DOLBY	CUC2059N
GRUNDIG	MW70-3201 NIC/DOLBY	CUC2069N
GRUNDIG	MW70-500IRDT ARGANTO70	CUC2059
GRUNDIG	MW70-502IRDT/DOLBY	CUC2059D
GRUNDIG	MW70-505IRDT ARGANTO70	CUC2059
GRUNDIG	MW70-510/8DPL ARGANTO70	CUC1930
GRUNDIG	MW70-515MV/DOLBY	CUC1934
GRUNDIG	MW70-600IRDT ARGANTO70	CUC2059D
GRUNDIG	MW70-605IRDT ARGANTO70	CUC2059D
GRUNDIG	MW72-490 XENTIA	CUC1832
GRUNDIG	MW82-100/9PAL PLUS	CUC1983 (Digi6)
GRUNDIG	MW82-100/9PALplus	CUC1983 (Digi6)

Brand	model	chassis
GRUNDIG	MW82-100PAL PLUS DENVER	CUC1984 (Digi6)
GRUNDIG	MW82-100PALplus DENVER	CUC1984 (Digi6)
GRUNDIG	MW82-150/8 DOLBY	CUC1935A (DIGI100)
GRUNDIG	MW82-2101NIC/DOLBY	CUC2058N
GRUNDIG	MW82-2201NIC/DOLBY	CUC2068N
GRUNDIG	MW82-2203NIC/DOLBY	CUC2068N
GRUNDIG	MW82-2210/8 DOLBY	CUC1935 (DIGI100)
GRUNDIG	MW82-2210/8 DOLBY	CUC1935A (DIGI100)
GRUNDIG	MW82-2690 NIC	CUC2058
GRUNDIG	MW82-2690 NIC/TOP	CUC2058N
GRUNDIG	MW82-2699 NIC	CUC2058
GRUNDIG	MW82-2699 NIC/TOP	CUC2058N
GRUNDIG	MW82-2700 DPL	CUC2058
GRUNDIG	MW82-2701 DOLBY	CUC2059N
GRUNDIG	MW82-2701DOLBY	CUC2059N
GRUNDIG	MW82-3110MV/DOLBY	CUC1935
GRUNDIG	MW82-3112 MV/DOLBY	CUC1935A (DIGI100)
GRUNDIG	MW82-3112MV/DOLBY	CUC1935
GRUNDIG	MW82-3699 DOLBY	CUC2059N
GRUNDIG	MW82-3699 DOLBY	CUC2059N
GRUNDIG	MW82-3700 DPL	CUC2059N
GRUNDIG	MW82-40/8	CUC1829
GRUNDIG	MW82-50	CUC1928
GRUNDIG	MW82-50/8	CUC1929
GRUNDIG	MW82-500IRDT ARGANTO82	CUC2058
GRUNDIG	MW82-505IRDT ARGANTO82	CUC2058
GRUNDIG	MW82-510/8DPL ARGANTO82	CUC1931
GRUNDIG	MW82-515MV/DOLBY	CUC1935
GRUNDIG	MW82-520/9PAL PLUS ARGANTO82	CUC1983 (Digi6)
GRUNDIG	MW82-520/9PALplus ARGANTO82	CUC1983 (Digi6)
GRUNDIG	P14-6210/4	CUC400
GRUNDIG	P14-6210/4 TEXT	CUC400
GRUNDIG	P14-6210/6	CUC400
GRUNDIG	P14-6210/6 TEXT	CUC400
GRUNDIG	P14-6210/8	CUC400

Brand	model	chassis
GRUNDIG	P14-6210/8 TEXT	CUC400
GRUNDIG	P25-449/12	CUC4200
GRUNDIG	P27-649/12	CUC5200
GRUNDIG	P37-00 MINERVA	CUC5300
GRUNDIG	P37-040	CUC5300
GRUNDIG	P37-040A	CUC5303
GRUNDIG	P37-050INT	CUC5303
GRUNDIG	P37-060 GB	CUC6300
GRUNDIG	P37-065/5	CUC7301
GRUNDIG	P37-066	CUC7303
GRUNDIG	P37-070	CUC7301
GRUNDIG	P37-071IR	CUC7303
GRUNDIG	P37-080 TEXT	CUC7303
GRUNDIG	P37-1010	TMB557A; CODE A (A.M.: ale to nic nie znacz
GRUNDIG	P37-1101	12.4/12.5
GRUNDIG	P37-1201/5 TOP	12.6 (BEKO)
GRUNDIG	P37-2101 MV	CUC2103
GRUNDIG	P37-2102MV	CUC2100
GRUNDIG	P37-2103MV	CUC2100
GRUNDIG	P37-2104MV	CUC2100
GRUNDIG	P37-2105MV	CUC2100
GRUNDIG	P37-2201 Davio	12.6 (BEKO)
GRUNDIG	P37-2201 FR	12.6 (BEKO)
GRUNDIG	P37-2226	CUC2201
GRUNDIG	P37-2301	12.6 (BEKO)
GRUNDIG	P37-2401	E1 (BEKO)
GRUNDIG	P37-2401 TEXT	12.6 !
GRUNDIG	P37-2401/5 TEXT	12.6 !
GRUNDIG	P37-240I/5	E1 (Z50.190-07)
GRUNDIG	P37-242	CUC2400
GRUNDIG	P37-2426GB	CUC2400
GRUNDIG	P37-3035 TEXT	CUC7303
GRUNDIG	P37-3050 TEXT	CUC7303
GRUNDIG	P37-3050 TR	CUC7303
GRUNDIG	P37-3201 FR	12.6 (BEKO)

Brand	model	chassis
GRUNDIG	P37-332IT	CUC3300
GRUNDIG	P37-342 CTI	CUC3400
GRUNDIG	P37-342/90	CUC3490
GRUNDIG	P37-343CTI	CUC3400
GRUNDIG	P37-4101 12MV	CUC2105
GRUNDIG	P37-4101 MV	CUC2103
GRUNDIG	P37-4201 TOP	12.6 BEKO
GRUNDIG	P37-4201/5 TOP	12.6 BEKO
GRUNDIG	P37-4204 TOP	12.5 (BEKO)
GRUNDIG	P37-43 MINERVA	CUC3400
GRUNDIG	P37-440 TEXT	CUC4400
GRUNDIG	P37-443	CUC4400
GRUNDIG	P37-449	CUC4401
GRUNDIG	P37-4501/5 TEXT	E3
GRUNDIG	P37-540 TEXT	CUC5301
GRUNDIG	P37-549/12	CUC5305
GRUNDIG	P37-640 TEXT	CUC6300
GRUNDIG	P37-730 TEXT	CUC7301
GRUNDIG	P37-731 TEXT	CUC7303
GRUNDIG	P37-731/12 TEXT	CUC7305
GRUNDIG	P37-732/5 TEXT	CUC7303
GRUNDIG	P37-740 TOP	CUC7300
GRUNDIG	P37-743 EURO	CUC6300
GRUNDIG	P37-745S EURO	CUC6300
GRUNDIG	P37-830 MULTI/ICN	CUC2003(H)
GRUNDIG	P37-830 TEXT	CUC7303
GRUNDIG	P37-830 TEXT/GB	CUC7303
GRUNDIG	P37-830 TEXT/IR	CUC7303
GRUNDIG	P37-830 TEXT/TR	CUC7303
GRUNDIG	P37-830/12 GLOBTROTTER	CUC7305
GRUNDIG	P37-830/4 TEXT	CUC7303
GRUNDIG	P37-837 TEXT	CUC7303
GRUNDIG	P37-838 TEXT	CUC7303
GRUNDIG	P37-840/12 TOP	CUC2005
GRUNDIG	P37-841 FR	CUC7303

Brand	model	chassis
GRUNDIG	P37-842 FR	CUC7303
GRUNDIG	P37-843 FR	CUC7301
GRUNDIG	P37-845 FR	CUC7300
GRUNDIG	P37-846 FR	CUC7303
GRUNDIG	P37-847FR	CUC7303
GRUNDIG	P37-9443 FR	CUC7303F
GRUNDIG	P3744/1	CUC4400
GRUNDIG	P3745/1	CUC4400
GRUNDIG	P3746 TEXT	CUC5301
GRUNDIG	P3747	CUC5303
GRUNDIG	P3748	CUC6300
GRUNDIG	P40-040	CUC5300
GRUNDIG	P40-040A	CUC5303
GRUNDIG	P40-050	CUC5303
GRUNDIG	P40-060	CUC6300
GRUNDIG	P40-242 CTI	CUC2400
GRUNDIG	P40-2422 CTI	CUC2400
GRUNDIG	P40-2426 CTI	CUC2401
GRUNDIG	P40-245A CTI	CUC2401
GRUNDIG	P40-342 CTI	CUC3400
GRUNDIG	P40-345CTI	CUC3400
GRUNDIG	P40-346 CTI	CUC3400
GRUNDIG	P40-43 MINERVA	CUC3400
GRUNDIG	P40-440	CUC4400
GRUNDIG	P40-46 MINERVA	CUC5300
GRUNDIG	P40-540 TEXT	CUC5301
GRUNDIG	P40-541DS	CUC5301
GRUNDIG	P40-640 TEXT	CUC6300
GRUNDIG	P40-740 TOP	CUC7300
GRUNDIG	P40-743 EURO	CUC6300
GRUNDIG	P40-745S EURO	CUC6300
GRUNDIG	P4044/1	CUC4400
GRUNDIG	P4045/1	CUC4400
GRUNDIG	P4047	CUC5303
GRUNDIG	P4064 FR	CUC6301

Brand	model	chassis
GRUNDIG	P42-040	CUC5300
GRUNDIG	P42-050	CUC5303
GRUNDIG	P42-060	CUC6300
GRUNDIG	P42-242 CTI	CUC2400
GRUNDIG	P42-2421	CUC2400
GRUNDIG	P42-2421A CTI	CUC2401
GRUNDIG	P42-2426GB	CUC2400
GRUNDIG	P42-242A CTI	CUC2401
GRUNDIG	P42-341 CTI	CUC3400
GRUNDIG	P42-342 CTI	CUC3400
GRUNDIG	P42-42 MINERVA	CUC3400
GRUNDIG	P440 CTI MIAMI	CUC3400
GRUNDIG	P445 OSLO	CUC3400
GRUNDIG	P45-0450	CUC4500
GRUNDIG	P45-342 CTI	CUC3400
GRUNDIG	P45-345CTI	CUC3400
GRUNDIG	P45-346 CTI	CUC3400
GRUNDIG	P45-4101 MV/TOP	CUC2103
GRUNDIG	P45-43CTI MINERVA	CUC3400
GRUNDIG	P45-44/1	CUC4400
GRUNDIG	P45-440	CUC4400
GRUNDIG	P45-446 TEXT	CUC4400
GRUNDIG	P45-45	CUC4400
GRUNDIG	P45-46 TEXT	CUC5301
GRUNDIG	P45-48 TEXT	CUC6300
GRUNDIG	P45-540 TEXT	CUC5301
GRUNDIG	P45-550 TEXT	CUC5350
GRUNDIG	P45-64/4	CUC6301
GRUNDIG	P45-640 TEXT	CUC6300
GRUNDIG	P45-731 TEXT	CUC7303
GRUNDIG	P45-740 TOP	CUC7300
GRUNDIG	P45-745EURO	CUC6300
GRUNDIG	P45-830 MULTI	CUC2003H
GRUNDIG	P45-830 MULTI/MegASIS	CUC2003H
GRUNDIG	P45-830 TEXT	CUC7303

Brand	model	chassis
GRUNDIG	P45-845 FR	CUC7300
GRUNDIG	P45-846 FR	CUC7300
GRUNDIG	P45-847FR	CUC7300
GRUNDIG	P45-864 FR	CUC7303
GRUNDIG	P450450	CUC4500
GRUNDIG	P4544/1	CUC4400
GRUNDIG	P4545	CUC4400
GRUNDIG	P4546 TEXT	CUC5301
GRUNDIG	P50-242 CTI	CUC2400
GRUNDIG	P50-242A CTI	CUC2401
GRUNDIG	P50-342 CTI	CUC3400
GRUNDIG	P50-440	CUC4400
GRUNDIG	P50-450	CUC4500
GRUNDIG	P50-540 TEXT	CUC5301
GRUNDIG	P50-550 TEXT	CUC5350
GRUNDIG	P50-640 TEXT	CUC6300
GRUNDIG	P540MIAMI	CUC4400
GRUNDIG	P545OSLO	CUC4400
GRUNDIG	P55-245CTI	CUC2400
GRUNDIG	P640 TEXT	CUC5301
GRUNDIG	P642 TEXT	CUC6300
GRUNDIG	PF2503	K1 (BEKO)
GRUNDIG	PW110-520/9 PALPLUS	--
GRUNDIG	PW110-8110/9 DOLBY	--
GRUNDIG	ROME Flat SE8272/7 Dolby	22.1 (BEKO)
GRUNDIG	S55-806 TOP	CUC2103
GRUNDIG	SE3780 TEXT GREENVILLE370	CUC7303
GRUNDIG	SE3781 TOP GREENVILLE370	CUC2003
GRUNDIG	SE4234PCC	CUC3400
GRUNDIG	SE4244	CUC4400
GRUNDIG	SE4254	CUC5300
GRUNDIG	SE4264 TEXT	CUC6300
GRUNDIG	SE4554 TEXT	CUC5301
GRUNDIG	SE5544 TEXT	CUC4400
GRUNDIG	SE5554 TEXT	CUC5301

Brand	model	chassis
GRUNDIG	SE5564 TEXT	CUC6300
GRUNDIG	SE5566 TOP	CUC5350
GRUNDIG	SE5574 TOP	CUC7300
GRUNDIG	SE5576 TEXT LISSABON	CUC7350
GRUNDIG	SE5586 TOP GREENVILLE	CUC2020
GRUNDIG	SE5587 TOP GREENVILLE560	CUC2021
GRUNDIG	SE5592MV	CUC2121M
GRUNDIG	SE5592MV/DOLBY	CUC2121M
GRUNDIG	SE5595 DOLBY	CUC2121
GRUNDIG	SE5595DOLBY	CUC2121
GRUNDIG	SE5595MV/DOLBY	CUC2121
GRUNDIG	SE6320 IDTV WIEN100	CUC1826
GRUNDIG	SE6320 IDTV WIEN100	CUC1826
GRUNDIG	SE6320 IDTV WIEN100	CUC1836
GRUNDIG	SE6320 IDTV WIEN100	CUC1836
GRUNDIG	SE6334PCC	CUC3410
GRUNDIG	SE6340 DOLBY	CUC1837A (DIGI100)
GRUNDIG	SE6346 TEXT	CUC4620
GRUNDIG	SE6356 TEXT	CUC4510
GRUNDIG	SE6366 TOP	CUC5361
GRUNDIG	SE6367 TEXT	CUC5360
GRUNDIG	SE6376 TOP	CUC6360
GRUNDIG	SE70-100BERLIN	CUC1828
GRUNDIG	SE7010 IDTV BOSTON	CUC1836
GRUNDIG	SE7010 IDTV BOSTON	CUC1836
GRUNDIG	SE7012 DOLBY	CUC1837 (DIGI100)
GRUNDIG	SE7012 DOLBY	CUC1837 (DIGI100)
GRUNDIG	SE7015 DOLBY	CUC1837A (DIGI100)
GRUNDIG	SE7016/9 Ref/PIP	CUC1952 (Digi6)
GRUNDIG	SE7016PIP	CUC1952 (Digi6)
GRUNDIG	SE7020 IDTV	CUC1826
GRUNDIG	SE7020 IDTV	CUC1826
GRUNDIG	SE7020 IDTV SYDNEY	CUC1836
GRUNDIG	SE7020 IDTV SYDNEY	CUC1836
GRUNDIG	SE7021 IDTV SYDNEY100	CUC1836

Brand	model	chassis
GRUNDIG	SE7026PAL PLUS	CUC1952 (Digi6)
GRUNDIG	SE7026PALplus	CUC1952 (Digi6)
GRUNDIG	SE7027PIP BERLIN	CUC1828
GRUNDIG	SE7030GREENVILLE100	CUC1836
GRUNDIG	SE7046 TEXT	CUC4620
GRUNDIG	SE7050/8PIP/DOLBY	CUC1930
GRUNDIG	SE7056 TEXT	CUC4510
GRUNDIG	SE7065 TEXT	CUC5360
GRUNDIG	SE7066 TOP	CUC5360
GRUNDIG	SE7066/8TOP	CUC55361
GRUNDIG	SE7072	22.1 (BEKO)
GRUNDIG	SE7075 TEXT	CUC5360
GRUNDIG	SE7076 TOP	CUC4511
GRUNDIG	SE7085 TEXT	CUC5360
GRUNDIG	SE7086 TOP	CUC5371
GRUNDIG	SE7087 TOP	CUC6360
GRUNDIG	SE7088 IDTV	CUC1824
GRUNDIG	SE7088IDTV	CUC1824
GRUNDIG	SE7089 IDTV	CUC1825
GRUNDIG	SE7089 IDTV	CUC1825
GRUNDIG	SE7090 IDTV	CUC1826
GRUNDIG	SE7090 IDTV	CUC1826
GRUNDIG	SE7210 NIC MELBOURNE	CUC2031
GRUNDIG	SE7210 TOP MELBOURNE	CUC2030
GRUNDIG	SE7210A NIC MELBOURNE	CUC2051
GRUNDIG	SE7210A NIC/TOP MELBOURNE	CUC2051N
GRUNDIG	SE7212 TOP MELBOURNE	CUC2033
GRUNDIG	SE7216/8 DOLBY	CUC1838
GRUNDIG	SE7216/8 DOLBY	CUC1838
GRUNDIG	SE7220 IDTV ATLANTA	CUC1826
GRUNDIG	SE7220 IDTV ATLANTA	CUC1826
GRUNDIG	SE7220A IDTV	CUC1830
GRUNDIG	SE7230 DOLBY SYDNEY	CUC1832
GRUNDIG	SE7230 DOLBY SYDNEY	CUC1832
GRUNDIG	SE7240 DOLBY	CUC1838

Brand	model	chassis
GRUNDIG	SE7240 DOLBY	CUC1838
GRUNDIG	SE7241 DOLBY	CUC1838A (DIGI100)
GRUNDIG	SE7250PIP ATLANTA	CUC1832
GRUNDIG	SE7260 DOLBY	CUC1838
GRUNDIG	SE7260 DOLBY	CUC1838
GRUNDIG	SE7261 DOLBY	CUC1838A (DIGI100)
GRUNDIG	SE7270 DOLBY	CUC1838
GRUNDIG	SE7270 DOLBY	CUC1838
GRUNDIG	SE7277 TEXT	CUC6331
GRUNDIG	SE7280 IDTV	CUC1822
GRUNDIG	SE7280 IDTV	CUC1822
GRUNDIG	SE7286 TOP	CUC5365
GRUNDIG	SE7287 TOP	CUC6365
GRUNDIG	SE7288 IDTV	CUC1822
GRUNDIG	SE7288IDTV	CUC1822
GRUNDIG	SE7289 IDTV	CUC1826
GRUNDIG	SE7289 IDTV	CUC1826
GRUNDIG	SE7289/9 IDTV	CUC1852
GRUNDIG	SE7289/9 IDTV	CUC1852
GRUNDIG	SE7290 IDTV BERLIN	CUC1822
GRUNDIG	SE7290 IDTV BERLIN	CUC1822
GRUNDIG	SE82-100PAL PLUS DENVER	CUC1984 (Digi6)
GRUNDIG	SE82-100PALplus DENVER	CUC1984 (Digi6)
GRUNDIG	SE8216PAL PLUS DENVER	CUC1984 (Digi6)
GRUNDIG	SE8216PALplus DENVER	CUC1984 (Digi6)
GRUNDIG	SE8219/9 PIP DENVER	CUC1984 (Digi6)
GRUNDIG	SE8227/8PIP DENVER	CUC1929
GRUNDIG	SE8240 DOLBY	CUC1935A (DIGI100)
GRUNDIG	SE8250/8 DOLBY	CUC1931
GRUNDIG	SE8260/8 DOLBY	CUC1935
GRUNDIG	Sedance 26--LXW68-6610 TOp	LM
GRUNDIG	Sedance 26--LXW68-6610 TOp	LM
GRUNDIG	Sedance 32--LXW82-6610 TOp	LM
GRUNDIG	Sedance 32--LXW82-8600DL	LM
GRUNDIG	Sedance 55 ST55-2502 Top	K1 (raczej K5) (KX1.190-09)

Brand	model	chassis
GRUNDIG	Sedance 55 ST55-2502/5 Top	K1 (BEKO)
GRUNDIG	Sedance 55 ST55-2502/8 FR/Ton	K1 (BEKO)
GRUNDIG	Sedance 55 ST55-2503/8 Top	K1 (BEKO)
GRUNDIG	SEDANCE 55 ST 55-2502 TOP	K1 (raczej K5) (KX1.190-02)
GRUNDIG	SEDANCE 55 ST55-2500 TOP	16.1 (BEKO)
GRUNDIG	SEDANCE 55 ST55-2500/5 TOP	16.1 (BEKO)
GRUNDIG	SEDANCE 55 ST55-2500/7 TOP	16.1 (BEKO)
GRUNDIG	Sedance 55--ST55-2502 Top	K1 (BEKO)
GRUNDIG	Sedance 55--ST55-2502/5 Top	K1 (BEKO)
GRUNDIG	Sedance 55--ST55-2502/8 FR/Ton	K1 (BEKO)
GRUNDIG	Sedance 55--ST55-2503/8 Top	K1 (BEKO)
GRUNDIG	Sedance 70	C7-C8 (C7/C8) (BEKO)
GRUNDIG	SEDANCE 70 ST70-285/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	SEDANCE 70 ST70-2410 Top	22.1 (BEKO)
GRUNDIG	SEDANCE 70 ST70-2410/7 Top	22.1 (BEKO)
GRUNDIG	Sedance70--ST70-2405/5 TOP	14.2 (BEKO)
GRUNDIG	SEDANCE72 ST72-8610 NIC/DOLBY (VNA)	CUC2033N
GRUNDIG	SP645 TEXT	CUC5350
GRUNDIG	SP737 TEXT	CUC7350
GRUNDIG	ST 70-270/8 IDTV	CUC1836
GRUNDIG	ST1470/9	CUC4635
GRUNDIG	ST1563 TOP	CUC4511
GRUNDIG	ST1570 TOP	CUC4511
GRUNDIG	ST1663 TEXT	CUC5360
GRUNDIG	ST1663 TOP	CUC5361
GRUNDIG	ST1670 TEXT	CUC5360
GRUNDIG	ST1670 TOP	CUC5361
GRUNDIG	ST1670PIP	CUC5371
GRUNDIG	ST170 IDTV BOSTON	CUC1824
GRUNDIG	ST170 IDTV BOSTON	CUC1824
GRUNDIG	ST172 IDTVATLANTA72	CUC1822
GRUNDIG	ST172IDTVATLANTA72	CUC1822
GRUNDIG	ST1770 TOP	CUC6360
GRUNDIG	ST1772 TOP	CUC6365
GRUNDIG	ST2663/8TOP	CUC5361

Brand	model	chassis
GRUNDIG	ST2670 TEXT	CUC5361
GRUNDIG	ST2670 TOP	CUC5361
GRUNDIG	ST270 IDTV BOSTON	CUC1825
GRUNDIG	ST270 IDTV BOSTON	CUC1825
GRUNDIG	ST3026	CUC730
GRUNDIG	ST3670 TEXT STOCKHOLM	CUC5360
GRUNDIG	ST463CTI	CUC4635
GRUNDIG	ST470 CTI	CUC4635
GRUNDIG	ST482/S	CUC3840
GRUNDIG	ST55-2556 CTI GRAZ	CUC2500
GRUNDIG	ST55-405/8 DOLBY	CUC2121
GRUNDIG	ST55-405/8 DOLBY	CUC2121
GRUNDIG	ST55-4105MV/DOLBY	CUC2121M
GRUNDIG	ST55-450 NIC	CUC4500
GRUNDIG	ST55-550 TEXT	CUC5350
GRUNDIG	ST55-550S EURO	CUC550F Stereo
GRUNDIG	ST55-556 NIC	CUC4500
GRUNDIG	ST55-576/9TEXT	CUC7350
GRUNDIG	ST55-605 TOP (VNM)	CUC2021
GRUNDIG	ST55-703GB DOLBY	CUC2121
GRUNDIG	ST55-710 TOP	CUC2020
GRUNDIG	ST55-715 (NIC/TOP)	CUC2021
GRUNDIG	ST55-715 NIC/TOP	CUC2021N
GRUNDIG	ST55-725FT	CUC7350
GRUNDIG	ST55-750 FR	CUC2020
GRUNDIG	ST55-753 EURO	CUC5350
GRUNDIG	ST55-798 TEXT	CUC7350
GRUNDIG	ST55-800 TEXT	CUC7350
GRUNDIG	ST55-800ATEXT	CUC2020
GRUNDIG	ST55-801/9TEXT	CUC7350
GRUNDIG	ST55-805 TOP	CUC2021
GRUNDIG	ST55-839/8 DOLBY	CUC2121
GRUNDIG	ST55-839/8 DOLBY	CUC2121
GRUNDIG	ST55-850 FR/TOP	CUC2020FR
GRUNDIG	ST55-850 TOP	CUC2020

Brand	model	chassis
GRUNDIG	ST55-854/8 DOLBY	CUC2121
GRUNDIG	ST55-854/8 DOLBY	CUC2121
GRUNDIG	ST55-855 TOP	CUC2021
GRUNDIG	ST55-875 FR	CUC5350
GRUNDIG	ST55-876/9TEXT	CUC7350
GRUNDIG	ST55-898TOP	CUC2021
GRUNDIG	ST55-900 FR	CUC2020
GRUNDIG	ST55-900 FR/TOP	CUC2020FR
GRUNDIG	ST55-908/8 DOLBY	CUC2121
GRUNDIG	ST55-908/8 FR DOLBY	CUC2121F
GRUNDIG	ST55-910 FR	CUC2020
GRUNDIG	ST55-934GB DOLBY	CUC2121
GRUNDIG	ST55-95ECO	CUC7350
GRUNDIG	ST55-998 DOLBY	CUC2121
GRUNDIG	ST55-998 DOLBY	CUC2121
GRUNDIG	ST5503	CUC5350
GRUNDIG	ST555 TEXT	CUC4500
GRUNDIG	ST5564 TEXT	CUC4500
GRUNDIG	ST5566 TEXT	CUC5350
GRUNDIG	ST563 TEXT	CUC4510
GRUNDIG	ST63-160A IDTV	CUC1822
GRUNDIG	ST63-2002/5 TEXT	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ST63-2103/8 DOLBY	CUC2130M
GRUNDIG	ST63-250 CTI	CUC2600
GRUNDIG	ST63-255 IDTV	CUC1825
GRUNDIG	ST63-2601 CTI	CUC2600
GRUNDIG	ST63-270/8 IDTV	CUC1836
GRUNDIG	ST63-300 DOLBY	CUC1837A (DIGI100)
GRUNDIG	ST63-300/8 DOLBY	CUC1837A (DIGI100)
GRUNDIG	ST63-305/8 DOLBY	CUC1837A (DIGI100)
GRUNDIG	ST63-360 CTI	CUC3510
GRUNDIG	ST63-361 CTI	CUC3510
GRUNDIG	ST63-366 CTI	CUC3510
GRUNDIG	ST63-400/DOLBY	CUC2030
GRUNDIG	ST63-4101/8 DOLBY	CUC2130M

Brand	model	chassis
GRUNDIG	ST63-450 TEXT	CUC4510
GRUNDIG	ST63-460S EURO	CUC4620
GRUNDIG	ST63-466 NIC	CUC4635
GRUNDIG	ST63-476 TEXT	CUC4620
GRUNDIG	ST63-550 TEXT	CUC5360
GRUNDIG	ST63-555 TEXT	CUC4510
GRUNDIG	ST63-555 TEXT/BM	CUC5360
GRUNDIG	ST63-556 NIC	CUC4510
GRUNDIG	ST63-560 NIC	CUC4511
GRUNDIG	ST63-576 NIC	CUC4510
GRUNDIG	ST63-650 TEXT	CUC5360
GRUNDIG	ST63-651 TOP	CUC6360
GRUNDIG	ST63-655 TEXT	CUC5360
GRUNDIG	ST63-656 TEXT	CUC5360
GRUNDIG	ST63-660 NIC	CUC5510
GRUNDIG	ST63-660/8TOP	CUC5361
GRUNDIG	ST63-660BL	CUC5511
GRUNDIG	ST63-663NIC	CUC5510
GRUNDIG	ST63-671 TEXT	CUC5361
GRUNDIG	ST63-700 DPL	CUC2040
GRUNDIG	ST63-700 NIC	CUC2030
GRUNDIG	ST63-700 TEXT	CUC2030
GRUNDIG	ST63-701NIC	CUC2030
GRUNDIG	ST63-702 NIC	CUC2030
GRUNDIG	ST63-702 TOP	CUC2032
GRUNDIG	ST63-702/8 DOLBY	CUC2130
GRUNDIG	ST63-702/8 DOLBY	CUC2130M
GRUNDIG	ST63-702/8 DOLBY	CUC2130M
GRUNDIG	ST63-702/8 DOLBY+B3560	CUC2130
GRUNDIG	ST63-705 FR	CUC2035
GRUNDIG	ST63-705 NIC	CUC2030
GRUNDIG	ST63-705 NIC/TEXT	CUC2030N
GRUNDIG	ST63-706 NIC	CUC2030
GRUNDIG	ST63-710 NIC	CUC2030
GRUNDIG	ST63-712 NIC	CUC2030

Brand	model	chassis
GRUNDIG	ST63-712 NIC/TOP	CUC2030N
GRUNDIG	ST63-713/8 DOLBY	CUC2030N
GRUNDIG	ST63-713/8 DOLBY	CUC2130M
GRUNDIG	ST63-713/8 DOLBY	CUC2130M
GRUNDIG	ST63-720/8 TEXT	CUC6330
GRUNDIG	ST63-725/8 TEXT	CUC6330
GRUNDIG	ST63-750 TEXT	CUC6330
GRUNDIG	ST63-750/9 TOP	CUC6360
GRUNDIG	ST63-755 TOP	CUC6360
GRUNDIG	ST63-755/8 TEXT	CUC6330
GRUNDIG	ST63-760 TOP	CUC5365
GRUNDIG	ST63-760/9 DPL	CUC7861
GRUNDIG	ST63-761 TOP	CUC6365
GRUNDIG	ST63-775DPL	CUC2040
GRUNDIG	ST63-780 NIC	CUC2030
GRUNDIG	ST63-781 IDTV	CUC1823
GRUNDIG	ST63-781 IDTV	CUC1823
GRUNDIG	ST63-782 NIC	CUC2030
GRUNDIG	ST63-782 TOP	CUC2032
GRUNDIG	ST63-800 TOP	CUC6360
GRUNDIG	ST63-875DPL/FT	CUC2050N
GRUNDIG	ST6303	CUC5360
GRUNDIG	ST6305	CUC6330
GRUNDIG	ST6362 CTI	CUC3510
GRUNDIG	ST6363S TEXT	CUC4620
GRUNDIG	ST6364 TEXT	CUC4510
GRUNDIG	ST6365 TEXT	CUC4510
GRUNDIG	ST6366 TEXT	CUC5360
GRUNDIG	ST6367	CUC5360
GRUNDIG	ST6368	CUC5360
GRUNDIG	ST655 TOP	CUC5350
GRUNDIG	ST66-260/9	CUC2600
GRUNDIG	ST663 TEXT	CUC5360
GRUNDIG	ST663 TOP	CUC5511
GRUNDIG	ST670 TOP	CUC5511

Brand	model	chassis
GRUNDIG	ST70-100 IDTV	CUC1824
GRUNDIG	ST70-100 IDTV	CUC1824
GRUNDIG	ST70-1002/7 TEXT	TV4KS
GRUNDIG	ST70-150 IDTV	CUC1824
GRUNDIG	ST70-150 IDTV	CUC1824
GRUNDIG	ST70-155 IDTV	CUC1824
GRUNDIG	ST70-155/9 IDTV	CUC1822
GRUNDIG	ST70-155/9 IDTV	CUC1822
GRUNDIG	ST70-155IDTV	CUC1824
GRUNDIG	ST70-160 IDTV	CUC1824
GRUNDIG	ST70-160 IDTV	CUC1824
GRUNDIG	ST70-169 TOP	CUC7951
GRUNDIG	ST70-200 IDTV	CUC1836
GRUNDIG	ST70-200 IDTV	CUC1836
GRUNDIG	ST70-2001/5	14.2 (BEKO)
GRUNDIG	ST70-2002/5 TEXT	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ST70-2010 TOP	22.2
GRUNDIG	ST70-2013/8 DOLBY	CUC2130 !
GRUNDIG	ST70-2015 DOLBY	22.2 (?)
GRUNDIG	ST70-209	CUC1836
GRUNDIG	ST70-2102 NIC/DOLBY	CUC2030N
GRUNDIG	ST70-2103/8 DOLBY	CUC2130M
GRUNDIG	ST70-2103/8 DOLBY	CUC2130M
GRUNDIG	ST70-2104/8 DOLBY	CUC2130
GRUNDIG	ST70-2104/8 DOLBY	CUC2130
GRUNDIG	ST70-2206 FR/DOLBY	CUC2060F
GRUNDIG	ST70-2210 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-2210 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-2310 DOLBY	CUC1837A (DIGI100)
GRUNDIG	ST70-250	CUC2600
GRUNDIG	ST70-250 IDTV	CUC1836
GRUNDIG	ST70-250 IDTV	CUC1836
GRUNDIG	ST70-2500	14.2 (U99.190-08)
GRUNDIG	ST70-2500 TOP	14.2 (BEKO)
GRUNDIG	ST70-2500/7	14.2 (BEKO)

Brand	model	chassis
GRUNDIG	ST70-2502 Top	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ST70-2502/8 Top	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ST70-2502/8 Top	C7-C8 (C7/C8) (BEKO)
GRUNDIG	ST70-255 IDTV	CUC1825
GRUNDIG	ST70-255IDTV	CUC1825
GRUNDIG	ST70-260 CTI	CUC2600
GRUNDIG	ST70-260/8 IDTV	CUC1836
GRUNDIG	ST70-260/8IDTV	CUC1836
GRUNDIG	ST70-2601 CTI	CUC2600
GRUNDIG	ST70-2602 CTI	CUC2600
GRUNDIG	ST70-2603CTI	CUC2600
GRUNDIG	ST70-2606 CTI SALZBURG	CUC2600
GRUNDIG	ST70-265/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-265/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-270 IDTV	CUC1825
GRUNDIG	ST70-270 IDTV	CUC1825
GRUNDIG	ST70-270 IDTV	CUC1836
GRUNDIG	ST70-270 IDTV	CUC1836
GRUNDIG	ST70-270/8 IDTV	CUC1836
GRUNDIG	ST70-278 IDTV	CUC1825
GRUNDIG	ST70-278 IDTV	CUC1836
GRUNDIG	ST70-278IDTV	CUC1825
GRUNDIG	ST70-278IDTV	CUC1836
GRUNDIG	ST70-280 IDTV	CUC1836
GRUNDIG	ST70-282/8	CUC1836 (100Hz)
GRUNDIG	ST70-284 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-284DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-285/8	CUC1837 (Digi100)
GRUNDIG	ST70-292/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-300/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-305/8 DOLBY	CUC1837A (DIGI100)
GRUNDIG	ST70-336 CTI	CUC3510
GRUNDIG	ST70-340A CTI	CUC3410
GRUNDIG	ST70-3500	C8 (BEKO)
GRUNDIG	ST70-360 CTI	CUC3510

Brand	model	chassis
GRUNDIG	ST70-361 CTI	CUC3510
GRUNDIG	ST70-364 CTI	CUC3600
GRUNDIG	ST70-398 DOLBY	CUC1837A (DIGI100)
GRUNDIG	ST70-450MP	CUC4510
GRUNDIG	ST70-455 TEXT	CUC4620
GRUNDIG	ST70-460 NIC	CUC4635
GRUNDIG	ST70-466 NIC	CUC4635
GRUNDIG	ST70-5001 DOLBY	CUC2032
GRUNDIG	ST70-5001DOLBY	CUC2032
GRUNDIG	ST70-5101 DAVIO70	CUC2130
GRUNDIG	ST70-5101 DOLBY	CUC2130
GRUNDIG	ST70-5101DOLBY	CUC2130
GRUNDIG	ST70-5109/8 DOLBY	CUC2130M
GRUNDIG	ST70-5109/8 DOLBY	CUC2130M
GRUNDIG	ST70-5210/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-5210/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-550 TEXT	CUC5360
GRUNDIG	ST70-555 TEXT	CUC4510
GRUNDIG	ST70-560 NIC	CUC4511
GRUNDIG	ST70-574 SAT	CUC5820
GRUNDIG	ST70-600 TEXT	CUC2030
GRUNDIG	ST70-650 TEXT	CUC5360
GRUNDIG	ST70-651 TOP	CUC6360
GRUNDIG	ST70-655 TEXT	CUC5360
GRUNDIG	ST70-656 TEXT	CUC5360
GRUNDIG	ST70-657 TOP	CUC5360
GRUNDIG	ST70-660 NIC	CUC5511
GRUNDIG	ST70-660/8TOP	CUC5361
GRUNDIG	ST70-661 TOP	CUC5511
GRUNDIG	ST70-665 TEXT	CUC5360
GRUNDIG	ST70-670 TOP	CUC5361
GRUNDIG	ST70-700 DPL	CUC2040
GRUNDIG	ST70-700 NIC	CUC2030
GRUNDIG	ST70-7010 NIC/DOLBY	CUC2030N
GRUNDIG	ST70-701NIC	CUC2030

Brand	model	chassis
GRUNDIG	ST70-702 NIC	CUC2030
GRUNDIG	ST70-702 TOP	CUC2032
GRUNDIG	ST70-703NIC	CUC2030
GRUNDIG	ST70-705 FR	CUC2035
GRUNDIG	ST70-705 NIC	CUC2030
GRUNDIG	ST70-705 NIC/TEXT	CUC2030N
GRUNDIG	ST70-705 TOP	CUC6360
GRUNDIG	ST70-705/8 TEXT	CUC6330
GRUNDIG	ST70-706 NIC	CUC2030
GRUNDIG	ST70-706 NIC/TOP	CUC2030
GRUNDIG	ST70-710 NIC	CUC2030
GRUNDIG	ST70-712 NIC	CUC2030
GRUNDIG	ST70-713/8 DOLBY	CUC2130
GRUNDIG	ST70-715 NIC	CUC2030
GRUNDIG	ST70-720/8 TEXT	CUC6330
GRUNDIG	ST70-721/8 TEXT	CUC6330
GRUNDIG	ST70-725/8 TEXT	CUC6330
GRUNDIG	ST70-728 TEXT	CUC6330
GRUNDIG	ST70-730 NIC	CUC2030
GRUNDIG	ST70-7301/8 TOP	CUC2130
GRUNDIG	ST70-740 NIC/DOLBY	CUC2030N
GRUNDIG	ST70-741/8 DOLBY	CUC2130M
GRUNDIG	ST70-742 PIP/DOLBY	CUC2050
GRUNDIG	ST70-743 PIP/DOLBY	CUC2060
GRUNDIG	ST70-745 TEXT	CUC6330
GRUNDIG	ST70-750 TEXT	CUC6330
GRUNDIG	ST70-750/9 TOP	CUC6360
GRUNDIG	ST70-7510/8 Dolby	22.1 (?)
GRUNDIG	ST70-755 SAT	CUC6360
GRUNDIG	ST70-755/8 TEXT	CUC6330
GRUNDIG	ST70-755/9 DPL	CUC6460
GRUNDIG	ST70-755/9 DPL/LOG	CUC6460
GRUNDIG	ST70-760 TOP	CUC6361
GRUNDIG	ST70-770 TEXT	CUC6330
GRUNDIG	ST70-778 TEXT	CUC6330

Brand	model	chassis
GRUNDIG	ST70-780 NIC	CUC2030
GRUNDIG	ST70-782 DOLBY	CUC2032
GRUNDIG	ST70-782 NIC	CUC2030
GRUNDIG	ST70-782 NIC/DOLBY	CUC2030N
GRUNDIG	ST70-782 NIC/TOP	CUC2030N
GRUNDIG	ST70-782 TOP	CUC2032
GRUNDIG	ST70-788	CUC2030
GRUNDIG	ST70-788A	CUC2032
GRUNDIG	ST70-798 TEXT	CUC2030
GRUNDIG	ST70-798A TEXT	CUC2032
GRUNDIG	ST70-800 TEXT	CUC6360
GRUNDIG	ST70-802 FR/DOLBY	CUC2035F
GRUNDIG	ST70-809	CUC6360
GRUNDIG	ST70-810 DPL	CUC2050
GRUNDIG	ST70-819 NIC	CUC2050
GRUNDIG	ST70-819 NIC/TOP	CUC2050N
GRUNDIG	ST70-820 TOP	CUC2032
GRUNDIG	ST70-822 DOLBY	CUC2032
GRUNDIG	ST70-850 NIC	CUC2050
GRUNDIG	ST70-8510 NIC/DOLBY	CUC2030N
GRUNDIG	ST70-8510/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-8510/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-860 FR/TOP	CUC2030F
GRUNDIG	ST70-860 TOP DAVIO70	CUC2030
GRUNDIG	ST70-869 IDTV	CUC1825
GRUNDIG	ST70-869 IDTV	CUC1825
GRUNDIG	ST70-869 IDTV/LOG	CUC1826 !
GRUNDIG	ST70-869A IDTV	CUC1836
GRUNDIG	ST70-870 TOP DAVIO70	CUC2035
GRUNDIG	ST70-875DPL/FT	CUC2050N
GRUNDIG	ST70-880 FR/DOLBY	CUC2035F
GRUNDIG	ST70-898/8 DOLBY	CUC2130M
GRUNDIG	ST70-898/8 DOLBY	CUC2130M
GRUNDIG	ST70-900 DOLBY	CUC2032
GRUNDIG	ST70-900 DOLBY	CUC2032

Brand	model	chassis
GRUNDIG	ST70-900 NIC/DOLBY	CUC2030N
GRUNDIG	ST70-900/4 DOLBY ELEGANCE	CUC2030
GRUNDIG	ST70-907 TEXT	CUC5360
GRUNDIG	ST70-93 TEXT	CUC5360
GRUNDIG	ST70-94 TEXT	CUC5360
GRUNDIG	ST70-95 TOP	CUC6360
GRUNDIG	ST70-969 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST70-969 DOLBY	CUC1837A (DIGI100)
GRUNDIG	ST70-97 IDTV	CUC1825
GRUNDIG	ST7003	CUC5360
GRUNDIG	ST7004	CUC6360
GRUNDIG	ST7062 CTI	CUC3510
GRUNDIG	ST7063 TEXT	CUC4635
GRUNDIG	ST7064 TEXT	CUC4510
GRUNDIG	ST7066 TEXT	CUC5360
GRUNDIG	ST7067 TEXT	CUC5360
GRUNDIG	ST70675 TOP	CUC5361
GRUNDIG	ST72-01 IDTV	CUC1826
GRUNDIG	ST72-01 IDTV	CUC1826
GRUNDIG	ST72-160 IDTV	CUC1822
GRUNDIG	ST72-161 IDTV	CUC1822
GRUNDIG	ST72-261 IDTV	CUC1826
GRUNDIG	ST72-3202/7 TOP	1.5
GRUNDIG	ST72-600 TOP	CUC2033
GRUNDIG	ST72-700 TOP	CUC2051
GRUNDIG	ST72-760 TEXT	CUC6331
GRUNDIG	ST72-760 TOP	CUC5365
GRUNDIG	ST72-760/9 DPL	CUC7861
GRUNDIG	ST72-761SAT	CUC6365
GRUNDIG	ST72-762 TOP	CUC6365
GRUNDIG	ST72-764 SAT	CUC7820
GRUNDIG	ST72-772 TOP SYDNEY	CUC5365
GRUNDIG	ST72-860 NIC	CUC2031
GRUNDIG	ST72-860A NIC	CUC2051
GRUNDIG	ST72-8610 NIC/DOLBY	CUC2033N

Brand	model	chassis
GRUNDIG	ST72-862 TOP	CUC2033
GRUNDIG	ST72-864 FR/DOLBY	CUC2033F
GRUNDIG	ST72-870 FR	CUC2031
GRUNDIG	ST755 TEXT	CUC7350
GRUNDIG	ST763 TOP	CUC6360
GRUNDIG	ST770 TOP	CUC6360
GRUNDIG	ST772 TOP SYDNEY	CUC5365
GRUNDIG	ST82-575 NIC	CUC5880
GRUNDIG	ST82-575/9 TXT	CUC5880
GRUNDIG	ST82-675/9 PIP	CUC6880
GRUNDIG	ST82-774 TOP	CUC7880
GRUNDIG	ST82-775 TOP	CUC7880
GRUNDIG	ST82-796 TOP	CUC6380
GRUNDIG	ST82-896 NIC	CUC2080
GRUNDIG	ST8276/9 TOP	CUC6880
GRUNDIG	ST8277 TOP	CUC7880
GRUNDIG	ST84-2202 NIC/DOLBY	CUC2062N
GRUNDIG	ST84-796/9	CUC6380
GRUNDIG	ST84-796/9 TOP/LOG	CUC6380
GRUNDIG	ST84-869 NIC/TOP	CUC2080N
GRUNDIG	ST84-8910 NIC/DOLBY	CUC2080N
GRUNDIG	ST84-8910 NIC/DOLBY (VNM)	CUC2080N
GRUNDIG	ST84-896 FR/TOP	CUC2080F
GRUNDIG	ST84-896 NIC/TOP	CUC2080N
GRUNDIG	ST84-896 NIC/TOP (VNA)	CUC2080N
GRUNDIG	ST84-899	CUC2080
GRUNDIG	ST84-899 DOLBY	CUC2080
GRUNDIG	ST84-899 DOLBY	CUC2080
GRUNDIG	ST84-899 DOLBY (VNM)	CUC2080
GRUNDIG	ST84-899 FR/DOLBY (VNM)	CUC2080F
GRUNDIG	ST872 TEXT	CUC6331
GRUNDIG	ST879/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST879/8 DOLBY	CUC1837 (DIGI100)
GRUNDIG	ST95-575/9 PIP	CUC5891
GRUNDIG	ST95-675/9 TOP	CUC6890

Brand	model	chassis
GRUNDIG	ST95-775/9 PIP	CUC7890
GRUNDIG	STF55-1502/5 TOP	K1 (BEKO)
GRUNDIG	STF72-1001	TV4KS (?)
GRUNDIG	STF72-1001/7	TV4KS
GRUNDIG	STF72-1002/7 TEXT	TV4KS
GRUNDIG	STF72-2002/8 TEXT	C7-C8 (C7/C8) (BEKO)
GRUNDIG	STF72-2011/8	22.2 (100Hz)
GRUNDIG	SUPER Color 1615	GSC100
Grundig	Super Color 30 seria 30T26 Eleganz 8285	GSC700 ?
GRUNDIG	Super Color 8276	GSC700
GRUNDIG	Super Color 8476	GSC700
GRUNDIG	Super Color 8876	GSC700
GRUNDIG	Super Color A3102/5 GB- UHF/VHF	CUC120
GRUNDIG	Super Color A3202/5	CUC120
GRUNDIG	Super Color A4102/5 GB- UHF/VHF	CUC120
GRUNDIG	Super Color A4202/5	CUC120
GRUNDIG	Super Color A5102/5	CUC120
GRUNDIG	Super Color A5202/5	CUC120
GRUNDIG	Super Color A6100/2/3/4 GB- UHF/VHF	CUC120
GRUNDIG	Super Color A6110/2/3/4 GB- UHF/VHF	CUC120
GRUNDIG	Super Color A6200/2/3/4 KT	CUC120
GRUNDIG	Super Color A7100/2/3 GB- UHF/VHF	CUC120
GRUNDIG	Super Color A7110/2/3 GB- UHF/VHF	CUC120
GRUNDIG	Super Color A7200/2/3	CUC120
GRUNDIG	Super Color A7210/2/3	CUC120
GRUNDIG	Super Color B3102	CUC40
GRUNDIG	Super Color B4101	CUC40
GRUNDIG	Super Color B4202	CUC40
GRUNDIG	Super Color B6400/2/4/7 GB- UHF/VHF	CUC220
GRUNDIG	Super Color B6410 GB-UHF/VHF	CUC220
GRUNDIG	Super Color B7400/2/4/7 GB- UHF/VHF	CUC220
GRUNDIG	Super Color B7410/2/3/4 GB- UHF/VHF	CUC220
GRUNDIG	Super Color B8400/4/7 KT/VT/GB-UHF/VHF TT	CUC720
GRUNDIG	Super Color B8410/2/3/4 KT	CUC720
GRUNDIG	Super Color B8440/2	CUC720

Brand	model	chassis
GRUNDIG	Super Color B8700	CUC730
GRUNDIG	Super Color B8710	CUC730
GRUNDIG	Super Color B8740	CUC730
GRUNDIG	Super Color C7500 GB- UHF/VHFTT	CUC731
GRUNDIG	Super Color C7500/2/4 96	CUC731
GRUNDIG	Super Color C7700	CUC731
GRUNDIG	Super Color C7701	CUC731
GRUNDIG	Super Color C7720	CUC731
GRUNDIG	Super Color C7760	CUC731
GRUNDIG	Super Color C8500/2 96	CUC731
GRUNDIG	Super Color C8500/2/4	CUC731
GRUNDIG	Super Color C8600 GB- UHF/VHFTT	CUC741
GRUNDIG	Super Color C8681/2/4 96	CUC741
GRUNDIG	Super Color C8681GB- UHF/VHFTT	CUC741
GRUNDIG	Super Color C8700	CUC731
GRUNDIG	Super Color C8706	CUC731
GRUNDIG	Super Color C8710	CUC731
GRUNDIG	Super Color C8720	CUC731
GRUNDIG	Super Color C8730	CUC731
GRUNDIG	Super Color C8760	CUC731
GRUNDIG	Super Color C8800	CUC741
GRUNDIG	Super Color C8801	CUC741
GRUNDIG	Super Color C8802	CUC741
GRUNDIG	Super Color C8810	CUC741
GRUNDIG	Super Color C8881	CUC741
GRUNDIG	Super Color C8902	CUC741
GRUNDIG	Super Color S8276	GSC700
GRUNDIG	SYDNEY Flat SE7272/7 Dolby	22.1 (BEKO)
GRUNDIG	SYDNEY100 SE7020 IDTV/LOG	CUC1826
GRUNDIG	SYDNEY100 SE7021 IDTV	CUC1836
GRUNDIG	T20-6210/4	CUC400
GRUNDIG	T20-6210/4 TEXT	CUC400
GRUNDIG	T20-6210/6	CUC400
GRUNDIG	T20-6210/6 TEXT	CUC400
GRUNDIG	T20-6210/8	CUC400

Brand	model	chassis
GRUNDIG	T20-6210/8 TEXT	CUC400
GRUNDIG	T21-6210/4	CUC400
GRUNDIG	T21-6210/4 TEXT	CUC400
GRUNDIG	T21-6210/6	CUC400
GRUNDIG	T21-6210/6 TEXT	CUC400
GRUNDIG	T21-6210/8	CUC400
GRUNDIG	T21-6210/8 TEXT	CUC400
GRUNDIG	T37-543 CL	CUC5301
GRUNDIG	T40-543 CL	CUC5301
GRUNDIG	T45-543 CL	CUC5301
GRUNDIG	T45-830/TEX	CUC7303
GRUNDIG	T455 TEXT ATHEN	CUC3400
GRUNDIG	T463CTI	CUC3410
GRUNDIG	T51-040/1	CUC5300
GRUNDIG	T51-040P/S	CUC5303
GRUNDIG	T51-050	CUC5303
GRUNDIG	T51-060	CUC6300
GRUNDIG	T51-070	CUC7301
GRUNDIG	T51-071 TR	CUC7303
GRUNDIG	T51-1101	12.4/12.5
GRUNDIG	T51-1101/5 TXT	12.4/12.5
GRUNDIG	T51-1201/5 TOP	12.6 (BEKO)
GRUNDIG	T51-2041	(Beko-ME164GRA04)
GRUNDIG	T51-2101 MV	CUC2103
GRUNDIG	T51-240 CTI	CUC2400
GRUNDIG	T51-2401 TEXT	12.6 !
GRUNDIG	T51-2401 TEXT	E1 (BEKO)
GRUNDIG	T51-2406 GB	CUC2400
GRUNDIG	T51-240A CTI	CUC2401
GRUNDIG	T51-3035 TEXT	CUC7303
GRUNDIG	T51-3050 TEXT	CUC7303
GRUNDIG	T51-3101 MV	CUC2103
GRUNDIG	T51-330	CUC3400
GRUNDIG	T51-340 GB	CUC3400
GRUNDIG	T51-40/1 MINERVA	CUC3400

Brand	model	chassis
GRUNDIG	T51-400	CUC3400
GRUNDIG	T51-4201 TOP	12.5 (BEKO)
GRUNDIG	T51-4201/5 TOP	12.6 (BEKO)
GRUNDIG	T51-43 MINERVA	CUC3400
GRUNDIG	T51-440 OIRT	CUC4400
GRUNDIG	T51-4501	E1
GRUNDIG	T51-540 TEXT	CUC5301
GRUNDIG	T51-540a TEXT	CUC5301
GRUNDIG	T51-545 TEXT	CUC5301
GRUNDIG	T51-546 TEXT	CUC5301
GRUNDIG	T51-640 TEXT	CUC6300
GRUNDIG	T51-711 TEXT	CUC7301
GRUNDIG	T51-720 TEXT	CUC7303
GRUNDIG	T51-721/5	CUC400
GRUNDIG	T51-721/5 TEXT	CUC400
GRUNDIG	T51-730 TEXT	CUC7301
GRUNDIG	T51-731 TEXT	CUC7303
GRUNDIG	T51-732/4 TEXT	CUC7303
GRUNDIG	T51-743 EURO	CUC6300
GRUNDIG	T51-830 MULTI	CUC2003
GRUNDIG	T51-830/12 TEXT	CUC7305
GRUNDIG	T51-846 TEXT	CUC7303
GRUNDIG	T5144/1	CUC4400
GRUNDIG	T5145 TEXT	CUC5301
GRUNDIG	T5148	CUC6300
GRUNDIG	T55-050	CUC5303
GRUNDIG	T55-060	CUC6300
GRUNDIG	T55-066/5	CUC7303
GRUNDIG	T55-1010	TMA518A
GRUNDIG	T55-1020	TMA518A
GRUNDIG	T55-1101	12.4/12.5 (A99.190-12)
GRUNDIG	T55-1101/5	12.4/12.5
GRUNDIG	T55-1120	TMA... (ORION)
GRUNDIG	T55-1201/5 TOP	12.6 (BEKO)
GRUNDIG	T55-1201/5 TOP	12.6 (BEKO)

Brand	model	chassis
GRUNDIG	T55-2101 MV	CUC2103
GRUNDIG	T55-2401 TEXT	12.6 !
GRUNDIG	T55-3035 TEXT	CUC7303
GRUNDIG	T55-3050 TEXT	CUC7303
GRUNDIG	T55-3101 TOP	CUC2103
GRUNDIG	T55-340 CTI	CUC3400
GRUNDIG	T55-340/90A	CUC3490
GRUNDIG	T55-342 CTI MINERVA	CUC3400
GRUNDIG	T55-345CTI	CUC3490
GRUNDIG	T55-345GB	CUC3400
GRUNDIG	T55-400 TEXT	CUC3400
GRUNDIG	T55-4101 MV	CUC2103
GRUNDIG	T55-4104 TOP	CUC2103
GRUNDIG	T55-4201 FR/TOP	12.6 (BEKO)
GRUNDIG	T55-4201 TOP	12.5 (BEKO)
GRUNDIG	T55-4201 TOP	12.6 (BEKO)
GRUNDIG	T55-4201/5	12.5 (BEKO)
GRUNDIG	T55-4201/5 TOP	12.6 (G98.190-09)
GRUNDIG	T55-44 MINERVA	CUC4400
GRUNDIG	T55-440 TEXT	CUC4400
GRUNDIG	T55-449INT	CUC4401
GRUNDIG	T55-540 TEXT	CUC5301
GRUNDIG	T55-545 TEXT	CUC5301
GRUNDIG	T55-546 TEXT	CUC5301
GRUNDIG	T55-549	CUC5302
GRUNDIG	T55-64 FR	CUC6301
GRUNDIG	T55-640 TEXT	CUC6300
GRUNDIG	T55-720 TEXT	CUC6300
GRUNDIG	T55-725FT	CUC7350
GRUNDIG	T55-730 TEXT	CUC7301
GRUNDIG	T55-730/5 TEXT	CUC7301
GRUNDIG	T55-731 TEXT	CUC7303
GRUNDIG	T55-731/5	CUC7301
GRUNDIG	T55-732/5 TEXT	CUC7303
GRUNDIG	T55-733/5 TEXT	CUC7303

Brand	model	chassis
GRUNDIG	T55-740 TOP	CUC7300
GRUNDIG	T55-740/6 TOP	CUC7302
GRUNDIG	T55-743 EURO	CUC6300
GRUNDIG	T55-830 MULTI	CUC2003H
GRUNDIG	T55-830 MULTI/ICN	CUC2003H
GRUNDIG	T55-830 MULTI/MegASIS	CUC2003H
GRUNDIG	T55-830/TEXT	CUC7303
GRUNDIG	T55-837 TEXT	CUC7303
GRUNDIG	T55-838 TEXT	CUC7303
GRUNDIG	T55-840 TOP/SAT	CUC2003(H)
GRUNDIG	T55-841 FR	CUC7303
GRUNDIG	T55-842 FR	CUC7303
GRUNDIG	T55-843 FR	CUC7301
GRUNDIG	T55-845 FR	CUC7300
GRUNDIG	T55-846 FR	CUC7303
GRUNDIG	T5542A CTI	CUC3400
GRUNDIG	T5545 TEXT	CUC5301
GRUNDIG	T555 TEXT ATHEN	CUC4400
GRUNDIG	T5574 TOP	CUC7300
GRUNDIG	T56-220	CUC2210 (?)
GRUNDIG	T56-240	CUC2410
GRUNDIG	T56-240 CTI	CUC2410
GRUNDIG	T56-2406GB	CUC2410
GRUNDIG	T56-2406GB UHF/VHF TT	CUC2410
GRUNDIG	T56-246SK	CUC2410
GRUNDIG	T56-260	CUC2600
GRUNDIG	T56-2601	CUC2600
GRUNDIG	T5655 TIVOLI	CUC5301
GRUNDIG	T63-230 CTI	CUC2410
GRUNDIG	T63-240 CTI	CUC2410
GRUNDIG	T63-330 CTI	CUC3410
GRUNDIG	T63-331 CTI	CUC3410
GRUNDIG	T63-336 CTI	CUC3410
GRUNDIG	T63-346 CTI	CUC3410
GRUNDIG	T63-430/1 TEXT	CUC4410

Brand	model	chassis
GRUNDIG	T63-439	CUC4411
GRUNDIG	T63-446 TEXT	CUC4410
GRUNDIG	T63-470 CTI/TEXT	CUC3600 ?
GRUNDIG	T63-530 DS	CUC5310
GRUNDIG	T63-539	CUC5312
GRUNDIG	T63-540E	CUC5310
GRUNDIG	T63-6335 TEXT	CUC5310
GRUNDIG	T63-640A FT	CUC6310
GRUNDIG	T63-640FT	CUC5310
GRUNDIG	T63-671 TEXT	CUC5361
GRUNDIG	T63-745S	CUC6310
GRUNDIG	T6332 CTI	CUC3410
GRUNDIG	T6334VC	CUC4410
GRUNDIG	T6348 TEXT	CUC6310
GRUNDIG	T636335 TEXT	CUC5310
GRUNDIG	T655 TEXT	CUC5301
GRUNDIG	T66-240	CUC2410
GRUNDIG	T66-240 CTI	CUC2410
GRUNDIG	T66-240 CTI-TT	CUC2410
GRUNDIG	T66-2401 CTI-TT	CUC2410
GRUNDIG	T66-2401SK	CUC2410
GRUNDIG	T70-1020	4400 PROFESSIONAL (PCB: 4410)
GRUNDIG	T70-1021	E9A ?
GRUNDIG	T70-340 CTI	CUC3410
GRUNDIG	T70-360 CTI	CUC3510
GRUNDIG	T70-440 OIRT	CUC4410
GRUNDIG	T70-540 TEXT	CUC5310
GRUNDIG	T70-549	CUC5312
GRUNDIG	T70-640 TEXT	CUC5310
GRUNDIG	T70-640A TEXT	CUC6310
GRUNDIG	T70-740 TEXT	CUC6310
GRUNDIG	T70-740/4	CUC6310
GRUNDIG	T70-745S EURO	CUC6310
GRUNDIG	T70-843 FR	CUC6310
GRUNDIG	T72-8300	16.x (BEKO)

Brand	model	chassis
GRUNDIG	T755 TEXT ATHEN	CUC7300
GRUNDIG	Tharus20--LCD51-9510 TOP	L5A (BEKO)
GRUNDIG	Torreon32--LXW82-8790REF	LC32IEA2
GRUNDIG	Trutzenstein 8276	GSC700
GRUNDIG	TV MAX E55-700 TOP/LOG	CUC6450
GRUNDIG	TV MAX E55-700/9 TOP/LOG	CUC6450
GRUNDIG	TVC7000EURO	CUC4511
GRUNDIG	TVD37-2401	D5
GRUNDIG	TVR3715	(Orion chassis)
GRUNDIG	TVR3735 FR	CP425G
GRUNDIG	TVR3740 FR	CP425G
GRUNDIG	TVR3805	(VMA230A)
GRUNDIG	TVR3815	(VMA230A)
GRUNDIG	TVR4500 CTI	CUC4100
GRUNDIG	TVR4500 GB	CUC4100
GRUNDIG	TVR4510	CUC4100
GRUNDIG	TVR5120	(VMA239A W)
GRUNDIG	TVR5500 CTI	CUC2500
GRUNDIG	TVR5504 CTI	CUC3500
GRUNDIG	TVR5505	CUC3500
GRUNDIG	TVR5510	CUC4100
GRUNDIG	TVR5540 FR	CP425G
GRUNDIG	TVR6300 CTI	CUC2600
GRUNDIG	TVR6300A CTI	CUC3600
GRUNDIG	TVR6305	CUC3600
GRUNDIG	Vision26--LXW68-8510 TOP	L6B (BEKO)
GRUNDIG	Vision32--LXW82-8510 TOP	L6B (BEKO)
GRUNDIG	Vivance32--LXW82-6710REF	LM (Beko)
GRUNDIG	W70-2020	E12 (?) (ELBE)
GRUNDIG	W70-2030	E9 (Anglia)
GRUNDIG	W70-685 PIP/TX/EURO	CUC5371
GRUNDIG	W82-2030	E9
GRUNDIG	WF56-3020	2550 (Włochy)
GRUNDIG	WF70-3020	Orion chassis, same as Matsui
GRUNDIG	WF70-3020	28WN05A (PCB TMA520B sub-PCB TMA520A (TMA521A)

Brand	model	chassis
GRUNDIG	WF82-3020	4400 PROFESSIONAL (PCB: 4410)
GRUNDIG	XEDANCE 72 Flat--MF72-3310/7 DOLBY	22.1 (BEKO)
GRUNDIG	XEDANCE 72 Flat--MF72-3310/7 TOP	22.1 (ZA1.190-12) (BEKO)
GRUNDIG	XEDANCE 82 Flat MFW82-3310/7 Dolby	22.1 (BEKO)
GRUNDIG	Xentia 32--LXW82-8625REF	D32IE11
GRUNDIG	Xentia 37--LXW94-8625REF	D32IE11
GRUNDIG	Xentia 42--LXW110-8625REF	D32IE11
GRUNDIG	XENTIA 55 ST55-400 DOLBY	CUC2021N
GRUNDIG	XENTIA 55 ST55-400 FR/DOLBY	CUC2021F
GRUNDIG	XENTIA 55 ST55-400 NIC/DOLBY	CUC2021
GRUNDIG	XENTIA 63 M63-400/8	CUC1836 (Basic++)
GRUNDIG	XENTIA 63 M63-400/8 DOLBY	CUC1837
GRUNDIG	XENTIA 72 Flat MF72-490 DOLBY	CUC1832 (Basic 3)
GRUNDIG	XENTIA 72 Flat MF72-490/8 DOLBY	CUC1832 (Basic 3)
GRUNDIG	XENTIA 72 M72-400 DOLBY	CUC1832 (Basic 3)
GRUNDIG	XENTIA 72 M72-400/8	CUC1832 (Basic 3)
GRUNDIG	XENTIA 82 Flat MF82-490/9 DOLBY	CUC1931 (Basic 3)
GRUNDIG	XENTIA M72-420/8 DOLBY	CUC1838
GRUNDIG	XENTIA MF29-493S	GR480
GRUNDIG	XENTIA21--PT3421NXS	K2
GRUNDIG	XENTIA26--68-7410 TOP	(G.BB96-00=GBB9600)
GRUNDIG	Xephia 42PW 110-5510 TOP	P7
GRUNDIG	Xephia 42PW110-5501 TOP	P7
GRUNDIG	Xephia 42PW110-6605	P7 (BEKO)
GRUNDIG	Xephia26--LXW68-5500 TOp	L6B (BEKO)
GRUNDIG	Xephia32--LXW82-5500 TOp	L6B (BEKO)
GRUNDIG	XS55	CUC5350
GRUNDIG	XS55/1	CUC7350
GRUNDIG	XS63	CUC5360
GRUNDIG	XS63/1	CUC6360
GRUNDIG	XS70	CUC5361
GRUNDIG	XS70/1	CUC6360
HAIER	HT2180	HH
HANSEATIC		TV4
HANSEATIC	318/724	F9-01

Brand	model	chassis
HANSEATIC	6710VT	COMPACT D-E
HANSEATIC	6720	TV8
HANSEATIC	6720--STV12-6714/P	TV12
HANSEATIC	6720VT	TV12
HANSEATIC	6720VT	TV8
HANSEATIC	6720VT	TV8
HANSEATIC	714/136	F6.00
HANSEATIC	714/181	F6.00
HANSEATIC	714/205	F6.00
HANSEATIC	714/249	F6.00
HANSEATIC	714/250	F6.00
HANSEATIC	714/379	F6.00
HANSEATIC	714/390	F6.00
HANSEATIC	714/415	F6.00
HANSEATIC	714/426	F6.00
HANSEATIC	714/437	F6.00
HANSEATIC	714/710	F6.00
HANSEATIC	714/798	F6.00
HANSEATIC	714/823	F6.00
HANSEATIC	714/889	F6.00
HANSEATIC	728/522	PC42C
HANSEATIC	CKT9825	PC91A
HANSEATIC	CTV100-70	DTV101
HANSEATIC	CTV2082VT	PC31A
HANSEATIC	CTV2083VT	CP005
HANSEATIC	CTV2084	CP375
HANSEATIC	CTV2084VT	CP375
HANSEATIC	CTV2084VT-A	CP375L
HANSEATIC	CTV2092	CP185
HANSEATIC	CTV2192	PC42C
HANSEATIC	CTV2192VT	PC42C
HANSEATIC	CTV2195	CP380L
HANSEATIC	CTV2195A-VT	CP385
HANSEATIC	CTV2195VT	CP380L
HANSEATIC	CTV70-110	TV17.1 (?)

Brand	model	chassis
HANSEATIC	CTV70-113	SCC113 (ELBIT)
HANSEATIC	CTV70-113 PIP	SCC113
HANSEATIC	CTV70-130	CUC1836
Hanseatic	CTV70-1650S	WP895/CP885
HANSEATIC	CTV70-1691	CP810
HANSEATIC	CTV70-1691	CP810
HANSEATIC	CTV70-1691	WP811
HANSEATIC	CTV70-1692S	20.2 (100Hz) ! (plyta: 7UZ.190-07 BEKO)
HANSEATIC	CTV70-2000	CP830
HANSEATIC	CTV70-6000S	WP895/CP885
HANSEATIC	CTV7008--TV-8-70315ip	TV8
HANSEATIC	CTV7010	TV8
HANSEATIC	CTV7010--TV9.1-70216.13/P	TV9.1
HANSEATIC	CTV70100	TV17 (100Hz)
HANSEATIC	CTV70113 PIP	SCC113 (ELBIT)
HANSEATIC	CTV701650S	CP830
HANSEATIC	CTV701692S	20.2 (100Hz) (BEKO)
HANSEATIC	CTV702000	CP830
HANSEATIC	CTV70224P	DTV101
HANSEATIC	CTV7028	TV4
HANSEATIC	CTV7030	TV9.1
HANSEATIC	CTV7035	FM100-30 ?
HANSEATIC	CTV7035	TV9.6
HANSEATIC	CTV7036	CUC2032
Hanseatic	CTV7038VT	CP785
HANSEATIC	CTV7110	TV9.1
HANSEATIC	CTV82-1692S	20.2 (BEKO)
HANSEATIC	CTV821692S	20.2 (100Hz) (BEKO)
HANSEATIC	CTVT2195SVT	CP385
HANSEATIC	DTV2-7032-11	DTV2
HANSEATIC	DTV6714	DTV1
HANSEATIC	FT67	DTV1
HANSEATIC	FT70	DTV1
HANSEATIC	T7125 PIP	DTV3
HANSEATIC	TV101	DTV101

Brand	model	chassis
HANSEATIC	TV1410	PICO D
HANSEATIC	TV2181VT	PC31A
HANSEATIC	TV5520	TV4
HANSEATIC	TV5525	TV4
HANSEATIC	TV70-405	SCC103 (ELBIT)
HANSEATIC	TV70113	SCC113 (ELBIT)
HANSEATIC	TV701692S	20.2 (100Hz) (BEKO)
HANSEATIC	TV70315	TV8
HANSEATIC	TV70330SAT	SCC103 (ELBIT)
HANSEATIC	TV70405	SCC103 (ELBIT)
HANSEATIC	TV70450 CTI	SCC103 (ELBIT)
HANSEATIC	TV7070	SCC103 (ELBIT)
HANSEATIC	TV7111	STV12
HANSEATIC	TVR2120	CP420
HAPO	GPM3915	K3915
HARVARD	CTV3409	11AK08
HARVARD	CTV3459	11AK08
HARVARD	GTV147	11AK08-9A
HARWOOD	CT14	Fidelity ZX4000
HARWOOD	CTV1401	Fidelity ZX4000
HARWOOD	Har14	Fidelity ZX4000
HECO	TC9201	MSC1
HECO	TC9301	MSC1
HECO	TC9401	MSC1
HECO	TC9501	MSC1
HINARI	14T1	CP370
HINARI	20T1	CP370
HINARI	21T1	CP370
HINARI	CT20	BS665
HINARI	CT21	PB2001VS
HINARI	CTV2101R	PB2001VS
HINARI	CTV3409	11AK08
HINARI	CTV3459	11AK08
HINARI	GTV147	11AK08-9A
HISAWA	XF82H100	20.2 (100Hz) (BEKO)

Brand	model	chassis
HITACHI	13GA1B	FH92XS2
HITACHI	20CX20B501	NA6L
HITACHI	20CX20B511	NA6L
HITACHI	20CX20B521	NA6L
HITACHI	26K70	K
HITACHI	27AX0B/C730	M1CLXU
HITACHI	27AX3B/C731	M1CLXU
HITACHI	27AX4B/C732	M1CLXU
HITACHI	27GX01B	NA8
HITACHI	27UX01B	NA8
HITACHI	32FX48B	M7LXU2
HITACHI	32HDT50	PT3E
HITACHI	32HDT55	PT3E
HITACHI	32UX58B	M7LXU2
HITACHI	36FX48B	M7LXU2
HITACHI	36UX58B	M7LXU2
HITACHI	42HDT50	PT3G
HITACHI	42HDT55	PT3G
HITACHI	42PD6600	17MB15 (?)
HITACHI	43FDX01B	DP05/DP05F
HITACHI	43GX01B	AP02
HITACHI	50HDT50M	PT3H
HITACHI	50HDT55M	PT3H
HITACHI	51F510	DP43
HITACHI	51F59	DP65
HITACHI	51F710	DP45
HITACHI	51F710	DP45
HITACHI	51F710A	DP55
HITACHI	51S500	DP37
HITACHI	51S715	DP47
HITACHI	51S715	DP47
HITACHI	53FDX01B	DP05/DP05F
HITACHI	53SDX01B	DP06
HITACHI	53UWX10BA	DP15
HITACHI	55EX1K	AP12

Brand	model	chassis
HITACHI	55FX48B	AP82
HITACHI	55HDS69	DW2U
HITACHI	55HDT79	DW2U
HITACHI	55HDX99	DW2U
HITACHI	57F510	DP43
HITACHI	57F59	DP65
HITACHI	57F710	DP45
HITACHI	57F710	DP45
HITACHI	57F710A	DP55
HITACHI	57S500	DP37
HITACHI	57S715	DP47
HITACHI	57S715	DP47
HITACHI	61HDX98B	DP85
HITACHI	61SDX01B	DP06
HITACHI	65F710	DP45
HITACHI	65F710	DP45
HITACHI	65F710A	DP55
HITACHI	65S500	DP37
HITACHI	AVC50	AVC3U
HITACHI	AVC51	AVC3U
HITACHI	C1410R	MONO PLUS
HITACHI	C1410T	MONO PLUS
HITACHI	C1420VT	CP375
HITACHI	C1422R	F1R (Tatung)
HITACHI	C1422T	F1Y (Tatung)
HITACHI	C14D24	11AK46
HITACHI	C14GM10	G7N
HITACHI	C14P216	G7PS
HITACHI	C15P108	L
HITACHI	C1714TE	A15
HITACHI	C2045MS	V2
HITACHI	C2048FS	V2
HITACHI	C2081MS	V2
HITACHI	C2081MSR	V2
HITACHI	C2086FS	V2

Brand	model	chassis
HITACHI	C2120PN	V2
HITACHI	C2121T	CP375
HITACHI	C2122T	F4Y
HITACHI	C2123MN	V2
HITACHI	C2125MS	V2
HITACHI	C2128FS	V2
HITACHI	C2133MN	S3-M3
HITACHI	C2135MN	V1 (czy? S3-M3)
HITACHI	C2145MS	V2
HITACHI	C2146	G8Q
HITACHI	C2146TN	G8Q
HITACHI	C2148FS	V2
HITACHI	C2156TN	A7 ?
HITACHI	C2172MS	S3
HITACHI	C2173MS	S3
HITACHI	C2176PX	S3
HITACHI	C2178FS	S3
HITACHI	C2181MS	V2
HITACHI	C2181MSR	V2
HITACHI	C2186FS	V2
HITACHI	C2196	G8Q
HITACHI	C2198	G8Q
HITACHI	C2198FS	V2
HITACHI	C21F60S	V2F1 ?
HITACHI	C21FL21F	V3AR
HITACHI	C21FL55A	V3AR
HITACHI	C21P226	G8Q
HITACHI	C21P226B	G8Q
HITACHI	C21P228	G8Q
HITACHI	C21P510	G8P
HITACHI	C21P720	M2
HITACHI	C21P745VT	M2
HITACHI	C21P818	G8Q
HITACHI	C21P819	G8Q
HITACHI	C21P820	G8Q

Brand	model	chassis
HITACHI	C21RM25S	V3AR
HITACHI	C21RM27S	V3AR
HITACHI	C21S250	G8Q
HITACHI	C21S720	M2
HITACHI	C21S820	G8Q
HITACHI	C21TF651	T1
HITACHI	C24W410SN	A7
HITACHI	C24W430N	A7
HITACHI	C24W511TN	A7
HITACHI	C24W511TN	SM00022 ?
HITACHI	C2519	G8Q
HITACHI	C2519R	G8Q
HITACHI	C2519T	G8Q
HITACHI	C2519TG	G8Q
HITACHI	C2544TN	G10
HITACHI	C2548TN	A6
HITACHI	C2556TN	A7
HITACHI	C2556TN2	SM00022 ?
HITACHI	C2558	G8Q
HITACHI	C2558N	G8Q
HITACHI	C2558T	G8Q
HITACHI	C2558TN	G8Q
HITACHI	C2564TN	G10
HITACHI	C2575TN	A5
HITACHI	C2576TN	A5
HITACHI	C2577TN	A5
HITACHI	C2578	G8Q
HITACHI	C2578FS	V1
HITACHI	C2586TN	A7
HITACHI	C2589FS	V1
HITACHI	C2596	G8Q
HITACHI	C2598	G8Q
HITACHI	C2598A	G8Q
HITACHI	C25FL30S	V1F2
HITACHI	C25P226	G8Q

Brand	model	chassis
HITACHI	C25P2268	G8Q
HITACHI	C25P228	G8Q
HITACHI	C25P238	G8Q
HITACHI	C25P440VT	K30
HITACHI	C25P445VT	M2
HITACHI	C25P500	G7P
HITACHI	C25P510	G8P
HITACHI	C25P720	M2
HITACHI	C25P740VT	M90
HITACHI	C25P745VT	M2
HITACHI	C25P750	M2
HITACHI	C25P811	G8P
HITACHI	C25S250	G8Q
HITACHI	C25S250	G8Q
HITACHI	C25S445	M2
HITACHI	C25S720	M2
HITACHI	C25S750	M2
HITACHI	C25S7L	EE6 (?)
HITACHI	C25TF300S	V1F2
HITACHI	C25TF750S	V3AL3
HITACHI	C28300	A5
HITACHI	C2842 N	11AK19PP
HITACHI	C2844TN	G10
HITACHI	C2856TN	A7
HITACHI	C2859RA	G8Q
HITACHI	C2864TN	G10
HITACHI	C2886TN	A7
HITACHI	C2886TN	A7
HITACHI	C28P405VT	M90
HITACHI	C28P440VT	K30
HITACHI	C28P445VT	M2 (STB350)
HITACHI	C28P500	G7P
HITACHI	C28P510	G8P
HITACHI	C28P510E	G7P
HITACHI	C28P720	M2

Brand	model	chassis
HITACHI	C28P745VT	M2
HITACHI	C28P750	M2
HITACHI	C28P811	G8P
HITACHI	C28S445	M2
HITACHI	C28S720	M2
HITACHI	C28S750	M2
HITACHI	C28W1TN (G5AVY261)	A7
HITACHI	C28W410SN	A7
HITACHI	C28W410TN	A7
HITACHI	C28W410TN	SM00022 ?
HITACHI	C28W411TN	A7
HITACHI	C28W430N	A7
HITACHI	C28W433N	A7
HITACHI	C28W440N	11AK33J4
HITACHI	C28W510SN	A7
HITACHI	C28W510TN	A7
HITACHI	C28W511NA	A7
HITACHI	C28WF523N	A8
HITACHI	C28WF560N	11AK45B5 (?)
HITACHI	C2975TN	A5
HITACHI	C2976TN	A5
HITACHI	C2977TN	A5
HITACHI	C2978FS	V1
HITACHI	C2988FS	MCL437F ?
HITACHI	C2989FS	V1
HITACHI	C29F100	V1F
HITACHI	C29F300B	V3AL1 ?
HITACHI	C29TF650S	MCL437F
HITACHI	C32W1TN	A7
HITACHI	C32W35TN	(E6548001B)
HITACHI	C32W433N	A7
HITACHI	C32W510SN	A7
HITACHI	C32W511TN	A7
HITACHI	C32WD2TN2	A7
HITACHI	C3390FSP	S6

Brand	model	chassis
HITACHI	C3399FSP	S6
HITACHI	C33P900	G8P
HITACHI	C33S900	G8P
HITACHI	C43FD5000	DP3M
HITACHI	C5068FS	AP7M
HITACHI	C50F200P	AP7M3
HITACHI	C50FD5000	DP3M
HITACHI	CAP166	NP8C
HITACHI	CAP167DS	NP8C
HITACHI	CDH29GS2	H902F
HITACHI	CEP138	NP6C
HITACHI	CEP286	NP6C
HITACHI	CL1422R	F1FR
HITACHI	CL2026S	11AK30
HITACHI	CL2121T	CP375
HITACHI	CL2122R	F4FR
HITACHI	CL2131	Eurostereo2B
HITACHI	CL2133TA	STEREO PLUS
HITACHI	CL2159TA	G8Q
HITACHI	CL2542TA	EUROSTEREO2
HITACHI	CL2543	G8Q ?
HITACHI	CL2543TA	11AK19P4
HITACHI	CL2554AN	CP785
HITACHI	CL2556TAN2	SM00022 ?
HITACHI	CL2559	G8Q
HITACHI	CL2559RA	G8Q
HITACHI	CL2559TA	G8Q
HITACHI	CL2560TA	G10
HITACHI	CL2562TA	EURO-DIGI 4/3
HITACHI	CL2564TA	G10
HITACHI	CL2572TA	EURO-DIGI 4/3
HITACHI	CL2576TAN	A5
HITACHI	CL2836AN	A4
HITACHI	CL2837TAN	A7
HITACHI	CL2840TA	EUROSTEREO2

Brand	model	chassis
HITACHI	CL2840TAN	A7
HITACHI	CL2842TA	EUROSTEREO2
HITACHI	CL28500TAN	A5WK 100Hz
HITACHI	CL2859	G8Q
HITACHI	CL2859RA	G8Q
HITACHI	CL2859TA	G8Q - NIE!!!
HITACHI	CL2860TA	G10
HITACHI	CL2862TA	EURO-DIGI 4/3
HITACHI	CL2864TA	G10
HITACHI	CL2893TAN	A5WK 100Hz
HITACHI	CL2894TAN	FEATURE STEREO
HITACHI	CL28W410TAN	A7
HITACHI	CL28W410TAN	SM00022 ?
HITACHI	CL28W440AN	11AK33J4
HITACHI	CL2965TAN	SM00022 ?
HITACHI	CL2976TAN	A5
HITACHI	CL2995TAN	A5WK 100Hz
HITACHI	CL3290	EURO-DIGI 16/9
HITACHI	CL3290TANX	EURO-DIGI 16/9
HITACHI	CL32WD2TAN2	A7
HITACHI	CL32WD2TAN2	SM00022 ?
HITACHI	CL32WF720AN	A8
HITACHI	CL3370TA	EURO-DIGI 4/3
HITACHI	CMT1450	G7PN26
HITACHI	CMT1471	S3
HITACHI	CMT1472	CTV1401
HITACHI	CMT1473	S3
HITACHI	CMT1496	S2
HITACHI	CMT2077	S2
HITACHI	CMT2090	S2
HITACHI	CMT2097	S2
HITACHI	CMT2114	G7PN24
HITACHI	CMT2130	NP84C22
HITACHI	CMT2139	G7PN-M
HITACHI	CMT2141	G7PN24

Brand	model	chassis
HITACHI	CMT2157	SO
HITACHI	CMT2178	S3
Hitachi	CMT2186	S2-M3SP
HITACHI	CMT2187	S2
HITACHI	CMT2191	S2-M3
HITACHI	CMT2192	S3-M3
HITACHI	CMT2193	A1PS
HITACHI	CMT2196	S2
HITACHI	CMT2198	S2
HITACHI	CMT2199	S2
HITACHI	CMT2400	G7PN-M6 (?)
HITACHI	CMT2519	G9PL2
HITACHI	CMT2578	V1
HITACHI	CMT2579	S2-M4
HITACHI	CMT2598	A3P
HITACHI	CMT2719	G9PL2
HITACHI	CMT2919	G9PL2
HITACHI	CMT2968	A3P
HITACHI	CMT2978	V1
HITACHI	CMT2990	S6
HITACHI	CMT2998	A3P
HITACHI	CMT3398	A3P
HITACHI	CMT4200	VP9M
HITACHI	CP1410T	MONO PLUS
HITACHI	CP1422R	F1GR
HITACHI	CP1422T	F1GY
HITACHI	CP1432RB	FY
HITACHI	CP1432TB	F1R
HITACHI	CP2022R	F2KR
HITACHI	CP2022T	F2GY
HITACHI	CP2025	11AK19PP
HITACHI	CP2111R	CP330
HITACHI	CP2121T	CP375
HITACHI	CP2122R	F4GR
HITACHI	CP2122T	F4GY

Brand	model	chassis
HITACHI	CP2125T	11AK19PP
HITACHI	CP2133TA	STEREO PLUS
HITACHI	CP2142	11AK19Y4
HITACHI	CP2146TA	CP46TA
HITACHI	CP2556TA2	SM00022 ?
HITACHI	CP2556TAN	A7 ?
HITACHI	CP2556TAN2	SM00022 ?
HITACHI	CP2576TAN	A5
HITACHI	CP2586TAN	A7 ?
HITACHI	CP2837TA	SM00022 ?
HITACHI	CP2837TAN	SM00022 ?
HITACHI	CP2840TAN	EUROSTEREO2B-F ?
HITACHI	CP2841TA	A4 ?
HITACHI	CP2842AN	11AK19Y4
HITACHI	CP2851TAN	A7
HITACHI	CP2856TAN	A7 ?
HITACHI	CP2886TAN	A7 ?
HITACHI	CP2893TAN	A5WK 100Hz
HITACHI	CP2894TAN	FS
HITACHI	CP2896TAN	MX
HITACHI	CP28W410TAN	A7
HITACHI	CP28W410TAN	SM00022 ?
HITACHI	CP2965TA	SM00022 ?
HITACHI	CP2965TAN	SM00022
HITACHI	CP2965TAN	SM00022 ?
HITACHI	CP2976TAN	A5
HITACHI	CP2994TAN	FS 100Hz
HITACHI	CP2996TAN	MX
HITACHI	CPT1351	NP80C2
HITACHI	CPT1352	NP80C2
HITACHI	CPT1353	NP80C2
HITACHI	CPT1420R	EI11271
HITACHI	CPT1455-301	NP84CQ
HITACHI	CPT1455-331	NP84CQ
HITACHI	CPT1455-341	NP84CQ

Brand	model	chassis
HITACHI	CPT1455-361	NP84CQ
HITACHI	CPT1456-331	NP84CQ
HITACHI	CPT1456-341	NP84CQ
HITACHI	CPT1456-361	NP84CQ
HITACHI	CPT1456SK	NP84CQ
HITACHI	CPT1471	NP80C2
HITACHI	CPT1472	NP80C2
HITACHI	CPT1473	NP80C2
HITACHI	CPT1474	NP80C2
HITACHI	CPT1475	NP80C2
HITACHI	CPT1476	NP80C2
HITACHI	CPT1477	NP80C2
HITACHI	CPT1478	NP80C2
HITACHI	CPT1479	NP80C2
HITACHI	CPT1491-311	NP83C2
HITACHI	CPT1492-301	NP84C2
HITACHI	CPT1492-341	NP84C2
HITACHI	CPT1493-311	NP84C2
HITACHI	CPT1494-751	NP84C2
HITACHI	CPT1497-051	NP84C2
HITACHI	CPT1499-081	NP84C2
HITACHI	CPT2020R	EI11271
HITACHI	CPT2020R	NP91 C13.01
HITACHI	CPT2024	NP82CQ
HITACHI	CPT2026	NP83CQ
HITACHI	CPT2028	NP83CQ
HITACHI	CPT2030R	NP94A MONO
HITACHI	CPT2030SR	NP94A STEREO
HITACHI	CPT2036	NP83CQ
HITACHI	CPT2038	NP83CQ
HITACHI	CPT2040	MC14K / MC14A
HITACHI	CPT2044	NP83CQ/2
HITACHI	CPT2046	NP83CQ/2
HITACHI	CPT2048	NP83CQ/2
HITACHI	CPT2050	Salora J22J40

Brand	model	chassis
HITACHI	CPT2051	NP80/CR
HITACHI	CPT2052 N	NP80C
HITACHI	CPT2052 NR	C12.01
HITACHI	CPT2055	NP80C
HITACHI	CPT2066	NP85CQ/2
HITACHI	CPT2068	NP85CQ/2
HITACHI	CPT2071	NP80CR
HITACHI	CPT2084	NP83C
HITACHI	CPT2086	NP83C
HITACHI	CPT2087	NP83C
HITACHI	CPT2088	NP83C
HITACHI	CPT2089	NP83C
HITACHI	CPT2090	S2
HITACHI	CPT2121R	EI11271
HITACHI	CPT2128	G7P
HITACHI	CPT2138	G7P-MK2
HITACHI	CPT2153	SO-P ?
HITACHI	CPT2155	K30
HITACHI	CPT2158-341	NP85CQ
HITACHI	CPT2158C	NP85CQ ?
HITACHI	CPT2196	G8Q
HITACHI	CPT2198	G8Q
HITACHI	CPT2282	F11
HITACHI	CPT2488	K30
HITACHI	CPT2528	G7P
HITACHI	CPT2563PS/VT	K (Salora)
HITACHI	CPT2578	G8Q
HITACHI	CPT2596	G8Q
HITACHI	CPT2598	G8Q
HITACHI	CPT2658	L2
HITACHI	CPT2666PS	K (Salora)
HITACHI	CPT2669PS/VT	K (Salora)
HITACHI	CPT2775PS	K (Salora)
HITACHI	CPT2785PS	K (Salora)
HITACHI	CPT2788PS	K (Salora)

Brand	model	chassis
HITACHI	CPT2789PS/VT	K (Salora)
HITACHI	CPT2828	G7P
HITACHI	CPT2828	G7P
HITACHI	CPT2950R	MCL437F
HITACHI	CPW137	NP6C
HITACHI	CPW350	NP8C2
HITACHI	CRP149	NP6C
HITACHI	CS1422P	16.2 (BEKO)
HITACHI	CS2106R	G7PS3S
HITACHI	CS2122R	F
HITACHI	CS2542TAN	EUROSTEREO2
HITACHI	CS2543TA	EUROSTEREO2B-F
HITACHI	CS2552TA	M2
HITACHI	CS2562TAN	EURO-DIGI 4/3
HITACHI	CS2572TA	EURO-DIGI 4/3
HITACHI	CS2832TA	N
HITACHI	CS2840TA	EUROSTEREO2
HITACHI	CS2842TAN	EUROSTEREO2
HITACHI	CS2852	EURO-DIGI 4/3
HITACHI	CS2852TA	EURO-DIGI 4/3
HITACHI	CS2852TA	M2
HITACHI	CS2862TAN	EURO-DIGI 4/3
HITACHI	CS2872TA	EURO-DIGI 4/3
HITACHI	CS3290TANX	EURO-DIGI 4/3
HITACHI	CS3370TA	EURO-DIGI 4/3
HITACHI	CST2166	K
HITACHI	CT2541	NP83LX
HITACHI	CT2542	NP83LX
HITACHI	CT2543	NP83LX
HITACHI	CTP207	NP6A
HITACHI	CTP215	NP6C
HITACHI	CTP217	NP6C
HITACHI	CTP218	NP8C
HITACHI	CTP235	NP8C
HITACHI	CTP250 DS	NP8C

Brand	model	chassis
HITACHI	CTP251DS	NP8C
HITACHI	CTP252DS	NP8C
HITACHI	CTP2828	G7P
Hometech	CTV2137T	TV2KR (40-MNTV2KR-K5H-M)
HQS	TQ1814	LA3C
HQS	TQ1820	LA3C
HYPSON	29HTV-BO16	HE828A
HYPSON	HY36LSI	CTS-AA? (VM7ASG)
HYUNDAI	CKT9825	PC91A
HYUNDAI	CTV2985RFX	11AK53-3
HYUNDAI	CTV3711SN	11AK36A15
HYUNDAI	HU-D21NK	3N10
HYUNDAI	HU-D25A	5N11
HYUNDAI	HU-D29	5N11
HYUNDAI	HUD25A	5N11
HYUNDAI	HY21N02	3Y03 (?)
HYUNDAI	TV70S-T01 STEREO SILVER	(40STT2822C5A)
ICE	CTV2024	K3910
ICE	TV1050	K3720
ICE	TV1055/2	K3921
ICE	TV2050	K3720
ICS	TV55SVT	K3820
IMPERIAL	15C53 TRINIDAD	960
IMPERIAL	15M63 TOBAGO	960
IMPERIAL	15M63 TOBAGO	960
IMPERIAL	16C53 TAHITI	960
IMPERIAL	17M63 TENNESSEE	960
IMPERIAL	20C76	960
IMPERIAL	21BF88 YALE	960
IMPERIAL	21DX88 MALIBU	960
IMPERIAL	21DX89 DENVER	960
IMPERIAL	22D88 MISSOURI	960
IMPERIAL	22DX88 HARVARD	960
IMPERIAL	25BF88 YUMA	960
IMPERIAL	25DX88	960

Brand	model	chassis
IMPERIAL	25DX88 MEMPHIS	960
IMPERIAL	25DX89 HOUSTON	960
IMPERIAL	2707	960
IMPERIAL	27D88 TEXAS	960
IMPERIAL	27D88 TEXAS	960
IMPERIAL	27DX88 HOLLYWOOD	960
IMPERIAL	28BF88 YORK	960
IMPERIAL	28DX88	990 (?)
IMPERIAL	28DX88 MADISON	960
IMPERIAL	28DX89 DALLAS	960
IMPERIAL	37M22GO	PC230
IMPERIAL	37M88 ONTARIO	960
IMPERIAL	37M88 ONTARIO	960
IMPERIAL	42M88 BRISTOL	960
IMPERIAL	55BF90 SIGMA	960
IMPERIAL	55BF90 SIGMA	960
IMPERIAL	63BF90 SIGMA	960
IMPERIAL	63BF90 SIGMA	960
IMPERIAL	70AX PANORAMA	960
IMPERIAL	70BF90 SIGMA	960
IMPERIAL	70BF90 SIGMA	960
IMPERIAL	70DX92 DELTA	990
IMPERIAL	CTV7971STE TXT	F16 (Formenti)
IMPERIAL	CTV8671	F19
IMPERIAL	CTV8671	F19
IMPERIAL	CTV8671STE TXT	F19
IMPERIAL	CTV8671TXT	F19
Imperial	Dedra 70BF95	F991/1
IMPERIAL	DI TG70 ST28"	FPC2001.0
IMPERIAL	DI7030	FPC2001 (TWIST 28")
IMPERIAL	DIFG51M22X0	FPC2002
IMPERIAL	DIMFL37M12X700	FPC2002.0
IMPERIAL	DITG70S4490	F19
IMPERIAL	DITS70S4490	F19
IMPERIAL	DIVG70SBEF0	PC240

Brand	model	chassis
IMPERIAL	DIVG70SBEFO	PC240
IMPERIAL	DIVV70SBEFD	PC240
IMPERIAL	FX21 PRISMA	960
IMPERIAL	FX25 PRISMA	960
IMPERIAL	FX28 PRISMA	860
IMPERIAL	FX63 THEMA	960
IMPERIAL	FX63 THEMA	960
IMPERIAL	FX70 THEMA	960
IMPERIAL	IF5500	960
IMPERIAL	IF5509	960
IMPERIAL	IF6300	960
IMPERIAL	IF6309	960
IMPERIAL	IF6700	960
IMPERIAL	IF6707	960
IMPERIAL	IF7000	960
IMPERIAL	IF7009	960
IMPERIAL	SAL0227-05	Twist PC2001
IMPERIAL	SS2108	960
IMPERIAL	SS2508	960
IMPERIAL	SS2808	960
IMPERIAL	T670ST28 (TG70ST28)	FPC2001
IMPERIAL	T70	FPC2001
IMPERIAL	TV85CM	F19
IMPERIAL	TV85CM9Z85	F19
IMPERIAL	TVC2H37TI	F24
IMPERIAL	TVC2H37TI TXT	F24 ?
IMPERIAL	TVC85CM9Z85	FPC2001 Twist (?)
INGELEN	4126	MONOPRINT B
INGELEN	4227	MONOPRINT B
INGELEN	4327	MONOPRINT B
INGELEN	7226	PICO S/3
INGELEN	7325	PICO S/3
INGELEN	HB32100 BOZEN	20.2 (100Hz) (BEKO)
INGELEN	HB32100BO	20.2 (BEKO)
INGELEN	HB71100 BADEN	20.2 (100Hz) (BEKO)

Brand	model	chassis
INGELEN	HB71100BA	20.2 (BEKO)
INGELEN	HB7120100	20.2 (100Hz) (BEKO)
INGELEN	HB72100 MUNCHEN	20.2 (100Hz) (BEKO)
INGELEN	HB72100 TRAISEN	20.2 (100Hz) (BEKO)
INGELEN	HB72100TR	20.2 (BEKO)
INGELEN	HB74100 KOESSEN	20.2 (100Hz) (BEKO)
INGELEN	HB74100KO	20.2 (BEKO)
INGELEN	HB82100 BERLIN	20.2 (100Hz) (BEKO)
INGELEN	HB84100 GRIFFEN	20.2 (100Hz) (BEKO)
Interbuy	20BZC	PW1644
INTERBUY	M530	P51-28 ?
INTERFUNK	5437 15 81	COMPACT D2 S4 SQ
INTERFUNK	9325	PICO S/3
INTERFUNK	9425	COMPACT 80R
INTERFUNK	9466	COMPACT 80R
INTERFUNK	9468	COMPACT D2
INTERFUNK	9570PSVT	COMPACT D-E
INTERFUNK	9866	COMPACT R2
INTERFUNK	9868	COMPACT D-E
INTERFUNK	9870PSVT	COMPACT D-E
INTERFUNK	IF7070	F990
INTERVISION	CTV2870	PT92
INTERVISION	CTV3710VT	NM
INTERVISION	CTV3740	GT9313
INTERVISION	CTV5112	10.2 (SIESTA60Z110)
INTERVISION	CTV7099MS--TV-8-70216/E	TV8 ?
ITS	TV1050	K3720
ITS	TV2050	K3720
ITS	TV55SVT	K3820
ITS	TV56SVT	K3820
ITT	1525HS	EUROMONO
ITT	1530HS	EUROMONO
ITT	1725HS	EUROMONO
ITT	1725HS	EUROMONO2
ITT	1730HS	EUROMONO

Brand	model	chassis
ITT	1730HS	EUROMONO2
ITT	17C20	CORE2
ITT	185552565	EUROSTEREO2
ITT	185631735	EUROSTEREO2
ITT	185631765	EUROSTEREO2
ITT	185632565	EUROSTEREO2
ITT	185701735	EUROSTEREO2
ITT	185701765	EUROSTEREO2
ITT	185702565	EUROSTEREO2
ITT	1878	FFS021
ITT	2124HS	EUROMONO
ITT	2130HS	EUROMONO2
ITT	2151VT	COMPACT D-E (90°) FST
ITT	2160	CORE2
ITT	2161	COMPACT D-E
ITT	21C40	CORE2
ITT	21C60	CORE2
ITT	21D61	COMPACT D-E
ITT	21D70	COMPACT D2
ITT	2327PS	MONOPRINT B
ITT	2560	COMPACT D2
ITT	2561	COMPACT D-E
ITT	2571	COMPACT D-E
ITT	25D70	COMPACT D2
ITT	25D80	COMPACT D2
ITT	25N8C	EUROSTEREO2
ITT	26A42	COMPACT D2
ITT	2805	FFS021
ITT	2805PS	FFS021
ITT	2861	COMPACT D-E
ITT	28FHD7050H	PCB2550
ITT	3106	MONOPRINT A
ITT	3125	PICO S/3
ITT	3126	MONOPRINT B
ITT	3164	MINI2 (5861 64 60)

Brand	model	chassis
ITT	3207	MONOPRINT A
ITT	3225	PICO S
ITT	3226	CORE2
ITT	3226	PICO S/3
ITT	3227	MONOPRINT B
ITT	32F8	EURO-DIGI
ITT	3323	CORE2
ITT	3325	COMPACT 80R
ITT	3325	PICO S/3
ITT	3327	MONOPRINT B
ITT	3446	DIGITAL3
ITT	3466	DIGITAL3
ITT	3476	DIGITAL3
ITT	3486HIFI	DIGITAL3
ITT	3487HIFI	DIGITAL3
ITT	3489	COMPACT D2
ITT	3498	COMPACT D2
ITT	3546	DIGITAL3
ITT	3567OSCAR	MONO PLUS (STEREO)
ITT	3568	COMPACT D2
ITT	3568 Stereo/TTX	COMPACT D2 S4 SQ
ITT	3569	COMPACT D2
ITT	3570	COMPACT D-E
ITT	3575EX	EUROSTEREO1
ITT	3576HIFI	DIGITAL3
ITT	3588	COMPACT D S4 SQ
ITT	3721	MONO PLUS2
ITT	3722	Core Kit MN NR 220V AC
ITT	3724	MONO PLUS (5864 6. ..)
ITT	3724VT	MONO PLUS
ITT	3725	COMPACT 80R
ITT	3725VT	MONO PLUS
ITT	3758	COMPACT 80R
ITT	3760	COMPACT D2
ITT	3767	DIGITAL3

Brand	model	chassis
ITT	3868	COMPACT D2
ITT	3869	COMPACT D2
ITT	3875	EUROSTEREO1
ITT	3876	DIGITAL3
ITT	3878	DIGITAL B/E
ITT	4000	M1
ITT	4030	CORE2
ITT	4032	EUROMONO2
ITT	4126	CORE2
ITT	4126	MONOPRINT B
ITT	4210	CORE2
ITT	4226	PICO S/3
ITT	4227	MONOPRINT B
ITT	4325	COMPACT 80R
ITT	4486	DIGITAL3
ITT	4487	DIGITAL3
ITT	4489	COMPACT D2
ITT	4530	CORE2
ITT	4532	EUROMONO2
ITT	4568	COMPACT D2
ITT	4586	DIGITAL3
ITT	4588	COMPACT D2
ITT	4868	COMPACT D2
ITT	4869	COMPACT D2
ITT	4876	DIGITAL3
ITT	5110	CORE2
ITT	5121	MONO PLUS2
ITT	5124VT	MONO PLUS
ITT	5156 NICAM	MONO PLUS (STEREO)
ITT	5166 NICAM	MONO PLUS (STEREO)
ITT	5169	CORE2
ITT	5465	COMPACT 80R
ITT	5467	COMPACT D2
ITT	5521	MONO PLUS2
ITT	5524VT	MONO PLUS

Brand	model	chassis
ITT	5551	COMPACT D-E
ITT	55540 NICAM	STEREO PLUS
ITT	5554VT	STEREO PLUS
ITT	5575SFN	STEREO PLUS
ITT	5575VT	STEREO PLUS
ITT	5576 NICAM	STEREO PLUS
ITT	5576 NICAM	STEREO PLUS
ITT	6330VT EE	CORE2 (110°)
ITT	6332	EUROMONO
ITT	6342	EUROMONO
ITT	6350	COMPACT D2
ITT	6351	COMPACT D-E
ITT	6353	EUROSTEREO2B
ITT	6354NICAM	STEREO PLUS
ITT	6355 NICAM	STEREO PLUS 110°
ITT	63550	STEREO PLUS 110°
ITT	63552F VT	STEREO PLUS 110°
ITT	6357NICAM	STEREO PLUS
ITT	6360	COMPACT D2
ITT	6361	COMPACT D-E
ITT	6362	COMPACT D-E
ITT	6363	EUROSTEREO2
ITT	6364VT	EUROSTEREO2B-F
ITT	6365 NICAM	STEREO PLUS
ITT	6369	COMPACT D2
ITT	6372	EUROSTEREO2
ITT	6374	EUROSTEREO2B-F
ITT	6375	EUROSTEREO FEATURE PLUS
ITT	6376 NICAM	STEREO PLUS
ITT	6376 NICAM	STEREO PLUS
ITT	6380	COMPACT D2
ITT	6381	DIGITAL B-E2
ITT	6382	EUROSTEREO
ITT	6383	EUROSTEREO1
ITT	6384	EURO-DIGI 4/3

Brand	model	chassis
ITT	6385	EUROSTEREO FEATURE PLUS
ITT	6386	FS
ITT	6387	COMPACT D2
ITT	6390	M1
ITT	6390	M1
ITT	6394	EURO-DIGI 4/3
ITT	6395	FX (100Hz)
ITT	6396	FX (100Hz)
ITT	6710	COMPACT D-E
ITT	6855VT	COMPACT R2
ITT	6856	COMPACT D-E
ITT	6887	COMPACT D S4 SQ
ITT	6887	COMPACT D-E
ITT	7018	EURO-DIGI 4/3
ITT	7027	EURO-DIGI 4/3
ITT	7028	EURO-DIGI 4/3
ITT	7069	COMPACT D2
ITT	7071	COMPACT D2
ITT	7092	COMPACT D2
ITT	7092	COMPACT D2
ITT	7126	MONOPRINT B
ITT	7128	EURO-DIGI
ITT	7138	EURO-DIGI 16/9
ITT	7142	EUROMONO
ITT	7155 NICAM	STEREO PLUS
ITT	71550	STEREO PLUS
ITT	71552F VT	STEREO PLUS
ITT	7157NICAM	STEREO PLUS
ITT	7160	COMPACT D2
ITT	7162	EUROSTEREO1
ITT	7163	EUROSTEREO2
ITT	7164	EUROSTEREO2B-F
ITT	7165 NICAM	STEREO PLUS
ITT	7170A	DIGITAL B-E
ITT	7171	DIGITAL B-E2

Brand	model	chassis
ITT	7172	EUROSTEREO2
ITT	7173	EUROSTEREO2B-F
ITT	7174	EUROSTEREO2B-F
ITT	7175 TOP	EUROSTEREO FEATURE PLUS
ITT	7176CLASSIC	STEREO PLUS
ITT	7177	STEREO PLUS
ITT	7180	COMPACT D2
ITT	7181	DIGITAL B-E2
ITT	7182	EUROSTEREO
ITT	7182VT TOP	COMPACT D-E
ITT	7183	EUROSTEREO2
ITT	7184	EURO-DIGI 4/3
ITT	7185	EUROSTEREO FEATURE PLUS
ITT	7186	FS
ITT	7190	M1
ITT	7192	EURO-DIGI 4/3
ITT	7193	EURO-DIGI 4/3
ITT	7194	EURO-DIGI 4/3
ITT	7195	FX (100Hz)
ITT	7196	FX (100Hz)
ITT	7226	PICO S/3
ITT	7291CINESCREEN	EURO-DIGI 16/9
ITT	7293	EURO-DIGI 16/9
ITT	7294	EURO-DIGI 16/9
ITT	7294MAC	EURO-DIGI 16/9
ITT	7325	PICO S/3
ITT	7326	MONOPRINT B
ITT	7327	MONOPRINT B
ITT	7495	EUROSTEREO FEATURE PLUS
ITT	7496	FS
ITT	7496	FX (100Hz)
ITT	7497	FX (100Hz)
ITT	7497DPL	FX (100Hz)
ITT	7876	DIGITAL3
ITT	8228	EURO-DIGI

Brand	model	chassis
ITT	8238	EURO-DIGI 16/9
ITT	8281	DIGITAL B-E2
ITT	8291	EURO-DIGI 16/9
ITT	8293	EURO-DIGI 16/9
ITT	8294	EURO-DIGI 16/9
ITT	8294 SAT	EURO-DIGI 16/9
ITT	8294MAC	EURO-DIGI 16/9
ITT	8294UK	EURO-DIGI 16/9
ITT	8325	PICO S
ITT	852SAT	M1
ITT	853SOLITAR	COMPACT D-E
ITT	8568	COMPACT D2
ITT	8588	COMPACT D2
ITT	882SAT	M1
ITT	883SOLITAR	M1
ITT	885 SAT	M1
ITT	8868	COMPACT D2
ITT	8888	COMPACT D2
ITT	9128	EURO-DIGI
ITT	9291	EURO-DIGI
ITT	9294 SAT	EURO-DIGI 16/9
ITT	9325	PICO S/3
ITT	9470	COMPACT D-E
ITT	9570	COMPACT D-E
ITT	9870	COMPACT D-E
ITT	COLOR 3567 OSCAR	Compact R2 110° !
ITT	COLOR 3758 OSCAR	Compact R2 110°
ITT	CP3128V	CORE2
ITT	CT3306	MONOPRINT A
ITT	CT5110UK	CORE2
ITT	CT5521UK	CORE2
ITT	CT5530V	CORE2
ITT	CT5532UK	EUROMONO2
ITT	DIGIVISION 3598 Hi-Fi	DIGITAL B 110° FST
ITT	DIGIVISION 3878 Hi-Fi	DIGITAL B 110° FST

Brand	model	chassis
ITT	DIGIVISION 3878 Hi-Fi Multinorm	DIGITAL B 110° FST
ITT	DIGIVISION 3988 Hi-Fi	DIGITAL B 110° FST
ITT	DIGIVISION 3988 I Hi-Fi	DIGITAL B 110° FST
ITT	FX4532UK	EUROMONO2
ITT	FX5521UK	CORE2
ITT	FX5532UK	EUROMONO2
ITT	FX6332UK	EUROMONO2
ITT	IDEAL COLOR 3125	PICO S/3
ITT	Ideal Color 3225 OSCAR	PICO S
ITT	IDEAL_COLOR3325OSCAR	COMPACT 80 90°
ITT	IT3025	SS1
ITT	MV4000	M1
ITT	PL14-24101	M1
ITT	SFN5550UK	COMPACT D-E
ITT	SFN5581UK	COMPACT D-E
ITT	SFN6361	COMPACT D-E
ITT	SFN6361UK	COMPACT D-E
ITT	SFN7161	COMPACT D-E
ITT	SFN7161UK	COMPACT D-E
ITT	SP71B1	STEREO PLUS
ITT	SP71D1	STEREO PLUS
ITT	T850	COMPACT D2
ITT	T880	COMPACT D2
IVORY	CT2251	CT5 (CTV5) - ?
JJK	TV3701	SQUAD
JJT	TV3701	SQUAD
JMB	NO28WSS	PT92
JMB	TV1402R	CTU AA
JOYCE	TV2855T--TV9.1-70231	TV9.1
JVC	2151	TX100
JVC	32AVL2EUBL	MF
JVC	32AVL2EUGR	MF
JVC	32AVL2EUGY	MF
JVC	7731R	TX90
JVC	7741R	TX100

Brand	model	chassis
JVC	7742T	TX100
JVC	7831R	TX9 (FERG)
JVC	7832T	TX10
JVC	7841R	TX100
JVC	7842T	TX100
JVC	7933TS	TX10
JVC	7943	TX10
JVC	AK25S1	MX II
JVC	AK28S1	MX II
JVC	AV-A14M2	CL
JVC	AV-A14T3	CG
JVC	AV-A21T2	CL
JVC	AV-B21M	CL
JVC	AV-C21T/E	MZ2
JVC	AV-DT21	CP375
JVC	AV-DT21EBU	CP375
JVC	AV-DT21EE	CP375S !
JVC	AV-DT21ERM	CP375
JVC	AV-DX25	JK
JVC	AV-F21PM	CG-F
JVC	AV-F2983	CM II'
JVC	AV-F2983	CM-II'
JVC	AV-F29MX3	CM-II'
JVC	AV-G14T	CA2
JVC	AV-G14T	CA2
JVC	AV-G21 TR	KA
JVC	AV-G21 TR	KA ? (czy? CA2)
JVC	AV-G210T	KA
JVC	AV-G210T	KA
JVC	AV-G21T	(SCA1018A)
JVC	AV-G21TT	KA ? (czy? CA2)
JVC	AV-G250MX	KA
JVC	AV-G250MX	KA
JVC	AV-G25MX	MZ2 (MZ II)
JVC	AV-G29MX	KA

Brand	model	chassis
JVC	AV-G29MX	KA
JVC	AV-K21 TR	CL
JVC	AV-K21T2LB	CL
JVC	AV-N21115	FV3
JVC	AV-N21120	FV3
JVC	AV-N21202	FV4
JVC	AV-N21203	FV5
JVC	AV-N21204	FV6
JVC	AV-N21F45	FJ2
JVC	AV-N21F45	FJ2
JVC	AV-N21F46	FJ3
JVC	AV-N280	BY II
JVC	AV-N280EKT	BY II
JVC	AV-N29101	GF2
JVC	AV-N29115	FV3
JVC	AV-N29120	FV3
JVC	AV-N29220	FV4
JVC	AV-N29301	GF2
JVC	AV-N29302	FD
JVC	AV-N29303	FE
JVC	AV-N29304	FE2
JVC	AV-N29320	FE
JVC	AV-N29401	GF2
JVC	AV-N29430	FE2
JVC	AV-N29702/S	AC
JVC	AV-N29703	GJ
JVC	AV-N29F46/R	GJ5
JVC	AV-N29F46/S	GJ5
JVC	AV-N34301	GF2
JVC	AV-N34301	GF2
JVC	AV-N34F46/Y	GJ5
JVC	AV-N34F46/Z	GJ5
JVC	AV-N65P74	SB3
JVC	AV-S21X1	KY (?)
JVC	AV-S250	BX II

Brand	model	chassis
JVC	AV-S250EGT	BY II
JVC	AV-S250EK	BX II
JVC	AV-S250M	BY I
JVC	AV-S25M1S	KX 25"
JVC	AV-S280EGT	BY II
JVC	AV-S280ET	BY II
JVC	AV-S290M	BY I (Uwaga: BY I = BY)
JVC	AV-S29M1S	KX
JVC	AV-S29MS6	CD
JVC	AV-S33MS6	CD
JVC	AV-T2912AR	GA
JVC	AV-T2922	GA
JVC	AV-T2982	GA (?)
JVC	AV-T2982AR	GA
JVC	AV029MX	KA
JVC	AV14 FR10	CG
JVC	AV1404F	CW
JVC	AV1410EE	CL
JVC	AV1413EE	CG
JVC	AV1414EE	CG
JVC	AV1414F	CW
JVC	AV1415EE	CG
JVC	AV1434EE	CG
JVC	AV1435 AV1435EE AV1435TEE	CG
JVC	AV1435EE	CG
JVC	AV1436EE	CG
JVC	AV1438	CG
JVC	AV14A10	CG
JVC	AV14A3	CG
JVC	AV14A4EE	CG
JVC	AV14AG16	CG4
JVC	AV14AM	CG
JVC	AV14AMG3	CG
JVC	AV14AT	CG
JVC	AV14ATG	CG

Brand	model	chassis
JVC	AV14BJ8EPS	11AK36 (non UK model)
JVC	AV14F13	GA2
JVC	AV14F14	CW
JVC	AV14F1P	GA2
JVC	AV14F3	CG
JVC	AV14F33	GA2
JVC	AV14F3PX	GA2
JVC	AV14F4	CG
JVC	AV14F43	CG
JVC	AV14F43BK	CG
JVC	AV14F4EE	CG
JVC	AV14F4TEE	CG
JVC	AV14F7	CG
JVC	AV14F71VT	CG
JVC	AV14FM	CG
JVC	AV14FMG3B	CG
JVC	AV14FMT3	CG
JVC	AV14FT	CG
JVC	AV14FTG	CG
JVC	AV14FTR	CG
JVC	AV14FTT	CG
JVC	AV14JT5EBU	CP005
JVC	AV14JT5EU	CP005
JVC	AV14KG11	CG
JVC	AV14ME	MZ2
JVC	AV14MEU	MZ2
JVC	AV14TE	MZ2
JVC	AV14UG11	CG
JVC	AV16N73	CG
JVC	AV16N8	CG
JVC	AV17V214	CW
JVC	AV17V314	CW
JVC	AV20220	FV4
JVC	AV20221	FV4
JVC	AV20CM3	GY ?

Brand	model	chassis
JVC	AV20D13	GA2
JVC	AV20D303	FE
JVC	AV20D33	GA2
JVC	AV20F475	FJ2
JVC	AV20N3	CG
JVC	AV20N43	CG
JVC	AV20N43BK	CG
JVC	AV20N4BK	CG
JVC	AV20N4NS	CG
JVC	AV20N8(BK)	CL-M
JVC	AV20N8(VT)	CL-M
JVC	AV20N83	CH
JVC	AV20N8VT	CL
JVC	AV20NMG3B	CG
JVC	AV20NN15	CW
JVC	AV20NT	CG
JVC	AV20NX3	CH
JVC	AV20RM4SE	11AK19
JVC	AV21 FR10	CG
JVC	AV21 FR3	CG
JVC	AV2104TEE	CG
JVC	AV2104TEE	CG-F
JVC	AV2104Y	CW
JVC	AV2105EE	CG
JVC	AV2114EE	CG
JVC	AV2114Y	CW
JVC	AV2115EE	CG
JVC	AV2124EE	CG
JVC	AV2130EE	CL
JVC	AV2134EE	CG
JVC	AV2134Y	CW
JVC	AV2135EE	CG
JVC	AV2136EE	CG
JVC	AV2154C	CW
JVC	AV2155VE	CW2

Brand	model	chassis
JVC	AV2168EE	CH
JVC	AV2168TEE	CH
JVC	AV2178TEE	CH
JVC	AV2185ME	CW2
JVC	AV2186ME	CW3
JVC	AV21A10	CG
JVC	AV21A10F	CG
JVC	AV21A4EE	CG
JVC	AV21AT	CG
JVC	AV21AT	CG
JVC	AV21ATG2	CG
JVC	AV21BD5	CP785
JVC	AV21BD5EES	CP785
JVC	AV21BF10EES	11AK19Y PRO
JVC	AV21BF11EES	11AK30A4
JVC	AV21BF11EJS	no chassis
JVC	AV21BF11ENS	11AK30A4
JVC	AV21BF11EPS	11AK30A4
JVC	AV21BF5EES	11AK19Y12
JVC	AV21BT7EEB	11AK19Y11
JVC	AV21BT7EES	11AK19PRO
JVC	AV21BT7ESP	11AK19Y11
JVC	AV21BT8	11AK19
JVC	AV21BT80	11AK19
JVC	AV21BT8EES	11AK30A4
JVC	AV21BX16/L	CW3
JVC	AV21BX16/L	CW3
JVC	AV21C116B	CG4
JVC	AV21C314	CW
JVC	AV21CX14	CW
JVC	AV21D10	CG
JVC	AV21D11	GA2
JVC	AV21D13	GA2
JVC	AV21D31	GA2
JVC	AV21D33	GA2

Brand	model	chassis
JVC	AV21D43	CG
JVC	AV21D43BK	CG
JVC	AV21D73	CG
JVC	AV21D83	CH
JVC	AV21DMT3	CG
JVC	AV21DX14	CW
JVC	AV21DX3	CH
JVC	AV21EM	CG
JVC	AV21ETG2	CG
JVC	AV21F10	CG
JVC	AV21F1EG	JX
JVC	AV21F1EK	JX
JVC	AV21F1P	GA2
JVC	AV21F3	CG
JVC	AV21F4EE	CG
JVC	AV21F7	CG
JVC	AV21F8	CL ?
JVC	AV21F8BK	CL-M
JVC	AV21F8VT	CL-M
JVC	AV21F9	CM II'
JVC	AV21F9	CM-II'
JVC	AV21FMG3B	CG
JVC	AV21FT	CG
JVC	AV21FT1Sxx	JK
JVC	AV21FTG	CG
JVC	AV21FTR	CG
JVC	AV21FX3	CH
JVC	AV21H1EK	JX III
JVC	AV21H1EK	JX III
JVC	AV21H1T	JX III
JVC	AV21H2	JX3
JVC	AV21H2EK	JX III
JVC	AV21JT5EBU	CP005
JVC	AV21JT5EU	CP005
JVC	AV21KJSEF	11AK30A4

Brand	model	chassis
JVC	AV21L11	CH
JVC	AV21L11PH	CH
JVC	AV21L14	CW
JVC	AV21L24	CW
JVC	AV21L31	CH
JVC	AV21L31B	CH
JVC	AV21L31PH	CH
JVC	AV21L41BK	CG
JVC	AV21L81BK	CH
JVC	AV21LMG3	CG
JVC	AV21LMG4/G	CW
JVC	AV21LMT3	CG
JVC	AV21LS2	CH
JVC	AV21LT1EE	CG
JVC	AV21LT3	CG
JVC	AV21LTR1	CG-F
JVC	AV21LTR3	CG
JVC	AV21LTT1	CG
JVC	AV21LTT1	CG-F
JVC	AV21LX2	CH
JVC	AV21M316V	CW3
JVC	AV21MS16	CW3
JVC	AV21MS26	CW3
JVC	AV21MS30	CW2
JVC	AV21MS30	CW2
JVC	AV21MS30N	CW2
JVC	AV21MT16	CW2
JVC	AV21MT36	CW2
JVC	AV21MX16	CW3
JVC	AV21MX56	CW3
JVC	AV21MX76	CW3
JVC	AV21N83	CH
JVC	AV21NX3	CH
JVC	AV21P4	CG-F
JVC	AV21P7EE	CG-F

Brand	model	chassis
JVC	AV21P8	CM-F
JVC	AV21P9BK	CM
JVC	AV21PM	CG-F
JVC	AV21PS	CM-F
JVC	AV21PX	CM-F
JVC	AV21Q3	CG
JVC	AV21QMG3	CG
JVC	AV21RM4SE	11AK19
JVC	AV21RM4SN	11AK19
JVC	AV21RM4SP	11AK19
JVC	AV21SX1	BB
JVC	AV21SX1E	BB
JVC	AV21SX1EK	BB
JVC	AV21TE	MZ2
JVC	AV21TS1	BB
JVC	AV21TS1E	BB
JVC	AV21TS1EK	BB
JVC	AV21TS2EK	JE
JVC	AV21TS4EK	JH
JVC	AV21TS4EN	JH
JVC	AV21U3	CG
JVC	AV21U4	CW
JVC	AV21V115B	CW
JVC	AV21VM1	BA
JVC	AV21VT15	CW
JVC	AV21VT35	CW
JVC	AV21VX15	CW2
JVC	AV21W33B	CH
JVC	AV21W83B	CH
JVC	AV21W93	CH
JVC	AV21W93B	CH
JVC	AV21WH3	CH
JVC	AV21WS3	CH
JVC	AV21WX25	CW2
JVC	AV21WX3	CH

Brand	model	chassis
JVC	AV21YMG4	CW
JVC	AV21YT15	CW
JVC	AV21YX14	CW
JVC	AV21ZE	MZ2
JVC	AV245L31B	CH
JVC	AV24WT2EK	JF
JVC	AV24WT5Exx	JK II
JVC	AV2553VE	CW
JVC	AV2555TEE	CH
JVC	AV2568TEE	CH
JVC	AV2586ME	CW3
JVC	AV25BD3EK	JE
JVC	AV25BT6ENS	11AK37
JVC	AV25F1	JX
JVC	AV25F1EK	JX
JVC	AV25FX11	JX2
JVC	AV25FX11EK	JX II
JVC	AV25GS1E	MX I
JVC	AV25GS1E	MX I/II
JVC	AV25GS1EK	MX II
JVC	AV25K83	CH
JVC	AV25KX3	CH
JVC	AV25L11PH	CH
JVC	AV25L33B	CH
JVC	AV25LS3	CH
JVC	AV25MEX (-A)	MZ2
JVC	AV25MS26	CW3
JVC	AV25MT16	CW2
JVC	AV25MX76	CW3
JVC	AV25P8TEE	JK
JVC	AV25P9	JK
JVC	AV25PS	JK
JVC	AV25PS	JK
JVC	AV25PX	JK
JVC	AV25S1E	MX I

Brand	model	chassis
JVC	AV25S1EK	MX II
JVC	AV25S4E	MX IV
JVC	AV25S4EK	MX IV
JVC	AV25S4EN	MX IV
JVC	AV25SD4EK	MX III
JVC	AV25SX1	JA
JVC	AV25SX1E	JA
JVC	AV25SX1EK	JA
JVC	AV25SX2EK	JE
JVC	AV25SX4EK	JH
JVC	AV25T25EKS	JL
JVC	AV25TS1EK	JC
JVC	AV25TS1EN	JC
JVC	AV25TS2EK	JE
JVC	AV25TS2EN	JC
JVC	AV25TS2PF	JE
JVC	AV25TS4EK	JH
JVC	AV25TS4ENS	JH
JVC	AV25TSQ	JC
JVC	AV25VM1	JA
JVC	AV25VM1EK	JA
JVC	AV25VM1EN	JA (czy? JC)
JVC	AV25VM1EN	JC !
JVC	AV25XD3E	MX III
JVC	AV25XD3EG	MX III
JVC	AV27150	GF
JVC	AV27220	FV4
JVC	AV27260	GC
JVC	AV27430	FE2
JVC	AV27432	FE2
JVC	AV2776S	GK27"
JVC	AV27820	FA (A53)
JVC	AV2795S	GYIII 27"
JVC	AV2796S	GK27"
JVC	AV27BH5	GM

Brand	model	chassis
JVC	AV27BH5	GM27"
JVC	AV27BH6	GM II 27"
JVC	AV27BM5	GYIV 27"
JVC	AV27BM6	GK27"
JVC	AV27BP5	GM
JVC	AV27BP5	GM
JVC	AV27BP6	GK27"
JVC	AV27BX5	GM 27" Y 31"
JVC	AV27BX5LC	GM
JVC	AV27D104	FE2
JVC	AV27D201	GR2
JVC	AV27D202	FD
JVC	AV27D203	FE
JVC	AV27D302	FD
JVC	AV27D303	FE
JVC	AV27D304	FE2
JVC	AV27D502/R	AC
JVC	AV27D502/S	AC
JVC	AV27F476	GJ5 (A134)
JVC	AV27F802	AC
JVC	AV27MF47	GJ6
JVC	AV28BD3EK	JE
JVC	AV28BD5BK	CP785
JVC	AV28BD5EE	CP785
JVC	AV28BD5EKIS	CP785
JVC	AV28BD5SL	CP785 ?
JVC	AV28BH7EES	11AK41
JVC	AV28BH7ENB	11AK41J4
JVC	AV28BH7ENS	11AK45
JVC	AV28BK5ECB	No chassis
JVC	AV28BK5ECS	No chassis
JVC	AV28BT5	11AK19 (nonUK)
JVC	AV28BT5EEB	11AK19Y PRO
JVC	AV28BT5EES	11AK19Y PRO
JVC	AV28BT5ENB	11AK19Y PRO

Brand	model	chassis
JVC	AV28BT5ENS	11AK19Y PRO
JVC	AV28BT7EES	11AK19
JVC	AV28BT7ENS	11AK19Y PRO
JVC	AV28BT80EP	11AK37
JVC	AV28BT8ENS	11AK37
JVC	AV28CT100EPS	JK2
JVC	AV28CT10EPS	JK2
JVC	AV28CT1EP	JK II
JVC	AV28EH1SUG	CP830 (?)
JVC	AV28F1	JX
JVC	AV28F1EG	JX
JVC	AV28FX11	JX II
JVC	AV28GH1SUF	11AK52 B8
JVC	AV28GS1E	MX I
JVC	AV28GS1E	MX I/II
JVC	AV28GS1EK	MX
JVC	AV28GS1EN	MX ?
JVC	AV28GT1SJF	11AK45 A
JVC	AV28GT1SJT	11AK45 ?
JVC	AV28H10EUS	MF
JVC	AV28H200EUSB	MF II
JVC	AV28H20E	MF II
JVC	AV28H35	ML (100Hz)
JVC	AV28H35SUE	ML (100Hz)
JVC	AV28H40SU	ML2
JVC	AV28H4BU	ML2
JVC	AV28H4SU	ML2
JVC	AV28H50SU	ML3
JVC	AV28H5BL	ML3
JVC	AV28H5BU	ML3
JVC	AV28H5SK	ML3
JVC	AV28H5SL	ML3
JVC	AV28H5SL	ML3
JVC	AV28H5SR	ML3
JVC	AV28H5SU	ML3

Brand	model	chassis
JVC	AV28H77SK	ML2
JVC	AV28KH15UF/A	11AK41
JVC	AV28KH1BUF/A	11AK41
JVC	AV28KH1SUF/A	11AK41
JVC	AV28KT1BUF	11AK45B5
JVC	AV28L2EUBL	MF
JVC	AV28L2EUGR	MF
JVC	AV28L2EUGY	MF
JVC	AV28NH4SU	CP830
JVC	AV28PH4N	11AK41
JVC	AV28PH4N	11AK52V (100Hz)
JVC	AV28R25EKS	JL2 ?
JVC	AV28R8TEE	JK
JVC	AV28RT4SU	11AK45B5
JVC	AV28RX	JK
JVC	AV28S1E	MX I
JVC	AV28S1EK	MX II
JVC	AV28S1EN	MX II (SMX2002A)
JVC	AV28S2EIBL	JK
JVC	AV28S2EIGR	JK
JVC	AV28S2EK	JK
JVC	AV28S2EKBL	JK
JVC	AV28S2EKGR	JK
JVC	AV28S4EK	MX IV
JVC	AV28S4EN	MX IV
JVC	AV28SD4EK	MX III
JVC	AV28T10EKSL	JK, colour variant of AV28WFT1EKS
JVC	AV28T25EK	JL
JVC	AV28T55EK	JL
JVC	AV28T55EKS	JL
JVC	AV28T5SK	JW2 ?
JVC	AV28T77SK	JW
JVC	AV28VM1	JA
JVC	AV28VM1EK	JA
JVC	AV28VM1EN	JA

Brand	model	chassis
JVC	AV28VM1PF	JB
JVC	AV28WFR1EK	JK
JVC	AV28WFR1EKS	JK (Dolby variant of AV28WFT1EKS)
JVC	AV28WFT1EIS	JK
JVC	AV28WFT1EKS	JK
JVC	AV28WFT1EPG	JK
JVC	AV28WFT1EPS	JK
JVC	AV28WFX1EU	MD
JVC	AV28WH3EP	MC
JVC	AV28WH5BK	MF
JVC	AV28WH5EU	MF
JVC	AV28WIDE	JA (?)
JVC	AV28WR2EK	JF
JVC	AV28WR4EK	JF
JVC	AV28WT2EK	JF
JVC	AV28WT4EK	JF
JVC	AV28WT500EPS	JK
JVC	AV28WT5EKS	JK II
JVC	AV28WX1	JD
JVC	AV28WX1EK	JD
JVC	AV28WX1EP	JD
JVC	AV28WZ2EN	MB
JVC	AV28WZ2EP	MB
JVC	AV28X10EKS	MF
JVC	AV28X10EUS	MF
JVC	AV28X10EV	MF ?
JVC	AV28X25	MK II
JVC	AV28X25EIGY	MF II
JVC	AV28X25EKGY	MF II
JVC	AV28X25EUS	MF II
JVC	AV28X35	ML (100Hz)
JVC	AV28X37	ML (100Hz)
JVC	AV28XD3E	MX III
JVC	AV28XD3EG	MX III
JVC	AV28Z10EUS	MF

Brand	model	chassis
JVC	AV28Z25EUY	MF II
JVC	AV2908TEE	CH
JVC	AV2934L	CW
JVC	AV2937V1E	CH3
JVC	AV294VT	SY2
JVC	AV2954WE	CW
JVC	AV2955VE	CW2
JVC	AV2956BE	CW3
JVC	AV2968TEE	CH
JVC	AV2971TEE	CD
JVC	AV29A10EUS	MF
JVC	AV29BD3EK	JE (100Hz)
JVC	AV29BD3EN	JE (100Hz)
JVC	AV29BF10EE	11AK37 J3
JVC	AV29BH11ENS	11AK41
JVC	AV29FH1SUG	CP830F
JVC	AV29L31	CH
JVC	AV29L31B	CH
JVC	AV29L6SU	MR
JVC	AV29LPZ	MF
JVC	AV29LS2	CH
JVC	AV29LX14	CW
JVC	AV29LX2	CH
JVC	AV29LX2U	CH
JVC	AV29M201	GA
JVC	AV29MT16	CW2
JVC	AV29MT36	CW2
JVC	AV29QT4SU	11AK45B5
JVC	AV29QT4SU	11AK49 (?)
JVC	AV29R8B	JK
JVC	AV29R9	JK
JVC	AV29R9B	JK
JVC	AV29RF6	JK
JVC	AV29RS	JK
JVC	AV29RSB	JK

Brand	model	chassis
JVC	AV29RX	JK
JVC	AV29RXB	JK
JVC	AV29S516B	CW3
JVC	AV29SX1	JA
JVC	AV29SX1EN	JA
JVC	AV29SX2EK	JE
JVC	AV29SX4EK	JH
JVC	AV29TH3ENB	MC
JVC	AV29TH3EPS	MC
JVC	AV29TS1EN	JC
JVC	AV29TS2EK	JE
JVC	AV29TS2EN	JE
JVC	AV29TS2EN	JE
JVC	AV29TS2PF	JE
JVC	AV29TS3EK	JE
JVC	AV29TS4EE	JH
JVC	AV29TS4EN	JH
JVC	AV29TS4EX	JH
JVC	AV29V311	CH3
JVC	AV29V511	CH3
JVC	AV29V531	CH3
JVC	AV29VA15	CW2
JVC	AV29VT14	CW
JVC	AV29VT15	CW
JVC	AV29VT34	CW
JVC	AV29VT35	CW
JVC	AV29VX15	CW2
JVC	AV29W33B	CH
JVC	AV29W83B	CH
JVC	AV29W93	CH
JVC	AV29W93B	CH
JVC	AV29WS3	CH
JVC	AV29WX14	CW
JVC	AV29WX24	CW
JVC	AV30W475	GV

Brand	model	chassis
JVC	AV30W475	GW
JVC	AV30W767	SR2
JVC	AV30W777	SR2
JVC	AV31BH6	GM II 31"
JVC	AV31BM5	GM
JVC	AV31BP5	GM
JVC	AV31BX4	BX4 ?
JVC	AV31BX5	GM 27" Y 31"
JVC	AV31BX5LC	GM
JVC	AV32115	GF
JVC	AV32120	GF
JVC	AV32150	GF
JVC	AV32230	AC
JVC	AV32230	GC
JVC	AV32260	AC
JVC	AV32D201	GR2
JVC	AV32D201	GR2
JVC	AV32D202	GC !
JVC	AV32D302	GC !
JVC	AV32D305	GE4
JVC	AV32D501	GR2
JVC	AV32D502	GC !
JVC	AV32F475	GJ4
JVC	AV32F476	GJ5 (A134)
JVC	AV32F485	GJ4
JVC	AV32H10EUS	MF
JVC	AV32H10SL	MF
JVC	AV32H200EUSB	MF II
JVC	AV32H20EUS	MF II (100Hz)
JVC	AV32H35 SAE	ML (100Hz)
JVC	AV32H35SUE	ML (100Hz)
JVC	AV32H40SU	ML2
JVC	AV32H47SU	ML2
JVC	AV32H4BU	ML2
JVC	AV32H4SU	ML2

Brand	model	chassis
JVC	AV32H50SU	ML3
JVC	AV32H57SU AV32H5BU	ML3
JVC	AV32H5SK	ML3
JVC	AV32H5SR	ML3
JVC	AV32H5SU	ML3
JVC	AV32H77SK	ML2
JVC	AV32L2EUBL	MF
JVC	AV32L2EUGR	MF
JVC	AV32L2EUGY	MF
JVC	AV32L2EUGY	MF (?)
JVC	AV32L5EIGY	MF
JVC	AV32L5EKGY	MF
JVC	AV32LPZ	MF
JVC	AV32MF47	GJ6
JVC	AV32P10EKS/EIS	MF
JVC	AV32R250EKS	JL
JVC	AV32R25EKS	JL (Dolby variant of AV32T25EKS)
JVC	AV32R57SK	JW II
JVC	AV32S2EIGR	JK
JVC	AV32S2EKBL	JK
JVC	AV32S2EKGR	JK
JVC	AV32T20EPS	JL
JVC	AV32T25EKS	JL
JVC	AV32T55EKS	JL
JVC	AV32WF47	GJ6
JVC	AV32WFP1EK	MD
JVC	AV32WFR1EKS	JK (Dolby variant of AV32WFT1EKS)
JVC	AV32WFT1EKS	JK
JVC	AV32WH3EP	MC
JVC	AV32WL1EK	MD
JVC	AV32WL1EU	MD
JVC	AV32WP2EK	MB
JVC	AV32WP2EN	MB
JVC	AV32WR2EK	JF
JVC	AV32WX1	JD

Brand	model	chassis
JVC	AV32WX1EK	JD
JVC	AV32WZ2EN	MB
JVC	AV32WZ2EP	MB
JVC	AV32X25	MK II (czy? MFII)
JVC	AV32X250EUS	MF II
JVC	AV32X25E	MF II ?
JVC	AV32X25EIGY	MF II
JVC	AV32X25EKGY	MF II
JVC	AV32X25EUS	MF II
JVC	AV32X35HKE	ML (100Hz)
JVC	AV32X35HUE	ML (100Hz)
JVC	AV32X35HUE	ML (100Hz)
JVC	AV32X37HIE	ML (100Hz)
JVC	AV32X37HIE	ML (100Hz)
JVC	AV32X37HKE	ML (100Hz)
JVC	AV32X37SUE	ML (100Hz)
JVC	AV32Z10EUS	MF
JVC	AV32Z25EUYY	MF II
JVC	AV3371TEE	CD
JVC	AV34WP84	SB4
JVC	AV35BH6	35"
JVC	AV35BP5	GM
JVC	AV35BP6	GK 35"
JVC	AV35BX8	GM
JVC	AV36150	GF
JVC	AV36230	AC
JVC	AV36230	GC
JVC	AV36230H	GC
JVC	AV36260	AC
JVC	AV36260R	GD
JVC	AV36D202R	GC
JVC	AV36D302H	GC
JVC	AV36D502R	GC
JVC	AV36F702	AC
JVC	AV36P902Y	SB II

Brand	model	chassis
JVC	AV36P903	SB II
JVC	AV48P777	SR2
JVC	AV48WP30	SB2
JVC	AV52WP30	SB II
JVC	AV6100	KB
JVC	AV61PRO	KB
JVC	AV65WP74	SB3
JVC	AVA14T3	CG
JVC	AVKG21	CG
JVC	AVS250EGT	BYII
JVC	AVS250M	BY
JVC	AVS290M	BY
JVC	C-FT14EE	CP375
JVC	C-FT21EE	CP375
JVC	C-J14EK	JG
JVC	C-J21EK	JG
JVC	C-JT14EP	JG
JVC	C-JT14EP	JG
JVC	C-JT21EP	JG
JVC	C-JT21EP	JG
JVC	C-N14110	FV3
JVC	C-N21102	FV4
JVC	C-N21103	FV5
JVC	C-N21110	FV3
JVC	C-N21203	FV5
JVC	C-N21210	FV4
JVC	C-N21310	FV5
JVC	C-S2180M	BX II
JVC	C-S2190EK	BX II
JVC	C-VT14EKB	CY21EK CV14EKB
JVC	C13210	FV4
JVC	C13211	FV4
JVC	C1431ME	FY IV
JVC	C1480EE	BX II
JVC	C1480EG	BX II

Brand	model	chassis
JVC	C1486	MZD†
JVC	C1490M	BX II
JVC	C14A1	MV
JVC	C14A1EK	MV
JVC	C14E1EK	Onwa
JVC	C14ET1EK	Onwa
JVC	C14M1	KY
JVC	C14T1	KY
JVC	C20210	FV4
JVC	C210ME	BX
JVC	C2151R	TX100
JVC	C2152T	TX100
JVC	C2153TS	TX100
JVC	C2164	FY IV
JVC	C21ET1EK	Onwa
JVC	C21M3EK	Onwa
JVC	C21ME	BB
JVC	C21T1	MY
JVC	C21TX1	MY
JVC	C21TX1	MY II
JVC	C21TX1EK	MY
JVC	C21ZE	MZ2
JVC	C21ZE/A	MZ2
JVC	CF14EE	CP375
JVC	CFT21EE	CP375
JVC	CS2180	BX II
JVC	CS2180M	BX II
JVC	CS2181	BY X
JVC	CS2181ET	BY X
JVC	CS2190	BX II
JVC	CS2191	BY X
JVC	CS21M2EK	MY II
JVC	CS21M3EK	Onwa
JVC	CV14EKB	CY21EK CVT14EKB
JVC	CV21EK	CV14EKB CVT14EKB

Brand	model	chassis
JVC	CY21EK	CV14EKB CVT14EKB
JVC	DLAG10EK	I
JVC	DLAS10EK	I II
JVC	FT8144	(17MB11-2)
JVC	FXE95TN	DXE95TN
JVC	GM-P420E	S3
JVC	GM-P420PCE	S3
JVC	GM-P421PCE	S3
JVC	GM-V42UG	T4
JVC	HD52G787	RA2
JVC	HD52G887	RA2
JVC	HD56G787	RA2
JVC	HD56G887	RA2
JVC	HD61G787	RA2
JVC	HD61G887	RA2
JVC	HV-L34PRO	MF
JVC	HV-Z29V1E	MM
JVC	HV-Z29V1S	MM
JVC	HV28D40BK	MM
JVC	HV29JH24	ML2
JVC	HV29LPZ	MF
JVC	HV29WH21	ML (100Hz)
JVC	HV29WZ	MF
JVC	HV32D25EUW	MK
JVC	HV32D40BK	MM
JVC	HV32P37SJE	MM
JVC	HV34LH21	ML (100Hz)
JVC	HV34LH51	ML (100Hz)
JVC	HV34LH71	ML (100Hz)
JVC	HV34LPZ	MF
JVC	HV34LZ	MF
JVC	HV53PRO	MF
JVC	HV53PRO A	MF
JVC	HV53PRO EE	MF
JVC	LT-Z26EX6	FL3

Brand	model	chassis
JVC	LT-Z32EX6	FL3
JVC	LT26A60BU	FT
JVC	LT26A60SJ	FT
JVC	LT26A60SU	FT
JVC	LT26S60BU	FL2
JVC	LT26S60SU	FL2
JVC	LT30E45SU	17MB11-2
JVC	LT32D50BJ	FL
JVC	LT32D50SJ	FL
JVC	LT32S60BU	FL2
JVC	LT32S60SU	FL2
JVC	LT32X575	FL
JVC	LT32X585	FL
JVC	LT40X667	FL4
JVC	LT46FH97	FL4
JVC	N48P5	RP
JVC	PD-Z50DX4	FP2
JVC	PD42DX	MK
JVC	PD42DXT	SB3
JVC	PD42WV74	SB3
JVC	PD42X776	FP3
JVC	PD42X795	FP2
JVC	PD50X795	FP2
JVC	TM1700PNS	A17
JVC	TMA10EK	A10
JVC	TMA14PNK	VL
JVC	TUC200	E2
JVC	TV20F242	No chassis
JVC	VM14PSN	14"
JVC	YA255	CW
K-Classic	TV65181	PT90 PBGE
KAIDO	CT20PS02TX	MSC1
KAPSH	CS8628	BS665
KARAT	CK3399	SW91ST
KARAT	CK5099	SW91ST

Brand	model	chassis
KARAT	CK5399	SW91ST
KARCHER	CTV1028VT	20.2 (100Hz) (BEKO)
KARCHER	CTV4420	P51-28
KARCHER	CTV5020	11AK06 (TV02--P924)
KARCHER	CTV5020VT	TV2
KARCHER	CTV5314V	TV84
KARCHER	CTV5314VT	TV84
KARCHER	CTV5320VT	SM2 ?
KARCHER	CTV5321	TV83
KARCHER	CTV5321VT	TV84 ?
KARCHER	CTV5514	TV2KF ?
KARCHER	CTV5514VT	TV2K
KARCHER	CTV5514VT	TV2K
KARCHER	CTV5520	TV2KF
KARCHER	CTV5521VT	TV3K
KARCHER	CTV5621VT	TV2K ?
KARCHER	CTV5625	TV2K
KARCHER	CTV5628VT	TV3K
KARCHER	CTV5628VT	TV4K
KARCHER	CTV6028A	SM2
KARCHER	CTV6028VT	SM2
KARCHER	CTV6114VT	PT92
KARCHER	CTV6221VT	PT11I
KARCHER	CTV6328VT	PT90A
Karcher	CTV6421	PT92
KARCHER	CTV6521	PT92-90
KARCHER	L1418TC3	TV2K ?
KARCHER	TV5514	TV2KF
KENDO	28L0601	ETC010
KENDO	28L0602	ETC010
KENDO	29L0603	ETC010
KENDO	32T21	20.2 (100Hz) (BEKO)
KENDO	79Y110	10.3 (BEKO TEKNIK 5093)
KENDO	CP20M36VT	11AK20S
KENDO	CP24M36VT	11AK36A15

Brand	model	chassis
KENDO	CT20M51VT	11AK19E3
KENDO	CT20S55VT	11AK19
KENDO	CT20S71VT	11AK19PRO
KENDO	CT21S55RFA	11AK30
KENDO	CT5223	TV9.1 ?
KENDO	CT5225	TV9.1
KENDO	CT63S92	BS990
KENDO	CT63S92	BS990
KENDO	CT71S92	BS990
KENDO	CT95S63 TOP	PC041
KENDO	CT95S71 TOP	PC040
KENDO	CT95S71 TOP	PC040
KENDO	CT97S63 TOP	PC170
KENDO	CT97S71	PC170
KENDO	CT97SWS71	PC040
KENDO	CT98S71VT	K110 (K110-7) = 2840 = PC180-90
KENDO	CT99S55VT	PC170 (albo PC180)
KENDO	CT99S71VT	K110
KENDO	STV2840	K110 (K110-7)
KENIA	3045K	MC97A
KEVLER	K2902	20.2 (100Hz) (BEKO)
KITON	5159	11AK10
KITON	5559	11AK10
KITON	Arizona	11AK19
KITON	ARIZONA 5511	11AK19
KITON	California	11AK18
KITON	California II	11AK18
KITON	Colorado	11AK19
KITON	COLORADO 5111	11AK19
KITON	CT2500	11AK10
KITON	CT2501	11AK10
KITON	CT2551	11AK10
KITON	CT2590ST	11AK10
KITON	CT3050	11AK10
KITON	CT3100ST	11AK10

Brand	model	chassis
KITON	CT3200ST	11AK10
KITON	CT3250ST	11AK10
KITON	CT510	11AK10
KITON	CTV3600	11AK20
KITON	CTV3610	11AK20
KITON	CTV5100	11AK10
KITON	CTV5100	11AK19
KITON	CTV5110	11AK10
KITON	CTV5110	11AK19
KITON	CTV5125	11AK10
KITON	CTV5125	11AK19
KITON	CTV5510	11AK19
KITON	CTV5525	11AK10
KITON	CTV5525	11AK19
KITON	CTV7225	11AK19
KITON	CTV7225 (7292)	11AK19
KITON	Montana	11AK20
KITON	Nevada	11AK19
KITON	Nevada II	11AK19
KITON	NEWADA II 7292	11AK19
KITON	ST5196VT	11AK10
Kitty Toys	KT2313	P1430
KNEISSEL	KN1432	CP330
KNEISSEL	KN2519	F19
KNEISSEL	KN2590TXT	CP760
KNEISSEL	KN2827TXT/ST	CP775 (?)
KNEISSEL	KN2828	K110
KNEISSEL	KN2828STX	K110-07
KOLON	CKT9742	PC91A
KOLON	CKT9745	PC91A
KOLON	CKT9822	PC91A
KOLON	CKT9825	PC91A
KOPERIKUS	PF29T18	CH20
KORPPEL	K6371TN	11AK04 ?
Kotron		P1430

Brand	model	chassis
KOTRON		P1430
KUBA	70STK100	TV2
KUBA	863KM100S	DTV1
KUBA	870KM100S	DTV1
KUBA	DTV7025	DTV1
L&S Electronic	30621/HTF62	P1420 ?
L&S Elektronik	F70-1363	22.1 (ZA1.190-09) (BEKO)
LENCO	LTV72870NS	11AK19E3
LENCO	LTV74928NS	11AK19
LENCO	NR14M03GREEN	12.1 (6BZ190-11)
LENCO	STC9750	F11
LENCO	TC9138	11AK36
LENCO	TC9201	MSC1
LENCO	TC9204	BA0/HBAL04A
LENCO	TC9301	MSC1
LENCO	TC9401	MSC1
LENCO	TC9404	BA0/HBAL04A
LENCO	TC9501	MSC1
LENCO	TCV9905	TVR402Pal 85-22-1001REV01
LENCO	VTV72858	11AK19-8A
LEXUS	RC4221PST	RC4121A
LEXUS	RC4421PST	RC4121A
LG	14D90	NC6HA
LG	14D90G	NC6HA
LG	14D99G	NC6HA
LG	14D99M	MC83A
LG	15LC1R-ZG	CL81
LG	20D90	NC6HA
LG	20D90G	NC6HA
LG	20D99	NC6HA
LG	20D99G	NC6HA
LG	20HIZ11	ML041F
LG	21FB50VX	MC019
LG	21FB5RLX	CW62B
LG	21FB7RB	MC059B

Brand	model	chassis
LG	21FB7RG	MC059B
LG	21FB7RG	MC059B
LG	21FB7RL	MC059B
LG	21FD4RG	MC059B
LG	21FD4RG-TH	MC059B
LG	21FE6AB	MC059B
LG	21FE6AB-TH	MC059B
LG	21FE6AG	MC059B
LG	21FE6AG-TH	MC059B
LG	21FE6RB	MC059B
LG	21FE6RB-TH	MC059B
LG	21FE6RG	MC059B
LG	21FE6RG-TH	MC059B
LG	21FJ4RB	MC059A
LG	21FS2RG	MC049C
LG	21FS2RG/RLX-TC	MC049C
LG	21FS2RLX	MC049C
LG	21FS4RLX	CW62B
LG	21FS4RLX-ZV	CW62B
LG	21FX4R/RB	MC059A
LG	21FX4R/RB-LD	MC059A
LG	21FX4RG	MC059A
LG	21FX4RG-LD	MC059A
LG	21FX5RF	MC059A
LG	21FX5RG	MC059A
LG	23LC1R-ZB	ML041G
LG	23LX1RV-MC	ML041D
LG	26LC2D-UE	LA63E
LG	26LC2R-ZJ	LP61A
LG	26LC5	LP78A
LG	27LZ5RV-ZC	ML041D
LG	28CZ10RX	14.2 (V80.190-07)
LG	29CF60XM	MC51A
LG	29FG1RL	CW62C
LG	29FS2ALX-ZG	CW62A

Brand	model	chassis
LG	29FS2AMB	MC05HA
LG	29FS2ANX	MC05HA
LG	29FS2RNB	MC035E
LG	29FX5BK-LG	CW62A
LG	29FX5BL	CW62A
LG	29FX5BL-LG	CW62A
LG	29FX5CL	CW62A
LG	29FX5CL-LG	CW62A
LG	30FZ1DC	AC02SD
LG	32FZ1DC-UB	AC02SD
LG	32HIZ10	ML041E
LG	32LC2R-ZJ	LP61A
LG	32LC3R-ZJ	LP61A
LG	32LC51ZA	LP78A
LG	32LC52ZC	LP78A
LG	32LC7R-ZA	LP78A
LG	32LX4DC-UB	LA53A
LG	32LX4DCS-UB	LA53A
LG	37LB4DS	LA73A
LG	37LC2RR-ZL	MF056M
LG	37LP1D	ML051A
LG	37LP1DA-ZA	ML03JA
LG	37LP1R-TE	ML051A
LG	37LP1RTE	ML051A
LG	42LB4DS	LA73A
LG	42LC2R	LP62A
LG	42LF66	LD75A
LG	42LF66ZE	LD75A
LG	42PC1DV	PB61A
LG	42PC1DVH	PA51D
LG	42PC1RR	MF056L
LG	42PC1RR-ZL	MF056L
LG	42PM3MVA	RF052A
LG	42PT85	PD74A
LG	42PX2RV	MF056A

Brand	model	chassis
LG	42PX3RV	MF056A
LG	42PX3RVA	MF056C
LG	42PX3RVA-ZC	MF056C
LG	42PX4DV	DF054A
LG	42PX4R	MF056A
LG	42PX4RV	MF056A
LG	42PX5D	DF054B
LG	44SZ30RB	MB03CC
LG	50PM1MA	RF052A
LG	52SZ30RB	MB03CC
LG	52SZ60DB	MB03CC
LG	909KT00978	MC993A
LG	CA14F33	MC84A
LG	CA21D65	MC84A
LG	CB14F80X	12.1 (BEKO)
LG	CB14F80X	MC84A
LG	CB14F84X	12.4/12.5 (A99.820-04)
LG	CB14J70X	11AK36
LG	CB20F80X	12.4/12.5
LG	CB20F84	12.4/12.5 (A99.190-16)
LG	CB20F84X	12.4/12.5 (BEKO)
LG	CB20F84X	12.4/12.5 (BEKO)
LG	CB21F84X	12.4 (BEKO) (czy? PC81A)
LG	CB21FX84X	12.5 ?
LG	CB21T20S	PC81A
LG	CE20F60K	MC019A
LG	CE20F60KX	MC019A
LG	CE20F66	MC00AA
LG	CE20F84X	12.4/12.5 (BEKO) ?
LG	CE20F86X	MC00AA
LG	CE20J3BX	MC009A
LG	CE20J3BX/GX/RX	MC009A
LG	CE20J50KX	MC019A
LG	CE20K48ET	MC00AA
LG	CE21F60KX	MC019A

Brand	model	chassis
LG	CE21F66X	MC00AA
LG	CE21J50KX	MC019A
LG	CE21Q26ET	MC007B
LG	CE21Q66	MC007B
LG	CE21T20KEX	MC019 A
LG	CE21T22KX	MC019A
LG	CE28H86T	MC007A
LG	CE29Q10ET	MC991A
LG	CE29Q12IP	MC993A
LG	CE29Q12TP	MC993A
LG	CE29Q26ET	MC007A
LG	CE29Q40RQ	MC022A
LG	CE29Q46ET	MC007A
LG	CE29Q90IP	MC006A
LG	CF14A40	MC41A ?
LG	CF14B10B	MC41A
LG	CF14D60B	MC41A
LG	CF14E20	MC41A
LG	CF14E20B	MC41A
LG	CF14F60X	MC84A
LG	CF14F69X	MC994A
LG	CF14F80X	MC84A
LG	CF14F84	12.4/12.5 (A99.190.07)
LG	CF14F89X	MC994A
LG	CF14J50	MC994A
LG	CF14K50X	MC84A
LG	CF14K52E	MC84A
LG	CF14K54ET	MC84A
LG	CF14S10X	MC84A
LG	CF14S12E	MC84A
LG	CF16S10X	MC84A
LG	CF16S12E	MC84A
LG	CF20A40	MC41A
LG	CF20A80V	MC34A
LG	CF20A80Y	MC41A

Brand	model	chassis
LG	CF20D60B	MC41A
LG	CF20D60X	MC41A
LG	CF20D79	MC994A
LG	CF20E20B	MC41A
LG	CF20F39	MC994A
LG	CF20F60	MC84A
LG	CF20F60X	MC84A
LG	CF20F66EX	MC00A
LG	CF20F66X	MC00A
LG	CF20F69X	MC994A
LG	CF20F80X	MC84A
LG	CF20F89X	MC994A
LG	CF20J50	MC994A
LG	CF20K50X	MC84A
LG	CF20K52E	MC84A
LG	CF20K54ET	MC84A
LG	CF20S10X	MC84A
LG	CF20S12E	MC84A
LG	CF20T24T	PC81B
LG	CF21A50F	PC58B
LG	CF21D30X	MC64B
LG	CF21D36EX	MC019A
LG	CF21D60B	MC41A
LG	CF21D60X	MC41A
LG	CF21D70B	MC41A
LG	CF21D79	MC994A
LG	CF21E20B	MC41A
LG	CF21F30K	MC019A
LG	CF21F39	MC994A
LG	CF21F60X	MC84A
LG	CF21F66EX	MC00A
LG	CF21F66X	MC00A
LG	CF21F69X	MC994A
LG	CF21F80X	MC84A
LG	CF21F89X	MC994A

Brand	model	chassis
LG	CF21K50X	MC84A
LG	CF21K52E	MC84A
LG	CF21K54ET	MC84A (?)
LG	CF21K54X	MC84A
LG	CF21Q94P	MC14 (?)
LG	CF21S10EX	MC84A
LG	CF21S11KE	MC019A
LG	CF21S12E	MC84A
LG	CF21S15	MC019A
LG	CF21S31KE	MC019A
LG	CF25A64D/T	PC73A
LG	CF25C20F	PC33J
LG	CF25C26	MC51B
LG	CF25C26X	MC51B
LG	CF25C36	MC51B
LG	CF25C42P	MC15A
LG	CF25C44XM	MC51A
LG	CF25C60	MC51A
LG	CF25C70	MC51A
LG	CF25C76	MC51B
LG	CF25C80	MC51A
LG	CF28C26	MC51B
LG	CF28C26X	MC51B
LG	CF28C28F	PC58A
LG	CF29B20	MC51A
LG	CF29C10V	MC15A
LG	CF29C20N	PC33J
LG	CF29C20P	MC15A
LG	CF29C26	MC51B
LG	CF29C36	MC51B
LG	CF29C42P	MC15A
LG	CF29C44	MC51A
LG	CF29C44XM	MC51A
LG	CF29C60	MC51A
LG	CF29C60XM	MC51A

Brand	model	chassis
LG	CF29C70	MC51A
LG	CF29C76	MC51B
LG	CF29C76X	MC51B
LG	CF29C80	MC51A (pono NIE!)
LG	CF29C80I	PC63A
LG	CF29C80I	PC82A (?)
LG	CF29F96IP	MC006A
LG	CF29H20TM	MC71A
LG	CF29H30T	MC74A
LG	CF29H30T	PC8KA ?
LG	CF29H90TM	MC71B
LG	CF29K40N	MC74A
LG	CF29N20M	MC71A
LG	CF51F82	MC99BA
LG	CF51F92	MC99BA
LG	CF51F92T	MC99BA
LG	CFT2875	MC15A
LG	CI14A80	PC31A
LG	CI14B50F	11.1 (BEKO)
LG	CI14F80F	12.1 (?? not sure)
LG	CI14F84X	12.4/12.5 (BEKO)
LG	CI20A80	PC31A
LG	CI20A96F	PC53A
LG	CI20E20F	PC53A
LG	CI20F60X	PC81A
LG	CI20F84X	12.4/12.5 (BEKO)
LG	CI21A80F	PC31A
LG	CI21E20F	PC53A
LG	CI21F60X	PC81A
LG	CI21F80F	PC81A
LG	CI21T24F	PC81B (=CI21T20F)
LG	CI25H40	PC8KA
LG	CI29H40	PC8KA
LG	CIS4361	PC04X
LG	CIS4441	PC04X

Brand	model	chassis
LG	CIT2162X	PC08X8
LG	CIT2165X	PC08X8
LG	CIT2168	PC04X
LG	CIT2168F	PC04A
LG	CIT2172	PC07X2
LG	CIT2175	PC07X2
LG	CIT2180	PC04X
LG	CIT2181	PC04A
LG	CIT2181F	PC04A
LG	CIT2190	PC04A
LG	CIT2190F	PC04A
LG	CIT2191	PC04A
LG	CIT2191F	PC04A
LG	CIT2570F	PC12B
LG	CIT2588	MC05B
LG	CIT4441	PC04X
LG	CIT4442	PC04X
LG	CIT4782	PC08X8
LG	CIT4785	PC08X8
LG	CIT4902	PC04A
LG	CIT4905	PC04A
LG	CIT6105	PC04X
LG	CIT9172	PC11A
LG	CIT9822	PC04A
LG	CIT9825	PC04A
LG	CIT9902	PC04A
LG	CIT9902F	PC04A
LG	CIT9905	PC04A
LG	CK14F84	12.4/12.5 (A99.190-06 (BEKO))
LG	CK14F84	12.4/12.5 (A99.190-19 (BEKO))
LG	CK14F84SX	12.4
LG	CK14F84X	12.4/12.5 (A99.190-12) (BEKO)
LG	CK20F60X	PC81A
LG	CK20F84	12.4
LG	CK20F84	12.4/12.5 (A99.190-19)

Brand	model	chassis
LG	CK20F84	12.4/12.5 (BEKO)
LG	CK20F84X	12.4/12.5 (BEKO) ?
LG	CK20F84X	12.5 ?
LG	CK20S84X	12.5 ?
LG	CK21F84X	12.4/12.5 (BEKO) ?
LG	CK21T24EX	PC81B
LG	CK21T43T	MC00AA
LG	CL29Q10ET	MC991A
LG	CMS9071	NC91H
LG	CMT2865	NC11A
LG	CMT9722	NC95H
LG	CN14A30H	NC5AA
LG	CN14B80H	NC5AA
LG	CN14D90	NC5AA
LG	CN14D99	NC5AA
LG	CN14E90	NC4HA
LG	CN14J20	NC5AA
LG	CN20A92H	NC5AA/5AD ?
LG	CN20B80H	NC5AA
LG	CN20B90	NC4JA
LG	CN20C60	NC5SD
LG	CN20D99	NC6HA
LG	CN20D99S	NC31A
LG	CN20E90	NC5AA (?)
LG	CN20H10	NC5AA
LG	CN20J20S	NC5AA
LG	CN29H90 DS	NC71A
LG	CP14F60	MC83A
LG	CP14F90	MC83A
LG	CP14J50	MC83A
LG	CP14K40	MC83A
LG	CP14K60	MC999A
LG	CP14K70	MC999A
LG	CP14K70	MC999A
LG	CP15Q90	MC83C

Brand	model	chassis
LG	CP20A30	MC83B
LG	CP20B80H	NC5AA
LG	CP20B80M	MC83A
LG	CP20B85	MC83C ?
LG	CP20CK40	MC83A
LG	CP20J20	MC58A ?
LG	CP20J50	MC83A
LG	CP20J52	MC83C
LG	CP20J52A	SC023A
LG	CP20K40	MC83A
LG	CP20K60	MC999A
LG	CP20K70	MC999A
LG	CP21D70M	MC83A
LG	CP21K44	MC83A
LG	CP21Q20	MC99GA
LG	CP21Q22	MC997A
LG	CP21Q24	MC83C
LG	CP21Q26	MC83C
LG	CP21Q60	MC83C
LG	CP25Q20	MC99GA
LG	CP25Q22	MC005A
LG	CP26K60	MC7CG
LG	CP26K60	MC7CG
LG	CP27K60	MC7CG
LG	CP29C34H	MC059A
LG	CP29C42P	MC53Z
LG	CP29C84M	MC059K
LG	CP29C85	MC7CD
LG	CP29FA30	MC005A
LG	CP29H34	MC059A
LG	CP29H90	MC53Z
LG	CP29K30	MC005A
LG	CP29K40	MC7CD
LG	CP29K40	MC7CD
LG	CP29K40 (Ilw.)	MC83A

Brand	model	chassis
LG	CP29K40P	MC7CD
LG	CP29K44P	MC7CG
LG	CP29M30A	MC022A
LG	CP29Q12P	MC996A
LG	CP29Q22	MC005A
LG	CP29Q30P	MC001A
LG	CP29Q50	MC99GA
LG	CP29Q54 Y Q22	MC005A
LG	CP29Q54A	MC022
LG	CP50J52	SC023A
LG	CT14J50	MC994A
LG	CT14K50X	MC84A
LG	CT14K52X	MC84A
LG	CT14K54ET	MC84A
LG	CT14S10X	MC84A
LG	CT14S12E	MC84A
LG	CT15Q91KEX	MC019A
LG	CT16S10X	MC84A
LG	CT16S12E	MC84A
LG	CT20J50	MC994A
LG	CT20K50X	MC84A
LG	CT20K52X	MC84A
LG	CT20K54ET	MC84A
LG	CT20S10X	MC84A
LG	CT20S12E	MC84A
LG	CT2190	Matsui 2090
LG	CT21K50X	MC84A
LG	CT21K52X	MC84A
LG	CT21K54ET	MC84A
LG	CT21Q20E/EN/ET	MC99BA
LG	CT21Q20ET	MC99BA
LG	CT21S10X	MC84A
LG	CT21S12E	MC84A
LG	CT25K90EN	MC022A ?
LG	CT25Q20EN	MC991A

Brand	model	chassis
LG	CT29K30VT	MC022A
LG	CT29K37E	MC007A
LG	CT29K37PX	MC007A
LG	CT29M60E	MC8CB
LG	CT29Q10ET	MC991A
LG	CT29Q12IP	MC993A
LG	CT29Q901	MC006A
LG	CT29Q90IP	MC006A
LG	CT29Q94PT	MC99AA
LG	CZ14J50	MC994A
LG	CZ20J50	MC994A
LG	DI28FZ11	DC026A
LG	DI28Z12	PD8TA
LG	DI32FZ11	DC026A
LG	DI32Q82	PD00JA
LG	DT7000	PC63A
LG	DU42LZ30	AL03HA
LG	FWD42PV1	CL86
LG	FWD42PV1A	CL86
LG	FWD42PV1P	CL86
LG	GCT1354MN	NC4JA
LG	KB20U71X	PV71A
LG	KB20V30	MV55A ?
LG	KCI20F60	PC81A
LG	KCI20F60X	PC81A
LG	KCI21F60	PC81A
LG	KCI21F60X	PC81A
LG	KCI21T24F	PC81B (=CI21T20F)
LG	KE14P21B	MV025A, DECK D33
LG	KE14P21BX	MV025A, DECK D33
LG	KE14P21S	MV025A, DECK D33
LG	KE14P21SX	MV025A, DECK D33
LG	KE14P2B/BX/GX/PX/SX	MV995B
LG	KE14U73X	MV995A
LG	KE20P30X	MV995B

Brand	model	chassis
LG	KE20P31X	MV025A , Deck D-33
LG	KE20U73X	MV995A
LG	KE21P10T	MV008A, Deck D33
LG	KF14V30	MC48A
LG	KF20V30	MC48A
LG	KI14U30	MV55A
LG	KI14U71	PV71A
LG	KI14U71X	PV71A
LG	KI14U72	PV71A, Deck D-27
LG	KI14V20	PC32A
LG	KI14V30	MC48A
LG	KI14V38	MV55A
LG	KI20U30	MV55A
LG	KI20U71	PV71A
LG	KI20U72	PV71A, Deck D-27
LG	KI20U72X	PV71A
LG	KI20V38	MV55A
LG	KU17WDVD	ML027B
LG	KY14V30	MC48A
LG	KY20V30	MC48A
LG	KZ21FC70	MV033A
LG	L1917S	CL82
LG	L27W46	ML041A
LG	LAFINION 72	MC035A, see RZ29FC40RB
LG	LAFINION 82W	MC035A, see RZ32FZ40RB
LG	LAFINION72	SC023 ?
LG	LAFINION72-82W	MC021B
LG	LAFINION82	SC023 ?
LG	LE15A10	MF004A
LG	LE15A15	ML012A
LG	LG8231	MC61B
LG	LPXG2	NP00EA
LG	LPXG22	NP00ED
LG	LPXG24	NP00ED
LG	MT42PZ10	MP00MC

Brand	model	chassis
LG	MT42PZ12	MP00MC
LG	MT42PZ14	MP00MC
LG	MT42PZ24	MP00MC
LG	MT42PZ44	RF03FA
LG	MT42PZ45	RF03FA
LG	MT50PZ41	RF02CA
LG	MT50PZ42	RF02CA
LG	MT50PZ43	RF02CA
LG	MT60PZ12	NP00KB
LG	MT60PZ14	NP00KB
LG	MT60PZ90M	RF03LA
LG	MT60PZ92M	RF03LA
LG	MU42PZ11B	NF01D
LG	Multiplex 55	MV033A
LG	Multiplex72	MV033A
LG	MW30LZ10	MF02HA
LG	MW60SZ12	RE01JB
LG	MW71PY10	RF04FA
LG	MZ40PZ10	MP00MC
LG	MZ42PM13	RF04GC
LG	MZ42PZ10	MP00MC
LG	MZ42PZ12	MP00MC
LG	MZ42PZ12	MP00MC
LG	MZ42PZ14	MP00MC
LG	MZ42PZ14	MP00MC (42SD3)
LG	MZ42PZ17	NF01DC
LG	MZ42PZ24	MP00MC
LG	MZ42PZ24	MP00MC
LG	MZ42PZ42S	RF02RA
LG	MZ42PZ44	RF03FA
LG	MZ42PZ45	RF03FA
LG	MZ50PZ42	RF02CA
LG	MZ50PZ43	RF02CA
LG	MZ50PZ43	RF02CA
LG	MZ50PZ46	RF03FB

Brand	model	chassis
LG	MZ60PZ10	NP00KA
LG	MZ60PZ12	NP00KB
LG	MZ60PZ14	NP00KB
LG	MZ60PZ92V	RF03LA
LG	PDP42V6	L6B (BEKO)
LG	PF43A20	MP87B
LG	PF43F20	MP87B
LG	PFM42V1	CL50
LG	PP43A80P	MP00PA
LG	PP48A80P	MP00PA
LG	PP53A80P	MP00PA
LG	RB28CZ10RX	14.2 (BEKO)
LG	RB32CZ10RX	14.2 (V80.190-08) BEKO
LG	RE20CB10MX	MC019A
LG	RE21CC30RX	11AK30 (?)
LG	RE21FB30RX	MC019A
LG	RE21FB50RX	MC019A
LG	RE28CB80RX	MC022A
LG	RE28CZ20	11AK45
LG	RE28FZ10PX	MC017A
LG	RE28FZ10RX	MC022A
LG	RE28FZ30RQ	MC036A
LG	RE29FA31PX	MC017A
LG	RE29FA33PX	MC017A (100Hz)
LG	RE29FA33PX(X)	MC017A
LG	RE29FA33X	MC017A
LG	RE29FA34RB	MC036A
LG	RE29FA34RP	MC036A
LG	RE29FB50RQ	MC022A
LG	RE29FB51RQ	MC036A
LG	RE32FZ10PX	MC017A
LG	RE32FZ30RQ	MC036A
LG	RE39NZ40RB	MP015D
LG	RE39NZ43RB	MP015D ?
LG	RE39NZ43RB	MP03AB

Brand	model	chassis
LG	RE40NZ60RB	MP03AB
LG	RE44NA13RB	MP03AB
LG	RE44NA14T	MP03AB
LG	RE44NZ21	MC015 ?
LG	RE44SZ20RD	MB02JA
LG	RE44SZ20RD	MB02JB
LG	RE44SZ21RD	MB02JB
LG	RE45NZ60RB	MP03AB
LG	RE49NZ21RB	MP015D
LG	RE54NA13RB	MP03AB
LG	RE56NZ21RB	MP015D
LG	RE56NZ60RB	MP03AB
LG	RF21FA31W	MC019A
LG	RI28CZ10RX	14.2 (V80.190-090)
LG	RI32CZ10RX	14.2 (BEKO)
LG	RJ15LA50	ML042
LG	RK14CC40M	12.6 (BEKO)
LG	RK20CC40M	12.6 (BEKO)
LG	RK21CC40MX	12.6 (BEKO)
LG	RL14CC40MX	12.6 (BEKO)
LG	RL21FA7AX	MC019A
LG	RL28CZ20RX	11AK45
LG	RL28FZ30RQ	MC036A
LG	RL29FB51RQ	MC036A
LG	RL32FZ30RQ	MC036A
LG	RL39NZ43RB	MP03AB
LG	RL40NZ60RB	MP03AB
LG	RL44NA13RB	MP03AB
LG	RL44SZ20RD	MB02JB
LG	RL45NZ60RB	MP03AB
LG	RL54NA13RB	MP03AB
LG	RL56NZ60RB	MP03AB
LG	RM15LA66K	ML041B
LG	RM15LA6R	ML041B
LG	RN21FD10T	SC023A

Brand	model	chassis
LG	RP14CB20	SC023A
LG	RP14CB25A	MC059A (?)
LG	RP15LA50	ML024A
LG	RP20CA10	MC83C
LG	RP20CA10A	SC023A
LG	RP20CB20	SC023A (?)
LG	RP20CB20A	SC023A
LG	RP20CB60	SC023A
LG	RP20CB62	SC023A
LG	RP20LA30	MF002A
LG	RP21FA35A	SC023A
LG	RP21FA37A	SC023A
LG	RP21FB20	SC023A
LG	RP21FB32	SC023A
LG	RP21FC60	SC023A
LG	RP21FD10	SC023A
LG	RP21FD15	MC059A
LG	RP21FD15G	MC059A
LG	RP21FD60	SC023A
LG	RP21FD60G	SC023A
LG	RP21FE60	SC023A
LG	RP21FE85G	MC059A
LG	RP29CC25	MC022A
LG	RP29CC26	MC049A
LG	RP29FA30	MC005A
LG	RP29FA30A	MC022A
LG	RP29FB30	MC022A
LG	RP29FD15	MC049A
LG	RP29FD60	MC049A
LG	RP40NZ60P	MP03AA
LG	RP44NA20PA	MP03AA
LG	RP44NA20PA	MP03AA
LG	RP44NA21P	MP00PA
LG	RP54NA20PA	MP03AA
LG	RT-BA50	RF03FA

Brand	model	chassis
LG	RT14CA50M	MC019A
LG	RT15LA30	MF004A
LG	RT15LA31	ML012A
LG	RT15LA70	ML041B
LG	RT21FB30M	MC019A
LG	RT21FB70RN/RQ/RX/V/VX	MC019A
LG	RT21FD15V	MC049B
LG	RT21FD15VX	MC049B
LG	RT26LZ50	ML041A
LG	RT29FA35RT	MC049A
LG	RT29FB50	MC022A
LG	RT29FD15R/RB/RE/RK	MC049A
LG	RT29FD15RQ/V/VE/VX	MC049A
LG	RT29FD16RX	MC049A
LG	RT34FB11RB	MC006A
LG	RT37LZ55	ML051B
LG	RT39NZ40RB	MP015D
LG	RT42PX10/H	RF043B
LG	RT42PZ45	RF03FA
LG	RT42PZ45V	RF03FA
LG	RT44SZ80LB	MB042C
LG	RT48SZ40RB	MB03CA
LG	RT50PZ60	RF03OB
LG	RT52SZ80LB	MB042C
LG	RT54NA61RB	MP03AB
LG	RT62 NA31RB/RP	MP015C
LG	RU17LZ22	ML027C
LG	RU20LA30	MF002A
LG	RU23LZ21	ML027C
LG	RU42PZ90	RF03GA
LG	RU44SZ51D	NB03JC
LG	RU52SZ51D	NB03JC
LG	RZ-BA50	RF03FA
LG	RZ15LA31	ML012A
LG	RZ15LA32	ML024A

Brand	model	chassis
LG	RZ15LA70	ML041B
LG	RZ15LA70	ML042E (czy? ML024E)
LG	RZ17LZ10	ML027A
LG	RZ17LZ40	ML024F
LG	RZ20LA31	LCD
LG	RZ20LA60	ML012B
LG	RZ20LA66	ML024D
LG	RZ20LA70	ML041B
LG	RZ20LA70	ML041B
LG	RZ20LZ50C	ML041F
LG	RZ21FB35MX	MC049B
LG	RZ21FB35RX	MC049B
LG	RZ21FD15RX	MC049B (?)
LG	RZ21FD70RX	MC049C (?)
LG	RZ23LZ20	LCD
LG	RZ26LZ50	ML041A
LG	RZ29FA34RB	MC017A
LG	RZ29FB51RX	MC036A
LG	RZ29FB55RX	MC049A
LG	RZ29FC40RB	MC021B (czy? raczej MC035A, Lafinion 72)
LG	RZ30LZ13	ML038A
LG	RZ30LZ50	ML041A
LG	RZ32FZ40RB	MC035A, Lafinion 82W
LG	RZ32LZ50	ML041A
LG	RZ32LZ55H	ML041E
LG	RZ37LZ30	ML038C (?)
LG	RZ37LZ55	ML051B
LG	RZ42LZ30	ML038C
LG	RZ42PX10	RF043B
LG	RZ42PX11	RF043B
LG	RZ42PX12X	RF043B
LG	RZ42PY10X	RF043B
LG	RZ50PY10	RF043B
LG	RZ60PY10	RF043B
LG	TVRB20CC40MX	12.6 (BEKO)

Brand	model	chassis
LG	WE32Q101P	MC993A
LG	WE32Q10IP	MC993A
LG	WE32Q81 ID	MC006A
LG	WF28A12T	MC52C
LG	WF32A10S	MC52A
LG	WF32A14T	MC52C
LG	WF32A14TM	MC52C
LG	WF32A20TM	MC61B
LG	WF32A22DI	PC82A
LG	WF32Q10IP	MC993A (100Hz)
LG	WP32A30	MC75A
LG-ZENITH	RP29FA40	FA
LIFETEC	7055VTS	7000 PROFESSIONAL
LIFETEC	7095VTSa	11AK19...
LIFETEC	LT3437	11AK20M6
LIFETEC	LT3710	GT9313
LIFETEC	LT3716	CP082
LIFETEC	LT3728	11AK08
LIFETEC	LT3733	11AK20 ?
Lifetec	LT3733VT	11AK20
LIFETEC	LT3738	11AK08
LIFETEC	LT3752VT	11AK20S
LIFETEC	LT5510VT	GT9313
LIFETEC	LT5520VT	GT9313
LIFETEC	LT5530VT	GT9313
LIFETEC	LT5548VTS	11AK10-17
LIFETEC	LT5548VTS	11AK10-18
LIFETEC	LT5548VTS	11AK19E3
LIFETEC	LT5561	11AK19 P4
LIFETEC	LT7000	TV8
LIFETEC	LT7049VTS	11AK19P4 (11AK19-8A)
LIFETEC	LT7049VTS	11AK19P4 (11AK19-8A)
LIFETEC	LT7055VTS	7000 Professional
LIFETEC	LT7061VTS	11AK19E3
LIFETEC	LT7079VTS	TV17.1

Brand	model	chassis
LIFETEC	LT7079VTS	TV9.6
LIFETEC	LT7090	TV8
LIFETEC	LT7095	11AK19B1
LIFETEC	LT7095VTS	11AK19-5
LIFETEC	LT7099VTS	11AK19
LIFETEC	LT7108	TV17.6 (100Hz)
LIFETEC	LT7108VTS	TV17.6 (100Hz)
LIFETEC	LT7109VTS	TV17.6 (100Hz)
LIFETEC	LT8201	TV17.1
LIFETEC	LT8201VTS	TV17.1
LIFETEC	VT7061VTC	11AK19PRO
LIFEVISION	5101	S0202-832R
LOEWE	1670Z Art.no 57404	Q4040 (110Q44)
LOEWE	2050MHZ/2	Q2100
LOEWE	51415	C9003
LOEWE	51423	C9003
LOEWE	51424	C9003
LOEWE	51470	C9003
LOEWE	53441	C9003
LOEWE	53442	C9003
LOEWE	53443	C9003
LOEWE	53446	C9003
LOEWE	53447	C9003
LOEWE	53448	C9003
LOEWE	53463	Q2100
LOEWE	53465	Q2100
LOEWE	53467	Q2100
LOEWE	53471	Q2100
LOEWE	54421	E3000
LOEWE	54427L30	Q2100 (110R21)
LOEWE	54451	E3000
LOEWE	54452	E3000
LOEWE	54453	E3000
LOEWE	54454	E3000
LOEWE	54455	E3000

Brand	model	chassis
LOEWE	55452	E3000
LOEWE	55453	E3000
LOEWE	55454	E3000
LOEWE	55457	Q4000
LOEWE	56406	Q4000
LOEWE	56408	Q4000
LOEWE	56416	Q4000
LOEWE	56451	Q4000
LOEWE	57401	E3000
LOEWE	57402	E3000
LOEWE	57409	E3000
LOEWE	57410	E3000
LOEWE	574404	Q4040
LOEWE	574413	Q4040
LOEWE	574414	Q4040
LOEWE	574415	Q4040
LOEWE	574416	Q4040
LOEWE	574425	Q4040
LOEWE	574426	Q4040
LOEWE	574427	Q4040
LOEWE	574431	Q4040
LOEWE	574432	Q4040
LOEWE	574433	Q4040
LOEWE	57464	Q4200
LOEWE	57480	Q4200
LOEWE	57482	Q4200
LOEWE	59401	MEDIA PLUS
LOEWE	59407	MEDIA PLUS
LOEWE	59417	MEDIA PLUS
LOEWE	59420	MEDIA PLUS
LOEWE	59437	MEDIA PLUS
LOEWE	59448	MEDIA PLUS
LOEWE	59449	MEDIA PLUS
LOEWE	59452	MEDIA PLUS
LOEWE	59453	MEDIA PLUS

Brand	model	chassis
LOEWE	59459	MEDIA PLUS
LOEWE	59464	MEDIA PLUS
LOEWE	59465	MEDIA PLUS
LOEWE	60407	C9003
LOEWE	60473	C9001
LOEWE	66420	C9000
LOEWE	66423	C9000
LOEWE	66425	C9000
LOEWE	66426	C9000
LOEWE	66445	C9000
LOEWE	66448	C9000
LOEWE	66449	C9000
LOEWE	66450	C9000
LOEWE	66460	C9000
LOEWE	66472	C9000
LOEWE	66480	C9000
LOEWE	66490	C9000
LOEWE	68411	C9001
LOEWE	68414	C9001
LOEWE	68418	C9001
LOEWE	68419	C9001
LOEWE	68424	C9001
LOEWE	68425	C9001
LOEWE	68428	C9001
LOEWE	68429	C9001
LOEWE	68432	C9001
LOEWE	68441	C9001
LOEWE	68442	C9001
LOEWE	68443	C9001
LOEWE	68447	C9001
LOEWE	68451	C9001
LOEWE	68454	C9001
LOEWE	68458	C9001
LOEWE	68491	C9001
LOEWE	68492	C9001

Brand	model	chassis
LOEWE	69244	C9001
LOEWE	69406	C9001
LOEWE	69407	C9001
LOEWE	69411	C9001
LOEWE	69412	C9001
LOEWE	69421	C9001
LOEWE	69422	C9001
LOEWE	69423	C9001
LOEWE	69425	C9001
LOEWE	69426	C9001
LOEWE	69427	C9001
LOEWE	69431	C9001
LOEWE	69432	C9001
LOEWE	69433	C9001
LOEWE	69434	C9001
LOEWE	69435	C9001
LOEWE	69436	C9001
LOEWE	69437	C9001
LOEWE	69441	C9001
LOEWE	69443	C9001
LOEWE	69444	C9001
LOEWE	69470	C9001
LOEWE	69471	C9001
LOEWE	69472	C9001
LOEWE	69483	C9001
LOEWE	69491	C9001
LOEWE	69492	C9001
LOEWE	70-100PIP	Q2100 (110R21)
LOEWE	ACO9303PB	A2400
LOEWE	ACONDA 9281	Q2400 MEDIA PLUS
LOEWE	ACONDA 9281ZW	Q2500/H MEDIA PLUS
LOEWE	ACONDA 93102ZW	Q2500/H MEDIA PLUS
LOEWE	ACONDA 9372ZP	Q2500/H MEDIA PLUS
LOEWE	Aconda 9381ZPW	Q2400
LOEWE	ACONDA 9381ZPW	Q2400 Media Plus

Brand	model	chassis
LOEWE	ACONDA 9381ZPW	Q2500/H MEDIA PLUS
LOEWE	ACONDA 9581ZW	Q2500/H MEDIA PLUS
LOEWE	AR TV700	Q2000
LOEWE	ARCADA 52470	Q2000
LOEWE	ARCADA 5684Z	Q2300
LOEWE	ARCADA 72 PIP	Q2000
LOEWE	Arcada 72--52470L	Q2000
LOEWE	ARCADA 72-100	Q2100 (110Q21)
LOEWE	Arcada 72-100 PIP	Q2100
LOEWE	ARCADA 72100	Q2100
LOEWE	ARCADA 8584ZP	Q2100
LOEWE	Arcada 8584ZP	Q2100
LOEWE	ARCADA 8584ZP	Q2200
LOEWE	ARCADA 8672Z	Q2300
LOEWE	Arcada 8672Z--56424L00	Q2200
LOEWE	Arcada 8672Z--57437L32/Q62	Q2100
LOEWE	ARCADA 8672ZP	Q2300
LOEWE	ARCADA 8672ZP/NIC-L	Q2300
LOEWE	ARCADA 8684	Q2300
LOEWE	ARCADA 8684ZP	Q2200
LOEWE	ARCADA 8684ZP	Q2300
LOEWE	Arcada 8684ZP--56425L32	Q2200
LOEWE	Arcada 8684ZP--57438L32	Q2300
LOEWE	ARCADA 8755Z	Q4140
LOEWE	Arcada 8772ZP	Q2400
LOEWE	ARCADA 8772ZP	Q2400 Media Plus
LOEWE	ARCADA 8772ZP	Q2500M MEDIA PLUS
LOEWE	Arcada 8784ZP	Q2400
LOEWE	ARCADA 8784ZP	Q2400 Media Plus
LOEWE	ARCADA 8784ZP	Q2500M MEDIA PLUS
LOEWE	ART 1	C9000
LOEWE	ART 1SAT	C9002
LOEWE	ART 500	C9002S
LOEWE	ART 55	C9001
LOEWE	ART 550	C9001

Brand	model	chassis
LOEWE	ART 5500	C9001
LOEWE	ART 550SAT	C9002
LOEWE	ART 63	C9001
LOEWE	ART 630SAT	C9002
LOEWE	ART 630SAT	C9002S
LOEWE	ART 68424	C9001
LOEWE	ART 68425	C9001
LOEWE	ART 68428	C9001
LOEWE	ART 68429	C9001
LOEWE	ART 68432	C9001
LOEWE	ART 68451	C9001
LOEWE	ART 68454	C9001
LOEWE	ART 68458	C9001
LOEWE	ART 68491	C9001
LOEWE	ART 68492	C9001
LOEWE	ART 69421	C9002
LOEWE	ART 69422	C9002
LOEWE	ART 69423	C9002
LOEWE	ART 69424	C9002
LOEWE	ART 69425	C9002
LOEWE	ART 69426	C9002
LOEWE	ART 69427	C9002
LOEWE	Art 70-100	Q2100
LOEWE	ART 7000	C9001
LOEWE	Art 7007	C9003
LOEWE	ART 700SAT	C9002
LOEWE	ART 700SAT	C9002S
LOEWE	ART 70100	Q2100
LOEWE	ART 70100 NIC	Q2100
LOEWE	ART 70SAT	C9001
LOEWE	ART 82SAT	C9001
LOEWE	ART 84 SAT	C9001
LOEWE	Art 84-100	Q2100
LOEWE	ART 8400	C9001
LOEWE	ART 840SAT	C9001

Brand	model	chassis
LOEWE	ART 840SAT	C9002
LOEWE	ART 84100 NIC	Q2100
LOEWE	ART 8420SAT/NIC	Q2000
LOEWE	ART 8500	C9001
LOEWE	ART 95 SAT	C9001
LOEWE	Art 95-100	Q2100
LOEWE	ART 950SAT	C9001
LOEWE	ART 950SAT	C9002
LOEWE	ART 95100	Q2100
LOEWE	ART 9520SAT/PIP/NIC	Q2000
LOEWE	ART P17	C8500 / Goldstar ch. PC06
LOEWE	ART PLUS 8420SAT	Q2000
LOEWE	ART S24	C9000
LOEWE	ART S32	C9001
LOEWE	ART T21	C9001
LOEWE	ART T28	C9001
LOEWE	ART TV700SAT	C9001
LOEWE	ART TV700SAT	C9002
LOEWE	ART TV70SAT	C9001
LOEWE	ART V2	C9001
LOEWE	ART V2/32	C9003
LOEWE	Art V20-100	Q2100
LOEWE	ART V20100	Q2100
LOEWE	ART V20100SAT	Q2100
LOEWE	ART V20SAT/PIP/NJC	Q2000
LOEWE	ART V63	C9001
LOEWE	ART V630SAT/MAC	Q2000
LOEWE	ART V70	C9001
LOEWE	Art V70-100	Q2100
LOEWE	ART V70-100	Q2100
LOEWE	ART V700SAT4	Q2000
LOEWE	ART V70100	Q2100
LOEWE	Art Vision 70-100	Q2100
LOEWE	Art Vision 70-100 PIP	Q2100
LOEWE	Art Vision 70-100 Video Hifi	Q2100

Brand	model	chassis
LOEWE	Art Vision 70-100 VidieoHifi PIP	Q2100
LOEWE	AV-ENTOS 3970ZW	Q2500B MEDIA PLUS
LOEWE	AV-ENTOS 3972ZP	Q2500B MEDIA PLUS
LOEWE	AV-ENTOS 3981ZW	Q2500M MEDIA PLUS
LOEWE	AVENTOS 3970ZW	Q2500/B MEDIA PLUS
LOEWE	AVENTOS 3972ZP	Q2500/B MEDIA PLUS
LOEWE	AVENTOS 3981ZW	Q2500M MEDIA PLUS
LOEWE	CAL2323MB	A2400
LOEWE	CALIDA 5055	E3000
LOEWE	CALIDA 5063	E3000
LOEWE	CALIDA 5072	E3000
LOEWE	Calida 5072--55401S/P/L/M 00	E3000
LOEWE	CALIDA 5155	E3000
LOEWE	CALIDA 5255	E3001
LOEWE	CALIDA 5555Z	Q2100
LOEWE	CALIDA 5563Z	Q2100
LOEWE	CALIDA 5572Z	Q2100 (110R21)
LOEWE	Calida 5572Z--54427U60/L30 60	Q2100
LOEWE	CALIDA 5584Z	Q2100
LOEWE	Calida 5584Z--54426L/U 60	Q2100
LOEWE	CALIDA 5655Z	Q4000 (90Q40)
LOEWE	CALIDA 5655Z	Q4040
LOEWE	CALIDA 5663Z	Q4000
LOEWE	CALIDA 5663Z	Q4040
LOEWE	CALIDA 5672Z	Q4000
LOEWE	CALIDA 5672Z	Q4040
LOEWE	Calida 5672Z--56420L30/P/S/U60	Q4000
LOEWE	Calida 5672Z--57427L30/P/S/U60	Q4040
LOEWE	CALIDA 5684Z	Q2200
LOEWE	CALIDA 5684Z	Q2300
LOEWE	CALIDA 5684Z	Q4140 (110Q4140)
LOEWE	Calida 5684Z--56421L/P/U 60	Q2200
LOEWE	Calida 5684Z--57428L/P/U 60	Q2300
LOEWE	CALIDA 5755Z	Q2500B MEDIA PLUS
LOEWE	CALIDA 5763Z	Q2500B MEDIA PLUS

Brand	model	chassis
LOEWE	CALIDA 5772ZP	Q2500B MEDIA PLUS
LOEWE	CALIDA 5772ZP	Q4140 ?
LOEWE	CALIDA 5784ZP	Q2500B MEDIA PLUS
LOEWE	Calida 70	E3000 (110E30)
LOEWE	CALIDA 7220SAT/MAC	Q2000
LOEWE	CALIDA 84	Q2000 (110Q20)
LOEWE	CALIDA 84NIC	Q2000
LOEWE	CALIDA M55H	PC65A (LG) (C8920)
LOEWE	CANTUS 3870ZW	Q2500B MEDIA PLUS
LOEWE	CANTUS 3870ZW	Q4140 (110Q414)
LOEWE	CANTUS 3872ZP	Q2500B MEDIA PLUS
LOEWE	CANTUS 3872ZP	Q2500S
LOEWE	Classic S127 64448	C8001 (110C81)
LOEWE	Classic S28 64447	C8001 (110C81)
LOEWE	Classic S724	C8001 (110C81)
LOEWE	Concept 17-100	Q2100
LOEWE	CONCEPT 17-100	Q2100
LOEWE	CONCEPT 1700	C9002 (C837)
LOEWE	CONCEPT 1720PLUS/VT/NIC	Q2000
LOEWE	CONCEPT 370VT	C8700 (?)
LOEWE	CONCEPT 40 art. nr. 51401	C8600 (GoldStar)
LOEWE	CONCEPT 40VT art. nr. 51441	C8600 (GoldStar)
LOEWE	CONCEPT 55	PC06A
LOEWE	CONCEPT 55 art.-nr. 51402	C8600 (GoldStar)
LOEWE	CONCEPT 55 SAT	C9001
LOEWE	CONCEPT 55 SAT	C9002
LOEWE	Concept 55 VT/Artikel Nr. 5144	C8500 / Goldstar ch. PC06
LOEWE	CONCEPT 550	C8700
LOEWE	CONCEPT 550	C9002
LOEWE	CONCEPT 550	C9002
LOEWE	CONCEPT 550VT	PC06A (GoldStar) - ?
LOEWE	CONCEPT 55VT	C8600 Mono
LOEWE	CONCEPT 55VT	PC06A (GoldStar)
LOEWE	CONCEPT 55VT art.-nr. 51444	C8600 (GoldStar)
LOEWE	CONCEPT 630	E3000

Brand	model	chassis
LOEWE	CONCEPT 63SAT	C9001
LOEWE	CONCEPT 70	C9001
LOEWE	CONCEPT 700	E3000
LOEWE	CONCEPT 70SAT	C9001
LOEWE	Concept 84-100	Q2100
LOEWE	CONCEPT 84100	Q2100
LOEWE	CONCEPT 8420PLUS	Q2000
LOEWE	Concept Plus 17-100	Q2100
LOEWE	CONCEPT PLUS 1700	C9003
LOEWE	CONCEPT PLUS 17100	Q2100
LOEWE	CONCEPT PLUS 763	C9003
LOEWE	CONCEPT PLUS 770	C9003
LOEWE	Concept Plus 84-100	Q2100
LOEWE	CONCEPT Plus 84-100-- 53458W32	Q2100
LOEWE	CONCEPT PLUS 8420PLUS	Q2000
LOEWE	CONCEPT T84NIC	Q2000
LOEWE	CONTUR 1263	E3000
LOEWE	CONTUR 1270	E3000
LOEWE	CONTUR 1463	E3000
LOEWE	CONTUR 1470	E3000
LOEWE	CONTUR 1570Z	Q4000
LOEWE	CONTUR 1663Z	Q2500B MEDIA PLUS
LOEWE	CONTUR 1663Z	Q4140
LOEWE	CONTUR 1670Z	Q2500B MEDIA PLUS
LOEWE	CONTUR 1670Z	Q4040
LOEWE	CONTUR 1670Z	Q4140 (110Q414)
LOEWE	CONTUR 2063	E3001
LOEWE	CONTUR 2070	E3001
LOEWE	CONTUR 63	C9001
LOEWE	CONTUR 630	C9003
LOEWE	CONTUR 70	C9001
LOEWE	CONTUR 700	C9003
LOEWE	CONTUR PLUS 630	C9003
LOEWE	CONTUR PLUS 700	C9003
LOEWE	Contur S124 64442	C8001 (110C81)

Brand	model	chassis
LOEWE	Contur S127 64444	C8001 (110C81)
LOEWE	Contur S128 64462	C8001 (110C81)
LOEWE	Contur S24 64424	C8001 (110C81)
LOEWE	Contur S28 64461	C8001 (110C81)
LOEWE	CONTUR T24	C9000
LOEWE	CONTUR T28	C9000
LOEWE	CONTUR T63	C9000 (110C9)
LOEWE	CONTUR T70	C9000
LOEWE	CREDO 7570ZP	Q2200
LOEWE	CREDO 7570ZPH	Q2300
LOEWE	Credo 7581ZP	Q2200
LOEWE	CREDO 7581ZP	Q2200
LOEWE	CREDO 7581ZPH	Q2300
LOEWE	CREDO 7670ZPW	MEDIA PLUS
LOEWE	Credo 7670ZPW	Q2400
LOEWE	CREDO 7670ZPW	Q2400 Media Plus
LOEWE	CREDO 7681ZPW	MEDIA PLUS
LOEWE	Credo 7681ZPW	Q2400
LOEWE	CREDO 7681ZPW	Q2400 Media Plus
LOEWE	CS1 Art.Nr 55410L00	Q2050
LOEWE	CS1--55410L00	Q2050
LOEWE	CT1163	E3000 (110E30)
LOEWE	CT1170	E3000
LOEWE	CTV4232	C8000 (80C8)
LOEWE	CTV6732	C8000 (80C8)
LOEWE	Ergo 6572	Q2100
LOEWE	ERGO 6572Z	Q2100
LOEWE	Ergo 6581	Q2100
LOEWE	ERGO 6581ZP	Q2100
LOEWE	ERGO 6581ZP	Q2200
LOEWE	ERGO 6581ZP	Q2300
LOEWE	ERGO 6670ZP	Q2200
LOEWE	ERGO 6670ZP	Q2300
LOEWE	ERGO 6672ZP	Q2200
LOEWE	ERGO 6672ZP	Q2300

Brand	model	chassis
LOEWE	ERGO 6681ZP	Q2200
LOEWE	ERGO 6681ZP	Q2300
LOEWE	ERGO 6770ZP	Q2400 Media Plus
LOEWE	ERGO 6770ZPW	MEDIA PLUS
LOEWE	Ergo 6770ZPW	Q2400
LOEWE	ERGO 6772ZP	MEDIA PLUS
LOEWE	Ergo 6772ZP	Q2400
LOEWE	ERGO 6772ZP	Q2400 Media Plus
LOEWE	ERGO 6781ZP	Q2400 Media Plus
LOEWE	Ergo 6781ZPW	Q2400
LOEWE	ERGO 6781ZW	MEDIA PLUS
LOEWE	EVOLUTION 8102	Q2300
LOEWE	F61431	C7000 (90C7)
LOEWE	FUN	Q2300
LOEWE	IMPRESION	Q2300
LOEWE	ISFG51M22G0	PC230
LOEWE	LC15A2L	FL38
LOEWE	MC26	7000
LOEWE	ME216	C8500 MONO (90C85)
LOEWE	MELODY 7205Z	Q2500B MEDIA PLUS
LOEWE	MIMO 15	L3005
LOEWE	MIMO 28	Q2500B MEDIA PLUS
LOEWE	MIMO 29	Q2500B MEDIA PLUS
LOEWE	MIMO 32	Q2500M MEDIA PLUS
LOEWE	Modus 4972	Q2100
LOEWE	MODUS 4972Z	Q2100
LOEWE	MONACO 7700	E3000
LOEWE	MTS 28L100	Q2100
LOEWE	MTS28L100	Q2100
LOEWE	NEMOS 28	Q2500B MEDIA PLUS
LOEWE	NEMOS 29	Q2500B MEDIA PLUS
LOEWE	NEMOS 32	Q2500M MEDIA PLUS
LOEWE	PLA5303PL	A2400
LOEWE	PLANUS 4063	E3000
LOEWE	PLANUS 4072	E3000

Brand	model	chassis
LOEWE	PLANUS 4072Z	E3000
LOEWE	PLANUS 4263	E3001
LOEWE	PLANUS 4272	E3001
LOEWE	Planus 4563	Q2100
LOEWE	PLANUS 4563Z	Q2100
LOEWE	PLANUS 4572Z	Q2100
LOEWE	PLANUS 4663Z	Q2500B MEDIA PLUS
LOEWE	PLANUS 4663Z	Q4000
LOEWE	PLANUS 4663Z	Q4040
LOEWE	PLANUS 4663Z	Q4140
LOEWE	PLANUS 4670Z	Q4000
LOEWE	PLANUS 4670Z	Q4040
LOEWE	PLANUS 4670ZP	Q2500B MEDIA PLUS
LOEWE	PLANUS 4670ZW	Q2500B MEDIA PLUS
LOEWE	PLANUS 4670ZW	Q4140
LOEWE	Planus 4672Z	Q4000 (110Q40)
LOEWE	PLANUS 4672Z	Q4040 (110Q44) (100Hz)
LOEWE	PLANUS 4672Z	Q4100 (110Q41)
LOEWE	PLANUS 4672ZP	Q2500B MEDIA PLUS
LOEWE	PLANUS 4672ZP	Q4140
LOEWE	PLANUS 4681Z	Q2200
LOEWE	PLANUS 4681Z	Q2300
LOEWE	PLANUS 4681Z/NIC-L	Q2300
LOEWE	PLANUS 4681ZP ART NO : 57417U62	Q2300
LOEWE	PLANUS 4781ZP	Q2500M MEDIA PLUS
LOEWE	PLANUS 4781ZPW	MEDIA PLUS
LOEWE	Planus 4781ZPW	Q2400
LOEWE	PLANUS 4781ZPW	Q2400 Media Plus
LOEWE	PLANUS 4872Z	Q2500B MEDIA PLUS
LOEWE	PLANUS 4872Z	Q4000
LOEWE	PLANUS 4872Z	Q4040
LOEWE	PLANUS 4872Z	Q4140
LOEWE	PROFI 3570Z	Q2500
LOEWE	PROFI 763	C9003
LOEWE	PROFI 770	C9003

Brand	model	chassis
LOEWE	PROFI 863	C9003
LOEWE	PROFI 870	C9003
LOEWE	PROFI 963	C9003
LOEWE	PROFI 970	C9003
LOEWE	PROFI M21	C8500 MONO - ?
LOEWE	Profi P115	C8500 (?)
LOEWE	Profi S28 64457	C8001 (110C81)
LOEWE	PROFI T28	C9000
LOEWE	PROFI TV28	C9000
LOEWE	PROFIL 2163	E3000
LOEWE	PROFIL 2170	E3000
LOEWE	PROFIL 2570Z	Q2100
LOEWE	PROFIL 2570Z	Q2100
LOEWE	PROFIL 3070	E3000
LOEWE	PROFIL 3070	E3000
LOEWE	PROFIL 3263	E3000
LOEWE	PROFIL 3270	E3000
LOEWE	PROFIL 3272	E3000
LOEWE	PROFIL 3563Z	Q2500B MEDIA PLUS
LOEWE	PROFIL 3563Z--56416L00	Q4000 !
LOEWE	PROFIL 3563Z--57431L00	Q4040
LOEWE	PROFIL 3570Z	Q2500B MEDIA PLUS
LOEWE	PROFIL 3570Z--56451L00	Q4000
LOEWE	PROFIL 3570Z--57432L00	Q4040
LOEWE	PROFIL 3570ZWP	Q2500B MEDIA PLUS
LOEWE	PROFIL 3572Z	Q4000
LOEWE	PROFIL 3572Z	Q4040
LOEWE	PROFIL 3572Z	Q4140
LOEWE	PROFIL 3572Z--55457L00	Q4000
LOEWE	PROFIL 3572Z--57433L00	Q4040
LOEWE	PROFIL 3572ZA	Q4040
LOEWE	PROFIL 3572ZA	Q4040
LOEWE	PROFIL 3572ZP	Q4140
LOEWE	PROFIL 3572ZWP	Q2500B MEDIA PLUS
LOEWE	PROFIL PLUS 3272Z	E3000

Brand	model	chassis
LOEWE	PROFIL PLUS 3472	E3000
LOEWE	PROFIL PLUS 3572Z	Q2500B MEDIA PLUS
LOEWE	PROFIT 28	C9000
LOEWE	PROLIL 3570Z	Q4000
LOEWE	S724 64445	C8001 (110C81)
LOEWE	S824	C9000
LOEWE	S870 64476	C8001 (110C81)
LOEWE	S963 64487	C8001 (110C81)
LOEWE	S970 64486	C8001 (110C81)
LOEWE	S970 64488	C8001 (110C81)
LOEWE	SC122 64431	C8001 (110C81)
LOEWE	SE26 Stereo	C8000 (110C8)
LOEWE	SPHEROS	P2400
LOEWE	SPHEROS 20	L3005
LOEWE	SPHEROS 42	P24 MEDIA PLUS
LOEWE	SPHEROS 42 HD C	S2550 MEDIA PLUS HD
LOEWE	Spheros R32HD	L2700
LOEWE	Spheros R37HD	L2700
LOEWE	Spheros S--Art.-N° 59436	P2400
LOEWE	Spheros W--Art.-N° 59434	P2400
LOEWE	STUDIO 63	C9001
LOEWE	STUDIO 63SAT	C9001
LOEWE	STUDIO 70	C9001
LOEWE	STUDIO 70SAT	C9001
LOEWE	STUDIO 84	C9001
LOEWE	STUDIO 84 SAT	C9001
LOEWE	Studio Art1 64481	C8001 (110C81)
LOEWE	Studio S28 64450	C8001 (110C81)
LOEWE	STUDIO T24	C9000
LOEWE	STUDIO T28	C9000
LOEWE	Studio T28	C9000
LOEWE	SYMPHONY	Q2300
LOEWE	T9063	C9001
LOEWE	T9070	C9001
LOEWE	T9630S	C9001

Brand	model	chassis
LOEWE	T9635	C9001
LOEWE	T9700S	C9001
LOEWE	T9705	C9001
LOEWE	T9770	C9001
LOEWE	Telerent TV70-3000	C9001
LOEWE	TV6310	11AK31
LOEWE	Twin-SAT NRS	Q2200/4000
LOEWE	TX29A10C	Q2100
LOEWE	TX29AD10DF	Q2100
LOEWE	TX29AD10I	Q2100
LOEWE	VITROS 6370ZW	Q2500B MEDIA PLUS
LOEWE	VITROS 6370ZWP	Q2500B MEDIA PLUS
LOEWE	VITROS 6372ZP	Q2500B MEDIA PLUS
LOEWE	VITROS 6372ZP	Q4140 (110Q414)
LOEWE	VITROS 6381ZW	MEDIA PLUS
LOEWE	VITROS 6381ZW	Q2500M MEDIA PLUS
LOEWE	XELOS 5255Z	Q2500B MEDIA PLUS
LOEWE	XELOS 5255Z	Q4140
LOEWE	XELOS 5261ZW	Q2500B MEDIA PLUS
LOEWE	XELOS 5261ZW	Q4040
LOEWE	XELOS 5261ZW	Q4100
LOEWE	XELOS 5261ZW	Q4140
LOEWE	XELOS 5270ZW	Q2500B MEDIA PLUS
LOEWE	XELOS 5270ZW	Q4040
LOEWE	XELOS 5270ZW	Q4140
LOEWE	XELOS 5270ZWP	Q2500B MEDIA PLUS
LOEWE	XELOS 5281ZW	Q2300
LOEWE	XELOS 5281ZW	Q4200
LOEWE	XELOS 5381ZW	Q2400
LOEWE	XELOS 5381ZW	Q2400 Media Plus
LOEWE	Xelos 5381ZW	Q2500M
LOEWE	XELOS 5381ZW	Q2500M MEDIA PLUS
LOEWE	XELOS 5861TVM	Q4200
LOEWE	XELOS 5870TVM	Q4200
LOEWE	XELOS 5970TVM	Q2500/H MEDIA PLUS

Brand	model	chassis
LOEWE	XELOS 5970ZPW	MEDIA PLUS
LOEWE	Xelos 5970ZPW	Q2400
LOEWE	XELOS 5970ZPW	Q2400 Media Plus
LOEWE	XELOS 5981TVM	Q2500/H MEDIA PLUS
LOEWE	XELOS 5981ZPW	MEDIA PLUS
LOEWE	Xelos 5981ZPW	Q2400
LOEWE	XELOS 5981ZPW	Q2400 Media Plus
LOEWE	XELOS M137VT	M2103
LOEWE	Xelos M137VT Art.-Nr. 61469	M2103
LOEWE	Xelos M155H Art.-Nr. 61477	M2106
LOEWE	XELOS M155TM	M2106
LOEWE	Xelos M155TM Art.-Nr. 61478	M2106
LOEWE	Xelos M155VT	M2103VNX_a
LOEWE	Xelos M155VT Art.-Nr. 61473	M2103
LOEWE	Xelos M37L--57484	M1000 (M1001?)
LOEWE	XELOS M37VT	M1000
LOEWE	Xelos M37VT--57483	M1000 (M1001?)
LOEWE	XELOS M55L	M1000-1001
LOEWE	Xelos M55L--57494	M1000 (M1001?)
LOEWE	XELOS M55TM	M1003
LOEWE	XELOS M55VT	M1000
LOEWE	XELOS M55VT	M1000-M1001
LOEWE	Xelos M55VT--57493	M1000 (M1001?)
LOGIK	L14TD100	11AK46
LOGIX	280ST	STV12
LOGIX	50 TV9.3-70439/M	TV9.3
LOHJA	25S34	5000
LOHJA	25S38	5000
LUMA	LF36D05	C43C (DAEWOO)
LUMA	LF36D06	C43M (DAEWOO)
LUMA	LF36D27	C600 (DAEWOO)
LUMA	LF36D35	C901 (DAEWOO)
LUMA	LF36D51	CP325
LUMA	LF36D51	CP330
LUMA	LF36D73	CP375

Brand	model	chassis
LUMA	LF36K92	P54S
LUMA	LF36V80	11AK20
LUMA	LF36V81	11AK20
LUMA	LF36V81 G2	11AK20
LUMA	LF36V81E	11AK20
LUMA	LF37V81G2	11AK36
LUMA	LF51D08	C43 (DAEWOO)
LUMA	LF51D52	CP330
LUMA	LF51D74	CP375
LUMA	LF51V81	11AK19
LUMA	LF51V82	11AK19
LUMA	LF51V82E	11AK19E
LUMA	LF51V82G2	11AK19P
LUMA	LF52V81G2	11AK30
LUMA	LF53M89	BS950
LUMA	LF54D21	C520
LUMA	LF54D53	CP330
LUMA	LF54D72	CP380
LUMA	LF54V90	11AK19
LUMA	LF54V90G2	11AK19P
LUMA	LF54V90P	11AK19P
LUMA	LF54V91E	11AK19E
LUMA	LF55V90G2	11AK30
LUMA	LF56M56	BS665
LUMA	LF63M54	BS990
LUMA	LF67M58	BS665
LUMA	LF67M59	BS665
LUMA	LF67M70	BS800.1
LUMA	LF71M01	BS950.2
LUMA	LF71M26	BS990
LUMA	LF71M26	BS990
LUMA	LF71M50	PC200 (SELECO)
LUMA	LF71M60	PC170 (SELECO)
LUMA	LF71V91	11AK19
LUMA	LF71V91E	11AK19E

Brand	model	chassis
LUMA	LF71V91G2	11AK19P
LUMA	LF72V91	11AK37
LUMA	LF83S79	TV4.2 (SCHNEIDER)
LUMA	LFW28NTG2	11AK19P
LUMA	LFW32 NTG2	11AK19P
LUMA	LV51D29	DVT9254D (DAEWOO)
LUMA	LV51D70	CP340
Lumatron	DVD14T4	11AK46
LUXMAN	LV2980N	M13PF
LUXMAN	LV3480N	M13PF
LUXOR	180333127	MONO PLUS
LUXOR	18036541	L
LUXOR	1805514-19	EUROMONO2
LUXOR	1805522-25	EUROMONO2
LUXOR	1805526	EUROSTEREO2B-F
LUXOR	1805564	L2
LUXOR	1805569	L2
LUXOR	1805597-16	CORE2
LUXOR	1805597-19	CORE2
LUXOR	1805597-26	CORE2
LUXOR	1806314-25	EUROMONO2
LUXOR	1806326-25	EUROSTEREO2B-F
LUXOR	1806326-29	EUROSTEREO2B-F
LUXOR	1806364	L2
LUXOR	1806369	L2
LUXOR	1806379	L2
LUXOR	1806390	L2
LUXOR	180639912	L2
LUXOR	180639916	L2
LUXOR	180639919	L2
LUXOR	180639926	L2
LUXOR	180639929	L2
LUXOR	1807014-25	EUROMONO2
LUXOR	1807026-25	EUROSTEREO2B-F
LUXOR	1807026-29	EUROSTEREO2B-F

Brand	model	chassis
LUXOR	1807064	L2
LUXOR	1807069	L2
LUXOR	1807079	L2
LUXOR	1807090	L2
LUXOR	180709912	L2
LUXOR	180709916	L2
LUXOR	180709919	L2
LUXOR	180709926	L2
LUXOR	180709929	L2
LUXOR	1807138	EURO-DIGI 16/9
LUXOR	1808238	EURO-DIGI 16/9
LUXOR	1808239	EURO-DIGI 16/9
LUXOR	185372415	MONO PLUS
LUXOR	1855525-65	EUROSTEREO2
LUXOR	1856317-35	EUROSTEREO2
LUXOR	1856317-65	EUROSTEREO2
LUXOR	1856325-65	EUROSTEREO2
LUXOR	1857017-35	EUROSTEREO2
LUXOR	1857017-65	EUROSTEREO2
LUXOR	1857025-65	EUROSTEREO2
LUXOR	28FNZ--7072STX	PCB2550 VERSION A
LUXOR	28FNZ--7072STX	PCB2550 VERSION C (PT92?)
LUXOR	28FZ2	PCB2550 VERSION A
LUXOR	3392TX	MONO PLUS2
LUXOR	3654	L
LUXOR	3780EW	11AK36
LUXOR	3794TX	MONO F
LUXOR	5028	5000
LUXOR	5192TX	MONO PLUS2
LUXOR	5194TX	MONO F
LUXOR	5525	N
LUXOR	5531	MONO PLUS
LUXOR	5564	L2
LUXOR	5592TX	MONO PLUS2
LUXOR	6345	FS

Brand	model	chassis
LUXOR	6346	FS
LUXOR	6354	STEREO PLUS
LUXOR	6364	L2
LUXOR	6392	COMPACT D2
LUXOR	7006	N
LUXOR	7018	EURO-DIGI
LUXOR	7018	EURO-DIGI (E)
LUXOR	7033	5100
LUXOR	7045	FS
LUXOR	7046	FS
LUXOR	7054	STEREO PLUS
LUXOR	7058	STEREO PLUS
LUXOR	7062-17	MONO PLUS ?
LUXOR	7064	L2
LUXOR	7092	COMPACT D2
LUXOR	7128	EURO-DIGI
LUXOR	72G3SF++	G3_GW Safety++
LUXOR	72G3TF++	G3_GW Safety++
LUXOR	72SF20 100Hz	MC2 (Multi Concept 2)
LUXOR	72TF100 100Hz	MC2 (Multi Concept 2)
LUXOR	7438	FS
LUXOR	8228	EURO-DIGI
LUXOR	8289 100Hz	MZ
LUXOR	8289 100Hz 3D/VGA/PiP	MZ
LUXOR	8289 100Hz VGA/PiP	MZ
LUXOR	82G3SF++	G3_GW Safety++
LUXOR	82G3TF++	G3_GW Safety++
LUXOR	82SF20 100Hz	MC2 (Multi Concept 2)
LUXOR	82TF100 100Hz	MC2 (Multi Concept 2)
LUXOR	82TF200 100Hz	MC2 (Multi Concept 2)
LUXOR	8405	EURO-DIGI (E)
LUXOR	9128	EURO-DIGI
LUXOR	SN71Z4	STEREO PLUS2 (inaczej: SP2)
MACTECH		K3922
MACTECH		K3922

Brand	model	chassis
MACTECH		K3922
MAGNASONIK	MTV2035	F4ah
Magnavox	13X605	GR5a
MAGNAVOX	20MG2049	GR1AX
MAGNAVOX	27MS343S	L01.1 ?
MAGNAVOX	55P8288	PTV910 ?
MAGNAVOX	M1432	L6.1
Magnavox	RR1337W101	13S401-00AA ?
MAGNUM	7090VT	14.2 ?
MAGNUM	TV3701	PT92 ?
MAGNUM	TV5510	PT11
MAGNUM	TV5520VT	PT2
MAGNUM	TV5545VT	12.1 (BEKO)
MAGNUM	TV5551RF	12.3 (BEKO)
MAGNUM	TV5555	CTS-AA
MAGNUM	TV5575	PT92
MAGNUM	TV5595	16.1 (BEKO)
MAGNUM	TV7050VT	(97TA027C)
MAGNUM	TV7050VT	SM2 ? (czy? PT2)
MAGNUM	TV7052SF	PT200
MAGNUM	TV7055VT	(97TA027G)
MAGNUM	TV7065	7S2190
MAGNUM	TV7065VT	14.1 (7SZ.190-12)
MAGNUM	TV7075VT	14.1 (BEKO)
MAGNUM	TV85100	DTV100
MARK	STB1401	12.1 (BEKO)
MARK	TBT201TXT	11.1 (6GJ.812)
MARK	TVD3200NT	11AK19PRO ?
MARQUANT	MCT1494P2	GK2C ?
MARSHAL	FA2170	C41
MASCOM	3714	PT92
MASCOM	MC3729	PT92J
MASCOM	MC5514SM2	SM2 (?)
MASCOM	MC5517FST	PT92
MASCOM	MC7123	SM2

Brand	model	chassis
Mastec	30621/HTF62	P1420 ?
MATSUI	1410R	CTN
MATSUI	1410R	CTN-BB (?)
MATSUI	1410T	CTN
MATSUI	1420T	TMA504A
MATSUI	1421T	11AK30 ?
MATSUI	1496	SM1
MATSUI	14T1	CP370
MATSUI	14TR50	F
MATSUI	14V1R	CUC7301 (?)
MATSUI	2010R	CTN
MATSUI	2010T	CTN
MATSUI	2096	SM1
MATSUI	20T1	CP370
MATSUI	20T1	CP370
MATSUI	20TN	D4N ?
MATSUI	2130TX	11AK02
MATSUI	2190	11AK02
MATSUI	21T1	CP370
MATSUI	21T10	BC10E
MATSUI	2530TX	11AK02
MATSUI	2580	11AK02
MATSUI	2590	11AK02
MATSUI	25M1	EB2A
MATSUI	25N03	4400 PROFESSIONAL (PCB: 4410)
MATSUI	28M1	EB2A
MATSUI	28N03	4400 PROFESSIONAL (PCB: 4410)
MATSUI	28N10	11AK37-8
MATSUI	28WN	CUC2059N
MATSUI	28WN05	TMA520A (TMA521A) - ?
MATSUI	28WN05A	TMA520B
MATSUI	32WN03	4400 PROFESSIONAL (PCB: 4410)
MATSUI	T3622RM	C41
MATSUI	T5122RM	C41M ?
MATSUI	T5122TS	C41M

Brand	model	chassis
MATSUI	TVR2095TT	TELRA PL2
MAXIM	RC4221PST	RC4121A
MAXIM	RC4421PST	RC4121A
MAXX	1851	17.3 (BEKO) - ?
MEDION	MD20-200A	PT90P
MEDION	MD20003	22.1 (BEKO)
MEDION	MD20003S	22.1 (ZA1.190-14) (BEKO)
MEDION	MD20015	PT90C
MEDION	MD20020A	PT92 ?
MEDION	MD20100A	PT90
MEDION	MD20101	PT92 ?
MEDION	MD20207S	E1 (BEKO) (Z50.190-05--E1 14 PH7 P BG TX AV KI NTSC 7 A ON M I ED)
MEDION	MD20207S	E1 ? (BEKO)
MEDION	MD21028	22.1 (BEKO)
MEDION	MD21031A	22.1 (ZA1.190-14) (BEKO)
MEDION	MD21032S	22.1 (ZA1.190-14) (BEKO)
MEDION	MD21072A	PT200 Mira
MEDION	MD2802A	11AK52B6
MEDION	MD3685VT	CODE A
MEDION	MD3701	GT9313
MEDION	MD3720	GT9313 ?
MEDION	MD3728	11AK08
MEDION	MD3729	11AK20
MEDION	MD3735VT	GT9313
MEDION	MD3745VTS	GT9313
MEDION	MD3751VT-B	11AK20S
MEDION	MD3795VT	GT9313
MEDION	MD40232	22.1 (ZA1.190-08) (BEKO)
MEDION	MD40275A	16.1 (ZA4.190-08)
MEDION	MD40275S	16.1 (BEKO)
MEDION	MD40855S	11AK37
MEDION	MD41332A	MC2B
MEDION	MD41537S	11AK36A8 ?
MEDION	MD42155S	PT92 (TC268 94V-0--TC9547CI)
MEDION	MD42207	12.7 (G70.190-13)

Brand	model	chassis
MEDION	MD42207A	12.7 (G70.190-13)
MEDION	MD42211	22.1 (ZA9-190-03)
MEDION	MD42211S	22.1 (BEKO)
MEDION	MD42287A	12.4 ?
MEDION	MD5102VTS	GT9420
MEDION	MD5122	11AK19
MEDION	MD5135VT	11AK41 ?
MEDION	MD5510VT	GT9313
MEDION	MD5515VTS-S	11AK30A4
MEDION	MD5520VT	GT9313
MEDION	MD5530VT	GT9313
MEDION	MD5538VT	11AK19
MEDION	MD5548VTS	11AK19E3
MEDION	MD6207SF	11AK28-10
MEDION	MD7042VTS	11AK19
MEDION	MD7048VTS	11AK19-5
MEDION	MD7061	11AK37-8
MEDION	MD7066VTS-A	11AK52B4
MEDION	MD7066VTS-S	11AK52
MEDION	MD7066VTSA	11AK52
MEDION	MD7068	11AK37
MEDION	MD7077	TV9.1
MEDION	MD7077--TV9.1-70238	TV9.1
MEDION	MD7078	TV17 (100Hz)
MEDION	MD7098	11AK52
MEDION	MD7103	11AK18
MEDION	MD7103VTS	11AK18
MEDION	MD7106VTS-A	11AK41
MEDION	MD7115	TV17.6 (100Hz)
MEDION	MD7115VTS	TV17.6 (100Hz)
MEDION	MD7115VTS	TV17XL.6 (100Hz)
MEDION	MD8201	TV17...
MEDION	MD8207SF	11AK28-10
MElectronic	3024M1GA550	3000 (Finlux) ?
MElectronic	MTS2802SY135	PCB2500C

Brand	model	chassis
MELELECTRONIC	MTS21BTS	STEREO PLUS
METRO	CTV7028	TV4
METRO	DMQ1417	C600
METRO	DMQ2169	CP315
METRO	EC70303	SCC103 (ELBIT)
METRO	FA2620	F6
METRO	MV480-87	F9
METZ		601G1
METZ	55TC34 Borneo Top Vt Stereo	11AK19-5
METZ	6042	687G2
METZ	6047	687G2
METZ	6057	687G2
METZ	6062	687G2
METZ	6067	687G2
METZ	6240	692G
METZ	6241	692G
METZ	6242	692G
METZ	6243	692G
METZ	6244	692G
METZ	6245	692G
METZ	6246	692G
METZ	6247	692G
METZ	6248	692G
METZ	6252	692G
METZ	6257	692G
METZ	6260	692G
METZ	6262	692G
METZ	6267	692G
METZ	630040	695G
METZ	630042	695G
METZ	630052	695G
METZ	630057	695G
METZ	630062	695G
METZ	6343	692G
METZ	6344	692G

Brand	model	chassis
METZ	6345	692G
METZ	6347	692G
METZ	6348	692G
METZ	6357	692G
METZ	6367	692G
METZ	6393	693G
METZ	63AT42	695G
METZ	63TB72	696G
METZ	6457 Sumatra	691G ?
METZ	700044	695G
METZ	70100VT	689G
METZ	70TB44	695G
METZ	70TB73	696G
METZ	70TF65	699G
METZ	720046	695G
METZ	720047	695G
METZ	720048	695G
METZ	720057	695G
METZ	720067	695G
METZ	72D66	696G
METZ	72TA57	695G
METZ	72TA67	695G
METZ	72TB47	695G
METZ	72TC58	696G
METZ	72TC68	696G
METZ	72TC76	696G
METZ	72TC83	696G
METZ	72TC84	696G
METZ	72TC85	696G
METZ	72TC87 Kreta-SF100 Hz	696G
METZ	72TD85	696G1
METZ	72TD87	696G1
METZ	72TF81--Astral-MF 100Hz	699G1
METZ	7395 MALLORCA STEREO SC	681G ?
METZ	7470	685G

Brand	model	chassis
METZ	7472	685G
METZ	7536	685G
METZ	7560	685G
METZ	7566	685G
METZ	7568	685G
METZ	7570	685G
METZ	7572	685G
METZ	7579	685G
METZ	7582	685G
METZ	7584	685G
METZ	7590	685G
METZ	7591	685G
METZ	7592	685G
METZ	7596	685G
METZ	7598	685G
METZ	7638	685G
METZ	7639	685G
METZ	7654	685G
METZ	7655	685G
METZ	7658	685G
METZ	7659	685G
METZ	7660	685G
METZ	7661	685G
METZ	7664	685G
METZ	7665	685G
METZ	7666	685G
METZ	7668	685G
METZ	7678	685G
METZ	7690	685G
METZ	7691	685G
METZ	7692	685G
METZ	7693	685G
METZ	7694	685G
METZ	7698	685G
METZ	7741	687G

Brand	model	chassis
METZ	7742	687G
METZ	7743	687G
METZ	7744	687G
METZ	7746	687G
METZ	7747	687G
METZ	7749	687G
METZ	7752	687G
METZ	7753	687G
METZ	7756	687G
METZ	7757	687G
METZ	7762	687G
METZ	7763	687G
METZ	7766	687G
METZ	7767	687G
METZ	7852	687G
METZ	7853	687G
METZ	7856	687G
METZ	7857	687G
METZ	7862	687G
METZ	7863	687G
METZ	7866	687G
METZ	7867	687G
METZ	7884	687G
METZ	7945	687G
METZ	7949	687G
METZ	7953	687G
METZ	7956	687G
METZ	7957	687G
METZ	7963	687G
METZ	7966	687G
METZ	7967	687G
METZ	7984	687G
METZ	7994	689G
METZ	7999	689G
METZ	82TD95	696G

Brand	model	chassis
METZ	82TF95	699G
METZ	84100VT	689G
METZ	84TC88	696G
METZ	84TD88V	696G ?
METZ	CARAT SF100HT	696G1
METZ	Florida 45	CUC5360
METZ	Florida FST793	CUC4400
METZ	Linea-SF100MT	696G
METZ	MALLORCA (czy? MALORCA) F100	693G
METZ	Palma 55/110	CUC5360
METZ	Palma VT7932	CUC4510
METZ	SAMOA B70VT STEREO	692G
MICROMAX	MM5548	11AK19
MICROMAXX		(40MN28Q10L1T)
Micromaxx	MM3732VT	PC230.1 ?
MICROMAXX	MM42388	TV4KS
Micromaxx	MM7103VTS 100Hz	11AK18 ?
MINERVA	14T1	CP370
MINERVA	20T1	CP370
MINERVA	2168	PC04A (111F30A7)
MINERVA	21T1	CP370
MINERVA	70100M/TXT	C136M
MINERVA	M4041 CTI	CUC2401
MINERVA	M6375CTI	CUC3600
MINERVA	MT3711(H)	G1000
MINERVA	MT5112	G1000 ?
MINERVA	P3741	CUC2401
MINERVA	P3743	CUC3400
MINERVA	P3748	CUC6300
MINERVA	P4045/1	CUC4400
MINERVA	P4241	CUC2401
MINERVA	P4545/1	CUC4400
MINERVA	P4548 TEXT	CUC6300
MINERVA	T5140/1	CUC3400
MINERVA	T5542 CTI	CUC3400

Brand	model	chassis
MINERVA	T6341 CTI	CUC2410
MINERVA	T6346 TEXT	CUC5310
Minineck		CS1076
MITSAI	1401	PTXM01
MITSAI	7003	PT92 v.C (99TA052D)
MITSAI	7003--PROSONIC2000	PT92
MITSAI	7003FT	PT92
MITSAI	Aura 28TXT	PT90+
Mitsai	Basic 37cm	PT92J
MITSAI	TECHNO 51CM	PT92-90
MITSAI	Techno37	PT92
MITSAI	Techno51	PT92
MITSAI	Techno55	PT92
MITSAI	TECHNO70	PT92
MITSAI	TM7002	SM2 ?
MITSAI	TM7003	PT92
MITSUBISHI	25AV1B	EE3
MITSUBISHI	28AV1B	EE3
MITSUBISHI	C21T7BA	EE5 ?
MITSUBISHI	C28D7B	EE6
MITSUBISHI	CT14M1EPM	EURO3 ?
MITSUBISHI	CT2125EET	EURO10
MITSUBISHI	CT2131EST	EURO4
MITSUBISHI	CT2132	EURO4
MITSUBISHI	CT2141	EURO4
MITSUBISHI	CT2142TX	EURO4
MITSUBISHI	CT2144TX	EURO4
MITSUBISHI	CT2154	EURO4
MITSUBISHI	CT21A2EST	EURO12
MITSUBISHI	CT21A2EST(Y)	EURO12
MITSUBISHI	CT21A5LST	E14SF (EURO14SF)
MITSUBISHI	CT21A5STX	E14SF (EURO14SF)
MITSUBISHI	CT21AV1B	EE3
MITSUBISHI	CT21AV1BS	EE3
MITSUBISHI	CT21M1FM	EURO10

Brand	model	chassis
mitsubishi	CT21M2ETM	EURO10
mitsubishi	CT21M3GT	EE1
mitsubishi	CT21M5BT	EE4
mitsubishi	CT21M5G	EE4
mitsubishi	CT2525LTX	EURO10
mitsubishi	CT2528STX	DIGITAL24
mitsubishi	CT2529EST	C9000
mitsubishi	CT2531EST	EURO4
mitsubishi	CT2532	EURO4
mitsubishi	CT2534TX	EURO4
mitsubishi	CT25A2EST	EURO12
mitsubishi	CT25A2EST(Y)	EURO12
mitsubishi	CT25A3STX	EURO12 ?
mitsubishi	CT25A4EST	EURO12 (?)
mitsubishi	CT25A4STX	EURO12
mitsubishi	CT25A5STX	E14SF (EURO14SF)
mitsubishi	CT25A5STX	EURO14SF ?
mitsubishi	CT25AV1BD	EE3
mitsubishi	CT25AV1BDS	EE3
mitsubishi	CT25AV1BS	EE3 ?
mitsubishi	CT25AV1LD	EE3
mitsubishi	CT25B2EST	EURO11
mitsubishi	CT25B2LST	B3
mitsubishi	CT25B2STX	B3
mitsubishi	CT25M2TX	EURO14
mitsubishi	CT25M3ETM	EURO4 ?
mitsubishi	CT25M3GT	EE1
mitsubishi	CT25M3TX	EURO14
mitsubishi	CT25M5BT	EE4
mitsubishi	CT25M5GT	EE4
mitsubishi	CT2839ETX	C9000 ?
mitsubishi	CT28AV1BD	EE3
mitsubishi	CT28AV1BDS	EE3
mitsubishi	CT28AV1DS	EE3
mitsubishi	CT28AV1LD	EE3

Brand	model	chassis
mitsubishi	CT2963EST	EURO8
mitsubishi	CT2964	EURO4
mitsubishi	CT2965STX	EURO8F
mitsubishi	CT29A4STX	EURO12 ?
mitsubishi	CT29AS1EST	E16 (ELBE)
mitsubishi	CT29AT5M	ATM (?)
Mitsubishi	CT29AX1	A1
mitsubishi	CT29B2EDT	EURO11
mitsubishi	CT29B2EST	EURO11
mitsubishi	CT29B2LST(3/4)	B3
mitsubishi	CT29B2STX	B3
mitsubishi	CT29B3EST	EURO11 ? (B3 ?)
mitsubishi	CT29B4EST	B4 ?
mitsubishi	CT32BW1B	W1
mitsubishi	CT32CW1CD	EW1
Mitsubishi	CT33AC2SL	AC2
mitsubishi	CT37C1EST	E9 ?
mitsubishi	CT37C2STX	E9
mitsubishi	TS4545	VZ3
mitsubishi	TS5045	VZ3
mitsubishi	TS5545	VZ3
mitsubishi	VS4543	VZ3
mitsubishi	VS4544	VZ3
mitsubishi	VS4551	VZ2
mitsubishi	VS4551A	VZ2
mitsubishi	VS4551C	VZ2
mitsubishi	VS4552	VZ2
mitsubishi	VS4552A	VZ2
mitsubishi	VS45605	VZ7
mitsubishi	VS45609	VZ9
mitsubishi	VS50111	V20A
mitsubishi	VS5043	VZ3
mitsubishi	VS5044	VZ3
mitsubishi	VS5047	VZ3
mitsubishi	VS5051	VZ2

Brand	model	chassis
mitsubishi	VS5051C	VZ2
mitsubishi	VS5052	VZ2
mitsubishi	VS50605	VZ7
mitsubishi	VS50609	VZ9
mitsubishi	VS50705	VZ7+
mitsubishi	VS50805	V16
mitsubishi	VS55609	VZ9
mitsubishi	VS55705	VZ7+
mitsubishi	VS60111	V20A
mitsubishi	VS6047	VZ3
mitsubishi	VS6051	VZ2
mitsubishi	VS6051C	VZ2
mitsubishi	VS60603	VZ5
mitsubishi	VS60609	VZ9
mitsubishi	VS60705	VZ7+
mitsubishi	VS60719	VZ9+
mitsubishi	VS60805	V16
mitsubishi	VS70705	VZ7+
mitsubishi	VS70709	VZ9+
mitsubishi	WS48311	V20C
mitsubishi	WS55311	V20C
mitsubishi	WS55411	V20C
mitsubishi	WS55805	V16
mitsubishi	WS55905	V16
mitsubishi	WS65311	V20C
mitsubishi	WS65411	V20C
mitsubishi	WS65413	V22
mitsubishi	WS65905	V16
mitsubishi	WS73411	V20C
mitsubishi	WS73905	V16
mitsubishi	WT42313	K20
mitsubishi	WT42413	K20
mitsubishi	WT46805	V16
MIVAR	14P1	11AK20S ?
MIVAR	14P2	11AK20S ?

Brand	model	chassis
MIVAR	20M1	M1
MIVAR	20P1	CS1080 ?
MORGANS	9828ST	SM1 Stereo
Multitec	2000S DALLAS	PT90A
Multitec	2002 SILVER	PT92-90
MultiTEC	BETA 2700	PT92 (?)
MULTITEC	CROMA 2800	11AK19-8A
MULTITEC	Croma 8200	PT100 (100Hz)
MULTITEC	CTV2100	11AK19-8A
MULTITEC	CTV2800	11AK19-8A
MULTITEC	MIRA 71-4903	PT90A-110
MULTITEC	Nova1400	(99TA017C)
MULTITEC	NOVA1400S	11AK19-8A ? - NIE !
MULTITECH	DMQ1417	C600
MULTITECH	DTV2049ST	C520
MULTITECH	KRB1570	K3910W
MULTITECH	KT8227	5701-B2077A-53
MULTITECH	KT8228	5701-B2077A-53
MULTITECH	KT8250	C41
MULTITECH	KT8254	K3922
MULTITECH	KT8351	K3922
NARITA	DVTV2	PT90C
NEC	CT1451	MM2
NEC	CT1901A	NEC19D
NEC	CT2051	MM2
NEC	CT2501A	NEC19D
NEC	FP68T30	CM916F
NEC	FS2120(T)	MM2
NEC	FS2181	MM2
NEC	FS2181SKB	(PWC4034A)
NEC	FS21NL(T)	MM2
NEC	FS8002	CM920F
NEC	PF32W502	CM921F
NEI	1451	INDIANA100
NEI	1551	INDIANA100

Brand	model	chassis
NEI	2031	INDIANA100
NEI	2131TX	INDIANA100
NEI	2151TX	11AK30A4
NEI	2152TX	INDIANA200 ?
NEI	2164TXS	10.3
NEI	E14D4R	E5
NEI	E14D8R	E5
NEI	E15D4R	E5
NEI	E2044R	E5
NEI	E20A4R	E5
NEI	E20A8X	E5
NEI	E20C8R	E5
NEI	E20CHR	E5
NEI	E20D44	E5
NEI	E20D8R	E5
NEI	E20S4X	E5
NEI	E20S8X	E5
NEI	E2144R	E5
NEI	E21A4R	E5
NEI	E21A8X	E5
NEI	E21C4X	E5
NEI	E21D4R	E5
NEI	E21D8X	E5
NEI	E21T4X	E5
NEI	E21T8X	E5
NEI	E25F4R	E5
NEI	E25G4X	E5
NEO	TV1426	TV2KF (czy? TV3K)
NEO	TV2132TX	SS
NESCO	CTV20P	PW1644
NESCO	TV51P	P2
Neufunk	2800	(97TA021C)
NEUFUNK	34BBN	4400 PROFESSIONAL (PCB: 4410)
NEUFUNK	34BNA FUTURA 9350KV063	4400 PROFESSIONAL (PCB: 4410)
Neufunk	RFL72BE	14.2 (U99.190-04)

Brand	model	chassis
NEUFUNK	TB16 70 01	14.1 (7SZ.190-17)
NEUFUNK	TVC7198	F16 (Formenti)
Newell	TV70 Vega	SM2 (99TA013B)
NEXUS	28800NX2850SE	(40F-STT28C-V5B)
NOBLEX	20TC620	DY400-421
NOBLEX	21TC617	DY400-421
NOBLEX	29TC642	PTDM07 ?
NOBLEX	29TC699N06PX	P66 (Samsung)
NOKIA	2130HS	EUROMONO
NOKIA	2130HS VT	EUROMONO2 ?
NOKIA	271A2	MONO PLUS
NOKIA	3487E	DIGI3
NOKIA	3570VT	7161VT DIGIVISION
NOKIA	3570VT	COMPACT D-E
NOKIA	3578 HIFI	Digital B 110 FST
NOKIA	3598 HIFI	Digital B 110 FST
NOKIA	3721	MONO PLUS2
NOKIA	3721T EURO	MONO PLUS2
NOKIA	3722	Core Kit MN NR 220V AC
NOKIA	3755VT	MONO PLUS90
NOKIA	3866	COMPACT 80 110°
NOKIA	3878 HIFI	Digital B 110 FST
NOKIA	3988 HIFI	Digital B 110 FST
NOKIA	4525	MONO PLUS (5864 6. ..)
NOKIA	4532	EUROMONO2
NOKIA	5110VT EE	CORE2 90°
NOKIA	5121	MONO PLUS2
NOKIA	5121 ST271A2	MONO PLUS2
NOKIA	5121T	MONO PLUS2
NOKIA	5121T EURO	MONO PLUS2
NOKIA	5125	MONO PLUS (5864 6. ..)
NOKIA	5155VT	STEREO
NOKIA	5199VT	MONO PLUS 90°
NOKIA	5511	L2
NOKIA	5520OS	CORE 110° SQ

Brand	model	chassis
NOKIA	5521	MONO PLUS2
NOKIA	5521T	MONO PLUS2
NOKIA	5521T EURO	MONO PLUS2
NOKIA	5523OS	Compact80 DST (?) (EB3214)
NOKIA	5525	MONO PLUS (5864 6. ...)
NOKIA	5530PS	CORE2 90°
NOKIA	5530VT	CORE2 90°
Nokia	5551VT	COMPACT D-E 90
NOKIA	5575	A34A=STEREO PLUS
NOKIA	5577 NICAM SPORTS	STEREO PLUS
NOKIA	5861	CORE2 90°
NOKIA	6197	FW 16:9
NOKIA	6311	L2
NOKIA	6320PS	CORE2
NOKIA	6332EE IL--5432 01 80	EUROMONO2
NOKIA	6351T,TN	STEREO PLUS2 (inaczej: SP2)
NOKIA	6355	A34A=STEREO PLUS
NOKIA	6355VT	STEREO PLUS
NOKIA	6357VT/NICAM/UK SFN/VTEE/F VT	STEREO PLUS
NOKIA	6361S-VT	2B-S ?
NOKIA	6363VT	EUROSTEREO1
NOKIA	6364VTEE	EUROSTEREO2B-F
NOKIA	6370	B-E2
NOKIA	6371	B-E2
NOKIA	6376VT EE	STEREO PLUS (?)
NOKIA	6377F NICAM	STEREO PLUS
NOKIA	6383 TOP	EUROSTEREO1
NOKIA	6384	EURO-DIGI 4/3
NOKIA	6386	FS
NOKIA	7131	MONO PLUS2
NOKIA	7138	EURO-DIGI 16/9
NOKIA	7140	CORE2 110°
NOKIA	7143	Euromono
NOKIA	7151T,TN	STEREO PLUS2 (inaczej: SP2)
NOKIA	7151TN	STEREO PLUS2 (inaczej: SP2)

Brand	model	chassis
NOKIA	7152TN	STEREO PLUS2 SN/SW
NOKIA	7155	A34A=STEREO PLUS
NOKIA	7155VT	STEREO PLUS
NOKIA	7156	MONO PLUS110
NOKIA	7157VT/NICAM/UK SFN/VT FF/EE VT	STEREO PLUS
NOKIA	7160	COMPACT D2
NOKIA	7161S-VT	2B-S (ITT)
NOKIA	7161VT DIGIVISION	COMPACT D-E 110° FST Nicam
NOKIA	7161VT DIGIVISION--5432 68 12	COMPACT D-E 110° FST
NOKIA	7164SVT	2B-S ? (ITT)
NOKIA	7165	A34A=STEREO PLUS
NOKIA	7171	B-E2
NOKIA	7174 TOP	EUROSTEREO2B-F ?
NOKIA	7175	EUROSTEREO FEATURE PLUS
NOKIA	7175 TOP	EUROSTEREO2B-F/FP 110° NT-X 12 /JEB 773---FS 2B F/FP 110 NT-X12
NOKIA	7175--4228T	EUROSTEREO FEATURE PLUS
NOKIA	7181	B-E2
NOKIA	7186	FS
NOKIA	7187	FS
NOKIA	7192	EURO-DIGI 4/3
NOKIA	7193	EURO-DIGI 4/3
NOKIA	7198	FX (100Hz)
NOKIA	7281T Multi	STEREO PLUS2 SN/SW
NOKIA	7282	FW 16:9
NOKIA	7291T Multi 100Hz	MZ
NOKIA	7293	EURO-DIGI 16/9
NOKIA	7294	EURO-DIGI 16/9
NOKIA	7295	FP (100Hz)
NOKIA	7296	FP (100Hz)
NOKIA	7297	MZ
NOKIA	72F7	FP (100Hz)
NOKIA	72SF20 100Hz	TZ
NOKIA	72TF100 100Hz	TZ
NOKIA	7451 SN74F3	STEREO PLUS2 (inaczej: SP2)
NOKIA	7451NT	STEREO PLUS2 (inaczej: SP2)

Brand	model	chassis
NOKIA	7487	FS ?
NOKIA	7496	FS
NOKIA	74F3TN	MX ?
NOKIA	8238	EURO-DIGI 16/9
NOKIA	8239	EURO-DIGI 16/9
NOKIA	8281	B-E2
NOKIA	8291T Multi 100Hz	MZ
NOKIA	8291T Multi 100Hz 3D/VGA/PiP	MZ
NOKIA	8293	EURO-DIGI 16/9
NOKIA	8294	EURO-DIGI 16/9
NOKIA	8296	FP (100Hz)
NOKIA	8297DPL	FP ?
NOKIA	82SF20 100Hz	TZ
NOKIA	82TF100 100Hz	TZ
NOKIA	82TF200 100Hz	TZ
NOKIA	8592	EURO DIGI
NOKIA	8751T	STEREO PLUS2 (inaczej: SP2)
NOKIA	CTV-XM55T	11AK19E3
NOKIA	FP72F7	MZ
NOKIA	FP82B2	FP (100Hz)
NOKIA	FP82B2RNP3C	FP (100Hz)
NOKIA	FP82F7	FP
NOKIA	FS63	FS
NOKIA	FS74F1	FS 100Hz
NOKIA	FS74F1EN6AL	FS 100Hz
NOKIA	FS74F2	FS ?
NOKIA	FT3287	E6
NOKIA	FT71403	FX74U1GUGHZ (100Hz)
NOKIA	FX71E1	FX
NOKIA	FX71L1	FX
NOKIA	FX74F1	FX (100Hz)
NOKIA	FX74F2RN73T	FX
NOKIA	FX74F2RN74T	FX
NOKIA	FZ82F7	FX
NOKIA	M55100	Euromono 90°

Brand	model	chassis
NOKIA	M5515	M5
NOKIA	MP251A2-5121	MONO PLUS2
NOKIA	MX63L3EN	MX
NOKIA	MX71L3	MX 100Hz
NOKIA	MX74F3	MX
NOKIA	MZ72F7	TZ
NOKIA	MZ82F7	MZ 100Hz
NOKIA	Prodac 3351HSI--NOKIA2010HS PS	CORE2 90° NN Hotel P/S
NOKIA	SN71L1	STEREO PLUS2 (inaczej: SP2)
NOKIA	SN74F3	STEREO PLUS2 (inaczej: SP2)
NOKIA	SN76F3	MX/MZ
NOKIA	SN87A2	STEREO PLUS2 (inaczej: SP2)
NOKIA	SP63D1	STEREO PLUS
NOKIA	ST255A2	MONO PLUS2
NOKIA	ST263A2	MONO PLUS2 ?
NOKIA	ST37H1	Stereo ?
NOKIA	ST63A2	A34A?=STEREO PLUS
NOKIA	TV7198	FX
NOKIA	TV8291T	EURO-DIGI 16/9
NOKIA	X5510	M4
NORDMENDE	1434PI	F10
NORDMENDE	1444	F10
NORDMENDE	2.572A	F9
NORDMENDE	2112	F10
NORDMENDE	250 GALAXY	TX80
NORDMENDE	2513A	F8
NORDMENDE	25MS GALAXY	TX90
NORDMENDE	25PRO GALAXY	TX90
NORDMENDE	3.513 SPECTRA	F8
NORDMENDE	3.515	F8
NORDMENDE	3031	F5TT
NORDMENDE	3035	F5TT
NORDMENDE	3135	F5TT
NORDMENDE	3434	F10
NORDMENDE	3601 GALAXY	TX80

Brand	model	chassis
NORDMENDE	3602	F8
NORDMENDE	3604	F14
NORDMENDE	36060 SPECTRA	F14
NORDMENDE	36A GALAXY	IKC2
NORDMENDE	36AF GALAXY	TX90
NORDMENDE	36DP GALAXY	TX80
NORDMENDE	36KC GALAXY	TX91
NORDMENDE	36KV FUTURA	TX91
NORDMENDE	36KWH GALAXY	TX91
NORDMENDE	36KX GALAXY	TX805
NORDMENDE	36LP GALAXY	TX90
NORDMENDE	36P GALAXY	TX80
NORDMENDE	36VP GALAXY	TX90
NORDMENDE	36X GALAXY	TX805
NORDMENDE	4031C GALAXY	TX90
NORDMENDE	40C GALAXY	TX90
NORDMENDE	40IMC	IKC2
NORDMENDE	40IMC VT	IKC2
NORDMENDE	40KV GALAXY	TX91
NORDMENDE	4230	FV1
NORDMENDE	42DP GALAXY	TX80
NORDMENDE	45KV GALAXY	TX91
NORDMENDE	45VP GALAXY	ICC6
NORDMENDE	5038	F15/16 (czy? F11b)
NORDMENDE	51PS GALAXY	ICC6
NORDMENDE	51X GALAXY	TX91
NORDMENDE	5205	F15/16
NORDMENDE	5208	F15-01 (albo F16-01)
NORDMENDE	5245	F15-01 (albo F16-01)
NORDMENDE	5255	F15-01 (albo F16-01)
NORDMENDE	5335	F15-01 (albo F16-01)
NORDMENDE	5432	F11
NORDMENDE	55 FUTURA	ICC5 IMC
NORDMENDE	55 PIP FUTURA	ICC5 IMC
NORDMENDE	55DV GALAXY	TX91

Brand	model	chassis
NORDMENDE	55IMC FUTURA	ICC5 IMC
NORDMENDE	55KV FUTURA	TX91
NORDMENDE	55KV GALAXY	TX91
NORDMENDE	55L FUTURA	ICC8
NORDMENDE	55LV GALAXY	ICC6
NORDMENDE	55V GALAXY	ICC8
NORDMENDE	55VS FUTURA	ICC9
NORDMENDE	5637	F11(91)B
NORDMENDE	6035	F15-01 (albo F16-01)
NORDMENDE	6208IMC SPECTRA	F19
NORDMENDE	63 FUTURA	ICC5 CMOS
NORDMENDE	63 PIP FUTURA	ICC5 IMC
NORDMENDE	63 PIP FUTURASOUND	ICC5 IMC
NORDMENDE	6342 - 992.652J Futurasound	F23+ ICC8 STEREO
NORDMENDE	6342 FUTURASOUND	F23+ ICC8 STEREO
NORDMENDE	6356DH	TX92F ver.2
NORDMENDE	6362 PIP	IDC2.1 !
NORDMENDE	63KD PRESTIGE	ICC11
NORDMENDE	63KD PRESTIGE	ICC11
NORDMENDE	63KH PRESTIGE	ICC10
NORDMENDE	63KH PRESTIGE	ICC10
NORDMENDE	63KH PRESTIGE	ICC10
NORDMENDE	63KH PRESTIGE	ICC10
NORDMENDE	63TD FUTURASOUND	IDC2.1 !
NORDMENDE	63TH SPECTRA	ICC10
NORDMENDE	63V - 992.645A Futura	F23+ ICC8 STEREO
NORDMENDE	63V FUTURA	F23+ ICC8 STEREO
NORDMENDE	63V GALAXY	ICC7
NORDMENDE	63VS GALAXY	ICC6
NORDMENDE	63XVY GALAXY	TX92
NORDMENDE	6559	F15
NORDMENDE	68KPL PRESTIGE	IDC2
NORDMENDE	68KPL PRESTIGE	IDC2
NORDMENDE	7000	F15
NORDMENDE	7056DH	TX92F ver.2

Brand	model	chassis
NORDMENDE	70V - 992.666A Futura	F23+ ICC8 STEREO
NORDMENDE	70V FUTURA	F23+ ICC8 STEREO
NORDMENDE	70VS GALAXY	ICC6
NORDMENDE	72 FUTURA	ICC5 CMOS
NORDMENDE	72 PIP FUTURA	ICC5 IMC
NORDMENDE	7242 - 992.673J Futurasound	F23+ ICC8 STEREO
NORDMENDE	7242 FUTURASOUND	F23+ ICC8 STEREO
NORDMENDE	7262 PIP	IDC2.1 !
NORDMENDE	72ADTV FUTURA	ICC5 IMC
NORDMENDE	72ADTV PRESTIGE	ICC5 IMC
NORDMENDE	72ADTV PRESTIGE	ICC5 IMC
NORDMENDE	72DK FUTURASOUND	ICC5 IMC
NORDMENDE	72DS PRESTIGE	F17DS
NORDMENDE	72KD PRESTIGE	ICC11
NORDMENDE	72KD PRESTIGE	ICC11
NORDMENDE	72KH PRESTIGE	ICC10
NORDMENDE	72KH PRESTIGE	ICC10
NORDMENDE	72KPL PRESTIGE	IDC2
NORDMENDE	72KPL PRESTIGE	IDC2
NORDMENDE	72SF FUTURASOUND	IDC2
NORDMENDE	72TD FUTURASOUND	IDC2.1 !
NORDMENDE	778535A	F5TT
NORDMENDE	780536A y B	F8
NORDMENDE	81DS SPACE-SYSTEM	IDC2.2
NORDMENDE	8205	F15-01 (albo F16-01)
NORDMENDE	8208	F15-01 (albo F16-01)
NORDMENDE	84 FUTURASOUND	ICC5 IMC
NORDMENDE	84TD FUTURASOUND	IDC2.1
NORDMENDE	84TS FUTURASOUND	ICC9
NORDMENDE	84VT FUTURA	ICC9-100
NORDMENDE	85 PIP FUTURASOUND	ICC5 IMC
NORDMENDE	85IMC FUTURAVISION	ICC5 IMC
NORDMENDE	94TS FUTURASOUND	ICC9
NORDMENDE	9572D	F5TT
NORDMENDE	982512H	F10

Brand	model	chassis
NORDMENDE	982514/H	F10
NORDMENDE	982515/H	F10
NORDMENDE	COLOR 1400	FVI
NORDMENDE	Color 1534	F10
NORDMENDE	COLOR 3031	F15/F17
NORDMENDE	Color 3205IMC	F20-9 / F20-11
NORDMENDE	Color 3208IMC	F20-9 / F20-11
NORDMENDE	Color 3614	F20-9 / F20-11
NORDMENDE	Color Stereo 6205IMC	F19-11
NORDMENDE	Color Stereo 6205VT	F19-11
NORDMENDE	Color Stereo 6208IMC	F19-11
NORDMENDE	Color Stereo 6208NIC	F19-11
NORDMENDE	Color Stereo 6208VT	F19-11
NORDMENDE	CV55 - 992.610A Spectra	F23+ ICC8 STEREO
NORDMENDE	CV55 SPECTRA	F23+ ICC8 STEREO
NORDMENDE	CV720	ICC7
NORDMENDE	Deluxe Color Sonic 2401	F9
NORDMENDE	Futura 55C-VT	F18 (?)
NORDMENDE	FUTURA 70V	F23+/ICC8DE !
NORDMENDE	GALAXY 36A	F20-9 / F20-11
NORDMENDE	GALAXY 36IMC	F20-9 / F20-11
NORDMENDE	GALAXY 36M	F20-9 / F20-11
NORDMENDE	Galaxy 36X	TX805
NORDMENDE	GALAXY 40IMC	F20-9 / F20-11
NORDMENDE	GALAXY 40IMC VT	F20-9 / F20-11
NORDMENDE	GALAXY 42IMC	F20-9 / F20-11
NORDMENDE	GALAXY 45	F14
NORDMENDE	GALAXY 4501C	F20-9 (IMC5)
NORDMENDE	GALAXY 4501C-VT	F20-9 (IMC5)
NORDMENDE	GALAXY 45C	F20-9 (IMC5)
NORDMENDE	GALAXY 45IMC	F20-9 / F20-11
NORDMENDE	GALAXY 45IMC VT	F20-9 / F20-11
NORDMENDE	GALAXY 45V	F20-9 (IMC5)
NORDMENDE	GALAXY 51E IMC	F20-9 / F20-11
NORDMENDE	GALAXY 51IMC	F20-9 / F20-11

Brand	model	chassis
NORDMENDE	GALAXY 5501VT	F20-9 (IMC5)
NORDMENDE	GALAXY 55C	F20-9 (IMC5)
NORDMENDE	GALAXY 55IMC	F20-9 / F20-11
NORDMENDE	Galaxy 55X	ICC6 (?)
NORDMENDE	M55 FUTURA	ICC5 NMOS
NORDMENDE	M63 FUTURA	ICC5 NMOS
NORDMENDE	M63BSPS FUTURA	ICC7
NORDMENDE	NDTV3701	11AK46
NORDMENDE	NMF2150	CTR-AA ?
NORDMENDE	NTV28-100T	20.2 (100Hz) (BEKO)
NORDMENDE	NTV32-100T	20.2 (7UZ.190-10) (100Hz)
NORDMENDE	S63BNIC SPECTRA	F23+ ICC8 STEREO
NORDMENDE	S72BNIC SPECTRA	F23+ ICC8 STEREO
NORDMENDE	SC63 - 992.659J Spectra	F23+ ICC8 STEREO
NORDMENDE	SC63 SPECTRA	F23+ ICC8 STEREO
NORDMENDE	SC6341 - 992.659J Spectra	F23+ ICC8 STEREO
NORDMENDE	SC6341 SPECTRA	F23+ ICC8 STEREO
NORDMENDE	SC63NIC SPECTRA	F23+ ICC8 STEREO
NORDMENDE	SC72 - 992.674E Spectra	F23+ ICC8 STEREO
NORDMENDE	SC72 NIC SPECTRA	F23+ ICC8 STEREO
NORDMENDE	SC72 SPECTRA	F23+ ICC8 STEREO
NORDMENDE	SC7241 - 992.674J Spectra	F23+ ICC8 STEREO
NORDMENDE	SC7241 SPECTRA	F23+ ICC8 STEREO
NORDMENDE	SC72TH Spectra	ICC10
NORDMENDE	SL55F	ICC8
NORDMENDE	SL55TS	ICC9
NORDMENDE	SL6361 Spectra	IDC2.1 !
NORDMENDE	SL63IMC SPECTRA	F17IMC
NORDMENDE	SL63TD Spectra	IDC2.1 !
NORDMENDE	SL70D SPACE-SYSTEM	ICC11
NORDMENDE	SL70D SPACESYSTEM	ICC11
NORDMENDE	SL7261 Spectra	IDC2.1 !
NORDMENDE	SL72IMC SPECTRA	F17IMC
NORDMENDE	SL72IMCNIC	ICC5 F17IMC
NORDMENDE	SL72TD Spectra	IDC2.1 !

Brand	model	chassis
NORDMENDE	SL72TDS	IDC2
NORDMENDE	SL72TDS SPECTRA	IDC2
NORDMENDE	Spectra 3604IMC	F20-9 / F20-11
NORDMENDE	Spectra 3606IMC	F20-9 / F20-11
NORDMENDE	Spectra Color 3205IMC	F20-9 / F20-11
NORDMENDE	Spectra SC72SF	ICC9
NORDMENDE	Spectra SK3	F7
NORDMENDE	Spectra SK3 2.541j TP3327	F9
NORDMENDE	Spectra SK3 DeLuxe Colorsonic 2400 tvn 0 572A	F7
NORDMENDE	Spectra SL72AT	F17AD
NORDMENDE	SPECTRA ST 9508 HIFI	F15-01 (albo F16-01)
NORDMENDE	SPECTRA ST. 6300	F15-02
NORDMENDE	SPECTRA ST. 7000	F15-02
NORDMENDE	Spectra Stereo 6205IMC	F19-11
NORDMENDE	Spectra Stereo 6205VT	F19-11
NORDMENDE	Spectra Stereo 6208IMC	F19-11
NORDMENDE	Spectra Stereo C55IMC	F19-11
NORDMENDE	Spectra Stereo C55IMC VT	F19-11
NORDMENDE	Spectra Stereo C63IMC	F19-11
NORDMENDE	Spectra Stereo C72IMC	F19-11
NORDMENDE	Spectra3 TP6047	F7
NORDMENDE	ST63	ICC8
NORDMENDE	ST63 - 992.646F Spectra	F23+ ICC8 STEREO
NORDMENDE	ST6341 - 992.644J Spectra	F23+ ICC8 STEREO
NORDMENDE	ST6341 SPECTRA	F23+ ICC8 STEREO
NORDMENDE	ST63KV	ICC9
NORDMENDE	ST63V - 992.644A/E Spectra	F23+ ICC8 STEREO
NORDMENDE	ST63V SPECTRA	F23+ ICC8 STEREO
NORDMENDE	ST7041 - 992.667J Spectra	F23+ ICC8 STEREO
NORDMENDE	ST7041 SPECTRA	F23+ ICC8 STEREO
NORDMENDE	ST70KH	ICC11
NORDMENDE	ST70KHC	ICC10
NORDMENDE	ST70KV	ICC9
NORDMENDE	ST70V	ICC8
NORDMENDE	ST70V - 992.667A/E Spectra	F23+ ICC8 STEREO

Brand	model	chassis
NORDMENDE	ST70V SPECTRA	F23+ ICC8 STEREO
NORDMENDE	ST70VE	TX92
NORDMENDE	T4633--2.515A	F8
NORDMENDE	TP4332 (Spectra SK3)	F9
NOVATRONIC	CTV2198TX	F16
OCEANIC	1530HS	EUROMONO
OCEANIC	3723	EUROMONO2
OCEANIC	3724	MONO PLUS
OCEANIC	4032	EUROMONO2
OCEANIC	4532	EUROMONO2
OCEANIC	5524	MONO PLUS
OCEANIC	5552	EUROSTEREO2
OCEANIC	5554	STEREO PLUS
Oceanic	5554	STEREO PLUS
OCEANIC	55540	STEREO PLUS
Oceanic	5575	STEREO PLUS
OCEANIC	5575	STEREO PLUS
OCEANIC	5576 NICAM	STEREO PLUS
OCEANIC	6323	EUROMONO2
OCEANIC	6342	EUROMONO2
OCEANIC	6352	EUROSTEREO2
OCEANIC	6353	EUROSTEREO2B
Oceanic	6355	STEREO PLUS
OCEANIC	6355	STEREO PLUS 110°
OCEANIC	63550	STEREO PLUS 110°
OCEANIC	6361	COMPACT D-E
OCEANIC	6363	EUROSTEREO2
OCEANIC	6364	L2
OCEANIC	6372	EUROSTEREO2
OCEANIC	6376 NICAM	STEREO PLUS
OCEANIC	6383	EUROSTEREO1
OCEANIC	6386	FS
OCEANIC	7123	EUROMONO2
OCEANIC	7153VT	EUROSTEREO2B-F
OCEANIC	7155	STEREO PLUS

Brand	model	chassis
Oceanic	7155	STEREO PLUS
OCEANIC	71550	STEREO PLUS
OCEANIC	7161	COMPACT D-E
OCEANIC	7163	EUROSTEREO2
OCEANIC	7164	EUROSTEREO2B-F
OCEANIC	7172	EUROSTEREO2
OCEANIC	7176CLASSIC	STEREO PLUS
OCEANIC	7183	EUROSTEREO2
OCEANIC	7185VT	EUROSTEREO FEATURE PLUS
OCEANIC	7186	FS
OCEANIC	7495	EUROSTEREO FEATURE PLUS
OCEANIC	7496	FS
OKANO	997/070	990
OKANO	999/070	990
OKANO	TV3700	4400 PROFESSIONAL
OKANO	TV3701	SQUAD
OKANO	TV5100	PC91A
OKANO	TV5500VT	C46
OKANO	TV55VT	SCC121
OKANO	TV630	TV8 (Schneider)
OKANO	TV7070VT	990
OKANO	TV70VT	990
OMEGA	3710	K9515BE
OMEGA	3711	K9515BT
OMEGA	5110	CORE2
OMEGA	5511	K9321BF
OMEGA	KV-T3712DK	K3912
OMEGA	KV-T5132DK	K3720
OMEGA	KVT3712DK	K3912
OMEGA	KVT5132DK	K3720
ONIMAX	STV2803T	DTV1
ONWA	TV3710	K8214
OPERA	TV7061RF	22.1 (ZA1.190-17--ZA1.194-19.) (100Hz) (BEKO)
ORAVA	CTV2801	TV3
ORAVA	CTV2802	TV1

Brand	model	chassis
ORION	14DS	TMA504A
ORION	20136SI	EA9 ?
ORION	210AE	3900
ORION	2115SI	TMC568A
ORION	2690 COMBI	CODE B ? (OVD4-C2690)
ORION	2694 COMBI	CODE B ?
ORION	28 TRIADE	4900
ORION	284BE	7000 PROFESSIONAL
ORION	284DN	7300 Professional
ORION	284FC	7300 Professional
ORION	284FE	7000 PROFESSIONAL
ORION	286BE TV715	4300 PROFESSIONAL
ORION	286DE	4300 PROFESSIONAL
ORION	287MF-TV715	(B4101)
ORION	28BDF	4400 PROFESSIONAL (PCB: 4410)
ORION	28DBF	4400 PROFESSIONAL (PCB: 4410)
ORION	28DDA-TV71100	8000 PROFESSIONAL
ORION	28WDA TV28301	8500 PROFESSIONAL (PCB8500)
ORION	28X2AB	2500 (PCB2500)
ORION	28XBA	2500
ORION	28XBC	2500
ORION	28XBG	2500 (PCB2500)
ORION	325DF	7000 PROFESSIONAL ?
ORION	32DDC TV82200	8000 PROFESSIONAL
ORION	32DDZ	TV82300E ?
ORION	32EDA TV8251	2500 (PCB2500)
ORION	32HDA	8500 PROFESSIONAL (PCB8500)
ORION	34 TRIADE	4900
ORION	3400 TRIADE	4300 PROFESSIONAL
ORION	3403 TRIADE	4900
ORION	36 TRIADE	4900
ORION	3609 COMBI	CODE A
ORION	3690 COMBI	CODE B ?
ORION	3694 COMBI	CODE C
ORION	3696 COMBI	CODE B ?

Brand	model	chassis
ORION	370	3900
ORION	371	3900
ORION	3780TX	3900
ORION	3781	3900
ORION	3789F	CODE A ?
ORION	3789F SI	CODE A ?
ORION	3850	4400 PROFESSIONAL (PCB: 4410)
ORION	4155ST	4300 PROFESSIONAL
ORION	5109 COMBI	CODE A
ORION	5170	3900
ORION	5175	3900
ORION	5190 COMBI	Code B
ORION	5196 COMBI	Code B
ORION	520VTP	CODE D
ORION	5521	MONO PLUS2
ORION	553DK	7300 Professional
ORION	612VT	4800
ORION	6325VT	DIGISYSTEM
ORION	683DK	CODE B
ORION	7000LXVT	DIGISYSTEM
ORION	7025VT	DIGISYSTEM
ORION	7028VT	DIGISYSTEM
ORION	7088VT	4AGS
ORION	709 STUDIO	4800
ORION	709 STUDIO	4900
ORION	710 STUDIO	4300
ORION	7100W	4900 ?
ORION	7103 TRIADE	4900
ORION	711VT COLOR	CODE A
ORION	730VT TORUS	4300 PROFESSIONAL
ORION	7400TRC	4300 PROFESSIONAL
ORION	740VT	4300 PROFESSIONAL
ORION	765/382	8000 PROFESSIONAL
ORION	8603 TRIADE	4900
ORION	8800RC	4300 PROFESSIONAL

Brand	model	chassis
ORION	9203 TRIADE	4900
ORION	Arena CT70-500SI	TMB542A
ORION	C14DVD04SLTXA	TMC574A
ORION	C1500	(VMA230A)
ORION	C612 VT	4800
ORION	C612VT	4800
ORION	C711 VT	C711
ORION	C711VT	C711
ORION	COLOR5598	CODE A (B800296)
ORION	Combi 2115SiB	TMC568A
ORION	Combi 5192	Code B
ORION	CT63S92 N	BS990
ORION	CT71S92 N	BS990
ORION	CTV2850	E9
ORION	DVD/C1020	TMA498A
ORION	G14DVD13	TMC574A
ORION	PT5036VT	CTN
ORION	PT5036VT	CTN
ORION	SKV2080TMK5	TM0230C ?
ORION	Studio 631	4800
ORION	STUDIO 631	4800
ORION	Studio 709	4800
ORION	Studio 709	4900
ORION	Studio 710	4300
ORION	STUDIO 710	4300 PROFESSIONAL
ORION	T2010MJ	11AK19PRO
ORION	T2120MTX	PT90
ORION	T2835S	11AK37
ORION	T2850	E9
ORION	Torus 730	4300
ORION	Torus 730	4300
ORION	Triade 28	4900
ORION	Triade 28	4900
ORION	Triade 34	4900
ORION	Triade 34	4900

Brand	model	chassis
ORION	Triade 34 PIP	4900
ORION	Triade 34 PIP	4900
ORION	Triade 3403	4900
ORION	Triade 3403	4900
ORION	Triade 36	4900
ORION	Triade 36	4900
ORION	Triade 7103	4900
ORION	Triade 7103	4900
ORION	Triade 8603	4900
ORION	Triade 8603	4900
ORION	Triade 9203	4900
ORION	Triade 9203	4900
ORION	Triade34	7000 PROFESSIONAL
ORION	TV1169	7000 PROFESSIONAL
ORION	TV134TX	TM9414A
ORION	TV1703	CTN
ORION	TV1703	CTN
ORION	TV20136	TV20136
ORION	TV20151	TV20136
ORION	TV20151SI	TV20136 (a fakt. 12.7 (G70.190-....)) - BEKO
ORION	TV2016	TV2150
ORION	TV2016	TV2150
ORION	TV20171SI	14.2 ?
ORION	TV205VT	D2GW
ORION	TV2150TX	TV2150
ORION	TV2150TX	TV2150
ORION	TV2461W	TV2150
ORION	TV2461W	TV2150
ORION	TV2550	2550
ORION	TV2550	2550
ORION	TV2807	7000 PROFESSIONAL
ORION	TV2810	7300 Professional
ORION	TV28100	8000 PROFESSIONAL
ORION	TV28100	8000 PROFESSIONAL
ORION	TV2816	7000 PROFESSIONAL

Brand	model	chassis
ORION	TV2816PIP	7000 PROFESSIONAL
ORION	TV28200	8000 PROFESSIONAL
ORION	TV28301	8500 PROFESSIONAL (PCB8500)
ORION	TV28301 28WDA	8500 PROFESSIONAL (PCB8500)
ORION	TV2840	7000 PROFESSIONAL
ORION	TV2840	7000 PROFESSIONAL
ORION	TV2844	4400 PROFESSIONAL (PCB: 4410)
ORION	TV2844W	4400 PROFESSIONAL (PCB: 4410)
ORION	TV2853	2550
ORION	TV2854N	2500
ORION	TV2854NA - 28XBA	2500 (PCB2500)
ORION	TV2854NA 28XBA	2500
ORION	TV2870	7000 PROFESSIONAL
ORION	TV2871	TV2150
ORION	TV2871P	7000 PROFESSIONAL
ORION	TV2871W	Code A
ORION	TV2872P	7000 PROFESSIONAL
ORION	TV287CETV	7000 PROFESSIONAL
ORION	TV28VPB	8000 PROFESSIONAL
ORION	TV29074	TV714
ORION	TV29078	TV714
ORION	TV3257N	4400C PROFESSIONAL
ORION	TV3258	4400C
ORION	TV3350	7300 Professional
ORION	TV3400	4300 PROFESSIONAL
ORION	TV34086	TV714
ORION	TV3500	4300
ORION	TV3500	4300 PROFESSIONAL
ORION	TV3500A	4300
ORION	TV3700	4400 PROFESSIONAL (PCB: 4410)
ORION	TV3700	4400B
ORION	TV372	CTN
ORION	TV372	D2GW
ORION	TV3780	CTN
ORION	TV3780DK3	CTN

Brand	model	chassis
ORION	TV3782B	CTN
ORION	TV3782S	CTS-AA
ORION	TV3782TX	CTN ?
ORION	TV3782TX	CTS-AA
ORION	TV3782TX	D2GW (czy? CTS-AA)
ORION	TV3782TXB	CTS-AA ?
ORION	TV3782TXSI	CTS-AA ?
ORION	TV3782W	CTS-AA
ORION	TV3786	TV3787
ORION	TV3786	TV3787
ORION	TV3787	TV3787
ORION	TV3787	TV3787
ORION	TV3788S1	CTU-AA
ORION	TV3788SI	CTU-AA
ORION	TV3789	TV3787
ORION	TV3789F	CODE A ?
ORION	TV3789FSI	TMB557A !; CODE A (A.M.: ale to nie znaczy)
ORION	TV3789SI	TMB557A
ORION	TV378TX	D2GW
ORION	TV38103	8500 PROFESSIONAL (PCB8500)
ORION	TV38108	8500 PROFESSIONAL (PCB8500)
ORION	TV3850	4400 PROFESSIONAL (PCB: 4410)
ORION	TV3850	4400B
ORION	TV3851	4400B
ORION	TV3860	4400B
ORION	TV3880	2550
ORION	TV3880	4400B
ORION	TV3880 34BDM	4400B PROFESIONAL
ORION	TV400TX	CTT-H
ORION	TV4155ST	4300
ORION	TV418	CTS-AA
ORION	TV419B	CTS-AA
ORION	TV4400NTX	4400 PROFESSIONAL (PCB: 4410)
ORION	TV5051VT	CTS-AA
ORION	TV5071VT	CTS AA

Brand	model	chassis
ORION	TV5172	CTS-AA
ORION	TV5175TX	CTN-AA (?)
ORION	TV5176	D2GW (CTS-AA)
ORION	TV5176B	CTS-AA
ORION	TV5176S	CTS-AA
ORION	TV5176SI	CTS-AA
ORION	TV5176TX	CTS-AA
ORION	TV5176TX	D2GW
ORION	TV5176W	CTS-AA
ORION	TV5177	TV20136
ORION	TV518	TV518
ORION	TV518SI	TV518
ORION	TV5531	TV5531
ORION	TV5531SI	CODE A
ORION	TV5531SI	TMA518A
ORION	TV5531SI	TV5531
ORION	TV5532	TV5532
ORION	TV5532SI	PT90 ? - NIE!
ORION	TV5535	CODE B
ORION	TV560	4300
ORION	TV5612	4300
ORION	TV562	CTN-BB !
ORION	TV562	CTS-AA
ORION	TV562S	CTN-AA
ORION	TV562SI	CTS-AA
ORION	TV562TX	CTS-AA
ORION	TV573TX	CTU-AA
ORION	TV574	CTU-AA
ORION	TV575 TX	4AGS
ORION	TV7107	4300 PROFESSIONAL
ORION	TV7109	7000 PROFESSIONAL
ORION	TV7109 PIP	7000 PROFESSIONAL
ORION	TV71100	8000 PROFESSIONAL
ORION	TV71100	8000 PROFESSIONAL
ORION	TV71100 28DDA	8000 PROFESSIONAL

Brand	model	chassis
ORION	TV71200	8000 PROFESSIONAL
ORION	TV71200	8000 PROFESSIONAL
ORION	TV714	TV714
ORION	TV715	4300
ORION	TV715	4300 PROFESSIONAL
ORION	TV715	B4104 (a fakt.: 4300 PROFESSIONAL)
ORION	TV715A	4400 PROFESSIONAL (PCB: 4410)
ORION	TV715A	4400A
ORION	TV715VT	4300 PROFESSIONAL
ORION	TV716	4300
ORION	TV716	4300 PROFESSIONAL
ORION	TV718	4300
ORION	TV719	TV714
ORION	TV72203	8500 PROFESSIONAL (PCB8500)
ORION	TV725	4300 PROFESSIONAL
ORION	TV725S	4300
ORION	TV726	4400A
ORION	TV730	4300
ORION	TV730	4300 PROFESSIONAL
ORION	TV735	7000 PROFESSIONAL
ORION	TV740GE	4300
ORION	TV740GE	4300 PROFESSIONAL
ORION	TV750	7000 PROFESSIONAL
ORION	TV755S	7000 PROFESSIONAL
ORION	TV775	7000 PROFESSIONAL
ORION	TV777 (28HDC)	8500 PROFESSIONAL (PCB8500)
ORION	TV788	8500 PROFESSIONAL (PCB8500)
ORION	TV789	4400 PROFESSIONAL (PCB: 4410)
ORION	TV790	2550
ORION	TV790	4400 PROFESSIONAL (PCB: 4410)
ORION	TV790	4400A
ORION	TV790 28BDF+B6568	4400 PROFESIONAL
ORION	TV791	4400A
ORION	TV792	4400A
ORION	TV794	2550

Brand	model	chassis
ORION	TV794	4400A
ORION	TV796	2500 (PCB2500)
ORION	TV796	2550
ORION	TV796N	2550
ORION	TV796SI	2500C (PCB2500C)
ORION	TV797SI	(S99.190-04)
ORION	TV799	2550
ORION	TV799	2550
ORION	TV8201	7000 PROFESSIONAL
ORION	TV8201 325BE	7000 PROFESSIONAL
ORION	TV8208	4400 PROFESSIONAL (PCB: 4410)
ORION	TV8208	4400C
ORION	TV8210	7300 Professional
ORION	TV82100	8000 PROFESSIONAL
ORION	TV82100 32DDA	8000 PROFESSIONAL
ORION	TV82200	8000 PROFESSIONAL
ORION	TV82201	8000 PROFESSIONAL
ORION	TV82301	8500 PROFESSIONAL (PCB8500)
ORION	TV82402	8500 PROFESSIONAL (PCB8500)
ORION	TV8250	7000
ORION	TV8250	7000 PROFESSIONAL
ORION	TV8251	2550
ORION	TV8270	7000 PROFESSIONAL ?
ORION	TV8295	7000 PROFESSIONAL
ORION	TV8295 PIP	7000 PROFESSIONAL
ORION	TV8607	7000 PROFESSIONAL
ORION	TV8607PIP	7000 PROFESSIONAL
ORION	TV9207	7000 PROFESSIONAL
ORION	TVC16997	7300 Professional
ORION	TVR1600	TVR1600
ORION	TVR1602	TVR1600
ORION	VPR44	TM0266A
ORION (SINUDYNE)	2539A	(3130 103 3193.2)
ORION (SINUDYNE)	2539W	2550 Professional - ?
ORION (SINUDYNE)	Api 26613/26633	5500 Professional

Brand	model	chassis
ORION (SINUDYNE)	Clio 22613	5500 Professional
ORION (SINUDYNE)	Delo 2503	5500 Professional
ORION (SINUDYNE)	Perseo 2501/25013	5500 Professional
ORION (SINUDYNE)	Teseo 22832/22833	5500 Professional
ORION (SINUDYNE)	Thor 26833	5500 Professional
ORION (SINUDYNE)	Urano 2801	5500 Professional
ORION (SINUDYNE)	Xantos 20032	5500 Professional
OSAKA	DMQ2157	C500
OSAKI	P60G	PC04X (Ilw.)
OTAKE	5133	C38
OTAVA	5572PST	K21 (ch. 'K')
OTAVA	7272PST	Q29 (ch. 'K')
OTTO	TV70303SAT	SCC103 (ELBIT)
PACIFIC	AP3210WNS	14.2 ?
Pacific	PTV3604	CTS-AA
PACIFIC	PTV3606	TMB557A (CODE A)
Pacific	PTV5102	CTS-AA
PACIFIC	PTV55200	CTU-AA (czy? CTU-AB)
PACIFIC	PTV7017	11AK37-11
PALLADIUM	015/407	PC180
PALLADIUM	015/415	PC180
PALLADIUM	015/733	DTV101
PALLADIUM	220/473	PT100 (100Hz)
Palladium	26921	CTV100 (04TA065A) - Profilo-Telra
PALLADIUM	26K70	K
PALLADIUM	284DE	7020 (ORION)
PALLADIUM	284DE	7020 (ORION)
PALLADIUM	284PC 772/178	7300 Professional
PALLADIUM	287	7000
PALLADIUM	2870P	7000 PROFESSIONAL ?
PALLADIUM	2871P	7000 PROFESSIONAL ?
PALLADIUM	2873P	7300 (B7300-1)
PALLADIUM	287PE 131/009	(B7310)
PALLADIUM	288/748	11AK45B5
PALLADIUM	28VPC719/583	8000 PROFESSIONAL

Brand	model	chassis
PALLADIUM	32DPB	8000
PALLADIUM	330/159	990
PALLADIUM	330/191	C9001
PALLADIUM	330/256	990
PALLADIUM	330/264	990
PALLADIUM	330/272	990
PALLADIUM	330/361	990
PALLADIUM	330/906	990
PALLADIUM	375/993	11AK33-J33 (?)
PALLADIUM	724/432	M 90°
PALLADIUM	724/556	PC04A
PALLADIUM	724/564	PC04A
PALLADIUM	724/874	SCC103 (ELBIT)
PALLADIUM	724/998	990
PALLADIUM	727/491	PC91A
PALLADIUM	727/539	990
PALLADIUM	727/547	990
PALLADIUM	727/652	860
PALLADIUM	727/660	860
PALLADIUM	727/679	860
PALLADIUM	727/679	960
PALLADIUM	727/830	PC91A
PALLADIUM	727/997	C9002S
PALLADIUM	732/613	K
PALLADIUM	757/547	990
PALLADIUM	765/155	PC170
PALLADIUM	765/220	TV17 (100Hz)
PALLADIUM	765/228	PC170
PALLADIUM	765/239	4400C
PALLADIUM	765/279	PC180
PALLADIUM	765/295	PC180
PALLADIUM	765/309	PC180
PALLADIUM	765/317	PC180
PALLADIUM	765/325	PC100
PALLADIUM	765/333	PC180

Brand	model	chassis
PALLADIUM	765/341	PC170
PALLADIUM	765/368	PC100
PALLADIUM	765/374	8000 PROFESSIONAL
PALLADIUM	765/376	8000 PROFESSIONAL
PALLADIUM	765/382	8000 PROFESSIONAL
PALLADIUM	765/384	PC100
PALLADIUM	765/390	8000 PROFESSIONAL
PALLADIUM	765/392	7000
PALLADIUM	765/465	PC220
PALLADIUM	765/868	8000 PROFESSIONAL
PALLADIUM	765/872	7000 PROFESSIONAL
PALLADIUM	765/949	8000 PROFESSIONAL
PALLADIUM	765/981	TV17.1 (a može PC100)
PALLADIUM	772/186	7S2190
PALLADIUM	772/275	7S2190
PALLADIUM	772/542	7300 (B7300-1)
PALLADIUM	772/591	4400 PROFESSIONAL ?
PALLADIUM	772/607	4400B
PALLADIUM	772/615	4400A
PALLADIUM	772/739	4400A
PALLADIUM	772/739A	2500C (PCB2500C)
PALLADIUM	970/107	F990
PALLADIUM	970/298	990
PALLADIUM	970/492	990
PALLADIUM	997/070	990
PALLADIUM	999/070	990
PALLADIUM	EC64303CTI	SCC103 (ELBIT)
PALLADIUM	EC70303SAT	SCC103 (ELBIT)
Palladium	TFT32921	CTV100 (04TA065A) - Profilo-Telra
Palladium	TFT32921	CTV100 (04TA065A) - Profilo-Telra
PALLADIUM	TV100-70227/P--Art Nr 765/171	DTV100
PALLADIUM	TV100-70435/P/DPS	DTV100
PALLADIUM	TV100/16:9 DPL artikel nr 100-70-43-5/P/DPS	DTV100
PALLADIUM	TV101	DTV101
PALLADIUM	TV17.1-70238	TV17.1 (100Hz)

Brand	model	chassis
PALLADIUM	TV17.1-70242P	TV17.1 (100Hz)
PALLADIUM	TV17.E-80543/M/C-AV/DVSS/AS	TV17
PALLADIUM	TV17170242P	TV17 (100Hz)
PALLADIUM	TV28100	8000 PROFESSIONAL
PALLADIUM	TV2870	7000
PALLADIUM	TV28VPB	8000 PROFESSIONAL
PALLADIUM	TV70222	TV9.1
PALLADIUM	TV70227P	DTV101
PALLADIUM	TV70435/P/PDS	DTV100
PALLADIUM	TV7070VT	990
PALLADIUM	TV70VT	990
PALLADIUM	TV71651	PT100 (100Hz)
PALLADIUM	TV82100	8000 PROFESSIONAL
PALLADIUM	TVB10720	14.2 ?
PALLADIUM	TVB5020S	14.2 (U99.190-02)
PALLADIUM	TVB5030S	14.2 (U99.190-02)
PANASCANIC	RC4221PST	RC4121A
PANASCANIC	RC4421PST	RC4121A
PANASONIC	25GX1889	GR6LS
PANASONIC	29GX1899	GR6LS
PANASONIC	CT -F2115M	NA10
PANASONIC	CT -G2985S	NA10
PANASONIC	CT-D14R	ADP219 ?
PANASONIC	CT-D20R	ADP221
PANASONIC	CT-F2120S	NA10
PANASONIC	CT-F2124	LDP432 ?
PANASONIC	CT-F2124J	NA10
PANASONIC	CT-F2124LJ	NA10
PANASONIC	CT-F2124LTJ	NA10
PANASONIC	CT-F2124TJ	NA10
PANASONIC	CT-F2134J	NA10
PANASONIC	CT-F2134LJ	NA10
PANASONIC	CT-F2134LT	NA10
PANASONIC	CT-F2134TJ	NA10
PANASONIC	CT-F2135LN	GN3M

Brand	model	chassis
PANASONIC	CT-F2136LC	GP41
PANASONIC	CT-F2156WLC	GP41
PANASONIC	CT-F2156WLP	GP41
PANASONIC	CT-F2522F	BP370
PANASONIC	CT-F2522LF	LBP370
PANASONIC	CT-F2522XF	XBP370
PANASONIC	CT-F2922F	BP368
PANASONIC	CT-F2922LF	LBP368
PANASONIC	CT-F2922XF	XBP368
PANASONIC	CT-F2936LC	GP41
PANASONIC	CT-F2936LP	GP41
PANASONIC	CT-F2942F	FP368
PANASONIC	CT-F2942LF	LFP368
PANASONIC	CT-F2942XF	XFP368
PANASONIC	CT-F2943XG	XFP406 ?
PANASONIC	CT-F3431E	BP371
PANASONIC	CT-F3431XE	XEP371
PANASONIC	CT-F3441LE	BP371
PANASONIC	CT-G2150R	NA10
PANASONIC	CT-G2158B	GP336
PANASONIC	CT-G2159E	ZP360
PANASONIC	CT-G2936W1	ATMEDP307 ?
PANASONIC	CT-G2938B	NP330
PANASONIC	CT-G2949LE	LAP375 ?
PANASONIC	CT-G2995	GN3
PANASONIC	CT-G2995L	GN3
PANASONIC	CT-P2031R	ADP213 ?
PANASONIC	CT-P2780SF	AEDP218
PANASONIC	CT-Z1423	TMC573
PANASONIC	CT-Z1423	TMC573
PANASONIC	CT-Z2110LT	ADP253 (?)
PANASONIC	CT13R17	TMB535
PANASONIC	CT13R17B	TMB535
PANASONIC	CT13R18B	TMC573
PANASONIC	CT13R27	TMB535

Brand	model	chassis
PANASONIC	CT13R27W	TMB535
PANASONIC	CT13R28B	TMC573
PANASONIC	CT13R32	DP358/EP358
PANASONIC	CT13R37	TMB535
PANASONIC	CT13R37S	TMB535
PANASONIC	CT13R38B	TMC573
PANASONIC	CT13R42	DP358/EP358
PANASONIC	CT13R52	DP358/EP358
PANASONIC	CT1423G	TMC573A
PANASONIC	CT2006SE	FP360
PANASONIC	CT2016SE	FP360
PANASONIC	CT2017F1	DP391
PANASONIC	CT20D11DE	EP360
PANASONIC	CT20D11E	EP360
PANASONIC	CT20G14A	DP326 (?)
PANASONIC	CT20G23W	AEDP301 ?
PANASONIC	CT20G6DE	DP359
PANASONIC	CT20G6E	DP359
PANASONIC	CT20G8G	NA10
PANASONIC	CT20G8SG	NA10
PANASONIC	CT20L8G	NA10
PANASONIC	CT20R10HR	AMDP229
PANASONIC	CT20R10R	ALDP229
PANASONIC	CT20R10XR	AXDP229
PANASONIC	CT20R14V	APEDP280
PANASONIC	CT20R6CE	AP359
PANASONIC	CT20R6E	AP359
PANASONIC	CT20S10R	ALEDP229
PANASONIC	CT20S15LR	ALEDP227
PANASONIC	CT20S15PR	ALEDP227
PANASONIC	CT20S15R	ALEDP227
PANASONIC	CT20S1R	AEDP229
PANASONIC	CT20S20R	AEDP227
PANASONIC	CT20SL13G	NA10
PANASONIC	CT20SX10B	AP354

Brand	model	chassis
PANASONIC	CT20SX10CB	AP354
PANASONIC	CT24SL13G	NA10
PANASONIC	CT24SL13UG	NA10
PANASONIC	CT24SX10B	AP353
PANASONIC	CT24SX10CB	AP353
PANASONIC	CT25G6E	AP361
PANASONIC	CT25L8G	NA10
PANASONIC	CT25L8UG	NA10
PANASONIC	CT2707DF	TP338
PANASONIC	CT2707DUF	TP338
PANASONIC	CT2772SCE	KP338
PANASONIC	CT2772SE	KP338
PANASONIC	CT2772SUE	KP338
PANASONIC	CT27C22V	APEDP280
PANASONIC	CT27C8G	NA10
PANASONIC	CT27D10B	AP338
PANASONIC	CT27D10DB	AP338
PANASONIC	CT27D10UB	AP338
PANASONIC	CT27D11DE	JP338
PANASONIC	CT27D11E	JP338
PANASONIC	CT27D11UE	JP338
PANASONIC	CT27D12DF	SP338
PANASONIC	CT27D12DUF	SP338
PANASONIC	CT27D20B	HP338
PANASONIC	CT27D20UB	EP358
PANASONIC	CT27D21E	KP338
PANASONIC	CT27D21UE	KP338
PANASONIC	CT27D30B	BP338
PANASONIC	CT27D30CB	BP338
PANASONIC	CT27D30UB	BP338
PANASONIC	CT27D31CE	RP338
PANASONIC	CT27D31E	RP338
PANASONIC	CT27D31UE	RP338
PANASONIC	CT27D32F	RP338
PANASONIC	CT27D32UF	RP338

Brand	model	chassis
PANASONIC	CT27E13G	NA10
PANASONIC	CT27E33G	NA10
PANASONIC	CT27G12V	APEDP280
PANASONIC	CT27G22	NA6 ?
PANASONIC	CT27G33CW	ED314C
PANASONIC	CT27G8G	NA10
PANASONIC	CT27G8UG	NA10
PANASONIC	CT27L8G	NA10
PANASONIC	CT27L8SG	NA10
PANASONIC	CT27L8UG	NA10
PANASONIC	CT27SF14V	APEDP264
PANASONIC	CT27SF24V	APEDP264
PANASONIC	CT27SF34V	APEDP264
PANASONIC	CT29G6XE	XBP362 (?)
PANASONIC	CT3020A	NMX-CL
PANASONIC	CT30WX52	DX3PW
PANASONIC	CT31SF24V	APEDP264
PANASONIC	CT3207DF	QP341
PANASONIC	CT3207DUF	QP341
PANASONIC	CT3274SCE	GP341
PANASONIC	CT32D10B	DP341
PANASONIC	CT32D10CB	DP341
PANASONIC	CT32D10UB	DP341
PANASONIC	CT32D11CE	EP341
PANASONIC	CT32D11E	EP341
PANASONIC	CT32D11UE	EP341
PANASONIC	CT32D12DF	TP341
PANASONIC	CT32D20B	AP341
PANASONIC	CT32D20UB	AP341
PANASONIC	CT32D30B	BP341
PANASONIC	CT32D30CB	BP341
PANASONIC	CT32D30UB	BP341
PANASONIC	CT32D31CE	GP341
PANASONIC	CT32D31E	GP341
PANASONIC	CT32D31UE	GP341

Brand	model	chassis
PANASONIC	CT32D32F	GP341
PANASONIC	CT32D32UF	GP341
PANASONIC	CT32E13G	NA10
PANASONIC	CT32E33G	NA10
PANASONIC	CT32G19J	GN3
PANASONIC	CT32G19UJ	GN3
PANASONIC	CT32G9J	GN3
PANASONIC	CT32G9UJ	GN3
PANASONIC	CT32HC14	DX4M
PANASONIC	CT32HX41CE	AP346
PANASONIC	CT32HX41E	AP346
PANASONIC	CT32HX41UE	AP346
PANASONIC	CT32SC14J	NA10FL
PANASONIC	CT32SC14UJ	NA10FL
PANASONIC	CT32SL14J	NA10FL
PANASONIC	CT32SL14UJ	NA10FL
PANASONIC	CT32SX31CE	NA8ML--BP371
PANASONIC	CT32SX31E	BP371
PANASONIC	CT32SX31E	NA8ML--BP371
PANASONIC	CT32SX31E (czy? TC32SX31E)	NA8ML
PANASONIC	CT32SX31UE	NA8ML--BP371
PANASONIC	CT33SF24TV	APEDP264
PANASONIC	CT36D11CE	GP342
PANASONIC	CT36D11E	GP342
PANASONIC	CT36D11UE	GP342
PANASONIC	CT36D12DF	KP342
PANASONIC	CT36D12DUF	KP342
PANASONIC	CT36D20B	AP342
PANASONIC	CT36D20UB	AP342
PANASONIC	CT36D30	NA8
PANASONIC	CT36D30B	BP342
PANASONIC	CT36D30CB	BP342
PANASONIC	CT36D30UB	BP342
PANASONIC	CT36D31CE	FP342
PANASONIC	CT36D31E	FP342

Brand	model	chassis
PANASONIC	CT36D31UE	FP342
PANASONIC	CT36D32F	HP342
PANASONIC	CT36D32UF	HP342
PANASONIC	CT36E13G	NA10
PANASONIC	CT36E33G	NA10
PANASONIC	CT36HX41CE	AP347
PANASONIC	CT36HX41E	AP347
PANASONIC	CT36HX41UE	AP347
PANASONIC	CT36SL14J	NA10FL
PANASONIC	CT36SL14UJ	NA10FL
PANASONIC	CT36SX31CE	NA8ML--BP372
PANASONIC	CT36SX31E	BP372
PANASONIC	CT36SX31E	NA8ML--BP372
PANASONIC	CT36SX31UE	NA8ML--BP372
PANASONIC	CTAV29EE	M15
PANASONIC	CTF2110XB	XP353
PANASONIC	CTF2510XB	XP353
PANASONIC	CTF29992V	APEDP264
PANASONIC	CTL2791S	AEDP168
PANASONIC	CTM2053R2	211ALDP
PANASONIC	CTN1061R	AMDP215 (?)
PANASONIC	PC21R10R	YALDP229
PANASONIC	PC21S10R	YALEDP229
PANASONIC	PC21XF20R	YALEDP227
PANASONIC	PC29XF20A	YANEDP218
PANASONIC	PT-W4734XJ	GN1P (AP832)
PANASONIC	PT37P1	GP2D
PANASONIC	PT42P1	GP2D
PANASONIC	PT42PD1	GP2D
PANASONIC	PT47WX42CF	EP824
PANASONIC	PT47WX42F	EP824
PANASONIC	PT47WX52CF	EP824
PANASONIC	PT47WX52F	EP824
PANASONIC	PT47X54J	GN1P
PANASONIC	PT47XD64J	P9M

Brand	model	chassis
PANASONIC	PT51G36CE	AP822
PANASONIC	PT51G36E	AP822
PANASONIC	PT51G45XU	AXMEDP809
PANASONIC	PT53WX42F	EP824
PANASONIC	PT53WX52CF	EP824
PANASONIC	PT53WX52CF	EP824/FP824
PANASONIC	PT53WX52F	EP824
PANASONIC	PT53X54J	GN1P
PANASONIC	PT56WX42F	FP824
PANASONIC	PT56WX52CF	FP824
PANASONIC	PT56WX52F	FP824
PANASONIC	QC21S15J	YAMEDC229
PANASONIC	SP20S15R	AMEDC229
PANASONIC	SP2724E	EC363
PANASONIC	SP3235F	RP341
PANASONIC	SP3235UF	RP341
PANASONIC	TC-AV29C	NMX-M15M
PANASONIC	TC-AV29EE	M15M
PANASONIC	TC-AV29XR	M15M ?
PANASONIC	TC-AV33EE	M15M
PANASONIC	TC-W21S	C150V
PANASONIC	TC1415HQ	MX5Z
PANASONIC	TC1420B10P	MX5Y
PANASONIC	TC1420TQ	MX
PANASONIC	TC1470UD	Z1
PANASONIC	TC1480EU	Z3
PANASONIC	TC1485	Z3
PANASONIC	TC1485DR	Z3T
PANASONIC	TC14A10	MX5Y
PANASONIC	TC14A12	BR3L
PANASONIC	TC14A12P	BR2L
PANASONIC	TC14B3EE	M15M
PANASONIC	TC14B3R	Z375
PANASONIC	TC14B3RC	Z375
PANASONIC	TC14B4R	Z185

Brand	model	chassis
PANASONIC	TC14B4R/B	Z185
PANASONIC	TC14JR1	Z7
PANASONIC	TC14JR1P	Z7
PANASONIC	TC14JT1P	Z7
PANASONIC	TC14K1R	Z7
PANASONIC	TC14L3R	MX1A
PANASONIC	TC14RM10LP	GP31
PANASONIC	TC14S15M	MX5Z
PANASONIC	TC14S1RC	Z5
PANASONIC	TC14S3R	Z7
PANASONIC	TC14S3RC	Z7
PANASONIC	TC14S4R	Z7
PANASONIC	TC14SV10S	MX3V
PANASONIC	TC14Z88R	MX5Z
PANASONIC	TC14Z88RQ	GP3
PANASONIC	TC15M2R	Z4
PANASONIC	TC15PM11R	MX7Z
PANASONIC	TC15PM11RQ	MX7Z
PANASONIC	TC15PM30R	MX7Z
PANASONIC	TC1665DRS	Z1
PANASONIC	TC1785DRS	Z3T
PANASONIC	TC2000T	MX5Z
PANASONIC	TC2091MR	M15L
PANASONIC	TC20A10	MX5Y
PANASONIC	TC20A12	BR3L
PANASONIC	TC20B12	BR2L
PANASONIC	TC20C7A	MX3
PANASONIC	TC20G11A-P	BR2
PANASONIC	TC20G11P	BR2
PANASONIC	TC20G9A	BR1L
PANASONIC	TC20KL03	MX5ZB
PANASONIC	TC20KL03P	MX5Z
PANASONIC	TC20KL05P	GP31
PANASONIC	TC20KM03	MX5ZB
PANASONIC	TC20KM03	MX5ZB

Brand	model	chassis
PANASONIC	TC20L3A	MX1 ?
PANASONIC	TC20RA10LP	GP31
PANASONIC	TC20RM10LP	GP31
PANASONIC	TC20S10M	MX5Z
PANASONIC	TC2105RT	MX3
PANASONIC	TC2125RT	MX3S (?)
PANASONIC	TC2130T	MX5Z
PANASONIC	TC2150RM	MX3C
PANASONIC	TC2150RM	MX5Y
PANASONIC	TC2150RM	MX5Y ?
PANASONIC	TC2151R	MX3C
PANASONIC	TC2155R	MX3C
PANASONIC	TC2160EE	M14EC
PANASONIC	TC2166R	MX3
PANASONIC	TC2170R	MX3
PANASONIC	TC2171EE	M15M
PANASONIC	TC2171NPSR	M15MA
PANASONIC	TC2175DRS	Z1
PANASONIC	TC2175UR	Z1
PANASONIC	TC2185DRS	Z3T
PANASONIC	TC2185TR	M15L
PANASONIC	TC2187R	MX3S
PANASONIC	TC2195DRN	Z3T
PANASONIC	TC2195DRS	Z3T
PANASONIC	TC21B3EE	M15M
PANASONIC	TC21D2Q	MX5Z
PANASONIC	TC21E1R	MX1A
PANASONIC	TC21F1	MX3
PANASONIC	TC21FG10P	GP31
PANASONIC	TC21FG20P	GP31
PANASONIC	TC21FG30P	GP31
PANASONIC	TC21FJ10T	GP3
PANASONIC	TC21FJ30P	GP3
PANASONIC	TC21GF10R	MX2
PANASONIC	TC21GF80R	MX3

Brand	model	chassis
PANASONIC	TC21JR1	Z7
PANASONIC	TC21JR1C (czy? TC21J1RC)	Z7 ?
PANASONIC	TC21K1R	Z7
PANASONIC	TC21KS30X	MX7A
PANASONIC	TC21L10R2	MX3A ?
PANASONIC	TC21L1EE	M16S ?
PANASONIC	TC21L1R	M16S
PANASONIC	TC21M1RD	Z4
PANASONIC	TC21M2RD	Z4
PANASONIC	TC21P22B	MX8
PANASONIC	TC21P50R	MX8
PANASONIC	TC21PM10R	MX7Z
PANASONIC	TC21PM30R	MX7Z
PANASONIC	TC21PS70T	MX5Z
PANASONIC	TC21PS72H	MX5Z
PANASONIC	TC21PS75RQ	MX12
PANASONIC	TC21R1L	ALPHA2
PANASONIC	TC21S1	MX3
PANASONIC	TC21S10R	MX3
PANASONIC	TC21S15M	MX5Z
PANASONIC	TC21S3R	Z7
PANASONIC	TC21S4RC	Z7
PANASONIC	TC21S80R2	MX5 ?
PANASONIC	TC21S85R	MX5Z
PANASONIC	TC21S85RQ	MX5Z
PANASONIC	TC21Z2A	MX5A
PANASONIC	TC21Z88RQ	GP3
PANASONIC	TC2458DR	U5W (?)
PANASONIC	TC24R1U	ALPHA2
PANASONIC	TC24WG12H	M17W
PANASONIC	TC25FJ20M	GP3
PANASONIC	TC25GF10R	M17
PANASONIC	TC25GV10R	M17V
PANASONIC	TC25L10R	MX3
PANASONIC	TC25P22LB	MX8B

Brand	model	chassis
PANASONIC	TC25P80B	MX10 (?)
PANASONIC	TC25P90R	MX12
PANASONIC	TC25P92H	MX12
PANASONIC	TC25PS70R	MX12
PANASONIC	TC25R2U	ALPHA2
PANASONIC	TC25R70	C150 ?
PANASONIC	TC25R70AB	C150 ?
PANASONIC	TC25V20R	MX2
PANASONIC	TC25V50R	MX2A
PANASONIC	TC25V70R	MX4
PANASONIC	TC25V70R	MX4
PANASONIC	TC2671EE	M15M
PANASONIC	TC2671NPSR	M15MB
PANASONIC	TC26B3EE	M15M
PANASONIC	TC28WG12H	M17
PANASONIC	TC28WG20R	M19W (M18W ?)
PANASONIC	TC2990EE	M15M
PANASONIC	TC29A11A	BR2
PANASONIC	TC29A4PX	NMX-M15M
PANASONIC	TC29A9	BR1
PANASONIC	TC29A9A	BR1L
PANASONIC	TC29FJ30L	GP3
PANASONIC	TC29G11A-P	BR2
PANASONIC	TC29GF10R	M17
PANASONIC	TC29GF15R	M17
PANASONIC	TC29GF30R	M18
PANASONIC	TC29GV10R	M17V
PANASONIC	TC29KL03	MX5ZB
PANASONIC	TC29KM03	MX5ZB
PANASONIC	TC29KM03	MX5ZB
PANASONIC	TC29KS30R	MX6
PANASONIC	TC29P10N	LX1
PANASONIC	TC29P22LA	MX8B
PANASONIC	TC29P700H	GP1
PANASONIC	TC29PL22	MX8

Brand	model	chassis
PANASONIC	TC29PS10P	EURO9L
PANASONIC	TC29PS60	GP3 ?
PANASONIC	TC29PS60B	GP3
PANASONIC	TC29PS60K	GP3
PANASONIC	TC29S100R	MX4
PANASONIC	TC29V2PX	NMX-M16MB
PANASONIC	TC29V30R	M16MV3
PANASONIC	TC29V50R	MX2A
PANASONIC	TC3370PER	ALPHA2
PANASONIC	TC33V30H	M16M
PANASONIC	TC34P150H	MD3A
PANASONIC	TC37P1	GP2D
PANASONIC	TC37P1F	GP2D
PANASONIC	TC37PD1	GP2D
PANASONIC	TC37PD1F	GP2D
PANASONIC	TC42P1	GP2D
PANASONIC	TC42P1F	GP2D
PANASONIC	TC42P1FA	GP2D
PANASONIC	TC42PD1	GP2D
PANASONIC	TC42PD1F	GP2D
PANASONIC	TC42PD1FA	GP2D
PANASONIC	TC43P250	EURO7VP
PANASONIC	TC51P250	EURO7VP
PANASONIC	TC51PS72Z	MX5ZA
PANASONIC	TC68GS90	M19 (?)
PANASONIC	TC68V85A	MX4M
PANASONIC	TCAV29EE	M15M
PANASONIC	TCW21S	C150V
PANASONIC	TH103PF10	GPF10D
PANASONIC	TH103PF9	GPF9D
PANASONIC	TH37PA20	GP6DA
PANASONIC	TH37PE30B	GP6DE
PANASONIC	TH37PW4	GP4D
PANASONIC	TH37PW5	GP5D
PANASONIC	TH37PWD4	GP4D

Brand	model	chassis
PANASONIC	TH37PWD5	GP5D
PANASONIC	TH37PWD5	GP5D
PANASONIC	TH37PWD8	GP8D
PANASONIC	TH42PA20E	GP6DE
PANASONIC	TH42PD50U	GP8DU
PANASONIC	TH42PHD5	GPH5D
PANASONIC	TH42PHW5	GPH5D
PANASONIC	TH42PV500A	GP8DA
PANASONIC	TH42PV60A	GP9DE
PANASONIC	TH42PV60H	GP9DE
PANASONIC	TH42PV60M	GP9DE
PANASONIC	TH42PV60MT	GP9DE
PANASONIC	TH42PV70L	GPH10DA
PANASONIC	TH42PW3E	GP3D
PANASONIC	TH42PW5	GP5D
PANASONIC	TH42PW6EX	GP6D
PANASONIC	TH42PWD5	GP5D
PANASONIC	TH42PWD7	GP7D
PANASONIC	TH42PWD8	GP8D
PANASONIC	TH42PX6U	GP9DU
PANASONIC	TH42PX75U	GP10DHU
PANASONIC	TH50PH9UK	GPH9D
PANASONIC	TH50PHD3	GPH3D
PANASONIC	TH50PHD5	GPH5D
PANASONIC	TH50PHD7BK	GPH7D2
PANASONIC	TH50PHD7BS	GPH7D2
PANASONIC	TH50PHD7EK	GPH7D2
PANASONIC	TH50PHD7ES	GPH7D2
PANASONIC	TH50PHD7UY	GPH7D2
PANASONIC	TH50PHW5	GPH5D
PANASONIC	TH50PHW5	GPH5D2
PANASONIC	TH50PHW7BX	GPH7D2
PANASONIC	TH50PHW7EX	GPH7D2
PANASONIC	TH50PV30E	GP6DE
PANASONIC	TH50PV60L	GP9DE

Brand	model	chassis
PANASONIC	TH50PV70L	GPH10DA
PANASONIC	TH50PX6U	GP9DU
PANASONIC	TH58PZ700	GPF10DE
PANASONIC	TH65PFUK	GPF9D
PANASONIC	TH65PV500E	GPH8DE
PANASONIC	TUPT600B	EURO7TUB
PANASONIC	TX-C22DR	U5 ?
PANASONIC	TX-C71DRS	ALPHA1
PANASONIC	TX-C74UR	ALPHA1W
PANASONIC	TX-C78D	ALPHA2
PANASONIC	TX-C81DRS	ALPHA2
PANASONIC	TX-C84DRS	ALPHA2
PANASONIC	TX-C88DRS	ALPHA2
PANASONIC	TX-G10	AC1
PANASONIC	TX-G10C	AC1
PANASONIC	TX-W28D1F	E2100
PANASONIC	TX-W28D1F	E2100
PANASONIC	TX-W28D2DP	EURO3HW
PANASONIC	TX-W28D2DP	EURO3HW
PANASONIC	TX-W28D3F	EURO3HW
PANASONIC	TX-W28D3F	EURO3HW
PANASONIC	TX-W28D4F	EURO5
PANASONIC	TX-W28D4F	EURO5
PANASONIC	TX-W28D5	EURO5
PANASONIC	TX-W28D5F	EURO5
PANASONIC	TX-W28D5F	EURO5
PANASONIC	TX-W28R3DP	EURO3W
PANASONIC	TX-W28R3DP	EURO3W
PANASONIC	TX-W28R4	EURO4
PANASONIC	TX-W32D20	EURO3HW
PANASONIC	TX-W32D20	EURO3HW
PANASONIC	TX-W32D2DP	EURO3HW
PANASONIC	TX-W32D2DP	EURO3HW
PANASONIC	TX-W32D3DP	EURO3HW
PANASONIC	TX-W32D3DP	EURO3HW

Brand	model	chassis
PANASONIC	TX-W32D4DP	EURO5
PANASONIC	TX-W32D4DP	EURO5
PANASONIC	TX-W32D4F	EURO5L
PANASONIC	TX-W32D5DPF	EURO5
PANASONIC	TX-W32D5DPF	EURO5
PANASONIC	TX-W32PF10F	EURO5L
PANASONIC	TX-W32PF10F	EURO5L
PANASONIC	TX-W32R4DP	EURO4
PANASONIC	TX-W32R4DP	EURO4
PANASONIC	TX-W33AK10	EURO5L
PANASONIC	TX-W33AK10	EURO5L
PANASONIC	TX-W36D	EURO3
PANASONIC	TX-W36D20	EURO3
PANASONIC	TX-W36D3DP	EURO3HWS
PANASONIC	TX-W36D3DP	EURO3HWS
PANASONIC	TX-W36D3DPL	EURO3
PANASONIC	TX-W36PF10F	EURO5L
PANASONIC	TX14B3T	Z375
PANASONIC	TX14B4T	Z185
PANASONIC	TX14B4T/B	Z185
PANASONIC	TX14B4TC	Z185
PANASONIC	TX14B4TL	Z185
PANASONIC	TX14C3T/S	Z7
PANASONIC	TX14GV1	Z421V
PANASONIC	TX14JT1	Z7
PANASONIC	TX14JT1P	Z7
PANASONIC	TX14K1T	Z7
PANASONIC	TX14K2T	Z7
PANASONIC	TX14S1TCP	Z5 ?
PANASONIC	TX14S3T	Z7
PANASONIC	TX14S4TC	Z7
PANASONIC	TX15AT1C	Z-M3L (TMB538A)
PANASONIC	TX15LT2F	LH1
PANASONIC	TX15PM11T	MX7Z
PANASONIC	TX15PM30T	MX7Z

Brand	model	chassis
PANASONIC	TX17LX2	SL115P
PANASONIC	TX1988URT	ALPHA1W
PANASONIC	TX20LA1P	GP1LCD
PANASONIC	TX20LA5P(F)	GLP2N
PANASONIC	TX2150TS	MX3
PANASONIC	TX2151TCP	Z5
PANASONIC	TX2166T	MX3
PANASONIC	TX2170T	MX3
PANASONIC	TX2173URT	ALPHA1
PANASONIC	TX2178DRS	ALPHA1
PANASONIC	TX2181UR	Z3T
PANASONIC	TX21AD2D	EURO2
PANASONIC	TX21AD3C	EURO2
PANASONIC	TX21AP1	Z8T
PANASONIC	TX21AP1C	Z8T
PANASONIC	TX21AP1F	Z8T
PANASONIC	TX21AP1P	EURO4
PANASONIC	TX21AP2P	GP3L
PANASONIC	TX21AS1	EURO4
PANASONIC	TX21AS1P	EURO4
PANASONIC	TX21AT1L	Z8T
PANASONIC	TX21AV1C	Z082PF (Daewoo CP082, K30 Deck)
PANASONIC	TX21CK1	Z8
PANASONIC	TX21F1T	MX3
PANASONIC	TX21F1TP	MX3
PANASONIC	TX21FJ70R	GP4
PANASONIC	TX21GF80T	MX3
PANASONIC	TX21GV1	Z421V
PANASONIC	TX21GV1F	Z421W
PANASONIC	TX21JT1	Z7
PANASONIC	TX21JT1P	Z7
PANASONIC	TX21JT2	Z-M3L
PANASONIC	TX21JT2P	Z-M3L !
PANASONIC	TX21JT2P	Z7 - NIE! -> Z-M3L
PANASONIC	TX21JT3P	Z-M3L

Brand	model	chassis
PANASONIC	TX21K1T	Z7
PANASONIC	TX21K2T	Z7
PANASONIC	TX21LT3P	MX1A
PANASONIC	TX21M1TC	Z4
PANASONIC	TX21MD1C	EURO2
PANASONIC	TX21MD3C	EURO2M
PANASONIC	TX21MD4P	EURO4
PANASONIC	TX21MK1	EURO4
PANASONIC	TX21MK1P	Z385
PANASONIC	TX21PM10T	MX7Z
PANASONIC	TX21PM30T	MX7Z
PANASONIC	TX21PM50T	MX5
PANASONIC	TX21PS70T	MX5ZA
PANASONIC	TX21PZ1	CP521FS
PANASONIC	TX21PZ1D	CP521FS
PANASONIC	TX21PZ1F	CP521FS
PANASONIC	TX21PZ1P	CP521FS
PANASONIC	TX21R1U	ALPHA2
PANASONIC	TX21S1TC	Z5
PANASONIC	TX21S3TC	Z7
PANASONIC	TX21S3TP	Z7
PANASONIC	TX21S4TC	Z7
PANASONIC	TX21S4TP	Z7
PANASONIC	TX21SV1C	Z5V
PANASONIC	TX21T1C	ALPHA2
PANASONIC	TX21T1EE	M16S
PANASONIC	TX21V1D	ALPHA2
PANASONIC	TX21V1E	ALPHA2
PANASONIC	TX21V2C	ALPHA4
PANASONIC	TX21V80T	MX4S
PANASONIC	TX21W2T	MX5
PANASONIC	TX21X1T	MX5A (czy? MX3S)
PANASONIC	TX21X3T	MX5A
PANASONIC	TX21Z88X	MX5ZA
PANASONIC	TX22LT2	LH4

Brand	model	chassis
PANASONIC	TX22LX2	LH35
PANASONIC	TX2488UP	ALPHA2
PANASONIC	TX24A1DT	ALPHA2
PANASONIC	TX24PS2	GP4
PANASONIC	TX24T1U	ALPHA2
PANASONIC	TX24W1DT	ALPHA2W
PANASONIC	TX25A2C	ALPHA3 (TNP107...)
PANASONIC	TX25A3C	EURO1
PANASONIC	TX25AD1C	EURO1M
PANASONIC	TX25AD1D	EURO2
PANASONIC	TX25AD2C	EURO2
PANASONIC	TX25AD50F	EURO3H
PANASONIC	TX25AD70C	EURO3H
PANASONIC	TX25AD90F	EURO5
PANASONIC	TX25BM1	ALPHA2
PANASONIC	TX25C1C	ALPHA4
PANASONIC	TX25C1CP	ALPHA4
PANASONIC	TX25CK1P	Z8
PANASONIC	TX25CK1P	Z8
PANASONIC	TX25CK1P	Z8
PANASONIC	TX25CK1P	Z8
PANASONIC	TX25F150T	GP2A
PANASONIC	TX25G1C	ALPHA2
PANASONIC	TX25LD4C	EURO4
PANASONIC	TX25LD4P	EURO4
PANASONIC	TX25LD90F	EURO5
PANASONIC	TX25LK1	Z8
PANASONIC	TX25LK10C	EURO4H
PANASONIC	TX25LK10P	EURO4H
PANASONIC	TX25LK1F	Z8
PANASONIC	TX25LK1F	Z8
PANASONIC	TX25MD1C	EURO2
PANASONIC	TX25MD2C	EURO2
PANASONIC	TX25MD2E	EURO2L
PANASONIC	TX25MD3P	EURO2M

Brand	model	chassis
PANASONIC	TX25MD4P	EURO4
PANASONIC	TX25MK1F	EURO4
PANASONIC	TX25MK1L	EURO4
PANASONIC	TX25MK1P	EURO4
PANASONIC	TX25P22X	MX8
PANASONIC	TX25P92X	MX12
PANASONIC	TX25PX10D	GP2
PANASONIC	TX25PX10F	GP2
PANASONIC	TX25PX10P	GP2
PANASONIC	TX25SL1F	EURO4
PANASONIC	TX25T2C	ALPHA2
PANASONIC	TX25V50T	MX2A
PANASONIC	TX25V70T	MX4
PANASONIC	TX25W2C	ALPHA3 (TNP107...)
PANASONIC	TX25W3C	EURO1
PANASONIC	TX25X1C	ALPHA4
PANASONIC	TX25X2C	ALPHA4
PANASONIC	TX25XD1C	EURO2
PANASONIC	TX25XD2C	EURO2
PANASONIC	TX25XD2F	EURO2
PANASONIC	TX25XD3P	EURO2M
PANASONIC	TX25XD4/A	EURO4
PANASONIC	TX25XD4P	EURO4
PANASONIC	TX25XD60C	EURO3H
PANASONIC	TX25XD90F	EURO5
PANASONIC	TX26LED7F	GLP22
PANASONIC	TX26LX60A	LH59
PANASONIC	TX26LX60F	GLP21
PANASONIC	TX26LX60P	GLP21
PANASONIC	TX26LXD60	GLP21
PANASONIC	TX26T1EE	M16M
PANASONIC	TX26T1EE	M16S
PANASONIC	TX2888UR	ALPHA2
PANASONIC	TX28A1DT	ALPHA2
PANASONIC	TX28A2C	ALPHA3 (TNP107...)

Brand	model	chassis
PANASONIC	TX28A2CX	ALPHA3 (TNP107...)
PANASONIC	TX28AS1	TV9.1
PANASONIC	TX28C1C	ALPHA4
PANASONIC	TX28CK1	Z8
PANASONIC	TX28CK1P	Z8
PANASONIC	TX28CK1P	Z8
PANASONIC	TX28CK2F	Z-M3P
PANASONIC	TX28CK2P	Z-M3P
PANASONIC	TX28CP1	ALPHA4
PANASONIC	TX28D2DP	EURO3H
PANASONIC	TX28DK1	EURO4
PANASONIC	TX28DK2	EURO4
PANASONIC	TX28DK20	EURO4H
PANASONIC	TX28DK20P	EURO4H
PANASONIC	TX28DT2	EURO4D
PANASONIC	TX28DT30C	EURO8
PANASONIC	TX28DTX10C	GP2D
PANASONIC	TX28DTX1C	EURO10D
PANASONIC	TX28EX2000	EURO4
PANASONIC	TX28EX20C	EURO4H
PANASONIC	TX28EX3F	Z8
PANASONIC	TX28G1C	ALPHA2
PANASONIC	TX28J1C	ALPHA2 ?
PANASONIC	TX28LB10	EURO4H
PANASONIC	TX28LB1P	Z8 ?
PANASONIC	TX28LD1C	EURO2
PANASONIC	TX28LD1P	EURO2
PANASONIC	TX28LD2E	EURO2
PANASONIC	TX28LD4P	EURO4
PANASONIC	TX28LD7C	EURO2L
PANASONIC	TX28LD90F	EURO5
PANASONIC	TX28LK1	Z8
PANASONIC	TX28LK10C	EURO4H
PANASONIC	TX28LK10P	EURO4H
PANASONIC	TX28LK1C	Z8

Brand	model	chassis
PANASONIC	TX28LK1F	Z8
PANASONIC	TX28MD3C	EURO2M
PANASONIC	TX28MD3P	EURO2M
PANASONIC	TX28MD4P	EURO4
PANASONIC	TX28MK1	EURO4
PANASONIC	TX28MK1P	EURO4
PANASONIC	TX28PK1	EURO4
PANASONIC	TX28PK10	EURO5L
PANASONIC	TX28PK10F	EURO5L
PANASONIC	TX28PK2	EURO4
PANASONIC	TX28PK20	EURO4H
PANASONIC	TX28PL1	EURO4
PANASONIC	TX28PM11C	GP2
PANASONIC	TX28PM11P	GP4
PANASONIC	TX28PM1C	GP4
PANASONIC	TX28PN1	GP4L
PANASONIC	TX28PN1D	GP4L
PANASONIC	TX28PN1F	GP4L
PANASONIC	TX28PN1P	GP4L
PANASONIC	TX28PS10P	EURO9L
PANASONIC	TX28R4	EURO4
PANASONIC	TX28S1	687G
PANASONIC	TX28S4TP	CP785
PANASONIC	TX28SK10C	EURO4H
PANASONIC	TX28SK1F	Z8
PANASONIC	TX28SL10F	EURO5
PANASONIC	TX28SL1F	EURO4
PANASONIC	TX28W1DT	ALPHA2W
PANASONIC	TX28W2C	ALPHA3 (TNP107...)
PANASONIC	TX28W2S	ALPHA3 (TNP107...)
PANASONIC	TX28W2X	ALPHA3
PANASONIC	TX28W3C	EURO1
PANASONIC	TX28WD1E	EURO2S
PANASONIC	TX28WG25CP	M18W
PANASONIC	TX28X1CP	ALPHA4

Brand	model	chassis
PANASONIC	TX28X2C	ALPHA4
PANASONIC	TX28XD1C	EURO2S
PANASONIC	TX28XD2C	EURO2
PANASONIC	TX28XD2F	EURO2
PANASONIC	TX28XD3P	EURO2M
PANASONIC	TX28XD4/A	EURO4
PANASONIC	TX28XD4P	EURO4
PANASONIC	TX28XD5C	EURO2S ?
PANASONIC	TX28XD60P	EURO3H
PANASONIC	TX28XD70C	EURO3H
PANASONIC	TX28XD90F	EURO5
PANASONIC	TX28XD90P	EURO5L (?)
PANASONIC	TX28XD1C (TX28XD1C)	EURO2
PANASONIC	TX28XDP2C	EURO2
PANASONIC	TX29A3C	EURO1
PANASONIC	TX29AB50D	EURO7
PANASONIC	TX29AB50F	EURO7
PANASONIC	TX29AD10C	E2100
PANASONIC	TX29AD10F	E2100
PANASONIC	TX29AD1P	EURO1M
PANASONIC	TX29AD20C	E2100
PANASONIC	TX29AD2D	EURO2S
PANASONIC	TX29AD2F	EURO2S
PANASONIC	TX29AD30C	E2100
PANASONIC	TX29AD3C	EURO2S
PANASONIC	TX29AD50F	EURO3H
PANASONIC	TX29AD70C	EURO3H
PANASONIC	TX29AD90F	EURO5
PANASONIC	TX29AK1	EURO4
PANASONIC	TX29AK10	EURO5
PANASONIC	TX29AK20C	EURO4H
PANASONIC	TX29AK20D	EURO4H
PANASONIC	TX29AK20F	EURO4H
PANASONIC	TX29AK3D	EURO4
PANASONIC	TX29AK3F	EURO4

Brand	model	chassis
PANASONIC	TX29AK40	EURO7
PANASONIC	TX29AK40	EURO7
PANASONIC	TX29AP300	E2100 (100Hz)
PANASONIC	TX29AS1	EURO4
PANASONIC	TX29AS10C	EURO4H
PANASONIC	TX29AS10P	EURO4H
PANASONIC	TX29AS1P	EURO4
PANASONIC	TX29B50F/P	EURO7
PANASONIC	TX29F155T	GP2
PANASONIC	TX29GA30X	M18 (?)
PANASONIC	TX29GF35T	M18
PANASONIC	TX29GF85T	M18
PANASONIC	TX29P100T	MD2
PANASONIC	TX29P100X	MD2 (?)
PANASONIC	TX29P10T	MD2L
PANASONIC	TX29P180X	MD3N
PANASONIC	TX29P200X	EURO7
PANASONIC	TX29P250T	EURO7
PANASONIC	TX29P700T	GP1
PANASONIC	TX29P800T	GP11
PANASONIC	TX29P80T	MX10
PANASONIC	TX29P90T	GP3
PANASONIC	TX29PM11D	GP2
PANASONIC	TX29PM11F	GP2 !
PANASONIC	TX29PM11P	GP2 !
PANASONIC	TX29PM11P	GP4 ?
PANASONIC	TX29PM1F	CP521F
PANASONIC	TX29PM1P	CP521F
PANASONIC	TX29PN1D	GP4L
PANASONIC	TX29PN1F	GP4L
PANASONIC	TX29PN1P	GP4L
PANASONIC	TX29PN1P	GP4L ?
PANASONIC	TX29PS10P	EURO9L
PANASONIC	TX29PS11P	GP2
PANASONIC	TX29PS12	CP830FP

Brand	model	chassis
PANASONIC	TX29PS12P	CP830FP
PANASONIC	TX29PS1D	EURO10
PANASONIC	TX29PS1F	EURO10
PANASONIC	TX29PS1P	EURO10
PANASONIC	TX29PS1P/B	EURO10
PANASONIC	TX29PS2D	GP3 ?
PANASONIC	TX29PS2P	GP3
PANASONIC	TX29PS2P/B	GP3
PANASONIC	TX29PS72X	MX12
PANASONIC	TX29PX10P	EURO9L
PANASONIC	TX29PX15P	GP2N
PANASONIC	TX29PX20P	EURO9S
PANASONIC	TX29S90X	MX4
PANASONIC	TX29V30XE	M16MV3 ?
PANASONIC	TX29V50T	MX2A
PANASONIC	TX32DK1	EURO4
PANASONIC	TX32DK1F	EURO4
PANASONIC	TX32DK1L	EURO4
PANASONIC	TX32DK2	EURO4
PANASONIC	TX32DK20	EURO4H
PANASONIC	TX32DT2	EURO4D
PANASONIC	TX32DT30C	EURO8
PANASONIC	TX32DTM40D	EURO9D
PANASONIC	TX32DTX10C	GP2D
PANASONIC	TX32DTX1C	EURO10D
PANASONIC	TX32DTX40C1	EURO9D
PANASONIC	TX32LED7F	GLP22
PANASONIC	TX32LX1F	LH18
PANASONIC	TX32LX60A	LH59
PANASONIC	TX32LX60F	GLP21
PANASONIC	TX32LX60P	GLP21
PANASONIC	TX32LXD1	EURO4 (LH18)
PANASONIC	TX32PB50D	EURO7 (?)
PANASONIC	TX32PD30D	GP1
PANASONIC	TX32PD30P	GP1

Brand	model	chassis
PANASONIC	TX32PD50	GP1
PANASONIC	TX32PD50C	GP1
PANASONIC	TX32PF10	EURO5L
PANASONIC	TX32PF12P	CP830FP
PANASONIC	TX32PG30	EURO7
PANASONIC	TX32PG50	EURO7
PANASONIC	TX32PG50F/P	EURO7
PANASONIC	TX32PK1	EURO4
PANASONIC	TX32PK2	EURO4
PANASONIC	TX32PK20	EURO5
PANASONIC	TX32PK20P	EURO5
PANASONIC	TX32PK25	EURO4H
PANASONIC	TX32PK25P	EURO4H
PANASONIC	TX32PL10	EURO4H
PANASONIC	TX32PL10D	EURO4H
PANASONIC	TX32PL10F	EURO4H
PANASONIC	TX32PM11	GP2
PANASONIC	TX32PM11C	GP2
PANASONIC	TX32PM11P	GP2
PANASONIC	TX32PM1C	GP4
PANASONIC	TX32PS11D	GP2
PANASONIC	TX32PS11P	GP2
PANASONIC	TX32PS12D	CP830
PANASONIC	TX32PS20D	EURO7P
PANASONIC	TX32PX10	EURO9L
PANASONIC	TX32PX10D	EURO9L
PANASONIC	TX32PX10F	EURO9L
PANASONIC	TX32PX10P	EURO10
PANASONIC	TX32PX30	GP1
PANASONIC	TX32PX30p	GP1
PANASONIC	TX32WG25CP	M18W
PANASONIC	TX3370DRS	ALPHA1W
PANASONIC	TX33A2C	ALPHA3 (TNP107...)
PANASONIC	TX33AK10	EURO5L
PANASONIC	TX33GF15P	M17

Brand	model	chassis
PANASONIC	TX33GF85T	M18
PANASONIC	TX33GF85X	M18J
PANASONIC	TX33P100T	MD2
PANASONIC	TX34P150B	MD3A
PANASONIC	TX34P150X	MD3A
PANASONIC	TX34P250T	EURO7
PANASONIC	TX36DT35	EURO8
PANASONIC	TX36P5H00X	EURO7
PANASONIC	TX36PD30P	GP1
PANASONIC	TX36PD50C	GP2
PANASONIC	TX36PF10	EURO5L
PANASONIC	TX36PG50	EURO7
PANASONIC	TX36PL30D	EURO7
PANASONIC	TX36PL32	Euro9S
PANASONIC	TX36PL35P	EURO9S
PANASONIC	TX37A2D	ALPHA3 ?
PANASONIC	TX37A2G	ALPHA3 ?
PANASONIC	TX42PT12FP	EURO7VP
PANASONIC	TX43P15H	E3
PANASONIC	TX43P15HQ	E3
PANASONIC	TX43P15HZ	E3
PANASONIC	TX43P15X	E3
PANASONIC	TX43P250	EURO7VP
PANASONIC	TX43P800HM	GP1VP
PANASONIC	TX43P800HQ	GP1VP
PANASONIC	TX43P800HZ	GP1VP
PANASONIC	TX43P800X	GP1VP
PANASONIC	TX47P500H	EURO7VP
PANASONIC	TX47PT1	EURO5VP
PANASONIC	TX47PT1	EURO5VP
PANASONIC	TX47PT10	EURO7VP
PANASONIC	TX47PT1F	EURO5VP
PANASONIC	TX51P100H,X	E3D
PANASONIC	TX51P15H	E3
PANASONIC	TX51P15HQ	E3

Brand	model	chassis
PANASONIC	TX51P15HZ	E3
PANASONIC	TX51P15X	E3
PANASONIC	TX51P250	EURO7VP
PANASONIC	TX51P800HM	GP1VP
PANASONIC	TX51P800HQ	GP1VP
PANASONIC	TX51P800X	GP1VP
PANASONIC	TX51PS72Z	MX5ZA
PANASONIC	TX60P80Z	MX10
PANASONIC	TX68P150Z	MD3
PANASONIC	TX68P22Z	MX8
PANASONIC	TX68P250Z	EURO7
PANASONIC	TX68P82Z	MX10A
PANASONIC	TX68P88A	MX10
PANASONIC	TX68PS72Z	MX12
PANASONIC	TX76DT30A	EURO8 (EURO8D-pono)
PANASONIC	TX79P100Z	MD2
PANASONIC	TX80P250Z	EURO7
PANASONIC	TX80P300A	EURO7 ?
PANASONIC	TX90U	ALPHA2
PANASONIC	TXG10	AC1
PANASONIC	TXW32R4DP	EURO4
PANTERA	MS21DW	C500 ?
PHANTOM	TV508B	JV845M-2600
PHANTOM	TV565E	JV565E-26M
PHILCO	14FC49	C700 ?
PHILCO	21M49	CM565 (?)
PHILCO	PCM1442	CPH05
PHILCO	PCM2044	CPH05
PHILCO	PCM2144	CPH05
PHILCO	PCR1447	CPH06M
PHILCO	PCR1449	CPH06M
PHILCO	PCR2047	CPH06M
PHILCO	PCR2049	CPH06M
PHILCO	PCS2144	CPH05
PHILCO	PCS2168	CPH05

Brand	model	chassis
PHILCO	PH2190	SN010
PHILCO	PM1414	LA5A
PHILIPS		3A
PHILIPS		A02E
PHILIPS		L01.1E AA
PHILIPS		L05L AA
PHILIPS		L05U AA
PHILIPS		L7.2E
PHILIPS		L9.2
PHILIPS		LC4.1E AB
PHILIPS		LC4.5E AA
PHILIPS		LC4.6E AA
PHILIPS		LC4.7E AA
PHILIPS		LC4.9E AA
PHILIPS		TC4.1U AA (42TD21S9)
PHILIPS	03LC2000	LCD2
PHILIPS	03LC2050	LCD3
PHILIPS	03LC3000	LCD3
PHILIPS	03LC3150	LCD3
PHILIPS	04LC1000	LCD4
PHILIPS	04LC1040	LCD4
PHILIPS	04LC4050	LCD4
PHILIPS	04PL040	04L
PHILIPS	04PL040/08	04LC
PHILIPS	04PL040/10	04L
PHILIPS	08KL2500	LCD2
PHILIPS	08KL3501	LCD3
PHILIPS	107FA4/12	OLD
PHILIPS	107FP4/12	OLD
PHILIPS	10FF2CME/00	10FF2Q
PHILIPS	10FF2CME/05	10FF2Q
PHILIPS	10FF2CME/27	10FF2
PHILIPS	10FF2CMI/00	10FF2Q
PHILIPS	10FF2CMI/05	10FF2Q
PHILIPS	10FF2CMI/27	10FF2

Brand	model	chassis
PHILIPS	10FF2CMW/00	10FF2
PHILIPS	10FF2CMW/05	10FF2
PHILIPS	10FF2CMW/27	10FF2
PHILIPS	10FF2CWO/00	10FF2Q
PHILIPS	10FF2CWO/05	10FF2
PHILIPS	10FF2CWO/27	10FF2
PHILIPS	10FF2M4/00	10FF2Q
PHILIPS	10FF2M4/05	10FF2Q
PHILIPS	10FF2M4/27	10FF2
PHILIPS	10FF2M4/75	10FF2Q
PHILIPS	10FF2M4/78	10FF2
PHILIPS	10FF2M4/93	10FF2Q
PHILIPS	10FF2XLE/00	10FF2
PHILIPS	10FF2XLE/05	10FF2
PHILIPS	10FF2XLE/27	10FF2
PHILIPS	115298/17	OLD
PHILIPS	11CE1211	CP90
PHILIPS	12TX1501	TX1
PHILIPS	13L100/85R	S8 AA
PHILIPS	13L110/35R	L8 AA
PHILIPS	13L110/37R	L8 AA
PHILIPS	13L110/85R	L8 AA
PHILIPS	13L115/35R	L8 AA
PHILIPS	13L115/37R	OLD
PHILIPS	13L115/85R	OLD
PHILIPS	13L130WH/35R	L8 AA
PHILIPS	13L130WH/37R	L8 AA
PHILIPS	13L130WH/85R	OLD
PHILIPS	13L135/85R	OLD
PHILIPS	13LP121HC/35R	OLD
PHILIPS	13LP128PA/35R	L01.2U AA
PHILIPS	13LP21/40A	OLD
PHILIPS	13LT010L/35	L8 AA;S8 AA
PHILIPS	13LT220P/35	OLD
PHILIPS	13MT1431/17	L03.2U AA

Brand	model	chassis
PHILIPS	13MT1431/37R	L03.2U AA
PHILIPS	13MT1432/17	J8 AA
PHILIPS	13MT1433/17	J8 AA
PHILIPS	13MT143S	J8 AA
PHILIPS	13MT1532/17	L03.2U AA
PHILIPS	13MT1533/17	L03.2U AA
PHILIPS	13PF7835/12	LC13E AA
PHILIPS	13PF7835/58	LC13E AA
PHILIPS	140201	CP90
PHILIPS	140201EK	CP90
PHILIPS	141243	ANUBIS A
PHILIPS	141243PP	ANUBIS A
PHILIPS	142021	GR1AX
PHILIPS	142021IR	GR1AX
PHILIPS	142133	ANUBIS A
PHILIPS	142133PP	ANUBIS A
PHILIPS	142401	GR1AX
PHILIPS	142401IR	GR1AX
PHILIPS	142412	G90B
PHILIPS	142412IR	G90B
PHILIPS	142421	GR1AX
PHILIPS	142421IR	GR1AX
PHILIPS	142432	G90B
PHILIPS	142432IR	G90B
PHILIPS	142821	GR1AX
PHILIPS	142912	G90B
PHILIPS	142912IR	G90B
PHILIPS	142921	G90B
PHILIPS	142921IR	G90B
PHILIPS	142932	G90B
PHILIPS	142932IR	G90B
PHILIPS	143243	ANUBIS A
PHILIPS	143243PP	ANUBIS A
PHILIPS	14AA3122	ANUBIS A
PHILIPS	14AA3320	ANUBIS A

Brand	model	chassis
PHILIPS	14AA3322	ANUBIS A
PHILIPS	14AA3324	ANUBIS A
PHILIPS	14AA3326	ANUBIS A
PHILIPS	14AA3327	ANUBIS A
PHILIPS	14AA3329	ANUBIS A
PHILIPS	14AA3527	ANUBIS A
PHILIPS	14CE1000	CP90
PHILIPS	14CE1002	CP90
PHILIPS	14CE1200	CP90
PHILIPS	14CE1201	CP90
PHILIPS	14CE1202	CP90
PHILIPS	14CE1500	CP90
PHILIPS	14CF1014	CF1
PHILIPS	14CF1114	CF1
PHILIPS	14CN2001	NC3CR
PHILIPS	14CN2001/05	NC3CR
PHILIPS	14CN2001/10	NC3CR
PHILIPS	14CN2001/50	NC3CR/S
PHILIPS	14CN2001/65	NC3CR/S
PHILIPS	14CN2001/66	NC3CR/S
PHILIPS	14CN2001/67	NC3CR/S
PHILIPS	14CN2001/68	NC3CR/S
PHILIPS	14CN2002/05	NC3CR
PHILIPS	14CN2002/50	NC3CR/S
PHILIPS	14CN2201	NC3CR
PHILIPS	14CN2201/05	NC3CR
PHILIPS	14CN2201/10	NC3CR
PHILIPS	14CN2201/50	NC3CR/S
PHILIPS	14CN2201/65	NC3CR/S
PHILIPS	14CN2201/68	NC3CR/S
PHILIPS	14CN2201/79	NC3CR/S
PHILIPS	14CN3001	NC3
PHILIPS	14CN3005	NC3
PHILIPS	14CN3015	NC3
PHILIPS	14CN3016	NC3

Brand	model	chassis
PHILIPS	14CN3415	NC3
PHILIPS	14CN3416	NC3
PHILIPS	14CN4010	NCF
PHILIPS	14CN4310	NCF
PHILIPS	14CN4415	NCF
PHILIPS	14CN5418	NC3CR
PHILIPS	14CT2006 - llw.	TX-E
PHILIPS	14CT2006 - lw.	CTX-S
PHILIPS	14CT2206	CTX-E
PHILIPS	14CT4206	KT4
PHILIPS	14CT4406	KT4
PHILIPS	14CT4406-02S	KT4
PHILIPS	14CT5204	KT4M
PHILIPS	14CT5406	KT4M
PHILIPS	14CT6015	CTO-S
PHILIPS	14CT6017	CTO-S
PHILIPS	14CT6018	CTO-S
PHILIPS	14CT6020/50	CTO-S
PHILIPS	14CT6020/51	CTO-N
PHILIPS	14CT6020/65	CTO-S
PHILIPS	14CT6020/67	CTO-S
PHILIPS	14CT6020/68	CTO-S
PHILIPS	14CT6020/70	CTO-S
PHILIPS	14CT6020/81	CTO-N
PHILIPS	14CT6022	CTO-N
PHILIPS	14CT6415	CTO-S
PHILIPS	14CT6416/50	CTO-S
PHILIPS	14CT6416/62T	CTO-N
PHILIPS	14CT6416/67	CTO-S
PHILIPS	14CT6420	CTO-S
PHILIPS	14CT6421	CTO-N
PHILIPS	14GL1311	GR1AL
PHILIPS	14GR1021	GR1AX
PHILIPS	14GR1022	GR1AX
PHILIPS	14GR1022/84	GR1AX-NTS

Brand	model	chassis
PHILIPS	14GR1022/87	GR1AX-NTS
PHILIPS	14GR1023/50	GR1AX
PHILIPS	14GR1023/66	GR1AX
PHILIPS	14GR1023/67	GR1AX
PHILIPS	14GR1023/68	GR1AX
PHILIPS	14GR1023/71	GR1AX-NTS
PHILIPS	14GR1024	GR1AX
PHILIPS	14GR1033	GR1AX
PHILIPS	14GR1034	GR1AX-LA
PHILIPS	14GR1036	GR1AX
PHILIPS	14GR1120	GR1AX
PHILIPS	14GR1220	GR1AX
PHILIPS	14GR1220/11	GR1AX-NTS
PHILIPS	14GR1220/54	GR1AX-LA
PHILIPS	14GR1220/77	GR1AX-LA
PHILIPS	14GR1220/85B	OLD
PHILIPS	14GR1221	GR1AX
PHILIPS	14GR1222	GR1AX
PHILIPS	14GR1222/84	GR1AX-NTS
PHILIPS	14GR1222/87	GR1AX-NTS
PHILIPS	14GR1223	GR1AX
PHILIPS	14GR1223/71	GR1AX-NTS
PHILIPS	14GR1224	GR1AX
PHILIPS	14GR1225	GR1AX
PHILIPS	14GR1227	GR1AX
PHILIPS	14GR1228	GR1AX
PHILIPS	14GR1228/11	GR1AX-NTS
PHILIPS	14GR1229	GR1AX
PHILIPS	14GR1230	GR1AX
PHILIPS	14GR1233	GR1AX
PHILIPS	14GR1234	GR1AX
PHILIPS	14GR1234/54	GR1AX-LA
PHILIPS	14GR1234/77	GR1AX-LA
PHILIPS	14GR1234/85	GR1AX-NTS
PHILIPS	14GR1234/87	GR1AX-NTS

Brand	model	chassis
PHILIPS	14GR1236	GR1AX
PHILIPS	14GR1236/54	GR1AX-LA
PHILIPS	14GR1236/77	GR1AX-LA
PHILIPS	14GR1236/85	GR1AX-NTS
PHILIPS	14GR1236/87	GR1AX-NTS
PHILIPS	14GR1237	GR1AX
PHILIPS	14GR1239	GR1AX
PHILIPS	14GR2125	G90B
PHILIPS	14GR2126	G90B
PHILIPS	14GR2320	G90AE
PHILIPS	14GR2325	G90B
PHILIPS	14GR2326	G90B
PHILIPS	14GR2520	G90AE
PHILIPS	14GX1010	ANUBIS S AA
PHILIPS	14GX1020	ANUBIS S AA
PHILIPS	14GX1310	ANUBIS S AA
PHILIPS	14GX1315	ANUBIS S
PHILIPS	14GX1320	ANUBIS S AA
PHILIPS	14GX1325	ANUBIS S
PHILIPS	14GX1510	ANUBIS S AA
PHILIPS	14GX1510/71R	OLD
PHILIPS	14GX1512	ANUBIS S AA
PHILIPS	14GX1513	ANUBIS S AA
PHILIPS	14GX1515	ANUBIS S CC
PHILIPS	14GX1515/52	ANUBIS S
PHILIPS	14GX1515/58	ANUBIS S
PHILIPS	14GX1515/85	ANUBIS S
PHILIPS	14GX1515/87	ANUBIS S
PHILIPS	14GX1516	ANUBIS S CC
PHILIPS	14GX1517	ANUBIS S CC
PHILIPS	14GX1520	ANUBIS S AA
PHILIPS	14GX1522	ANUBIS S
PHILIPS	14GX1525	ANUBIS S
PHILIPS	14GX1525/71R	OLD
PHILIPS	14GX1527	ANUBIS S

Brand	model	chassis
PHILIPS	14GX1710	ANUBIS S
PHILIPS	14GX1715	ANUBIS S CC
PHILIPS	14GX1810	ANUBIS S AA
PHILIPS	14GX1815	ANUBIS S
PHILIPS	14GX3315	ANUBIS S
PHILIPS	14GX3515	ANUBIS S
PHILIPS	14GX3516	GR1AX
PHILIPS	14GX3516/59R	ANUBIS S CC
PHILIPS	14GX3517	GR1AX
PHILIPS	14GX3715	ANUBIS CC
PHILIPS	14GX7512	ANUBIS S
PHILIPS	14GX8310	ANUBIS DD
PHILIPS	14GX8325	ANUBIS S
PHILIPS	14GX8510	ANUBIS DD
PHILIPS	14GX8510/71R	OLD
PHILIPS	14GX8512	ANUBIS DD
PHILIPS	14GX8525	ANUBIS DD
PHILIPS	14GX8525/71R	OLD
PHILIPS	14GX8527	ANUBIS S
PHILIPS	14HC3252	A7H.1
PHILIPS	14HT3152	A7H.1
PHILIPS	14HT3202	A7H.1
PHILIPS	14HT3252	A7H.1
PHILIPS	14HT3302	A7H.1AA
PHILIPS	14HT3304	L01H.2E AA
PHILIPS	14HT4202	A7H.1
PHILIPS	14KO1401	GR1AX
PHILIPS	14KO1411	GR1AX
PHILIPS	14LJ16	X6 ?
PHILIPS	14LL1701	Y6
PHILIPS	14LL1711	Y6
PHILIPS	14LW1932/87R	OLD
PHILIPS	14LX1703	Y6
PHILIPS	14MS2331/17	L03.2U AA
PHILIPS	14PF6826	LC4.1E

Brand	model	chassis
PHILIPS	14PF6826	TF1.1E AA
PHILIPS	14PF6826/12	OLD
PHILIPS	14PF6826/37	OLD
PHILIPS	14PF6826/69S	OLD
PHILIPS	14PF7846/12	LC4.1E AA
PHILIPS	14PF7846/58	LC4.1E AA
PHILIPS	14PI3601	AA5 AA
PHILIPS	14PT110A	L7L
PHILIPS	14PT111A	L7L
PHILIPS	14PT1120/59A	OLD
PHILIPS	14PT1120/59B	OLD
PHILIPS	14PT1120/59C	OLD
PHILIPS	14PT1120/59R	OLD
PHILIPS	14PT1120/65R	OLD
PHILIPS	14PT1120/67R	OLD
PHILIPS	14PT1120/71R	OLD
PHILIPS	14PT1120/79R	OLD
PHILIPS	14PT118A/75R	L7.1A AA
PHILIPS	14PT121A	GR1AX
PHILIPS	14PT1322	L6.1AA
PHILIPS	14PT132A/50B	L7.1A AA
PHILIPS	14PT132A/50R	L7.1A AA
PHILIPS	14PT132A/60R	L7.1A AA
PHILIPS	14PT132A/75R	L7.1A AA
PHILIPS	14PT1332	L6.1
PHILIPS	14PT1342	L6.1
PHILIPS	14PT1346	L01.2E AA
PHILIPS	14PT1346/58	L01.2E AA;L01.2E AB
PHILIPS	14PT1347	TE1.1E
PHILIPS	14PT1352	L6.1
PHILIPS	14PT1353	L6.1E AA
PHILIPS	14PT1353	L6.2 ?
PHILIPS	14PT1354	L9.2E
PHILIPS	14PT1356	L01.2E AA
PHILIPS	14PT1356/01	L01.2E AA;L01.2E AB

Brand	model	chassis
PHILIPS	14PT1356/05	L01.2E AA;L01.2E AB
PHILIPS	14PT1356/58	L01.2E AA;L01.2E AB
PHILIPS	14PT1358/58	OLD
PHILIPS	14PT135A	ANUBIS A
PHILIPS	14PT135B	AA5 AA
PHILIPS	14PT1361	AA5
PHILIPS	14PT1362	AA5
PHILIPS	14PT1363	L6.1
PHILIPS	14PT1365	L9.2E AB
PHILIPS	14PT136A	ANUBIS A
PHILIPS	14PT136B	AA5 AA
PHILIPS	14PT1382/67R	L7.2A AA
PHILIPS	14PT138A	L7.1A AA (?)
PHILIPS	14PT138A/50B	L7.1A AA
PHILIPS	14PT138A/50R	L7.1A AA
PHILIPS	14PT138A/54R	L7.1A AA
PHILIPS	14PT138A/57R	L7.1A AA
PHILIPS	14PT138A/58H	L7.1A AA
PHILIPS	14PT138A/58R	L7.1A AA
PHILIPS	14PT138A/59B	L7.1A AA
PHILIPS	14PT138A/59H	L7.1A AA
PHILIPS	14PT138A/59R	L7.1A AA
PHILIPS	14PT138A/59T	L7.1A AA
PHILIPS	14PT138A/71R	L7.1A AA
PHILIPS	14PT138A/73R	L7.1A AA
PHILIPS	14PT138A/75R	L7.1A AA
PHILIPS	14PT138A/93S	L7.1A AA
PHILIPS	14PT138A/94R	L7.1A AA
PHILIPS	14PT138A/97R	L7.1A AA
PHILIPS	14PT138B/94I	OLD
PHILIPS	14PT1405/94R	OLD
PHILIPS	14PT1422/50R	L7.1A AA
PHILIPS	14PT1422/68R	L7.1A AA
PHILIPS	14PT1422/75R	L7.1A AA
PHILIPS	14PT1422/75T	L7.1A AA

Brand	model	chassis
PHILIPS	14PT1423/94R	L01.2A AA;L01.2A AB
PHILIPS	14PT1425/94R	OLD
PHILIPS	14PT1482/50B	L7.1A AA
PHILIPS	14PT1482/50R	L7.1A AA
PHILIPS	14PT1482/50T	L7.1A AA
PHILIPS	14PT1482/57R	L7.1A AA
PHILIPS	14PT1482/57T	L7.1A AA
PHILIPS	14PT1482/58R	L7.1A AA
PHILIPS	14PT1482/58T	L7.1A AA
PHILIPS	14PT1482/59B	L7.1A AA
PHILIPS	14PT1482/59M	L7.1A AA
PHILIPS	14PT1482/59T	L7.1A AA
PHILIPS	14PT1482/67R	L7.1A AA
PHILIPS	14PT1482/68R	L7.1A AA
PHILIPS	14PT1482/70R	L7.1A AA
PHILIPS	14PT1482/71R	L7.1A AA
PHILIPS	14PT1482/73R	L7.1A AA
PHILIPS	14PT1482/79R	L7.1A AA
PHILIPS	14PT148A/77B	L7.1A AA
PHILIPS	14PT1501	TE3.2E (Telra PT19)
PHILIPS	14PT1501/12	TE3.2E CA
PHILIPS	14PT1501/62	TE3.2E CA
PHILIPS	14PT151	ANUBIS A
PHILIPS	14PT151A	ANUBIS A
PHILIPS	14PT1521	TE3.2E (Telra PT19)
PHILIPS	14PT1521/12	TE3.2E CA
PHILIPS	14PT1532	L6.1
PHILIPS	14PT1542	L6.1
PHILIPS	14PT1546	L01.2E
PHILIPS	14PT1547	TE1.1E AA
PHILIPS	14PT1552	L6.1
PHILIPS	14PT1553	L6
PHILIPS	14PT1556	L01.2E AB
PHILIPS	14PT1556/01	L01.2E AA;L01.2E AB
PHILIPS	14PT1556/05	L01.2E AA;L01.2E AB

Brand	model	chassis
PHILIPS	14PT1556/21	L01.2E AA;L01.2E AB
PHILIPS	14PT1556/58	L01.2E AA
PHILIPS	14PT155A	ANUBIS A
PHILIPS	14PT155B	AA5 AA
PHILIPS	14PT1562 - llw.	L6.1
PHILIPS	14PT1562 - lw.	AA5
PHILIPS	14PT1563	L6.1
PHILIPS	14PT1564	L9.2
PHILIPS	14PT1565	L9.2
PHILIPS	14PT156A	ANUBIS A
PHILIPS	14PT156B	AA5 AA
PHILIPS	14PT1573	L6.1
PHILIPS	14PT1574	L6.1
PHILIPS	14PT1620/01	L01.2E AA;L01.2E AB
PHILIPS	14PT1620/05	L01.2E AA;L01.2E AB
PHILIPS	14PT1657/01	OLD
PHILIPS	14PT1686/01B	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/01G	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/01P	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/01S	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/01V	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/05B	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/05G	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/05S	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/05V	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/58B	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/58P	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/58S	L01.2E AA;L01.2E AB
PHILIPS	14PT1686/58V	L01.2E AA;L01.2E AB
PHILIPS	14PT1687/01	OLD
PHILIPS	14PT1687/05	OLD
PHILIPS	14PT1687/58	OLD
PHILIPS	14PT2001/59A	L01.2A AA
PHILIPS	14PT2001/59B	L01.2A AA
PHILIPS	14PT2001/59C	L01.2A AA

Brand	model	chassis
PHILIPS	14PT2001/65R	L01.2A AA
PHILIPS	14PT2001/67R	L01.2A AA
PHILIPS	14PT2001/71R	L01.2A AA
PHILIPS	14PT2001/79R	L01.2A AA
PHILIPS	14PT2002	L01.2E
PHILIPS	14PT201	L01.2E
PHILIPS	14PT2010	T1.1A
PHILIPS	14PT2010/69R	T1.1A AA
PHILIPS	14PT2011/71R	L01.2A AA
PHILIPS	14PT2011/74R	L01.2A AA
PHILIPS	14PT2012	L01.2E
PHILIPS	14PT2012/57R	L01.2A AA
PHILIPS	14PT2012/59A	L01.2A AA
PHILIPS	14PT2012/59B	L01.2A AA
PHILIPS	14PT2012/59C	L01.2A AA
PHILIPS	14PT2012/65R	L01.2A AA
PHILIPS	14PT2014	TC2.1A
PHILIPS	14PT2014/56R	TC2.1A AB
PHILIPS	14PT2104/94	OLD
PHILIPS	14PT210A	L7L
PHILIPS	14PT2110	TC2.1A
PHILIPS	14PT2110/56R	TC2.1A AA
PHILIPS	14PT2110/67R	OLD
PHILIPS	14PT2110/69R	TC2.1A AA
PHILIPS	14PT2110/79R	TC2.1A AA
PHILIPS	14PT2115/56	TC2.1A AB
PHILIPS	14PT2115/69	TC2.1A AB
PHILIPS	14PT2116/56	TC2.1A AB
PHILIPS	14PT2116/69	TC2.1A AA
PHILIPS	14PT2117/94	SK4.0A CA
PHILIPS	14PT214B	L9.2A AA
PHILIPS	14PT218A	L01.2L AA
PHILIPS	14PT2204/94	OLD
PHILIPS	14PT228A	L01.2L AA
PHILIPS	14PT230A	ANUBIS S

Brand	model	chassis
PHILIPS	14PT231A	ANUBIS S
PHILIPS	14PT2321/50B	L7.1A AA
PHILIPS	14PT2321/50R	L7.1A AA
PHILIPS	14PT2321/59R	L7.1A AA
PHILIPS	14PT232A	ANUBIS S
PHILIPS	14PT233A/71R	OLD
PHILIPS	14PT2381/54R	L7.1A AA
PHILIPS	14PT2381/58R	L7.1A AA
PHILIPS	14PT2381/59B	L7.1A AA
PHILIPS	14PT2381/59E	OLD
PHILIPS	14PT2381/59R	L7.1A AA
PHILIPS	14PT2381/73R	L7.1A AA
PHILIPS	14PT2381/74R	L7.1A AA
PHILIPS	14PT2381/75R	L7.1A AA
PHILIPS	14PT2381/77B	L7.1A AA
PHILIPS	14PT2381/94R	L7.1A AA
PHILIPS	14PT2382/56R	L7.2A AA
PHILIPS	14PT2382/57R	L7.2A AA
PHILIPS	14PT2382/71R	OLD
PHILIPS	14PT238A	ANUBIS S
PHILIPS	14PT238B/94I	OLD
PHILIPS	14PT2401/94R	L01.2A AA
PHILIPS	14PT2411/94R	OLD
PHILIPS	14PT2622/77B	L7.2A AA
PHILIPS	14PT2663	L6.1
PHILIPS	14PT2665	L9.2E
PHILIPS	14PT2666	L01.2E AA
PHILIPS	14PT2666/01	L01.2E AA;L01.2E AB
PHILIPS	14PT2666/05	L01.2E AA;L01.2E AB
PHILIPS	14PT2666/58	L01.2E AA;L01.2E AB
PHILIPS	14PT2667/01	OLD
PHILIPS	14PT2667/05	OLD
PHILIPS	14PT2667/58	OLD
PHILIPS	14PT2682/57R	L7.2A AA
PHILIPS	14PT2682/77B	L7.2A AA

Brand	model	chassis
PHILIPS	14PT2683	L6...
PHILIPS	14PT3005/44	L03.2L AA
PHILIPS	14PT3005/55	L03.2L AA
PHILIPS	14PT300A	ANUBIS A
PHILIPS	14PT310A	AA5 AA
PHILIPS	14PT3131	L03.1L AA
PHILIPS	14PT3131/77R	OLD
PHILIPS	14PT314A	L9.2A (?)
PHILIPS	14PT318A	L01.2E (?)
PHILIPS	14PT3336	L03.6L
PHILIPS	14PT3336/78	L03.6L CA
PHILIPS	14PT3337/78	UNKNOWN
PHILIPS	14PT3337C/78	UNKNOWN
PHILIPS	14PT3685	L9.3E
PHILIPS	14PT3685/01E	L9.3E AA
PHILIPS	14PT3685/58	OLD
PHILIPS	14PT3722	L9.2A
PHILIPS	14PT3862/69R	L9.3A AA
PHILIPS	14PT3862/79R	L9.3A AA
PHILIPS	14PT4131	L03.1L AA
PHILIPS	14PT4137/77	UNKNOWN
PHILIPS	14PT4137C/77	UNKNOWN
PHILIPS	14PT414A	L9.2E
PHILIPS	14PT418A	L01.2L AA
PHILIPS	14PT428A	L01.2L AA
PHILIPS	14PT519	L01.2L AB 2K2
PHILIPS	14PT519A/44R	OLD
PHILIPS	14PT519A/55R	OLD
PHILIPS	14PT519A/78R	OLD
PHILIPS	14PT519B/77R	OLD
PHILIPS	14PT528A	L01.2L AA
PHILIPS	14PT6007/01	OLD
PHILIPS	14PT6107	TDVD1.1E AA
PHILIPS	14PT6107G/00	TDVD1.1E AA ?
PHILIPS	14PT6441/37	L03.1U AA

Brand	model	chassis
PHILIPS	14PV010	TVCR D (TVCR Delta2000)
PHILIPS	14PV100	TVCR D (TVCR Delta2000)
PHILIPS	14PV101	TVCR D (TVCR Delta2000)
PHILIPS	14PV110	TVCR E (TVCR Epsilon 2001)
PHILIPS	14PV111	Z11 (2002) = MK11 (Funai)
PHILIPS	14PV112	Z11 (2002)
PHILIPS	14PV125	Z12
PHILIPS	14PV162	TVCR B
PHILIPS	14PV162	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV163	TVCR B
PHILIPS	14PV163	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV170	TVCR B
PHILIPS	14PV170	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV172	TVCR B
PHILIPS	14PV172	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV182	TVCR B
PHILIPS	14PV182	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV183	TVCR B
PHILIPS	14PV183	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV200	TVCR D (TVCR Delta2000)
PHILIPS	14PV201	TVCR D (TVCR Delta2000)
PHILIPS	14PV202	TVCR E (TVCR Epsilon 2001)
PHILIPS	14PV202	TVCR EPSILON
PHILIPS	14PV203	Z11 (2002)
PHILIPS	14PV205	EPSILON AB
PHILIPS	14PV210	TVCR D (TVCR Delta2000)
PHILIPS	14PV210	TVCR DELTA99 AA
PHILIPS	14PV211	TVCR D (TVCR Delta2000)
PHILIPS	14PV217	TVCR D (TVCR Delta2000)
PHILIPS	14PV220	TVCR E (TVCR Epsilon 2001)
PHILIPS	14PV220	TVCR E (TVCR Epsilon 2001)
PHILIPS	14PV225	TVCR E (TVCR Epsilon 2001)
PHILIPS	14PV227	TVCR E (TVCR Epsilon 2001)
PHILIPS	14PV263	TVCR B
PHILIPS	14PV263	TVCR MONO98 (TVCR Delta98 ?)

Brand	model	chassis
PHILIPS	14PV264	TVCR B
PHILIPS	14PV264	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV274	TVCR B
PHILIPS	14PV274	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV284	TVCR B
PHILIPS	14PV284	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	14PV320	TVCR D (TVCR Delta2000)
PHILIPS	14PV320	TVCR DELTA99 AA
PHILIPS	14PV325	Delta99
PHILIPS	14PV325	TVCR D (TVCR Delta2000)
PHILIPS	14PV325	TVCR DELTA99 AA
PHILIPS	14PV327	DELTA99
PHILIPS	14PV327	TVCR D (TVCR Delta2000)
PHILIPS	14PV327	TVCR DELTA99 AA
PHILIPS	14PV330	TVCR D (TVCR Delta2000)
PHILIPS	14PV334	TVCR D (TVCR Delta2000)
PHILIPS	14PV335	TVCR D (TVCR Delta2000)
PHILIPS	14PV340	TVCR D (TVCR Delta2000)
PHILIPS	14PV340	TVCR DELTA99 AA
PHILIPS	14PV345	TVCR D (TVCR Delta2000)
PHILIPS	14PV345	TVCR DELTA99 AA
PHILIPS	14PV350	TVCR D (TVCR Delta2000) ?
PHILIPS	14PV350	TVCR E (TVCR Epsilon 2001)
PHILIPS	14PV353	TVCR D (TVCR Delta2000)
PHILIPS	14PV354	TVCR D (TVCR Delta2000)
PHILIPS	14PV354	TVCR E (TVCR Epsilon 2001)
PHILIPS	14PV358	TVCR D (TVCR Delta2000)
PHILIPS	14PV400	TVCR D (TVCR Delta2000)
PHILIPS	14PV404	TVCR D (TVCR Delta2000)
PHILIPS	14PV405	TVCR D (TVCR Delta2000)
PHILIPS	14PV406	TVCR D (TVCR Delta2000)
PHILIPS	14PV415	Z11 (2002)
PHILIPS	14PV460	Z11 (2002)
PHILIPS	14PV465	TVCR D (TVCR Delta2000)
PHILIPS	14PV503	TVCR D (TVCR Delta2000)

Brand	model	chassis
PHILIPS	14PV505	TVCR D (TVCR Delta2000)
PHILIPS	14RFL150/35R	L8 AA
PHILIPS	14RFL150/37C	L03.1U AA
PHILIPS	14RFL150/37R	L8 AA
PHILIPS	14RFL150/85R	L8 AA
PHILIPS	14S11BGY	GR1AX-NTS
PHILIPS	14TVCR240/01N	TVCR B
PHILIPS	14TX1004	TX
PHILIPS	14VCR240	TVCR A
PHILIPS	151001EK	CP90
PHILIPS	151021EK	CP90
PHILIPS	151951EK	CP90
PHILIPS	153233PP	ANUBIS A
PHILIPS	153243PP	ANUBIS A
PHILIPS	153332IR	G90AE
PHILIPS	153732IR	G90B
PHILIPS	153932IR	G90B
PHILIPS	153933PP	ANUBIS A
PHILIPS	15AA3330	ANUBIS A
PHILIPS	15AA3332	ANUBIS A AB
PHILIPS	15AA3334	ANUBIS A
PHILIPS	15AA3336	ANUBIS A
PHILIPS	15AA3537	ANUBIS A
PHILIPS	15AB3536	ANUBIS B
PHILIPS	15CE1010	CP90
PHILIPS	15CE1210	CP90
PHILIPS	15CE1219	CP90
PHILIPS	15CE1510	CP90
PHILIPS	15CE1518	CP90
PHILIPS	15CE1519	CP90
PHILIPS	15CF5218	TVC15
PHILIPS	15CN3425	NC3
PHILIPS	15CN4020	NCF
PHILIPS	15CN4320	NCF
PHILIPS	15CN4321	NCF

Brand	model	chassis
PHILIPS	15CN4420	NCF
PHILIPS	15FT3220/37	LC4.1HU AA
PHILIPS	15FT3230/35	LC13U AA
PHILIPS	15FT9955/35	LC03U AA
PHILIPS	15FT9975/35	LC03U AA
PHILIPS	15GR2130	G90AE
PHILIPS	15GR2330	G90AE
PHILIPS	15GR2331	G90AE
PHILIPS	15GR2336	G90B
PHILIPS	15GR2530	G90AE
PHILIPS	15GR2532	G90AE
PHILIPS	15GR2636	G90B
PHILIPS	15GR2730	G90B
PHILIPS	15HF5443/10	LC4.1HE AB
PHILIPS	15HF7835/22	LC13E AA
PHILIPS	15HF7835/22Z	LC13E AA
PHILIPS	15HF7835/69	LC13A AA
PHILIPS	15HF8442/12	LC4.1E AA
PHILIPS	15HF9936/12	LC03E AA
PHILIPS	15HF9936/12Z	OLD
PHILIPS	15MF050V/17	OLD
PHILIPS	15MF050V/37	OLD
PHILIPS	15MF150V/37	OLD
PHILIPS	15MF170V/17	OLD
PHILIPS	15MF200V/37	OLD
PHILIPS	15MF227B/27	TPM1.0U LA
PHILIPS	15MF237S/27	TPM1.0U LA
PHILIPS	15MF400T/37	TP1.1U EA
PHILIPS	15P6576	TVC15 90 MULTI
PHILIPS	15PF5120/28	ML1.1U AA
PHILIPS	15PF7835/12	LC13E AA
PHILIPS	15PF7835/37	LC13U AA
PHILIPS	15PF7835/58	LC13E AA
PHILIPS	15PF7835/69I	LC13A AA
PHILIPS	15PF7835/69S	LC13A AA

Brand	model	chassis
PHILIPS	15PF7835/93	LC13A AA
PHILIPS	15PF7846	LC4.1E AA (?)
PHILIPS	15PF7846/12	LC4.1E AA
PHILIPS	15PF7846/58	LC4.1E AA
PHILIPS	15PF7946/12	OLD
PHILIPS	15PF8946/12	LC4.1E AA
PHILIPS	15PF8946/37	LC4.1U AA
PHILIPS	15PF8946/58	LC4.1E AA
PHILIPS	15PF8946/78	LC4.1L AA
PHILIPS	15PF8946/P00	OLD
PHILIPS	15PF9225	LCD1.15E
PHILIPS	15PF9925	LC4.1U AA
PHILIPS	15PF9925/12S	LCD1.15E AA
PHILIPS	15PF9935/17S	OLD
PHILIPS	15PF9936	LC03L AA
PHILIPS	15PF9936/12	LC03E AA
PHILIPS	15PF9936/12I	LC03E AA
PHILIPS	15PF9936/37	LC03U AA
PHILIPS	15PF9936/58	LC03E AA
PHILIPS	15PF9936/58I	LC03E AA
PHILIPS	15PF9936/69	LC03A AA
PHILIPS	15PF9936/69I	LC03A AA
PHILIPS	15PF9936/69S	LC03A AA
PHILIPS	15PF9936/93I	LC03A AA
PHILIPS	15PF9945/37	LC03U AA
PHILIPS	15PFL3403/10	UNKNOWN
PHILIPS	15PFL3403D/10	UNKNOWN
PHILIPS	15PFL4122/93	TPS1.0E LA
PHILIPS	15PT136A	ANUBIS A
PHILIPS	15PT136B	AA5 AA
PHILIPS	15PT1563	L7.2E
PHILIPS	15PT156B	AA5 AA
PHILIPS	15PT161A	ANUBIS A
PHILIPS	15PT166A	ANUBIS A
PHILIPS	15PT1767	L01.2E

Brand	model	chassis
PHILIPS	15PT2301/67R	L01.2A AA
PHILIPS	15PT2301/71R	L01.2A AA
PHILIPS	15PT2301/74R	L01.2A AA
PHILIPS	15PT2302	L01.2A
PHILIPS	15PT2302/56A	L01.2A AA
PHILIPS	15PT2302/57R	L01.2A AA
PHILIPS	15PT2302/65R	L01.2A AA
PHILIPS	15PT2302/68R	L01.2A AA
PHILIPS	15PT2302/69R	L01.2A AA
PHILIPS	15PT2302/79R	L01.2A AA
PHILIPS	15PT2441/94R	L01.2A AA
PHILIPS	15PT2966/58	OLD
PHILIPS	15PT2966N/01	OLD
PHILIPS	15PT2966N/58	OLD
PHILIPS	15PT3057/44	UNKNOWN
PHILIPS	15PT3057/55	UNKNOWN
PHILIPS	15PT539A/44R	OLD
PHILIPS	15PT539A/55R	OLD
PHILIPS	15PT539A/77R	OLD
PHILIPS	15PT539A/78R	OLD
PHILIPS	15PT6807/01	TDVD2.1E AA
PHILIPS	15PT6807/01D	TDVD2.1E AA
PHILIPS	15PT6807/01F	TDVD2.1E AA
PHILIPS	15PT6807/01G	TDVD2.1E AA
PHILIPS	15PT6807/01H	TDVD2.1E AA
PHILIPS	15PT6807/01I	TDVD2.1E AA
PHILIPS	15PT6807/01S	TDVD2.1E AA
PHILIPS	15PT6807/05	TDVD2.1E AA
PHILIPS	15PT6807/05N	TDVD2.1E AA
PHILIPS	15PT6807/58	TDVD2.1E AA
PHILIPS	15PT6807B/01	TDVD2.1E AA
PHILIPS	15PT6807F/01	TDVD2.1E AA
PHILIPS	15PT6807I/01	TDVD2.1E AA
PHILIPS	15PT6807I/05	TDVD2.1E AA
PHILIPS	15PT6807N/00	TDVD2.1E AA

Brand	model	chassis
PHILIPS	15PT6807S/01	TDVD2.1E AA
PHILIPS	16CF1016	CF1
PHILIPS	16CT2016/16S	CTX-S
PHILIPS	16CT2216	CTX-E ?
PHILIPS	16CT4216	KT4
PHILIPS	16CT4217	KT4
PHILIPS	16CT4218	KT4
PHILIPS	16CT4416	KT4
PHILIPS	16CT4418	KT4
PHILIPS	16CT4616	KT4
PHILIPS	16CT4718	KT4
PHILIPS	16CT5214	KT4M
PHILIPS	16CT5418	KT4M
PHILIPS	16CT6025/50	CTO-N
PHILIPS	16CT6025/50	CTO-S
PHILIPS	16CT6025/62S	CTO-N
PHILIPS	16CT6025/65	CTO-S
PHILIPS	16CT6025/66	CTO-S
PHILIPS	16CT6025/67	CTO-S
PHILIPS	16CT6025/68	CTO-S
PHILIPS	16CT6026/65	CTO-S
PHILIPS	16CT6026/67	CTO-S
PHILIPS	16CT6026/68	CTO-S
PHILIPS	16CT6026/70	CTO-S
PHILIPS	16CT6026/80	CTO-N
PHILIPS	16CT6425/51	CTO-N
PHILIPS	16CT6425/81	CTO-N
PHILIPS	16CT6426/50	CTO-S
PHILIPS	16CT6426/51	CTO-N
PHILIPS	16CT6426/65	CTO-S
PHILIPS	16CT6426/67	CTO-S
PHILIPS	16CT6426/70	CTO-S
PHILIPS	16CT6426/79	CTO-S
PHILIPS	16CT6426/81	CTO-N
PHILIPS	16CT6427	CTO-N

Brand	model	chassis
PHILIPS	170B4	SH3
PHILIPS	170C4	SH3
PHILIPS	170N4	SH3
PHILIPS	170S4	SH3
PHILIPS	170X4	SH3L
PHILIPS	173101EK	CP90
PHILIPS	173121EK	CP90
PHILIPS	173151EK	CP90
PHILIPS	174243PP	ANUBIS A
PHILIPS	174332IR	G90AE
PHILIPS	174352IR	G90AE
PHILIPS	174932IR	G90B
PHILIPS	174933PP	ANUBIS A
PHILIPS	174962IR	G90B
PHILIPS	17AA3324	ANUBIS A
PHILIPS	17AA3340	ANUBIS A
PHILIPS	17AA3342	ANUBIS A
PHILIPS	17AA3346	ANUBIS A
PHILIPS	17AA3347	ANUBIS A
PHILIPS	17AA3547	ANUBIS A
PHILIPS	17AB3546	ANUBIS B
PHILIPS	17AB3740	ANUBIS B
PHILIPS	17CE1031	CP90NCR
PHILIPS	17CE1230	CP90
PHILIPS	17CE1231	CP90
PHILIPS	17CE1530	CP90
PHILIPS	17CE1531	CP90
PHILIPS	17CE1538	CP90
PHILIPS	17CE1630	CP90
PHILIPS	17CE7530	3A
PHILIPS	17CE7531	3A
PHILIPS	17CE7630	3A
PHILIPS	17FW9955/35	LC03U AA
PHILIPS	17FW9975/35	LC03U AA
PHILIPS	17GR2340	G90AE

Brand	model	chassis
PHILIPS	17GR2341	G90AE
PHILIPS	17GR2346	G90B
PHILIPS	17GR2540	G90AE
PHILIPS	17GR2546	G90B
PHILIPS	17GR2646	G90B
PHILIPS	17GR2730	G90B
PHILIPS	17GR2740	G90B
PHILIPS	17GR2742	G90B
PHILIPS	17GR3342	G90AE
PHILIPS	17HF9945/12	OLD
PHILIPS	17HF9945/12Z	OLD
PHILIPS	17HF9945/22	LC03E AA
PHILIPS	17HF9945/22Z	LC03E AA
PHILIPS	17HF9945/69I	LC03A AA
PHILIPS	17HM8801/12	LC03E AA
PHILIPS	17HT1340	ANUBIS B
PHILIPS	17HT1349	ANUBIS B
PHILIPS	17HT1540	ANUBIS B
PHILIPS	17HT1540/20	ANUBIS B
PHILIPS	17HT1549	ANUBIS B
PHILIPS	17HT3152	A7H.1
PHILIPS	17HT3153	L9H.2E
PHILIPS	17HT3202	A7H.1
PHILIPS	17HT3252	A7H.1
PHILIPS	17HT3253	L9H.2E
PHILIPS	17HT3302	A7H.1
PHILIPS	17HT3352	A7H.1
PHILIPS	17HT3402	A7H.1
PHILIPS	17HT4202	A7H.1
PHILIPS	17HT5403	L9H.2E
PHILIPS	17HT5423	L9H.2E
PHILIPS	17MD250V/17	OLD
PHILIPS	17MD255V/17	17MD255V
PHILIPS	17MF200V/17	OLD
PHILIPS	17MW9010/37	LC03U AA

Brand	model	chassis
PHILIPS	17PF8946/12	LC4.1E AA
PHILIPS	17PF8946/37	LC4.1U AA
PHILIPS	17PF8946/58	LC4.1E AA
PHILIPS	17PF8946/78	LC4.1L AA
PHILIPS	17PF8946/79	LC4.1A AA
PHILIPS	17PF8946A/37	LC03U AA
PHILIPS	17PF9936/37	LC03U AA
PHILIPS	17PF9945	LC03E AA (czy? LC03LAA)
PHILIPS	17PF9945	LC03L AA
PHILIPS	17PF9945/12	LC03E AA
PHILIPS	17PF9945/12I	LC03E AA
PHILIPS	17PF9945/37	LC03U AA
PHILIPS	17PF9945/58	LC03E AA
PHILIPS	17PF9945/58I	LC03E AA
PHILIPS	17PF9945/61I	LC03A AA
PHILIPS	17PF9945/61S	LC03A AA
PHILIPS	17PF9945/69I	LC03A AA
PHILIPS	17PF9945/69S	LC03A AA
PHILIPS	17PF9945/93I	LC03A AA
PHILIPS	17PF9946/12	LC4.2E AA
PHILIPS	17PF9946/37	LC4.2U AA
PHILIPS	17PF9946/79	LC4.2A AA
PHILIPS	17PF9946/98	LC4.2A AA
PHILIPS	17PF9946/P00	OLD
PHILIPS	17PT136A	ANUBIS A
PHILIPS	17PT136A	ANUBIS A
PHILIPS	17PT136B	AA5 AA
PHILIPS	17PT136B	AA5 AB
PHILIPS	17PT1563	L7.2E
PHILIPS	17PT1563	L7.2E AA
PHILIPS	17PT1564	L9.2
PHILIPS	17PT156A	ANUBIS A ?
PHILIPS	17PT156B	AA5 AA
PHILIPS	17PT156B	AA5 AB
PHILIPS	17PT161A	ANUBIS A

Brand	model	chassis
PHILIPS	17PT1666/01	L01.2E AA;L01.2E AB
PHILIPS	17PT1666/05	L01.2E AA;L01.2E AB
PHILIPS	17PT1666/58	L01.2E AA;L01.2E AB
PHILIPS	17PT166A	ANUBIS A
PHILIPS	17PT310A	AA5 AA
PHILIPS	17PT313A	AA5 AA
PHILIPS	190G6FB/05	UNKNOWN
PHILIPS	190VW8FB/96	UNKNOWN
PHILIPS	19F800	F8 (19F8)
PHILIPS	19L110/35R	L8 AA
PHILIPS	19L110/37R	L8 AA
PHILIPS	19L110/85R	L8 AA
PHILIPS	19L111/85R	OLD
PHILIPS	19L115/35R	L8 AA
PHILIPS	19L115/37R	OLD
PHILIPS	19L115/85R	L8 AA
PHILIPS	19L130/35R	L8 AA
PHILIPS	19L130/37R	L8 AA
PHILIPS	19L130/85R	L8 AA
PHILIPS	19L135/37R	S8 AA
PHILIPS	19L135/85R	OLD
PHILIPS	19L140/35R	L8 AA
PHILIPS	19L140/37R	L8 AA
PHILIPS	19L140/85R	L8 AA
PHILIPS	19L145/37R	S8 AA
PHILIPS	19L145/85R	OLD
PHILIPS	19L145R/37R	OLD
PHILIPS	19L150/35R	L8 AA
PHILIPS	19L150/37R	OLD
PHILIPS	19L150/85R	L8 AA
PHILIPS	19LP121HC/35R	OLD
PHILIPS	19LP122PL/17R	OLD
PHILIPS	19LP124CH/35R	OLD
PHILIPS	19LP124N1/35R	OLD
PHILIPS	19LP124PC/17R	OLD

Brand	model	chassis
PHILIPS	19LP21/37R	OLD
PHILIPS	19LP22/37R	OLD
PHILIPS	19LP22/40C	OLD
PHILIPS	19LP24/40C	OLD
PHILIPS	19LP26/40A	OLD
PHILIPS	19LP26/40B	OLD
PHILIPS	19LP26/40C	OLD
PHILIPS	19LP26/40D	OLD
PHILIPS	19LP26/40E	OLD
PHILIPS	19LP26/40F	OLD
PHILIPS	19LT010L/35	L8 AA;S8 AA
PHILIPS	19LT220L/17	L8 AA;S8 AA
PHILIPS	19LT220V/17	OLD
PHILIPS	19MD357B/37	TPM1.0U LA
PHILIPS	19MD358B/37	UNKNOWN
PHILIPS	19MF337B/27	TPM1.0U LA
PHILIPS	19MF338B/27	UNKNOWN
PHILIPS	19PFL3403/10	UNKNOWN
PHILIPS	19PFL3403D/10	UNKNOWN
PHILIPS	19PFL3403D/93	UNKNOWN
PHILIPS	19PFL3603D/10	UNKNOWN
PHILIPS	19PFL4322/45	TPS1.0L LA
PHILIPS	19PFL4322/93	TPS1.0E LA
PHILIPS	19PFL5322/12	LC7.1E LB
PHILIPS	19PFL5323D/27	UNKNOWN
PHILIPS	19PFL5402D/27	TPM1.0U LA
PHILIPS	19PFL5403/77	UNKNOWN
PHILIPS	19PFL5403/78	UNKNOWN
PHILIPS	19PFL5403D/10	UNKNOWN
PHILIPS	19PFL5422D/27	TPM1.0U LA
PHILIPS	19PFL5522D/05	LC7.2E LB
PHILIPS	19PFL5522D/12	LC7.2E LB
PHILIPS	19PFL5602D/05	LC7.2E LB
PHILIPS	19PFL5602D/12	LC7.2E LB
PHILIPS	19PFL5622D/37	TPM1.0U LA

Brand	model	chassis
PHILIPS	19PFL5723D/27	UNKNOWN
PHILIPS	19PR21C121	19J800
PHILIPS	19SL010/37R1	OLD
PHILIPS	19SL010/55R	OLD
PHILIPS	19ST110P/35	L8 AA;S8 AA
PHILIPS	19ST220L/17	19S800
PHILIPS	19ST220L/17	L8 AA;S8 AA
PHILIPS	202644TK	KT4
PHILIPS	202664TK	KT4
PHILIPS	202844TK	KT4
PHILIPS	203664TK	KT4
PHILIPS	205021	GR1AX
PHILIPS	205021IR	GR1AX
PHILIPS	20CE2060	2A
PHILIPS	20CE2240	2A
PHILIPS	20CN4361	NCF-CR
PHILIPS	20CN4362	NCF-CR
PHILIPS	20CN4764	NCF-CR
PHILIPS	20CN6215	NC3
PHILIPS	20CT2235	CTX-E
PHILIPS	20CT4426	KT4
PHILIPS	20CT4428	KT4
PHILIPS	20CT4626	KT4
PHILIPS	20CT4636	KT4
PHILIPS	20CT4726	KT4
PHILIPS	20CT4728	KT4
PHILIPS	20CT5226	KT4M
PHILIPS	20CT5236	KT4M
PHILIPS	20CT5426	KT4M
PHILIPS	20CT5428	KT4M
PHILIPS	20CT5728	KT4M
PHILIPS	20CT6050/50	CTO-S
PHILIPS	20CT6050/51	CTO-N
PHILIPS	20CT6050/65	CTO-S
PHILIPS	20CT6050/67	CTO-S

Brand	model	chassis
PHILIPS	20CT6050/68	CTO-S
PHILIPS	20CT6050/70	CTO-S
PHILIPS	20CT6050/81	CTO-N
PHILIPS	20CT6052	CTO-N
PHILIPS	20CT6160/50	CTO-S
PHILIPS	20CT6160/51	CTO-N
PHILIPS	20CT6160/65	CTO-S
PHILIPS	20CT6160/67	CTO-S
PHILIPS	20CT6160/68	CTO-S
PHILIPS	20CT6250/50	CTO-S
PHILIPS	20CT6250/51	CTO-N
PHILIPS	20CT6250/65	CTO-S
PHILIPS	20CT6250/67	CTO-S
PHILIPS	20CT6250/68	CTO-S
PHILIPS	20CT6250/81	CTO-N
PHILIPS	20CT6350/50	CTO-S
PHILIPS	20CT6350/56	CTO-N
PHILIPS	20CT6350/65	CTO-S
PHILIPS	20CT6350/66	CTO-S
PHILIPS	20CT6360	CTO-S
PHILIPS	20CT6363	CTO-S
PHILIPS	20CT6450/50	CTO-S
PHILIPS	20CT6450/59	CTO-N
PHILIPS	20CT6450/61	CTO-N
PHILIPS	20CT6450/65	CTO-S
PHILIPS	20CT6450/67	CTO-S
PHILIPS	20CT6450/70	CTO-S
PHILIPS	20CT6450/83	CTO-N
PHILIPS	20CT6451	CTO-S
PHILIPS	20CT6550/50	CTO-S
PHILIPS	20CT6550/51	CTO-N
PHILIPS	20CT6550/70	CTO-S
PHILIPS	20CT6550/81	CTO-N
PHILIPS	20CT6750	CTO-S
PHILIPS	20CT6753	CTO-S

Brand	model	chassis
PHILIPS	20CT6760	CTO-S
PHILIPS	20CT6850	CTO-N
PHILIPS	20CT9350/67	CTO-S
PHILIPS	20CT9350/68	CTO-S
PHILIPS	20DV6931/37R	L01.1U AC;L01.2U AA
PHILIPS	20DV6932/37R	L01.1U AC;L01.2U AA
PHILIPS	20DV6941/37	OLD
PHILIPS	20DV6942	TC4.1U
PHILIPS	20DV6942/37	TC4.1U AA
PHILIPS	20FT3010/37	LC13U AA
PHILIPS	20FT3210/35	LC13U AA
PHILIPS	20FT3215/37	LC13U AA
PHILIPS	20FT3220/37	LC4.1HU AA
PHILIPS	20FT3230/35	LC13U AA
PHILIPS	20FT3310/37	LC4.1HU AA
PHILIPS	20FT9955/35	LCD1.20U AA
PHILIPS	20GR1050	GR1AX
PHILIPS	20GR1052	GR1AX
PHILIPS	20GR1055	GR1AX
PHILIPS	20GR1055/55	GR1AX-LA
PHILIPS	20GR1055/77	GR1AX-LA
PHILIPS	20GR1056	GR1AX
PHILIPS	20GR1250	GR1AX
PHILIPS	20GR1252	GR1AX
PHILIPS	20GR1258	GR1AX
PHILIPS	20GR1258	GR1AX
PHILIPS	20GR1259	GR1AX
PHILIPS	20GR1259	GR1AX
PHILIPS	20GR1260	GR1AX
PHILIPS	20GR1355	GR1AX
PHILIPS	20GR1355	GR1AX
PHILIPS	20GR1355/54	GR1AX-LA
PHILIPS	20GR1355/71R	OLD
PHILIPS	20GR1355/77	GR1AX-LA
PHILIPS	20GR1355/85	GR1AX-NTS

Brand	model	chassis
PHILIPS	20GR1355/87	GR1AX-NTS
PHILIPS	20GR1356	GR1AX
PHILIPS	20GR1358	GR1AX
PHILIPS	20GR1359	GR1AX
PHILIPS	20GX1050	ANUBIS S
PHILIPS	20GX1350	ANUBIS S
PHILIPS	20GX1355	ANUBIS S
PHILIPS	20GX1550	ANUBIS S
PHILIPS	20GX1550/71R	OLD
PHILIPS	20GX1552	ANUBIS S
PHILIPS	20GX1553	ANUBIS S
PHILIPS	20GX1555	ANUBIS
PHILIPS	20GX1555/71R	OLD
PHILIPS	20GX1556	ANUBIS S
PHILIPS	20GX1557	ANUBIS S
PHILIPS	20GX1558	ANUBIS S
PHILIPS	20GX1750	ANUBIS S
PHILIPS	20GX1755	ANUBIS S
PHILIPS	20GX1850	ANUBIS S
PHILIPS	20GX1855	ANUBIS S
PHILIPS	20GX3355	ANUBIS S
PHILIPS	20GX3555	ANUBIS S
PHILIPS	20GX35556	ANUBIS S
PHILIPS	20GX3557	ANUBIS S
PHILIPS	20GX3558	ANUBIS S
PHILIPS	20GX3755	ANUBIS S
PHILIPS	20GX8350	ANUBIS S
PHILIPS	20GX8550	ANUBIS S
PHILIPS	20GX8550/71R	OLD
PHILIPS	20GX8552	ANUBIS S
PHILIPS	20HF4003F/10	LC4.1HE AB
PHILIPS	20HF5335D/05	LC7.2E LB
PHILIPS	20HF5335D/12	LC7.2E LB
PHILIPS	20HF5473/10	LC4.1HE AB
PHILIPS	20HF5474/10	LC4.1HE AB

Brand	model	chassis
PHILIPS	20HF7462/12	LC4.1HE AA
PHILIPS	20HF7835/22	LC13E AA
PHILIPS	20HF7835/22Z	LC13E AA
PHILIPS	20HF7835/69	LC13A AA
PHILIPS	20HF8432/11	LC4.1HE AA
PHILIPS	20HF8432/98	LC4.1HA AA
PHILIPS	20HF9925/12Z	LCD1.20E AA
PHILIPS	20HF9925/19Z	LCD1.20E AA
PHILIPS	20HF9925/35	LCD1.20U AA
PHILIPS	20HT1582	L9H.2A
PHILIPS	20HT1582/59Z	L9H.2A AA
PHILIPS	20HT1582/67Z	L9H.2A AA
PHILIPS	20HT1582/68Z	L9H.2A AA
PHILIPS	20HT1582/71Z	L9H.2A AA
PHILIPS	20HT1582/75Z	L9H.2A AA
PHILIPS	20HT1782/94R	OLD
PHILIPS	20HT1782/94Z	L9H.2A AA
PHILIPS	20HT2001/94Z	L01H.2A AA
PHILIPS	20HT3153	L9H.2E AA
PHILIPS	20HT3253	L9H.2E
PHILIPS	20HT3303	L9H.2E
PHILIPS	20HT3782/94Z	L9H.2A AA
PHILIPS	20HT4203	L9H.2E
PHILIPS	20HT4331/78S	OLD
PHILIPS	20HT528A/78H	OLD
PHILIPS	20HT528A/78S	OLD
PHILIPS	20KO2011	GR1AX
PHILIPS	20L135/37R	S8 AA
PHILIPS	20L140/35R	S8 AA
PHILIPS	20L140/37C	L03.1U AA
PHILIPS	20L145/37R	S8 AA
PHILIPS	20LCD35	LC4.1U AA
PHILIPS	20LL200122	19L800 (inaczej: ch. 19L8)
PHILIPS	20LL26-0121	GR5A ?
PHILIPS	20LL2701	Y6

Brand	model	chassis
PHILIPS	20LL2711	Y6
PHILIPS	20LW202222	19L800 (inaczej: ch. 19L8); ale raczej: 20L800
PHILIPS	20LX27	19Y6 ?
PHILIPS	20LX2703	Y6
PHILIPS	20MF200V/17	OLD
PHILIPS	20MF251W/37	SHA2.0U LA
PHILIPS	20MG2049	GR1AX
PHILIPS	20MS2331/17	L03.2U AA
PHILIPS	20MS2331/37R	L03.2U AA
PHILIPS	20MS233S	J8 AA
PHILIPS	20MS3341/37C	L03.1U AA
PHILIPS	20MS3442/17	TC3.1U AA
PHILIPS	20MT1331/17	L03.2U AA
PHILIPS	20MT1336/37	L03.2U AA
PHILIPS	20MT133S	J8 AA
PHILIPS	20MT4405/17	L03.1U AA
PHILIPS	20PA155A	ANUBIS A
PHILIPS	20PF1000/62	TEH1.0E LA
PHILIPS	20PF4110/37	OLD
PHILIPS	20PF4124/01	LC4.1E
PHILIPS	20PF5120/28	ML1.1U AA
PHILIPS	20PF5120/79	ML1.1A AA
PHILIPS	20PF5120/93	ML1.1A AA
PHILIPS	20PF5120/98	ML1.1A AA
PHILIPS	20PF5121/77	LC4.1L AA
PHILIPS	20PF5121/78	LC4.1L AA
PHILIPS	20PF7835	LC13E AA (?)
PHILIPS	20PF7835/12	LC13E AA
PHILIPS	20PF7835/37	LC13U AA
PHILIPS	20PF7835/58	LC13E AA
PHILIPS	20PF7835/69I	LC13A AA
PHILIPS	20PF7835/69S	LC13A AA
PHILIPS	20PF7835/93	LC13A AA
PHILIPS	20PF7846	LC4.1AA
PHILIPS	20PF7846/12	LC4.1E AA

Brand	model	chassis
PHILIPS	20PF7846/58	LC4.1E AA
PHILIPS	20PF7846/P00	OLD
PHILIPS	20PF8846/12	LC4.1E AA
PHILIPS	20PF8846/58	LC4.1E AA
PHILIPS	20PF8846/79	LC4.1A AA
PHILIPS	20PF8846/93	OLD
PHILIPS	20PF8846/98	LC4.1A AA
PHILIPS	20PF8946/37	LC4.1U AA
PHILIPS	20PF8946/78	LC4.1L AA
PHILIPS	20PF8946/93	LC4.1A AA
PHILIPS	20PF9925	LC4.1U AA
PHILIPS	20PF9925	LCD1.20E
PHILIPS	20PF9925/17S	LCD1.20U AA
PHILIPS	20PF9935/17S	OLD
PHILIPS	20PFL3403/10	UNKNOWN
PHILIPS	20PFL3403D/10	UNKNOWN
PHILIPS	20PFL4122/79	TPS1.0A LA
PHILIPS	20PFL4122/93	TPS1.0A LA
PHILIPS	20PFL4122/93	TPS1.0E LA
PHILIPS	20PFL4122/98	TPS1.0A LA
PHILIPS	20PFL5122/01	LC4.1E AC
PHILIPS	20PFL5122/58	LC4.1E AC
PHILIPS	20PFL5122/77	LC4.1L AA
PHILIPS	20PFL5122/78	LC4.1L AA
PHILIPS	20PFL5403D/10	UNKNOWN
PHILIPS	20PFL5522D/05	LC7.2E LB
PHILIPS	20PFL5522D/12	LC7.2E LB
PHILIPS	20PS40S	LC4.1U AA
PHILIPS	20PS47S	LC4.1U AA
PHILIPS	20PT1120/59A	OLD
PHILIPS	20PT1120/59B	OLD
PHILIPS	20PT1120/59C	OLD
PHILIPS	20PT1120/59S	OLD
PHILIPS	20PT1120/65R	OLD
PHILIPS	20PT1120/67R	OLD

Brand	model	chassis
PHILIPS	20PT1120/71R	OLD
PHILIPS	20PT1120/73R	OLD
PHILIPS	20PT1120/79R	OLD
PHILIPS	20PT118A	L7.1A
PHILIPS	20PT118A/73R	L7.1A AA
PHILIPS	20PT118A/75R	L7.1A AA
PHILIPS	20PT120A	L7.1
PHILIPS	20PT120A	L7L
PHILIPS	20PT121A	L7L
PHILIPS	20PT132A	L7.1A
PHILIPS	20PT132A/50R	L7.1A AA
PHILIPS	20PT132A/60R	L7.1A AA
PHILIPS	20PT132A/75R	L7.1A AA
PHILIPS	20PT1342	L6.1
PHILIPS	20PT1346/01	L01.2E AA;L01.2E AB
PHILIPS	20PT1346/58	L01.2E AA;L01.2E AB
PHILIPS	20PT1352	L6.1
PHILIPS	20PT1353	L6.2
PHILIPS	20PT1353/00	L6.2 AA
PHILIPS	20PT1353/01	L6.2 AA
PHILIPS	20PT1353/58	L6.2 AA
PHILIPS	20PT1353/58S	L6.2 AA
PHILIPS	20PT1354	L9.2E
PHILIPS	20PT135A	ANUBIS A
PHILIPS	20PT135B	AA5 AA
PHILIPS	20PT138/P00	OLD
PHILIPS	20PT1382/67R	L7.2A AA
PHILIPS	20PT138A	L7.1A
PHILIPS	20PT138A/50B	L7.1A AA
PHILIPS	20PT138A/50R	L7.1A AA
PHILIPS	20PT138A/54R	L7.1A AA
PHILIPS	20PT138A/57R	L7.1A AA
PHILIPS	20PT138A/58H	L7.1A AA
PHILIPS	20PT138A/58R	L7.1A AA
PHILIPS	20PT138A/59B	L7.1A AA

Brand	model	chassis
PHILIPS	20PT138A/59H	L7.1A AA
PHILIPS	20PT138A/59R	L7.1A AA
PHILIPS	20PT138A/71R	L7.1A AA
PHILIPS	20PT138A/73R	L7.1A AA
PHILIPS	20PT138A/75R	L7.1A AA
PHILIPS	20PT138A/97R	L7.1A AA
PHILIPS	20PT138B/94I	OLD
PHILIPS	20PT1422	L7.1A
PHILIPS	20PT1422/50R	L7.1A AA
PHILIPS	20PT1422/59R	L7.1A AA
PHILIPS	20PT1433/94R	L01.2A AA;L01.2A AB
PHILIPS	20PT1482	L7.1A
PHILIPS	20PT1482/50B	L7.1A AA
PHILIPS	20PT1482/50R	L7.1A AA
PHILIPS	20PT1482/57R	L7.1A AA
PHILIPS	20PT1482/59B	L7.1A AA
PHILIPS	20PT1482/59M	L7.1A AA
PHILIPS	20PT1482/59R	L7.1A AA
PHILIPS	20PT1482/67R	L7.1A AA
PHILIPS	20PT1482/68R	L7.1A AA
PHILIPS	20PT1482/70R	L7.1A AA
PHILIPS	20PT1482/71R	L7.1A AA
PHILIPS	20PT1482/73R	L7.1A AA
PHILIPS	20PT1482/79R	L7.1A AA
PHILIPS	20PT1482/97R	L7.1A AA
PHILIPS	20PT148A/77B	L7.1A AA
PHILIPS	20PT150A	ANUBIS A
PHILIPS	20PT1542	L6.1
PHILIPS	20PT1546	L01.2E AA
PHILIPS	20PT1546	L6.1 ?
PHILIPS	20PT1546/01	L01.2E AA;L01.2E AB
PHILIPS	20PT1546/05	L01.2E AA;L01.2E AB
PHILIPS	20PT1546/58	L01.2E AA;L01.2E AB
PHILIPS	20PT1547	TE1.1E (?)
PHILIPS	20PT1552	L6.1

Brand	model	chassis
PHILIPS	20PT1553	L6.1
PHILIPS	20PT1553/00	L6.2 AA
PHILIPS	20PT1553/01	L6.2 AA
PHILIPS	20PT1553/07	L6.2 AA
PHILIPS	20PT1553/11	L6.2 AA
PHILIPS	20PT1553/58	L6.2 AA
PHILIPS	20PT1553/58H	L6.2 AA
PHILIPS	20PT1554	L9.2E
PHILIPS	20PT155A	ANUBIS A
PHILIPS	20PT155B	AA5 AA
PHILIPS	20PT1582	L9.2A
PHILIPS	20PT2001/59A	L01.2A AA
PHILIPS	20PT2001/59B	L01.2A AA
PHILIPS	20PT2001/59C	L01.2A AA
PHILIPS	20PT2001/59S	L01.2A AA
PHILIPS	20PT2001/65R	L01.2A AA
PHILIPS	20PT2001/67R	L01.2A AA
PHILIPS	20PT2001/71R	L01.2A AA
PHILIPS	20PT2001/79R	L01.2A AA
PHILIPS	20PT2004/94R	L01.2A AA;L01.2A AB
PHILIPS	20PT2005/94R	UNKNOWN
PHILIPS	20PT2011/67R	L01.2A AA
PHILIPS	20PT2011/71R	L01.2A AA
PHILIPS	20PT2011/74R	L01.2A AA
PHILIPS	20PT2012/59A	L01.2A AA
PHILIPS	20PT2012/59B	L01.2A AA
PHILIPS	20PT2012/59C	L01.2A AA
PHILIPS	20PT2012/59S	L01.2A AA
PHILIPS	20PT2012/65R	L01.2A AA
PHILIPS	20PT2104/94	OLD
PHILIPS	20PT2123/67R	OLD
PHILIPS	20PT2151/67R	L01.2A AA
PHILIPS	20PT2151/71R	L01.2A AA
PHILIPS	20PT2151/74R	L01.2A AA
PHILIPS	20PT2152/65R	L01.2A AA

Brand	model	chassis
PHILIPS	20PT2152/68R	L01.2A AA
PHILIPS	20PT2152/69R	L01.2A AA
PHILIPS	20PT220A	L7L
PHILIPS	20PT228A	L01.2L
PHILIPS	20PT2381	L7.1A
PHILIPS	20PT2381/50B	L7.1A AA
PHILIPS	20PT2381/50R	L7.1A AA
PHILIPS	20PT2381/54R	L7.1A AA
PHILIPS	20PT2381/58H	L7.1A AA
PHILIPS	20PT2381/58R	L7.1A AA
PHILIPS	20PT2381/59B	L7.1A AA
PHILIPS	20PT2381/59M	L7.1A AA
PHILIPS	20PT2381/59R	L7.1A AA
PHILIPS	20PT2381/59S	L7.1A AA
PHILIPS	20PT2381/67R	L7.1A AA
PHILIPS	20PT2381/70B	L7.1A AA
PHILIPS	20PT2381/73R	L7.1A AA
PHILIPS	20PT2381/75R	L7.1A AA
PHILIPS	20PT2381/77B	L7.1A AA
PHILIPS	20PT2382	L7.1A
PHILIPS	20PT2382/56R	L7.2A AA
PHILIPS	20PT2382/57R	L7.2A AA
PHILIPS	20PT2382/71R	L7.2A AA
PHILIPS	20PT2401/94R	L01.2A AA
PHILIPS	20PT2401/94T	OLD
PHILIPS	20PT2411/94R	L01.2A AA
PHILIPS	20PT2411/94T	OLD
PHILIPS	20PT2423/94R	L01.2A AA;L01.2A AB
PHILIPS	20PT2682	L7.2A
PHILIPS	20PT2682/67R	L7.2A AA
PHILIPS	20PT2682/77B	L7.2A AA
PHILIPS	20PT2682/97R	L7.1A
PHILIPS	20PT2682/97R	L7.2A AA
PHILIPS	20PT2722	L7.1A
PHILIPS	20PT2722/50R	L7.1A AA

Brand	model	chassis
PHILIPS	20PT2782	L7.1A
PHILIPS	20PT2782/50R	L7.1A AA
PHILIPS	20PT2782/57R	L7.1A AA
PHILIPS	20PT2782/59E	L7.1A AA
PHILIPS	20PT2782/59M	L7.1A AA
PHILIPS	20PT2782/59R	L7.1A AA
PHILIPS	20PT2782/65R	L7.1A AA
PHILIPS	20PT2782/67R	L7.1A AA
PHILIPS	20PT2782/68R	L7.1A AA
PHILIPS	20PT2782/71R	L7.1A AA
PHILIPS	20PT2782/73R	L7.1A AA
PHILIPS	20PT2782/94R	L7.1A AA
PHILIPS	20PT2822/77B	L7.2A AA
PHILIPS	20PT2882	L7.1A
PHILIPS	20PT2882/57R	L7.2A AA
PHILIPS	20PT2882/65R	L7.2A AA
PHILIPS	20PT2882/67R	L7.2A AA
PHILIPS	20PT2882/71R	L7.2A AA
PHILIPS	20PT2882/97R	L7.2A AA
PHILIPS	20PT324A	77B ?
PHILIPS	20PT326A	L9.2A
PHILIPS	20PT326A/44R	OLD
PHILIPS	20PT3331	L03.1L AA
PHILIPS	20PT3331 - Ilw.	L03.1E AA
PHILIPS	20PT3336	L03.6L
PHILIPS	20PT3336/78	L03.6L CA
PHILIPS	20PT3722	L9.2A
PHILIPS	20PT3732/67R	OLD
PHILIPS	20PT3732/71R	OLD
PHILIPS	20PT3742	L9.2A
PHILIPS	20PT3742/59A	OLD
PHILIPS	20PT3742/59B	OLD
PHILIPS	20PT3742/59C	OLD
PHILIPS	20PT3822	L9.2A
PHILIPS	20PT3832/67R	OLD

Brand	model	chassis
PHILIPS	20PT3842	L9.2A
PHILIPS	20PT3842/68R	OLD
PHILIPS	20PT3842/69R	OLD
PHILIPS	20PT424A	L9.2A
PHILIPS	20PT428A	L01.2L
PHILIPS	20PT428B/77R	OLD
PHILIPS	20PT4331	L03.1L AA
PHILIPS	20PT524A	L9.2A
PHILIPS	20PT524A/44R	OLD
PHILIPS	20PT524A/55R	OLD
PHILIPS	20PT528A	L01.2L
PHILIPS	20PT528B/77R	OLD
PHILIPS	20PT529	L01.2L (?)
PHILIPS	20PT529A	L01.2L AB ?
PHILIPS	20PT529A/55R	OLD
PHILIPS	20PT529A/78R	OLD
PHILIPS	20PT5441/37	L03.1U AA
PHILIPS	20PT6245/37	L03.1U AA
PHILIPS	20PT6331/37C	L03.1U AA
PHILIPS	20PT633R	L03.1U AA
PHILIPS	20PT6341/35R	L01.2U
PHILIPS	20PT6341/37	L03.1U
PHILIPS	20PT6341/37	L03.1U AA
PHILIPS	20PT6341/37R	L01.2U
PHILIPS	20PT6431	L01.2U !
PHILIPS	20PT6431	L03.1U !
PHILIPS	20PT6431/37C	L03.1U AA
PHILIPS	20PT643R	L03.1U AA
PHILIPS	20PT6441/37	L03.1U AA
PHILIPS	20PT6446/37	L03.1U AA
PHILIPS	20PT653R	L03.1U AA
PHILIPS	20PT9007D/17	TC6.1U CA
PHILIPS	20PV162	TVCR B
PHILIPS	20PV164	TVCR B
PHILIPS	20PV164	TVCR MONO98 (TVCR Delta98 ?)

Brand	model	chassis
PHILIPS	20PV184	TVCR B
PHILIPS	20PV184	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	20PV210	TVCR D (TVCR Delta2000)
PHILIPS	20PV220	TVCR D (TVCR Delta2000)
PHILIPS	20PV220	TVCR DELTA99 AA
PHILIPS	20PV230	TVCR E (TVCR Epsilon 2001)
PHILIPS	20RF050/85R	OLD
PHILIPS	20RFL160/35R	M8 AA
PHILIPS	20RFL160/37R	M8 AA
PHILIPS	20RFL160/85R	M8 AA
PHILIPS	20RFL250/37R	T8 AA
PHILIPS	20TA1000/93	TPF1.3A LA
PHILIPS	20TA1000/98	TPF1.3A LA
PHILIPS	20TA1600/98	TPF1.3A LA
PHILIPS	20TP4331	L03.1L
PHILIPS	213372SB	GR2.2
PHILIPS	213842SB	GR2.2
PHILIPS	213861SB	GR2.1
PHILIPS	213862SB	GR2.2
PHILIPS	213961SB	GR2.2
PHILIPS	213962SB	GR2.2
PHILIPS	213982SB	GR2.2
PHILIPS	214032EK	2A
PHILIPS	214094SK	KT4-FS/S (System4)
PHILIPS	214624EK	2B
PHILIPS	214724EK	2B
PHILIPS	214924EK	2B
PHILIPS	214924WR	2B-F
PHILIPS	215024WR	2B
PHILIPS	215033PP	ANUBIS A
PHILIPS	215051EK	CP90
PHILIPS	215054EK	2B
PHILIPS	215101EK	CP90
PHILIPS	215121EK	CP90
PHILIPS	215151EK	CP90

Brand	model	chassis
PHILIPS	215162IR	G90B
PHILIPS	215172IR	G90B
PHILIPS	215312IR	G90AE
PHILIPS	215332IR	G90AE
PHILIPS	215333PQ	ANUBIS B
PHILIPS	215352IR	G90AE
PHILIPS	215433PQ	ANUBIS B
PHILIPS	215482IR	G90B
PHILIPS	215572IR	G90B
PHILIPS	215732IR	G90B
PHILIPS	215752IR	G90B
PHILIPS	215762IR	G90B
PHILIPS	215769IR	G90B
PHILIPS	215779IR	G90B
PHILIPS	215924EK	2B
PHILIPS	215932IR	G90B
PHILIPS	215933PP	ANUBIS A
PHILIPS	215951EK	CP90
PHILIPS	215954EK	2B
PHILIPS	215962IR	G90B
PHILIPS	215962WR	G90B
PHILIPS	215969IR	G90B
PHILIPS	216179IR	G90B
PHILIPS	21A11200	21A90
PHILIPS	21AA3350	ANUBIS A
PHILIPS	21AA3356	ANUBIS A
PHILIPS	21AA3557	ANUBIS A
PHILIPS	21AB3357	ANUBIS B
PHILIPS	21AB3556	ANUBIS B
PHILIPS	21B30300	21B90
PHILIPS	21CE1051	CP90NCR
PHILIPS	21CE1059	CP90
PHILIPS	21CE1250	CP90
PHILIPS	21CE1250/30	CP90-SMD
PHILIPS	21CE1251	CP90

Brand	model	chassis
PHILIPS	21CE1259	CP90
PHILIPS	21CE1550	CP90
PHILIPS	21CE1551	CP90
PHILIPS	21CE1556	CP90
PHILIPS	21CE1557	CP90
PHILIPS	21CE1558	CP90
PHILIPS	21CE1559	CP90
PHILIPS	21CE2340	2A
PHILIPS	21CE2640	2A
PHILIPS	21CE4246	2B
PHILIPS	21CE4247	2B
PHILIPS	21CE4250	2B
PHILIPS	21CE4256	2B
PHILIPS	21CE4259	2B
PHILIPS	21CE4550	2B
PHILIPS	21CE4551	2B
PHILIPS	21CE4556	2B
PHILIPS	21CE4557	2B
PHILIPS	21CE4559	2B
PHILIPS	21CE5551	2B
PHILIPS	21CE5554	2B
PHILIPS	21CE7550	3A
PHILIPS	21CE7551	3A
PHILIPS	21CE7552	3A
PHILIPS	21CE7554	3A
PHILIPS	21CE7649	3A
PHILIPS	21CE7650	3A
PHILIPS	21CE7655	3A
PHILIPS	21CF4550	2B
PHILIPS	21CN4060	NCF
PHILIPS	21CN4460	NCF
PHILIPS	21CN4461	NCF
PHILIPS	21CN4462	NCF CR
PHILIPS	21CN4472	NCF CR
PHILIPS	21CN4760	NCF

Brand	model	chassis
PHILIPS	21CN4762	NCF CR
PHILIPS	21CN4763	NCF
PHILIPS	21CN4765	NCF-CR
PHILIPS	21CN4772	NCF CR
PHILIPS	21CN4775	NCF CR
PHILIPS	21CN6415	NC3
PHILIPS	21CN6515	NC3
PHILIPS	21CT4529	KT4-FS
PHILIPS	21CT4829	KT4-FS
PHILIPS	21CT5529	KT4M-FS
PHILIPS	21CT5829	KT4M-FS
PHILIPS	21CT8870	2B-S
PHILIPS	21CT8873	2B-S
PHILIPS	21CT8874	2B-S
PHILIPS	21CT8880	2B-S
PHILIPS	21CT9060	CTO-N
PHILIPS	21CT9460/50	CTO-S
PHILIPS	21CT9460/56	CTO-N
PHILIPS	21CT9460/65	CTO-S
PHILIPS	21CT9460/67	CTO-S
PHILIPS	21CT9460/68	CTO-S
PHILIPS	21CT9460/70S	CTO-S
PHILIPS	21CT9651	CTO-S
PHILIPS	21CT9760	CTO-S
PHILIPS	21CT9763	CTO-S
PHILIPS	21CT9952	CTO-S
PHILIPS	21CT9953	CTO-S
PHILIPS	21ET2434	GR2.2
PHILIPS	21GR1051	GR1AX
PHILIPS	21GR1251	GR1AX
PHILIPS	21GR1254	GR1AX
PHILIPS	21GR1255	GR1AX
PHILIPS	21GR1257	GR1AX
PHILIPS	21GR1260	GR1AX
PHILIPS	21GR1260/54	GR1AX-LA

Brand	model	chassis
PHILIPS	21GR1260/77	GR1AX-LA
PHILIPS	21GR1260/85	GR1AX-NTS
PHILIPS	21GR1260/87	GR1AX-NTS
PHILIPS	21GR1261	GR1AX
PHILIPS	21GR1268	GR1AX
PHILIPS	21GR1336	GR1AX
PHILIPS	21GR1366	GR1AX
PHILIPS	21GR1369	GR1AX
PHILIPS	21GR1990	G110 S
PHILIPS	21GR2131	GR2.2
PHILIPS	21GR2150	G90AE
PHILIPS	21GR2350	G90AE
PHILIPS	21GR2352	G90AE
PHILIPS	21GR2356	G90B
PHILIPS	21GR2357	G90B
PHILIPS	21GR2396	G90B
PHILIPS	21GR2550	G90AE
PHILIPS	21GR2552	G90AE
PHILIPS	21GR2554	G90AE
PHILIPS	21GR2556	G90B
PHILIPS	21GR2650	G90B
PHILIPS	21GR2651	G90B
PHILIPS	21GR2656	G90B
PHILIPS	21GR2657	G90B
PHILIPS	21GR2750	G90B
PHILIPS	21GR2751	G90B
PHILIPS	21GR2752	G90B
PHILIPS	21GR2753	G90B
PHILIPS	21GR2756	G90B
PHILIPS	21GR2757	G90B
PHILIPS	21GR2937	GR2.2
PHILIPS	21GR2950	G90AE
PHILIPS	21GR5656	G110
PHILIPS	21GR5750	G110
PHILIPS	21GR5856	G110

Brand	model	chassis
PHILIPS	21GR6655	G110-S
PHILIPS	21GR6755	G110-S
PHILIPS	21GR6756	G110
PHILIPS	21GR6761	G110 S
PHILIPS	21GR6762	G111-E
PHILIPS	21GR6763	G110
PHILIPS	21GR9650	G90B
PHILIPS	21GR9651	G90B
PHILIPS	21GR9656	G90B
PHILIPS	21GR9657	G90B
PHILIPS	21GR9750	G90B
PHILIPS	21GR9751	G90B
PHILIPS	21GR9752	G90B
PHILIPS	21GR9753	G90B
PHILIPS	21GR9756	G90B
PHILIPS	21GR9757	G90B
PHILIPS	21GX1560	ANUBIS S
PHILIPS	21GX1560/71R	OLD
PHILIPS	21GX1562	ANUBIS S
PHILIPS	21GX1563	ANUBIS S
PHILIPS	21GX1565	ANUBIS S
PHILIPS	21GX1565/71R	OLD
PHILIPS	21GX1566	ANUBIS S
PHILIPS	21GX1567	ANUBIS S
PHILIPS	21GX1568	ANUBIS S
PHILIPS	21GX1760	ANUBIS S
PHILIPS	21GX1763	ANUBIS S
PHILIPS	21GX1765	ANUBIS S
PHILIPS	21GX1768	ANUBIS S
PHILIPS	21GX1865	ANUBIS S
PHILIPS	21GX1870	ANUBIS S
PHILIPS	21GX1870/93R	ANUBIS S
PHILIPS	21GX1871	ANUBIS S
PHILIPS	21GX1871/93R	ANUBIS S
PHILIPS	21GX1872	ANUBIS S

Brand	model	chassis
PHILIPS	21GX1875	ANUBIS S
PHILIPS	21GX1876	ANUBIS S
PHILIPS	21GX1877	ANUBIS S
PHILIPS	21GX1970	ANUBIS S
PHILIPS	21GX1975	ANUBIS S
PHILIPS	21GX3556	ANUBIS S
PHILIPS	21GX3565	ANUBIS S
PHILIPS	21GX3565/71R	OLD
PHILIPS	21GX3566	ANUBIS S
PHILIPS	21GX3567	ANUBIS S
PHILIPS	21GX3568	ANUBIS S
PHILIPS	21GX3765	ANUBIS S
PHILIPS	21GX3865	ANUBIS S
PHILIPS	21GX8568	ANUBIS S
PHILIPS	21HT1350	ANUBIS B
PHILIPS	21HT1359	ANUBIS B
PHILIPS	21HT1550	ANUBIS B
PHILIPS	21HT1559	ANUBIS B
PHILIPS	21HT1559/20	ANUBIS B
PHILIPS	21HT1582	L9H.2A
PHILIPS	21HT1582/56Y	L9H.2A AA
PHILIPS	21HT1582/59Z	L9H.2A AA
PHILIPS	21HT1582/61R	L9H.2A AA
PHILIPS	21HT1582/67R	L9H.2A AA
PHILIPS	21HT1582/67Z	L9H.2A AA
PHILIPS	21HT1582/75R	L9H.2A AA
PHILIPS	21HT1582/75Z	L9H.2A AA
PHILIPS	21HT1582/93Z	OLD
PHILIPS	21HT2001/59Z	L01H.2A AA
PHILIPS	21HT2001/67Z	L01H.2A AA
PHILIPS	21HT2001/79Z	L01H.2A AA
PHILIPS	21HT2001/93Z	L01H.2A AA
PHILIPS	21HT2001/94Z	L01H.2A AA
PHILIPS	21HT2002/79R	L01H.2A AA
PHILIPS	21HT2017/69Y	L01H.2A AA

Brand	model	chassis
PHILIPS	21HT2017/79Y	L01H.2A AA
PHILIPS	21HT2211/68Z	L01H.1A AA
PHILIPS	21HT2211/69Z	L01H.1A AA
PHILIPS	21HT2211/94Z	L01H.1A AA
PHILIPS	21HT2212/67R	L01H.1A AA
PHILIPS	21HT2212/69R	L01H.1A AA
PHILIPS	21HT3152	A7H.1
PHILIPS	21HT3154	L01H.2E
PHILIPS	21HT3182/93R	L9H.2A AA
PHILIPS	21HT3182/93Z	L9H.2A AA
PHILIPS	21HT3187/93Y	L9H.2A AA
PHILIPS	21HT3202	A7H.1
PHILIPS	21HT3252	A7H.1
PHILIPS	21HT3302	A7H.1AA
PHILIPS	21HT3304	L01H.2E
PHILIPS	21HT3312/69R	L04HA AA
PHILIPS	21HT3312/79R	L04HA AA
PHILIPS	21HT3352	A7H.1
PHILIPS	21HT3402	A7H.1
PHILIPS	21HT3411Z/93	L01H.1A AA;L01H.1A AB
PHILIPS	21HT3411Z/94	L01H.1A AA
PHILIPS	21HT3412Z/94	L01H.2A AA
PHILIPS	21HT3504	L01HE3 1.1
PHILIPS	21HT3552	AA5H.1
PHILIPS	21HT3622	L9H.2A
PHILIPS	21HT3622/57R	L9H.2A AA
PHILIPS	21HT3622/69R	L9H.2A AA
PHILIPS	21HT3627	L9H.2A
PHILIPS	21HT3627/57Y	L9H.2A AA
PHILIPS	21HT3627/69Y	L9H.2A AA
PHILIPS	21HT3627/79Y	L9H.2A AA
PHILIPS	21HT3627/94Y	L9H.2A AA
PHILIPS	21HT3782/71Z	L9H.2A AA
PHILIPS	21HT3942	L9H.1A
PHILIPS	21HT3942/69R	L9H.2A AA

Brand	model	chassis
PHILIPS	21HT3942/69Z	L9H.2A AA
PHILIPS	21HT4404/05	L01H.1E AA;L01H.2E AA
PHILIPS	21HT4431/77H	OLD
PHILIPS	21HT4431/77S	OLD
PHILIPS	21HT538A/77H	OLD
PHILIPS	21HT538A/77S	OLD
PHILIPS	21HT5403	L9H.2E
PHILIPS	21HT5404	L01H.1E
PHILIPS	21HT5405	L04HE AA
PHILIPS	21HT5413	L9H.2E
PHILIPS	21HT5423	L9H.2E
PHILIPS	21HT5432/77H	L01H.1L AA
PHILIPS	21HT5432/77S	L01H.1L AA
PHILIPS	21HT5432/78H	L01H.1L AA
PHILIPS	21HT5432/78S	L01H.1L AA
PHILIPS	21L145/85R	L01.2L AA;L01.2L AB
PHILIPS	21MK2460	MK2
PHILIPS	21MK2760	MK2
PHILIPS	21PD5932/55R	L01.1L AC
PHILIPS	21PD5932/77R	L01.1L AC
PHILIPS	21PD5932/78R	L01.1L AC
PHILIPS	21PD5932/85R	OLD
PHILIPS	21PT1004/94	UNKNOWN
PHILIPS	21PT118A	ANUBIS S
PHILIPS	21PT128A	ANUBIS S AA
PHILIPS	21PT128A/50R	OLD
PHILIPS	21PT129A	ANUBIS A
PHILIPS	21PT131	ANUBIS A
PHILIPS	21PT131A	ANUBIS A
PHILIPS	21PT131B	ANUBIS A
PHILIPS	21PT1320/56A	OLD
PHILIPS	21PT1320/57R	OLD
PHILIPS	21PT1320/59A	L01.1A AB
PHILIPS	21PT1320/59B	L01.1A AB
PHILIPS	21PT1320/59C	L01.1A AB

Brand	model	chassis
PHILIPS	21PT1320/65R	L01.1A AB
PHILIPS	21PT1320/67R	L01.1A AB
PHILIPS	21PT1320/68R	OLD
PHILIPS	21PT1320/69R	OLD
PHILIPS	21PT1320/71R	L01.1A AB
PHILIPS	21PT1320/73R	OLD
PHILIPS	21PT1320/74R	OLD
PHILIPS	21PT1320/79R	L01.1A AB
PHILIPS	21PT1320/93R	OLD
PHILIPS	21PT1320/97R	OLD
PHILIPS	21PT1321	L7.1A
PHILIPS	21PT1321/50B	L7.1A AA
PHILIPS	21PT1321/50R	L7.1A AA
PHILIPS	21PT1321/50T	L7.1A AA
PHILIPS	21PT1321/60R	L7.1A AA
PHILIPS	21PT1321/60T	L7.1A AA
PHILIPS	21PT1321/75R	L7.1A AA
PHILIPS	21PT1321/75T	L7.1A AA
PHILIPS	21PT1323	L1.1A
PHILIPS	21PT1323/56R	L01.1A AC;L2K3 AA
PHILIPS	21PT1323/56S	L01.1A AC;L2K3 AA
PHILIPS	21PT1323/67R	L01.1A AC;L2K3 AA
PHILIPS	21PT1323/69R	L01.1A AC;L2K3 AA
PHILIPS	21PT1323/69S	L01.1A AC;L2K3 AA
PHILIPS	21PT1323/71R	L01.1A AC;L2K3 AA
PHILIPS	21PT1323/79R	L01.1A AC;L2K3 AA
PHILIPS	21PT132A	ANUBIS S
PHILIPS	21PT1331/69R	OLD
PHILIPS	21PT1332	L6.1
PHILIPS	21PT133A	ANUBIS S
PHILIPS	21PT1342	L6.1
PHILIPS	21PT1346/58	L01.2E AA;L01.2E AB
PHILIPS	21PT1346/58T	L01.2E AA;L01.2E AB
PHILIPS	21PT134B	ANUBIS A
PHILIPS	21PT1352	L6.2

Brand	model	chassis
PHILIPS	21PT1353	L6.2
PHILIPS	21PT1353/01	L6.2 AA
PHILIPS	21PT1353/58	L6.2 AA
PHILIPS	21PT1353/58P	L6.2 AA
PHILIPS	21PT1353/78	L6.2 AA
PHILIPS	21PT1353/78P	L6.2 AA
PHILIPS	21PT1354	L9.2E
PHILIPS	21PT1356	L01.2E AA
PHILIPS	21PT1356/01	L01.2E AA;L01.2E AB
PHILIPS	21PT1356/58	L01.2E AA;L01.2E AB
PHILIPS	21PT1357/01	L01.2E AA;L01.2E AB
PHILIPS	21PT135A	ANUBIS A
PHILIPS	21PT135B	AA5 AA
PHILIPS	21PT136A	ANUBIS A
PHILIPS	21PT136B	AA5 AA
PHILIPS	21PT137A	ANUBIS S
PHILIPS	21PT1381	L7.1A
PHILIPS	21PT1381/50B	L7.1A AA
PHILIPS	21PT1381/50R	L7.1A AA
PHILIPS	21PT1381/50T	L7.1A AA
PHILIPS	21PT1381/57R	L7.1A AA
PHILIPS	21PT1381/58R	L7.1A AA
PHILIPS	21PT1381/58T	L7.1A AA
PHILIPS	21PT1381/59B	L7.1A AA
PHILIPS	21PT1381/59H	L7.1A AA
PHILIPS	21PT1381/59R	L7.1A AA
PHILIPS	21PT1381/59T	L7.1A AA
PHILIPS	21PT1381/70B	L7.1A AA
PHILIPS	21PT1381/71R	L7.1A AA
PHILIPS	21PT1381/75R	L7.1A AA
PHILIPS	21PT1381/77B	L7.1A AA
PHILIPS	21PT1382/67R	L7.2A AA
PHILIPS	21PT1382/67S	L7.2A AA
PHILIPS	21PT138A	ANUBIS S
PHILIPS	21PT1423/94R	L01.2A AA;L01.2A AB

Brand	model	chassis
PHILIPS	21PT1532	L6.1
PHILIPS	21PT1532/94R	OLD
PHILIPS	21PT1542	L6.1
PHILIPS	21PT1546	L01.2E AA
PHILIPS	21PT1546/58	L01.2E AA;L01.2E AB
PHILIPS	21PT1546/58A	L01.2E AA;L01.2E AB
PHILIPS	21PT1546/58S	L01.2E AA;L01.2E AB
PHILIPS	21PT154B	AA5 AB
PHILIPS	21PT1556	L01.2E
PHILIPS	21PT1556/58	L01.2E AA;L01.2E AB
PHILIPS	21PT1557	L01.2E
PHILIPS	21PT1557/01	L01.2E AA;L01.2E AB
PHILIPS	21PT1557/05	L01.2E AA;L01.2E AB
PHILIPS	21PT1582/93R	OLD
PHILIPS	21PT161	ANUBIS A
PHILIPS	21PT1617/60	L01.2A AA;L01.2A AB
PHILIPS	21PT161A	ANUBIS A
PHILIPS	21PT161B	ANUBIS A
PHILIPS	21PT1627/60	L01.2A AA;L01.2A AB
PHILIPS	21PT164	ANUBIS A
PHILIPS	21PT164A	ANUBIS A
PHILIPS	21PT164B	ANUBIS A
PHILIPS	21PT1653	L6.2
PHILIPS	21PT1653/00	L6.2 AA
PHILIPS	21PT1653/01	L6.2 AA
PHILIPS	21PT1653/43	L6.2 AA
PHILIPS	21PT1653/58	L6.2 AA
PHILIPS	21PT1653/58H	L6.2 AA
PHILIPS	21PT1653/58P	L6.2 AA
PHILIPS	21PT1653/58Y	L6.2 AA
PHILIPS	21PT1654	L9.2A
PHILIPS	21PT1654	L9.2E AA
PHILIPS	21PT165A	ANUBIS A
PHILIPS	21PT165B	AA5 AA
PHILIPS	21PT165B	AA5 AB

Brand	model	chassis
PHILIPS	21PT165C	AA5
PHILIPS	21PT1663	L7.2E
PHILIPS	21PT1664	L9.2
PHILIPS	21PT1666	SL01.2E AA
PHILIPS	21PT1666/01	L01.2E AA;L01.2E AB
PHILIPS	21PT1666/05	L01.2E AA;L01.2E AB
PHILIPS	21PT166A	ANUBIS A
PHILIPS	21PT166A/00	ANUBIS A AC
PHILIPS	21PT166B	AA5 AA
PHILIPS	21PT166C	AA5
PHILIPS	21PT1717/60	L01.2A AA;L01.2A AB
PHILIPS	21PT1727/60	L01.1A AC;L2K3 AA
PHILIPS	21PT1820	TE3.2E (Telra PT19)
PHILIPS	21PT1820/12	TE3.2E CA
PHILIPS	21PT1865	L9.2E
PHILIPS	21PT1866	A10E ?
PHILIPS	21PT1866/58	L01.2E AA;L01.2E AB
PHILIPS	21PT1867	L01.2E
PHILIPS	21PT1867/58	L01.2E AA;L01.2E AB
PHILIPS	21PT1967/01	L01.2E AA;L01.2E AB
PHILIPS	21PT1967/05	L01.2E AA;L01.2E AB
PHILIPS	21PT1967/58	L01.2E AA;L01.2E AB
PHILIPS	21PT2001/59B	L01.2A AA
PHILIPS	21PT2001/67R	L01.2A AA
PHILIPS	21PT2001/71R	L01.2A AA
PHILIPS	21PT2001/79R	L01.2A AA
PHILIPS	21PT2004/94R	L01.2A AA;L01.2A AB
PHILIPS	21PT2010	T1.1A
PHILIPS	21PT2010/69R	T1.1A AA
PHILIPS	21PT2011/67R	L01.2A AA
PHILIPS	21PT2011/71R	L01.2A AA
PHILIPS	21PT2011/74R	L01.2A AA
PHILIPS	21PT2012/59A	L01.2A AA
PHILIPS	21PT2012/59B	L01.2A AA
PHILIPS	21PT2012/59C	L01.2A AA

Brand	model	chassis
PHILIPS	21PT2012/65R	L01.2A AA
PHILIPS	21PT2012/79R	L01.2A AA
PHILIPS	21PT2014	TC2.1A
PHILIPS	21PT2014/56R	TC2.1A AB
PHILIPS	21PT2105/94R	OLD
PHILIPS	21PT2110	TC2.1A
PHILIPS	21PT2110	TC2.1A
PHILIPS	21PT2110/56R	TC2.1A AA
PHILIPS	21PT2110/67R	OLD
PHILIPS	21PT2110/69R	TC2.1A AA
PHILIPS	21PT2110/71R	OLD
PHILIPS	21PT2110/79R	TC2.1A AA
PHILIPS	21PT2110C/79	TC2.1A AA
PHILIPS	21PT2115	L01.2A AB
PHILIPS	21PT2124	L01.2A
PHILIPS	21PT2124/71R	L01.2A AA;L01.2A AB
PHILIPS	21PT2125/94	L01.1A AB
PHILIPS	21PT2125B/94	L01.1A AB
PHILIPS	21PT2135/94R	OLD
PHILIPS	21PT2152	L01.2A
PHILIPS	21PT2152/68R	L01.2A AA
PHILIPS	21PT2152/69R	L01.2A AA
PHILIPS	21PT2152/79R	L01.2A AA
PHILIPS	21PT2204/94R	L04A AA
PHILIPS	21PT2214/94R	L04A AA
PHILIPS	21PT2217/94	TC8.1A CA
PHILIPS	21PT2217B/94	TC8.1A CA
PHILIPS	21PT2251/67R	L01.1A AA
PHILIPS	21PT2251/71R	L01.1A AA
PHILIPS	21PT2251/74R	L01.1A AA
PHILIPS	21PT2251/97R	L01.1A AA
PHILIPS	21PT2252	L01.x A
PHILIPS	21PT2252/56A	L01.1A AA
PHILIPS	21PT2252/57R	L01.1A AA
PHILIPS	21PT2252/65R	L01.1A AA

Brand	model	chassis
PHILIPS	21PT2252/68R	L01.1A AA
PHILIPS	21PT2252/69R	L01.1A AA
PHILIPS	21PT2252/79R	L01.1A AA
PHILIPS	21PT2264	L9.2E
PHILIPS	21PT2265	L9.2E
PHILIPS	21PT2301/67R	L01.1A AA
PHILIPS	21PT2301/71R	L01.1A AA
PHILIPS	21PT2301/74R	L01.1A AA
PHILIPS	21PT2301/97R	L01.1A AA
PHILIPS	21PT2302/56A	L01.1A AA
PHILIPS	21PT2302/57R	L01.1A AA
PHILIPS	21PT2302/65R	L01.1A AA
PHILIPS	21PT2302/68R	L01.1A AA
PHILIPS	21PT2302/69R	L01.1A AA
PHILIPS	21PT2302/73R	L01.1A AA
PHILIPS	21PT2302/79R	L01.1A AA
PHILIPS	21PT2304/94R	L04A AA
PHILIPS	21PT231A	PV4.0 AA
PHILIPS	21PT2321	L7.1A
PHILIPS	21PT2321/50B	L7.1A AA
PHILIPS	21PT2321/50R	L7.1A AA
PHILIPS	21PT2321/58R	L7.1A AA
PHILIPS	21PT2321/58T	L7.1A AA
PHILIPS	21PT2324/56R	L01.2A AA;L01.2A AB
PHILIPS	21PT2324/56S	L01.2A AA;L01.2A AB
PHILIPS	21PT2324/67S	L01.2A AA;L01.2A AB
PHILIPS	21PT2324/69R	L01.2A AA;L01.2A AB
PHILIPS	21PT2324/69S	L01.2A AA;L01.2A AB
PHILIPS	21PT2324/71R	L01.2A AA;L01.2A AB
PHILIPS	21PT2324/79R	L01.2A AA;L01.2A AB
PHILIPS	21PT2325	L01.2A AB
PHILIPS	21PT2327/56	TC8.1A CA
PHILIPS	21PT2327/69	TC8.1A CA
PHILIPS	21PT2327/79	TC8.1A CA
PHILIPS	21PT2327C/79	TC8.1A CA

Brand	model	chassis
PHILIPS	21PT232A	ANUBIS S
PHILIPS	21PT232A/58R	PV4.0
PHILIPS	21PT233A	PV4.0 AA
PHILIPS	21PT233A/71R	OLD
PHILIPS	21PT2381	L7.1A
PHILIPS	21PT2381/50B	L7.1A AA
PHILIPS	21PT2381/58R	L7.1A AA
PHILIPS	21PT2381/58T	L7.1A AA
PHILIPS	21PT2381/59B	L7.1A AA
PHILIPS	21PT2381/59M	L7.1A AA
PHILIPS	21PT2381/59R	L7.1A AA
PHILIPS	21PT2381/59S	L7.1A AA
PHILIPS	21PT2381/73R	L7.1A AA
PHILIPS	21PT2381/75R	L7.1A AA
PHILIPS	21PT2381/94R	L7.1A AA
PHILIPS	21PT2382	L7.2E
PHILIPS	21PT2382/56H	L7.2A AA
PHILIPS	21PT2382/56R	L7.2A AA
PHILIPS	21PT2382/57R	L7.2A AA
PHILIPS	21PT2382/71R	L7.2A AA
PHILIPS	21PT2386	L7.2A
PHILIPS	21PT2386/75Y	L7.2A AA
PHILIPS	21PT238A	ANUBIS S AA PV4.0 AA
PHILIPS	21PT238A/50B	OLD
PHILIPS	21PT238A/50B	PV4.0
PHILIPS	21PT238A/56R	PV4.0
PHILIPS	21PT238A/57R	PV4.0
PHILIPS	21PT238A/58R	PV4.0
PHILIPS	21PT238A/59R	PV4.0
PHILIPS	21PT238A/75R	PV4.0
PHILIPS	21PT238A/93R	PV4.0
PHILIPS	21PT238B/94I	OLD
PHILIPS	21PT2404/94R	L04A AA
PHILIPS	21PT240A	PV4.0 AA
PHILIPS	21PT240A/65R	PV4.0

Brand	model	chassis
PHILIPS	21PT240A/93R	PV4.0
PHILIPS	21PT240A/94R	PV4.0
PHILIPS	21PT2411/94R	L01.2A AA
PHILIPS	21PT2411/94T	OLD
PHILIPS	21PT241A	PV4.0 AA
PHILIPS	21PT2421/94R	L01.2A AA
PHILIPS	21PT2423/94R	L01.2A AA;L01.2A AB
PHILIPS	21PT2425/94R	L01.2A AA
PHILIPS	21PT2426/94R	L01.2A AA
PHILIPS	21PT2443/94R	L01.1A AA;L01.1A AB
PHILIPS	21PT2443B/94	L01.1A AB
PHILIPS	21PT2452/94R	L01.1A AA
PHILIPS	21PT2452/94T	OLD
PHILIPS	21PT2460/94R	L01.1A AB
PHILIPS	21PT2465/94R	L01.1A AA
PHILIPS	21PT249A	ANUBIS S
PHILIPS	21PT2501/93R	L01.2A AA
PHILIPS	21PT2502/93R	L01.2A AA
PHILIPS	21PT2521/93R	L01.2A AA
PHILIPS	21PT2563	L6.1
PHILIPS	21PT2564	L6.1
PHILIPS	21PT2565/93R	L01.1A AA
PHILIPS	21PT260A	PV4.0 AA
PHILIPS	21PT260A/57R	PV4.0
PHILIPS	21PT260A/57V	PV4.0
PHILIPS	21PT260A/75R	PV4.0
PHILIPS	21PT260A/75V	PV4.0
PHILIPS	21PT261A	ANUBIS S
PHILIPS	21PT2622	L7.2A
PHILIPS	21PT2622/69R	L7.2A AA
PHILIPS	21PT2622/75R	L7.2A AA
PHILIPS	21PT2622/77B	L7.2A AA
PHILIPS	21PT2622/79R	L7.2A AA
PHILIPS	21PT2626	L7.2A
PHILIPS	21PT2626/69V	L7.2A AA

Brand	model	chassis
PHILIPS	21PT262A	ANUBIS S
PHILIPS	21PT262A/68R	PV4.0
PHILIPS	21PT262A/69R	PV4.0
PHILIPS	21PT262A/69V	PV4.0
PHILIPS	21PT262A/79R	PV4.0
PHILIPS	21PT262A/79V	PV4.0
PHILIPS	21PT263A	ANUBIS S
PHILIPS	21PT263A/97R	OLD
PHILIPS	21PT263A/97R	PV4.0 AA
PHILIPS	21PT2664	L9.2
PHILIPS	21PT2665	L9.2E
PHILIPS	21PT2666	L01.2E AA
PHILIPS	21PT2682	L7.2A
PHILIPS	21PT2682/56H	L7.2A AA
PHILIPS	21PT2682/56R	L7.2A AA
PHILIPS	21PT2682/56S	L7.2A AA
PHILIPS	21PT2682/57R	L7.2A AA
PHILIPS	21PT2682/67S	L7.2A AA
PHILIPS	21PT2682/71R	L7.2A AA
PHILIPS	21PT2682/77B	L7.2A AA
PHILIPS	21PT2682/97R	L7.2A AA
PHILIPS	21PT2683	L7.2E
PHILIPS	21PT2684	L9.2
PHILIPS	21PT2685	L9.2E
PHILIPS	21PT2686	L7.2A
PHILIPS	21PT2686/57Y	L7.2A AA
PHILIPS	21PT3005/55	L03.2L AA
PHILIPS	21PT3005/85	L03.2L AA
PHILIPS	21PT310A	AA5 AA
PHILIPS	21PT3136/55	L03.2L AA
PHILIPS	21PT313A	AA5 AA
PHILIPS	21PT3182/93R	OLD
PHILIPS	21PT3205/44	L03.2L AA
PHILIPS	21PT3205/55	L03.2L AA
PHILIPS	21PT3205/85	L03.2L AA

Brand	model	chassis
PHILIPS	21PT3223/67R	L01.1A AC;L2K3 AA
PHILIPS	21PT3224/93R	L01.2A AA;L01.2A AB
PHILIPS	21PT3304	L01.2E AA
PHILIPS	21PT3323	L01.1A
PHILIPS	21PT3323/56R	L01.1A AC;L2K3 AA
PHILIPS	21PT3323/56S	L01.1A AC;L2K3 AA
PHILIPS	21PT3323/61R	L01.1A AC;L2K3 AA
PHILIPS	21PT3323/67R	L01.1A AC;L2K3 AA
PHILIPS	21PT3323/69R	L01.1A AC;L2K3 AA
PHILIPS	21PT3323/69S	L01.1A AC;L2K3 AA
PHILIPS	21PT3323/71R	L01.1A AC;L2K3 AA
PHILIPS	21PT3323/79R	L01.1A AC;L2K3 AA
PHILIPS	21PT3324	L01H.2E AA ?
PHILIPS	21PT3324/56R	L01.1A AC;L01.2A AA;L01.2A AB;L2K3 AA
PHILIPS	21PT3324/56S	L01.2A AA;L01.2A AB
PHILIPS	21PT3324/67S	L01.2A AA;L01.2A AB
PHILIPS	21PT3324/69R	L01.2A AA;L01.2A AB
PHILIPS	21PT3324/69S	L01.2A AA;L01.2A AB
PHILIPS	21PT3324/71R	L01.2A AA;L01.2A AB
PHILIPS	21PT3324/79R	L01.2A AA;L01.2A AB
PHILIPS	21PT3327/94	SK4.0A CA
PHILIPS	21PT3335/93	L01.1A AC;L2K3 AA
PHILIPS	21PT3355/93	L01.1A AC;L2K3 AA
PHILIPS	21PT3423/94R	L01.2A AA;L01.2A AB
PHILIPS	21PT3442/94R	L01.1A AB
PHILIPS	21PT3442B/94	L01.1A AB
PHILIPS	21PT3443/94R	L01.1A AA;L01.1A AB
PHILIPS	21PT350A	ANUBIS B AB
PHILIPS	21PT351A	TV/VCR1AA
PHILIPS	21PT351A/00	TV/VCR1AA
PHILIPS	21PT351A/01	TV/VCR1AA
PHILIPS	21PT351A/13	TV/VCR1AA
PHILIPS	21PT351B	TV/VCR1 (TV/VCR1AA ?)
PHILIPS	21PT3520/93R	OLD
PHILIPS	21PT352A	ANUBIS B

Brand	model	chassis
PHILIPS	21PT3532/93R	OLD
PHILIPS	21PT355A	TV/CDI-1
PHILIPS	21PT3606/93	SK1.0A CA
PHILIPS	21PT3626/93	SK1.0A CA
PHILIPS	21PT3722	L9.2A
PHILIPS	21PT3742	L9.2A
PHILIPS	21PT3752/71R	OLD
PHILIPS	21PT3752/74R	OLD
PHILIPS	21PT3762/59B	OLD
PHILIPS	21PT3762/59C	OLD
PHILIPS	21PT3762/79R	OLD
PHILIPS	21PT3822	L9.2A
PHILIPS	21PT3832	L9.2A
PHILIPS	21PT3832/67R	OLD
PHILIPS	21PT3832/71R	OLD
PHILIPS	21PT3832/74R	OLD
PHILIPS	21PT3832/93R	OLD
PHILIPS	21PT3842	L9.2A
PHILIPS	21PT3882	L9.2A
PHILIPS	21PT3885	L9.2A
PHILIPS	21PT3911/67R	OLD
PHILIPS	21PT3911/71R	OLD
PHILIPS	21PT3921	L9.1A
PHILIPS	21PT3921/69R	OLD
PHILIPS	21PT3921/79R	OLD
PHILIPS	21PT3932	L9.1A
PHILIPS	21PT3942	L9.1A
PHILIPS	21PT3942	L9.2A
PHILIPS	21PT3952	L9.1A
PHILIPS	21PT3962	L9.1A
PHILIPS	21PT4136/44	L03.2L AA
PHILIPS	21PT4136/55	L03.2L AA
PHILIPS	21PT4204	L7.2E
PHILIPS	21PT4207/44	UNKNOWN
PHILIPS	21PT420A	ANUBIS S

Brand	model	chassis
PHILIPS	21PT4223	L01.1A
PHILIPS	21PT4223/67R	L01.1A AC;L2K3 AA
PHILIPS	21PT4223/69R	L01.1A AC;L2K3 AA
PHILIPS	21PT4223/69S	L01.1A AC;L2K3 AA
PHILIPS	21PT4301	GR2.4
PHILIPS	21PT4303	MD1.2E
PHILIPS	21PT4304	L6.2
PHILIPS	21PT4304/00	L6.2 AA
PHILIPS	21PT4305	L7.2E
PHILIPS	21PT4320/56A	L01.1A AB
PHILIPS	21PT4320/57R	L01.1A AB
PHILIPS	21PT4320/65R	L01.1A AB
PHILIPS	21PT4320/67R	L01.1A AB
PHILIPS	21PT4320/68R	L01.1A AB
PHILIPS	21PT4320/69R	L01.1A AB
PHILIPS	21PT4320/71R	L01.1A AB
PHILIPS	21PT4320/74R	L01.1A AB
PHILIPS	21PT4320/79R	L01.1A AB
PHILIPS	21PT4320/97R	L01.1A AB
PHILIPS	21PT4323	L01.1A
PHILIPS	21PT4323/56R	L01.1A AC;L2K3 AA
PHILIPS	21PT4323/56S	L01.1A AC;L2K3 AA
PHILIPS	21PT4323/61R	L01.1A AC;L2K3 AA
PHILIPS	21PT4323/67R	L01.1A AC;L2K3 AA
PHILIPS	21PT4323/69	L01.1A AC;L2K3 AA
PHILIPS	21PT4323/69R	L01.1A AC;L2K3 AA
PHILIPS	21PT4323/69S	L01.1A AC;L2K3 AA
PHILIPS	21PT4323/71R	L01.1A AC;L2K3 AA
PHILIPS	21PT4323/79R	L01.1A AC;L2K3 AA
PHILIPS	21PT4324	L6.2
PHILIPS	21PT4324/01	L6.2 AA
PHILIPS	21PT4325	L7.2E
PHILIPS	21PT4333/79	L01.1A AC;L2K3 AA
PHILIPS	21PT4355	L9.2E
PHILIPS	21PT4375	L9.2E

Brand	model	chassis
PHILIPS	21PT4403	L6.2
PHILIPS	21PT4403/00	L6.2 AA
PHILIPS	21PT4404	L7.2
PHILIPS	21PT4406	L01.2E
PHILIPS	21PT4406/01	L01.2E AA;L01.2E AB
PHILIPS	21PT4406/58	L01.2E AA;L01.2E AB
PHILIPS	21PT440A	GR2.2
PHILIPS	21PT440B	MD1.1E
PHILIPS	21PT4418	MD1.1E
PHILIPS	21PT441B	MD1.1E AB
PHILIPS	21PT441B	MD1.2E
PHILIPS	21PT4420/01	L01.2E AA;L01.2E AB
PHILIPS	21PT4420/05	L01.2E AA;L01.2E AB
PHILIPS	21PT4422	MD1.2E
PHILIPS	21PT4423	L6.2
PHILIPS	21PT4423/01	L6.2 AA
PHILIPS	21PT4423/05	L6.2 AA
PHILIPS	21PT4423/11	L6.2 AA
PHILIPS	21PT4423/58	L6.2 AA
PHILIPS	21PT4423/58P	L6.2 AA
PHILIPS	21PT4424	L7.2E
PHILIPS	21PT4425	L9.2E
PHILIPS	21PT4426	L01.2E
PHILIPS	21PT4426/01	L01.2E AA;L01.2E AB
PHILIPS	21PT4426/58	L01.2E AA;L01.2E AB
PHILIPS	21PT442A	GR2.2
PHILIPS	21PT442B	MD1.1E
PHILIPS	21PT4438/01	L01.2E AA;L01.2E AB
PHILIPS	21PT4443/94R	L01.1A AA;L01.1A AB
PHILIPS	21PT4454	L6.3
PHILIPS	21PT4454/00	L6.3 AA
PHILIPS	21PT4455	L9.2E
PHILIPS	21PT4456	L9.2E
PHILIPS	21PT4456/00	L9.1E AA;L9.2E AA
PHILIPS	21PT4456/01	L9.1E AA;L9.2E AA

Brand	model	chassis
PHILIPS	21PT4456/05	L9.1E AA;L9.2E AA
PHILIPS	21PT4456/58	L9.1E AA;L9.2E AA
PHILIPS	21PT4457	L01.2E
PHILIPS	21PT4457/01	L01.2E AA;L01.2E AB
PHILIPS	21PT4457/05	L01.2E AA;L01.2E AB
PHILIPS	21PT4457/58	L01.2E AA;L01.2E AB
PHILIPS	21PT4458	L01.1E
PHILIPS	21PT4458/01	L01.2E AA;L01.2E AB
PHILIPS	21PT4458/05	L01.2E AA;L01.2E AB
PHILIPS	21PT4458/58	L01.2E AA;L01.2E AB
PHILIPS	21PT4462	L01.2E AA
PHILIPS	21PT4474	L6.3
PHILIPS	21PT4474/01	L6.3 AA
PHILIPS	21PT4475	L9.2E
PHILIPS	21PT4475/58C	L9.1E AA;L9.2E AA
PHILIPS	21PT4494	L6.3
PHILIPS	21PT4494/05	L6.3 AA
PHILIPS	21PT4655	L9.2E
PHILIPS	21PT5007/56	TC8.1A CA
PHILIPS	21PT5007/69	TC8.1A CA
PHILIPS	21PT5007/74	TC8.1A CA
PHILIPS	21PT5007/94	TC8.1A CA
PHILIPS	21PT5007C/74	TC8.1A CA
PHILIPS	21PT5017/94	TC8.1A CA
PHILIPS	21PT5027/56	TC8.1A CA
PHILIPS	21PT5027/69	TC8.1A CA
PHILIPS	21PT5027/74	TC8.1A CA
PHILIPS	21PT5027/79	TC8.1A CA
PHILIPS	21PT5027/94	TC8.1A CA
PHILIPS	21PT5027C/74	TC8.1A CA
PHILIPS	21PT5027C/79	TC8.1A CA
PHILIPS	21PT5107/60	L01.1A AC;L2K3 AA
PHILIPS	21PT5117/60	L01.2A AA;L01.2A AB
PHILIPS	21PT5207/60	L01.1A AC;L01.2A AB;L2K3 AA
PHILIPS	21PT520A	GR2.2

Brand	model	chassis
PHILIPS	21PT520B	GR2.4
PHILIPS	21PT520B/00	GR2.4
PHILIPS	21PT5217/60	L01.1A AC;L2K3 AA
PHILIPS	21PT522	GR2.4
PHILIPS	21PT522A	GR2.2
PHILIPS	21PT522B	GR2.4
PHILIPS	21PT523B	GR2.4
PHILIPS	21PT529	L01EX
PHILIPS	21PT529A/85R	S8 AA
PHILIPS	21PT5301	GR2.2
PHILIPS	21PT5302	MD1.2E
PHILIPS	21PT5304	A8.0
PHILIPS	21PT5305	L9.1E
PHILIPS	21PT5305	L9.2
PHILIPS	21PT5307/60	L01.1A AC;L2K3 AA
PHILIPS	21PT5307S/60	L01.1A AC;L2K3 AA
PHILIPS	21PT530A	GR2.2
PHILIPS	21PT530B	GR2.4
PHILIPS	21PT5317	L01.1A
PHILIPS	21PT5317/60	L01.1A AC;L2K3 AA
PHILIPS	21PT5321	GR2.4
PHILIPS	21PT5321/01	OLD
PHILIPS	21PT5322	MD1.2E
PHILIPS	21PT5324	A8.0
PHILIPS	21PT532A	GR2.2
PHILIPS	21PT532B	GR2.4
PHILIPS	21PT5401	TE3.1E CA
PHILIPS	21PT5401/12	TE3.2E CA
PHILIPS	21PT5402/01	TE3.2E CA
PHILIPS	21PT5402/58	TE3.2E CA
PHILIPS	21PT5405	L9.1E
PHILIPS	21PT5406	L9.1E
PHILIPS	21PT5406	L9.1E
PHILIPS	21PT5407	L01.1E AA
PHILIPS	21PT5408/01	L01.1E AA;L01.1E AB

Brand	model	chassis
PHILIPS	21PT5408/58S	L01.1E AA;L01.1E AB
PHILIPS	21PT5409/01	L01.2E AA;L01.2E AB
PHILIPS	21PT5420	L01.2E AA (?)
PHILIPS	21PT5420/01	L01.2E AA;L01.2E AB
PHILIPS	21PT5420/05	L01.1E AA;L01.1E AB
PHILIPS	21PT5421	TE3.2E
PHILIPS	21PT5421/12	TE3.2E CA
PHILIPS	21PT5425	L03.1L AA (?)
PHILIPS	21PT5431	L01.1L AC 2K3
PHILIPS	21PT5431/55R	L01.1L AC
PHILIPS	21PT5431/77R	L01.1L AC
PHILIPS	21PT5431/78R	L01.1L AC
PHILIPS	21PT5432	L01.1L AC 2K3
PHILIPS	21PT5432/55R	L01.1L AC
PHILIPS	21PT5432/77R	L01.1L AC
PHILIPS	21PT5432/78R	L01.1L AC
PHILIPS	21PT5433	L03.1L AA
PHILIPS	21PT5434	L03.1L AA
PHILIPS	21PT5437/94	SK4.0A CA
PHILIPS	21PT5443/94R	L01.2A AA
PHILIPS	21PT5457	L01.2E
PHILIPS	21PT5457/01	L01.2E AA;L01.2E AB
PHILIPS	21PT5457/05	L01.2E AA;L01.2E AB
PHILIPS	21PT5457/58	L01.2E AA;L01.2E AB
PHILIPS	21PT5458	L04E
PHILIPS	21PT5505	L9.1E
PHILIPS	21PT5507	L01.1E
PHILIPS	21PT5515	A10E ?
PHILIPS	21PT5518	L04EE AA ?
PHILIPS	21PT5547/94	SK4.0A CA
PHILIPS	21PT5606	L01.1E
PHILIPS	21PT5618	L04E
PHILIPS	21PT570A	GR2.2
PHILIPS	21PT6257/85	UNKNOWN
PHILIPS	21PT6258/85	UNKNOWN

Brand	model	chassis
PHILIPS	21PT6331	L01...
PHILIPS	21PT6332/85	L01.1L AC
PHILIPS	21PT6337/85	UNKNOWN
PHILIPS	21PT6341/44	L03.1L
PHILIPS	21PT6347/55	UNKNOWN
PHILIPS	21PT639A/55R	OLD
PHILIPS	21PT639A/78R	OLD
PHILIPS	21PT639A/85R	T8 AA
PHILIPS	21PT639B/77R	L01.1L AB
PHILIPS	21PT6431	L01.2U
PHILIPS	21PT6437/44	UNKNOWN
PHILIPS	21PT643R85	L01.1U
PHILIPS	21PT6441	L03.1L AA
PHILIPS	21PT6447/85	UNKNOWN
PHILIPS	21PT6457/44	UNKNOWN
PHILIPS	21PT6457/85	UNKNOWN
PHILIPS	21PT6457C/77	UNKNOWN
PHILIPS	21PT6541/44	L04L AA
PHILIPS	21PT6541/85	L04L AA
PHILIPS	21PT6807	TDVD12.1E
PHILIPS	21PT6807/58	L01.1E AA
PHILIPS	21PT6818	L01.1E
PHILIPS	21PT6820/01	TDVD3.1E AA
PHILIPS	21PT6820/05	TDVD3.1E AA
PHILIPS	21PT700A	FL1.10
PHILIPS	21PT700A/>20	FL1.10
PHILIPS	21PT700A/19R	FL1.0
PHILIPS	21PT700A/20	FL1.10
PHILIPS	21PT700B	GR2.3
PHILIPS	21PT701A	GR2.3
PHILIPS	21PT701B	GR2.4
PHILIPS	21PT701C	GR2.4
PHILIPS	21PT702A	FL1.10
PHILIPS	21PT703A	GR2.3
PHILIPS	21PT703B	GR2.4

Brand	model	chassis
PHILIPS	21PT703C	GR2.4
PHILIPS	21PT739A/55R	L01.1L AB
PHILIPS	21PT739A/78R	L01.1L AB
PHILIPS	21PT739B/77R	L01.1L AB
PHILIPS	21PT838A/44R	L01.1L AA
PHILIPS	21PT838A/55R	L01.1L AA
PHILIPS	21PT838A/77R	L01.1L AA
PHILIPS	21PT838A/78R	L01.1L AA
PHILIPS	21PT839A/55R	L01.1L AB
PHILIPS	21PT839A/78R	OLD
PHILIPS	21PT839B/77R	L01.1L AB
PHILIPS	21PT839B/85R	T8 AA
PHILIPS	21PT8467/44	UNKNOWN
PHILIPS	21PT8467/85	UNKNOWN
PHILIPS	21PT8468/77	UNKNOWN
PHILIPS	21PT8468/78	UNKNOWN
PHILIPS	21PT8468C/77	UNKNOWN
PHILIPS	21PT8468C/78	UNKNOWN
PHILIPS	21PT8468K/77	UNKNOWN
PHILIPS	21PT8667/93	SK4.0A CA
PHILIPS	21PT8857/93	SK4.0A CA
PHILIPS	21PT8867/93	SK4.0A CA
PHILIPS	21PT8867/94	SK4.0A CA
PHILIPS	21PT9457/44	SK4.0L CA
PHILIPS	21PT9457/55	SK4.0L CA
PHILIPS	21PT9457/85	SK4.0L CA
PHILIPS	21PT9467/77	SK4.0L CA
PHILIPS	21PT9467/78	SK4.0A CA
PHILIPS	21PT9467C/77	UNKNOWN
PHILIPS	21PT9467C/78	UNKNOWN
PHILIPS	21PT9467K/77	UNKNOWN
PHILIPS	21PT9467S/78	UNKNOWN
PHILIPS	21PV210	TVCR DELTA99 AA
PHILIPS	21PV267	TVCR B
PHILIPS	21PV288	TVCR GAMMA--TVCR MONO98 !

Brand	model	chassis
PHILIPS	21PV320	TVCR D (TVCR Delta2000)
PHILIPS	21PV320	TVCR DELTA99 AA
PHILIPS	21PV325	TVCR D (TVCR Delta2000)
PHILIPS	21PV330	TVCR D (TVCR Delta2000)
PHILIPS	21PV335	TVCR D (TVCR Delta2000)
PHILIPS	21PV340	TVCR E (TVCR Epsilon 2001)
PHILIPS	21PV345	TVCR E (TVCR Epsilon 2001)
PHILIPS	21PV375	Z12
PHILIPS	21PV520	TVCR D (TVCR Delta2000)
PHILIPS	21PV520	TVCR DELTA99 AA
PHILIPS	21PV548	TVCR E (TVCR Epsilon 2001)
PHILIPS	21PV620	TVCR G (TVCR STEREO98)
PHILIPS	21PV677	TVCR B
PHILIPS	21PV677	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	21PV688	TVCR G (TVCR STEREO98)
PHILIPS	21PV700	TVCR D (TVCR Delta2000)
PHILIPS	21PV708	TVCR D (TVCR Delta2000)
PHILIPS	21PV715	TVCR D (TVCR Delta2000)
PHILIPS	21PV908	TVCR D (TVCR Delta2000)
PHILIPS	21PV918	TVCR D (TVCR Delta2000)
PHILIPS	21SL2636	GR2.3
PHILIPS	21SL2937	GR2.3
PHILIPS	21SL5100	FL1.0
PHILIPS	21SL5101	FL1.0
PHILIPS	21SL5750	FL1.0
PHILIPS	21SL5756	FL1.0
PHILIPS	21ST1636	GR2.1
PHILIPS	21ST1730	GR2.1
PHILIPS	21ST1731	GR2.1
PHILIPS	21ST2131	GR2.2
PHILIPS	21ST2430	GR2.2
PHILIPS	21ST2436	GR2.2
PHILIPS	21ST2630	GR2.2
PHILIPS	21ST2636	GR2.2
PHILIPS	21ST2637	GR2.2

Brand	model	chassis
PHILIPS	21ST2730	GR2.2
PHILIPS	21ST2731	GR2.2
PHILIPS	21ST2737	GR2.2
PHILIPS	21ST2931	GR2.2
PHILIPS	21ST2937	GR2.2
PHILIPS	21TT1866	L01.2E
PHILIPS	220321SK	K30
PHILIPS	220501SK	K30
PHILIPS	220CW8FB/93	TC5.1L CA
PHILIPS	220VW8FB/96	UNKNOWN
PHILIPS	221001SK/05	K30
PHILIPS	221001SK/25	K35
PHILIPS	221003SK	K30
PHILIPS	222621SK	K30
PHILIPS	223815SK	K40
PHILIPS	224003SK	K35
PHILIPS	224023SK	K35
PHILIPS	224025SK	K40
PHILIPS	224073SK	K35
PHILIPS	224075SK	K40
PHILIPS	224523SK	K35
PHILIPS	224573SK	K35
PHILIPS	224623SK	K35
PHILIPS	224673SK	K35
PHILIPS	225075SK	K40
PHILIPS	225083SK	K35
PHILIPS	225084SK	K40
PHILIPS	225094SK	K40-SYS.T
PHILIPS	225175SK	K40
PHILIPS	226002EK	2A
PHILIPS	226102EK	2A
PHILIPS	226122EK	2A
PHILIPS	226152EK	2A
PHILIPS	22AV1015/01	OLD
PHILIPS	22AV1037	K30

Brand	model	chassis
PHILIPS	22AV1051	K35
PHILIPS	22AV1052	K35
PHILIPS	22AV1053	K30
PHILIPS	22AV1054	K35
PHILIPS	22AV1055	K35
PHILIPS	22AV1060	K30-K35
PHILIPS	22AV1061	KT4-K40
PHILIPS	22AV1062	KT4-K40
PHILIPS	22AV1063	K35
PHILIPS	22AV1065	K35
PHILIPS	22AV1076	K40
PHILIPS	22AV1077	K40
PHILIPS	22AV1078	K35
PHILIPS	22AV1079	K35
PHILIPS	22AV1080	K40
PHILIPS	22AV1081	K40
PHILIPS	22AV1083	KT4-K40
PHILIPS	22AV1084	KT4-K40
PHILIPS	22AV1085	KT4-K40
PHILIPS	22AV1092	K40
PHILIPS	22AV1093	F1
PHILIPS	22AV1096	K40
PHILIPS	22AV1112	2B
PHILIPS	22AV1113	2B
PHILIPS	22AV1114	2A
PHILIPS	22AV1121	2B
PHILIPS	22AV1122	CP90
PHILIPS	22AV1130	2A
PHILIPS	22AV1131	2B
PHILIPS	22AV1200	CTO-S
PHILIPS	22AV1201	NCF
PHILIPS	22AV1205	NCF
PHILIPS	22AV1210	NC3CR/S
PHILIPS	22AV1221/00	OLD
PHILIPS	22AV1340	22AV1340

Brand	model	chassis
PHILIPS	22AV1440	22AV1440
PHILIPS	22AV1999	22AV1999
PHILIPS	22CE2060	2A
PHILIPS	22CE2061	2A
PHILIPS	22CE2064	2A
PHILIPS	22CE2065	2A
PHILIPS	22CE2261	2A
PHILIPS	22CE2267	2A
PHILIPS	22CE2561	2A
PHILIPS	22CE2565	2A
PHILIPS	22CE2567	2A
PHILIPS	22CE3271	CP110
PHILIPS	22CS1000	K30
PHILIPS	22CS1001	K30
PHILIPS	22CS1002	K30
PHILIPS	22CS1003	K30
PHILIPS	22CS1004	K30
PHILIPS	22CS1014	K30
PHILIPS	22CS1019	K30
PHILIPS	22CS1200	K30
PHILIPS	22CS1201	K30
PHILIPS	22CS1202	K30
PHILIPS	22CS1210	K30
PHILIPS	22CS1212	K30
PHILIPS	22CS1218	K30
PHILIPS	22CS1220	K30
PHILIPS	22CS1225	K30
PHILIPS	22CS1234	K30
PHILIPS	22CS1238	K30M
PHILIPS	22CS1240	K30M
PHILIPS	22CS1241	K30
PHILIPS	22CS1245	K30
PHILIPS	22CS1253	K30
PHILIPS	22CS1260	K30
PHILIPS	22CS1263	K30

Brand	model	chassis
PHILIPS	22CS3040	K35
PHILIPS	22CS3240	K35
PHILIPS	22CS3244	K35
PHILIPS	22CS3245	K35
PHILIPS	22CS3246	K35M
PHILIPS	22CS3248	K35
PHILIPS	22CS3250	K35
PHILIPS	22CS3340	K35
PHILIPS	22CS3343	K35
PHILIPS	22CS3344	K35
PHILIPS	22CS3345	K35
PHILIPS	22CS3348	K35
PHILIPS	22CS3360	K35
PHILIPS	22CS3361	K35
PHILIPS	22CS3364	K35
PHILIPS	22CS3368	K35
PHILIPS	22CS3373	K35
PHILIPS	22CS3379	K35
PHILIPS	22CS3440	K35
PHILIPS	22CS3441	K35
PHILIPS	22CS3446	K35
PHILIPS	22CS3460	K35
PHILIPS	22CS3740	K35
PHILIPS	22CS3745	K35
PHILIPS	22CS3760	K35
PHILIPS	22CS3761	K35
PHILIPS	22CS3850	K35
PHILIPS	22CS3851	K35
PHILIPS	22CS3868	K35
PHILIPS	22CS4360	K40
PHILIPS	22CS4363	K40
PHILIPS	22CS4366	K40M
PHILIPS	22CS4460	K40
PHILIPS	22CS4560	K40
PHILIPS	22CS4850	K40

Brand	model	chassis
PHILIPS	22CS4856	K40M
PHILIPS	22CS4860	K40
PHILIPS	22CS4861	K40
PHILIPS	22CS5240	K40
PHILIPS	22CS5242	K40
PHILIPS	22CS5246	K40M
PHILIPS	22CS5250	K40
PHILIPS	22CS5251	K40
PHILIPS	22CS5350	K40
PHILIPS	22CS5351	K40
PHILIPS	22CS5355	K40
PHILIPS	22CS5356	K40M
PHILIPS	22CS5445	K40
PHILIPS	22CS5735	K40
PHILIPS	22CS5739	K40
PHILIPS	22CS5740	K40
PHILIPS	22CS5744	K40
PHILIPS	22CS5745	K40
PHILIPS	22CS5747	K40
PHILIPS	22CS5748	K40
PHILIPS	22CS5750	K40
PHILIPS	22CS5751	K40
PHILIPS	22CS5752	K40
PHILIPS	22CS5755	K40
PHILIPS	22CS5756	K40M
PHILIPS	22CS5757	K40M
PHILIPS	22CS5758	K40
PHILIPS	22CS5840	K40
PHILIPS	22CS5846	K40M
PHILIPS	22PFL5403D/10	UNKNOWN
PHILIPS	22PFL5503D/10	UNKNOWN
PHILIPS	22PFL5603D/10	UNKNOWN
PHILIPS	23FW5220/37	LC4.2HU AA
PHILIPS	23FW9915/37	LC4.1U AA
PHILIPS	23FW9955/35	LC03U AA

Brand	model	chassis
PHILIPS	23FW9975/35	LC03U AA
PHILIPS	23HF5473/10	LC4.1HE AB
PHILIPS	23HF5474/10	LC4.1HE AB
PHILIPS	23HF9442/98	LC4.2HA AA
PHILIPS	23HF9945/22	LC03HE AA
PHILIPS	23HF9945/22Z	LC03HE AA
PHILIPS	23HF9945/69I	LC03A AA
PHILIPS	23HF9945/93	LC03A AA
PHILIPS	23HM8801/12	LC03E AA
PHILIPS	23HM8801/69	LC03A AA
PHILIPS	23HM8821/12	LC03E AA
PHILIPS	23HM8821/69	LC03A AA
PHILIPS	23IF9946/12	LC4.2E AA
PHILIPS	23MT2336/17	TC5.1U CA
PHILIPS	23MW9010/37	LC03U AA
PHILIPS	23MW9030/37	LC03U AA
PHILIPS	23MW9110/37	LC03U AA
PHILIPS	23MW9130/37	LC03U AA
PHILIPS	23PF3310/01	OLD
PHILIPS	23PF3310/58	OLD
PHILIPS	23PF5320/28	ML1.2U AA
PHILIPS	23PF5320/79	ML1.2A AA
PHILIPS	23PF5320/98	ML1.2A AA
PHILIPS	23PF5321/78	LC4.1L AA
PHILIPS	23PF8946/12	LC4.1E AA
PHILIPS	23PF8946/37	LC4.1U AA
PHILIPS	23PF8946/58	LC4.1E AA
PHILIPS	23PF8946/78	LC4.1L AA
PHILIPS	23PF8946A/37	LC03U AA
PHILIPS	23PF8946M/78	LC4.1L AA
PHILIPS	23PF9320	LC4.3U AA ?
PHILIPS	23PF9945	LC03L AA
PHILIPS	23PF9945/12	LC03E AA
PHILIPS	23PF9945/12A	LC03E AA
PHILIPS	23PF9945/37	LC03U AA

Brand	model	chassis
PHILIPS	23PF9945/58	LC03E AA
PHILIPS	23PF9945/61	LC03A AA
PHILIPS	23PF9945/61S	LC03A AA
PHILIPS	23PF9945/69	LC03A AA
PHILIPS	23PF9945/69S	LC03A AA
PHILIPS	23PF9945/93	LC4.2A AA
PHILIPS	23PF9946/12	LC4.2E AA
PHILIPS	23PF9946/79	LC4.2A AA
PHILIPS	23PF9946/98	LC4.2A AA
PHILIPS	23PF9956/12	LC4.2E AA
PHILIPS	23PF9956/79	LC4.2A AA
PHILIPS	23PF9956/98	LC4.2A AA
PHILIPS	23PF9966/37	LC4.2U AA
PHILIPS	23PF9976I/37	LC4.2U AA
PHILIPS	23PFL5322/01	LC4.1E AC
PHILIPS	23PFL5322/58	LC4.1E AC
PHILIPS	23PFL5522D/05	LC7.2E LB
PHILIPS	23PFL5522D/12	LC7.2E LB
PHILIPS	240BW8EB/00	UNKNOWN
PHILIPS	245096SK	K40-FS/S.
PHILIPS	246077EK	3A
PHILIPS	246171KI	3D
PHILIPS	246177EK	3A
PHILIPS	246377WR	3A
PHILIPS	246623EK	CP110
PHILIPS	246624EK	2B
PHILIPS	246723EK	CP110
PHILIPS	246724EK	2B
PHILIPS	246924WR	2B
PHILIPS	247023EK	CP110
PHILIPS	247023WR	CP110
PHILIPS	247024WR	2B
PHILIPS	247032EK	2A
PHILIPS	247053EK	CP110
PHILIPS	247054EK	2B

Brand	model	chassis
PHILIPS	247062	2A
PHILIPS	247062EK	2A
PHILIPS	247123EK	CP110
PHILIPS	247153EK	CP110
PHILIPS	247723EK	CP110
PHILIPS	247853EK	CP110
PHILIPS	247924EK	2B
PHILIPS	247954EK	2B
PHILIPS	248023WR	CP110
PHILIPS	24CE2370	2A
PHILIPS	24CE2670	2A
PHILIPS	24CE3077	CP110
PHILIPS	24CE3266	CP110
PHILIPS	24CE3267	CP110
PHILIPS	24CE3269	CP110
PHILIPS	24CE3270	CP110
PHILIPS	24CE3271	CP110
PHILIPS	24CE3276	CP110
PHILIPS	24CE3277	CP110
PHILIPS	24CE3278	CP110
PHILIPS	24CE3570	CP110
PHILIPS	24CE3571	CP110
PHILIPS	24CE3578	CP110
PHILIPS	24CE3588	CP110
PHILIPS	24CE4266	2B
PHILIPS	24CE4267	2B
PHILIPS	24CE4270	2B
PHILIPS	24CE4271	2B
PHILIPS	24CE4272	2B
PHILIPS	24CE4273	2B
PHILIPS	24CE4276	2B
PHILIPS	24CE4279	2B
PHILIPS	24CE4570	2B
PHILIPS	24CE4571	2B
PHILIPS	24CE4572	2B

Brand	model	chassis
PHILIPS	24CE4573	2B
PHILIPS	24CE4576	2B
PHILIPS	24CE4577	2B
PHILIPS	24CE4579	2B
PHILIPS	24CE4590	2B
PHILIPS	24CE4591	2B
PHILIPS	24CE4773	2B
PHILIPS	24CE579	2B
PHILIPS	24CE7570	3A
PHILIPS	24CE7571	3A
PHILIPS	24CE7572	3A
PHILIPS	24CE7574	3A
PHILIPS	24CE7770	3A
PHILIPS	24CE7771	3A
PHILIPS	24CE7772	3A
PHILIPS	24CE7777	3A
PHILIPS	24CF5376	TVC15
PHILIPS	24CI1770	3D
PHILIPS	24CI1771	3D
PHILIPS	24CI1777	3D
PHILIPS	24CI1790	3D
PHILIPS	24CI1791	3D
PHILIPS	24CI1797	3D
PHILIPS	24CS6540	K40-FS
PHILIPS	24CS6840	K40-FS
PHILIPS	24CT8883	2B
PHILIPS	24PT633R	LC4.1U AA
PHILIPS	24PT6341/37	L04U
PHILIPS	24PW462A	MD1.0A
PHILIPS	24PW462A/56R	MD1.0A AA
PHILIPS	24PW462A/57R	MD1.0A AA
PHILIPS	24PW462A/75R	MD1.0A AA
PHILIPS	24PW462A/93R	MD1.0A AA
PHILIPS	24PW463A	MD1.0A
PHILIPS	24PW463A/61R	MD1.0A AA

Brand	model	chassis
PHILIPS	24PW463A/71R	MD1.0A AA
PHILIPS	24PW463A/78R	MD1.0A AA
PHILIPS	24PW463A/97R	MD1.0A AA
PHILIPS	24PW469A	MD1.0A
PHILIPS	24PW469A/69R	MD1.0A AA
PHILIPS	24PW469A/79R	MD1.0A AA
PHILIPS	24PW6005	A10E
PHILIPS	24PW6006	L01.1E
PHILIPS	24PW6301	MD1.1E
PHILIPS	24PW6301/03	OLD
PHILIPS	24PW6302	MD1.2E
PHILIPS	24PW6304	A8.0E AA
PHILIPS	24PW6321	MD1.1E
PHILIPS	24PW6322	MD1.2E
PHILIPS	24PW6324	A8.0E AA
PHILIPS	24PW6506/01	OLD
PHILIPS	24PW6506/05	OLD
PHILIPS	24PW6818/01	L01.1E AA;L01.1E AB
PHILIPS	24PW6818/05	L01.1E AA;L01.1E AB
PHILIPS	24PW8504	MG2.1E
PHILIPS	24PW9502	MD2.12E
PHILIPS	24PW9553	MD2.21E
PHILIPS	24PW9553	MD2.22E
PHILIPS	24PW9553/12	MD2.22E AA
PHILIPS	24PW9553/19	MD2.22E AA
PHILIPS	24ST2200/27	L04HU AA
PHILIPS	25 SA01/0	L9.1E
PHILIPS	250175IR	G110
PHILIPS	250571SB	GR2.1
PHILIPS	250861SB	GR2.1
PHILIPS	252961SB	GR2.1
PHILIPS	254961SB	GR2.1
PHILIPS	255231CB	GR2.1
PHILIPS	255251CB	GR2.2
PHILIPS	255741CB	GR2.2

Brand	model	chassis
PHILIPS	255831CB	GR2.2
PHILIPS	255831CB/>20	GR2.2
PHILIPS	255942SB	GR2.2
PHILIPS	255962SB	GR2.2
PHILIPS	256265IR	G110
PHILIPS	256269IR	G110 SVHS
PHILIPS	256275IR	G110
PHILIPS	256275KR	FL1.10
PHILIPS	256279IR	G110 SVHS
PHILIPS	256289IR	G110
PHILIPS	256297WQ	FL1.0
PHILIPS	256341SB	GR2.1
PHILIPS	256362BX	D16
PHILIPS	256372SB	GR2.2
PHILIPS	256392SB	GR2.2
PHILIPS	256575KR	FL1.0
PHILIPS	256597WQ	FL1.0
PHILIPS	256665IR	G110
PHILIPS	256769IR	G110
PHILIPS	256775IR	G110
PHILIPS	256779IR	G110
PHILIPS	256861SB	GR2.1
PHILIPS	256862SB	GR2.2
PHILIPS	256865IR	G110
PHILIPS	256961SB	GR2.1
PHILIPS	257126EK	CP110
PHILIPS	257156EK	CP110
PHILIPS	257325EK	2B
PHILIPS	257326EK	CP110
PHILIPS	257355EK	2B
PHILIPS	257356EK	CP110
PHILIPS	257426EK	CP110
PHILIPS	257626EK	CP110
PHILIPS	257925EK	2B-F
PHILIPS	257925WR	2B-F

Brand	model	chassis
PHILIPS	257926EK	CP110
PHILIPS	258279IR	G110 SVHS
PHILIPS	25CE5270	2B
PHILIPS	25CE5276	2B
PHILIPS	25CE5570	2B
PHILIPS	25CE5571	2B
PHILIPS	25CE5573	2B
PHILIPS	25CE5574	2B
PHILIPS	25CE5575	2B
PHILIPS	25CE6269	CP110
PHILIPS	25CE6270	CP110
PHILIPS	25CE6271	CP110
PHILIPS	25CE6276	CP110
PHILIPS	25CE6277	CP110
PHILIPS	25CE6286	CP110
PHILIPS	25CE6287	CP110
PHILIPS	25CE6569	CP110
PHILIPS	25CE6570	CP110
PHILIPS	25CE6571	CP110
PHILIPS	25CE6578	CP110
PHILIPS	25CE7590	3A
PHILIPS	25CT8880	2B
PHILIPS	25CT8883	2B-S
PHILIPS	25CT8884	2B
PHILIPS	25CT9085/62	CTO-S
PHILIPS	25CT9085/73	CTO-N
PHILIPS	25DC2060	D16
PHILIPS	25DC2065	D16
PHILIPS	25DC2560	D16
PHILIPS	25DC2660	D16
PHILIPS	25ET2764	GR2.2
PHILIPS	25F800-7583	F8 (25F8)
PHILIPS	25FL1760	FL1.0S
PHILIPS	25FL1765	FL1.0S
PHILIPS	25GR1990	G110-S

Brand	model	chassis
PHILIPS	25GR2552	G90AE
PHILIPS	25GR5560	G110
PHILIPS	25GR5616	G110
PHILIPS	25GR5660	G110
PHILIPS	25GR5664	G110
PHILIPS	25GR5666	G110
PHILIPS	25GR5667	G110
PHILIPS	25GR5668	G110
PHILIPS	25GR5711	G110
PHILIPS	25GR5716	G110
PHILIPS	25GR5721	G110
PHILIPS	25GR5731	G110
PHILIPS	25GR5760	G110
PHILIPS	25GR5762	G110
PHILIPS	25GR5763	G110
PHILIPS	25GR5764	G110
PHILIPS	25GR5765	G110
PHILIPS	25GR5768	G110
PHILIPS	25GR5775	G110
PHILIPS	25GR5868	G110 SVHS
PHILIPS	25GR5964	G110 SVHS
PHILIPS	25GR6765	G110
PHILIPS	25GR6766	G110-S
PHILIPS	25GR6770	G111-S
PHILIPS	25GR6771	G110
PHILIPS	25GR9660	G110
PHILIPS	25GR9666	G110
PHILIPS	25GR9667	G110
PHILIPS	25GR9760	G110 SVHS
PHILIPS	25GR9761	G110
PHILIPS	25GR9762	G110 SVHS
PHILIPS	25GR9763	G110
PHILIPS	25GR9765	G110
PHILIPS	25GR9768	G110
PHILIPS	25GR9867	G110

Brand	model	chassis
PHILIPS	25GR9960	G110
PHILIPS	25GR9963	G110
PHILIPS	25GR9968	G110
PHILIPS	25GR9975	G110
PHILIPS	25GX1880	ANUBIS S
PHILIPS	25GX1881	ANUBIS S
PHILIPS	25GX1882	ANUBIS S
PHILIPS	25GX1885	ANUBIS S
PHILIPS	25GX1886	ANUBIS S
PHILIPS	25GX1887	ANUBIS S
PHILIPS	25GX1887/71R	OLD
PHILIPS	25GX1980	ANUBIS S
PHILIPS	25GX1985	ANUBIS S
PHILIPS	25HT2011/69Z	L01H.1A AA
PHILIPS	25HT2011/94Z	L01H.1A AA
PHILIPS	25HT2012/79R	L01H.1A AA
PHILIPS	25HT2012/93R	L01H.1A AA
PHILIPS	25HT2211/69Z	L01H.1A AA
PHILIPS	25HT2212	L01H.1A
PHILIPS	25HT2212/67R	L01H.1A AA
PHILIPS	25HT2212/69R	L01H.1A AA
PHILIPS	25HT2212/93R	L01H.1A AA
PHILIPS	25HT2217/69Y	L01H.1A AA
PHILIPS	25HT2217/79Y	L01H.1A AA
PHILIPS	25HT2217/93Y	L01H.1A AA
PHILIPS	25HT3312/69R	L04HA AA
PHILIPS	25HT3312/79R	L04HA AA
PHILIPS	25HT3312/93R	L04HA AA
PHILIPS	25HT3317/69Y	L04HA AA
PHILIPS	25HT3317/79Y	L04HA AA
PHILIPS	25HT3317/93Y	L04HA AA
PHILIPS	25HT3352	A7H.1
PHILIPS	25HT3402	A7H.1
PHILIPS	25HT4672	L9H.1A
PHILIPS	25HT4672/69R	L9H.1A AA

Brand	model	chassis
PHILIPS	25HT4672/71R	L9H.1A AA
PHILIPS	25HT4672/79R	L9H.1A AA
PHILIPS	25HT4672/94R	L9H.1A AA
PHILIPS	25HT4677	L9H.1A
PHILIPS	25HT4677/57Y	L9H.1A AA
PHILIPS	25HT4677/69Y	L9H.1A AA
PHILIPS	25HT4677/79Y	L9H.1A AA
PHILIPS	25HT4677/94Y	L9H.1A AA
PHILIPS	25HT4822	L9H.1A
PHILIPS	25HT5403	L9H.1E
PHILIPS	25HT5403/01Z	L9H.1E AA
PHILIPS	25HT5403/05Z	L9H.1E AA
PHILIPS	25HT5403/21R	L9H.1E AA
PHILIPS	25HT5403/25R	L9H.1E AA
PHILIPS	25HT5403/58Z	L9H.1E AA
PHILIPS	25HT5403/78R	L9H.1E AA
PHILIPS	25HT5404/01B	L01H.1E AA
PHILIPS	25HT5404/01Z	L01H.1E AA
PHILIPS	25HT5404/05Z	L01H.1E AA
PHILIPS	25HT5404/21R	L01H.1E AA
PHILIPS	25HT5404/25R	L01H.1E AA
PHILIPS	25HT5423	L9H.1E
PHILIPS	25HT5423/21R	L9H.1E AA
PHILIPS	25HT5423/25R	L9H.1E AA
PHILIPS	25HT548A/77H	OLD
PHILIPS	25HT548A/77S	OLD
PHILIPS	25HT5531/77S	L01H.1L AA
PHILIPS	25HT5531/78S	L01H.1L AA
PHILIPS	25HT5541/77S	L04HL AA
PHILIPS	25HT5541/78S	L04HL AA
PHILIPS	25L105/35R	M8 AA
PHILIPS	25L105/37R	M8 AA
PHILIPS	25L105/85R	M8 AA
PHILIPS	25L130/35R	M8 AA
PHILIPS	25L130/37R	M8 AA;T8 AA

Brand	model	chassis
PHILIPS	25L130/85R	M8 AA
PHILIPS	25L140/35R	M8 AA
PHILIPS	25L140/37R	OLD
PHILIPS	25L140/37R1	OLD
PHILIPS	25L140/85R	OLD
PHILIPS	25L150/35R	M8 AA
PHILIPS	25L150/37R	OLD
PHILIPS	25L150/85R	OLD
PHILIPS	25L230/37R	OLD
PHILIPS	25LP122PL/17R	OLD
PHILIPS	25LP124PC/17R	OLD
PHILIPS	25LP21/40A	OLD
PHILIPS	25LP21/40C	OLD
PHILIPS	25LP22/37R	OLD
PHILIPS	25LP22/40C	OLD
PHILIPS	25LP222/37R	OLD
PHILIPS	25LP222/40C	OLD
PHILIPS	25LP23/87R	OLD
PHILIPS	25LP232/87R	OLD
PHILIPS	25LP24/37R	OLD
PHILIPS	25LP24/40C	OLD
PHILIPS	25LP242	OLD
PHILIPS	25LP242/37R	OLD
PHILIPS	25LP242/40C	OLD
PHILIPS	25LP26/40A	OLD
PHILIPS	25LP26/40B	OLD
PHILIPS	25LP26/40C	OLD
PHILIPS	25LP26/40D	OLD
PHILIPS	25LP26/40P	OLD
PHILIPS	25M800	25M8
PHILIPS	25MK2480	MK2
PHILIPS	25MK2780	MK2
PHILIPS	25ML8300	FL1.7
PHILIPS	25ML8305	FL1.7
PHILIPS	25ML8500	FL1.6

Brand	model	chassis
PHILIPS	25ML8505	FL1.6
PHILIPS	25ML8760	FL1.1
PHILIPS	25ML8766	FL1.1
PHILIPS	25ML8776	FL1.1
PHILIPS	25ML8960	FL1.1
PHILIPS	25ML8966	FL1.1
PHILIPS	25MN1350	GR2.1
PHILIPS	25MN1350/>20	GR2.2
PHILIPS	25MN1353	GR2.2
PHILIPS	25MN1353/<20	GR2.2
PHILIPS	25MN1355	GR2.2
PHILIPS	25MN1355/<20	GR2.2
PHILIPS	25MN1356	GR2.2
PHILIPS	25MN1356/>20	GR2.2
PHILIPS	25MN1370	GR2.1
PHILIPS	25MN1550	GR2.1
PHILIPS	25MN1550/>20	GR2.2
PHILIPS	25MN1550/22B	GR2AA
PHILIPS	25MN1553	GR2.2
PHILIPS	25PT10C121	F8 (25F8)
PHILIPS	25PT2152/56A	L01.1A AA
PHILIPS	25PT2152/65R	L01.1A AA
PHILIPS	25PT2152/67R	L01.1A AA
PHILIPS	25PT2152/68R	L01.1A AA
PHILIPS	25PT2152/69R	L01.1A AA
PHILIPS	25PT2152/71R	L01.1A AA
PHILIPS	25PT2152/79R	L01.1A AA
PHILIPS	25PT2252	L01.1A
PHILIPS	25PT2252/56A	L01.1A AA
PHILIPS	25PT2252/57R	L01.1A AA
PHILIPS	25PT2252/67R	L01.1A AA
PHILIPS	25PT2252/68R	L01.1A AA
PHILIPS	25PT2252/69R	L01.1A AA
PHILIPS	25PT2252/71R	L01.1A AA
PHILIPS	25PT2252/79R	L01.1A AA

Brand	model	chassis
PHILIPS	25PT233A	PV4.0 AA
PHILIPS	25PT2435/94R	L01.1A AA
PHILIPS	25PT2455/94R	L01.1A AA
PHILIPS	25PT2511/93R	L01.1A AA
PHILIPS	25PT2521/93R	L01.1A AA
PHILIPS	25PT263A	PV4.0 AA
PHILIPS	25PT3252	A7H.1
PHILIPS	25PT3323	L01.1A
PHILIPS	25PT3323/56	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/56R	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/61R	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/67R	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/69	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/69R	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/69S	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/71	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/71R	L01.1A AC;L2K3 AA
PHILIPS	25PT3323/94	L01.1A AC;L2K3 AA
PHILIPS	25PT3523/93R	L01.1A AC;L2K3 AA
PHILIPS	25PT3532/93R	OLD
PHILIPS	25PT4001	AA5 AB
PHILIPS	25PT400A	GR2.2
PHILIPS	25PT4051	AA5 AB
PHILIPS	25PT405A	GR2.2
PHILIPS	25PT4101	AA5 AB
PHILIPS	25PT4103	L6.2
PHILIPS	25PT4103/00	L6.2 AA
PHILIPS	25PT4103/01	L6.2 AA
PHILIPS	25PT4103/05	L6.2 AA
PHILIPS	25PT4103/07	L6.2 AA
PHILIPS	25PT4103/15	L6.2 AA
PHILIPS	25PT4103/39	L6.2 AA
PHILIPS	25PT4103/58	L6.2 AA
PHILIPS	25PT4103/58H	L6.2 AA
PHILIPS	25PT4103/58P	L6.2 AA

Brand	model	chassis
PHILIPS	25PT4103/60	L6.2 AA
PHILIPS	25PT4104	L9.1E AA
PHILIPS	25PT4104	L9.1E AA
PHILIPS	25PT4107	L01.2E
PHILIPS	25PT410A	ANUBIS B
PHILIPS	25PT410A	GR2.2
PHILIPS	25PT4151	AA5 AB
PHILIPS	25PT415A	GR2.2
PHILIPS	25PT420A	GR2.2
PHILIPS	25PT4223	L9.1A
PHILIPS	25PT4224	L9.1A
PHILIPS	25PT4273	L9.1A
PHILIPS	25PT4275	L9.1E
PHILIPS	25PT4301	MD1.1E
PHILIPS	25PT4301/02	OLD
PHILIPS	25PT4320/56A	OLD
PHILIPS	25PT4320/57R	OLD
PHILIPS	25PT4320/67R	OLD
PHILIPS	25PT4320/68R	OLD
PHILIPS	25PT4320/69R	OLD
PHILIPS	25PT4320/71R	OLD
PHILIPS	25PT4320/79R	OLD
PHILIPS	25PT4320/93R	OLD
PHILIPS	25PT4323	L6.2
PHILIPS	25PT4323/56R	L01.1A AC;L2K3 AA
PHILIPS	25PT4323/56S	L01.1A AC;L2K3 AA
PHILIPS	25PT4323/61R	L01.1A AC;L2K3 AA
PHILIPS	25PT4323/67R	L01.1A AC;L2K3 AA
PHILIPS	25PT4323/69R	L01.1A AC;L2K3 AA
PHILIPS	25PT4323/69S	L01.1A AC;L2K3 AA
PHILIPS	25PT4323/71R	L01.1A AC;L2K3 AA
PHILIPS	25PT4323/79R	L01.1A AC;L2K3 AA
PHILIPS	25PT4324/93S	OLD
PHILIPS	25PT4342	L9.1A
PHILIPS	25PT4375	L9.1E

Brand	model	chassis
PHILIPS	25PT4401	MD1.1E
PHILIPS	25PT4403	L6.2
PHILIPS	25PT4403/00	L6.2 AA
PHILIPS	25PT4403/43	L6.2 AA
PHILIPS	25PT440A	GR2.2
PHILIPS	25PT4411	MD1.1E
PHILIPS	25PT4421	MD1.1E
PHILIPS	25PT4421/13	OLD
PHILIPS	25PT4423	L6.2
PHILIPS	25PT4423/58	L6.2 AA
PHILIPS	25PT4423/58P	L6.2 AA
PHILIPS	25PT4426/58	OLD
PHILIPS	25PT4428	L7.3
PHILIPS	25PT4428/67R	L7.3A AA
PHILIPS	25PT4428/68R	L7.3A AA
PHILIPS	25PT4428/70R	L7.3A AA
PHILIPS	25PT4428/75R	L7.3A AA
PHILIPS	25PT4428/94R	L7.3A AA
PHILIPS	25PT442A	GR2.2
PHILIPS	25PT443A	GR2.4
PHILIPS	25PT4454	L6.3
PHILIPS	25PT4455	L9.1E
PHILIPS	25PT4456	L9.1E
PHILIPS	25PT4457	L01.1E
PHILIPS	25PT4473	L7.3A
PHILIPS	25PT4473/69R	L7.3A AA
PHILIPS	25PT4473/69T	L7.3A AA
PHILIPS	25PT4473/75R	L7.3A AA
PHILIPS	25PT4473/75T	L7.3A AA
PHILIPS	25PT4473/79R	L7.3A AA
PHILIPS	25PT4475	L9.1E AA
PHILIPS	25PT4476	L9.1A
PHILIPS	25PT448A	PV4.0 AA
PHILIPS	25PT4494	L6.3
PHILIPS	25PT4494/05	L6.3 AA

Brand	model	chassis
PHILIPS	25PT4501	MD1.1E
PHILIPS	25PT4503	MD1.1E
PHILIPS	25PT4503	MD1.2E AA
PHILIPS	25PT450A	GR2.2
PHILIPS	25PT4511	MD1.1E
PHILIPS	25PT4511/22	OLD
PHILIPS	25PT4512	MD1.1E
PHILIPS	25PT4513	MD1.2E
PHILIPS	25PT451A	GR2.2
PHILIPS	25PT4521	MD1.1
PHILIPS	25PT4523	MD1.2E
PHILIPS	25PT4524	A8.0E
PHILIPS	25PT4524/93R	L04A AA
PHILIPS	25PT452A	GR2.2
PHILIPS	25PT4531/77R	L01.1L AC
PHILIPS	25PT4622	L7.3A
PHILIPS	25PT4622/61R	L7.3A AA
PHILIPS	25PT4622/71R	L7.3A AA
PHILIPS	25PT4622/77R	L7.3A AA
PHILIPS	25PT4623	L7.3A
PHILIPS	25PT4623/56A	L7.3A AA
PHILIPS	25PT4623/56R	L7.3A AA
PHILIPS	25PT4623/56T	L7.3A AA
PHILIPS	25PT4623/57R	L7.3A AA
PHILIPS	25PT4623/57T	L7.3A AA
PHILIPS	25PT4623/67R	L7.3A AA
PHILIPS	25PT4623/73R	L7.3A AA
PHILIPS	25PT4623/74R	L7.3A AA
PHILIPS	25PT4623/P00	L7.3A AA
PHILIPS	25PT462A	PV4.0 AA
PHILIPS	25PT462A/69R	OLD
PHILIPS	25PT4632	L7.3A
PHILIPS	25PT4632	L9.1A
PHILIPS	25PT463A	PV4.0 AA
PHILIPS	25PT463A/71R	OLD

Brand	model	chassis
PHILIPS	25PT4642	L7.3A
PHILIPS	25PT4642	L9.1A
PHILIPS	25PT4654	L6.3
PHILIPS	25PT4655	L9.1E
PHILIPS	25PT4673	L7.3A
PHILIPS	25PT4673/68R	L7.3A AA
PHILIPS	25PT4673/69R	L7.3A AA
PHILIPS	25PT4673/69T	L7.3A AA
PHILIPS	25PT4673/70R	L7.3A AA
PHILIPS	25PT4673/75R	L7.3A AA
PHILIPS	25PT4673/79R	L7.3A AA
PHILIPS	25PT4673/79T	L7.3A AA
PHILIPS	25PT4674/01	L6.3 AA
PHILIPS	25PT4675	L9.1E
PHILIPS	25PT4676	L7.3A
PHILIPS	25PT4676/69V	L7.3A AA
PHILIPS	25PT468A	PV4.0 AA
PHILIPS	25PT468A/73R	OLD
PHILIPS	25PT4701	MD1.1E
PHILIPS	25PT470A	GR2.2
PHILIPS	25PT4721	MD1.1
PHILIPS	25PT4721/13	OLD
PHILIPS	25PT4721/16	OLD
PHILIPS	25PT4721/33	OLD
PHILIPS	25PT472A	GR2.2
PHILIPS	25PT472B	GR2.4
PHILIPS	25PT480A	GR2.2
PHILIPS	25PT480B	GR2.2
PHILIPS	25PT480C	GR2.2
PHILIPS	25PT4811	MD1.1E
PHILIPS	25PT481B	GR2.2
PHILIPS	25PT4821	MD1.1E
PHILIPS	25PT4822	L9.1A
PHILIPS	25PT4823	L9.1E
PHILIPS	25PT482A	GR2.2

Brand	model	chassis
PHILIPS	25PT4873	L9.1A
PHILIPS	25PT490A	GR2.2
PHILIPS	25PT492A	GR2.2
PHILIPS	25PT5005	L9.1E
PHILIPS	25PT5007/01	L01.1E AA;L01.1E AB
PHILIPS	25PT5016/56	L01.1A AC;L2K3 AA
PHILIPS	25PT5016/69	L01.1A AC;L2K3 AA
PHILIPS	25PT5016/71	L01.1A AC;L2K3 AA
PHILIPS	25PT5016/94	L01.1A AC;L2K3 AA
PHILIPS	25PT5025	L9.1E
PHILIPS	25PT5101	MD1.1E
PHILIPS	25PT5105	L9.1E
PHILIPS	25PT5106	L9.1E
PHILIPS	25PT5107	L01.1E
PHILIPS	25PT5107/05	OLD
PHILIPS	25PT510A	GR2.2
PHILIPS	25PT510B/00	GR2.2
PHILIPS	25PT5111	MD1.1E
PHILIPS	25PT5121	MD1.1
PHILIPS	25PT5121/13	OLD
PHILIPS	25PT5123	MD1.2E
PHILIPS	25PT5124	A8.0E
PHILIPS	25PT5125	L9.1E
PHILIPS	25PT512A	GR2.2
PHILIPS	25PT512B	GR2.2
PHILIPS	25PT512C	GR2.4
PHILIPS	25PT5155	L9.1E
PHILIPS	25PT5207	L01.2E
PHILIPS	25PT5207/60	L01.1A AC;L2K3 AA
PHILIPS	25PT5207/60S	L01.1A AC;L2K3 AA
PHILIPS	25PT520A	GR2.2
PHILIPS	25PT520B	GR2.4
PHILIPS	25PT521B	GR2.2
PHILIPS	25PT522A	GR2.2
PHILIPS	25PT522B	GR2.4

Brand	model	chassis
PHILIPS	25PT5255	L9.1E
PHILIPS	25PT528A/55R	OLD
PHILIPS	25PT528A/78R	OLD
PHILIPS	25PT5301	GR2.4
PHILIPS	25PT5302	MD1.2E
PHILIPS	25PT5304	A8.0E
PHILIPS	25PT5305	L9.1E AB
PHILIPS	25PT5307	L01AT6 1.1
PHILIPS	25PT5307/60	L01.1A AC;L2K3 AA
PHILIPS	25PT5307/60S	L01.1A AC;L2K3 AA
PHILIPS	25PT530A	GR2.2
PHILIPS	25PT530B	GR2.4
PHILIPS	25PT530B/00	GR2.4
PHILIPS	25PT530C	GR2.4
PHILIPS	25PT5321	GR2.4
PHILIPS	25PT5322	MD1.2E AA
PHILIPS	25PT5322	MD1.2E AA
PHILIPS	25PT5324	A8.0E
PHILIPS	25PT532A	GR2.2
PHILIPS	25PT532B	GR2.4
PHILIPS	25PT5401	GR2.4
PHILIPS	25PT5402	GR2.4
PHILIPS	25PT5403	MD1.2E
PHILIPS	25PT5405	A8.0E
PHILIPS	25PT540A	GR2.2
PHILIPS	25PT540B	GR2.4
PHILIPS	25PT541B	GR2.4
PHILIPS	25PT5423	MD1.2E
PHILIPS	25PT5424	MD1.2E
PHILIPS	25PT5425	A8.0E
PHILIPS	25PT542A	GR2.2
PHILIPS	25PT542B	GR2.4
PHILIPS	25PT544A	L9.1A
PHILIPS	25PT548A/77R	L01.1L AA
PHILIPS	25PT550A	GR2.2

Brand	model	chassis
PHILIPS	25PT550B	GR2.4
PHILIPS	25PT5531	L01.1L AC 2K3
PHILIPS	25PT5531/55R	L01.1L AC
PHILIPS	25PT5531/77R	L01.1L AC
PHILIPS	25PT5531/78R	L01.1L AC
PHILIPS	25PT5536/77	L01.1L AC
PHILIPS	25PT5536/78	L01.1L AC
PHILIPS	25PT5541/44	L04L AA
PHILIPS	25PT5541/55	L04L AA
PHILIPS	25PT5541/77	L04L AA
PHILIPS	25PT5541/78	L04L AA
PHILIPS	25PT5541/78	L04U AA
PHILIPS	25PT560A	GR2.3
PHILIPS	25PT5621	GR2.4
PHILIPS	25PT562A	GR2.3
PHILIPS	25PT570A	GR2.2
PHILIPS	25PT570B	GR2.4
PHILIPS	25PT572A	GR2.3
PHILIPS	25PT620B	GR2.4
PHILIPS	25PT622B	GR2.4
PHILIPS	25PT630A	GR2.4
PHILIPS	25PT6322	MD1.2E
PHILIPS	25PT632A	GR2.4
PHILIPS	25PT6331/44R	OLD
PHILIPS	25PT6341/85	L04L AA
PHILIPS	25PT7001	GR2.4
PHILIPS	25PT700B	GR2.4
PHILIPS	25PT7021	GR2.4
PHILIPS	25PT702B	GR2.4
PHILIPS	25PT7106	EM2E
PHILIPS	25PT720B	GR2.4
PHILIPS	25PT722B	GR2.4
PHILIPS	25PT727B	GR2.4
PHILIPS	25PT7302	MD2.12
PHILIPS	25PT7302	MD2.21E

Brand	model	chassis
PHILIPS	25PT7302	MG2.1E
PHILIPS	25PT7302/12	MD2.11 AA
PHILIPS	25PT7303	MD2.21E
PHILIPS	25PT7303/12	MD2.21E AA
PHILIPS	25PT7304	MD2.1E
PHILIPS	25PT800A	FL1.17
PHILIPS	25PT800B	FL1.17
PHILIPS	25PT802A	FL1.17
PHILIPS	25PT802B	FL1.17
PHILIPS	25PT805A	FL1.17
PHILIPS	25PT805B	FL4.17
PHILIPS	25PT815A	FL1.17
PHILIPS	25PT817A	FL1.17
PHILIPS	25PT820A	FL4.17
PHILIPS	25PT822A	FL4.17
PHILIPS	25PT825A	FL4.16
PHILIPS	25PT825A/00	FL4.16
PHILIPS	25PT825B	FL4.26
PHILIPS	25PT827A	FL4.16
PHILIPS	25PT827B	FL4.26
PHILIPS	25PT8302	MD2.12
PHILIPS	25PT8303	MD2.21 AA
PHILIPS	25PT8303/12	MD2.22E AA
PHILIPS	25PT8303/19	MD2.22E AA
PHILIPS	25PT8303/58	MD2.22E AA
PHILIPS	25PT8304	MG2.1E AA
PHILIPS	25PT848A/44R	L01.1L AA
PHILIPS	25PT848A/55R	L01.1L AA
PHILIPS	25PT848A/77R	L01.1L AA
PHILIPS	25PT848A/78R	L01.1L AA
PHILIPS	25PT8702	MD2.12
PHILIPS	25PT8703	MD2.21
PHILIPS	25PT8703	MD2.22 AA
PHILIPS	25PT8703	MD2.23E AA
PHILIPS	25PT8703/12	MD2.22E AA

Brand	model	chassis
PHILIPS	25PT8703/32	MD2.25E AA
PHILIPS	25PT9001	GFL2.20E AA
PHILIPS	25PT900A	FL2.16
PHILIPS	25PT900B	FL2.26
PHILIPS	25PT900C	GFL5
PHILIPS	25PT9011	5GFL2.20E
PHILIPS	25PT9021	GFL2.20E AA
PHILIPS	25PT902A	FL2.16
PHILIPS	25PT902B	FL2.26
PHILIPS	25PT902C	GFL5
PHILIPS	25PT9031	GFL2.20E AA
PHILIPS	25PT9101	GFL2.20E AA
PHILIPS	25PT910A	FL2.16
PHILIPS	25PT910B	FL2.26
PHILIPS	25PT9121	GFL2.20E AA
PHILIPS	25PT912A	FL2.16
PHILIPS	25PT912B	FL2.26
PHILIPS	25PT912D	GFL2.20E AA
PHILIPS	25PV720	TVCR D (TVCR Delta2000 czy? TVCR Delta99)
PHILIPS	25PV720	TVCR DELTA99 AA
PHILIPS	25PV7505	FL1.0
PHILIPS	25PV7505	FL1.10
PHILIPS	25PV7505	FL1.8
PHILIPS	25PV7506	FL1.0
PHILIPS	25PV7506	FL1.10
PHILIPS	25PV7960	FL1.0
PHILIPS	25PV7966	FL1.0
PHILIPS	25PV7970	FL1.0
PHILIPS	25PV7976	FL1.0
PHILIPS	25PV808	TVCR D (TVCR Delta2000)
PHILIPS	25PV815	TVCR D (TVCR Delta2000)
PHILIPS	25RFL160/37R	M8 AA
PHILIPS	25RFL160/85R	M8 AA
PHILIPS	25SL5500	FL1.0
PHILIPS	25SL5500	FL1.10

Brand	model	chassis
PHILIPS	25SL5501	FL1.0
PHILIPS	25SL5501	FL1.10
PHILIPS	25SL5760	FL1.0
PHILIPS	25SL5766	FL1.0
PHILIPS	25SL5800	FL1.0
PHILIPS	25SP1688	G112
PHILIPS	25SP1698	G112
PHILIPS	25SP1788	G112
PHILIPS	25ST1603	GR2.1
PHILIPS	25ST1607	GR2.1
PHILIPS	25ST1617	GR2.1
PHILIPS	25ST1627	GR2.1
PHILIPS	25ST1660	GR2.1
PHILIPS	25ST1666	GR2.1
PHILIPS	25ST1667	GR2.1
PHILIPS	25ST1687	GR2.1
PHILIPS	25ST1702	GR2.1
PHILIPS	25ST1704	GR2.1
PHILIPS	25ST1707	GR2.1
PHILIPS	25ST1724	GR2.1
PHILIPS	25ST1750	GR2.1
PHILIPS	25ST1760	GR2.1
PHILIPS	25ST1761	GR2.1
PHILIPS	25ST1767	GR2.1
PHILIPS	25ST1804	GR2.1
PHILIPS	25ST1861	GR2.1
PHILIPS	25ST1881	GR2.1
PHILIPS	25ST2161	GR2.2
PHILIPS	25ST2167	GR2.2
PHILIPS	25ST2451	GR2.2
PHILIPS	25ST2454	GR2.2
PHILIPS	25ST2457	GR2.2
PHILIPS	25ST2657	GR2.2
PHILIPS	25ST2664	GR2.2
PHILIPS	25ST2666	GR2.2

Brand	model	chassis
PHILIPS	25ST2751	GR2.2
PHILIPS	25ST2759	GR2.2
PHILIPS	25ST2760	GR2.2
PHILIPS	25ST2761	GR2.2
PHILIPS	25ST2767	GR2.2
PHILIPS	25ST2769	GR2.2
PHILIPS	25ST2860	GR2.2
PHILIPS	25ST2864	GR2.2
PHILIPS	25ST2961	GR2.2
PHILIPS	25ST2967	GR2.2
PHILIPS	25SX8661	G8
PHILIPS	25SX8662	G8
PHILIPS	25SX8663	G8
PHILIPS	25SX8666	G8.1
PHILIPS	25SX8667	G8
PHILIPS	25SX8668	G8
PHILIPS	25SX8761	G8
PHILIPS	25SX8766	G8.1
PHILIPS	25TR19C225	F8 (25F8)
PHILIPS	260201SK	K30
PHILIPS	260221SK	K30
PHILIPS	260801SK	K30
PHILIPS	2617	K35
PHILIPS	262521SK	K30M
PHILIPS	2627	K35
PHILIPS	262821SK	K30
PHILIPS	266122EK	2A
PHILIPS	267003SK	K35
PHILIPS	267023SK	K35
PHILIPS	267025SK	K40
PHILIPS	267073SK	K35
PHILIPS	267075SK	K40
PHILIPS	267103SK	K35M
PHILIPS	267475SK	K40
PHILIPS	267523SK	K35

Brand	model	chassis
PHILIPS	267573SK	K35
PHILIPS	267623	K35
PHILIPS	267673	K35
PHILIPS	268002EK	2A
PHILIPS	268022EK	2A
PHILIPS	268052EK	2A
PHILIPS	268075SK	K40
PHILIPS	268083SK	K35
PHILIPS	268084SK	K40
PHILIPS	268094SK	K40-SYS.T
PHILIPS	268102EK	2A
PHILIPS	268122EK	2A
PHILIPS	268152EK	2A
PHILIPS	269033SK	K35
PHILIPS	269575SK	K40
PHILIPS	26C568	K11
PHILIPS	26CE2080	2A
PHILIPS	26CE2081	2A
PHILIPS	26CE2281	2A
PHILIPS	26CE2282	2A
PHILIPS	26CE2581	2A
PHILIPS	26CE2582	2A
PHILIPS	26CE4386	2B
PHILIPS	26CE4691	2B
PHILIPS	26CS1005	K30
PHILIPS	26CS1006	K30
PHILIPS	26CS1009	K30
PHILIPS	26CS1011	K30
PHILIPS	26CS1012	K30
PHILIPS	26CS1015	K30M
PHILIPS	26CS1203	K30
PHILIPS	26CS1204	K30
PHILIPS	26CS1205	K30
PHILIPS	26CS1207	K30
PHILIPS	26CS1213	K30

Brand	model	chassis
PHILIPS	26CS1215	K30
PHILIPS	26CS1220	K30
PHILIPS	26CS1221	K30
PHILIPS	26CS1223	K30
PHILIPS	26CS1224	K30
PHILIPS	26CS1227	K30
PHILIPS	26CS1229	K30
PHILIPS	26CS1231	K30
PHILIPS	26CS1231/42	K30-SCAN
PHILIPS	26CS1232	K30
PHILIPS	26CS1233	K30
PHILIPS	26CS1239	K30M
PHILIPS	26CS1250	K30
PHILIPS	26CS1251	K30
PHILIPS	26CS1264	K30
PHILIPS	26CS1267	K30
PHILIPS	26CS1268	K30
PHILIPS	26CS1270	K30
PHILIPS	26CS1271	K30
PHILIPS	26CS3070	K35
PHILIPS	26CS3071	K35
PHILIPS	26CS3075	K35M
PHILIPS	26CS3270	K35
PHILIPS	26CS3271	K35M
PHILIPS	26CS3274	K35
PHILIPS	26CS3275	K35
PHILIPS	26CS3276	K35
PHILIPS	26CS3277	K35
PHILIPS	26CS3278	K35
PHILIPS	26CS3280	K35
PHILIPS	26CS3281	K35
PHILIPS	26CS3285	K35
PHILIPS	26CS3290	K35
PHILIPS	26CS3295	K35
PHILIPS	26CS3296	K35

Brand	model	chassis
PHILIPS	26CS3370	K35
PHILIPS	26CS3371	K35M
PHILIPS	26CS3372	K35
PHILIPS	26CS3374	K35
PHILIPS	26CS3375	K35
PHILIPS	26CS3376	K35
PHILIPS	26CS3377	K35
PHILIPS	26CS3378	K35
PHILIPS	26CS3380	K35
PHILIPS	26CS3381	K35
PHILIPS	26CS3385	K35
PHILIPS	26CS3387	K35
PHILIPS	26CS3390	K35
PHILIPS	26CS3391	K35
PHILIPS	26CS3393	K35
PHILIPS	26CS3394	K35
PHILIPS	26CS3395	K35
PHILIPS	26CS3396	K35
PHILIPS	26CS3397	K35
PHILIPS	26CS3398	K35
PHILIPS	26CS3399	K35
PHILIPS	26CS3470	K35
PHILIPS	26CS3471	K35
PHILIPS	26CS3476	K35
PHILIPS	26CS3490	K35
PHILIPS	26CS3573	K35
PHILIPS	26CS3574	K35
PHILIPS	26CS3575	K35
PHILIPS	26CS3590	K35
PHILIPS	26CS3595	K35
PHILIPS	26CS3770	K35
PHILIPS	26CS3771	K35M
PHILIPS	26CS3775	K35
PHILIPS	26CS3776	K35
PHILIPS	26CS3778	K35

Brand	model	chassis
PHILIPS	26CS3780	K35
PHILIPS	26CS3790	K35
PHILIPS	26CS3791	K35
PHILIPS	26CS3870	K35
PHILIPS	26CS3880	K35
PHILIPS	26CS3881	K35
PHILIPS	26CS3890	K35
PHILIPS	26CS3892	K35
PHILIPS	26CS3895	K35
PHILIPS	26CS3897	K35
PHILIPS	26CS3898	K35
PHILIPS	26CS4376	K40
PHILIPS	26CS4377	K40
PHILIPS	26CS4378	K40
PHILIPS	26CS4379	K40
PHILIPS	26CS4385	K40
PHILIPS	26CS4385/20	K40M
PHILIPS	26CS4386	K40M
PHILIPS	26CS4387	K40
PHILIPS	26CS4390	K40
PHILIPS	26CS4390/20	K40M
PHILIPS	26CS4391	K40
PHILIPS	26CS4391/20	K40M
PHILIPS	26CS4392	K40
PHILIPS	26CS4393	K40
PHILIPS	26CS4396	K40
PHILIPS	26CS4398	K40
PHILIPS	26CS4490	K40
PHILIPS	26CS4590	K40
PHILIPS	26CS4880	K40
PHILIPS	26CS4881	K40
PHILIPS	26CS4882	K40M
PHILIPS	26CS4895	K40
PHILIPS	26CS5270	K40
PHILIPS	26CS5272	K40

Brand	model	chassis
PHILIPS	26CS5273	K40
PHILIPS	26CS5275	K40
PHILIPS	26CS5276	K40M
PHILIPS	26CS5280	K40
PHILIPS	26CS5280/20	K40M
PHILIPS	26CS5281	K40
PHILIPS	26CS5380	K40
PHILIPS	26CS5382	K40
PHILIPS	26CS5383	K40
PHILIPS	26CS5385	K40
PHILIPS	26CS5385/20	K40M
PHILIPS	26CS5386	K40M
PHILIPS	26CS5387	K40
PHILIPS	26CS5390	K40
PHILIPS	26CS5395	K40
PHILIPS	26CS5475	K40
PHILIPS	26CS5479	K40
PHILIPS	26CS5570	K40
PHILIPS	26CS5573	K40
PHILIPS	26CS5577	K40
PHILIPS	26CS5577/20	K40M
PHILIPS	26CS5578	K40
PHILIPS	26CS5737	K40
PHILIPS	26CS5770	K40
PHILIPS	26CS5771	K40
PHILIPS	26CS5772	K40
PHILIPS	26CS5773	K40
PHILIPS	26CS5774	K40
PHILIPS	26CS5775	K40
PHILIPS	26CS5776	K40M
PHILIPS	26CS5777	K40
PHILIPS	26CS5779	K40
PHILIPS	26CS5780	K40
PHILIPS	26CS5780/20	K40M
PHILIPS	26CS5781	K40

Brand	model	chassis
PHILIPS	26CS5782	K40
PHILIPS	26CS5785	K40
PHILIPS	26CS5786	K40M
PHILIPS	26CS5787	K40M
PHILIPS	26CS5790	K40
PHILIPS	26CS5793	K40
PHILIPS	26CS5795	K40
PHILIPS	26CS5796	K40M
PHILIPS	26CS5797	K40
PHILIPS	26CS5798	K40
PHILIPS	26CS5799	K40
PHILIPS	26CS5870	K40
PHILIPS	26CS5876	K40M
PHILIPS	26CS5878	K40
PHILIPS	26CS5898	K40
PHILIPS	26CT6070/50	CTO-S
PHILIPS	26CT6070/64Z	CTO-N
PHILIPS	26CT6070/65	CTO-S
PHILIPS	26CT6070/80	CTO-N
PHILIPS	26CT6470/50	CTO-S
PHILIPS	26CT6470/51	CTO-N
PHILIPS	26CT6470/65	CTO-S
PHILIPS	26CT6470/67	CTO-S
PHILIPS	26CT6770	CTO-S
PHILIPS	26DV6941/37	OLD
PHILIPS	26FW5220/37	LC4.2HU AA
PHILIPS	26HF5334D/27	EL1.1U AA
PHILIPS	26HF5335D/05	UNKNOWN
PHILIPS	26HF5335D/12	LC7.2E LA
PHILIPS	26HF5335D/27	EJ3.0U LA
PHILIPS	26HF5443/28	LC4.3HU AA
PHILIPS	26HF5443/93	LC4.3HA AA
PHILIPS	26HF5443/97	LC4.3HA AA
PHILIPS	26HF5444/10	LC4.31HE AA
PHILIPS	26HF5445/10	LC7.1HE LA

Brand	model	chassis
PHILIPS	26HF5473/10	LC4.3HE AA
PHILIPS	26HF5544D/27	LC4.3HU AA
PHILIPS	26HF5545D/27	LC7.2HU LA
PHILIPS	26HF5565D/27	UNKNOWN
PHILIPS	26HF7544A/27	LC4.31HU AB
PHILIPS	26HF7874/10	LC4.31HE AA
PHILIPS	26HF7875/10	LC7.1HE LA
PHILIPS	26HF7945D/27	LC7.2HU LA
PHILIPS	26HF7955H/27	LC7.2HU LA
PHILIPS	26HF7965D/27	UNKNOWN
PHILIPS	26HF7965H/27	UNKNOWN
PHILIPS	26HF9472	LC4.2HE AA
PHILIPS	26HW9100D/27	L05.1HU AA
PHILIPS	26KE2615	2A
PHILIPS	26LL57	25B800 (B8)
PHILIPS	26MD251D/37	TPE1.1U LA
PHILIPS	26MD255V/17	26MD255V
PHILIPS	26MD357B/37	TPM1.0U LA
PHILIPS	26MF231D/37	TPE1.0U LA
PHILIPS	26MF337B/27	TPM1.0U LA
PHILIPS	26MF605W/17	FL1;TPF1.4U LA
PHILIPS	26PF1000/62	TES1.0E LA
PHILIPS	26PF3302/10	LC4.31E AA
PHILIPS	26PF3302/12	LC4.31E AA
PHILIPS	26PF3320	LC4.3E AA (?)
PHILIPS	26PF3321/10	LC4.31E AA
PHILIPS	26PF3321/12	LC4.31E AA
PHILIPS	26PF4310	LC4.3E AA
PHILIPS	26PF4311S/10	LC4.31E AA
PHILIPS	26PF5320	LC4.3U AA
PHILIPS	26PF5320	LC4.3U AA
PHILIPS	26PF5320/79	LC4.3A AA
PHILIPS	26PF5320/93	LC4.3A AA
PHILIPS	26PF5320/98	LC4.3A AA
PHILIPS	26PF5321/10	LC4.31E AA

Brand	model	chassis
PHILIPS	26PF5321/12	LC4.31E AA
PHILIPS	26PF5321D/37	EL1.1U AA
PHILIPS	26PF5321F/10	LC4.31E AA
PHILIPS	26PF5411/10	LC4.31E AA
PHILIPS	26PF5520D/10	LC4.3E AB
PHILIPS	26PF5521D	LC4.31E AB
PHILIPS	26PF7321/12	LC4.31E AA
PHILIPS	26PF7521D	LC4.31E AB
PHILIPS	26PF8946/12	LC4.2E AA
PHILIPS	26PF8946/37	LC4.2U AA
PHILIPS	26PF8946/79	LC4.2A AA
PHILIPS	26PF8946/93	LC4.2A AA
PHILIPS	26PF8946/98	LC4.2A AA
PHILIPS	26PF9320/10	LC4.2E AA
PHILIPS	26PF9531/10	BJ3.0E LA
PHILIPS	26PF9631D/10	BJ3.0E LA
PHILIPS	26PF9946/12	LC4.2E AA
PHILIPS	26PF9946/79	LC4.2A AA
PHILIPS	26PF9946/98	LC4.2A AA
PHILIPS	26PF9956/12	LC4.2E AA
PHILIPS	26PF9956/79	LC4.2A AA
PHILIPS	26PF9956/98	LC4.2A AA
PHILIPS	26PF9966/37	LC4.2U AA
PHILIPS	26PFL3312/10	LC7.1E LA
PHILIPS	26PFL3312S/60	LC7.1E LA
PHILIPS	26PFL3321S/60	LC4.31E AA
PHILIPS	26PFL3403/10	UNKNOWN
PHILIPS	26PFL3403D/10	UNKNOWN
PHILIPS	26PFL3512D/12	LC7.2E LA
PHILIPS	26PFL5302D/37	EJ3.0U LA
PHILIPS	26PFL5322/10	LC7.1E LA
PHILIPS	26PFL5322/12	LC7.1E LA
PHILIPS	26PFL5322/45	LC7.1L LA
PHILIPS	26PFL5322/77	LC7.1L LA
PHILIPS	26PFL5322/78	LC7.1L LA

Brand	model	chassis
PHILIPS	26PFL5322D/37	EJ3.0U LA
PHILIPS	26PFL5322S/60	LC7.1E LA
PHILIPS	26PFL5342D/37	UNKNOWN
PHILIPS	26PFL5403/77	UNKNOWN
PHILIPS	26PFL5403/78	UNKNOWN
PHILIPS	26PFL5403D/10	UNKNOWN
PHILIPS	26PFL5522D/05	LC7.2E LA
PHILIPS	26PFL5522D/12	LC7.2E LA
PHILIPS	26PFL7332S/60	LC7.1E LA
PHILIPS	26PFL7532D/05	LC7.2E LA
PHILIPS	26PFL7532D/12	LC7.2E LA
PHILIPS	26PP912A	FL1-PTV (100Hz)
PHILIPS	26PT5331/44R	OLD
PHILIPS	26PT5331/85R	OLD
PHILIPS	26TA1000/79	TPF1.4A LA
PHILIPS	26TA1000/93	TPF1.4A LA
PHILIPS	26TA1000/98	TPF1.4A LA
PHILIPS	26TA1600/98	TPF1.4A LA
PHILIPS	26TA2800/79	TPS1.1A LA
PHILIPS	26TA2800/93	TPS1.1A LA
PHILIPS	26TA2800/98	TPS1.1A LA
PHILIPS	270023WR	CP110
PHILIPS	278071KI	3D
PHILIPS	278077EK	3A
PHILIPS	278096SK	K40-FS/S.
PHILIPS	278171KI	3D
PHILIPS	278177EK	3A
PHILIPS	278377WR	3A
PHILIPS	278623EK	CP110
PHILIPS	278624EK	2B
PHILIPS	278723EK	CP110
PHILIPS	278724EK	2B-F
PHILIPS	278924WR	2B-F
PHILIPS	279023EK	CP110
PHILIPS	279023WR	CP110

Brand	model	chassis
PHILIPS	279024EK	2B-F
PHILIPS	279032EK	2A
PHILIPS	279053EK	CP110
PHILIPS	279054EK	2B
PHILIPS	279062EK	2A
PHILIPS	279123EK	CP110
PHILIPS	279153EK	CP110
PHILIPS	279723EK	CP110
PHILIPS	279853EK	CP110
PHILIPS	279924EK	2B
PHILIPS	279954EK	2B
PHILIPS	27A850/36R	OLD
PHILIPS	27A975/37R	OLD
PHILIPS	27A976/37R	OLD
PHILIPS	27CE2390	2A
PHILIPS	27CE2391	2A
PHILIPS	27CE2690	2A
PHILIPS	27CE3286	CP110
PHILIPS	27CE3287	CP110
PHILIPS	27CE3290	CP110
PHILIPS	27CE3291	CP110
PHILIPS	27CE3296	CP110
PHILIPS	27CE3297	CP110
PHILIPS	27CE3299	CP110
PHILIPS	27CE3590	CP110
PHILIPS	27CE3591	CP110
PHILIPS	27CE3598	CP110
PHILIPS	27CE4286	2B-F
PHILIPS	27CE4287	2B-F
PHILIPS	27CE4290	2B
PHILIPS	27CE4291	2B
PHILIPS	27CE4292	2B
PHILIPS	27CE4293	2B
PHILIPS	27CE4295	2B
PHILIPS	27CE4296	2B

Brand	model	chassis
PHILIPS	27CE4297	2B
PHILIPS	27CE4298	2B
PHILIPS	27CE4299	2B
PHILIPS	27CE4391	2B
PHILIPS	27CE4392	2B
PHILIPS	27CE4590	2B
PHILIPS	27CE4591	2B
PHILIPS	27CE4592	2B
PHILIPS	27CE4593	2B
PHILIPS	27CE4596	2B
PHILIPS	27CE4598	2B
PHILIPS	27CE4599	2B
PHILIPS	27CE4690	2B
PHILIPS	27CE4691	2B
PHILIPS	27CE4692	2B
PHILIPS	27CE4695	2B
PHILIPS	27CE4696	2B
PHILIPS	27CE4697	2B
PHILIPS	27CE4698	2B
PHILIPS	27CE4699	2B
PHILIPS	27CE7590	3A
PHILIPS	27CE7591	3A
PHILIPS	27CE7592	3A
PHILIPS	27CE7593	3A
PHILIPS	27CE7594	3A
PHILIPS	27CE7595	3A
PHILIPS	27CE7596	3A
PHILIPS	27CE7690	3A
PHILIPS	27CE7695	3A
PHILIPS	27CE7790	3A
PHILIPS	27CE7791	3A
PHILIPS	27CE7792	3A
PHILIPS	27CE7797	3A
PHILIPS	27CI1790	3D
PHILIPS	27CI1791	3D

Brand	model	chassis
PHILIPS	27CI1797	3D
PHILIPS	27CS6573	K40-FS
PHILIPS	27CS6577	K40-FS
PHILIPS	27CS6578	K40-FS
PHILIPS	27CS6579	K40-FS
PHILIPS	27CS6590	K40-FS
PHILIPS	27CS6870	K40-FS
PHILIPS	27CS6876	K40M-FS
PHILIPS	27CS6877	K40-FS
PHILIPS	27CS6879	K40-FS
PHILIPS	27CS6895	K40-FS
PHILIPS	27CS6896	K40M-FS (KT4)
PHILIPS	27CS6898	K40-FS
PHILIPS	27CS6899	K40-FS
PHILIPS	27E4695	2B
PHILIPS	27HT2000/27	L04HU AA
PHILIPS	27HT300D/37S	OLD
PHILIPS	27HT4000D/27	L04.6HU CA
PHILIPS	27HT7210D	L04.6HU CA ?
PHILIPS	27HT7210D/27	L04.6HU CA
PHILIPS	27KE1112	CP90
PHILIPS	27KE1115	CP90
PHILIPS	27L130/35R	M8 AA
PHILIPS	27L130/37R	OLD
PHILIPS	27L130/85R	M8 AA
PHILIPS	27L150/35R	M8 AA
PHILIPS	27L150/37R	M8 AA
PHILIPS	27L150/85R	M8 AA
PHILIPS	27L155/35R	M8 AA
PHILIPS	27L155/37R	M8 AA
PHILIPS	27L155/85R	M8 AA
PHILIPS	27L160/35R	M8 AA
PHILIPS	27L160/37R	OLD
PHILIPS	27L160/85R	M8 AA
PHILIPS	27L230/37R	OLD

Brand	model	chassis
PHILIPS	27LP122PL/17R	OLD
PHILIPS	27LP124AV/35	OLD
PHILIPS	27LP124CH/35R	OLD
PHILIPS	27LP124N1/35R	OLD
PHILIPS	27LP124P1/35R	OLD
PHILIPS	27LP124PC/17R	OLD
PHILIPS	27LP124SN/35R	OLD
PHILIPS	27LP125PW/17R	OLD
PHILIPS	27LP126PW/17RC	OLD
PHILIPS	27LP126PW/17RS	OLD
PHILIPS	27LP127SN2/35	OLD
PHILIPS	27LP128PA/35R	OLD
PHILIPS	27LP222/37R	OLD
PHILIPS	27LP222/40C	OLD
PHILIPS	27LP24/40C	OLD
PHILIPS	27LP242/40C	OLD
PHILIPS	27LP26/40A	OLD
PHILIPS	27LP26/40B	OLD
PHILIPS	27LP26/40E	OLD
PHILIPS	27LP262/40P	OLD
PHILIPS	27LP28/40A	OLD
PHILIPS	27LP28/40C	OLD
PHILIPS	27LP29/40B	L9H.1A AA
PHILIPS	27LT2200/27	OLD
PHILIPS	27LT621L	L01.1U.AC.7638
PHILIPS	27MS3451/37R	OLD
PHILIPS	27MS346S/37	L03.1U AA
PHILIPS	27MS5431/37R	OLD
PHILIPS	27MT3305/17	L03.1U AA
PHILIPS	27MT4505/17	OLD
PHILIPS	27MT5005D/37	L04.6U AA
PHILIPS	27MT6005D/37	L04.6U AA
PHILIPS	27PL2106/17	UNKNOWN
PHILIPS	27PS55S	L04.6U AA
PHILIPS	27PT5245/37	27VM34U

Brand	model	chassis
PHILIPS	27PT541S	L04.6U AA
PHILIPS	27PT543S	L04.6U AA
PHILIPS	27PT5445/37	L03.1U AA
PHILIPS	27PT563S	L03.1U AA
PHILIPS	27PT8301/37R	OLD
PHILIPS	27PT8319/37R	OLD
PHILIPS	27PT8320/37R	OLD
PHILIPS	27PT8419/17	N8 AA
PHILIPS	27PT9007D/17	TC7.1U CA
PHILIPS	27PT9015D/37	L04.6U AA
PHILIPS	27RF085/35R	OLD
PHILIPS	27RF085/37R	OLD
PHILIPS	27RF085/85R	OLD
PHILIPS	27RF270/37R	OLD
PHILIPS	27RF280/37R	OLD
PHILIPS	27RF290/37R	OLD
PHILIPS	27RF50S	L04.6U AA
PHILIPS	27RFA160/35R	OLD
PHILIPS	27RFA160/37R	OLD
PHILIPS	27RFA160/85R	OLD
PHILIPS	27RFA185/35R	OLD
PHILIPS	27RFA185/37R	OLD
PHILIPS	27RFA185/85R	OLD
PHILIPS	27RFA190/35R	OLD
PHILIPS	27RFA190/37R	OLD
PHILIPS	27RFDVD140/37R	OLD
PHILIPS	27RFDVD140/37T	OLD
PHILIPS	27RFDVD140/85R	OLD
PHILIPS	27RFDVD260/37R	OLD
PHILIPS	27RFDVD260/85R	OLD
PHILIPS	27RFL150/35R	M8 AA
PHILIPS	27RFL150/37R	M8 AA
PHILIPS	27RFL150/85R	M8 AA
PHILIPS	27RFL260/37R	T8 AA
PHILIPS	27ST2200/27	L04HU AA

Brand	model	chassis
PHILIPS	27ST6210/27	L04HU AA
PHILIPS	27V505	TP2783 ?
PHILIPS	280175IR	G110
PHILIPS	281571SB	GR2.1
PHILIPS	281861SB	GR2.1
PHILIPS	281961SB	GR2.1
PHILIPS	281963SB	GR2.1
PHILIPS	283961SB	GR2.1
PHILIPS	286NS/05	COMET
PHILIPS	287229IR	G110
PHILIPS	287231CB	GR2.2
PHILIPS	287265IR	G110
PHILIPS	287269IR	G110
PHILIPS	287275IR	GR2.2 (?)
PHILIPS	287275KR	FL1.0
PHILIPS	287279IR	G110
PHILIPS	287289IR	G110
PHILIPS	287297WQ	FL1.0
PHILIPS	287332BX	D16
PHILIPS	287342SB	GR2.2
PHILIPS	287362BX	D16
PHILIPS	287575KR	FL1.0
PHILIPS	287596WQ	FL1.0
PHILIPS	287597WQ	FL1.0
PHILIPS	28765IR	G110
PHILIPS	287665IR	G110
PHILIPS	287775IR	G110
PHILIPS	287831CB	GR2.1
PHILIPS	287865IR	G110
PHILIPS	287869IR	G110
PHILIPS	287942SB	GR2.2
PHILIPS	287962SB	GR2.2
PHILIPS	288271SB	GR2.1
PHILIPS	288371SB	GR2.1
PHILIPS	288372SB	GR2.1

Brand	model	chassis
PHILIPS	288372SB	GR2.2
PHILIPS	288372SB/>20	GR2.2
PHILIPS	288392SB	GR2.2
PHILIPS	288572SB	GR2.2
PHILIPS	288861SB	GR2.1
PHILIPS	288862SB	GR2.2
PHILIPS	288961SB	GR2.1
PHILIPS	289126EK	CP110
PHILIPS	289156EK	CP110
PHILIPS	289279IR	G110
PHILIPS	289325EK	2B
PHILIPS	289326EK	CP110
PHILIPS	289355EK	2B
PHILIPS	289356EK	CP110
PHILIPS	289626EK	CP110
PHILIPS	289726EK	CP110
PHILIPS	289925EK	2B-F
PHILIPS	289925WR	2B
PHILIPS	289926EK	CP110
PHILIPS	28CE5290	2B
PHILIPS	28CE5296	2B
PHILIPS	28CE5298	2B
PHILIPS	28CE5590	2B
PHILIPS	28CE5591	2B
PHILIPS	28CE5592	2B
PHILIPS	28CE5593	2B
PHILIPS	28CE5594	2B
PHILIPS	28CE5595	2B
PHILIPS	28CE5597	2B
PHILIPS	28CE6290	CP110
PHILIPS	28CE6291	CP110
PHILIPS	28CE6295	CP110
PHILIPS	28CE6296	CP110
PHILIPS	28CE6297	CP110
PHILIPS	28CE6298	CP110

Brand	model	chassis
PHILIPS	28CE6398	CP110
PHILIPS	28CE6590	CP110
PHILIPS	28CE6591	CP110
PHILIPS	28CE6595	CP110
PHILIPS	28CL6770	FL1.0
PHILIPS	28CL6770	FL1.10
PHILIPS	28CL6776	FL1.0
PHILIPS	28CL6970	FL1.0
PHILIPS	28CL6970	FL1.10
PHILIPS	28CL6976	FL1.0
PHILIPS	28CL6976	FL1.10
PHILIPS	28CT8890	2B-S
PHILIPS	28CT8893	2B
PHILIPS	28CT8894	2B
PHILIPS	28CT9495	CTO-N
PHILIPS	28DC2070	D16
PHILIPS	28DC2075	D16
PHILIPS	28DC2171	D16
PHILIPS	28DC2271	D16
PHILIPS	28DC2670	D16
PHILIPS	28DV6931/85R	L01.1L AC
PHILIPS	28DW6557/01	A10E BB
PHILIPS	28DW6558/01	A10E BB
PHILIPS	28DW6558/05	A10E BB
PHILIPS	28DW6559/01	L04E AA;L04E AB
PHILIPS	28DW6559/05	L04E AA;L04E AB
PHILIPS	28DW8957/05	OLD
PHILIPS	28DW8957/12	OLD
PHILIPS	28DW9625/05R	MG4.1E AA
PHILIPS	28ET2485	GR2.1
PHILIPS	28ET2785	GR2.2
PHILIPS	28FL2870	FL2.G
PHILIPS	28FL2871	FL2.G
PHILIPS	28FL2872	FL2.G
PHILIPS	28FL2873	FL2.G

Brand	model	chassis
PHILIPS	28FL2874	FL2.G
PHILIPS	28GE9970	G110
PHILIPS	28GR1990	G110-S
PHILIPS	28GR5606	G110
PHILIPS	28GR5631	G110
PHILIPS	28GR5636	G110
PHILIPS	28GR5670	G110
PHILIPS	28GR5674	G110
PHILIPS	28GR5676	G110
PHILIPS	28GR5677	G110
PHILIPS	28GR5678	G110
PHILIPS	28GR5701	G110
PHILIPS	28GR5706	G110
PHILIPS	28GR5731	G110
PHILIPS	28GR5736	G110
PHILIPS	28GR5765	G110
PHILIPS	28GR5770	G110
PHILIPS	28GR5772	G110
PHILIPS	28GR5773	G110
PHILIPS	28GR5774	G110
PHILIPS	28GR5775	G110
PHILIPS	28GR5776	G110
PHILIPS	28GR5777	G110
PHILIPS	28GR5779	G110
PHILIPS	28GR5878	G110
PHILIPS	28GR5974	G110
PHILIPS	28GR6775	G110-S
PHILIPS	28GR6776	G110
PHILIPS	28GR6780	G111S
PHILIPS	28GR6781	G110
PHILIPS	28GR9670	G110
PHILIPS	28GR9676	G110
PHILIPS	28GR9677	G110
PHILIPS	28GR9770	G110
PHILIPS	28GR9772	G110

Brand	model	chassis
PHILIPS	28GR9773	G110
PHILIPS	28GR9775	G110
PHILIPS	28GR9776	G110
PHILIPS	28GR9777	G110
PHILIPS	28GR9778	G110
PHILIPS	28GR9779	G110
PHILIPS	28GR9875	G110
PHILIPS	28GR9877	G110
PHILIPS	28GR9970	G110
PHILIPS	28GR9973	G110
PHILIPS	28GR9977	G110
PHILIPS	28GR9979	G110
PHILIPS	28HT5403	L9H.1E
PHILIPS	28HT5403/01Z	L9H.1E AA
PHILIPS	28HT5403/05Z	L9H.1E AA
PHILIPS	28HT5403/21R	L9H.1E AA
PHILIPS	28HT5403/25R	L9H.1E AA
PHILIPS	28HT5403/58Z	L9H.1E AA
PHILIPS	28HT5403/78R	L9H.1E AA
PHILIPS	28HT5404	L9H.1E
PHILIPS	28HT5404/01Z	L01H.1E AA
PHILIPS	28HT5404/05Z	L01H.1E AA
PHILIPS	28HW6404	L01H.1E
PHILIPS	28HW6404/01Z	L01H.1E AA
PHILIPS	28HW6404/05Z	L01H.1E AA
PHILIPS	28HW6404/21R	L01H.1E AA
PHILIPS	28HW6404/25R	L01H.1E AA
PHILIPS	28HW6505	L04HE AA
PHILIPS	28M800	25M8
PHILIPS	28MK2490	MK2
PHILIPS	28MK2790	MK2
PHILIPS	28ML8505	FL1.6
PHILIPS	28ML8600	FL1.7
PHILIPS	28ML8605	FL1.7
PHILIPS	28ML8762	FL1.2

Brand	model	chassis
PHILIPS	28ML8765	FL1.2
PHILIPS	28ML8765	FL1.4
PHILIPS	28ML8770	FL1.1
PHILIPS	28ML8776	FL1.1
PHILIPS	28ML8785	FL1.2
PHILIPS	28ML8800	FL1.6
PHILIPS	28ML8805	FL1.6
PHILIPS	28ML8916	FL1.2
PHILIPS	28ML8926	FL1.2
PHILIPS	28ML8970	FL1.1
PHILIPS	28ML8976	FL1.10
PHILIPS	28ML8978	FL1.1
PHILIPS	28MN1370	GR2.1
PHILIPS	28MN1370/>20	GR2.2
PHILIPS	28MN1376	GR2.1
PHILIPS	28MN1376/>20	GR2.2
PHILIPS	28MN1570	GR2.1
PHILIPS	28MN1570/>20	GR2.2
PHILIPS	28PD6921/44R	OLD
PHILIPS	28PD6921/55R	OLD
PHILIPS	28PD6921/77R	OLD
PHILIPS	28PD6921/78R	OLD
PHILIPS	28PD6932/55R	L01.1L AC
PHILIPS	28PD6932/77R	L01.1L AC
PHILIPS	28PD6932/78R	L01.1L AC
PHILIPS	28PD6932/85R	OLD
PHILIPS	28PN9611	GFL2.30E
PHILIPS	28PN9671	GFL2.30E
PHILIPS	28PT2071	EM2E
PHILIPS	28PT2665	L9.1E
PHILIPS	28PT2683	L01.1E
PHILIPS	28PT4001	AA5 AB
PHILIPS	28PT400A	GR2.2
PHILIPS	28PT4051	AA5
PHILIPS	28PT405A	GR2.2

Brand	model	chassis
PHILIPS	28PT4101	AA5 AB
PHILIPS	28PT4102	L6.2
PHILIPS	28PT4102/00	L6.2 AA
PHILIPS	28PT4103	L6.2
PHILIPS	28PT4103/00	L6.2 AA
PHILIPS	28PT4103/01	L6.2 AA
PHILIPS	28PT4103/39	L6.2 AA
PHILIPS	28PT4103/58	L6.2 AA
PHILIPS	28PT4103/60	L6.2 AA
PHILIPS	28PT4104	L9.1E
PHILIPS	28PT410A	GR2.2
PHILIPS	28PT4151	AA5 AB
PHILIPS	28PT4204	L6.2
PHILIPS	28PT4224	L6.2
PHILIPS	28PT4254	L6.3
PHILIPS	28PT4254/00	L6.2 AA
PHILIPS	28PT4255	L9.1E
PHILIPS	28PT4275	L9.1E
PHILIPS	28PT4301	MD1.1E
PHILIPS	28PT4323	L6.2
PHILIPS	28PT4323/11	L6.2 AA
PHILIPS	28PT4375	L9.1E
PHILIPS	28PT4401	MD1.1E
PHILIPS	28PT4403	L6.2
PHILIPS	28PT4403/00	L6.2 AA
PHILIPS	28PT4403/43	L6.2 AA
PHILIPS	28PT4404	L9.1E
PHILIPS	28PT4405	L01.1E
PHILIPS	28PT440A	GR2.2
PHILIPS	28PT4411	MD1.1E
PHILIPS	28PT4418	L04E AA
PHILIPS	28PT4421	MD1.1E
PHILIPS	28PT4421/13	OLD
PHILIPS	28PT4423	L6.1
PHILIPS	28PT4423/01	L6.2 AA

Brand	model	chassis
PHILIPS	28PT4423/11	L6.2 AA
PHILIPS	28PT4423/58	L6.2 AA
PHILIPS	28PT4426	L01.1E
PHILIPS	28PT442A	GR2.2
PHILIPS	28PT4438/01	L01.1E AA;L01.1E AB
PHILIPS	28PT443A	GR2.4
PHILIPS	28PT4453	L6.2
PHILIPS	28PT4453/00	L6.2 AA
PHILIPS	28PT4454	L6.3
PHILIPS	28PT4454/00	L6.3 AA
PHILIPS	28PT4455	L9.1E
PHILIPS	28PT4456	L9.1E
PHILIPS	28PT4456	L9.1E
PHILIPS	28PT4457	L01.1E AA
PHILIPS	28PT4473	L6.2
PHILIPS	28PT4473/01	L6.2 AA
PHILIPS	28PT4474	L6.3
PHILIPS	28PT4475	L9.1E
PHILIPS	28PT4494	L6.3
PHILIPS	28PT4501	MD1.1
PHILIPS	28PT4503	MD1.1E
PHILIPS	28PT4505	E6
PHILIPS	28PT450A	GR2.2
PHILIPS	28PT4511	MD1.1E
PHILIPS	28PT4511/02	OLD
PHILIPS	28PT4512	MD1.1E
PHILIPS	28PT4513	MD1.2E
PHILIPS	28PT451A	GR2.2
PHILIPS	28PT4521	MD1.1
PHILIPS	28PT4523	MD1.2E AA
PHILIPS	28PT4524	A8.0E
PHILIPS	28PT4527/CE	10.3 (BEKO)
PHILIPS	28PT452A	GR2.2
PHILIPS	28PT4557/01	L01.1E AA;L01.1E AB
PHILIPS	28PT4653	L6.3

Brand	model	chassis
PHILIPS	28PT4654	L6.3
PHILIPS	28PT4654/00	L6.3 AA
PHILIPS	28PT4655	L9.1E
PHILIPS	28PT4657	L01.1E
PHILIPS	28PT4674	L6.3
PHILIPS	28PT4675	L9.1E
PHILIPS	28PT4701	MD1.1
PHILIPS	28PT4701/00	OLD
PHILIPS	28PT470A	GR2.2
PHILIPS	28PT4721	MD1.1E
PHILIPS	28PT4721/19	OLD
PHILIPS	28PT472A	GR2.2
PHILIPS	28PT472B	GR2.4
PHILIPS	28PT4755	L9.1E
PHILIPS	28PT480A	GR2.2
PHILIPS	28PT480B	GR2.2
PHILIPS	28PT480C	GR2.2
PHILIPS	28PT4811	MD1.1E
PHILIPS	28PT481B	GR2.2
PHILIPS	28PT4821	MD1.1E
PHILIPS	28PT482A	GR2.2
PHILIPS	28PT4855	L9.1E
PHILIPS	28PT490A	GR2.2
PHILIPS	28PT492A	GR2.2
PHILIPS	28PT5001	MD1.1E
PHILIPS	28PT5001/02B	OLD
PHILIPS	28PT5005	L9.1E
PHILIPS	28PT5007	L01.1E AA
PHILIPS	28PT5007/01	L01.1E AA;L01.1E AB
PHILIPS	28PT5007/58	L01.1E AA;L01.1E AB
PHILIPS	28PT5025	L9.1E
PHILIPS	28PT5101	MD1.1E
PHILIPS	28PT5105	L9.1E
PHILIPS	28PT5106	L9.1E
PHILIPS	28PT5107/05	OLD

Brand	model	chassis
PHILIPS	28PT510A	GR2.2
PHILIPS	28PT510B/00	GR2.2
PHILIPS	28PT5111	MD1.1
PHILIPS	28PT5121	MD1.1
PHILIPS	28PT5125	L9.1E
PHILIPS	28PT512A	GR2.2
PHILIPS	28PT512B	GR2.2
PHILIPS	28PT512C	GR2.4
PHILIPS	28PT5155	L9.1E
PHILIPS	28PT5205	L9.1E
PHILIPS	28PT520A	GR2.2
PHILIPS	28PT520B	GR2.4
PHILIPS	28PT522A	GR2.2
PHILIPS	28PT522B	GR2.4
PHILIPS	28PT530A	GR2.2
PHILIPS	28PT530B	GR2.4
PHILIPS	28PT532A	GR2.2
PHILIPS	28PT532B	GR2.4
PHILIPS	28PT5401	GR2.4
PHILIPS	28PT540A	GR2.2
PHILIPS	28PT540B	GR2.4
PHILIPS	28PT541B	GR2.4
PHILIPS	28PT542A	GR2.2
PHILIPS	28PT542B	GR2.4
PHILIPS	28PT550A	GR2.2
PHILIPS	28PT550A (1993r.)	GR2.3
PHILIPS	28PT550A (1994r.)	GR2.4
PHILIPS	28PT550B	GR2.4
PHILIPS	28PT550B (1994r.)	GR2.4
PHILIPS	28PT552A	GR2.2
PHILIPS	28PT552B	GR2.4
PHILIPS	28PT560A	GR2.3
PHILIPS	28PT562A	GR2.3
PHILIPS	28PT570A	GR2.2
PHILIPS	28PT570B	GR2.2

Brand	model	chassis
PHILIPS	28PT7007	EM2E
PHILIPS	28PT7103	MD2.21E
PHILIPS	28PT7103/12	MD2.21E AA
PHILIPS	28PT7104	MG2.1E
PHILIPS	28PT7106	EM2E
PHILIPS	28PT7109	A02E
PHILIPS	28PT7120/12	ES1E AA
PHILIPS	28PT7129	A02E
PHILIPS	28PT7139	A02E
PHILIPS	28PT7156	EMG
PHILIPS	28PT7158	EM2E AA
PHILIPS	28PT7159	A02E
PHILIPS	28PT7203	MD2.21E
PHILIPS	28PT7203/12	MD2.21E AA
PHILIPS	28PT7206	EM2E
PHILIPS	28PT7302	MD2.11
PHILIPS	28PT7302	MD2.12
PHILIPS	28PT7303	MD2.21
PHILIPS	28PT7303/12	MD2.21E AA
PHILIPS	28PT7303/19	MD2.21E AA
PHILIPS	28PT7304	MG2.1E
PHILIPS	28PT7306	EM2E
PHILIPS	28PT7393	MD2.21
PHILIPS	28PT7403	MD2.21E
PHILIPS	28PT7403/12	MD2.21E AA
PHILIPS	28PT7404	MG2.1AA
PHILIPS	28PT800	FL1.7
PHILIPS	28PT8001	MG2.1E
PHILIPS	28PT800A	FL1.17
PHILIPS	28PT800B	FL1.17AA
PHILIPS	28PT802A	FL1.17
PHILIPS	28PT802B	FL1.17
PHILIPS	28PT805A	FL1.7
PHILIPS	28PT815A	FL1.17
PHILIPS	28PT817A	FL1.17

Brand	model	chassis
PHILIPS	28PT8303	MD2.22E
PHILIPS	28PT8407	TV9.6
PHILIPS	28PT840A	FL1.17
PHILIPS	28PT840B	FL1.16
PHILIPS	28PT842A	FL1.17
PHILIPS	28PT842B	FL1.16
PHILIPS	28PT845A	FL1.17
PHILIPS	28PT845B	FL1.16
PHILIPS	28PT847A	FL1.17
PHILIPS	28PT8703	MID2.25AA ?
PHILIPS	28PT8704	TV9.6
PHILIPS	28PT8714	DTV101 (czy? DTV100)
PHILIPS	28PT8714 TV17.1-70724	TV17.1
PHILIPS	28PT900A	FL2.16 (100Hz)
PHILIPS	28PT902A	FL2.16
PHILIPS	28PT905A	FL2.16
PHILIPS	28PT910A	FL2.16AA
PHILIPS	28PT912A	FL2.16
PHILIPS	28PT9140	SM2 (99TA013B)
PHILIPS	28PT9144	11AK18
PHILIPS	28PT9210	7300 (ORION)
PHILIPS	28PT9211	DTV101
PHILIPS	28PT9417	11AK28-3
PHILIPS	28PT9640	MD2.25AA
PHILIPS	28PV7805	FL1.0
PHILIPS	28PV7805	FL1.10
PHILIPS	28PV7806	FL1.0
PHILIPS	28PV7806	FL1.10
PHILIPS	28PV7970	FL1.0
PHILIPS	28PV7976	FL1.0
PHILIPS	28PV7978	FL1.0
PHILIPS	28PV7979	FL1.0
PHILIPS	28PW4287	E6A
PHILIPS	28PW4523/79R	OLD
PHILIPS	28PW4523/93R	OLD

Brand	model	chassis
PHILIPS	28PW463A	MD1.0A
PHILIPS	28PW463A/61R	MD1.0A AA
PHILIPS	28PW463A/71R	MD1.0A AA
PHILIPS	28PW463A/78R	MD1.0A AA
PHILIPS	28PW463A/97R	MD1.0A AA
PHILIPS	28PW468A/56R	MD1.0A AA
PHILIPS	28PW468A/57R	MD1.0A AA
PHILIPS	28PW468A/75R	MD1.0A AA
PHILIPS	28PW468A/93R	MD1.0A AA
PHILIPS	28PW469A/69R	MD1.0A AA
PHILIPS	28PW469A/79R	MD1.0A AA
PHILIPS	28PW5304	A8.0
PHILIPS	28PW5324	A8.0E
PHILIPS	28PW5406	A10E
PHILIPS	28PW5407	L01.1E
PHILIPS	28PW6005	A10E
PHILIPS	28PW6006	L01.1E
PHILIPS	28PW6106	L01.1E
PHILIPS	28PW6106/01	OLD
PHILIPS	28PW6106/58	OLD
PHILIPS	28PW6108/01	L01.1E AA;L01.1E AB
PHILIPS	28PW6202	MD1.2E
PHILIPS	28PW6301	MD1.1E
PHILIPS	28PW6302	MD1.2E
PHILIPS	28PW6304	A8.0
PHILIPS	28PW6305	A10EP2
PHILIPS	28PW6306/01	L01.1E AA;L01.1E AB
PHILIPS	28PW630A	GR2.3
PHILIPS	28PW630B	GR2.4
PHILIPS	28PW6312	MD1.2E
PHILIPS	28PW6315	A10E AA ?
PHILIPS	28PW6321	MD1.1E
PHILIPS	28PW6322	MD1.2E
PHILIPS	28PW6324	A8.0E
PHILIPS	28PW6324/95R	OLD

Brand	model	chassis
PHILIPS	28PW632A	GR2.3
PHILIPS	28PW632B	GR2.4
PHILIPS	28PW6332	MD1.2E
PHILIPS	28PW6341/85	L04L AA
PHILIPS	28PW6408	L04E
PHILIPS	28PW6421/55R	OLD
PHILIPS	28PW6421/77R	OLD
PHILIPS	28PW6421/78R	OLD
PHILIPS	28PW6431	L01.1L AC 2K3
PHILIPS	28PW6431/55R	L01.1L AC
PHILIPS	28PW6431/77R	L01.1L AC
PHILIPS	28PW6431/78R	L01.1L AC
PHILIPS	28PW6441/44	L04L AA
PHILIPS	28PW6441/55	L04L AA
PHILIPS	28PW6441/77	L04L AA
PHILIPS	28PW6441/78	L04L AA
PHILIPS	28PW6441/78	L04U AA
PHILIPS	28PW6441/85	L04L AA
PHILIPS	28PW6451/01	L04E AC
PHILIPS	28PW6451/05	L04E AC
PHILIPS	28PW6506	L01.1E AB
PHILIPS	28PW6507/05	L01.1E AA;L01.1E AB
PHILIPS	28PW6515	A10E
PHILIPS	28PW6516	A10E
PHILIPS	28PW6516/79R	A10A AA
PHILIPS	28PW6521/44R	OLD
PHILIPS	28PW6521/55R	OLD
PHILIPS	28PW6521/77R	OLD
PHILIPS	28PW6521/78R	OLD
PHILIPS	28PW6526	A10E
PHILIPS	28PW6531/85R	L01.1L AC
PHILIPS	28PW6532	L01.1L AC 2K3
PHILIPS	28PW6532/44R	L01.1L AC
PHILIPS	28PW6532/55R	L01.1L AC
PHILIPS	28PW6532/77R	L01.1L AC

Brand	model	chassis
PHILIPS	28PW6532/78R	L01.1L AC
PHILIPS	28PW6532/85R	L01.1L AC
PHILIPS	28PW6542/44	L04L AA
PHILIPS	28PW6542/55	L04L AA
PHILIPS	28PW6542/77	L04L AA
PHILIPS	28PW6542/78	L04L AA
PHILIPS	28PW6542/78	L04U AA
PHILIPS	28PW660B	GR2.4
PHILIPS	28PW6615	MG1.1
PHILIPS	28PW6615/05	MG1.1E AA
PHILIPS	28PW6618	L04E AA !
PHILIPS	28PW662B	GR2.4
PHILIPS	28PW6720D/01	L04E AD
PHILIPS	28PW6720D/05	L04E AD
PHILIPS	28PW6805	A10E
PHILIPS	28PW6809	A02
PHILIPS	28PW6816	A10E
PHILIPS	28PW6816/05	A10E
PHILIPS	28PW6818/01	L01.1E AA;L01.1E AB
PHILIPS	28PW6826	A10E
PHILIPS	28PW6826/01	A10E DVD-DPL AA
PHILIPS	28PW6826/05	A10E DVD-DPL AA
PHILIPS	28PW6827/01	OLD
PHILIPS	28PW6827/05	OLD
PHILIPS	28PW756A	GFL2.00A
PHILIPS	28PW757A	GFL2.00A
PHILIPS	28PW758A	GFL2.00A
PHILIPS	28PW768A	GFL2.00A
PHILIPS	28PW769B	GFL2.00A
PHILIPS	28PW777A	GFL2.00A
PHILIPS	28PW778A	GFL2.00A
PHILIPS	28PW787C	GFL2.00A
PHILIPS	28PW8206	EM2E
PHILIPS	28PW8380	11AK28-6 (100Hz)
PHILIPS	28PW8502	MG2.1E

Brand	model	chassis
PHILIPS	28PW8504	MG2.1E
PHILIPS	28PW8505	MG2.1E
PHILIPS	28PW8506	EM2E
PHILIPS	28PW858A/44R	OLD
PHILIPS	28PW858A/55R	OLD
PHILIPS	28PW858A/77R	OLD
PHILIPS	28PW858A/78R	OLD
PHILIPS	28PW8609	A02
PHILIPS	28PW8620/12	ES1E AA
PHILIPS	28PW8651/12	ES1E AA
PHILIPS	28PW8707	EM2E AA
PHILIPS	28PW8717	EM2E
PHILIPS	28PW8719	A02E
PHILIPS	28PW8720/05	ES1E AA
PHILIPS	28PW8720/12	ES1E AA
PHILIPS	28PW8806	MG3.1E
PHILIPS	28PW8807	EM3E
PHILIPS	28PW8807/12	EM3E AA
PHILIPS	28PW8807/19	EM3E AA
PHILIPS	28PW8807/58	EM3E AA
PHILIPS	28PW8818	EM3E
PHILIPS	28PW8818/12	EM3E AA
PHILIPS	28PW9206/028	11AK28-7 !
PHILIPS	28PW9308	EM5.1E AA
PHILIPS	28PW9309/05	EM5.2E AA
PHILIPS	28PW9309/12	EM5.2E AA
PHILIPS	28PW9417	8000 Professional
PHILIPS	28PW9501	GFL2.20E
PHILIPS	28PW9502	MD2.12
PHILIPS	28PW9503	MD2.21E
PHILIPS	28PW9503	MD2.22E
PHILIPS	28PW9503/12	MD2.22E AA
PHILIPS	28PW9503/19	MD2.22E AA
PHILIPS	28PW9505	MG2.1E
PHILIPS	28PW9509	EM5.3E

Brand	model	chassis
PHILIPS	28PW950C	FL1.22
PHILIPS	28PW9512	MD2.12E
PHILIPS	28PW9513	MD2.21E
PHILIPS	28PW9513	MD2.22E
PHILIPS	28PW9513	MD2.25E
PHILIPS	28PW9513/05	MD2.22E AA
PHILIPS	28PW9513/12	MD2.22E AA
PHILIPS	28PW9513/12F	MD2.22E AA
PHILIPS	28PW9513/32	MD2.25E AA
PHILIPS	28PW9513/39	MD2.25E AA
PHILIPS	28PW9515	MG2.1E
PHILIPS	28PW9520	EM5.3E AA
PHILIPS	28PW9521	GFL2.20E
PHILIPS	28PW9525	MG3.1E
PHILIPS	28PW9525	MG7.1E
PHILIPS	28PW9525/05	MG3.1E AA
PHILIPS	28PW9525/05L	MG7.1E AA
PHILIPS	28PW9525/05R	MG7.1E AA
PHILIPS	28PW9525/12	MG3.1E AA
PHILIPS	28PW9525/12L	MG7.1E AA
PHILIPS	28PW9525/12R	MG7.1E AA
PHILIPS	28PW9525/19	MG3.1E AA
PHILIPS	28PW9525/19L	MG7.1E AA
PHILIPS	28PW9525/19R	MG7.1E AA
PHILIPS	28PW9525/58L	MG7.1E AA
PHILIPS	28PW9525/58R	MG7.1E AA
PHILIPS	28PW9527	EM5E
PHILIPS	28PW9528	EM5.1E AA ?
PHILIPS	28PW9535	MG2.1E
PHILIPS	28PW9536	MG7.1E
PHILIPS	28PW9536/05	MG7.1E AA
PHILIPS	28PW9536/05R	MG7.1E AA
PHILIPS	28PW9536/12	MG7.1E AA
PHILIPS	28PW9536/12R	MG7.1E AA
PHILIPS	28PW9536/19	MG7.1E AA

Brand	model	chassis
PHILIPS	28PW9545	MG2.1E
PHILIPS	28PW960A	FL2.14
PHILIPS	28PW960B	FL2.24
PHILIPS	28PW9611	GFL2.20E
PHILIPS	28PW9611	GFL2.30E
PHILIPS	28PW9615	MG3.1E
PHILIPS	28PW9615/01	MG3.1E AA
PHILIPS	28PW9615/05	MG3.1E AA
PHILIPS	28PW9615/12	MG3.1E AA
PHILIPS	28PW9615/19	MG3.1E AA
PHILIPS	28PW9616	MG3.1E
PHILIPS	28PW9616/01	MG3.1E AA
PHILIPS	28PW9616/05	MG3.1E AA
PHILIPS	28PW9616/05R	MG3.1E AA
PHILIPS	28PW9616/12	MG3.1E AA
PHILIPS	28PW9616/12R	MG3.1E AA
PHILIPS	28PW9616/58	MG3.1E AA
PHILIPS	28PW9616/58R	MG3.1E AA
PHILIPS	28PW9617	MG3.2E
PHILIPS	28PW9618	EM6E AA
PHILIPS	28PW9623	MD2.25
PHILIPS	28PW9623/05	MD2.25E AA
PHILIPS	28PW9623/12	MD2.25E AA
PHILIPS	28PW9623/19	MD2.25E AA
PHILIPS	28PW9623/58	MD2.25E AA
PHILIPS	28PW962A	FL2.14
PHILIPS	28PW962B	FL2.24
PHILIPS	28PW9631	GFL2.30E
PHILIPS	28PW9671	GFL2.20E
PHILIPS	28PW9761	GFL2.30E
PHILIPS	28PW9763	MD2.21E
PHILIPS	28PW9763/12	MD2.22E AA
PHILIPS	28PW9763/32	MD2.25E AA
PHILIPS	28PW9763/58	MD2.22E AA
PHILIPS	28PW9765	11AK16

Brand	model	chassis
PHILIPS	28PW9781	GFL2.30E
PHILIPS	28SA01/0	L9.1E
PHILIPS	28SL5770	FL1.0
PHILIPS	28SL5776	FL1.0
PHILIPS	28SL5800	FL1.0
PHILIPS	28SL5800	FL1.10
PHILIPS	28SL5801	FL1.0
PHILIPS	28ST1181	GR2.1
PHILIPS	28ST1281	GR2.1
PHILIPS	28ST1414	GR2.1
PHILIPS	28ST1617	GR2.1
PHILIPS	28ST1637	GR2.1
PHILIPS	28ST1686	GR2.1
PHILIPS	28ST1687	GR2.1
PHILIPS	28ST1712	GR2.1
PHILIPS	28ST1714	GR2.1
PHILIPS	28ST1717	GR2.1
PHILIPS	28ST1734	GR2.1
PHILIPS	28ST1770	GR2.1
PHILIPS	28ST1780	GR2.1
PHILIPS	28ST1781	GR2.1
PHILIPS	28ST1786	GR2.1
PHILIPS	28ST1787	GR2.1
PHILIPS	28ST1789	GR2.1
PHILIPS	28ST1814	GR2.1
PHILIPS	28ST1817	GR2.1
PHILIPS	28ST1881	GR2.1
PHILIPS	28ST2181	GR2.2
PHILIPS	28ST2187	GR2.2
PHILIPS	28ST2281	GR2.2
PHILIPS	28ST2287	GR2.2
PHILIPS	28ST2471	GR2.2
PHILIPS	28ST2477	GR2.2
PHILIPS	28ST2485	GR2.2
PHILIPS	28ST2674	GR2.2

Brand	model	chassis
PHILIPS	28ST2686	GR2.2
PHILIPS	28ST2687	GR2.2
PHILIPS	28ST2761	GR2.2
PHILIPS	28ST2771	GR2.2
PHILIPS	28ST2780	GR2.2
PHILIPS	28ST2781	GR2.2
PHILIPS	28ST2784	GR2.2
PHILIPS	28ST2785	GR2.2
PHILIPS	28ST2786	GR2.2
PHILIPS	28ST2787	GR2.2
PHILIPS	28ST2789	GR2.2
PHILIPS	28ST2871	GR2.2
PHILIPS	28ST2880	GR2.2
PHILIPS	28ST2884	GR2.2
PHILIPS	28ST288S	GR2.2
PHILIPS	28ST2981	GR2.2
PHILIPS	28ST2987	GR2.2
PHILIPS	29CE56	2B ? (100Hz?)
PHILIPS	29DV6931/85R	L01.1L AC
PHILIPS	29FL1770	FL1.0 SAT
PHILIPS	29FL1775	FL1.0S
PHILIPS	29GX1890	ANUBIS S
PHILIPS	29GX1890	ANUBIS S DD
PHILIPS	29GX1891	ANUBIS S
PHILIPS	29GX1893	ANUBIS S
PHILIPS	29GX1896	ANUBIS S
PHILIPS	29GX1897	ANUBIS S
PHILIPS	29GX1898	ANUBIS VA AA
PHILIPS	29GX1990	ANUBIS S
PHILIPS	29GX1995	ANUBIS S
PHILIPS	29HT2211/69Z	L01H.1A AA
PHILIPS	29HT2212/79R	L01H.1A AA
PHILIPS	29HT2212/93R	L01H.1A AA
PHILIPS	29HT2217/69Y	L01H.1A AA
PHILIPS	29HT3312/69R	L04HA AA

Brand	model	chassis
PHILIPS	29HT3312/93R	L04HA AA
PHILIPS	29HT3317/69Y	L04HA AA
PHILIPS	29HT3317/79Y	L04HA AA
PHILIPS	29HT3317/93Y	L04HA AA
PHILIPS	29HT4182/93R	L9H.1A AA
PHILIPS	29HT4182/93Z	L9H.1A AA
PHILIPS	29HT4187/93Y	L9H.1A AA
PHILIPS	29HT4631/77H	L01H.1L AA
PHILIPS	29HT4631/77S	L01H.1L AA
PHILIPS	29HT4631/78H	L01H.1L AA
PHILIPS	29HT4631/78S	L01H.1L AA
PHILIPS	29HT4641/78S	L04HL AA
PHILIPS	29HT4677/69Y	L9H.1A AA
PHILIPS	29HT558A/77H	OLD
PHILIPS	29HT558A/77S	OLD
PHILIPS	29HT558A/78H	L01H.1L AA
PHILIPS	29HT558A/78S	L01H.1L AA
PHILIPS	29HT5632/77S	L01H.1L AA
PHILIPS	29HT5632/78S	L01H.1L AA
PHILIPS	29HT5642/77S	L04HL AA
PHILIPS	29HT5642/78S	L04HL AA
PHILIPS	29HT658A/78S	L01H.1L AA
PHILIPS	29LL6711-21	29B800 (B8)
PHILIPS	29LL6901	UNKNOWN
PHILIPS	29MMTV/69V	OLD
PHILIPS	29MT4505/78	L01.1L AC
PHILIPS	29MT4515/78	L01.1L AC
PHILIPS	29P7320/93R	OLD
PHILIPS	29PD6932/44R	L01.1L AC
PHILIPS	29PD6932/55R	L01.1L AC
PHILIPS	29PD6932/77R	L01.1L AC
PHILIPS	29PD6932/78R	L01.1L AC
PHILIPS	29PD860A/44R	OLD
PHILIPS	29PD860A/55R	OLD
PHILIPS	29PD860A/77R	OLD

Brand	model	chassis
PHILIPS	29PD860A/78R	OLD
PHILIPS	29PT2004/94R	L04A AA
PHILIPS	29PT2104/94R	L04A AA
PHILIPS	29PT2152	L01.1A
PHILIPS	29PT2152/56A	L01.1A AA
PHILIPS	29PT2152/65R	L01.1A AA
PHILIPS	29PT2152/67R	L01.1A AA
PHILIPS	29PT2152/68R	L01.1A AA
PHILIPS	29PT2152/69R	L01.1A AA
PHILIPS	29PT2152/71R	L01.1A AA
PHILIPS	29PT2152/79R	L01.1A AA
PHILIPS	29PT2162	L01.1A
PHILIPS	29PT2162/56A	L01.1A AA
PHILIPS	29PT2162/65R	OLD
PHILIPS	29PT2162/67R	L01.1A AA
PHILIPS	29PT2162/68R	L01.1A AA
PHILIPS	29PT2162/69R	L01.1A AA
PHILIPS	29PT2162/79R	L01.1A AA
PHILIPS	29PT2204/94R	L04A AA
PHILIPS	29PT2252	L01.1A
PHILIPS	29PT2252/56A	L01.1A AA
PHILIPS	29PT2252/57R	L01.1A AA
PHILIPS	29PT2252/65R	L01.1A AA
PHILIPS	29PT2252/67R	L01.1A AA
PHILIPS	29PT2252/68R	L01.1A AA
PHILIPS	29PT2252/69R	L01.1A AA
PHILIPS	29PT2252/71R	L01.1A AA
PHILIPS	29PT2252/79R	L01.1A AA
PHILIPS	29PT2252/97R	L01.1A AA
PHILIPS	29PT2420/94R	L01.1A AA;L01.1A AB
PHILIPS	29PT2420/94T	OLD
PHILIPS	29PT2423/94R	L01.1A AA;L01.1A AB
PHILIPS	29PT2425/94R	OLD
PHILIPS	29PT2425/94T	OLD
PHILIPS	29PT2426/94R	L01.1A AA;L01.1A AB

Brand	model	chassis
PHILIPS	29PT2426/94T	OLD
PHILIPS	29PT2435/94R	OLD
PHILIPS	29PT2452/94	UNKNOWN
PHILIPS	29PT2460/94R	L01.1A AA;L01.1A AB
PHILIPS	29PT2460/94T	OLD
PHILIPS	29PT2465/94R	L01.1A AA
PHILIPS	29PT2535/93R	L01.1A AA
PHILIPS	29PT2552/94	L01.1A AC;L2K3 AA
PHILIPS	29PT2565/93R	L01.1A AA
PHILIPS	29PT2565/93S	L01.1A AA
PHILIPS	29PT2566/93R	L01.1A AA
PHILIPS	29PT310A	AA5
PHILIPS	29PT3133/93R	L01.1A AC;L2K3 AA
PHILIPS	29PT3143	TC...
PHILIPS	29PT3143/93R	TC3.2A AA
PHILIPS	29PT3223	L01.1A
PHILIPS	29PT3223/56	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/56R	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/67R	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/69	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/69R	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/69S	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/71	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/71R	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/79R	L01.1A AC;L2K3 AA
PHILIPS	29PT3223/94	L01.1A AC;L2K3 AA
PHILIPS	29PT3224/93	OLD
PHILIPS	29PT3224/93R	L04A AA
PHILIPS	29PT3225/93	L04A AA
PHILIPS	29PT3323	L01.1A
PHILIPS	29PT3323/56	L01.1A AC;L2K3 AA
PHILIPS	29PT3323/56R	L01.1A AC;L2K3 AA
PHILIPS	29PT3323/67R	L01.1A AC;L2K3 AA
PHILIPS	29PT3323/69	L01.1A AC;L2K3 AA
PHILIPS	29PT3323/69R	L01.1A AC;L2K3 AA

Brand	model	chassis
PHILIPS	29PT3323/69S	L01.1A AC;L2K3 AA
PHILIPS	29PT3323/71	L01.1A AC;L2K3 AA
PHILIPS	29PT3323/71R	L01.1A AC;L2K3 AA
PHILIPS	29PT3323/79	L01.1A AC;L2K3 AA
PHILIPS	29PT3323/79R	L01.1A AC;L2K3 AA
PHILIPS	29PT3324/93R	L04A AA
PHILIPS	29PT3333/79	L01.1A AC;L2K3 AA
PHILIPS	29PT3423/94R	L01.1A AA;L01.1A AB
PHILIPS	29PT3425/56	L01.1A AC;L2K3 AA
PHILIPS	29PT3425/69	L01.1A AC;L2K3 AA
PHILIPS	29PT3425/71	L01.1A AC;L2K3 AA
PHILIPS	29PT3425/79	L01.1A AC;L2K3 AA
PHILIPS	29PT3532/93R	OLD
PHILIPS	29PT3543/93R	L01.1A AC;L2K3 AA
PHILIPS	29PT4182	L9.1A
PHILIPS	29PT4182	L9.1A
PHILIPS	29PT4223	L9.1A
PHILIPS	29PT4223	L9.1A
PHILIPS	29PT4273	L9.1A
PHILIPS	29PT4323	L01.1A
PHILIPS	29PT4323/56R	L01.1A AC;L2K3 AA
PHILIPS	29PT4323/67R	L01.1A AC;L2K3 AA
PHILIPS	29PT4323/69R	L01.1A AC;L2K3 AA
PHILIPS	29PT4323/69S	L01.1A AC;L2K3 AA
PHILIPS	29PT4323/71R	L01.1A AC;L2K3 AA
PHILIPS	29PT4323/79R	L01.1A AC;L2K3 AA
PHILIPS	29PT4324/93R	L04A AA
PHILIPS	29PT4325/69	L01.1A AC;L2K3 AA
PHILIPS	29PT4325/93	L04A AC
PHILIPS	29PT4326/69	L01.1A AC;L2K3 AA
PHILIPS	29PT4420/93R	L01.1A AB
PHILIPS	29PT4423	L7.3A (?)
PHILIPS	29PT4423/67R	L7.3A AA
PHILIPS	29PT4423/68R	L7.3A AA
PHILIPS	29PT4423/70R	L7.3A AA

Brand	model	chassis
PHILIPS	29PT4423/75R	L7.3A AA
PHILIPS	29PT4423/79R	L7.3A AA
PHILIPS	29PT4423/94R	L7.3A AA
PHILIPS	29PT442A	MD1.1
PHILIPS	29PT442A/56H	MD1.0A AA
PHILIPS	29PT442A/56R	MD1.0A AA
PHILIPS	29PT442A/67R	MD1.0A AA
PHILIPS	29PT442A/73R	MD1.0A AA
PHILIPS	29PT442A/75R	MD1.0A AA
PHILIPS	29PT4433/P00	OLD
PHILIPS	29PT4443/94R	L01.1A AA;L01.1A AB
PHILIPS	29PT4453/94R	L01.1A AA;L01.1A AB
PHILIPS	29PT446A	MD1.0A
PHILIPS	29PT446A/93S	OLD
PHILIPS	29PT4473	L7.3A
PHILIPS	29PT4473/75R	L7.3A AA
PHILIPS	29PT4473/79R	L7.3A AA
PHILIPS	29PT448A	MD1.1
PHILIPS	29PT448A/65R	MD1.0A AA
PHILIPS	29PT448A/67R	MD1.0A AA
PHILIPS	29PT448A/68R	MD1.0A AA
PHILIPS	29PT448A/93S	MD1.0A AA
PHILIPS	29PT449A/79R	MD1.0A AA
PHILIPS	29PT4520/93R	L01.1A AB
PHILIPS	29PT4523/93R	OLD
PHILIPS	29PT4525/93R	UNKNOWN
PHILIPS	29PT4531/44R	OLD
PHILIPS	29PT4531/55R	OLD
PHILIPS	29PT4531/77R	OLD
PHILIPS	29PT4531/78R	OLD
PHILIPS	29PT458A/44R	L01.1L AA
PHILIPS	29PT458A/55R	L01.1L AA
PHILIPS	29PT458A/77R	L01.1L AA
PHILIPS	29PT458A/78R	L01.1L AA
PHILIPS	29PT4606/93	SK2.0A CA

Brand	model	chassis
PHILIPS	29PT461A/77R	MD1.0A AA
PHILIPS	29PT461A/97R	MD1.0A AA
PHILIPS	29PT4622	L7.3A
PHILIPS	29PT4622/61R	L7.3A AA
PHILIPS	29PT4622/71R	L7.3A AA
PHILIPS	29PT4622/77R	L7.3A AA
PHILIPS	29PT4622/97R	L7.3A AA
PHILIPS	29PT462A/73R	MD1.0A AA
PHILIPS	29PT4630	L01.1A AC (?)
PHILIPS	29PT4630/77	L01.1A AC
PHILIPS	29PT4631	L01.1L AC 2K3
PHILIPS	29PT4631/44R	L01.1L AC
PHILIPS	29PT4631/55R	L01.1L AC
PHILIPS	29PT4631/77R	L01.1L AC
PHILIPS	29PT4631/78R	L01.1L AC
PHILIPS	29PT4635/78	L01.1L AC
PHILIPS	29PT463A	MD1.1
PHILIPS	29PT463A/61R	MD1.0A AA
PHILIPS	29PT463A/71R	MD1.0A AA
PHILIPS	29PT463A/97R	MD1.0A AA
PHILIPS	29PT4640/78	OLD
PHILIPS	29PT4641/55	L04L AA
PHILIPS	29PT4641/77	L04L AA
PHILIPS	29PT4641/78	L04L AA
PHILIPS	29PT4643/77	L04L AA
PHILIPS	29PT4643/78	L04L AA
PHILIPS	29PT4647/78	L01.1L AC
PHILIPS	29PT4663	L7.3A
PHILIPS	29PT4663/56A	L7.3A AA
PHILIPS	29PT4663/56R	L7.3A AA
PHILIPS	29PT4663/57R	L7.3A AA
PHILIPS	29PT4663/67R	L7.3A AA
PHILIPS	29PT4663/69R	L7.3A AA
PHILIPS	29PT4663/73R	L7.3A AA
PHILIPS	29PT4663/74R	L7.3A AA

Brand	model	chassis
PHILIPS	29PT4663/75R	L7.3A AA
PHILIPS	29PT4666	L7.3A
PHILIPS	29PT4666/57Y	L7.3A AA
PHILIPS	29PT4673/68R	L7.3A AA
PHILIPS	29PT4673/69R	L7.3A AA
PHILIPS	29PT4673/75R	L7.3A AA
PHILIPS	29PT4676/57Y	L7.3A AA
PHILIPS	29PT468A	MD1.1
PHILIPS	29PT468A/57R	MD1.0A AA
PHILIPS	29PT468A/67R	MD1.0A AA
PHILIPS	29PT468A/75R	MD1.0A AA
PHILIPS	29PT469A	MD1.1
PHILIPS	29PT469A/68R	MD1.0A AA
PHILIPS	29PT469A/69R	MD1.0A AA
PHILIPS	29PT469A/75R	MD1.0A AA
PHILIPS	29PT469A/79R	MD1.0A AA
PHILIPS	29PT4723/93R	OLD
PHILIPS	29PT4762/94R	OLD
PHILIPS	29PT4822	L9.1A
PHILIPS	29PT4822	L9.1A
PHILIPS	29PT4823	L9.1A
PHILIPS	29PT4823	L9.1A
PHILIPS	29PT4824	L9.1A
PHILIPS	29PT4824	L9.1A
PHILIPS	29PT4873	L9.1A
PHILIPS	29PT4873	L9.1A
PHILIPS	29PT4888	L9.1A
PHILIPS	29PT4922	L9.1A
PHILIPS	29PT4973	L9.1A
PHILIPS	29PT5005/56	L01.1A AC;L2K3 AA
PHILIPS	29PT5005/63	L01.1A AC
PHILIPS	29PT5005/69	L01.1A AC;L2K3 AA
PHILIPS	29PT5005/71	L01.1A AC;L2K3 AA
PHILIPS	29PT5006/56	L01.1A AC;L2K3 AA
PHILIPS	29PT5006/69	L01.1A AC;L2K3 AA

Brand	model	chassis
PHILIPS	29PT5006/71	L01.1A AC;L2K3 AA
PHILIPS	29PT5006/94	L01.1A AC;L2K3 AA
PHILIPS	29PT5016/69	L01.1A AC;L2K3 AA
PHILIPS	29PT5016/94	L01.1A AC;L2K3 AA
PHILIPS	29PT5026/56	L01.1A AC;L2K3 AA
PHILIPS	29PT5026/69	L01.1A AC;L2K3 AA
PHILIPS	29PT5026/71	L01.1A AC;L2K3 AA
PHILIPS	29PT5026/79	L01.1A AC;L2K3 AA
PHILIPS	29PT5026/94	L01.1A AC
PHILIPS	29PT5026C/79	L01.1A AC
PHILIPS	29PT5105	L9.1E
PHILIPS	29PT5107/60	L01.1A AC;L2K3 AA
PHILIPS	29PT5107/60S	L01.1A AC;L2K3 AA
PHILIPS	29PT5124	A8.0E
PHILIPS	29PT5207/60	L01.1A AC;L2K3 AA
PHILIPS	29PT5207/60S	L01.1A AC;L2K3 AA
PHILIPS	29PT5217/60S	L01.1A AC;L2K3 AA
PHILIPS	29PT5220/93R	OLD
PHILIPS	29PT5221/60	L01.1A AC;L2K3 AA
PHILIPS	29PT5221S/60	L01.1A AC;L2K3 AA
PHILIPS	29PT5301	GR2.4
PHILIPS	29PT5302	MD1.2E
PHILIPS	29PT5304	A8.0
PHILIPS	29PT5305	L9.1E
PHILIPS	29PT5306	L01.1E
PHILIPS	29PT5307/60	L01.1A AC;L2K3 AA
PHILIPS	29PT5307/60S	L01.1A AC;L2K3 AA
PHILIPS	29PT5307/62	TE2.2E CA
PHILIPS	29PT5308/60	L01.1A AC;L2K3 AA
PHILIPS	29PT530C	GR2.4
PHILIPS	29PT5321	GR2.4
PHILIPS	29PT5322	MD1.2
PHILIPS	29PT5324	A8.0E AA
PHILIPS	29PT5342/60	L01.1A AC
PHILIPS	29PT5402	GR2.4

Brand	model	chassis
PHILIPS	29PT5403	MD1.2
PHILIPS	29PT5405	A8
PHILIPS	29PT5407	L01.2A
PHILIPS	29PT5407/01	L01.1E AA;L01.1E AB
PHILIPS	29PT5407/21	L01.1E AA;L01.1E AB
PHILIPS	29PT5408	L04E AA
PHILIPS	29PT5408/01	L04E AA;L04E AE
PHILIPS	29PT5423	MD1.2
PHILIPS	29PT5424	MD1.2
PHILIPS	29PT5425	A8.0E
PHILIPS	29PT5431	L01.1U AC
PHILIPS	29PT5458	L04E AA
PHILIPS	29PT5458/01	L04E AA;L04E AE
PHILIPS	29PT548A	MD1.0
PHILIPS	29PT5501	GR2.4
PHILIPS	29PT5506	L01.1E AA
PHILIPS	29PT5507	L01.1E AA
PHILIPS	29PT5507/58	L01.1E AB
PHILIPS	29PT5507/94	SK5.0A CA
PHILIPS	29PT5515	A10
PHILIPS	29PT5515	A10EP2
PHILIPS	29PT5516	A10E
PHILIPS	29PT5518	L04E AA
PHILIPS	29PT552	LLS
PHILIPS	29PT552A/78R	L7.3A AA
PHILIPS	29PT554A	L9.1A
PHILIPS	29PT554A	L9.1A AA
PHILIPS	29PT558A	L01.1L
PHILIPS	29PT558A/44R	L01.1L AA
PHILIPS	29PT558A/55R	L01.1L AA
PHILIPS	29PT558A/77R	L01.1L AA
PHILIPS	29PT558A/78R	L01.1L AA
PHILIPS	29PT5606	L01.1E
PHILIPS	29PT5607/94	SK5.0A CA
PHILIPS	29PT5621	GR2.4

Brand	model	chassis
PHILIPS	29PT5622	MD2.25E
PHILIPS	29PT5622/97R	A8.0A AA
PHILIPS	29PT5631	L01.1U
PHILIPS	29PT5632	L01.1L AC 2K3
PHILIPS	29PT5632/44R	L01.1L AC
PHILIPS	29PT5632/55R	L01.1L AC
PHILIPS	29PT5632/77R	L01.1L AC
PHILIPS	29PT5632/78R	L01.1L AC
PHILIPS	29PT5633	MD2.25E
PHILIPS	29PT5633/61R	A8.0A AA
PHILIPS	29PT5633/71R	A8.0A AA
PHILIPS	29PT5642/44	L04L AA
PHILIPS	29PT5642/55	L04L AA
PHILIPS	29PT5642/77	L04L AA
PHILIPS	29PT5642/78	L04L AA
PHILIPS	29PT5642/78	L04U AA
PHILIPS	29PT5645/77	L04L AA;L04L AB
PHILIPS	29PT5645/78	L04L AA;L04L AB
PHILIPS	29PT5663	MD2.25E
PHILIPS	29PT5663/56A	A8.0A AA
PHILIPS	29PT5663/56R	A8.0A AA
PHILIPS	29PT5663/57R	A8.0A AA
PHILIPS	29PT5663/68R	A8.0A AA
PHILIPS	29PT5663/75R	A8.0A AA
PHILIPS	29PT5663/93H	A8.0A AA
PHILIPS	29PT5673	A8.0E
PHILIPS	29PT5673/68R	A8.0A AA
PHILIPS	29PT5673/69R	A8.0A AA
PHILIPS	29PT5673/70R	A8.0A AA
PHILIPS	29PT5673/75R	A8.0A AA
PHILIPS	29PT5673/79R	A8.0A AA
PHILIPS	29PT5683/56A	A8.0A AA
PHILIPS	29PT5683/57R	A8.0A AA
PHILIPS	29PT5683/65R	A8.0A AA
PHILIPS	29PT5683/67R	A8.0A AA

Brand	model	chassis
PHILIPS	29PT5683/69R	A8.0A AA
PHILIPS	29PT5683/79R	A8.0A AA
PHILIPS	29PT5683/93	A8.0A AA
PHILIPS	29PT5683/93G	A8.0A AA
PHILIPS	29PT5783	A8.0A
PHILIPS	29PT5783/56A	A8.0A AA
PHILIPS	29PT5783/57R	A8.0A AA
PHILIPS	29PT5783/69R	A8.0A AA
PHILIPS	29PT5783/79R	A8.0A AA
PHILIPS	29PT6001/93R	A10A AA
PHILIPS	29PT600A	GR2.3
PHILIPS	29PT600B	GR2.4
PHILIPS	29PT6011	A10A
PHILIPS	29PT6011/69R	A10A AA
PHILIPS	29PT6011/79R	A10A AA
PHILIPS	29PT6011/93R	A10A AA
PHILIPS	29PT6012/93R	OLD
PHILIPS	29PT6021	A10A
PHILIPS	29PT6021/56A	A10A AA
PHILIPS	29PT6021/56E	A10A AA
PHILIPS	29PT6021/57R	A10A AA
PHILIPS	29PT6021/61R	A10A AA
PHILIPS	29PT6021/68R	A10A AA
PHILIPS	29PT6021/69R	A10A AA
PHILIPS	29PT6021/71R	A10A AA
PHILIPS	29PT6021/73R	A10A AA
PHILIPS	29PT6021/79R	A10A AA
PHILIPS	29PT602A	GR2.3
PHILIPS	29PT602B	GR2.4
PHILIPS	29PT6031	A8.0A
PHILIPS	29PT6031/61R	A8.0A AA
PHILIPS	29PT6031/71R	A8.0A AA
PHILIPS	29PT6111/93R	A10A AA
PHILIPS	29PT6211/93S	OLD
PHILIPS	29PT6211/93T	A8.0A AA

Brand	model	chassis
PHILIPS	29PT6221/93S	OLD
PHILIPS	29PT6221/93T	A8.0A AA
PHILIPS	29PT6231	A8.0A
PHILIPS	29PT6231/57R	A8.0A AA
PHILIPS	29PT6231/69R	A8.0A AA
PHILIPS	29PT6231/79B	A8.0A AA
PHILIPS	29PT6231/79R	A8.0A AA
PHILIPS	29PT630A	GR2.4
PHILIPS	29PT6320/56A	A10A AA
PHILIPS	29PT6320/57R	A10A AA
PHILIPS	29PT6320/61R	A10A AA
PHILIPS	29PT6320/69R	A10A AA
PHILIPS	29PT6320/71R	A10A AA
PHILIPS	29PT6320/79R	A10A AA
PHILIPS	29PT6320/93R	A10A AA
PHILIPS	29PT632A	GR2.4
PHILIPS	29PT6331/44R	OLD
PHILIPS	29PT6341	A10A
PHILIPS	29PT6341/56A	A10A AA
PHILIPS	29PT6341/57R	A10A AA
PHILIPS	29PT6341/61R	A10A AA
PHILIPS	29PT6341/69R	A10A AA
PHILIPS	29PT6341/71R	A10A AA
PHILIPS	29PT6341/79R	A10A AA
PHILIPS	29PT6361	A10A
PHILIPS	29PT6361/56A	A10A AA
PHILIPS	29PT6361/57R	A10A AA
PHILIPS	29PT6361/61R	A10A AA
PHILIPS	29PT6361/69R	A10A AA
PHILIPS	29PT6361/71R	A10A AA
PHILIPS	29PT6361/79B	A10A AA
PHILIPS	29PT6361/79R	A10A AA
PHILIPS	29PT6413	MD1.2E
PHILIPS	29PT6431/85R	L01.1L AC
PHILIPS	29PT6433	MD1.2E

Brand	model	chassis
PHILIPS	29PT6441	L04.1U AA
PHILIPS	29PT6441/44	L04L AA
PHILIPS	29PT6441/85	L04L AA
PHILIPS	29PT6445/85	L04L AA
PHILIPS	29PT6446/44	L04L AA
PHILIPS	29PT6446/85	L04L AA
PHILIPS	29PT6447/44	L04L AA
PHILIPS	29PT6447/55	L04L AA
PHILIPS	29PT6456/44	L04L AA
PHILIPS	29PT6456/55	L04L AA
PHILIPS	29PT6456/77	L04L AA;L04L AB
PHILIPS	29PT6456/78	L04L AA;L04L AB
PHILIPS	29PT6457/44	UNKNOWN
PHILIPS	29PT6457/55	UNKNOWN
PHILIPS	29PT6461/57R	OLD
PHILIPS	29PT6461/69R	OLD
PHILIPS	29PT6461/79R	OLD
PHILIPS	29PT650A	GR2.3
PHILIPS	29PT6541/44	L04L AA
PHILIPS	29PT6541/85	L04L AA
PHILIPS	29PT654A/44R	OLD
PHILIPS	29PT654A/55R	OLD
PHILIPS	29PT654A/77R	OLD
PHILIPS	29PT654A/78R	OLD
PHILIPS	29PT6566/78	L04L AA;L04L AB
PHILIPS	29PT656A	A10E AA
PHILIPS	29PT658A	L01.1E
PHILIPS	29PT658A/44R	OLD
PHILIPS	29PT658A/55R	OLD
PHILIPS	29PT658A/77R	OLD
PHILIPS	29PT658A/78R	OLD
PHILIPS	29PT659A/44R	OLD
PHILIPS	29PT659A/55R	OLD
PHILIPS	29PT659A/77R	OLD
PHILIPS	29PT659A/78R	OLD

Brand	model	chassis
PHILIPS	29PT6626/93	SK3.0A CA
PHILIPS	29PT6657/85	TC5.1L CA
PHILIPS	29PT6667/85	TC5.1L CA
PHILIPS	29PT6773	MD1.2E
PHILIPS	29PT6807/56	SK5.0A CA
PHILIPS	29PT6807/69	SK5.0A CA
PHILIPS	29PT6807/94	SK5.0A CA
PHILIPS	29PT6961	A10A
PHILIPS	29PT6961/57R	A10A AA
PHILIPS	29PT6961/69R	A10A AA
PHILIPS	29PT6961/79R	A10A AA
PHILIPS	29PT6970/57R	OLD
PHILIPS	29PT6970/69R	OLD
PHILIPS	29PT6970/79R	OLD
PHILIPS	29PT700A	GR2.3
PHILIPS	29PT700B	GR2.4
PHILIPS	29PT702A	GR2.3
PHILIPS	29PT702B	GR2.4
PHILIPS	29PT720B	GR2.4
PHILIPS	29PT721B	GR2.3
PHILIPS	29PT722B	GR2.4
PHILIPS	29PT727B	GR2.4
PHILIPS	29PT7322/56R	EM1.1A AA
PHILIPS	29PT7322/69R	EM1.1A AA
PHILIPS	29PT7322/79R	EM1.1A AA
PHILIPS	29PT7322/93G	L04A AB
PHILIPS	29PT7325/69	L04A AB
PHILIPS	29PT7333/93R	L04A AB
PHILIPS	29PT740A	G88
PHILIPS	29PT742A	G88
PHILIPS	29PT745A	G88
PHILIPS	29PT746A	G88
PHILIPS	29PT746C/56R	OLD
PHILIPS	29PT752A	A8.0A
PHILIPS	29PT752A/77B	A8.0A AA

Brand	model	chassis
PHILIPS	29PT760A	G88
PHILIPS	29PT760C/57R	OLD
PHILIPS	29PT762A	G88
PHILIPS	29PT763A	G88
PHILIPS	29PT763C	G8
PHILIPS	29PT780A	G88
PHILIPS	29PT780A/57R	OLD
PHILIPS	29PT785A	G88
PHILIPS	29PT785C	G88
PHILIPS	29PT786A	G88
PHILIPS	29PT786C	G88
PHILIPS	29PT8001	MG2.1E
PHILIPS	29PT8004	MG2.1E
PHILIPS	29PT8005	MG2.1E
PHILIPS	29PT8006	EM2E
PHILIPS	29PT805B	FL4.17
PHILIPS	29PT8102	MD2.2 AA
PHILIPS	29PT8103	MD2.22E
PHILIPS	29PT8103/12	MD2.25E AA
PHILIPS	29PT820B	FL4.27
PHILIPS	29PT822B	FL4.27
PHILIPS	29PT825B	FL4.26 AA
PHILIPS	29PT825B/00	FL4.26
PHILIPS	29PT826C	GFL2.2E AA
PHILIPS	29PT827B	FL4.26
PHILIPS	29PT828C	GFL2.2E AA
PHILIPS	29PT8302	MD2.12
PHILIPS	29PT8303	MD2.21E
PHILIPS	29PT8303	MD2.22E
PHILIPS	29PT8303/12	MD2.22E AA
PHILIPS	29PT8303/19	MD2.22E AA
PHILIPS	29PT8303/58	MD2.22E AA
PHILIPS	29PT8304	MG2.1E
PHILIPS	29PT8306	EM2E AA
PHILIPS	29PT830B	FL4.27

Brand	model	chassis
PHILIPS	29PT8319	EM1A
PHILIPS	29PT8319/57R	EM1A AA
PHILIPS	29PT8319/93G	EM1A AA
PHILIPS	29PT8319/93R	EM1A AA
PHILIPS	29PT8319/93S	OLD
PHILIPS	29PT8320/57R	EM1A AA
PHILIPS	29PT8320/69R	OLD
PHILIPS	29PT8320/93R	EM1A AA
PHILIPS	29PT8320/93S	EM1A AA
PHILIPS	29PT8322/69R	EM1.1A AA
PHILIPS	29PT8322/93R	EM1.1A AA
PHILIPS	29PT8333	MD2.22E
PHILIPS	29PT8333/12	MD2.22E AA
PHILIPS	29PT8344	MG2.1E
PHILIPS	29PT8346	EM2E
PHILIPS	29PT8402	MD2.12E
PHILIPS	29PT8403	MD2.22E
PHILIPS	29PT8403/12	MD2.22E AA
PHILIPS	29PT8403/19	MD2.22E AA
PHILIPS	29PT8403/32	MD2.25E AA
PHILIPS	29PT8403/39	MD2.25E AA
PHILIPS	29PT8403/58	MD2.22E AA
PHILIPS	29PT8412	MD2.12
PHILIPS	29PT8413	MD2.21E
PHILIPS	29PT8413/05	MD2.22E AA
PHILIPS	29PT8419	EM1A
PHILIPS	29PT8419/56R	EM1A AA
PHILIPS	29PT8419/57R	EM1A AA
PHILIPS	29PT8419/61R	EM1A NTSC AA
PHILIPS	29PT8419/69R	EM1A AA
PHILIPS	29PT8419/71R	EM1A NTSC AA
PHILIPS	29PT8419/77	EM1L AA
PHILIPS	29PT8419/78	EM1L AA
PHILIPS	29PT8419/79R	EM1A AA
PHILIPS	29PT8419/93R	EM1A AA

Brand	model	chassis
PHILIPS	29PT8420	EM1A
PHILIPS	29PT8420/56A	EM1A AA
PHILIPS	29PT8420/57R	EM1A AA
PHILIPS	29PT8420/61R	EM1A AA
PHILIPS	29PT8420/69R	EM1A AA
PHILIPS	29PT8420/71R	EM1A AA
PHILIPS	29PT8420/79R	EM1A AA
PHILIPS	29PT8420/93R	EM1A AA
PHILIPS	29PT8422	L05U AA
PHILIPS	29PT8423	MD2.22E
PHILIPS	29PT8423/12	MD2.22E AA
PHILIPS	29PT8424	MD2.25E
PHILIPS	29PT8424/12	MD2.25E AA
PHILIPS	29PT8424/58	MD2.25E AA
PHILIPS	29PT8434	MD2.25E
PHILIPS	29PT8434/12	MD2.25E AA
PHILIPS	29PT8444	MD2.25E
PHILIPS	29PT8444/12	MD2.25E AA
PHILIPS	29PT8444/58	MD2.25E AA
PHILIPS	29PT8457/77	L04L AB
PHILIPS	29PT8457/78	L04L AB
PHILIPS	29PT8505	EM2E
PHILIPS	29PT8507	EM2E
PHILIPS	29PT8508	EM2E AA
PHILIPS	29PT8509	A02E B1
PHILIPS	29PT8520	ES.1E AA (100Hz)
PHILIPS	29PT8520/12	ES1E AA
PHILIPS	29PT8521/12	ES1E AA
PHILIPS	29PT854A/77R	OLD
PHILIPS	29PT854A/78R	OLD
PHILIPS	29PT854A/85R	OLD
PHILIPS	29PT8567/77	UNKNOWN
PHILIPS	29PT8567/78	UNKNOWN
PHILIPS	29PT8567C/77	UNKNOWN
PHILIPS	29PT8567C/78	UNKNOWN

Brand	model	chassis
PHILIPS	29PT856A	A10E AA
PHILIPS	29PT8600	MD1.1A
PHILIPS	29PT8600/57R	MD1.1A BA
PHILIPS	29PT8606	EM2E
PHILIPS	29PT8607	EM2E
PHILIPS	29PT8608	EM2E
PHILIPS	29PT8609	A02E
PHILIPS	29PT860A	MD1.1
PHILIPS	29PT860A/57R	MD1.1A AA
PHILIPS	29PT8610/12	OLD
PHILIPS	29PT8617	EM2E
PHILIPS	29PT8620	MD1.1A
PHILIPS	29PT8620/68R	MD1.1A BA
PHILIPS	29PT8620/69R	MD1.1A BA
PHILIPS	29PT862A	MD1.1A
PHILIPS	29PT862A/68R	MD1.1A AA
PHILIPS	29PT862A/69R	MD1.1A AA
PHILIPS	29PT8630	MD1.1A
PHILIPS	29PT8630/97R	MD1.1A BA
PHILIPS	29PT8639	A02E
PHILIPS	29PT863A	MD1.1A
PHILIPS	29PT863A/97R	MD1.1A AA
PHILIPS	29PT8640/12	ES1E AA
PHILIPS	29PT8641	A02E
PHILIPS	29PT8641/12	ES1E AA
PHILIPS	29PT8650/12	ES1E AA
PHILIPS	29PT8660/12	ES1E AA
PHILIPS	29PT8667/93	SK6.0A CA
PHILIPS	29PT8702	MD2.12
PHILIPS	29PT8703	MD2.21E
PHILIPS	29PT8703	MD2.25E
PHILIPS	29PT8703/12	MD2.22E AA
PHILIPS	29PT8703/32	MD2.25E AA
PHILIPS	29PT8703/58	MD2.25E AA
PHILIPS	29PT8800	MD1.1A

Brand	model	chassis
PHILIPS	29PT8800/57R	MD1.1A BA
PHILIPS	29PT8805/93	L04A AB
PHILIPS	29PT880A	MD1.1A
PHILIPS	29PT880A/57R	MD1.1A AA
PHILIPS	29PT880A/93R	MD1.1A AA
PHILIPS	29PT8811/60	L04E AD
PHILIPS	29PT8811S/60	L04A AD
PHILIPS	29PT8825/93	L04A AB
PHILIPS	29PT8836/94	L04A AB
PHILIPS	29PT8841/60	L04A AD
PHILIPS	29PT8841S/60	L04A AD
PHILIPS	29PT8842S/60	L04A AD
PHILIPS	29PT8845/56	L04A AB
PHILIPS	29PT8845/69	L04A AB
PHILIPS	29PT8857/93	SK6.0A CA
PHILIPS	29PT885A	MD1.1A
PHILIPS	29PT885A/61R	MD1.1A AA
PHILIPS	29PT8860	MD1.1A
PHILIPS	29PT8860/75R	MD1.1A BA
PHILIPS	29PT8860/79R	MD1.1A BA
PHILIPS	29PT8865/93	L04A AB
PHILIPS	29PT8867/93	SK6.0A CA
PHILIPS	29PT886A	MD1.1A
PHILIPS	29PT886A/75R	MD1.1A AA
PHILIPS	29PT886A/79R	MD1.1A AA
PHILIPS	29PT8880	MD1.1A
PHILIPS	29PT8888	MD1.1A
PHILIPS	29PT888A	MD1.1A
PHILIPS	29PT888A/93R	MD1.1A AA
PHILIPS	29PT8890	MD1.1A
PHILIPS	29PT8890/56H	MD1.1A BA
PHILIPS	29PT8890/56R	MD1.1A BA
PHILIPS	29PT8890/68R	MD1.1A BA
PHILIPS	29PT8890/69R	MD1.1A BA
PHILIPS	29PT889A	MD1.1A

Brand	model	chassis
PHILIPS	29PT889A/56H	MD1.1A AA
PHILIPS	29PT889A/69R	MD1.1A AA
PHILIPS	29PT9001	GFL2.2E AA
PHILIPS	29PT9005	MG2.1E
PHILIPS	29PT9006	MG2.1E
PHILIPS	29PT9007	EM2E
PHILIPS	29PT9009	EM5E AA
PHILIPS	29PT9009/12	EM5.2E AA
PHILIPS	29PT900B	FL2.26
PHILIPS	29PT9015	MG2.1E
PHILIPS	29PT9020/12	EM5.3E AA
PHILIPS	29PT9021	GFL2.2E AA
PHILIPS	29PT902B	FL2.26
PHILIPS	29PT9046	MG2.1E
PHILIPS	29PT9047	EM2E
PHILIPS	29PT9055	MG2.1E
PHILIPS	29PT9101	GFL2.2E AA
PHILIPS	29PT910A	FL2.16
PHILIPS	29PT910B	FL2.26
PHILIPS	29PT9111	GFL2.20E
PHILIPS	29PT9113	MD2.21E
PHILIPS	29PT9113	MD2.22E
PHILIPS	29PT9113/05	MD2.22E AA
PHILIPS	29PT9113/12	MD2.22E AA
PHILIPS	29PT9113/19	MD2.22E AA
PHILIPS	29PT9113/58	MD2.22E AA
PHILIPS	29PT9121	GFL2.2E AA
PHILIPS	29PT912A	FL2.16
PHILIPS	29PT912B	FL2.26
PHILIPS	29PT912C	GFL2.2E
PHILIPS	29PT9131	GFL2.20E
PHILIPS	29PT9221/93R	EM5.2A AA
PHILIPS	29PT9413	MD2.25E
PHILIPS	29PT9413/05	MD2.25E AA
PHILIPS	29PT9413/12	MD2.25E AA

Brand	model	chassis
PHILIPS	29PT9413/19	MD2.25E AA
PHILIPS	29PT9413/58	MD2.25E AA
PHILIPS	29PT9415	MG3.1E
PHILIPS	29PT9415/05	MG3.1E AA
PHILIPS	29PT9415/12	MG3.1E AA
PHILIPS	29PT9415/19	MG3.1E AA
PHILIPS	29PT9415/58	MG3.1E AA
PHILIPS	29PT9416	MG3.1E
PHILIPS	29PT9416/12	MG3.1E AA
PHILIPS	29PT9416/12B	MG3.1E AA
PHILIPS	29PT9416/12R	MG3.1E AA
PHILIPS	29PT9416/58	MG3.1E AA
PHILIPS	29PT9416/58R	MG3.1E AA
PHILIPS	29PT9417	EM5.1E
PHILIPS	29PT9418	MG3.1A
PHILIPS	29PT9418/56G	MG3.1A AA
PHILIPS	29PT9418/56R	MG3.1A AA
PHILIPS	29PT9418/56T	MG3.1A AA
PHILIPS	29PT9418/57G	MG3.1A AA
PHILIPS	29PT9418/57R	MG3.1A AA
PHILIPS	29PT9418/57T	MG3.1A AA
PHILIPS	29PT9418/69G	MG3.1A AA
PHILIPS	29PT9418/69R	MG3.1A AA
PHILIPS	29PT9418/69T	MG3.1A AA
PHILIPS	29PT9418/79G	MG3.1A AA
PHILIPS	29PT9418/79R	MG3.1A AA
PHILIPS	29PT9418/79T	MG3.1A AA
PHILIPS	29PT9418/93G	MG3.1A AA
PHILIPS	29PT9418/93T	MG3.1A AA
PHILIPS	29PT9418/93X	MG3.1A AA
PHILIPS	29PT9420	EM5A
PHILIPS	29PT9420/57R	EM5A P/M AA
PHILIPS	29PT9420/61R	EM5A NTSC AA
PHILIPS	29PT9420/69R	EM5A P/M AA
PHILIPS	29PT9420/71R	EM5A NTSC AA

Brand	model	chassis
PHILIPS	29PT9420/79R	EM5A P/M AA
PHILIPS	29PT9421	EM5.3A P/M AA (?)
PHILIPS	29PT9421/56R	EM5.2A AA;EM5.3A P/M AA
PHILIPS	29PT9421/69R	EM5.2A AA;EM5.3A P/M AA
PHILIPS	29PT9457/44	SK5.0L CA
PHILIPS	29PT9457/55	SK5.0L CA
PHILIPS	29PT9457/77	L07.1L CA
PHILIPS	29PT9457/78	L07.1L CA
PHILIPS	29PT9467/78	UNKNOWN
PHILIPS	29PT9467C/77	UNKNOWN
PHILIPS	29PT9467C/78	UNKNOWN
PHILIPS	29PT9467S/78	UNKNOWN
PHILIPS	29PT9521	L06.1E AA
PHILIPS	29PTF16/93S	A8.0A AA
PHILIPS	29PW662B	GR2.4
PHILIPS	29PX8001	GFL2.20E
PHILIPS	29PX8031	GFL2.20E
PHILIPS	29PX8111	GFL2.20E
PHILIPS	29PX8131	GFL2.20E
PHILIPS	29SP1698	G112
PHILIPS	29SP1798	G112
PHILIPS	29SX8664	G8
PHILIPS	29SX8671	G8
PHILIPS	29SX8672	G8
PHILIPS	29SX8673	G8
PHILIPS	29SX8674	G8
PHILIPS	29SX8674/85R	OLD
PHILIPS	29SX8676	G8.1
PHILIPS	29SX8677	G8
PHILIPS	29SX8678	G8
PHILIPS	29SX8770	G8
PHILIPS	29SX8771	G8AA
PHILIPS	29SX8776	G8
PHILIPS	29SX8876	G8
PHILIPS	29SX8878	G8

Brand	model	chassis
PHILIPS	29SX8879	G8
PHILIPS	29SX8976	G8
PHILIPS	300WN5BS/00	OLD
PHILIPS	300WN5BS/93	OLD
PHILIPS	300WN5VB/00	OLD
PHILIPS	300WN5VB/93	OLD
PHILIPS	300WN5VS/93	OLD
PHILIPS	30DV6941/37	OLD
PHILIPS	30FW5220/37	LC4.6HU AA
PHILIPS	30FW9915/37	LC4.6HU AA
PHILIPS	30FW9955/35	FTL13U AA
PHILIPS	30FW9975/35	FTL13U AA
PHILIPS	30HF9442/12	LC4.6HE AA
PHILIPS	30HF9442/93	LC4.6A AA;LC4.6HA AA
PHILIPS	30HF9442/98	LC4.6HA AA
PHILIPS	30HF9975/12	FTL13E AA
PHILIPS	30HF9975/12Z	FTL13E AA
PHILIPS	30HF9975/69	FTL13E AA
PHILIPS	30HF9975/69Z	OLD
PHILIPS	30HW8815/35	MG3.1U AA
PHILIPS	30HW9100D/27	L05.1HU AA
PHILIPS	30HW9817/35R	OLD
PHILIPS	30MF200V/17	LC4.6U AA
PHILIPS	30MW9002/37	LC4.6U AA
PHILIPS	30PF9946	LC4.6E AA
PHILIPS	30PF9946/37	FTL13U AA
PHILIPS	30PF9946/79	LC4.6A AA
PHILIPS	30PF9946/93	LC4.6A AA
PHILIPS	30PF9946/98	LC4.6A AA
PHILIPS	30PF9946D/37	LC4.6U AA
PHILIPS	30PF9946D/78	LC4.6L AA
PHILIPS	30PF9975	FTL13E
PHILIPS	30PF9975/12	FTL13E AA
PHILIPS	30PF9975/12A	FTL13E AA
PHILIPS	30PF9975/17	FTL13U AA

Brand	model	chassis
PHILIPS	30PF9975/69	FTL13E AA
PHILIPS	30PF9975/77	FTL13E AA
PHILIPS	30PF9975/78	FTL13U AB
PHILIPS	30PW6341	L04.1U AA
PHILIPS	30PW8420	L05U AA
PHILIPS	30PW8501/37R	EM1.1U AA
PHILIPS	30PW850H	A02U AA
PHILIPS	30PW8520/17	OLD
PHILIPS	30PW8621/37R	EM1.1U AA
PHILIPS	30PW8859/17	N8 AA
PHILIPS	30PW8869/17	N8 AA
PHILIPS	30PW8879/17	N8 AA
PHILIPS	30PW9110D	L05.1U AA
PHILIPS	30PW9815/17	MG3.1U AA
PHILIPS	30PW9817/17	MG3.1U AA
PHILIPS	30PW9818	EM5U AA;R8 AA
PHILIPS	30PW9818/17	EM5U AA;R8 AA
PHILIPS	30PW9819/17	EM5U AA;R8 AA
PHILIPS	31HT1550	ANUBIS B
PHILIPS	32A840/36R	OLD
PHILIPS	32A960/37R	OLD
PHILIPS	32A976/37R	OLD
PHILIPS	32DV6931/85R	L01.1L AC
PHILIPS	32DW6557/01	A10E BB
PHILIPS	32DW6558/01	A10E BB
PHILIPS	32DW6558/05	A10E BB
PHILIPS	32DW6559/01	L04E AA;L04E AB
PHILIPS	32DW6559/05	L04E AA;L04E AB
PHILIPS	32DW6658/79R	A10A AA
PHILIPS	32DW8957/05	OLD
PHILIPS	32DW9625/05	MG4.1E AA
PHILIPS	32DW9625/05R	MG4.1E AA
PHILIPS	32FD9944	FM23
PHILIPS	32FD9944/01S	FM23 AA;FM23 AB;FM23 AC
PHILIPS	32FD9944/69S	FM23 AA;FM23 AB;FM23 AC

Brand	model	chassis
PHILIPS	32FD994401S (32FD9944/01S)	FM23AA
PHILIPS	32FD9954	FM23 AA;FM23 AB;FM23 AC
PHILIPS	32FD9954/17S	FM23 AA;FM23 AB;FM23 AC
PHILIPS	32FD9954/69S	FM23 AA;FM23 AB;FM23 AC
PHILIPS	32FL2880	FL2.G
PHILIPS	32FL2881	FL2.G
PHILIPS	32FL2881/69R	OLD
PHILIPS	32FL2882	FL2.G
PHILIPS	32FL2882/97R	OLD
PHILIPS	32FL2883	FL2.G
PHILIPS	32FL2884	FL2.G
PHILIPS	32HF5335D/12	LC7.2E LA
PHILIPS	32HF5335D/27	EJ3.0U LA
PHILIPS	32HF5445/10	LC7.1HE LA
PHILIPS	32HF5545D/27	LC7.2HU LA
PHILIPS	32HF5565D/27	UNKNOWN
PHILIPS	32HF7235/93	UNKNOWN
PHILIPS	32HF7443/93	LC4.3HA AA
PHILIPS	32HF7443/97	LC4.3HA AA
PHILIPS	32HF7444/10	LC4.31HE AA
PHILIPS	32HF7445/93	TPT1.1HA LA
PHILIPS	32HF7445/97	TPT1.1HA LA
PHILIPS	32HF7473/10	LC4.3HE AA
PHILIPS	32HF7543/37	BL2.3HU AA
PHILIPS	32HF7544D/27	LC4.31HU AB
PHILIPS	32HF7874/10	LC4.31HE AA
PHILIPS	32HF7875/10	LC7.1HE LA
PHILIPS	32HF7945D/27	LC7.2HU LA
PHILIPS	32HF7955H/27	LC7.2HU LA
PHILIPS	32HF7965D/27	UNKNOWN
PHILIPS	32HF7965H/27	UNKNOWN
PHILIPS	32HF9385D/10	Q528.1E LA
PHILIPS	32L150/35R	M8 AA
PHILIPS	32L150/37R	M8 AA
PHILIPS	32L150/85R	M8 AA

Brand	model	chassis
PHILIPS	32L155/37R	M8 AA;T8 AA
PHILIPS	32L160/35R	M8 AA
PHILIPS	32L160/37R	OLD
PHILIPS	32L160/37R1	OLD
PHILIPS	32L160/85R	OLD
PHILIPS	32LP128PA/35R	OLD
PHILIPS	32LP128PP/35R	OLD
PHILIPS	32LP128SN/35R	OLD
PHILIPS	32LP28/40A	OLD
PHILIPS	32LP28/40B	OLD
PHILIPS	32LP28/40C	OLD
PHILIPS	32LP28/40P	OLD
PHILIPS	32LP28PP2/35	OLD
PHILIPS	32LP29/40B	OLD
PHILIPS	32MD251D/37	TPE1.1U LA
PHILIPS	32MD357B/37	TPM1.0U LA
PHILIPS	32MD358B/37	UNKNOWN
PHILIPS	32MF231D/37	TPE1.0U LA
PHILIPS	32MF337B/27	QCZ1.0U LA;TPM1.0U LA
PHILIPS	32MF338B/27	UNKNOWN
PHILIPS	32MF605W/17	FL1;TPF1.4U LA
PHILIPS	32MT5015D/37	L04.6U AA
PHILIPS	32MT6015D/37	L04.6U AA
PHILIPS	32PD6921/37R	OLD
PHILIPS	32PD6921/44R	OLD
PHILIPS	32PD6921/55R	OLD
PHILIPS	32PD6921/77R	OLD
PHILIPS	32PD6921/78R	OLD
PHILIPS	32PD6932	L01.1L AC 2K3
PHILIPS	32PD6932/55R	L01.1L AC
PHILIPS	32PD6932/77R	L01.1L AC
PHILIPS	32PD6932/78R	L01.1L AC
PHILIPS	32PD880A/44R	OLD
PHILIPS	32PD880A/55R	OLD
PHILIPS	32PD880A/77R	OLD

Brand	model	chassis
PHILIPS	32PD880A/78R	OLD
PHILIPS	32PF1000/62	TES1.0E LA
PHILIPS	32PF1600T/96	MQC2.0A LA
PHILIPS	32PF1700T/96	IMP1.0A LA
PHILIPS	32PF3302/10	LC4.31E AA
PHILIPS	32PF3302/12	LC4.31E AA
PHILIPS	32PF3321/10	LC4.31E AA
PHILIPS	32PF3321/12	LC4.31E AA
PHILIPS	32PF4311S/10	LC4.31E AA
PHILIPS	32PF4320	LC4.5E AA
PHILIPS	32PF4321/96	MQC1.0A LA
PHILIPS	32PF5320	LC4.3A
PHILIPS	32PF5320	LC4.3U AA
PHILIPS	32PF5320/79	LC4.3A AA
PHILIPS	32PF5320/93	LC4.3A AA
PHILIPS	32PF5320/98	LC4.3A AA
PHILIPS	32PF5321	SD2.1 ?
PHILIPS	32PF5321/10	LC4.31E AA
PHILIPS	32PF5321/12	LC4.31E AA
PHILIPS	32PF5321D/37	EL1.1U AA
PHILIPS	32PF5331/10	LC4.31E AA
PHILIPS	32PF5331/12	LC4.31E AA
PHILIPS	32PF5411/10	LC4.31E AA
PHILIPS	32PF5520D/10	LC4.3E AB
PHILIPS	32PF5520D/79	LC4.3A AB
PHILIPS	32PF5521D	LC4.31E AB
PHILIPS	32PF5531D	LC4.31E AA v.2
PHILIPS	32PF7320/79	LC4.3A AA
PHILIPS	32PF7320/93	LC4.3A AA
PHILIPS	32PF7320/98	LC4.3A AA
PHILIPS	32PF7320A/37	BL2.3U AA
PHILIPS	32PF7321/12	LC4.31E AA
PHILIPS	32PF7321/79	LC4.31A AA
PHILIPS	32PF7321/93	LC4.31A AA
PHILIPS	32PF7321/98	LC4.31A AA

Brand	model	chassis
PHILIPS	32PF7321D/37	EL1.1U AA
PHILIPS	32PF7331/12	LC4.31E AA
PHILIPS	32PF7411/10	LC4.31E AA
PHILIPS	32PF7421D/37	EL1.1U AA
PHILIPS	32PF7520D/10	LC4.3E AB
PHILIPS	32PF7521D	LC4.31E AB
PHILIPS	32PF9431/93	BJ3.0A LA
PHILIPS	32PF9531/10	FJ3.0E LA
PHILIPS	32PF9531/79	BJ3.0A LA
PHILIPS	32PF9531/93	BJ3.0A LA
PHILIPS	32PF9531/98	BJ3.0A LA
PHILIPS	32PF9541/10	BJ3.0E LA
PHILIPS	32PF9551/10	BJ3.0E LA
PHILIPS	32PF9630/78	FTL2.4L AA
PHILIPS	32PF9630A/37	BL2.2U AA
PHILIPS	32PF9631D/10	FJ3.0E LA
PHILIPS	32PF9631D/79	BJ3.0E LA
PHILIPS	32PF9641D	BX3.1E
PHILIPS	32PF9641D/10	BJ3.0E LA
PHILIPS	32PF9731	FJ3.0E ?
PHILIPS	32PF9731D/10	FJ3.0E LA
PHILIPS	32PF9956/12	FTL3.1E AA
PHILIPS	32PF9964/12S	F21RE AA;F21RE AB;FM23 AA;FM23 AB;FM23 AC
PHILIPS	32PF9965/12S	F22RE AA;FM23 AA
PHILIPS	32PF9966/10	FTL2.4E AA
PHILIPS	32PF9966/37	FTL2.2U AA
PHILIPS	32PF9966/69	FTL2.2A AA
PHILIPS	32PF9966/79	FTL2.4A AA
PHILIPS	32PF9966/93	FTL2.2A AA;FTL2.4A AA
PHILIPS	32PF9966/98	FTL2.4A AA
PHILIPS	32PF9967D/10	FTL2.4E AB
PHILIPS	32PF9968/10	BJ3.0E LA
PHILIPS	32PF9976	FTL2.2E AA
PHILIPS	32PF9986	FTL2.1E
PHILIPS	32PF9986/12	FTL2.1E AA

Brand	model	chassis
PHILIPS	32PF9996/37	FTL2.1U AA
PHILIPS	32PF9996/78	FTL2.1L AA
PHILIPS	32PFL2302/62	UNKNOWN
PHILIPS	32PFL3312/10	LC7.1E LA
PHILIPS	32PFL3312S/60	LC7.1E LA
PHILIPS	32PFL3321S/60	LC4.31E AA
PHILIPS	32PFL3403/77	UNKNOWN
PHILIPS	32PFL3403/78	UNKNOWN
PHILIPS	32PFL3403/93	UNKNOWN
PHILIPS	32PFL3403/97	UNKNOWN
PHILIPS	32PFL3403S/60	UNKNOWN
PHILIPS	32PFL3512D/12	LC7.2E LA
PHILIPS	32PFL5312/77	LC4.8L LA
PHILIPS	32PFL5312/78	LC4.8L LA
PHILIPS	32PFL5322/10	LC7.1E LA
PHILIPS	32PFL5322/12	LC7.1E LA
PHILIPS	32PFL5322D/37	EJ3.0U LA
PHILIPS	32PFL5322S/60	LC7.1E LA
PHILIPS	32PFL5323D/27	UNKNOWN
PHILIPS	32PFL5332/45	LC7.1L LA
PHILIPS	32PFL5332/77	LC7.1L LA
PHILIPS	32PFL5332/78	LC7.1L LA
PHILIPS	32PFL5332D	EJ3.0U
PHILIPS	32PFL5332D/37	EJ3.0U LA
PHILIPS	32PFL5332S/60	LC7.1E LA
PHILIPS	32PFL5403/77	UNKNOWN
PHILIPS	32PFL5403/78	UNKNOWN
PHILIPS	32PFL5403/93	UNKNOWN
PHILIPS	32PFL5403/97	UNKNOWN
PHILIPS	32PFL5403D/12	UNKNOWN
PHILIPS	32PFL5403H/10	UNKNOWN
PHILIPS	32PFL5403M/08	UNKNOWN
PHILIPS	32PFL5403S/60	UNKNOWN
PHILIPS	32PFL5422/96	IMP1.0A LA
PHILIPS	32PFL5522D/05	LC7.2E LA

Brand	model	chassis
PHILIPS	32PFL5522D/12	LC7.2E LA
PHILIPS	32PFL5723D/27	UNKNOWN
PHILIPS	32PFL7332/10	BJ3.1E LA
PHILIPS	32PFL7332/93	LC7.1A LA
PHILIPS	32PFL7332/98	LC7.1A LA
PHILIPS	32PFL7332D/37	EJ3.0U LA
PHILIPS	32PFL7342/77	LC7.1L LA
PHILIPS	32PFL7342/78	LC7.1L LA
PHILIPS	32PFL7403D/12	UNKNOWN
PHILIPS	32PFL7403H/10	UNKNOWN
PHILIPS	32PFL7403S/60	UNKNOWN
PHILIPS	32PFL7422/79	TPT1.1A LA
PHILIPS	32PFL7422/93	TPT1.1A LA
PHILIPS	32PFL7422/98	TPT1.1A LA
PHILIPS	32PFL7532D/79	BJ3.1A LA
PHILIPS	32PFL7562D/10	BJ3.1E LA
PHILIPS	32PFL7572D/10	BJ3.1E LA
PHILIPS	32PFL7582D/10	BJ3.1E LA
PHILIPS	32PFL7602D/10	BJ3.1E LA
PHILIPS	32PFL7603/78	UNKNOWN
PHILIPS	32PFL7603D/12	UNKNOWN
PHILIPS	32PFL7603H/10	UNKNOWN
PHILIPS	32PFL7603M/08	UNKNOWN
PHILIPS	32PFL7603S/60	UNKNOWN
PHILIPS	32PFL7633S/60	UNKNOWN
PHILIPS	32PFL7762D/05	LC7.5E LA
PHILIPS	32PFL7762D/12	LC7.5E LA
PHILIPS	32PFL7772D/12	LC7.5E LA
PHILIPS	32PFL7782D/05	UNKNOWN
PHILIPS	32PFL7782D/12	LC7.5E LA
PHILIPS	32PFL7862D/10	Q528.1E LA
PHILIPS	32PFL7932/93	LC7.1A LA
PHILIPS	32PFL7962D/05	LC7.5E LA
PHILIPS	32PFL7962D/12	LC7.5E LA
PHILIPS	32PFL9403D/08	UNKNOWN

Brand	model	chassis
PHILIPS	32PFL9403D/10	UNKNOWN
PHILIPS	32PFL9403D/19	UNKNOWN
PHILIPS	32PFL9432/98	Q528.1A LA
PHILIPS	32PFL9432D/79	Q528.1E LA
PHILIPS	32PFL9603D/08	UNKNOWN
PHILIPS	32PFL9603D/10	UNKNOWN
PHILIPS	32PFL9603D/19	UNKNOWN
PHILIPS	32PFL9632D/10	Q528.1E LA
PHILIPS	32PM8822/10	FL1;ML1.2E AA
PHILIPS	32PT563R85G	L01U AC
PHILIPS	32PT6441	L04.1U
PHILIPS	32PT7005D/37	L04.6U AA
PHILIPS	32PT7301/37R	OLD
PHILIPS	32PT7319/37R	OLD
PHILIPS	32PT7401/37R	OLD
PHILIPS	32PT740H	L04.6U AA
PHILIPS	32PT8301/37R	OLD
PHILIPS	32PT8319/37R	OLD
PHILIPS	32PT8320/37R	OLD
PHILIPS	32PT8321/37R	OLD
PHILIPS	32PT8421/37R	OLD
PHILIPS	32PT9005D/37	L04.6U AA
PHILIPS	32PV60C/01---32PW6006/01	L01.1E AA
PHILIPS	32PW4523	L01.1A (=L2K3)
PHILIPS	32PW4523/79R	L01.1A AC;L2K3 AA
PHILIPS	32PW4523/93R	L01.1A AC;L2K3 AA
PHILIPS	32PW5405	A10E AA
PHILIPS	32PW5406	A10E
PHILIPS	32PW5406/21	OLD
PHILIPS	32PW5407	L01.1E
PHILIPS	32PW6005	A10E
PHILIPS	32PW6005/01	A10
PHILIPS	32PW6006	L01.1E AA
PHILIPS	32PW6302	MD1.2E
PHILIPS	32PW6304	A8.0

Brand	model	chassis
PHILIPS	32PW6305	A10E AA
PHILIPS	32PW6312	MD1.2E
PHILIPS	32PW6315	A10E
PHILIPS	32PW6322	MD1.2E
PHILIPS	32PW6324	A8.0E
PHILIPS	32PW6331/85R	L01.1L AC
PHILIPS	32PW6332	MD1.1E
PHILIPS	32PW6341/85	L04L AA
PHILIPS	32PW6421/55R	OLD
PHILIPS	32PW6421/77R	OLD
PHILIPS	32PW6421/78R	OLD
PHILIPS	32PW6431/55R	L01.1L AC
PHILIPS	32PW6431/77R	L01.1L AC
PHILIPS	32PW6431/78R	L01.1L AC
PHILIPS	32PW6451/01	L04E AC
PHILIPS	32PW6506	L01.1E
PHILIPS	32PW6506	L01.2E AA
PHILIPS	32PW6515	A10E
PHILIPS	32PW6516	A10E
PHILIPS	32PW6516/79R	A10A AA
PHILIPS	32PW6516/93R	A10A AA
PHILIPS	32PW6518	L04E
PHILIPS	32PW6521/44R	OLD
PHILIPS	32PW6521/55R	OLD
PHILIPS	32PW6521/77R	OLD
PHILIPS	32PW6521/78R	OLD
PHILIPS	32PW6526	A10E
PHILIPS	32PW6532	L01.1L AC 2K3
PHILIPS	32PW6532/44R	L01.1L AC
PHILIPS	32PW6532/55R	L01.1L AC
PHILIPS	32PW6532/77R	L01.1L AC
PHILIPS	32PW6532/78R	L01.1L AC
PHILIPS	32PW6542/44	L04L AA
PHILIPS	32PW6542/55	L04L AA
PHILIPS	32PW6542/77	L04L AA

Brand	model	chassis
PHILIPS	32PW6542/78	L04L AA
PHILIPS	32PW6542/78	L04U AA
PHILIPS	32PW6615	MG1.1E
PHILIPS	32PW6615/25	MG1.1E AA
PHILIPS	32PW6720D/01	L04E AD
PHILIPS	32PW6720D/05	L04E AD
PHILIPS	32PW6826	A10E-DVD
PHILIPS	32PW6826/01	A10E DVD-DPL AA
PHILIPS	32PW6826/05	A10E DVD-DPL AA
PHILIPS	32PW6826/58	A10E DVD-DPL AA
PHILIPS	32PW6827/01	OLD
PHILIPS	32PW6827/05	OLD
PHILIPS	32PW7566/44I	OLD
PHILIPS	32PW7566/44P	OLD
PHILIPS	32PW7566/55I	OLD
PHILIPS	32PW7566/55P	OLD
PHILIPS	32PW7566/77I	OLD
PHILIPS	32PW7566/77P	OLD
PHILIPS	32PW7566/78I	OLD
PHILIPS	32PW7566/78P	OLD
PHILIPS	32PW7723/69R	OLD
PHILIPS	32PW7723/79R	OLD
PHILIPS	32PW8106	EM2E
PHILIPS	32PW8206	EMG
PHILIPS	32PW8406	EM2E AA
PHILIPS	32PW8422	L05L AA
PHILIPS	32PW8504	MG2.1E
PHILIPS	32PW8505	MG2.1E
PHILIPS	32PW8506	EM2E
PHILIPS	32PW850A	FL2.22
PHILIPS	32PW8521/79R	EM1.1A AA
PHILIPS	32PW8521/93R	EM1.1A AA
PHILIPS	32PW8522/78R	OLD
PHILIPS	32PW852A	FL2.22
PHILIPS	32PW8604	EM2E

Brand	model	chassis
PHILIPS	32PW8604	MG2.1E ?
PHILIPS	32PW8608	EM2E (?)
PHILIPS	32PW8609	A02E
PHILIPS	32PW8620	ES.1E AA (100Hz)
PHILIPS	32PW8620/12	ES1E AA
PHILIPS	32PW8621/85R	EM1.1L AA
PHILIPS	32PW8651/12	ES1E AA
PHILIPS	32PW8707	EM2E
PHILIPS	32PW8717	EM2E AA
PHILIPS	32PW8719	A02E AA
PHILIPS	32PW8720/05	ES1E AA
PHILIPS	32PW8720/12	ES1E AA
PHILIPS	32PW874A/78R	A8.0A AA
PHILIPS	32PW8751	ES.1E (100Hz)
PHILIPS	32PW8751/12	ES1E AA
PHILIPS	32PW8757	EM2E
PHILIPS	32PW8760/12	ES1E AA
PHILIPS	32PW878A/44R	OLD
PHILIPS	32PW878A/55R	OLD
PHILIPS	32PW878A/77R	OLD
PHILIPS	32PW878A/78R	OLD
PHILIPS	32PW8806	MG2.1E
PHILIPS	32PW8807	EM3E
PHILIPS	32PW8807	MG2.1
PHILIPS	32PW8807	MG3.1E
PHILIPS	32PW8807/12	EM3E AA
PHILIPS	32PW8807/19	EM3E AA
PHILIPS	32PW8807/58	EM3E AA
PHILIPS	32PW8807/79	EM3E AA
PHILIPS	32PW8808	EM5A
PHILIPS	32PW8808/79R	EM5A P/M AA
PHILIPS	32PW8818/12	EM3E AA
PHILIPS	32PW8820/12	ES1E AA
PHILIPS	32PW8844/12	EM3E AA
PHILIPS	32PW8858/12	EM3E AA

Brand	model	chassis
PHILIPS	32PW8887	EM5E
PHILIPS	32PW8887/12	EM5E-DVD AA
PHILIPS	32PW8906	MG3.1E
PHILIPS	32PW8906/12	MG3.1E AA
PHILIPS	32PW8906/19	MG3.1E AA
PHILIPS	32PW9309	EM5.2E
PHILIPS	32PW9309/05	EM5.2E AA
PHILIPS	32PW9309/12	EM5.2E AA
PHILIPS	32PW9319	EM5.2E
PHILIPS	32PW9319/12	EM5.2E AA
PHILIPS	32PW9403	MD2.22E
PHILIPS	32PW9403/12	MD2.22E AA
PHILIPS	32PW9501	GFL2.20E
PHILIPS	32PW9502	MD2.12E
PHILIPS	32PW9503	MD2.22E
PHILIPS	32PW9503/12	MD2.22E AA
PHILIPS	32PW9503/19	MD2.22E AA
PHILIPS	32PW9503/58	MD2.22E AA
PHILIPS	32PW9505	MG2.1E
PHILIPS	32PW9509	EM5.3E
PHILIPS	32PW9512	MD2.12E
PHILIPS	32PW9513	MD2.25E
PHILIPS	32PW9513/12	MD2.25E AA
PHILIPS	32PW9513/19	MD2.25E AA
PHILIPS	32PW9515	MD2.1E
PHILIPS	32PW9520	EM5.3E AA
PHILIPS	32PW9521	GFL2
PHILIPS	32PW9523	MD2.22E
PHILIPS	32PW9523	MD2.25E
PHILIPS	32PW9523	MG2.1E
PHILIPS	32PW9523/05	MD2.22E AA
PHILIPS	32PW9523/12	MD2.22E AA
PHILIPS	32PW9523/19	MD2.22E AA
PHILIPS	32PW9523/25	MD2.25E AA
PHILIPS	32PW9523/32	MD2.25E AA

Brand	model	chassis
PHILIPS	32PW9523/39	MD2.25E AA
PHILIPS	32PW9523/58	MD2.22E AA
PHILIPS	32PW9523/75	MD2.25E AA
PHILIPS	32PW9523/95	MD2.25E AA
PHILIPS	32PW9525	MG3.1E
PHILIPS	32PW9525	MG7.1E ?
PHILIPS	32PW9525/05	MG3.1E AA
PHILIPS	32PW9525/05L	MG7.1E AA
PHILIPS	32PW9525/05R	MG7.1E AA
PHILIPS	32PW9525/12	MG3.1E AA
PHILIPS	32PW9525/12L	MG7.1E AA
PHILIPS	32PW9525/12R	MG7.1E AA
PHILIPS	32PW9525/19	MG3.1E AA
PHILIPS	32PW9525/19L	MG7.1E AA
PHILIPS	32PW9525/19R	MG7.1E AA
PHILIPS	32PW9525/58	MG3.1E AA
PHILIPS	32PW9525/58L	MG7.1E AA
PHILIPS	32PW9525/58R	MG7.1E AA
PHILIPS	32PW9525/79R	MG7.1E AA
PHILIPS	32PW9527	EM5E
PHILIPS	32PW9527/61R	EM5A NTSC AA
PHILIPS	32PW9527/79R	EM5A P/M AA
PHILIPS	32PW9528	EM5.1E AA
PHILIPS	32PW9529/79R	EM5.2A AA
PHILIPS	32PW9534	EM2E
PHILIPS	32PW9534	MD2.25E
PHILIPS	32PW9534	MG2.1E
PHILIPS	32PW9534/05	MD2.25E AA
PHILIPS	32PW9534/12	MD2.25E AA
PHILIPS	32PW9534/19	MD2.25E AA
PHILIPS	32PW9534/75	MD2.25E AA
PHILIPS	32PW9535	MG2.1E
PHILIPS	32PW9536	MG7.1E
PHILIPS	32PW9536/05	MG7.1E AA
PHILIPS	32PW9536/05R	MG7.1E AA

Brand	model	chassis
PHILIPS	32PW9536/12	MG7.1E AA
PHILIPS	32PW9536/12R	MG7.1E AA
PHILIPS	32PW9536/19	MG7.1E AA
PHILIPS	32PW9536/19R	MG7.1E AA
PHILIPS	32PW9536/58	MG7.1E AA
PHILIPS	32PW9536/58R	MG7.1E AA
PHILIPS	32PW9544	MD2.25E
PHILIPS	32PW9544	MG2.1E
PHILIPS	32PW9544/05	MD2.25E AA
PHILIPS	32PW9544/12	MD2.25E AA
PHILIPS	32PW9544/19	MD2.25E AA
PHILIPS	32PW9544/75	MD2.25E AA
PHILIPS	32PW9545	MG2.1E
PHILIPS	32PW9546	MG7.1E
PHILIPS	32PW9546	MG7.1E
PHILIPS	32PW9546/05	MG7.1E AA
PHILIPS	32PW9546/05R	MG7.1E AA
PHILIPS	32PW9546/12	MG7.1E AA
PHILIPS	32PW9546/12R	MG7.1E AA
PHILIPS	32PW9546/19	MG7.1E AA
PHILIPS	32PW9546/19R	MG7.1E AA
PHILIPS	32PW9546/58	MG7.1E AA
PHILIPS	32PW9546/58R	MG7.1E AA
PHILIPS	32PW9551	L06.1E AA
PHILIPS	32PW9556	EM3E
PHILIPS	32PW9556	MG2.1E
PHILIPS	32PW9556	MG3.1E
PHILIPS	32PW9556/12E	EM3E AA
PHILIPS	32PW9556/57E	EM3E AA
PHILIPS	32PW9556/58E	EM3E AA
PHILIPS	32PW9556/58R	MG3.1E AA
PHILIPS	32PW9556/69E	EM3E AA
PHILIPS	32PW9556/79E	EM3E AA
PHILIPS	32PW9566	MG2.1E
PHILIPS	32PW9566/05E	EM3E AA

Brand	model	chassis
PHILIPS	32PW9566/12E	EM3E AA
PHILIPS	32PW9566/19E	EM3E AA
PHILIPS	32PW9566/57E	EM3E AA;N8 AA
PHILIPS	32PW9566/58E	EM3E AA
PHILIPS	32PW9566/69E	EM3E AA
PHILIPS	32PW9566/79E	EM3E AA
PHILIPS	32PW956A	GFL2.20A
PHILIPS	32PW9576	MG2.1E
PHILIPS	32PW9576/05E	EM3E AA
PHILIPS	32PW9576/12E	EM3E AA
PHILIPS	32PW9576/19E	EM3E AA
PHILIPS	32PW9576/58E	EM3E AA
PHILIPS	32PW9576/79E	EM3E AA
PHILIPS	32PW9586	EM3E
PHILIPS	32PW9586/05	EM3E AA
PHILIPS	32PW9586/12	EM3E AA
PHILIPS	32PW9588	EM6E AA
PHILIPS	32PW958A	GFL2.20A
PHILIPS	32PW9594	EM3E
PHILIPS	32PW9594/05	EM3E AA
PHILIPS	32PW9594/12	EM3E AA
PHILIPS	32PW9595	EM3E
PHILIPS	32PW9595/05	EM3E AA
PHILIPS	32PW9595/12	EM3E AA
PHILIPS	32PW9596	EM3E
PHILIPS	32PW9596/05	EM3E AA
PHILIPS	32PW9596/12	EM3E AA
PHILIPS	32PW959A	GFL2.20A
PHILIPS	32PW960A	FL2.14
PHILIPS	32PW960B	FL2.24
PHILIPS	32PW9611	5GFL2.20E
PHILIPS	32PW9615	MG3.1E
PHILIPS	32PW9615/01	MG3.1E AA
PHILIPS	32PW9615/05	MG3.1E AA
PHILIPS	32PW9615/12	MG3.1E AA

Brand	model	chassis
PHILIPS	32PW9615/19	MG3.1E AA
PHILIPS	32PW9615/58	MG3.1E AA
PHILIPS	32PW9616	MG3.1E
PHILIPS	32PW9616	MG3.1E
PHILIPS	32PW9616/01	MG3.1E AA
PHILIPS	32PW9616/01M	MG3.1E AA
PHILIPS	32PW9616/01R	MG3.1E AA
PHILIPS	32PW9616/05	MG3.1E AA
PHILIPS	32PW9616/05M	MG3.1E AA
PHILIPS	32PW9616/05R	MG3.1E AA
PHILIPS	32PW9616/12	MG3.1E AA
PHILIPS	32PW9616/12M	MG3.1E AA
PHILIPS	32PW9616/12R	MG3.1E AA
PHILIPS	32PW9616/19	MG3.1E AA
PHILIPS	32PW9616/19M	MG3.1E AA
PHILIPS	32PW9616/19R	MG3.1E AA
PHILIPS	32PW9616/58M	MG3.1E AA
PHILIPS	32PW9616/58R	MG3.1E AA
PHILIPS	32PW9617	MG3.2E
PHILIPS	32PW9618	EM6E AA
PHILIPS	32PW962A	FL2.14
PHILIPS	32PW962B	FL2.24
PHILIPS	32PW9631	GFL2.30
PHILIPS	32PW967A	GFL2.20A
PHILIPS	32PW968A	GFL2.20A
PHILIPS	32PW969A	GFL2.20A
PHILIPS	32PW9713	MD2.21E
PHILIPS	32PW9713/05	MD2.22E AA
PHILIPS	32PW9713/12	MD2.22E AA
PHILIPS	32PW9713/19	MD2.22E AA
PHILIPS	32PW9723	MD2.25E
PHILIPS	32PW9723/05	MD2.25E AA
PHILIPS	32PW9723/12	MD2.25E AA
PHILIPS	32PW9723/19	MD2.25E AA
PHILIPS	32PW9723/32	MD2.25E AA

Brand	model	chassis
PHILIPS	32PW975A	FL2.24
PHILIPS	32PW9761	5GFL2.20E
PHILIPS	32PW9761	5GFL2.30E AA
PHILIPS	32PW9763	MD2.21E
PHILIPS	32PW9763	MD2.25E
PHILIPS	32PW9763/05	MD2.22E AA
PHILIPS	32PW9763/12	MD2.22E AA
PHILIPS	32PW9763/19	MD2.22E AA
PHILIPS	32PW9763/25	MD2.25E AA
PHILIPS	32PW9763/32	MD2.25E AA
PHILIPS	32PW9763/39	MD2.25E AA
PHILIPS	32PW9763/58	MD2.22E AA
PHILIPS	32PW9763/95	MD2.25E AA
PHILIPS	32PW9765	MG3.1E
PHILIPS	32PW9765/01	MG3.1E AA
PHILIPS	32PW9765/01M	MG3.1E AA
PHILIPS	32PW9765/01R	MG3.1E AA
PHILIPS	32PW9765/12	MG3.1E AA
PHILIPS	32PW9765/12M	MG3.1E AA
PHILIPS	32PW9765/12R	MG3.1E AA
PHILIPS	32PW9765/19	MG3.1E AA
PHILIPS	32PW9765/19R	MG3.1E AA
PHILIPS	32PW9765/58	MG3.1E AA
PHILIPS	32PW9765/58M	MG3.1E AA
PHILIPS	32PW9765/58R	MG3.1E AA
PHILIPS	32PW9767	MG3.2E AA
PHILIPS	32PW9768	EM6E
PHILIPS	32PW9768/05	EM5E
PHILIPS	32PW9768/12	EM6E
PHILIPS	32PW977A	FL2.24
PHILIPS	32PW9781	GFL2.30E
PHILIPS	32PW978A	GFL2.20A
PHILIPS	32PW979B	GFL2.20A
PHILIPS	32PW987C	GFL2.20A
PHILIPS	32PW988C	GFL2.20A

Brand	model	chassis
PHILIPS	32PW988C/71	OLD
PHILIPS	32PX967A	GFL2.20A
PHILIPS	32PX977A	GFL2.20A
PHILIPS	32PX979B/61	OLD
PHILIPS	32RF085/35R	OLD
PHILIPS	32RF085/37R	OLD
PHILIPS	32RF085/85R	OLD
PHILIPS	32RF250/37R	OLD
PHILIPS	32RF280/37R	OLD
PHILIPS	32RF290/37R	OLD
PHILIPS	32RFA150/35R	OLD
PHILIPS	32RFA150/37R	OLD
PHILIPS	32RFA150/85R	OLD
PHILIPS	32RFA185/35R	OLD
PHILIPS	32RFA185/37R	OLD
PHILIPS	32RFA185/85R	OLD
PHILIPS	32RFA190/35R	OLD
PHILIPS	32RFA190/37R	OLD
PHILIPS	32RFA190/85R	OLD
PHILIPS	32RFDVD140/37R	OLD
PHILIPS	32RFDVD260/37R	OLD
PHILIPS	32ST2200/27	L04HU AA
PHILIPS	32ST6210/27	L04HU AA
PHILIPS	32TA1000/79	TPF1.4A LA
PHILIPS	32TA1000/93	TPF1.4A LA
PHILIPS	32TA1000/98	TPF1.4A LA
PHILIPS	32TA1600/93	TPF1.4A LA
PHILIPS	32TA1600/98	TPF1.4A LA
PHILIPS	32TA2800/79	TPS1.1A LA
PHILIPS	32TA2800/93	TPS1.1A LA
PHILIPS	32TA2800/98	TPS1.1A LA
PHILIPS	32TA3000/93	TPS1.1A LA
PHILIPS	333457EK	3A
PHILIPS	337557EK	3A
PHILIPS	338302BX	D16

Brand	model	chassis
PHILIPS	338362BX	D16
PHILIPS	339975KR	FL1.0
PHILIPS	33CE3930	3A
PHILIPS	33CE7531	3A
PHILIPS	33CE7533	3A
PHILIPS	33CE7535	3A
PHILIPS	33CE7536	3A
PHILIPS	33CE7537	3A
PHILIPS	33CE7538	3A
PHILIPS	33CE7539	3A
PHILIPS	33D2080	D16 III ?
PHILIPS	33DC2080	D16
PHILIPS	33DC2085	D16
PHILIPS	33FL1780	FL1.0S
PHILIPS	33FL1785	FL1.0S
PHILIPS	33FL1880	FL1.1S
PHILIPS	33ML8905	FL1.6
PHILIPS	33ML8905/>20	FL1.16
PHILIPS	33ML8990	FL1.1
PHILIPS	33ML8996	FL1.1 AB
PHILIPS	33PT5441/85	L04L AA
PHILIPS	33PT5631/44R	OLD
PHILIPS	33PT5631/85R	L01.1L AC
PHILIPS	33PT5633/61R	A8.0A AA
PHILIPS	33PT5633/71R	A8.0A AA
PHILIPS	33PT5633/97R	A8.0A AA
PHILIPS	33PT5683/93S	A8.0A AA
PHILIPS	33PT5693/57R	A8.0A AA
PHILIPS	33PT5693/68R	A8.0A AA
PHILIPS	33PT5693/69R	A8.0A AA
PHILIPS	33PT5693/70R	A8.0A AA
PHILIPS	33PT5693/75R	A8.0A AA
PHILIPS	33PT5693/79R	A8.0A AA
PHILIPS	33PT574	L9.1A ?
PHILIPS	33PT574A/78R	OLD

Brand	model	chassis
PHILIPS	33PT578A	L01.1E
PHILIPS	33PT578A/55R	L01.1L AA
PHILIPS	33PT578A/77R	L01.1L AA
PHILIPS	33PT578A/78R	L01.1L AA
PHILIPS	33PT670	Z5
PHILIPS	33PT700A	FL1.10
PHILIPS	33PT700B	FL1.0
PHILIPS	33PT700B	FL1.10
PHILIPS	33PT700C	FL1.20
PHILIPS	33PT700C/00	UNKNOWN
PHILIPS	33PT702A	FL1.10
PHILIPS	33PT702B	FL1.10
PHILIPS	33PT702C	FL1.20 AA
PHILIPS	33PT710A	FL1.10
PHILIPS	33PT710B	FL1.10
PHILIPS	33PT710C	FL1.20
PHILIPS	33PT712A	FL1.10
PHILIPS	33PT712B	FL1.10
PHILIPS	33PT772A/77B	A8.0A AA
PHILIPS	33PT9101	GFL2.20 AA
PHILIPS	33PT910B	FL2.26
PHILIPS	33PT9121	GFL2.20E AA
PHILIPS	33PT912B	FL2.26
PHILIPS	33PV7905	FL1.0
PHILIPS	33PV7906	FL1.0
PHILIPS	33PV7990	FL1.0
PHILIPS	33PV7996	FL1.0
PHILIPS	33PX8001	GFL33V
PHILIPS	33SL5790	FL1.0
PHILIPS	33SL5796	FL1.0
PHILIPS	33SL5900	FL1.0
PHILIPS	33SL5901	FL1.0
PHILIPS	34HT3312/93R	L04HA AA
PHILIPS	34HW8815/35	MG3.1U AA
PHILIPS	34HW9817/35R	OLD

Brand	model	chassis
PHILIPS	34PH9915/17	MG4.1U AA
PHILIPS	34PT3224/93R	L04A AA
PHILIPS	34PT3225/93	L04A AA
PHILIPS	34PT3543/93R	L01.1A AC;L2K3 AA
PHILIPS	34PT4323/56R	L01.1A AC;L2K3 AA
PHILIPS	34PT4323/67R	L01.1A AC;L2K3 AA
PHILIPS	34PT4323/69R	L01.1A AC;L2K3 AA
PHILIPS	34PT4323/71R	L01.1A AC;L2K3 AA
PHILIPS	34PT4323/79R	OLD
PHILIPS	34PT4524/93R	L04A AA
PHILIPS	34PT4822	L9.1A
PHILIPS	34PT4873	L9.1A
PHILIPS	34PT5633/61R	A8.0A AA
PHILIPS	34PT5633/71R	A8.0A AA
PHILIPS	34PT5683/93S	A8.0A AA
PHILIPS	34PT5693	A8.0A
PHILIPS	34PT5693/56A	A8.0A AA
PHILIPS	34PT5693/56E	A8.0A AA
PHILIPS	34PT5693/57R	A8.0A AA
PHILIPS	34PT5693/68R	A8.0A AA
PHILIPS	34PT5693/69R	A8.0A AA
PHILIPS	34PT5693/70R	A8.0A AA
PHILIPS	34PT5693/75R	A8.0A AA
PHILIPS	34PT5693/79R	A8.0A AA
PHILIPS	34PT5693/93	A8.0A AA
PHILIPS	34PT5693/93S	A8.0A AA
PHILIPS	34PT5792	A8.0A AA (?)
PHILIPS	34PT5793	A8.0A
PHILIPS	34PT5793/56A	A8.0A AA
PHILIPS	34PT5793/57R	A8.0A AA
PHILIPS	34PT5793/69R	A8.0A AA
PHILIPS	34PT5793/79R	A8.0A AA
PHILIPS	34PT5893/93S	A8.0A AA
PHILIPS	34PT6131/93R	A10A AA
PHILIPS	34PT6231/93R	A10A AA

Brand	model	chassis
PHILIPS	34PT6251/93S	A10A AA
PHILIPS	34PT6320/56A	A10A AA
PHILIPS	34PT6320/57R	A10A AA
PHILIPS	34PT6320/61R	A10A AA
PHILIPS	34PT6320/69R	A10A AA
PHILIPS	34PT6320/71R	A10A AA
PHILIPS	34PT6320/79R	A10A AA
PHILIPS	34PT6320/93R	A10A AA
PHILIPS	34PT6361	A10A
PHILIPS	34PT6361/57R	A10A AA
PHILIPS	34PT6361/61R	A10A AA
PHILIPS	34PT6361/69R	A10A AA
PHILIPS	34PT6361/71R	A10A AA
PHILIPS	34PT6361/79R	A10A AA
PHILIPS	34PT6361/97R	A10A AA
PHILIPS	34PT7322/93G	L04A AB
PHILIPS	34PT7333/93R	L04A AB
PHILIPS	34PT786	A10E AA
PHILIPS	34PT8319/93G	OLD
PHILIPS	34PT8319/93S	OLD
PHILIPS	34PT8320/93S	OLD
PHILIPS	34PT8322/56R	EM1.1A AA
PHILIPS	34PT8322/69R	EM1.1A AA
PHILIPS	34PT8322/93R	EM1.1A AA
PHILIPS	34PT8419	EM1A
PHILIPS	34PT8419/56R	EM1A AA
PHILIPS	34PT8419/57R	EM1A AA
PHILIPS	34PT8419/61R	EM1A NTSC AA
PHILIPS	34PT8419/69R	EM1A AA
PHILIPS	34PT8419/71R	EM1A NTSC AA
PHILIPS	34PT8419/77	EM1L AA
PHILIPS	34PT8419/78	EM1L AA
PHILIPS	34PT8419/79R	EM1A AA
PHILIPS	34PT8419/93R	EM1A AA
PHILIPS	34PT8420	EM1A

Brand	model	chassis
PHILIPS	34PT8420/56A	EM1A AA
PHILIPS	34PT8420/56R	EM1A AA
PHILIPS	34PT8420/57R	EM1A AA
PHILIPS	34PT8420/61R	EM1A NTSC AA
PHILIPS	34PT8420/69R	EM1A AA
PHILIPS	34PT8420/71R	EM1A NTSC AA
PHILIPS	34PT8420/79R	EM1A AA
PHILIPS	34PT8420/93R	OLD
PHILIPS	34PT8422	L05U (?)
PHILIPS	34PT8805/93	L04A AB
PHILIPS	34PT8825/93	L04A AB
PHILIPS	34PT8845/69	L04A AB
PHILIPS	34PT8865/93	L04A AB
PHILIPS	34PT9420	EM1A
PHILIPS	34PT9420	EM5A
PHILIPS	34PT9420/57R	EM5A P/M AA
PHILIPS	34PT9420/61R	EM5A NTSC AA
PHILIPS	34PT9420/69R	EM5A P/M AA
PHILIPS	34PT9420/71R	EM5A NTSC AA
PHILIPS	34PT9420/93R	EM5A P/M AA
PHILIPS	34PT9421/56R	EM5.2A AA;EM5.3A P/M AA
PHILIPS	34PT9421/69R	EM5.2A AA;EM5.3A P/M AA
PHILIPS	34PT9421/93R	EM5.2A AA;EM5.3A P/M AA
PHILIPS	34PT9818	EM5A
PHILIPS	34PW8501/37R	EM1.1U AA
PHILIPS	34PW850H37F	EM1.2AA
PHILIPS	34PW8520/17	P8 AA
PHILIPS	34PW8621/37R	EM1.1U AA
PHILIPS	34PW9815/17	MG3.1U AA
PHILIPS	34PW9815/97R	MG3.1U AA
PHILIPS	34PW9817/17	MG3.1U AA
PHILIPS	34PW9817/97R	MG3.1U AA
PHILIPS	34PW9818/17	EM5U AA;R8 AA
PHILIPS	34PW9818/71R	EM5L AA
PHILIPS	34PW9819/17	EM5U AA;R8 AA

Brand	model	chassis
PHILIPS	34PW9846/17	MG3.1U AA
PHILIPS	34PW9847/17	MG3.1U AA
PHILIPS	36A840/36R	OLD
PHILIPS	36A975/37R	OLD
PHILIPS	36A975/85R	OLD
PHILIPS	36FL1890	FL1.2 SAT
PHILIPS	36FL8965	FL1.2
PHILIPS	36L150/35R	OLD
PHILIPS	36L150/37R	OLD
PHILIPS	36L150/37R1	OLD
PHILIPS	36L150/37R2	M8 AA;T8 AA
PHILIPS	36L150/85R	OLD
PHILIPS	36LP128PP/35R	OLD
PHILIPS	36LP128SN/35R	OLD
PHILIPS	36LP28/40C	OLD
PHILIPS	36LP29	OLD
PHILIPS	36LP29/40A	OLD
PHILIPS	36LP29/40B	OLD
PHILIPS	36ML8906	FL1.2
PHILIPS	36ML8908	FL1.2
PHILIPS	36ML8908/39B	FL1.14
PHILIPS	36ML8965	FL1.2
PHILIPS	36ML8965	FL1.4
PHILIPS	36ML8985	FL1.4
PHILIPS	36PT8320	R8 AA
PHILIPS	36PT8320/37R	OLD
PHILIPS	36PT8320/71R	OLD
PHILIPS	36PT8421/37R	OLD
PHILIPS	36PT842H	R8 AA
PHILIPS	36PW8521/78R	EM1.1L AA
PHILIPS	36PW8621/85R	EM1.1L AA
PHILIPS	36PW9525	MG3.1E
PHILIPS	36PW9525/05	MG3.1E AA
PHILIPS	36PW9525/05R	MG3.1E AA
PHILIPS	36PW9525/12	MG3.1E AA

Brand	model	chassis
PHILIPS	36PW9525/12R	MG3.1E AA
PHILIPS	36PW9525/19	MG3.1E AA
PHILIPS	36PW9525/19R	MG3.1E AA
PHILIPS	36PW9525/57R	MG3.1E AA
PHILIPS	36PW9525/58	MG3.1E AA
PHILIPS	36PW9525/58R	MG3.1E AA
PHILIPS	36PW9525/69R	MG3.1E AA
PHILIPS	36PW9525/79R	MG3.1E AA
PHILIPS	36PW9527	EM5A
PHILIPS	36PW9527/57R	EM5A P/M AA
PHILIPS	36PW9527/61R	EM5A NTSC AA
PHILIPS	36PW9527/69R	EM5A P/M AA
PHILIPS	36PW9527/79R	EM5A P/M AA
PHILIPS	36PW9607	MG3.2E
PHILIPS	36PW9765	MG3.1E
PHILIPS	36PW9765/01	MG3.1E AA
PHILIPS	36PW9765/01R	MG3.1E AA
PHILIPS	36PW9765/05	MG3.1E AA
PHILIPS	36PW9765/12	MG3.1E AA
PHILIPS	36PW9765/12R	MG3.1E AA
PHILIPS	36PW9765/19	MG3.1E AA
PHILIPS	36PW9765/19R	MG3.1E AA
PHILIPS	36PW9765/58	MG3.1E AA
PHILIPS	36PW9765/58R	MG3.1E AA
PHILIPS	36PW9767	MG3.2E
PHILIPS	36PW9817/78	MG3.1U AA
PHILIPS	36PW9818	EM5L
PHILIPS	36PW9818/55	EM5U AA;R8 AA
PHILIPS	36PW9818/77	EM5L AA
PHILIPS	36PW9818/78	EM5L AA
PHILIPS	36RF280/37R	OLD
PHILIPS	37CS5600	K40-PROJ.
PHILIPS	37CS5600/02S	System4 (KT4)
PHILIPS	37CS5606	K40-PROJ.
PHILIPS	37CS5607	K40

Brand	model	chassis
PHILIPS	37FD9944/01S	FM33 AA
PHILIPS	37FD9954/17	FM33 AA
PHILIPS	37FD9954/69S	FM33 AA
PHILIPS	37FD9954F/17	OLD
PHILIPS	37HF7444/10	LC4.31HE AA
PHILIPS	37HF7543/37	BL2.3HU AA
PHILIPS	37HF7544D/27	LC4.31HU AB
PHILIPS	37KE1020	CP90
PHILIPS	37KE1022	CP90
PHILIPS	37KE1025	CP90
PHILIPS	37KF1140	CF1
PHILIPS	37KF1141	CF1
PHILIPS	37KN2010	NC3CR
PHILIPS	37KN2012	NC3CR
PHILIPS	37KN3030	NC3
PHILIPS	37KN3050	NC3
PHILIPS	37KN3150	NC3
PHILIPS	37KN3154	NC3
PHILIPS	37KN3164	NC3
PHILIPS	37KN5184	NC3CR
PHILIPS	37KT5042	KT4M
PHILIPS	37KT6200	CTO-S
PHILIPS	37KV1212	GR1AX
PHILIPS	37KV1222	GR1AX
PHILIPS	37KV1230	GR1AX
PHILIPS	37KV1232	GR1AX
PHILIPS	37KV1240	GR1AX
PHILIPS	37KV1242	GR1AX
PHILIPS	37KV2225	G90B
PHILIPS	37KV2271	G90B
PHILIPS	37KV2273	G90B
PHILIPS	37KV2281	G90B
PHILIPS	37KV2283	G90B
PHILIPS	37KV2291	G90B
PHILIPS	37MF231D/37	TPE1.0U LA

Brand	model	chassis
PHILIPS	37MF321D/37	TPE1.0U LA
PHILIPS	37MF331D/37	TPE1.0U LA
PHILIPS	37MF337B/37	TPM1.0U LA
PHILIPS	37MF437B/37	TPM2.0U LA
PHILIPS	37PF1600T/96	MQC2.0A LA
PHILIPS	37PF3321/10	LC4.31E AA
PHILIPS	37PF5320/10	LC4.8E AA
PHILIPS	37PF5321/10	LC4.31E AA
PHILIPS	37PF5321/12	LC4.31E AA
PHILIPS	37PF5520D/10	LC4.8E AB
PHILIPS	37PF5521D	LC4.31E AB
PHILIPS	37PF7320	LC4.8E
PHILIPS	37PF7320/10	LC4.8E AA
PHILIPS	37PF7320/79	LC4.8A AA
PHILIPS	37PF7320/93	LC4.8A AA
PHILIPS	37PF7320/98	LC4.8A AA
PHILIPS	37PF7320A/37	BL2.3U AA
PHILIPS	37PF7321/12	LC4.31E AA
PHILIPS	37PF7321/79	LC4.31A AA
PHILIPS	37PF7321/93	LC4.31A AA
PHILIPS	37PF7321/98	LC4.31A AA
PHILIPS	37PF7321D/37	EL1.1U AA
PHILIPS	37PF7331/12	LC4.31E AA
PHILIPS	37PF7411/12	LC4.31E AA
PHILIPS	37PF7521D	LC4.31E AB
PHILIPS	37PF7641D/10	BJ3.0E LA
PHILIPS	37PF9431D/37	BJ2.5U LA
PHILIPS	37PF9531/79	BJ3.0A LA
PHILIPS	37PF9531/93	BJ3.0A LA
PHILIPS	37PF9531/98	BJ3.0A LA
PHILIPS	37PF9631D/10	BJ3.0E LA
PHILIPS	37PF9631D/37	EJ2.0U LA
PHILIPS	37PF9631D/79	BJ3.0E LA
PHILIPS	37PF9641D/10	BJ3.0E LA
PHILIPS	37PF9731/69	FJ3.0E LA

Brand	model	chassis
PHILIPS	37PF9731D	FJ3.0E
PHILIPS	37PF9731D/10	FJ3.0E LA
PHILIPS	37PF9936/37	LC4.7U AA
PHILIPS	37PF9946	EM2E
PHILIPS	37PF9965/12S	F22RE AA;FM33 AA
PHILIPS	37PF9975/12	FTP2.2E AA
PHILIPS	37PF9986/12	FTL2.1E AA
PHILIPS	37PFL3312/10	LC7.1E LA
PHILIPS	37PFL3312S/60	LC7.1E LA
PHILIPS	37PFL3403/93	UNKNOWN
PHILIPS	37PFL3403/97	UNKNOWN
PHILIPS	37PFL3403S/60	UNKNOWN
PHILIPS	37PFL3512D/12	LC7.2E LA
PHILIPS	37PFL5322/10	LC7.1E LA
PHILIPS	37PFL5322/12	LC7.1E LA
PHILIPS	37PFL5322D/37	TPM1.0U LA
PHILIPS	37PFL5322S/60	LC7.1E LA
PHILIPS	37PFL5332/77	LC7.1L LA
PHILIPS	37PFL5332/78	LC7.1L LA
PHILIPS	37PFL5332D/37	EJ3.0U LA
PHILIPS	37PFL5403/10	UNKNOWN
PHILIPS	37PFL5403/77	UNKNOWN
PHILIPS	37PFL5403/78	UNKNOWN
PHILIPS	37PFL5403D/12	UNKNOWN
PHILIPS	37PFL5403H/10	UNKNOWN
PHILIPS	37PFL5403M/08	UNKNOWN
PHILIPS	37PFL5403S/60	UNKNOWN
PHILIPS	37PFL5422/96	IMP1.0A LA
PHILIPS	37PFL5522D/05	LC7.2E LA
PHILIPS	37PFL5522D/12	LC7.2E LA
PHILIPS	37PFL7312/77	LC4.8L LA
PHILIPS	37PFL7312/78	LC4.8L LA
PHILIPS	37PFL7332/10	BJ3.1E LA
PHILIPS	37PFL7332D/37	EJ3.0U LA
PHILIPS	37PFL7422/79	TPT1.2A LA

Brand	model	chassis
PHILIPS	37PFL7422/93	TPT1.2A LA
PHILIPS	37PFL7422/98	TPT1.2A LA
PHILIPS	37PFL7562D/10	BJ3.1E LA
PHILIPS	37PFL7603D/05	UNKNOWN
PHILIPS	37PFL7603D/12	UNKNOWN
PHILIPS	37PFL7603H/10	UNKNOWN
PHILIPS	37PFL7603M/08	UNKNOWN
PHILIPS	37PFL7603S/60	UNKNOWN
PHILIPS	37PFL7662D/05	LC7.2E LA
PHILIPS	37PFL7662D/12	LC7.2E LA
PHILIPS	37PFL9603D/08	UNKNOWN
PHILIPS	37PFL9603D/10	UNKNOWN
PHILIPS	37PFL9603D/19	UNKNOWN
PHILIPS	37PFL9632D/10	Q528.1E LA
PHILIPS	37PFL9642D/19	Q528.1E LB
PHILIPS	37PFL9732D/10	Q528.1E LA
PHILIPS	37PT782A/77B	A8.0A AA
PHILIPS	37PT786A/77R	L10 (?)
PHILIPS	37TA1040	CTT-H
PHILIPS	37TA1050	CTT-H
PHILIPS	37TA1060	CTT-H
PHILIPS	37TA1070	CTT-H
PHILIPS	37TA1080	CTT-H
PHILIPS	37TA1090	CTT-H
PHILIPS	37TA1161	ANUBIS A
PHILIPS	37TA1171	AA5 AA
PHILIPS	37TA1210	ANUBIS A
PHILIPS	37TA1211	AA5 AA
PHILIPS	37TA1262 (Radiola)	L6.1
PHILIPS	37TA1271	AA5 AA
PHILIPS	37TA1272	L6.1
PHILIPS	37TA1276/03	L01.2E AA;L01.2E AB
PHILIPS	37TA1438/03	OLD
PHILIPS	37TA1438/16	OLD
PHILIPS	37TA1462	L6.1

Brand	model	chassis
PHILIPS	37TA1471	AA5 AA
PHILIPS	37TA1472	L6.1
PHILIPS	37TA1476/03	L01.2E AA;L01.2E AB
PHILIPS	37TA1800/93	TPT1.0A LA
PHILIPS	37TA2000/93	TPT1.0A LA
PHILIPS	37TA2800/79	TPT1.1A LA
PHILIPS	37TA2800/93	TPT1.1A LA
PHILIPS	37TA2800/98	TPT1.1A LA
PHILIPS	37TB1140	ANUBIS A
PHILIPS	37TB1141	ANUBIS A
PHILIPS	37TB1151	AA5 AA
PHILIPS	37TB1190	ANUBIS A
PHILIPS	37TB1191	AA5 AA
PHILIPS	37TB1238/19	OLD
PHILIPS	37TB1252	L6.1
PHILIPS	37TR120	TVCR B
PHILIPS	37TR125	TVCR B
PHILIPS	37TR126	TVCR B
PHILIPS	37TR127	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	37TR210	TVCR E (TVCR Epsilon 2001)
PHILIPS	37TR215	TVCR DELTA99 AA
PHILIPS	37TR216	TVCR D (TVCR Delta2000)
PHILIPS	37TR220	TVCR E (TVCR Epsilon 2001)
PHILIPS	37TVB10	TVCR B
PHILIPS	37TVB11	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	37TVB50	TVCR DELTA99 AA
PHILIPS	37TVB51	TVCR D (TVCR Delta2000)
PHILIPS	37TVB60	TVCR E (TVCR Epsilon 2001)
PHILIPS	37ZZ3223	ANUBIS A
PHILIPS	37ZZ3233	ANUBIS A AB
PHILIPS	37ZZ3241	ANUBIS A
PHILIPS	37ZZ3243	ANUBIS A
PHILIPS	38KE1100	CP90
PHILIPS	38KE1102	CP90
PHILIPS	38KE1105	CP90

Brand	model	chassis
PHILIPS	38KE1185	CP90
PHILIPS	38KN3254	NC3
PHILIPS	38KV2321	G90
PHILIPS	38KV2323	G90
PHILIPS	38KV2325	G90B
PHILIPS	38KV2383	G90B
PHILIPS	38KV2386	G90B
PHILIPS	38KV2393	G90B
PHILIPS	38PT6351/93R	OLD
PHILIPS	38PT6361/56A	OLD
PHILIPS	38PT6361/57R	OLD
PHILIPS	38PT6361/61R	OLD
PHILIPS	38PT6361/69R	OLD
PHILIPS	38PT6361/71R	OLD
PHILIPS	38PT6361/79R	OLD
PHILIPS	38PT6361/97R	OLD
PHILIPS	38PT876A/44R	OLD
PHILIPS	38PT876A/55R	OLD
PHILIPS	38PT876A/77R	OLD
PHILIPS	38PT876A/78R	OLD
PHILIPS	38TA1271	AA5 AA
PHILIPS	38TB1191	AA5 AA
PHILIPS	38ZY3325	ANUBIS A
PHILIPS	38ZZ3253	ANUBIS A
PHILIPS	38ZZ3273	ANUBIS A
PHILIPS	38ZZ3383	ANUBIS A
PHILIPS	38ZZ3385	ANUBIS A
PHILIPS	414488IR	G110 PTV
PHILIPS	41CE8740	3A
PHILIPS	41CE8741	3A
PHILIPS	41CE8743	3A-PTV
PHILIPS	41CE8745	3A
PHILIPS	41CE8746	3A-PTV
PHILIPS	41CE8748	3A-PTV
PHILIPS	41CE8749	3A-PTV

Brand	model	chassis
PHILIPS	41CE8760	3A
PHILIPS	41CE8761	3A
PHILIPS	41CE8763	3A
PHILIPS	41CE8765	3A
PHILIPS	41CE8766	3A
PHILIPS	41CE8768	3A
PHILIPS	41CE8769	3A
PHILIPS	41GR8840	G110PTV
PHILIPS	41GR8841	G110PTV
PHILIPS	41KE8417	3A-PTV
PHILIPS	41KE8437	3A-PTV
PHILIPS	41KE8467	3A
PHILIPS	41KE8487	3A-PTV
PHILIPS	41KV8408	G110
PHILIPS	41KV8428	G110
PHILIPS	41KV8438	G110
PHILIPS	41ML0955	FL1
PHILIPS	420P10	FTV1.9DEAA
PHILIPS	420P10/00	FTV1.9DE AA
PHILIPS	420P30/00	FM23 AA;FM23 AB;FM23 AC
PHILIPS	42FD9932	FTV1.9DEAA
PHILIPS	42FD9932/01G	FTV1.9DE AA
PHILIPS	42FD9932/01S	FTV1.9DE AA
PHILIPS	42FD9932/69S	FTV1.9DE AA
PHILIPS	42FD9934	FM24 AA;FM24 AB
PHILIPS	42FD9934/69C	FM24 AB
PHILIPS	42FD9935	FM242 AA
PHILIPS	42FD9944	FM24 AA
PHILIPS	42FD9944/93S	FM24 AB
PHILIPS	42FD9945	FM242 ?
PHILIPS	42FD9954/69C	FM24 AB
PHILIPS	42FW9015/37	FTP1.1U AA
PHILIPS	42FW9020/37	LC4.7HU AA
PHILIPS	42FW9030/17	LC4.7U AA
PHILIPS	42FW9220/37	FTP2.2U AA

Brand	model	chassis
PHILIPS	42FW991P/35A	OLD
PHILIPS	42FW9975/35	FTP2.2U AA
PHILIPS	42HF7443/10	LC4.9HE AA
PHILIPS	42HF7444T/27	LC4.41HU AB
PHILIPS	42HF7543/37	BP2.3HU AA
PHILIPS	42HF7544D/27	LC4.41HU AB
PHILIPS	42HF7544R/27	LC4.41HU AB
PHILIPS	42HF7845/10	LC7.1HE LA
PHILIPS	42HF7945D/27	LC7.2HU LA
PHILIPS	42HF7965D/27	UNKNOWN
PHILIPS	42HF9385D/10	Q528.1E LA
PHILIPS	42HF9442/12	LC4.7HE AA
PHILIPS	42HF9442/98	LC4.7HA AA
PHILIPS	42HF9952/12Z	F21RE AA;FM23 AA;FTV1.9EE AA
PHILIPS	42HF9952/35R	OLD
PHILIPS	42HF9953/12	OLD
PHILIPS	42HF9953/12Z	FM24 AB
PHILIPS	42HF9953/69	OLD
PHILIPS	42HF9953/69Z	OLD
PHILIPS	42HF9964/12Z	F21RE AA;FM24 AA
PHILIPS	42HF9964/22Z	F21RE AA;FM24 AA
PHILIPS	42KT4146	KT4
PHILIPS	42KT4164	KT4
PHILIPS	42KT4166	KT4
PHILIPS	42KT4184	KT4
PHILIPS	42KT4187	KT4
PHILIPS	42KT5142	KT4M
PHILIPS	42KT5184	KT4M
PHILIPS	42KT6250	CTO-S
PHILIPS	42KT6254	CTO-S
PHILIPS	42KT6260	CTO-S
PHILIPS	42MF130A/37	MP1.1U AA
PHILIPS	42MF230A/37	MP1.1U AA
PHILIPS	42MF231D/17	TPE1.0U PA
PHILIPS	42MF231D/37	TPE1.0U PA

Brand	model	chassis
PHILIPS	42MF237S/37	EJ3.0U PA
PHILIPS	42MF337B/37	TPM1.0U LA
PHILIPS	42MF338B/27	UNKNOWN
PHILIPS	42MF431D/37	TPE1.0U LA
PHILIPS	42MF437B/37	TPM2.0U LA
PHILIPS	42MF438B/27	UNKNOWN
PHILIPS	42MF521D/37	TPE1.0U LA
PHILIPS	42MF531D/37	TPE1.0U LA
PHILIPS	42MF7000	U25
PHILIPS	42MF7010	U25
PHILIPS	42PF1000/62	TES1.1E PA
PHILIPS	42PF3320	LC4.9E AA
PHILIPS	42PF3331/10	LC4.31E AA
PHILIPS	42PF5320	LC4.9E AA
PHILIPS	42PF5320/10	LC4.9E
PHILIPS	42PF5320/79	LC4.9A AA
PHILIPS	42PF5321D/37	EP1.1U AA
PHILIPS	42PF5321D/85	EP1.1U AA
PHILIPS	42PF5331/10	LC4.41E AA
PHILIPS	42PF5421/10	LC4.31E AA
PHILIPS	42PF5421D/37	EL1.1U AA
PHILIPS	42PF5521D/10	LC4.41E AB
PHILIPS	42PF5521D/12	LC4.41E AB
PHILIPS	42PF7220A/37	BP2.3U AA
PHILIPS	42PF7320	LC4.9AA
PHILIPS	42PF7320/28	LC4.9U AA
PHILIPS	42PF7320/77	LC4.9U AA
PHILIPS	42PF7320/78	LC4.9U AA
PHILIPS	42PF7320/79	LC4.9A AA
PHILIPS	42PF7320/93	LC4.9A AA
PHILIPS	42PF7320/98	LC4.9A AA
PHILIPS	42PF7320A	BP2.3U AA ?
PHILIPS	42PF7320A/37	BP2.3U AA
PHILIPS	42PF7320G/79	LC4.41A AA
PHILIPS	42PF7320G/98	LC4.41A AA

Brand	model	chassis
PHILIPS	42PF7320Z/93	LC4.9A AA
PHILIPS	42PF7321/77	LC4.9U AA
PHILIPS	42PF7321/78	LC4.9U AA
PHILIPS	42PF7321D/37	EP1.1U AA
PHILIPS	42PF7411/10	LC4.31E AA
PHILIPS	42PF7420/10	LC4.8E AA
PHILIPS	42PF7420/79	LC4.8A AA
PHILIPS	42PF7420/93	LC4.8A AA
PHILIPS	42PF7420/98	LC4.8A AA
PHILIPS	42PF7421/79	LC4.31A AA
PHILIPS	42PF7421/93	LC4.31A AA
PHILIPS	42PF7421/98	LC4.31A AA
PHILIPS	42PF7421D	LC4.31E AB
PHILIPS	42PF7421D/37	EL1.1U AA
PHILIPS	42PF7520D	LC4.9E AB
PHILIPS	42PF7520D/79	LC4.9A AB
PHILIPS	42PF7520G/98	LC4.41A AA
PHILIPS	42PF7520Z/93	LC4.9A AA
PHILIPS	42PF7521D/10	LC4.41E AB
PHILIPS	42PF7521D/12	LC4.41E AB
PHILIPS	42PF7621D/10	BJ3.0E LA
PHILIPS	42PF7641D/10	BJ3.0E LA
PHILIPS	42PF9431D/37	BJ2.5U PA
PHILIPS	42PF9531/79	BJ3.0A PA
PHILIPS	42PF9531/93	BJ3.0A PA
PHILIPS	42PF9531/98	BJ3.0A PA
PHILIPS	42PF9541/93	BJ3.0A LA
PHILIPS	42PF9541/98	BJ3.0A LA
PHILIPS	42PF9630/78	FTP2.4L AA
PHILIPS	42PF9630A/37	BP2.2U AA
PHILIPS	42PF9630A/96	BP2.2U AA
PHILIPS	42PF9631D/10	BJ3.0E PA
PHILIPS	42PF9631D/37	BJ2.4U PA
PHILIPS	42PF9631D/79	BJ3.0E PA
PHILIPS	42PF9641D/10	FJ3.0E LA

Brand	model	chassis
PHILIPS	42PF9641D/79	BJ3.0E LA
PHILIPS	42PF9730A/37	BL2.2U AA
PHILIPS	42PF9730A/96	BL2.2U AA
PHILIPS	42PF9731D/10	FJ3.0E LA
PHILIPS	42PF9731D/37	BJ2.4U LA
PHILIPS	42PF9830/69	JL2.1A AA
PHILIPS	42PF9830/93	JL2.1A AA
PHILIPS	42PF9830A	BL2.1U AA ?
PHILIPS	42PF9830A	JL2.1E AA
PHILIPS	42PF9830A/37	BL2.1U AA
PHILIPS	42PF9831/69	FJ3.0E LA
PHILIPS	42PF9831D/10	FJ3.0E LA
PHILIPS	42PF9831D/37	BJ2.4U LA
PHILIPS	42PF9831D/78	BJ3.0L LA
PHILIPS	42PF9936D/37	LC4.7U AA
PHILIPS	42PF9936D/78	LC4.7L AA
PHILIPS	42PF9936D/78M	LC4.7L AA
PHILIPS	42PF9945/12	FTP1.1E AA
PHILIPS	42PF9946	LC4.7E AA
PHILIPS	42PF9946/79	LC4.7A AA
PHILIPS	42PF9946/93	LC4.7A AA
PHILIPS	42PF9946/98	LC4.7A AA
PHILIPS	42PF9952	FTV1.9DE
PHILIPS	42PF9952/12M	F21RE AA;FM23 AA;FTV1.9EE AA
PHILIPS	42PF9952/12S	FTV1.9DE AA;FTV1.9EE AA
PHILIPS	42PF9952/19S	FTV1.9DE AA;FTV1.9EE AA
PHILIPS	42PF9955/12	F21RE AA;FM242 AA
PHILIPS	42PF9956/00	OLD
PHILIPS	42PF9956/12	FTP2.2E AA
PHILIPS	42PF9956/37	FTP2.2U AA
PHILIPS	42PF9956/93	FTP2.2A AA
PHILIPS	42PF9965/12S	F22RE AA;FM24 AA
PHILIPS	42PF9966	FTL2.2E
PHILIPS	42PF9966	FTP2.4E
PHILIPS	42PF9966/10	FTP2.4E AA

Brand	model	chassis
PHILIPS	42PF9966/12	FTP2.2E AA
PHILIPS	42PF9966/37	FTP2.2U AA
PHILIPS	42PF9966/79	FTP2.2A AA;FTP2.4A AA
PHILIPS	42PF9966/93	FTP2.2A AA;FTP2.4A AA
PHILIPS	42PF9966/98	FTP2.4A AA
PHILIPS	42PF9967D/10	FTP2.4E AB
PHILIPS	42PF9986/12	FTL2.1E AA
PHILIPS	42PF9986/69	FTL2.1A AA
PHILIPS	42PF9986/93	FTL2.1A AA
PHILIPS	42PF9996/37	FTL2.1U AA
PHILIPS	42PFL2302/62	UNKNOWN
PHILIPS	42PFL3312/10	LC7.1E LA
PHILIPS	42PFL3312S/60	LC7.1E LA
PHILIPS	42PFL3403/77	UNKNOWN
PHILIPS	42PFL3403/78	UNKNOWN
PHILIPS	42PFL3403/93	UNKNOWN
PHILIPS	42PFL3403/97	UNKNOWN
PHILIPS	42PFL3403S/60	UNKNOWN
PHILIPS	42PFL3512D/12	LC7.2E LA
PHILIPS	42PFL3522D/12	UNKNOWN
PHILIPS	42PFL5322/10	LC7.1E LA
PHILIPS	42PFL5322/12	LC7.1E LA
PHILIPS	42PFL5322S/60	LC7.1E LA
PHILIPS	42PFL5332/45	LC7.1L PA
PHILIPS	42PFL5332/77	LC7.1L LA
PHILIPS	42PFL5332/78	LC7.1L LA
PHILIPS	42PFL5332D/37	EJ3.0U LA
PHILIPS	42PFL5403/10	UNKNOWN
PHILIPS	42PFL5403/78	UNKNOWN
PHILIPS	42PFL5403/93	UNKNOWN
PHILIPS	42PFL5403/97	UNKNOWN
PHILIPS	42PFL5403D/05	UNKNOWN
PHILIPS	42PFL5403D/12	UNKNOWN
PHILIPS	42PFL5403D/27	UNKNOWN
PHILIPS	42PFL5403H/10	UNKNOWN

Brand	model	chassis
PHILIPS	42PFL5403M/08	UNKNOWN
PHILIPS	42PFL5403S/60	UNKNOWN
PHILIPS	42PFL5422/96	IMP1.0A LA
PHILIPS	42PFL5432/77	LC7.1L LA
PHILIPS	42PFL5432/78	LC7.1A LA
PHILIPS	42PFL5432D/37	EJ3.0U LA
PHILIPS	42PFL5522D/05	LC7.2E LA
PHILIPS	42PFL5522D/12	LC7.2E LA
PHILIPS	42PFL5603/77	UNKNOWN
PHILIPS	42PFL5603D/27	UNKNOWN
PHILIPS	42PFL7312/77	LC4.8L LA
PHILIPS	42PFL7312/78	LC4.8L LA
PHILIPS	42PFL7332/10	BJ3.1E LA
PHILIPS	42PFL7332D/37	EJ3.0U LA
PHILIPS	42PFL7342/77	LC7.1L LA
PHILIPS	42PFL7342/78	LC7.1L LA
PHILIPS	42PFL7403/77	UNKNOWN
PHILIPS	42PFL7403/78	UNKNOWN
PHILIPS	42PFL7403/93	UNKNOWN
PHILIPS	42PFL7403/97	UNKNOWN
PHILIPS	42PFL7403D/05	UNKNOWN
PHILIPS	42PFL7403D/12	UNKNOWN
PHILIPS	42PFL7403D/27	UNKNOWN
PHILIPS	42PFL7403H/10	UNKNOWN
PHILIPS	42PFL7422/79	TPT1.2A LA
PHILIPS	42PFL7422/93	TPT1.2A LA
PHILIPS	42PFL7422/98	TPT1.2A LA
PHILIPS	42PFL7422D/37	Q523.1U LA
PHILIPS	42PFL7432/93	LC7.1A LA
PHILIPS	42PFL7432/98	LC7.1A LA
PHILIPS	42PFL7432D/37	Q523.1U LA
PHILIPS	42PFL7532D/79	BJ3.1A LA
PHILIPS	42PFL7562D/10	BJ3.1E LA
PHILIPS	42PFL7572D/10	BJ3.1E LA
PHILIPS	42PFL7603/93	UNKNOWN

Brand	model	chassis
PHILIPS	42PFL7603D/05	UNKNOWN
PHILIPS	42PFL7603D/12	UNKNOWN
PHILIPS	42PFL7603D/27	UNKNOWN
PHILIPS	42PFL7603D/78	UNKNOWN
PHILIPS	42PFL7603H/10	UNKNOWN
PHILIPS	42PFL7603M/08	UNKNOWN
PHILIPS	42PFL7603S/60	UNKNOWN
PHILIPS	42PFL7662D/05	LC7.2E LA
PHILIPS	42PFL7662D/12	LC7.2E LA
PHILIPS	42PFL7682D/05	LC7.2E LA
PHILIPS	42PFL7682D/12	LC7.2E LA
PHILIPS	42PFL7762D/05	LC7.5E LA
PHILIPS	42PFL7762D/12	LC7.5E LA
PHILIPS	42PFL7772D/12	LC7.5E LA
PHILIPS	42PFL7782D/12	LC7.5E LA
PHILIPS	42PFL7803D/78	UNKNOWN
PHILIPS	42PFL7803D/93	UNKNOWN
PHILIPS	42PFL7862D/10	Q528.1E LA
PHILIPS	42PFL7932/78	UNKNOWN
PHILIPS	42PFL7932/93	LC7.1A LA
PHILIPS	42PFL7932D/78	UNKNOWN
PHILIPS	42PFL7962D/05	LC7.5E LA
PHILIPS	42PFL7962D/12	LC7.5E LA
PHILIPS	42PFL7982D/12	LC7.5E LA
PHILIPS	42PFL9403D/08	UNKNOWN
PHILIPS	42PFL9403D/10	UNKNOWN
PHILIPS	42PFL9403D/19	UNKNOWN
PHILIPS	42PFL9532/93	Q528.1A LA
PHILIPS	42PFL9532/98	Q528.1A LA
PHILIPS	42PFL9603D/08	UNKNOWN
PHILIPS	42PFL9603D/10	UNKNOWN
PHILIPS	42PFL9603D/19	UNKNOWN
PHILIPS	42PFL9632D/10	Q528.1E LA
PHILIPS	42PFL9632D/79	Q528.1E LA
PHILIPS	42PFL9732D/10	Q528.1E LA

Brand	model	chassis
PHILIPS	42PFL9742D/19	Q528.1E LB
PHILIPS	42PFL9803D/08	UNKNOWN
PHILIPS	42PFL9803D/10	UNKNOWN
PHILIPS	42PFL9803D/19	UNKNOWN
PHILIPS	42PFL9900/98	UNKNOWN
PHILIPS	42PFL9900D/10	Q528.1E LA
PHILIPS	42PFL9900D/79	UNKNOWN
PHILIPS	42PFP5332/10	LC7.1E PA
PHILIPS	42PFP5332/12	LC7.1E PA
PHILIPS	42PFP5332D/37	EJ3.0U PA
PHILIPS	42PFP5532D/05	LC7.2E PA
PHILIPS	42PFP5532D/12	LC7.2E PA
PHILIPS	42PH9954/35R	OLD
PHILIPS	42PM8822/10	FL1;ML1.2E AA
PHILIPS	42PW9962/17	FTV1.5E AA
PHILIPS	42PW9982	FTV1.5E
PHILIPS	42PW9982/12	FTV1.5E AA
PHILIPS	42PW9982/12	FTV1.5U
PHILIPS	42PW9982/19	FTV1.5E AA
PHILIPS	42PW9982/69	FTV1.5E AA
PHILIPS	42TA1800/93	TPT1.0A LA
PHILIPS	42TA2000/93	TPT1.0A LA
PHILIPS	42TA2800/79	TPT1.1A LA
PHILIPS	42TA2800/93	TPT1.1A LA
PHILIPS	42TA2800/98	TPT1.1A LA
PHILIPS	42TA2800S/93	TPT1.1A LA
PHILIPS	42TA3000/93	TPT1.1A LA
PHILIPS	431932TK	2A
PHILIPS	43KE1310	CP90
PHILIPS	43KE1312	CP90
PHILIPS	43KE1315	CP90
PHILIPS	43KE1385	CP90
PHILIPS	43KT2193	2A
PHILIPS	43KV2421	G90
PHILIPS	43KV2423	G90

Brand	model	chassis
PHILIPS	43KV2425	G90
PHILIPS	43KV2427	G90B
PHILIPS	43KV2447	G90B
PHILIPS	43KV2483	G90B
PHILIPS	43KV2485	G90B
PHILIPS	43KV2486	G90B
PHILIPS	43KV2493	G90B
PHILIPS	43P8341	PTV910 (lub PTV914)
PHILIPS	43P8341/37	OLD
PHILIPS	43PP6360/57	A10PTV2.0 PAL AA
PHILIPS	43PP6360/61	A10PTV2.0 NTSC AA
PHILIPS	43PP6360/69	A10PTV2.0 PAL AA
PHILIPS	43PP6360/79	A10PTV2.0 PAL AA
PHILIPS	43PP6360/97	A10PTV2.0 NTSC AA
PHILIPS	43PP7445/69	DPTV565 AA
PHILIPS	43PP7445/93	DPTV565 AA
PHILIPS	43PP8320/93S	DPTV320 AA
PHILIPS	43PP8420	DPTV325
PHILIPS	43PP8421	DPTV325
PHILIPS	43PP8441/93	DPTV355 AA
PHILIPS	43PP8442/93	DPTV355 AA
PHILIPS	43PP8443/93	DPTV355 AA
PHILIPS	43PP8445/93	DPTV465 AA
PHILIPS	43PP8446/93	DPTV465 AA
PHILIPS	43PP8447/93	DPTV465 AA
PHILIPS	43PP8541/93	DPTV355 AA
PHILIPS	43PP8545/69	DPTV465 AA
PHILIPS	43PP9202/17	DPTV305
PHILIPS	43PP925	A10PTV
PHILIPS	43PP925/57	A10PTV2.0 PAL AA
PHILIPS	43PP925/61	A10PTV2.0 NTSC AA
PHILIPS	43PP925/69	A10PTV2.0 PAL AA
PHILIPS	43PP925/79	A10PTV2.0 PAL AA
PHILIPS	43PP925/93	A10PTV2.0 PAL AA
PHILIPS	43PP925/93E	A10PTV2.0 PAL AA

Brand	model	chassis
PHILIPS	43PP925/97	A10PTV2.0 NTSC AA
PHILIPS	43PP935/93	A10PTV2.0 PAL AA
PHILIPS	43PP935/93S	OLD
PHILIPS	43PP9402/17	OLD
PHILIPS	43TA1271	AA5 AA
PHILIPS	43TB1191	AA5 AA
PHILIPS	43ZY3425	ANUBIS B
PHILIPS	43ZZ3453	ANUBIS A
PHILIPS	43ZZ3473	ANUBIS A
PHILIPS	43ZZ3483	ANUBIS A
PHILIPS	43ZZ3485	ANUBIS A
PHILIPS	44PL9522F/17	OLD
PHILIPS	46CE8760	3A-PTV
PHILIPS	46CE8761	3A
PHILIPS	46CE8763	3A-PTV
PHILIPS	46CE8765	3A
PHILIPS	46CE8766	3A
PHILIPS	46CE8768	3A-PTV
PHILIPS	46CE8769	3A-PTV
PHILIPS	46GR8850	G110
PHILIPS	46GR8850/02B	G110PTV (GB)
PHILIPS	46GR8851	G110
PHILIPS	46KE8637	3A
PHILIPS	46KE8657	3A
PHILIPS	46KE8687	3A
PHILIPS	46KV8508	G110
PHILIPS	46KV8528	G110
PHILIPS	46KV8538	G110
PHILIPS	46ML0985	FL1
PHILIPS	46PA9030	PTV-FL1 (100Hz)
PHILIPS	46PP7745/93	DPTV565 AA
PHILIPS	46PP8741/93	DPTV355 AA
PHILIPS	46PP8745/93	DPTV465 AA
PHILIPS	46PP910A	PTV-FL1 (100Hz)
PHILIPS	46PP910A	PTV-FL1 (100Hz)

Brand	model	chassis
PHILIPS	46PP912A	PTV-FL1 (100Hz)
PHILIPS	46PP912A/07	FL1-PTV (100Hz)
PHILIPS	46PP9302	EM8U AA
PHILIPS	46PP9302/17	DPTV330
PHILIPS	46PP9302/17F	DPTV330
PHILIPS	46PP9302/84	DPTV330
PHILIPS	46PP9302H/17	DPTV330
PHILIPS	46PP9501	MG5.1E
PHILIPS	46PP9527/57	DPTV355 AA
PHILIPS	46PP9527/61	DPTV355 AA
PHILIPS	46PP9527/69	DPTV355 AA
PHILIPS	46PP9527/79	DPTV355 AA
PHILIPS	46PP9527/93	DPTV355 AA
PHILIPS	46PP9545/69	DPTV475 AA
PHILIPS	46PP9545/93	DPTV475 AA
PHILIPS	46PP960A	FL1-PTV (100Hz)
PHILIPS	46PP962A	FL1
PHILIPS	46PP96XA	FL1-PTV (100Hz)
PHILIPS	47MF437B/37	TPM2.0U LA
PHILIPS	47MF438/27	UNKNOWN
PHILIPS	47MF438B/27	UNKNOWN
PHILIPS	47PF9441D/37	BJ3.0U LA
PHILIPS	47PF9541/93	BJ3.0A LA
PHILIPS	47PF9541/98	BJ3.0A LA
PHILIPS	47PFL3403/93	UNKNOWN
PHILIPS	47PFL3403/97	UNKNOWN
PHILIPS	47PFL3403D/45	UNKNOWN
PHILIPS	47PFL3403S/60	UNKNOWN
PHILIPS	47PFL5403/10	UNKNOWN
PHILIPS	47PFL5403/93	UNKNOWN
PHILIPS	47PFL5403/97	UNKNOWN
PHILIPS	47PFL5403D/05	UNKNOWN
PHILIPS	47PFL5403D/12	UNKNOWN
PHILIPS	47PFL5403H/10	UNKNOWN
PHILIPS	47PFL5432D/37	Q523.1U LA

Brand	model	chassis
PHILIPS	47PFL5522D/05	LC7.2E LA
PHILIPS	47PFL5522D/12	LC7.2E LA
PHILIPS	47PFL5603D/27	UNKNOWN
PHILIPS	47PFL7403/77	UNKNOWN
PHILIPS	47PFL7403/78	UNKNOWN
PHILIPS	47PFL7403D/12	UNKNOWN
PHILIPS	47PFL7403D/27	UNKNOWN
PHILIPS	47PFL7403H/10	UNKNOWN
PHILIPS	47PFL7422/79	TPT1.2A LA
PHILIPS	47PFL7422/93	TPT1.2A LA
PHILIPS	47PFL7422/98	TPT1.2A LA
PHILIPS	47PFL7422D/37	Q523.1U LA
PHILIPS	47PFL7432D/37	Q523.1U LA
PHILIPS	47PFL7603D/05	UNKNOWN
PHILIPS	47PFL7603D/12	UNKNOWN
PHILIPS	47PFL7603D/27	UNKNOWN
PHILIPS	47PFL7603H/10	UNKNOWN
PHILIPS	47PFL7642D/05	LC7.2E LA
PHILIPS	47PFL7642D/12	LC7.2E LA
PHILIPS	47PFL9403D/08	UNKNOWN
PHILIPS	47PFL9403D/10	UNKNOWN
PHILIPS	47PFL9403D/19	UNKNOWN
PHILIPS	47PFL9532/93	Q528.1A LA
PHILIPS	47PFL9532/98	Q528.1A LA
PHILIPS	47PFL9532D/10	Q528.1E LA
PHILIPS	47PFL9603D/08	UNKNOWN
PHILIPS	47PFL9603D/10	UNKNOWN
PHILIPS	47PFL9603D/19	UNKNOWN
PHILIPS	47PFL9632D/10	Q528.1E LA
PHILIPS	47PFL9632D/79	Q528.1E LA
PHILIPS	47PFL9732D/10	Q528.1E LA
PHILIPS	47PFL9732D/37	Q523.1U LA
PHILIPS	47PFL9803D/08	UNKNOWN
PHILIPS	47PFL9803D/10	UNKNOWN
PHILIPS	47PFL9803D/19	UNKNOWN

Brand	model	chassis
PHILIPS	48P915/57	OLD
PHILIPS	48P915/69	OLD
PHILIPS	48P915/75	OLD
PHILIPS	48P915/79	OLD
PHILIPS	48P915/93	OLD
PHILIPS	48P977	GFL6D
PHILIPS	48P977/69	OLD
PHILIPS	48P977/79	OLD
PHILIPS	48PP72A/17	OLD
PHILIPS	48PP9103/05	OLD
PHILIPS	48PP9103/12	OLD
PHILIPS	48PP9103/58	UNKNOWN
PHILIPS	48WP44C/37R	OLD
PHILIPS	48WP91	GFL7D AA ?
PHILIPS	48XP43C/17	OLD
PHILIPS	48XP43C/37	OLD
PHILIPS	48XP44C/17	OLD
PHILIPS	49KV1257	GR1AX
PHILIPS	500P30/00	OLD
PHILIPS	50FD9934	FM25AA
PHILIPS	50FD9934/01S	FM25AA
PHILIPS	50FD9955	EM8U AA
PHILIPS	50FW9220/37	UNKNOWN
PHILIPS	50FW9975/35	OLD
PHILIPS	50MF231D/37	EP1.1U AA
PHILIPS	50ML6200D/37	CT2.0U RA
PHILIPS	50ML8105D/17	50ML8105D
PHILIPS	50ML8205D/17	50ML8105D
PHILIPS	50ML8305D/17	50ML8105D
PHILIPS	50P8341/37	OLD
PHILIPS	50P8342/37	OLD
PHILIPS	50PF7220A/37	BP2.3U AA
PHILIPS	50PF7320/79	LC4.9A AA
PHILIPS	50PF7320/93	LC4.9A AA
PHILIPS	50PF7320/98	LC4.9A AA

Brand	model	chassis
PHILIPS	50PF7320A/37	BP2.3U AA
PHILIPS	50PF7320G/93	LC4.41A AA
PHILIPS	50PF7320G/98	LC4.41A AA
PHILIPS	50PF7321D/37	EP1.1U AA
PHILIPS	50PF7521D/10	LC4.41E AB
PHILIPS	50PF7521D/12	LC4.41E AB
PHILIPS	50PF9431D/37	BJ2.5U PA
PHILIPS	50PF9531/69	BJ3.0A PA
PHILIPS	50PF9630/78	FTP2.4L AA
PHILIPS	50PF9630A/37	BP2.2U AA
PHILIPS	50PF9630A/96	BP2.2U AA
PHILIPS	50PF9631D/10	BJ3.0E PA
PHILIPS	50PF9631D/37	BJ2.4U PA
PHILIPS	50PF9631D/79	BJ3.0E PA
PHILIPS	50PF9731D/37	BJ2.4U PA
PHILIPS	50PF9830A/37	BP2.1U AA
PHILIPS	50PF9956/37	FTP2.2U AA
PHILIPS	50PF9964/12S	F21RE AA;F21RE AB
PHILIPS	50PF9965/12N	F22RE AA;FM25 AA
PHILIPS	50PF9965/12S	F22RE AA;FM25 AA
PHILIPS	50PF9966/10	FTP2.4E AA
PHILIPS	50PF9966/12	FTP2.2E AA
PHILIPS	50PF9966/37	FTP2.2U AA
PHILIPS	50PF9966/69	FTP2.2A AA
PHILIPS	50PF9966/78	FTP2.2L AA
PHILIPS	50PF9966/79	FTP2.4A AA
PHILIPS	50PF9966/93	FTP2.4A AA
PHILIPS	50PF9966/98	FTP2.4A AA
PHILIPS	50PF9967D/10	FTP2.4E AB
PHILIPS	50PFP5332D/37	EJ3.0U PA
PHILIPS	50PFP5532D/05	LC7.2E PA
PHILIPS	50PFP5532D/12	LC7.2E PA
PHILIPS	50PL9126D/37	CT2.0U RA
PHILIPS	50PL9200D/37	CT2.0U RA
PHILIPS	50PL9220D/37	CT2.0U RA

Brand	model	chassis
PHILIPS	50PP241/761	PTV918
PHILIPS	50PP73A/78	OLD
PHILIPS	50PP7445/69	DPTV565 AA
PHILIPS	50PP7445/93	DPTV565 AA
PHILIPS	50PP8541/93	DPTV355 AA
PHILIPS	50PP8545/69	DPTV465 AA
PHILIPS	50PP8545/93	DPTV465 AA
PHILIPS	50PP9202/17	DPTV305
PHILIPS	50PP9202/17F	DPTV305
PHILIPS	50PP9202/84	DPTV305
PHILIPS	50PP925/57	A10PTV2.0 PAL AA
PHILIPS	50PP925/69	A10PTV2.0 PAL AA
PHILIPS	50PP925/79	A10PTV2.0 PAL AA
PHILIPS	50PP925/93	A10PTV2.0 PAL AA
PHILIPS	50YP43C/85	OLD
PHILIPS	50YP44C/61	OLD
PHILIPS	50YP45C/36	OLD
PHILIPS	50YP45C/87	OLD
PHILIPS	51 TR225	TVCR D (TVCR Delta99)
PHILIPS	51 TR225	TVCR DELTA99 AA
PHILIPS	51 TR226	2A
PHILIPS	51 TR226	TVCR D (TVCR Delta2000)
PHILIPS	51 TR300	TVCR E (TVCR Epsilon 2001)
PHILIPS	51 TR426	TVCR B
PHILIPS	51 TR427	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	51IF5123	GR1AX
PHILIPS	51KE2402	2A
PHILIPS	51KT4264	KT4
PHILIPS	51KT4266	KT4
PHILIPS	51KT4284	KT4
PHILIPS	51KT4287	KT4
PHILIPS	51KT4309	KT4-SYS.T
PHILIPS	51KT4366	KT4
PHILIPS	51KT4369	KT4-FS/S (System4)
PHILIPS	51KT5262	KT4M

Brand	model	chassis
PHILIPS	51KT5264	KT4M
PHILIPS	51KT5362	KT4M
PHILIPS	51KT6500	CTO-S
PHILIPS	51KT6502	CTO-S
PHILIPS	51KV1056	GR1AX
PHILIPS	51KV1256	G90
PHILIPS	51MP392H/17	MAG01
PHILIPS	51MP3964H/17	MAG01
PHILIPS	51MP6100D/37	DPTV585 AA
PHILIPS	51MP6200D/37	EBJ1.0U RA
PHILIPS	51PP9100D/37	DPTV585 AA
PHILIPS	51PP9200D/37	EBJ1.0U RA
PHILIPS	51PP9303/17	OLD
PHILIPS	51PP9303H/17	DPTV345
PHILIPS	51PP9363/17	DPTV335
PHILIPS	51PP9363H/17	DPTV335
PHILIPS	51PP9910/17	DPTV410
PHILIPS	51PP9920/17	DPTV415
PHILIPS	51PW9303	DPTV415
PHILIPS	51PW9303/17F	DPTV340
PHILIPS	51PW9363	DPTV415
PHILIPS	51PW9363/17F	DPTV335
PHILIPS	51TA1171	AA5 AA
PHILIPS	51TA1260	ANUBIS A
PHILIPS	51TA1262	L6.1
PHILIPS	51TA1410	ANUBIS A
PHILIPS	51TA1411	ANUBIS A
PHILIPS	51TA1460	ANUBIS A
PHILIPS	51TA1471	AA5 AB
PHILIPS	51TA1472	L6.1
PHILIPS	51TA1473/03	L6.2 AA
PHILIPS	51TA1473/11	L6.2 AA
PHILIPS	51TA1473/16	L6.2 AA
PHILIPS	51TA1473/18	L6.2 AA
PHILIPS	51TA1476/03	L01.2E AA;L01.2E AB

Brand	model	chassis
PHILIPS	51TA1476/11	L01.2E AA;L01.2E AB
PHILIPS	51TB1151	AA5 AB
PHILIPS	51TB1252	L6.1
PHILIPS	51TVB20	TVCR B
PHILIPS	51TVB30	TVCR MONO98 (TVCR Delta98 ?)
PHILIPS	51TVB60	TVCR DELTA99 AA
PHILIPS	51TVB61	TVCR D (TVCR Delta2000)
PHILIPS	51TVB70	TVCR D (TVCR Delta2000)
PHILIPS	51TVB70	TVCR E (TVCR Epsilon 2001)
PHILIPS	52 NA1307	GR2.1
PHILIPS	52 NA1364	GR2.1
PHILIPS	52 NA2304	GR2.2
PHILIPS	52 NA2307	GR2.2
PHILIPS	52 NA2317	GR2.2
PHILIPS	52 NA2364	GR2.2
PHILIPS	52 NA2366	GR2.2
PHILIPS	52 NA2376	GR2.2
PHILIPS	52 NA2377	GR2.2
PHILIPS	524032EK	2A
PHILIPS	525024EK	2B
PHILIPS	52IU4482	2B
PHILIPS	52IU4492	2B
PHILIPS	52KE1505	CP90
PHILIPS	52KE1510	CP90
PHILIPS	52KE1512	CP90
PHILIPS	52KE1515	CP90
PHILIPS	52KE1585	CP90
PHILIPS	52KE2403	2A
PHILIPS	52KE2406	2A
PHILIPS	52KE4462	2B
PHILIPS	52KE4472	2B
PHILIPS	52KE4502	2B
PHILIPS	52KE4505	2B
PHILIPS	52KE4535	2B
PHILIPS	52KE4562	2B

Brand	model	chassis
PHILIPS	52KE4565	2B
PHILIPS	52KE4592	2B
PHILIPS	52KE4595	2B
PHILIPS	52KF5572	2A
PHILIPS	52KT4295	KT4-FS
PHILIPS	52KT4298	KT4-FS
PHILIPS	52KT4409	KT4-FS/S.
PHILIPS	52KT4459	KT4-FS/S.
PHILIPS	52KT4469	KT4-FS/S (System4)
PHILIPS	52KT5295	KT4M-FS
PHILIPS	52KT5298	KT4M-FS
PHILIPS	52KV1508	GR1AX
PHILIPS	52KV1528	GR1AX
PHILIPS	52KV1592	GR1AX
PHILIPS	52KV2521	G90
PHILIPS	52KV2523	G90AE
PHILIPS	52KV2525	G90AE
PHILIPS	52KV2526	G90B
PHILIPS	52KV2527	G90B
PHILIPS	52KV2529	G90
PHILIPS	52KV2537	G90B
PHILIPS	52KV2547	G90B
PHILIPS	52KV2553	G90B
PHILIPS	52KV2565	G90
PHILIPS	52KV2583	G90B
PHILIPS	52KV2585	G90B
PHILIPS	52KV2586	G90B
PHILIPS	52KV2587	G90B
PHILIPS	52KV2593	G90B
PHILIPS	52KV2596	G90B
PHILIPS	52KV2597	G90B
PHILIPS	52KV5717	G110
PHILIPS	52KV9526	G90B
PHILIPS	52KV9527	G90B
PHILIPS	52KV9537	G90B

Brand	model	chassis
PHILIPS	52KV9547	G90B
PHILIPS	52KV9566	G90B
PHILIPS	52KV9597	G90B
PHILIPS	52KV9696	G90B
PHILIPS	52MF437B/37	Q523.1U LA
PHILIPS	52MF437S/37	Q523.1U LA
PHILIPS	52MF438/27	UNKNOWN
PHILIPS	52MF438B/27	UNKNOWN
PHILIPS	52PFL3403D/45	UNKNOWN
PHILIPS	52PFL5403/93	UNKNOWN
PHILIPS	52PFL5403/97	UNKNOWN
PHILIPS	52PFL5432/77	LC7.1L LA
PHILIPS	52PFL5432/78	LC7.1L LA
PHILIPS	52PFL5603D/27	UNKNOWN
PHILIPS	52PFL7403/77	UNKNOWN
PHILIPS	52PFL7403/93	UNKNOWN
PHILIPS	52PFL7403/97	UNKNOWN
PHILIPS	52PFL7403D/10	UNKNOWN
PHILIPS	52PFL7403D/27	UNKNOWN
PHILIPS	52PFL7403H/10	UNKNOWN
PHILIPS	52PFL7422D/37	Q523.1U LA
PHILIPS	52PFL7432/98	Q528.1E LA
PHILIPS	52PFL7603D/27	UNKNOWN
PHILIPS	52PFL7762D/05	LC7.5E LA
PHILIPS	52PFL7762D/12	LC7.5E LA
PHILIPS	52PFL7803/78	UNKNOWN
PHILIPS	52PFL7803D/05	UNKNOWN
PHILIPS	52PFL7803D/12	UNKNOWN
PHILIPS	52PFL7803D/93	UNKNOWN
PHILIPS	52PFL7932/78	UNKNOWN
PHILIPS	52PFL9432D/79	Q528.1E LA
PHILIPS	52PFL9603D/08	UNKNOWN
PHILIPS	52PFL9603D/10	UNKNOWN
PHILIPS	52PFL9603D/19	UNKNOWN
PHILIPS	52PFL9632D/10	Q528.1E LA

Brand	model	chassis
PHILIPS	52PFL9803D/08	UNKNOWN
PHILIPS	52PFL9803D/10	UNKNOWN
PHILIPS	52PFL9803D/19	UNKNOWN
PHILIPS	52TA1071	AA5 AA
PHILIPS	52TA1161	ANUBIS
PHILIPS	52TA1171	AA5 AA
PHILIPS	52TA1262	L6.1
PHILIPS	52TA1271	AA5 AA
PHILIPS	52TA1471	AA5 AA
PHILIPS	52TA1472	L6.1
PHILIPS	52TA1476/03	L01.2E AA;L01.2E AB
PHILIPS	52TA1476/11	L01.2E AA;L01.2E AB
PHILIPS	52TA4310	GR2.2
PHILIPS	52TA4311	MD1.1
PHILIPS	52TA4311/03B	OLD
PHILIPS	52TA4314/03	L6.2 AA
PHILIPS	52TA4314/11	L6.2 AA
PHILIPS	52TA4315	L7.2E
PHILIPS	52TA5210	GR2.2
PHILIPS	52TA5211	GR2.2
PHILIPS	52TA5212	GR2.2
PHILIPS	52TA5213	GR2.4
PHILIPS	52TA5214/03	OLD
PHILIPS	52TB1051	AA5 AA
PHILIPS	52TB1141	ANUBIS A
PHILIPS	52TB1252	L6.1
PHILIPS	52TB1452	L6.1 AA
PHILIPS	52TB4290	GR2.2
PHILIPS	52TB4291	MD1.1
PHILIPS	52TB5190	GR2.2
PHILIPS	52TB5191	GR2.2
PHILIPS	52TB5192	GR2.2
PHILIPS	52TB5193	GR2.4
PHILIPS	52ZY3523	ANUBIS B
PHILIPS	52ZY3535	ANUBIS B

Brand	model	chassis
PHILIPS	52ZZ3523	ANUBIS A
PHILIPS	52ZZ3533	ANUBIS A
PHILIPS	52ZZ3583	ANUBIS A
PHILIPS	52ZZ3585	ANUBIS A
PHILIPS	53TA4315	L7.2E
PHILIPS	54P915	GFL7D
PHILIPS	54P915/57	OLD
PHILIPS	54P915/69	OLD
PHILIPS	54P915/75	OLD
PHILIPS	54P915/77	OLD
PHILIPS	54P915/79	OLD
PHILIPS	54P915/93	OLD
PHILIPS	54PP700A	PTV781
PHILIPS	54PP72A/17	OLD
PHILIPS	54WP43C/36	OLD
PHILIPS	54WP44C/36	OLD
PHILIPS	54XP43C/17	OLD
PHILIPS	54XP43C/37	OLD
PHILIPS	54XP44C/17	OLD
PHILIPS	554538/17	OLD
PHILIPS	554538/37	OLD
PHILIPS	55P8241/37	OLD
PHILIPS	55P8288/37	OLD
PHILIPS	55P8341/35R	OLD
PHILIPS	55P8341/37	OLD
PHILIPS	55P8342/37	OLD
PHILIPS	55P9161	DPTV415
PHILIPS	55P9161/17	DPTV415
PHILIPS	55P9271/17	OLD
PHILIPS	55PA944/17	OLD
PHILIPS	55PP73A/78	OLD
PHILIPS	55PP8620	DPTV325 AA
PHILIPS	55PP8741/93	DPTV355 AA
PHILIPS	55PP925/61	A10PTV2.0 NTSC AA
PHILIPS	55PP925/69	A10PTV2.0 PAL AA

Brand	model	chassis
PHILIPS	55PP925/79	A10PTV2.0 PAL AA
PHILIPS	55PP925/93	A10PTV2.0 PAL AA
PHILIPS	55PP925/97	A10PTV2.0 NTSC AA
PHILIPS	55PP9352/17	DPTV310
PHILIPS	55PP9363/17	DPTV335
PHILIPS	55PP9363H/17	DPTV335
PHILIPS	55PP9383/17	OLD
PHILIPS	55PP9383/84	OLD
PHILIPS	55PP9401	PP15
PHILIPS	55PP950/35R	OLD
PHILIPS	55PP9501	MG5.1E AA
PHILIPS	55PP9502	DPTV335
PHILIPS	55PP9502/17	DPTV315
PHILIPS	55PP9502/84	DTV315
PHILIPS	55PP9502/84	OLD
PHILIPS	55PP9527/61	DPTV355 AA
PHILIPS	55PP9527/69	DPTV355 AA
PHILIPS	55PP9527/79	DPTV355 AA
PHILIPS	55PP9527/93	DPTV355 AA
PHILIPS	55PP9545/69	DPTV475 AA
PHILIPS	55PP9545/93	DPTV475 AA
PHILIPS	55PP97	DPTV210
PHILIPS	55PP9701/17	OLD
PHILIPS	55PP9701/35R	OLD
PHILIPS	55PP9753/17	DPTV335
PHILIPS	55PP9753/84	DPTV335
PHILIPS	55PP9910/17	DPTV410
PHILIPS	55PP9920/17	DPTV415
PHILIPS	55PW9363	DPTV415
PHILIPS	55PW9383	DPTV340
PHILIPS	55RW9515/35	OLD
PHILIPS	55YP43C/85	OLD
PHILIPS	55YP44C/61	OLD
PHILIPS	55YP45C/36	OLD
PHILIPS	561050KS	K30

Brand	model	chassis
PHILIPS	566122EK	2A
PHILIPS	56KE2600	2A
PHILIPS	56KE2610	2A
PHILIPS	56KE2612	2A
PHILIPS	56KE2615	2A
PHILIPS	56KS1030	K30
PHILIPS	56KS1032	K30
PHILIPS	56KS1042	K30
PHILIPS	56KS1050	K30
PHILIPS	56KS1052	K30
PHILIPS	56KS1060	K30
PHILIPS	56KS1062	K30
PHILIPS	56KS1070	K30
PHILIPS	56KS1072	K30
PHILIPS	56KS1102	K30
PHILIPS	56KS1182	K30
PHILIPS	56KS1242	K30M
PHILIPS	56KS1262	K30
PHILIPS	56KS1332	K30
PHILIPS	56KS1402	K30M
PHILIPS	56KS1902	K30
PHILIPS	56KS3400	K35
PHILIPS	56KS3402	K35
PHILIPS	56KS3403	K35
PHILIPS	56KS3404	K35
PHILIPS	56KS3407	K35
PHILIPS	56KS3433	K35
PHILIPS	56KS3442	K35
PHILIPS	56KS3452	K35
PHILIPS	56KS3457	K35
PHILIPS	56KS3462	K35M
PHILIPS	56KS3464	K35
PHILIPS	56KS3477	K35
PHILIPS	56KS3482	K35
PHILIPS	56KS3492	K35

Brand	model	chassis
PHILIPS	56KS3500	K35
PHILIPS	56KS3508	K35
PHILIPS	56KS3603	K35
PHILIPS	56KS3604	K35
PHILIPS	56KS3606	K35
PHILIPS	56KS3623	K35
PHILIPS	56KS4508	K40
PHILIPS	56KS4509	K40-SYS.T
PHILIPS	56KS4568	K40M
PHILIPS	56KS4569	K40-SYS.T
PHILIPS	56KS4603	K40
PHILIPS	56KS4604	K40
PHILIPS	56KS4623	K40
PHILIPS	56KS4638	K40
PHILIPS	56KS5402	K40
PHILIPS	56KS5407	K40
PHILIPS	56KS5408	K40
PHILIPS	56KS5414	K40
PHILIPS	56KS5418	K40
PHILIPS	56KS5427	K40
PHILIPS	56KS5447	K40
PHILIPS	56KS5457	K40
PHILIPS	56KS5462	K40M
PHILIPS	56KS5477	K40
PHILIPS	56KS5487	K40
PHILIPS	56KS5497	K40
PHILIPS	56KS5502	K40
PHILIPS	56KS5503	K40
PHILIPS	56KS5513	K40
PHILIPS	56KS5517	K40
PHILIPS	56KS5553	K40
PHILIPS	56KS5557	K40
PHILIPS	56KS5567	K40M
PHILIPS	56KS5577	K40M
PHILIPS	56KS5587	K40

Brand	model	chassis
PHILIPS	56KS5707	K40
PHILIPS	56PP9960/17	DPTV420
PHILIPS	57PFL7603D/27	UNKNOWN
PHILIPS	597024EK	2B
PHILIPS	597032EK	2A
PHILIPS	597062EK	2A
PHILIPS	59IK1607	3D
PHILIPS	59IK1617	3D
PHILIPS	59IK1717	3D
PHILIPS	59IK1777	3D
PHILIPS	59IU3692	CP110
PHILIPS	59IU3698	CP110
PHILIPS	59IU3790	CP110
PHILIPS	59IU3792	CP110
PHILIPS	59IU4682	2B
PHILIPS	59IU4692	2B
PHILIPS	59IU7627	3A
PHILIPS	59KE2703	3A
PHILIPS	59KE2706	2A
PHILIPS	59KE3672	CP110
PHILIPS	59KE3675	CP110
PHILIPS	59KE3702	CP110
PHILIPS	59KE3705	CP110
PHILIPS	59KE3712	CP110
PHILIPS	59KE3715	CP110
PHILIPS	59KE3765	CP110
PHILIPS	59KE3770	CP110
PHILIPS	59KE3772	CP110
PHILIPS	59KE3775	CP110
PHILIPS	59KE3785	CP110
PHILIPS	59KE4662	2B
PHILIPS	59KE4672	2B
PHILIPS	59KE4702	2B
PHILIPS	59KE4705	2B
PHILIPS	59KE4722	2B

Brand	model	chassis
PHILIPS	59KE4725	2B
PHILIPS	59KE4732	2B
PHILIPS	59KE4765	2B
PHILIPS	59KE4775	2B
PHILIPS	59KE4792	2B
PHILIPS	59KE4795	2B
PHILIPS	59KE7607	3A
PHILIPS	59KE7617	3A
PHILIPS	59KE7627	3A
PHILIPS	59KE7717	3A
PHILIPS	59KS6418	K40-FS
PHILIPS	59KS6468	K40M-FS
PHILIPS	59KS6509	K40-FS/S.
PHILIPS	59KS6559	K40-FS/S.
PHILIPS	59KS6569	K40M-FS/S
PHILIPS	5FF2CMI/00	5FF2Q
PHILIPS	5FF2CMI/05	5FF2Q
PHILIPS	5FF2CMI/27	5FF2Q
PHILIPS	60P8241/37	OLD
PHILIPS	60P8288/37	OLD
PHILIPS	60P8341	PTV915
PHILIPS	60P8341/37	OLD
PHILIPS	60P8342/37	OLD
PHILIPS	60P8351	PTV915
PHILIPS	60P915/57	OLD
PHILIPS	60P915/69	OLD
PHILIPS	60P915/79	OLD
PHILIPS	60P915/93	OLD
PHILIPS	60P9161/17	OLD
PHILIPS	60P9271/17	OLD
PHILIPS	60PA40C/17	OLD
PHILIPS	60PA944/17	OLD
PHILIPS	60PL9200D/37	CT2.0U RA
PHILIPS	60PL9220D/37	CT2.0U RA
PHILIPS	60PP73A/78	OLD

Brand	model	chassis
PHILIPS	60PP9100D/37	DPTV585 AA
PHILIPS	60PP9200D/37	EBJ1.0U RA
PHILIPS	60PP9202	DPTV305
PHILIPS	60PP9202	DPTV305F
PHILIPS	60PP9202/17	DPTV305
PHILIPS	60PP9202/17F	DPTV305
PHILIPS	60PP9352/17	DPTV310
PHILIPS	60PP9363/17	DPTV335
PHILIPS	60PP9363H/17	DPTV335
PHILIPS	60PP9383/17	OLD
PHILIPS	60PP9502/17	DPTV315
PHILIPS	60PP9601/17	OLD
PHILIPS	60PP97	DPTV215 ?
PHILIPS	60PP9701/17	OLD
PHILIPS	60PP9753/17	DPTV335
PHILIPS	60PP9910/17	DPTV415
PHILIPS	60PP9920/17	DPTV415
PHILIPS	60PW9363	DPTV335
PHILIPS	60PW9383	DPTV340
PHILIPS	60XP43C/17	OLD
PHILIPS	60YP43C/85	OLD
PHILIPS	60YP44C/61	OLD
PHILIPS	61PP9960/17	DPTV420
PHILIPS	62CA1503	GR2.2
PHILIPS	62CA1563	GR2.2
PHILIPS	63CA1503	GR2.1
PHILIPS	63CA1503/>20	GR2.2
PHILIPS	63CA1505	GR2.1
PHILIPS	63CA1505/>20	GR2.2
PHILIPS	63CA1513	GR2.2
PHILIPS	63CA1513/>20	GR2.2
PHILIPS	63CA1515	GR2.2
PHILIPS	63CA1515/>20	GR2.2
PHILIPS	63CA1563	GR2.1
PHILIPS	63CA1563/>20	GR2.2

Brand	model	chassis
PHILIPS	63CA1573	GR2.2
PHILIPS	63CA1573/>20	GR2.2
PHILIPS	63CA1595	GR2.2
PHILIPS	63IU5782	2B
PHILIPS	63KB5626	G110
PHILIPS	63KD2620	D16
PHILIPS	63KD2623	D16
PHILIPS	63KD2626	D16
PHILIPS	63KE5722	2B
PHILIPS	63KE5725	2B
PHILIPS	63KE5735	2B
PHILIPS	63KE5755	2B
PHILIPS	63KE5765	2B
PHILIPS	63KE5775	2B
PHILIPS	63KE5782	2B
PHILIPS	63KE5792	2B
PHILIPS	63KE5795	2B
PHILIPS	63KE6672	CP110
PHILIPS	63KE6702	CP110
PHILIPS	63KE6705	CP110
PHILIPS	63KE6722	CP110
PHILIPS	63KE6725	CP110
PHILIPS	63KE6782	CP110
PHILIPS	63KE6795	CP110
PHILIPS	63KKE5722	2B
PHILIPS	63KV5176	G110
PHILIPS	63KV5616	G110
PHILIPS	63KV5617	G110
PHILIPS	63KV5626	G110
PHILIPS	63KV5637	G110
PHILIPS	63KV5686	G110
PHILIPS	63KV5687	G110
PHILIPS	63KV5687	G110
PHILIPS	63KV5697	G110
PHILIPS	63KV5897	G110

Brand	model	chassis
PHILIPS	63KV9616	G110
PHILIPS	63KV9617	G110
PHILIPS	63KV9636	G110
PHILIPS	63KV9637	G110
PHILIPS	63KV9647	G110
PHILIPS	63KV9656	G110
PHILIPS	63KV9686	G110
PHILIPS	63KV9687	G110
PHILIPS	63KV9817	G110
PHILIPS	63NA1047	GR2.1
PHILIPS	63NA1048	GR2.1
PHILIPS	63NA1076	GR2.1
PHILIPS	63NA1077	GR2.1
PHILIPS	63NA1276	GR2.1
PHILIPS	63NA1467	GR2.1
PHILIPS	63NA1607	GR2.1
PHILIPS	63NA1617	GR2.1
PHILIPS	63NA1618	GR2.1
PHILIPS	63NA1666	GR2.1
PHILIPS	63NA1676	GR2.1
PHILIPS	63NA1677	GR2.1
PHILIPS	63NA2514	GR2.2
PHILIPS	63NA2517	GR2.2
PHILIPS	63NA2574	GR2.2
PHILIPS	63NA2576	GR2.2
PHILIPS	63NA2607	GR2.2
PHILIPS	63NA2617	GR2.2
PHILIPS	63NA2618	GR2.2
PHILIPS	63NA2666	GR2.2
PHILIPS	63NA2676	GR2.2
PHILIPS	63NA2677	GR2.2
PHILIPS	63PF9631D/37	BJ3.0U PA
PHILIPS	63QW7619	FL1.0
PHILIPS	63QW7689	FL1.0
PHILIPS	63QW7699	FL1.0

Brand	model	chassis
PHILIPS	63RK5617	FL1.0
PHILIPS	63RK5647	FL1.0
PHILIPS	63RK5687	FL1.0
PHILIPS	63TA3910	GR2.2
PHILIPS	63TA3911	AA5 AB
PHILIPS	63TA3913/18	L6.2 AA
PHILIPS	63TA3960	GR2.2
PHILIPS	63TA3961	AA5 AB
PHILIPS	63TA4010	GR2.2
PHILIPS	63TA4011	AA5 AB
PHILIPS	63TA4013/07	L6.2 AA
PHILIPS	63TA4013/16	L6.2 AA
PHILIPS	63TA4110	GR2.2
PHILIPS	63TA4310	GR2.2
PHILIPS	63TA4311	MD1.1E
PHILIPS	63TA4410	GR2.2
PHILIPS	63TA4411	GR2.2
PHILIPS	63TA4412	GR2.2
PHILIPS	63TA4412	MD1.1
PHILIPS	63TA4412/08	OLD
PHILIPS	63TA4412/36	OLD
PHILIPS	63TA4413/08	L6.2 AA
PHILIPS	63TA4413/11	L6.2 AA
PHILIPS	63TA4413/18	L6.2 AA
PHILIPS	63TA4415	L9.1E
PHILIPS	63TA4415	L9.1E AA
PHILIPS	63TA4610	GR2.2
PHILIPS	63TA4611	GR2.2
PHILIPS	63TA4612	GR2.4
PHILIPS	63TA5210	GR2.2
PHILIPS	63TA5211	GR2.2
PHILIPS	63TA5211/08	GR2.2
PHILIPS	63TA5211/11	GR2.2
PHILIPS	63TA5211/16	GR2.2
PHILIPS	63TA5211/18	GR2.2

Brand	model	chassis
PHILIPS	63TA5212	GR2.4
PHILIPS	63TA5213	MD1.2E
PHILIPS	63TA5213/03	MD1.2E
PHILIPS	63TA5213/03	OLD
PHILIPS	63TA5213/11	MD1.2E
PHILIPS	63TA5213/11	OLD
PHILIPS	63TA5213/16	MD1.2E
PHILIPS	63TA5213/18	MD1.2E
PHILIPS	63TA5213/18	OLD
PHILIPS	63TA5215	L9.1E
PHILIPS	63TA5610	GR2.3
PHILIPS	63TA6911	GR2.4
PHILIPS	63TA6912	GR2.4
PHILIPS	63TA6931	GR2.4
PHILIPS	63TA7111	GR2.4
PHILIPS	63TA7910	FL1.17
PHILIPS	63TA7911	FL4.17
PHILIPS	63TA7912	FL4.16
PHILIPS	63TA7930	FL1.17
PHILIPS	63TA7931	FL4.17
PHILIPS	63TA7932	FL4.16
PHILIPS	63TB3890	GR2.2
PHILIPS	63TB3891	AA5 AB
PHILIPS	63TB3893/19	L6.2 AA
PHILIPS	63TB4390	GR2.2
PHILIPS	63TB4391	GR2.2
PHILIPS	63TB4392	MD1.1E
PHILIPS	63TB4392/39	OLD
PHILIPS	63TB4393	MD1.1E
PHILIPS	63TB4395	FL4.17
PHILIPS	63TB4395	L9.1E
PHILIPS	63TB4590	GR2.2
PHILIPS	63TB4591	GR2.2
PHILIPS	63TB4592	GR2.2
PHILIPS	63TB4599	GR2.2

Brand	model	chassis
PHILIPS	63TB5190	GR2.2
PHILIPS	63TB5191	GR2.2
PHILIPS	63TB5192	GR2.4
PHILIPS	63TB5193	MD1.2E
PHILIPS	64P8341/37	OLD
PHILIPS	64P8342/37	OLD
PHILIPS	64P9161/17	OLD
PHILIPS	64P9271/17	OLD
PHILIPS	64PP9751/17	OLD
PHILIPS	6671	K35
PHILIPS	6672	K35
PHILIPS	6673	K35
PHILIPS	668002EK	2A
PHILIPS	668102EK	2A
PHILIPS	668122EK	2A
PHILIPS	66KE2800	2A
PHILIPS	66KE2802	2A
PHILIPS	66KE2805	2A
PHILIPS	66KE2810	2A
PHILIPS	66KE2812	2A
PHILIPS	66KE2815	2A
PHILIPS	66KE2822	2A
PHILIPS	66KS1020	K30
PHILIPS	66KS1022	K30
PHILIPS	66KS1040	K30
PHILIPS	66KS1080	K30
PHILIPS	66KS1100	K30
PHILIPS	66KS1120	K30M
PHILIPS	66KS1122	K30
PHILIPS	66KS1129	K30
PHILIPS	66KS1132	K30
PHILIPS	66KS1142	K30
PHILIPS	66KS1152	K30
PHILIPS	66KS1162	K30
PHILIPS	66KS1252	K30M

Brand	model	chassis
PHILIPS	66KS1282	K30
PHILIPS	66KS1292	K30
PHILIPS	66KS1322	K30
PHILIPS	66KS3700	K35
PHILIPS	66KS3702	K35
PHILIPS	66KS3703	K35
PHILIPS	66KS3707	K35
PHILIPS	66KS3710	K35
PHILIPS	66KS3712	K35M
PHILIPS	66KS3713	K35M
PHILIPS	66KS3714	K35
PHILIPS	66KS3717	K35M
PHILIPS	66KS3735	K35
PHILIPS	66KS3752	K35
PHILIPS	66KS3753	K35
PHILIPS	66KS3757	K35
PHILIPS	66KS3761	K30/K35
PHILIPS	66KS3762	K35
PHILIPS	66KS3763	K35
PHILIPS	66KS3772	K35
PHILIPS	66KS3792	K35
PHILIPS	66KS3808	K35
PHILIPS	66KS3903	K35
PHILIPS	66KS3904	K35
PHILIPS	66KS3905	K35
PHILIPS	66KS3908	K35
PHILIPS	66KS3917	K35
PHILIPS	66KS3918	K35
PHILIPS	66KS3923	K35
PHILIPS	66KS3933	K35
PHILIPS	66KS3943	K35
PHILIPS	66KS3955	K35
PHILIPS	66KS3958	K35
PHILIPS	66KS4808	K40
PHILIPS	66KS4809	K40-SYS.T

Brand	model	chassis
PHILIPS	66KS4819	K40-SYS.T
PHILIPS	66KS4863	K40M
PHILIPS	66KS4869	K40-SYS.T
PHILIPS	66KS4904	K40
PHILIPS	66KS4933	K40
PHILIPS	66KS4938	K40
PHILIPS	66KS4943	K40
PHILIPS	66KS4958	K40
PHILIPS	66KS5507	K40
PHILIPS	66KS5702	K40
PHILIPS	66KS5704	K40
PHILIPS	66KS5705	K40
PHILIPS	66KS5708	K40
PHILIPS	66KS5714	K40
PHILIPS	66KS5735	K40
PHILIPS	66KS5738	K40
PHILIPS	66KS5747	K40
PHILIPS	66KS5757	K40
PHILIPS	66KS5762	K40M
PHILIPS	66KS5767	K40M
PHILIPS	66KS5768	K40M
PHILIPS	66KS5777	K40
PHILIPS	66KS5787	K40M
PHILIPS	66KS5802	K40
PHILIPS	66KS5803	K40
PHILIPS	66KS5807	K40
PHILIPS	66KS5813	K40
PHILIPS	66KS5817	K40
PHILIPS	66KS5853	K40
PHILIPS	66KS5857	K40
PHILIPS	66KS5863	K40M
PHILIPS	66KS5867	K40M
PHILIPS	66KS5917	K40
PHILIPS	66KS5937	K40
PHILIPS	66KS5947	K40

Brand	model	chassis
PHILIPS	66KS5957	K40
PHILIPS	66KS5967	K40
PHILIPS	689024EK	2B
PHILIPS	689032EK	2A
PHILIPS	689054EK	2B
PHILIPS	689062EK	2A
PHILIPS	689064EK	2B
PHILIPS	68IK1807	3D
PHILIPS	68IK1817	3D
PHILIPS	68IK1817 Aristona	3D
PHILIPS	68IK1917	3D
PHILIPS	68IK1977	3D
PHILIPS	68IU3892	CP110
PHILIPS	68IU3992	CP110
PHILIPS	68IU4882	2B-F
PHILIPS	68IU4892	2B
PHILIPS	68IU7827	3A
PHILIPS	68KE1817	CP90
PHILIPS	68KE2903	2A
PHILIPS	68KE2906	2A
PHILIPS	68KE3862	CP110
PHILIPS	68KE3872	CP110
PHILIPS	68KE3902	CP110
PHILIPS	68KE3905	CP110
PHILIPS	68KE3912	CP110
PHILIPS	68KE3915	CP110
PHILIPS	68KE3972	CP110
PHILIPS	68KE3985	CP110
PHILIPS	68KE4862	2B
PHILIPS	68KE4872	2B-F
PHILIPS	68KE4902	2B
PHILIPS	68KE4905	2B
PHILIPS	68KE4906	2B
PHILIPS	68KE4922	2B
PHILIPS	68KE4923	2B

Brand	model	chassis
PHILIPS	68KE4925	2B
PHILIPS	68KE4932	2B
PHILIPS	68KE4962	2B
PHILIPS	68KE4965	2B
PHILIPS	68KE4966	2B
PHILIPS	68KE4975	2B
PHILIPS	68KE4986	2B
PHILIPS	68KE4986	2B
PHILIPS	68KE4992	2B
PHILIPS	68KE4995	2B
PHILIPS	68KE4996	2B
PHILIPS	68KE7807	3A
PHILIPS	68KE7817	3A
PHILIPS	68KE7827	3A
PHILIPS	68KE7917	3A
PHILIPS	68KF9635	2A
PHILIPS	68KS6708	K40-FS
PHILIPS	68KS6735	K40-FS
PHILIPS	68KS6738	K40-FS
PHILIPS	68KS6768	K40M-FS
PHILIPS	68KS6809	K40-FS/S.
PHILIPS	68KS6859	K40-FS/S.
PHILIPS	68KS6869	K40M-FS/S
PHILIPS	68KS6958	K40-FS
PHILIPS	68KS6968	K40M-FS
PHILIPS	70CA1703	GR2.1
PHILIPS	70CA1703/>20	GR2.2
PHILIPS	70CA1705	GR2.2
PHILIPS	70CA1705/>20	GR2.2
PHILIPS	70CA1763	GR2.1
PHILIPS	70CA1763/>20	GR2.2
PHILIPS	70IU5982	2B-F
PHILIPS	70KD2720	D16
PHILIPS	70KD2723	D16
PHILIPS	70KD2726	D16

Brand	model	chassis
PHILIPS	70KE5922	2B
PHILIPS	70KE5925	2B
PHILIPS	70KE5928	2B
PHILIPS	70KE5935	2B
PHILIPS	70KE5975	2B
PHILIPS	70KE5982	2B-F
PHILIPS	70KE5992	2B
PHILIPS	70KE5995	2B
PHILIPS	70KE6862	CP110
PHILIPS	70KE6872	CP110
PHILIPS	70KE6902	CP110
PHILIPS	70KE6905	CP110
PHILIPS	70KE6922	CP110
PHILIPS	70KE6925	CP110
PHILIPS	70KE6982	CP110
PHILIPS	70KR5816	FL1.2
PHILIPS	70KV5027	G110
PHILIPS	70KV5076	G110
PHILIPS	70KV5317	G110
PHILIPS	70KV5687	G110
PHILIPS	70KV5716	G110
PHILIPS	70KV5717	G110
PHILIPS	70KV5726	G110
PHILIPS	70KV5737	G110
PHILIPS	70KV5787	G110
PHILIPS	70KV5987	G110
PHILIPS	70KV9656	G110
PHILIPS	70KV9716	G110
PHILIPS	70KV9717	G110
PHILIPS	70KV9736	G110
PHILIPS	70KV9737	G110
PHILIPS	70KV9747	G110
PHILIPS	70KV9787	G110
PHILIPS	70KV9917	G110
PHILIPS	70NA1147	GR2.1AA

Brand	model	chassis
PHILIPS	70NA1148	GR2.1
PHILIPS	70NA1167	GR2.1
PHILIPS	70NA1176	GR2.1
PHILIPS	70NA1177	GR2.1
PHILIPS	70NA1376	GR2.1
PHILIPS	70NA1807	GR2.1
PHILIPS	70NA1817	GR2.1
PHILIPS	70NA1818	GR2.1
PHILIPS	70NA1866	GR2.1
PHILIPS	70NA1876	GR2.1
PHILIPS	70NA1877	GR2.1
PHILIPS	70NA2714	GR2.2
PHILIPS	70NA2717	GR2.2
PHILIPS	70NA2774	GR2.2
PHILIPS	70NA2776	GR2.2
PHILIPS	70NA2807	GR2.2
PHILIPS	70NA2808	GR2.2
PHILIPS	70NA2817	GR2.2
PHILIPS	70NA2818	GR2.2
PHILIPS	70NA2819	GR2.2
PHILIPS	70NA2866	GR2.2
PHILIPS	70NA2876	GR2.2
PHILIPS	70NA2877	GR2.2
PHILIPS	70NA2879	GR2.2
PHILIPS	70QW7719	FL1.0
PHILIPS	70QW7789	FL1.0
PHILIPS	70QW7799	FL1.0
PHILIPS	70QW7916	FL1.2
PHILIPS	70RK5717	FL1.0
PHILIPS	70RK5787	FL1.0
PHILIPS	70RK5797	FL1.0
PHILIPS	70RK5816	FL1.2 AB
PHILIPS	70TA3910	GR2.2
PHILIPS	70TA3911	AA5 AB
PHILIPS	70TA3913/11	L6.2 AA

Brand	model	chassis
PHILIPS	70TA3913/18	L6.2 AA
PHILIPS	70TA3960	GR2.2
PHILIPS	70TA3961	AA5 AB
PHILIPS	70TA4010	GR2.2
PHILIPS	70TA4011	AA5 AB
PHILIPS	70TA4013/16	L6.2 AA
PHILIPS	70TA4310	GR2.2
PHILIPS	70TA4311	MD1.1E
PHILIPS	70TA4410	GR2.2
PHILIPS	70TA4411	GR2.2
PHILIPS	70TA4412	MD1.1
PHILIPS	70TA4413/08	L6.2 AA
PHILIPS	70TA4413/11	L6.2 AA
PHILIPS	70TA4413/18	L6.2 AA
PHILIPS	70TA4415	L9.1E
PHILIPS	70TA4417/03	TE2.1E AA
PHILIPS	70TA4417/16	TE2.1E AA
PHILIPS	70TA4418/03	OLD
PHILIPS	70TA4418/16	OLD
PHILIPS	70TA4610	GR2.2
PHILIPS	70TA4611	GR2.2
PHILIPS	70TA4612	GR2.4
PHILIPS	70TA5210	GR2.2
PHILIPS	70TA5211	GR2.2
PHILIPS	70TA5212	GR2.4
PHILIPS	70TA5610	GR2.3
PHILIPS	70TA7212	FL1.17
PHILIPS	70TA7212	MD2.12
PHILIPS	70TA7213/03	MD2.21E AA
PHILIPS	70TA7213/11	MD2.21E AA
PHILIPS	70TA7213/18	MD2.21E AA
PHILIPS	70TA7910	FL1.17
PHILIPS	70TA7930	FL1.17
PHILIPS	70TA8030	FL1.17
PHILIPS	70TA8310	FL1.17

Brand	model	chassis
PHILIPS	70TA8330	FL1.17
PHILIPS	70TA8331	FL1.16
PHILIPS	70TB3890	GR2.2
PHILIPS	70TB3891	AA5 AB
PHILIPS	70TB3893/19	L6.2 AA
PHILIPS	70TB4316/19	OLD
PHILIPS	70TB4390	GR2.2
PHILIPS	70TB4391	GR2.2
PHILIPS	70TB4392	MD1.1
PHILIPS	70TB4392/19	OLD
PHILIPS	70TB4393	MD1.1E
PHILIPS	70TB4394/19	L6.2 AA
PHILIPS	70TB4395	L9.1E
PHILIPS	70TB4417/19	TE1.1E AA;TE2.1E AA
PHILIPS	70TB4417/19	TE2.1E AA - ???
PHILIPS	70TB4590	GR2.2
PHILIPS	70TB4591	GR2.2
PHILIPS	70TB4592	GR2.4
PHILIPS	70TB5190	GR2.2
PHILIPS	70TB5191	GR2.2
PHILIPS	70TB7192	MD2.12E
PHILIPS	70TB7890	FL1.17
PHILIPS	70WA5211	GR2.4
PHILIPS	70WA6210	GR2.3
PHILIPS	70WA6211	GR2.4
PHILIPS	70WA6212	MD1.1E
PHILIPS	70WA6213/11	OLD
PHILIPS	70WA6213/18	OLD
PHILIPS	70WA6214	A8.0E
PHILIPS	70WA8416 Aristona	EM2E AA
PHILIPS	70WA9410	GFL2.20E
PHILIPS	70WA9412/03	MD2.22E AA
PHILIPS	70WA9412/11	MD2.22E AA
PHILIPS	70WA9412/18	MD2.22E AA
PHILIPS	70WA9430	GFL2.30E

Brand	model	chassis
PHILIPS	70WB5191	GR2.4
PHILIPS	70WB6190	GR2.3
PHILIPS	70WB6192	MD1.1E
PHILIPS	70WB6193/19	OLD
PHILIPS	70WB6195/19	OLD
PHILIPS	72TA5213	MD1.2E
PHILIPS	72TA5213/03	MD1.2E
PHILIPS	72TA5213/03	OLD
PHILIPS	72TA5213/11	MD1.2E
PHILIPS	72TA5213/11	OLD
PHILIPS	72TA5213/16	MD1.2E
PHILIPS	72TA5213/18	MD1.2E
PHILIPS	72TA5213/18	OLD
PHILIPS	72TA5215	L9.1E
PHILIPS	72TA5216/18	OLD
PHILIPS	72TA6211	GR2.4
PHILIPS	72TA6911	GR2.4
PHILIPS	72TA6931	GR2.4
PHILIPS	72TA7911	FL4.17
PHILIPS	72TA7912	FL4.16
PHILIPS	72TA7931	FL4.17
PHILIPS	72TA7932	FL4.16
PHILIPS	72TA8031	FL4.17
PHILIPS	72TA8032	FL4.26
PHILIPS	72TA9713	MD2.12E
PHILIPS	72TB7891	FL4.17
PHILIPS	72TB7911	FL4.17
PHILIPS	72TB7912	FL4.16
PHILIPS	76FA4/12	OLD
PHILIPS	76FB4/12	OLD
PHILIPS	76FP4/12	OLD
PHILIPS	7FF1AW/05	7FF1
PHILIPS	7FF1AW/10	7FF1
PHILIPS	7FF1AW/75	7FF1
PHILIPS	7FF1AW/93	7FF1

Brand	model	chassis
PHILIPS	7FF1CME/00	7FF1
PHILIPS	7FF1CME/05	7FF1
PHILIPS	7FF1CME/37	7FF1
PHILIPS	7FF1CME/75	7FF1
PHILIPS	7FF1CME/93	7FF1
PHILIPS	7FF1CMI/00	7FF1
PHILIPS	7FF1CMI/05	7FF1
PHILIPS	7FF1CMI/37	7FF1
PHILIPS	7FF1CMI/75	7FF1
PHILIPS	7FF1CMI/93	7FF1
PHILIPS	7FF1CWO/00	7FF1
PHILIPS	7FF1CWO/05	7FF1
PHILIPS	7FF1CWO/37	7FF1
PHILIPS	7FF1CWO/69	7FF1
PHILIPS	7FF1CWO/75	7FF1
PHILIPS	7FF1CWO/93	7FF1
PHILIPS	7FF1CWO/96	7FF1
PHILIPS	7FF1M4/00	7FF1
PHILIPS	7FF1M4/05	7FF1
PHILIPS	7FF1M4/11	7FF1
PHILIPS	7FF1M4/37	7FF1
PHILIPS	7FF1M4/75	7FF1
PHILIPS	7FF1M4/93	7FF1
PHILIPS	7FF1MS/00	7FF1
PHILIPS	7FF1MS/05	7FF1
PHILIPS	7FF1MS/37	7FF1
PHILIPS	7FF2CME/00	7FF2
PHILIPS	7FF2CME/05	7FF2
PHILIPS	7FF2CME/27	7FF2
PHILIPS	7FF2CMI/00	7FF2
PHILIPS	7FF2CMI/05	7FF2
PHILIPS	7FF2CMI/27	7FF2
PHILIPS	7FF2CWO/00	7FF2
PHILIPS	7FF2CWO/05	7FF2
PHILIPS	7FF2CWO/27	7FF2

Brand	model	chassis
PHILIPS	7FF2FPA/00	7FF2
PHILIPS	7FF2FPA/05	UNKNOWN
PHILIPS	7FF2FPA/27	7FF2
PHILIPS	7FF2FPA/75	7FF2
PHILIPS	7FF2FPA/93	7FF2
PHILIPS	7FF2M4/00	7FF2
PHILIPS	7FF2M4/05	7FF2
PHILIPS	7FF2M4/27	7FF2
PHILIPS	7FF2M4/75	7FF2
PHILIPS	7FF2M4/93	7FF2
PHILIPS	82WA6213/11	OLD
PHILIPS	82WA6213/18	OLD
PHILIPS	82WA9412/11	MD2.22E AA
PHILIPS	82WA9412/18	MD2.22E AA
PHILIPS	82WA9430	GFL2.20E
PHILIPS	82WB6195/19	OLD
PHILIPS	85A6930	FL1.1
PHILIPS	85DK2820	D16
PHILIPS	85DK2826	D16
PHILIPS	85KD2820	D16
PHILIPS	85KD2826	D16
PHILIPS	85KE7345	3A
PHILIPS	85KE7365	3A
PHILIPS	85KE7375	3A
PHILIPS	85KE7385	3A
PHILIPS	85QW7789	FL1.0
PHILIPS	85QW7989	FL1.0
PHILIPS	85RK5927	FL1.0
PHILIPS	85RK5985	FL1.0
PHILIPS	85RK5987	FL1.0
PHILIPS	85TA6910	FL1.10
PHILIPS	85TA6911	FL1.10
PHILIPS	85TA6912	FL1.20
PHILIPS	85TA6930	FL1.10
PHILIPS	85TA6931	FL1.10

Brand	model	chassis
PHILIPS	85TA6932	FL1.20
PHILIPS	85TA7010	FL1.10
PHILIPS	85TA7010	FL1.10
PHILIPS	85TA7030	FL1.10
PHILIPS	85TA7031	FL1.10
PHILIPS	85TA7032	FL1.20
PHILIPS	8P4831C/17	OLD
PHILIPS	8P4834C/17	OLD
PHILIPS	8P4841C/17	OLD
PHILIPS	8P4844C/17	OLD
PHILIPS	8P5431C/17	OLD
PHILIPS	8P5434C/17	OLD
PHILIPS	8P5441C/17	OLD
PHILIPS	8P5444C/17	OLD
PHILIPS	8P6031C/17	OLD
PHILIPS	8P6034C/17	OLD
PHILIPS	8P6041C/17	OLD
PHILIPS	8P6044C/17	OLD
PHILIPS	8P6051C/17	OLD
PHILIPS	94KS5006	K40-PROJ.
PHILIPS	9FF2CME/00	9FF2
PHILIPS	9FF2CME/05	9FF2
PHILIPS	9FF2CME/37	9FF2
PHILIPS	9FF2CME/75	9FF2
PHILIPS	9FF2CME/93	9FF2
PHILIPS	9FF2CMI/00	9FF2
PHILIPS	9FF2CMI/05	9FF2
PHILIPS	9FF2CMI/37	9FF2
PHILIPS	9FF2CMI/75	9FF2
PHILIPS	9FF2CMI/93	9FF2
PHILIPS	9FF2CWO/00	9FF2
PHILIPS	9FF2CWO/05	9FF2
PHILIPS	9FF2CWO/37	9FF2
PHILIPS	9FF2CWO/69	9FF2
PHILIPS	9FF2CWO/75	9FF2

Brand	model	chassis
PHILIPS	9FF2CWO/93	9FF2
PHILIPS	9FF2CWO/96	9FF2
PHILIPS	9FF2M4/00	9FF2
PHILIPS	9FF2M4/05	9FF2
PHILIPS	9FF2M4/37	9FF2
PHILIPS	9FF2M4/75	9FF2
PHILIPS	9FF2M4/93	9FF2
PHILIPS	9P5031C/17	OLD
PHILIPS	9P5034C/17	OLD
PHILIPS	9P5040C/17	OLD
PHILIPS	9P5044C/17	OLD
PHILIPS	9P5511C/17	OLD
PHILIPS	9P5514C/17	OLD
PHILIPS	9P5531C/17	OLD
PHILIPS	9P5534C/17	OLD
PHILIPS	9P5540C/17	OLD
PHILIPS	9P5544C/17	OLD
PHILIPS	9P6031C/17	OLD
PHILIPS	9P60349/17	OLD
PHILIPS	9P6034C/17	OLD
PHILIPS	9P6040C/17	OLD
PHILIPS	9P6044C/17	OLD
PHILIPS	9P6440C/17	OLD
PHILIPS	9P6444C/17	OLD
PHILIPS	ACEC2291	K40
PHILIPS	ACEC2609	K40
PHILIPS	ACEC2618	K40
PHILIPS	ACEC2628	K40
PHILIPS	ACEC2638	K40
PHILIPS	ACEC2657	K40
PHILIPS	ACEC26572	K40
PHILIPS	ACEC2667	K40
PHILIPS	ACEC26672	K40
PHILIPS	ACEC2677	K35
PHILIPS	ACEC2697	K40

Brand	model	chassis
PHILIPS	ACEC41031	K35
PHILIPS	ACEC41032	K35
PHILIPS	ACEC41035	K35
PHILIPS	ACEC41311	K35
PHILIPS	BDH4211/00	FM24 AB
PHILIPS	BDH4221/00	FM24 AB
PHILIPS	BDL3231C/00	TPT1.1S LA
PHILIPS	BDL4211V/00	MT2
PHILIPS	BDL4211V/27	MT2
PHILIPS	BDL4211VS/00	MT2
PHILIPS	BDL4231C/00	TPT1.1S LA
PHILIPS	BDS4211/00	FM24 AB
PHILIPS	BDS4241V	PDP42V7 (LG) - ?
PHILIPS	BM02511/00	UNKNOWN
PHILIPS	BM03221/00	UNKNOWN
PHILIPS	BM04321/00	UNKNOWN
PHILIPS	BP01010/00	UNKNOWN
PHILIPS	BS03210/00	UNKNOWN
PHILIPS	BS03313/00	UNKNOWN
PHILIPS	C1764AS	C1764
PHILIPS	C2064AS	C2X64
PHILIPS	C2064N	C2X64
PHILIPS	C2064N-LE	C2X64
PHILIPS	C2082-DAS	DAS
PHILIPS	C2164-AS	C2X64
PHILIPS	C2182-DAS	DAS
PHILIPS	C51GP2	G90AE
PHILIPS	C51GP4	G90AE
PHILIPS	CDU2082	DAS
PHILIPS	CHW027C1	OLD
PHILIPS	CT3245	11AK19-5
PHILIPS	CTV2830	10.3 (BEKO)
PHILIPS	CTV76	K30
PHILIPS	CTV77	K30
PHILIPS	CTV82-1692S	20.2 (100Hz) ! (7UZ.190-07)

Brand	model	chassis
PHILIPS	D14GP2	GR1AX
PHILIPS	D14GP3	GR1AX
PHILIPS	D14GP4	GR1AX
PHILIPS	D14GP5	GR1AX
PHILIPS	D51GP2	G90AE
PHILIPS	D51GP4	G90AE
PHILIPS	D51GY4	G90AE
PHILIPS	EMD155A002	19D503-00BB
PHILIPS	F8050	11AK18-6
PHILIPS	FP5230	PTV620
PHILIPS	FT6188/100Hz	11AK53 (11AK52B6)
PHILIPS	FTR9952	FTV1.9E AA
PHILIPS	FTR9952/12	FTV1.9EE AA
PHILIPS	FTR9952/12S	FTV1.9EE AA
PHILIPS	FTR9952/17	FTV1.9EE AA
PHILIPS	FTR9952/19	FTV1.9EE AA
PHILIPS	FTR9952/19S	FTV1.9EE AA
PHILIPS	FTR9952/58S	FTV1.9EE AA
PHILIPS	FTR9955	F21RE
PHILIPS	FTR9955	F22RU
PHILIPS	FTR9955/12	F21RE AB
PHILIPS	FTR9955/17	F21RU AB
PHILIPS	FTR9955/69	F21RE AB
PHILIPS	FTR9964 2001	F21RE
PHILIPS	FTR9964 2001	FTV2.1E
PHILIPS	FTR9964/12S	F21RE AA
PHILIPS	FTR9964/17S	--
PHILIPS	FTR9964/69S	F21RE
PHILIPS	FTR9964/69S	F21RE AA;FTV2.1EE AA
PHILIPS	FTR9965 2003	F21RE
PHILIPS	FTR9965 2003	F22RU
PHILIPS	FTR9965/12S	F22RE AA
PHILIPS	FTR9965/17S	F22RU AA
PHILIPS	FTR9965/69S	F22RE AA
PHILIPS	GENERAL	GENERAL

Brand	model	chassis
PHILIPS	HC9913C2	OLD
PHILIPS	HC9919C2	OLD
PHILIPS	HD6400W/17	OLD
PHILIPS	KH3647	NCF
PHILIPS	KP3647	NCF
PHILIPS	KR3647	NCF
PHILIPS	KR3648	NCF
PHILIPS	KR5187	2B-S
PHILIPS	KR5987	2B-S
PHILIPS	KR6687	2B-S
PHILIPS	KS6687	2B-S
PHILIPS	LCP5100	LCP5100
PHILIPS	LR2021	GR5AL
PHILIPS	LS2641	T6 (?)
PHILIPS	M1432	L6.1
PHILIPS	M1452	L6.1
PHILIPS	M2032	L6.1
PHILIPS	M2052	L6.1
PHILIPS	M2125	ANUBIS A
PHILIPS	M2126	AA5 AA
PHILIPS	M2132	L6.1
PHILIPS	M2140	ANUBIS A
PHILIPS	M2141	AA5 AA
PHILIPS	M2152	L6.1
PHILIPS	M2182	L6.1
PHILIPS	M2192	L6.1
PHILIPS	M3730	GR1AX
PHILIPS	M3740	GR1AX
PHILIPS	M3750	GR1AX
PHILIPS	M3751	GR1AX
PHILIPS	M3752	GR1AX
PHILIPS	M3760	GR1AX
PHILIPS	M7229	GR2.2
Philips	Magnavox RX4325/WA03	20N1-01 (?)
PHILIPS	MDV545VR/17	UNKNOWN

Brand	model	chassis
PHILIPS	MK4270	19L402-0011
PHILIPS	MP2982	27X110-00AA (?)
PHILIPS	MR2004	19Y406-00AA
PHILIPS	MS2010	19Y405-00AA
PHILIPS	MS2947C101	17X109-00AA
PHILIPS	MT895	3A
PHILIPS	MTV750	K40
PHILIPS	MX5472C/17	OLD
PHILIPS	MX6072C/17	OLD
PHILIPS	MX6472C/17	OLD
PHILIPS	NET01SC/00	UNKNOWN
PHILIPS	P140	GR1AX
PHILIPS	P145R	GR1AX
PHILIPS	PA9032C2	OLD
PHILIPS	PC0127N121	27M800
PHILIPS	PCW027C2	OLD
PHILIPS	PD5029C1	GFL2.20E
PHILIPS	PD5029M	GFL2.20E
PHILIPS	PD5029S	GFL2.20E
PHILIPS	PH3752VT/A	11AK20S ?
PHILIPS	PL9127 C101	F8
PHILIPS	PR1906C121	J8
PHILIPS	PV5470C/17	OLD
PHILIPS	PV5571C/17	OLD
PHILIPS	PV5580W/17	OLD
PHILIPS	PV6070C/17	OLD
PHILIPS	PV6071C/17	OLD
PHILIPS	PV6080W/17	OLD
PHILIPS	PV6480W/17	OLD
PHILIPS	Royal 8028 Color 16CT3215	KT3
PHILIPS	S7022C	ICC17EU
PHILIPS	SBR4210	KT4
PHILIPS	SBR5106	KT4
PHILIPS	SBR5107	KT4M
PHILIPS	SBR5108	KT4

Brand	model	chassis
PHILIPS	SBR5112	KT4M
PHILIPS	SBR5612	K35
PHILIPS	SBR5613	K35
PHILIPS	SBR5614	K35
PHILIPS	SBR5618	K35
PHILIPS	SBR5619	K40
PHILIPS	SBR6662	K35
PHILIPS	SBR6665	K35
PHILIPS	SBR6666	K35
PHILIPS	SBR6667	K35M
PHILIPS	SBR6668	K35
PHILIPS	SBR6669	K35
PHILIPS	SBR6675	K40
PHILIPS	SBR6676	K40
PHILIPS	SBR6677	K35M
PHILIPS	SBR6679	K40
PHILIPS	SBR6681	K40
PHILIPS	SBR6682	K40
PHILIPS	SBR6683	K40
PHILIPS	SBR6685	K40
PHILIPS	SBR6686	K40M
PHILIPS	SBR6690	K40
PHILIPS	SBR6887	K40-FS
PHILIPS	SC2932C2	OLD
PHILIPS	SC3927C2	OLD
PHILIPS	SC3932C2	OLD
PHILIPS	SC3932N2	OLD
PHILIPS	SV2103	2B
PHILIPS	SV2503	2B
PHILIPS	SV2803	2B
PHILIPS	SW3027C1	OLD
PHILIPS	SW3027N1	OLD
PHILIPS	test	kt
PHILIPS	TS2746C101	27F800
PHILIPS	TV17.1-70242/P	TV17.1

Brand	model	chassis
PHILIPS	TV7099VT	TV17 (100Hz)
PHILIPS	V6610	KT4-SYS.T
PHILIPS	V6611	KT4-FS/S.
PHILIPS	V6615	KT4M-SYS.
PHILIPS	V6616	KT4-FS/S.
PHILIPS	V6620	KT4-SYS.T
PHILIPS	V6621	KT4-FS/S (System4)
PHILIPS	V6625	KT4-SYS.T
PHILIPS	V6626	KT4-FS/S (System4)
PHILIPS	V6640	KT4-SYS.T
PHILIPS	V6650	KT4-SYS.T
PHILIPS	V6651	KT4-FS/S.
PHILIPS	V6655	KT4-SYS.T
PHILIPS	V6656	KT4-FS/S (System4)
PHILIPS	V6661	KT4-SYS.T
PHILIPS	V6710	K40-SYS.T
PHILIPS	V6711	K40-FS/S.
PHILIPS	V6715	K40M-SYS.
PHILIPS	V6716	K40-FS/S.
PHILIPS	V6720	K40-SYS.T
PHILIPS	V6721	K40-FS/S.
PHILIPS	V6725	K40M-FS/S
PHILIPS	V6725/10	KT4-SYS.T
PHILIPS	V6726	K40M-FS/S
PHILIPS	V6800	K35
PHILIPS	V6810	K40-SYS.T
PHILIPS	V6811	K40-FS/S.
PHILIPS	V6815	K40M-SYS.
PHILIPS	V6816	K40-FS/S.
PHILIPS	V6820	K40-SYS.T
PHILIPS	V6821	K40-FS/S.
PHILIPS	V6825	K40-SYS.T
PHILIPS	V6826	K40M-FS/S
PHILIPS	V6831	K40-SYS.T
PHILIPS	V6840	K40-SYS.T

Brand	model	chassis
PHILIPS	V6850	K40-SYS.T
PHILIPS	V6851	K40-FS/S.
PHILIPS	V6855	K40-SYS.T
PHILIPS	V6856	K40-FS/S.
PHILIPS	V6861	K40-SYS.T
PHILIPS	W469510001/12	OLD
PHILIPS	W559510001/12	OLD
PHILIPS?	TV2807A	7000 PROFESSIONAL
Phocus	CRT-DVD14S	TDA9345PS/N3/3
Phocus	CRT28FS	14.5 ? (ZX8.190-14)
PHOENIX	CTV2C55 BIF	F10 (?)
PHONOLA		FPC2001
PHONOLA	51M12X30A	FPC2002
PILOT	PL21A5	GUW7 ?
PIONEER	SD21AV1	COMPACT D-E
PIONEER	SD21AV2	EUROSTEREO 2
PIONEER	SD25A2	COMPACT D-E
PIONEER	SD25AV1	COMPACT D-E
PIONEER	SD25AV2	EUROSTEREO2
PIONEER	SD25AV2(1)	2B-S !
PIONEER	SD28AV1	COMPACT D-E
PIONEER	SD28AV2	COMPACT D-E
PIONEER	SDP4053K	KUX1C
PIONEER	SDP4552K	KUX1C
PIONEER	SDP4553K	KUX1C
PIONEER	SDP455K	KUX1C
PIONEER	SV2103	2B
PIONEER	SV2503	2B
PIONEER	SV2803	2B
Platinum (Chiny)	SKY2122	E5S
PLAYSONIC	29L0602	ETC010
PLAYSONIC	32T21NXM	20.2 (100Hz) (BEKO)
PLAYSONIC	PS14432S	SS1
POLAR		S0205-832R
POLAR	3701	S0202-832R

Brand	model	chassis
POLAR	5101	S0202-832R
POLAR	51CTV4029	S07
POLAR	5401	S0202-832R
Precision	PTV1444	CN12C
PRESICION	PTV2044	CN12C
PRESICION	PTV2148	CH16CA
PRESTIGE	EC64303 SAT	SCC103 (ELBIT)
PRIMA		TAE35
PRIMA	TA2955	J21A2
PROFEX	5563VT--5861 75 33	COMPACT B-Kit
PROFEX	CTV2090	P51-28 ? (czy raczej P54S)
PROFEX	CTV2190	P51-28 ? (czy raczej P54S)
PROFEX	CTV3710	MN220
PROFEX	CTV5510	MN220
PROFEX	CTV5520	MN220
PROFILO	4037	SM1 (TELRA01)
PROLINE	1405R	PC180 NOVA
PROLINE	1420R	F1, lub F1W, lub F2W, lub F4W
PROLINE	1420T	F1, lub F1W, lub F2W, lub F4W
PROLINE	1485T	CP185
PROLINE	F2825T	FPC2001
PROLINE	G2892S	11AK37-6
PROLINE	TVD1430	11AK46
PROLUX	14APT02	PT90
PROLUX	14APT102	PT92
PROLUX	14PRT01	PT91
PROLUX	20BGT02FTB1	PT92SBDE
PROLUX	21NMRT02	PT90
Promus	1511SL	17MB20 (Vestel)
PROSONIC	28NXFX	20.2 (100Hz) (BEKO)
PROSONIC	32 NXFX	20.2 (100Hz) (BEKO)
PROSONIC	33TL5N	14.1 (BEKO 7SZ.190-16)
PROSONIC	CTV7289DVT	11AK16
PROTECH	6392	11AK19
PROTECH	7206NT	11AK19

Brand	model	chassis
PROTECH	CE3703	P37-19 ?
PROTECH	CTV2003	11AK30D
PROVISION		TV3K
PROVISION	1410T	TV85
PROVISION	14CX3	TV2KF !
PROVISION	14CX7	TV2K !
PROVISION	14R1	TV2KF !
PROVISION	20CX7	TV2K
PROVISION	2127T	TV2KF
PROVISION	21CX7	TV2K !
PROVISION	C1410R	TV85
PROVISION	DMQ1417	C600
PROVISION	L-TC1418TC7	TV2KR-LT2
PROVISION	L1410T	TV81
PROVISION	L1411T	TV81
PROVISION	L1418T	TV83
PROVISION	L1418TC7	TV2KR
PROVISION	L1418TC7	TV2KR (40-MNTV2KR-K5H-M
PROVISION	L1418TC7	TV3K ?
PROVISION	L1423T	TV2KM ?
PROVISION	L1426	TV2KF !
PROVISION	L1426T	TV2KM
PROVISION	L2021	TV2KF
PROVISION	L2021	TV91
PROVISION	L2021A	TV91
PROVISION	L2021T	TV2KM
PROVISION	L2021T	TV90 ?
PROVISION	L2021TA	TV91 ?
PROVISION	L2103T	TV81
PROVISION	L2121	TV2KF !
PROVISION	L2121T	TV2K ? (czy? TV84, TV83)
PROVISION	L2121T	TV3K
PROVISION	L2121T	TV83
PROVISION	L2121T	TV84
PROVISION	L2121T	TV84 ?

Brand	model	chassis
PROVISION	L2121TMS	TV3K
PROVISION	L2122	TV3KF !
PROVISION	L2126	TV2KF !
PROVISION	L2126T	TV2KR-L2T
PROVISION	L2126T	TV2KR-L2T
PROVISION	L2128TS	PT90 ?
PROVISION	L2163	TV3K (TV3KF) - ?
PROVISION	L2163	TV3KF !
PROVISION	L2163RFS Silver	TV2KR-L5H-M
PROVISION	L2165	TV3KF !
PROVISION	L2815TM	TV4K (40F-STT28C-V5C)
PROVISION	RF2163SI	TV2KM
PROVISION	ST1410T	TV84
PROVISION	ST1411	TV2K
PROVISION	ST2121T	TV95
PROVISION	ST2121T--TV95A	TV95 (200-100-TV95 REV:A)
Quadro	CTV37V10	3401
QUADRO	CTV37V10	3401 (3Y01)
QUADRO	CTV5520TXT	4S02
QUADRO	CTV55V10	4401 (4Y01)
QUADRO	CTV55X10TXT	3Y11
QUADRO	CTV55Z10	3Y11
Quadro	CTV63S10	5N11
QUADRO	CTV72F10	5S01 ?
Quadro	CTV72I10	5N11
Quadro	CTV72V10	5N11
QUASAR	TP2009DV	APEDP280
QUELLE	FT-HDD8123	11AK33J3
RADIOLA	52KE1512	CP90
RADIONETTE	RN21A60T	PC58B
RADIOTONE	Mira 7100	PT92-110
RADIOTONE	P37-508	11AK20 SE-2
RADIOTONE	P37-508	11AK20SE2
RADIOTONE	R5131	11AK30
RADIOTONE	TV2040VT	TELRA

Brand	model	chassis
RADIOTONE	TV2054VT	11AK19
RADIOTONE	TV2150VT	SM1
RADIOTONE	TV370AV	DTV1400 (czy? raczej CP370)
RADIOTONE	TV380VT	TELRA
RADIOTONE	TV386VT	CTT-H
RADIOTONE	TV511AV	SM1 MONO
RADIOTONE	TV5140VT	TELRA
RADIOTONE	TV5540VT	TELRA
RADIOTONE	TV7040VT	TELRA
RADIOTONE	TV7097ST	SM2 ?
RADIOTONE	TV7098	SM2
RADIOTONE	TV7098VT	SM2
RADIOTONE	TV7098VT	SM2
RADIOTONE	TV7099VT	SM2 (99TA013B)
RADIOTONE	TV7100VT	(97TA021C)
RADIOTONE	TV72721	PT90PBG
RAINFORD	TV3711	11AK20SE
RAINFORD	TV3715C	PT92
RAINFORD	TV5126	11AK30A4
RAINFORD	TV5151T	PT92
RAINFORD	TV5196	11AK19E3
RAINFORD	TV5515T	PT92
RAINFORD	TV5531	11AK30A4
RAINFORD	TV5561C	11AK30A4
RAINFORD	TV6382	11AK19P
RAINFORD	TV6661	11AK19PRO
RAINFORD	TVF5568	ST9J
RCA	13GP211C04	TX825
RCA	13GP243	TX825
RCA	14F512T	M123L
RCA	20V500T	M123SP
RCA	24F512T	M134C
RCA	24F630T	M134C
RCA	24V511T	M134C (?)
RCA	25GT503TX2	CTC177AA3

Brand	model	chassis
RCA	25GT506TX2	CTC177AA3
RCA	25GT510FE1/TX1	CTC177AA3
RCA	27F520T	M134C
RCA	27F630T	M134C
RCA	27F630T	M134C
RCA	27GT612	CTC167R
RCA	27V512T	M134C
RCA	27V512T	M134C
RCA	27V513T	M134C
RCA	27V520T	M134C
RCA	27V520T	M134C
RCA	27V530T	ITC008FBK
RCA	32F530T	ATC113
RCA	32V520T	M134C
RCA	44JW642A	ITC222
RCA	C21520	CTC186D
RCA	CR14401	K15A (Samsung)
RCA	CR20401	K15A (Samsung)
RCA	D52120	CTC211A
RCA	E13250BTF03	TX82T
RCA	E13320	TX808H
RCA	F19421	TX808S
RCA	F19423	TX809C (?)
RCA	F20601SE	CTC175A
RCA	F25209BCTX1	CTC185AA3
RCA	F25209BCTX1	CTC185AA3
RCA	F25209WTTX1	CTC185AA3
RCA	F25209WTTX1	CTC185AA3
RCA	F25211BCTX1	CTC185AA3
RCA	F25211BCTX1	CTC185AA3
RCA	F27634ET	CTC187BJ
RCA	F27672ETFE1/JX1	CTC187BD
RCA	F27673SEFE1	CTC187BD
RCA	F32730SBFM1	CTC179CM
RCA	F35665	CTC203CX

Brand	model	chassis
RCA	G27666ATLM1	CTC187BG
RCA	G27684PKF1	CTC187BG
RCA	G27688HPLF1	CTC187BG
RCA	G27689ATDX1/LM1	CTC187BG
RCA	M27GE500	CTC177AF3 (?)
RCA	MCR51R310	CN12C5
RCA	MCR51R410	CN12C5
RCA	MG13400	K15A (Samsung)
RCA	MG19400	K15A (Samsung)
RCA	MM36100	MM101CC
RCA	MR13401	K15A (Samsung)
RCA	MR13401	K15A (Samsung)
RCA	MR19401	K15A (Samsung)
RCA	MR29310	CTC203AF9
RCA	P46922YX6	PTK195M11A
RCA	P46924	PTK195M26A
RCA	P60812BL	PTK195AC ?
RCA	PS32600YX1	CTC197CK
RCA	PS32700YX1	CTC197CJ3
RCA	PS35682	CTC170
RCA	PS36600YX1	CTC197CK
RCA	PS36605YX2	CTC197CK
RCA	PS36700YX1	CTC197CJ3
RCA	R21GG8RA	TX807
RCA	RBA33694	CTC186/187
RCA	X13152GS	TX81 ?
RCA	X20162GSA04	CTC146L/LA
RCA	X25101	CTC177
RECOR	RC4220PST	RC4121A
RECOR	RC4221PST	RC4121A
RECOR	RC4421PST	RC4121A
RED STAR	CTV2155	PT90A
RED STAR	CTV28169	PT91 ?
RED STAR	CTV2870	PT90A
RED STAR	CTV2870	PT90A

Brand	model	chassis
RED STAR	CTV3714VT	TV2K
RED STAR	CTV8232	PT90A (02TA058G)
RED STAR	HTS28	PT90A (02TA058G)
RED STAR	HTS32	PT90A
REKORD	37TC5188	200-100TV2K
REKORD	51TC5149	SW211
REKORD	51TC5168	H501V
REKORD	51TC5169	SW211
REKORD	51TC5169	SW216AP
REKORD	51TC5169	SW216M
REKORD	51TC5171	G1000
REKORD	51TC5188	200-100TV2K
REKORD	54TC5149	SW211
REKORD	54TC5168	H501V
REKORD	54TC5169	H501
REKORD	54TC5169	H501
REKORD	54TC5169	SW211
REKORD	54TC5169	SW216AP
REKORD	54TC5169	SW216M
REKORD	54TC5171	G1000
REKORD	54TC5188	200-100TV2K
REKORD	54TC88	TV2K
REVOX	B234S	C9002
REVOX	TV70CM	C9002
RFT	TV55-2000	E7 (czy? E9)
RFT	TV55-3000	TV3000
RFT	TV55-353	TV520
RFT	TV63-1000	LP (?)
RFT	TV63-3000	TV3000
RFT	TV63-3000	TV3000
RFT	TV63-4000H	(100Hz)
RFT	TV70-2000	LP
RFT	TV70-2000 COLANI	LP
RFT	TV70-3000	TV3000
RFT	TV70-343	TV520

Brand	model	chassis
RFT	TV70-4000H	(100Hz)
RFT	TV72-3000	TV3000
ROADSTAR	1450KT	VE01
ROADSTAR	2050KT	VE01
ROADSTAR	2150KT	VE01
ROADSTAR	CTV1424XT	GT9313
ROADSTAR	CTV2003	11AK19
ROADSTAR	CTV2020XT	12.6 (BEKO)
ROADSTAR	CTV2134T/S	12.7 ?
ROADSTAR	CTV2811XTS	14.2 (BEKO)
ROADSTAR	TDV1437X/TX (czy? TVD1437X/TX)	P1420
ROADSTAR	TLV1084	TMX482A
ROADSTAR	TV700TX	CTR-AA
ROADSTAR	TVD1437XT	P1420
ROADSTAR	TVD2151KLTN	11AK46
ROLSEN	C1420	TCL
ROLSEN	C2120	TCL
ROLSEN	C2121	EX1A1
ROLSEN	C2910	CH10
ROYAL	28NXT09S	7S2190
ROYAL	STAR 14M04	BEKO ...
ROYAL	TV3703	C41
ROYAL	TV3706	C41
ROYAL	TV3710	K8214
ROYAL	TV5103	C41
ROYAL	TV5104	C41
ROYAL	TV5115	K3721
ROYAL	TV5502(H)	TV3KF ?
ROYAL	TV6399	11AK37 ?
ROYAL-LUX	TV3799TXT	CTV5
ROYAL-LUX	TV5599TXT/ST	(40-258411-OAG)
ROYAL-STAR	21TXM12	12.5 ?
ROYAL-STAR	21TXM12	12.5 ?
ROYAL-STAR	21TXT29S	12.6 (BEKO)
ROYAL-STAR	28NXT07	BEKO...

Brand	model	chassis
SABA	36C41	IKC2
SABA	36C904	IKC2
SABA	36T905	IKC2
SABA	51K40	TX91
SABA	55ES955	IKC2
SABA	63PL945	IKC2
SABA	70E991	IKC2
SABA	C3610F	EUROCOMBO2
SABA	C5110F	EUROCOMBO2 (442B/COMBO99)
SABA	F21182T	ETC009
SABA	F29182T	ETC010
SABA	M2503	SX08
SABA	M2504	TX90
SABA	M3610	TX807
SABA	M3615FT	TX807EU
SABA	M3616ET	TX807C/CS
SABA	M3700	TX805
SABA	M3702	IKC2
SABA	M3703	SX08
SABA	M3705	IKC2 ?
SABA	M3706	TX90
SABA	M3707	TX805
SABA	M3711	TX90
SABA	M3715	TX805
SABA	M3716	TX91
SABA	M3799	TX90
SABA	M37K10	TX805
SABA	M4007	TX90
SABA	M4203	SX08
SABA	M4206	TX90
SABA	M4209VT	TX90
SABA	M4211	TX90
SABA	M4507VT	ICC6
SABA	M5106D	TX90
SABA	M5107VT	ICC6

Brand	model	chassis
SABA	M5108	TX80
SABA	M5109	TX90 ?
SABA	M5110E	TX807C/CS
SABA	M5112VT	TX91
SABA	M5115ET	TX807C/CS
SABA	M5116VT	TX91
SABA	M5132 NIC Y	TX91
SABA	M5170HCT	TX91G
SABA	M5176HCT	TX91G
SABA	M51K30VT	TX90
SABA	M5506	IKC2 (?)
SABA	M5507VT	ICC6
SABA	M5510C	TX807
SABA	M5515CG	TX807
SABA	M5515VT	ICC6
SABA	M5516VT	TX91
SABA	M5517E1	TX807
SABA	M5518E	ICC17
SABA	M5520C	TX91G
SABA	M5528	ICC8
SABA	M5530VT	ICC8
SABA	M5531VT	ICC9
SABA	M5532VT	TX91
SABA	M5566GBT	TX91
SABA	M5576GCT	TX91
SABA	M55K20	ICC7
SABA	M55K30	TX91
SABA	M6308VT	ICC6
SABA	M6316ET	ICC17
SABA	M6316VT	ICC9
SABA	M6317E	TX807CS !
SABA	M6317VT	ICC6
SABA	M6321VT PIP	ICC5 NMOS
SABA	M6322C	ICC17
SABA	M6330VT	ICC8

Brand	model	chassis
SABA	M6331NIC	ICC9
SABA	M6361GH	TX92F
SABA	M6376GH	TX92F
SABA	M7016ET	ICC17
SABA	M7022C	ICC17
SABA	M7030VT	ICC8
SABA	M7032 NIC	ICC9
SABA	M7050	ICC7
SABA	M7061GH	TX92F
SABA	M7076GH	TX92F
SABA	M7077	ICC7
SABA	M70KV	ICC6
SABA	M7221VT PIP	ICC5
SABA	M7221VT PIP	SX50 PIP
SABA	M7224	ICC5
SABA	M7228VT	ICC8
SABA	M8500VT	ICC9
SABA	M8505VT	TX92F
SABA	M8510 NIC	ICC9
SABA	M8521C	ICC17
SABA	M8522C	ICC17
SABA	P37S41	S90
SABA	RP46L	ICC9
SABA	RP52L	ICC9
SABA	S7022C	ICC17
SABA	S7040C	ICC20 (100Hz)
SABA	S7042E	ICC20 (100Hz)
SABA	S70S170	ITC008EN
SABA	S70S170T	ETC010
SABA	SB9221	ICC8
SABA	SD6325VT	ICC9
SABA	SD6365VT	TX92
SABA	SD7025VT	ICC9
SABA	SD7065	TX92
SABA	SD7071	ICC9

Brand	model	chassis
SABA	SD81	ICC9-107
SABA	SDM7020	ICC9
SABA	SDM7021	TX92
SABA	SM253 PIP	ICC5 CMOS IMC
SABA	SM256	ICC7
SABA	SM258	ICC8
SABA	SV81D	IDC2.2
SABA	T5540LY	TX91
SABA	T5576SF	TX91
SABA	T56SC44	82c
SABA	T6300M	ICC7
SABA	T6307	ICC7
SABA	T6308VT	ICC6
SABA	T6321VT	ICC5 NMOS
SABA	T6332 NIC	TX92
SABA	T6345VT	IKC2
SABA	T6347VT	ICC7
SABA	T6348VT	ICC8
SABA	T6349 NIC	ICC9
SABA	T6350 NIC	ICC9
SABA	T6350VT	ICC5 NMOS
SABA	T6351VT	ICC5 NMOS
SABA	T6351VT	SX50
SABA	T6352	ICC5 NMOS
SABA	T6353	ICC7 (?)
SABA	T6354P SAT	ICC5 NMOS
SABA	T6355	ICC8
SABA	T6356OH	TX92F
SABA	T6356S	ICC9
SABA	T6360SH	TX92
SABA	T6360VT	ICC5 ?
SABA	T6366SH	TX92F
SABA	T6371VT	ICC5 NMOS
SABA	T6372	ICC5 NMOS
SABA	T63U83	ICC5

Brand	model	chassis
SABA	T67SC44	82c
SABA	T7002C	ICC17
SABA	T7008VT	ICC6
SABA	T70170	ITC008
SABA	T7017VT	ICC6
SABA	T7019F	ICC6
SABA	T7021C	ICC17
SABA	T7022C	ICC17
SABA	T7032 NIC	TX92
SABA	T7040E	ICC19 100Hz
SABA	T7040VT	ICC5 NMOS
SABA	T7041E	ICC19 100Hz
SABA	T7045VT	ICC5 NMOS
SABA	T7047NIC	ICC9
SABA	T7048	SC85/ICC8DE !
SABA	T7048NIC	ICC8
SABA	T7049VT	ICC9
SABA	T7050 NIC	ICC9
SABA	T7051VT	TX92
SABA	T7052S	ICC9
SABA	T7055	ICC8
SABA	T7056 NIC	ICC9
SABA	T7056OH	TX92
SABA	T7060 NIC	TX92
SABA	T7065SH	TX92F
SABA	T7066SH	TX92F
SABA	T7068TL	ICC11
SABA	T7077VT	ICC7
SABA	T7078TM	ICC19 100Hz
SABA	T70B20VT	TX92
SABA	T70K20	ICC7
SABA	T70K30	ICC9
SABA	T70K30VT	TX92
SABA	T70U83	ICC5
SABA	T71SC83	82c

Brand	model	chassis
SABA	T7232 NIC	TX92
SABA	T7250VT	ICC5 NMOS
SABA	T7251VT SAT	ICC5 NMOS
SABA	T7252VT	ICC5 NMOS
SABA	T7253VT	ICC5 NMOS
SABA	T7254	ICC5 NMOS
SABA	T7254	SX50
SABA	T7260	ICC5 NMOS
SABA	T7262	ICC5
SABA	T7271AD	ICC5 NMOS
SABA	T7272BS	ICC5 NMOS
SABA	T7280VT	ICC5 NMOS
SABA	T7281VT PIP	SX50=ICC5 NMOS
SABA	T7635V	ICC5 NMOS
SABA	T7636	ICC5
SABA	T7677SC	(110/70/B)
SABA	T7700	ICC5
SABA	T7704VT	ICC5
SABA	T7706	ICC5
SABA	T8226D	ICC5
SABA	T8727	ICC5
SABA	T8728	ICC5
SABA	T9677SC	82c
SABA	T9786V	ICC5
SABA	W7021C	ICC17
SABA	W7022E	ICC17
SABA	WF28B60	B14.2 = 14.2 !
SADKO	21T31	12.6 (?)
SAISHO	14T1	CP370
SAISHO	14T1	CP370
SAISHO	20T1	CP370
SAISHO	20T1	CP370
SAISHO	2190	11AK02
SAISHO	21T1	CP370
SAISHO	21T1	CP370

Brand	model	chassis
SAISHO	2580	11AK02
SAISHO	2590	11AK02
SAISHO	25M1	EB2A
SAISHO	28M1	EB2A
SAIVOD		11AK19E3
SAIVOD	28P2S	PT90 ?
SAIVOD	TFT304CT	17MB11
SALORA	14MF50VT	F8GY ?
SALORA	14MP50VT TICO	MONO PLUS2
SALORA	14S2VT	MONO PLUS
SALORA	14S3	MONO PLUS (5864 6. ...)
SALORA	14S3	MONOPLUS
SALORA	15L30	L
SALORA	15L32	L1
SALORA	15S2C	EUROMONO1
SALORA	17C20	CORE2
SALORA	17S2C	EUROMONO1
SALORA	1H3A	H
SALORA	1H9	H
SALORA	20A5	MONO PLUS (STEREO)
SALORA	20MP50VT TICO	MONO PLUS2
SALORA	20S3	MONO PLUS (5864 6. ...)
SALORA	21C40	CORE2
SALORA	21C51	CORE2
SALORA	21D61	COMPACT D-E
SALORA	21D80	COMPACT D2
SALORA	21D81	COMPACT D-E
SALORA	21K70	K
SALORA	21K77	K
SALORA	21K7V	K
SALORA	21M80	M 90°
SALORA	21M87	M 90°
SALORA	21M90	M 90°
SALORA	21MP50VT TICO	MONO PLUS2
SALORA	21N58/C	Eurostereo 2A/2B-S

Brand	model	chassis
SALORA	21N58/C	Eurostereo 2A/2B-S
SALORA	21N5S	EUROSTEREO2
SALORA	21N6	EUROSTEREO1
SALORA	21N6F	EUROSTEREO2
SALORA	21N80	Eurostereo 2A/2B-S
SALORA	21N80	EUROSTEREO2
SALORA	21N81	EUROMONO2
SALORA	21S2VT	MONOPLUS
SALORA	21S3	MONO PLUS (5864 6. ...)
SALORA	21S41	EUROMONO2
SALORA	21S4S	EUROMONO2
SALORA	21S5C	EUROMONO2
SALORA	21SSU/C/F	EUROMONO
SALORA	21T6	STEREO PLUS
Salora	21T6-7	A34A=STEREO PLUS
SALORA	21T7	STEREO PLUS
SALORA	22K30	K
SALORA	22K37	K
SALORA	24K70	K
SALORA	24K77	K
SALORA	24K7V	K
SALORA	24L60	L2
SALORA	25C40	CORE2
SALORA	25C51	CORE2 110°
SALORA	25C5F	CORE2 110°
SALORA	25C60	CORE2 110°
SALORA	25D61	COMPACT D-E
SALORA	25D70	COMPACT D2
SALORA	25D80	COMPACT D2
SALORA	25D81	COMPACT D-E
SALORA	25E7	EURO-DIGI 4/3
SALORA	25E7	EURO-DIGI 4/3
SALORA	25E7S	EURO-DIGI (E)
SALORA	25E80	Eurostereo feature
SALORA	25E80	EUROSTEREO FEATURE PLUS

Brand	model	chassis
SALORA	25E9	EURO-DIGI 4/3
SALORA	25E9	EURO-DIGI 4/3
SALORA	25E9S	EURO-DIGI (E)
SALORA	25M87	M 110°
SALORA	25N5C/S	Eurostereo 2A/2B-S
SALORA	25N6	EUROSTEREO1
SALORA	25N6F	EUROSTEREO2
SALORA	25N6S	Eurostereo 2A/2B-S
SALORA	25N7S	N
SALORA	25N8F	EUROSTEREO2
SALORA	25N8F/C	Eurostereo 2
SALORA	25S4S	EUROMONO2
SALORA	25S5U/C/F	EUROMONO
SALORA	25SP55	STEREOPLUS 2
SALORA	25T6	STEREO PLUS
SALORA	25T7	A34A=STEREO PLUS
SALORA	25T7	STEREO PLUS
SALORA	25V80	FS
SALORA	26A42	COMPACT D2
SALORA	26K30	K
SALORA	26K70	K30
SALORA	28C40	CORE2
SALORA	28D80	COMPACT D2
SALORA	28D81	COMPACT D-E
SALORA	28E7	EURO-DIGI 4/3
SALORA	28E7S	EURO-DIGI (E)
SALORA	28E80	EUROSTEREO FEATURE PLUS
SALORA	28E9	EURO-DIGI 4/3
SALORA	28E9S	EURO-DIGI (E)
SALORA	28F8	EURO-DIGI 16/9
SALORA	28F9C	EURO-DIGI 16/9
SALORA	28G30 Maestro++ Black	G3_GW Safety++
SALORA	28G30 Maestro++ Silver	G3_GW Safety++
SALORA	28G35 Soul++	G3_GW Safety++
SALORA	28K70	K

Brand	model	chassis
SALORA	28K77	K
SALORA	28K7H	K
SALORA	28K7V	K
SALORA	28K80	K30
SALORA	28L41	L2
SALORA	28M87	M 110°
SALORA	28MCW110 100Hz Forum II	MC2 (Multi Concept 2)
SALORA	28MCW110 100Hz Forum II	TZ
SALORA	28MCW110 100Hz Opera	MC2 (Multi Concept 2)
SALORA	28MCW110 100Hz Opera	TZ
SALORA	28MZ100 100Hz Forum	MZ
SALORA	28N7S	N
SALORA	28N8C	EUROSTEREO2
SALORA	28N8F/C	EUROSTEREO2
SALORA	28N8S	EUROSTEREO2
SALORA	28S4C	EUROMONO2
SALORA	28S4S/C	EUROMONO
SALORA	28SE50M	E9A
SALORA	28T7	STEREO PLUS
SALORA	28V80	FS
SALORA	28W35	EURO-DIGI 16/9
SALORA	29E90	EUROSTEREO FEATURE PLUS
SALORA	29V100	FX (100Hz)
SALORA	29V90	EUROMONO
SALORA	29V90	FX
SALORA	32F9C	EURO-DIGI 16/9
SALORA	32G30 Maestro++ Silver	G3_GW Safety++
SALORA	32G35 Soul++	G3_GW Safety++
SALORA	32MCW110 100Hz Forum II Silver	MC2 (Multi Concept 2)
SALORA	32MCW110 100Hz Forum II Silver	TZ
SALORA	32MCW110 100Hz Opera	MC2 (Multi Concept 2)
SALORA	32MCW110 100Hz Opera	TZ
SALORA	32MCW120 100Hz Opera	TZ
SALORA	32MZ110 100Hz 3D VGA PiP Arena	MZ
SALORA	32MZ110 100Hz Arena	MZ

Brand	model	chassis
SALORA	32W35	EURO-DIGI 16/9
SALORA	3321U	A3-A14
SALORA	33E9	EURO-DIGI 4/3
SALORA	33E9S	EURO-DIGI (E)
SALORA	36F8	EURO-DIGI 4/3
SALORA	Forum_II TZ72R3	MC2A (SALORA); TZ (NOKIA)
SALORA	FX21D61	COMPACT D-E
SALORA	J709	J
SALORA	KV-C2521D	AE1B (SCC-D51E-A)
SALORA	KV-C2531D	(SCC-D51D-A)
SALORA	P1424101	M1
SALORA	SN63B6	STEREO PLUS2 (inaczej: SP2) - ?
SALORA	SN63L1 (25SP5M)	STEREO PLUS2 (inaczej: SP2)
SALORA	SN63L1 (25SP5M)	STEREO PLUS2 PFC SN
SAMSUNG	RC4221PST	RC4121A
SAMSUNG	RC4421PST	RC4121A
SAMSUNG		CB338RSF
SAMSUNG		WZ72
SAMSUNG	14TC616/NOCX	KCT12A
SAMSUNG	20TC615/NOCX	KCT12A
SAMSUNG	24W6VW	S51A
SAMSUNG	28W6HG	KS3A ?
SAMSUNG	3350X	SCV11
SAMSUNG	3350XT	SCV11
SAMSUNG	42HD43A	P55A(N_Rev.1)
SAMSUNG	510M	GS15MS
SAMSUNG	510N	MJ15AS*
SAMSUNG	510T	MJ15BS*
SAMSUNG	701N	MJ17AS*
SAMSUNG	710M	GS17MS
SAMSUNG	710N	MJ17AS*
SAMSUNG	710T	MJ17BS*
SAMSUNG	710V	GS17VS
SAMSUNG	73V	GS17VT
SAMSUNG	910B	MJ19QS*

Brand	model	chassis
SAMSUNG	910M	GS19MS
SAMSUNG	910N	MJ19AS*
SAMSUNG	910T	MJ19BS*
SAMSUNG	910V	GS19VS
SAMSUNG	911N	MJ19AS*
SAMSUNG	912T	MJ19DS*
SAMSUNG	913N	MJ19ES*
SAMSUNG	913T	MJ19QS*
SAMSUNG	915N	MJ19US*
SAMSUNG	920N	MJ19AS*
SAMSUNG	93V	GS19VT
SAMSUNG	C21SAA11MH	S56A
SAMSUNG	CB14F12TS	KS1A
SAMSUNG	CB14F1T	S15A
SAMSUNG	CB14F1T0X/XEC	S15A
SAMSUNG	CB14F1T0X/XET	S15A
SAMSUNG	CB14F1T5H	S15A02
SAMSUNG	CB14F1TS0X/XEC	S15A
SAMSUNG	CB14F2V5X/XST	S15A
SAMSUNG	CB14Y52TB	KS1A
SAMSUNG	CB14Y5B0XXET	S15A
SAMSUNG	CB14Y5TB0XXEC	S15A
SAMSUNG	CB14Y5TS0XXEC	S15A
SAMSUNG	CB14Y5TS0XXET	S15A
SAMSUNG	CB14Y5TW0XXEC	S15A
SAMSUNG	CB14Y5TW0XXET	S15A
SAMSUNG	CB20792TS	KS1A
SAMSUNG	CB20F12TS	KS1A
SAMSUNG	CB20F12Z	KS1A
SAMSUNG	CB20F42TS	KS1A
SAMSUNG	CB20F42TSXXEC	KS1A(P)_Rev.1
SAMSUNG	CB20F42Z	KS1A
SAMSUNG	CB20H1T	S15A
SAMSUNG	CB20H1T0X	S15A
SAMSUNG	CB20H1T0X	S15A

Brand	model	chassis
SAMSUNG	CB20H1T0X/XEC	S15A
SAMSUNG	CB20H1T0X/XET	S15A
SAMSUNG	CB20H1T0XEC	S15A
SAMSUNG	CB20H1T0XET	S15A
SAMSUNG	CB20H1T5X	S15A
SAMSUNG	CB20H1Z5X	S15A
SAMSUNG	CB20H32TS	KS1A
SAMSUNG	CB20H42TSXXEC	KS1A(P)_Rev.1
SAMSUNG	CB20P30BT	S15A
SAMSUNG	CB20S10BZ	SCT13B
SAMSUNG	CB20S20BT	S15A
SAMSUNG	CB21F32TSXXEC	KS1A(P)_Rev.1
SAMSUNG	CB21F32ZSXXEC	KS1A(P)_Rev.1
SAMSUNG	CB21F52TSX	KS1A
SAMSUNG	CB21F52TSXXEC	KS1A(P)_Rev.1
SAMSUNG	CB21H12TS	KS1A
SAMSUNG	CB21H12TSXXEC	KS1A(P)_Rev.1
SAMSUNG	CB21H1T5X	S15A
SAMSUNG	CB21H1Z5X	S15A
SAMSUNG	CB21H42TSXXEC	KS1A(P)_Rev.1
SAMSUNG	CB21M17MLHXXST	S17A(P)_KILLER
SAMSUNG	CB21N112TZXXEC	KS9A(P)
SAMSUNG	CB21S20BT	S15A
SAMSUNG	CB322AT	P68AT
SAMSUNG	CB3335T	P69SA
SAMSUNG	CB3335Z	P69SA
SAMSUNG	CB333FBX	KS1A
SAMSUNG	CB3351	P58
SAMSUNG	CB3351FA	P68SA
SAMSUNG	CB3351XMT	P68SC
SAMSUNG	CB3373T0X/XEC	S15A
SAMSUNG	CB3373T0X/XET	S15A
SAMSUNG	CB3373Z	P1B03
SAMSUNG	CB3373Z	S15A ?
SAMSUNG	CB3373Z	SCT11D ?

Brand	model	chassis
SAMSUNG	CB346ZSE	P54S
SAMSUNG	CB347F	P50F
SAMSUNG	CB349FSA	P50
SAMSUNG	CB5012AT	P68SA
SAMSUNG	CB5012T	P58SC
SAMSUNG	CB5012Z	P58T
SAMSUNG	CB5013Z	P58SC
SAMSUNG	CB501FT0X/XEC	S15A
SAMSUNG	CB5020T0X/XET	S15A
SAMSUNG	CB5020T1HV2CX	SCT11D ?
SAMSUNG	CB5020T1SHV1CX	SCT11D
SAMSUNG	CB5020T1SHV2CX	SCT11D
SAMSUNG	CB5020T4X/XEC	SCT13B
SAMSUNG	CB5020T4X/XEP	SCT13B
SAMSUNG	CB5020T4X/XET	SCT13B
SAMSUNG	CB5020Z1HSLCX	SCT11D
SAMSUNG	CB5020Z1SHVCX	SCT11D
SAMSUNG	CB5035T	P69SA
SAMSUNG	CB5035Z	P69SA
SAMSUNG	CB5035Z	SCT11B
SAMSUNG	CB5051	P68SC
SAMSUNG	CB5051A	P68SC
SAMSUNG	CB5073T	P1B
SAMSUNG	CB5073T1	SCT11D
SAMSUNG	CB5073Z	SCT11B
SAMSUNG	CB5073Z	SCT11D
SAMSUNG	CB5073Z5X/XEG	S15A
SAMSUNG	CB5079T	SCT11B
SAMSUNG	CB5079T	SCT13B
SAMSUNG	CB5079T5X	S15A
SAMSUNG	CB5079Z5X	S15A
SAMSUNG	CB512ZSE	P54S
SAMSUNG	CB514ZSD	P54
SAMSUNG	CB528Z	P54SB
SAMSUNG	CB528ZSE	P54S !

Brand	model	chassis
SAMSUNG	CB5314XT	P68SC
SAMSUNG	CB5320T	SCT11B
SAMSUNG	CB5320T	SCT11D ?
SAMSUNG	CB5320T1SHV1CX	SCT11D
SAMSUNG	CB5320T1SHV2CX	SCT11D
SAMSUNG	CB5320T4X/AMF	SCT13B
SAMSUNG	CB5320T4X/XEC	SCT13B
SAMSUNG	CB5320T4X/XET	SCT13B
SAMSUNG	CB5320Z1SHVCX	SCT11D
SAMSUNG	CB533CW	S51A
SAMSUNG	CB536ZSE	P54S
SAMSUNG	CB5373UKV1CX	P1B
SAMSUNG	CB5373UKV2CX	P1B
SAMSUNG	CB5379T5X	S15A
SAMSUNG	CB5379UKVCX	SCT11B
SAMSUNG	CB566BT1X	SCT57B
SAMSUNG	CB5933W	S60MT (SM60T, SM60MT)
SAMSUNG	CB6226W/SEIX	S60MT (SM60T, SM60MT)
SAMSUNG	CB6230WT	S60MT
SAMSUNG	CB6833W	S60MT (SM60T, SM60MT)
SAMSUNG	CB7226W/AMFX	S60MT (SM60T, SM60MT)
SAMSUNG	CB7230	P72-1
SAMSUNG	CF14F12T/SXXEF	KS1A
SAMSUNG	CF20F42ZS	KS1A
SAMSUNG	CF20H12T	KS1A
SAMSUNG	CF21F32ZSXXEF	KS1A(P)_Rev.1
SAMSUNG	CF21H1T	S15A
SAMSUNG	CF21H42TSXXEF	KS1A(P)_Rev.1
SAMSUNG	CF21K22T	KS1A
SAMSUNG	CF501FTOX/XEF	S15A
SAMSUNG	CF536R	S60
SAMSUNG	CF537	S60(F) ?
SAMSUNG	CF5413Z	S60SC1 (?)
SAMSUNG	CF6844N0	S51A
SAMSUNG	CFT27918X/SMS	KS3A

Brand	model	chassis
SAMSUNG	CFTD2083TX/SMS	V18A
SAMSUNG	CFTD2085	V18A(N)
SAMSUNG	CH7226	S60MT (SM60T, SM60MT)
SAMSUNG	CI20F12TS	KS1A
SAMSUNG	CI3351A	P68SA
SAMSUNG	CI3352X	P68SC
SAMSUNG	CI3352X/TSECX	P68SC
SAMSUNG	CI338F	P36A
SAMSUNG	CI338Z	P36A
SAMSUNG	CI340ZA	P50
SAMSUNG	CI347FA	P50
SAMSUNG	CI501FT	S15A
SAMSUNG	CI501FZ	S15A
SAMSUNG	CI5052AT	P68SA
SAMSUNG	CI5061A	P68SA
SAMSUNG	CI5061AT	P68SA(AT)
SAMSUNG	CI5062V	CKC50HM
SAMSUNG	CI5079Z	SCT11B
SAMSUNG	CI514F	P36A
SAMSUNG	CI5361A	P68SA
SAMSUNG	CI5937AN	P70
SAMSUNG	CI593CN	KS2A
SAMSUNG	CI593CN8XXEU	KS3A
SAMSUNG	CI6229T/SEUKX	P72
SAMSUNG	CI6271	Z68
SAMSUNG	CI7271	Z68
SAMSUNG	CK14E1VR5S	S15A
SAMSUNG	CK14F12T	KS1A
SAMSUNG	CK14F1T5X/XEH	S15A
SAMSUNG	CK14F1T5X/XEO	S15A
SAMSUNG	CK14F1T5XEO	S15A
SAMSUNG	CK14F1Z5X/XEO	S15A
SAMSUNG	CK20E1VR5C	S15A
SAMSUNG	CK20H1 TR	S15-A2
SAMSUNG	CK20H1T5XE	S15A

Brand	model	chassis
SAMSUNG	CK20H1VR5X/NWT	S15A
SAMSUNG	CK20R1VR5X/BWT	S15A
SAMSUNG	CK20S20	S15A
SAMSUNG	CK20S20BT	S15A
SAMSUNG	CK20S20BT	S15A
SAMSUNG	CK20S20BT	S15A
SAMSUNG	CK20T3VR5C	S15A
SAMSUNG	CK2139XR	S15A
SAMSUNG	CK2139XR5X	S15A (?)
SAMSUNG	CK2173VR5X/BWT	S15A
SAMSUNG	CK2199X3X	S51A
SAMSUNG	CK2199X3X/VWT	S51A
SAMSUNG	CK21F1VR	S15A
SAMSUNG	CK21P30BT	SCT13B (czy? S15A)
SAMSUNG	CK21S20	S15A
SAMSUNG	CK21S20BT	S15A
SAMSUNG	CK21S20BT	S15A
SAMSUNG	CK25D4V3X	S51A
SAMSUNG	CK25D4V3X/BWT	S51A
SAMSUNG	CK28C7VD3X	S51A
SAMSUNG	CK28C7VD3X/XEH	S51A
SAMSUNG	CK28C7VDG3X/EH	S51A ?
SAMSUNG	CK2902SXC	S51A
SAMSUNG	CK29D4V3X	S51A
SAMSUNG	CK29D4V3X/BWT	S51A
SAMSUNG	CK29D4V3X/NWT	S51A
SAMSUNG	CK3312Z	P58SC
SAMSUNG	CK3312Z/VNEX	P58SC
SAMSUNG	CK3313EICIX	P68SC
SAMSUNG	CK331EZR4X/BWT	SCT13B
SAMSUNG	CK331FVR5X	S15A
SAMSUNG	CK3326Z/OTX	P58SC
SAMSUNG	CK3326Z/OTX	P58SC
SAMSUNG	CK3335TR1SERX	P69SA1
SAMSUNG	CK3335TRSERX	P69SA1

Brand	model	chassis
SAMSUNG	CK3335WELTCX	P69SA
SAMSUNG	CK3338ZR4X	SCT13B
SAMSUNG	CK3338ZR4X/BWT	SCT13B
SAMSUNG	CK333ETR4X	SCT13B
SAMSUNG	CK333EZR4X/BWT	SCT13B
SAMSUNG	CK3351A	P68SA
SAMSUNG	CK3351AT/SGCX	P68SA(AT)
SAMSUNG	CK3351X	P68CS-M
SAMSUNG	CK3351XT	P68T
SAMSUNG	CK3361A	P64 ?
SAMSUNG	CK3366ZR4X/BWT	SCT13B
SAMSUNG	CK3373T1	SCT11D
SAMSUNG	CK3373T4X	SCT13B
SAMSUNG	CK3373T5X	S15A
SAMSUNG	CK3373TSEPCX	SCT11B
SAMSUNG	CK3373Z	P1B
SAMSUNG	CK3373Z	S15A ?
SAMSUNG	CK3373Z1X	S15A
SAMSUNG	CK3373ZR4X/BWT	SCT13B
SAMSUNG	CK3383ZR1BWX	P69SA1
SAMSUNG	CK3385ZR4X/BWT	SCT13B
SAMSUNG	CK5012SIBEX	P58SC
SAMSUNG	CK5012T	P58SC !
SAMSUNG	CK5012X	P68SC-N
SAMSUNG	CK5012Z	P58SC
SAMSUNG	CK5012Z/LINX	P58SC
SAMSUNG	CK5013Z	P58SC
SAMSUNG	CK501ETB4X	SCT13B
SAMSUNG	CK501ETB4X/NWT	SCT13B
SAMSUNG	CK501ETR4X/BWT	SCT13B
SAMSUNG	CK501EZR4X/BWT	SCT13B
SAMSUNG	CK501FT5X	S15A
SAMSUNG	CK501FVR5S/NWT	S15A
SAMSUNG	CK501FVR5X/NWT	S15A
SAMSUNG	CK501FZ5X	S15A

Brand	model	chassis
SAMSUNG	CK501T2	P58SC
SAMSUNG	CK5020T4ANA	SCT13B
SAMSUNG	CK5020T5S(X)	S15A
SAMSUNG	CK5020T5X	S15A
SAMSUNG	CK5020Z5S(X)	S15A
SAMSUNG	CK5022SGVX	P68XT
SAMSUNG	CK5027AT	P68SA
SAMSUNG	CK5027WELTX	P58T
SAMSUNG	CK5027Z	P58SC
SAMSUNG	CK5038T/ANASX	SCT11B
SAMSUNG	CK5038TBWCX	SCT11B
SAMSUNG	CK5038ZR/BWX	SCT11B
SAMSUNG	CK5038ZR/TBWCX	SCT11B
SAMSUNG	CK5038ZR4X	SCT13B
SAMSUNG	CK5038ZR4X/BWT	SCT13B
SAMSUNG	CK5039TR4S	SCT13B
SAMSUNG	CK5039TR4S/NWT	SCT13B
SAMSUNG	CK5039TR4X/BWT	SCT13B
SAMSUNG	CK5039VR5S/AWT	S15A
SAMSUNG	CK5039ZR	P1B
SAMSUNG	CK5039ZR1	SCT11D
SAMSUNG	CK503ETR4S	SCT13B
SAMSUNG	CK503EZR4X/BWT	SCT13B
SAMSUNG	CK5051A	P68SA ?
SAMSUNG	CK5051X	P68SC
SAMSUNG	CK5061A	P68SA
SAMSUNG	CK5061AT	P68SA ?
SAMSUNG	CK5062A	PT11 ? (01-95TA055F)
SAMSUNG	CK5066TR4S	SCT13B
SAMSUNG	CK5066VR5X	S51A
SAMSUNG	CK5066ZR4X/BWT	SCT13B
SAMSUNG	CK5073SEPCX	SCT11B
SAMSUNG	CK5073T	P1B
SAMSUNG	CK5073T	S15A
SAMSUNG	CK5073T	SCT13B

Brand	model	chassis
SAMSUNG	CK5073T	SCT13B
SAMSUNG	CK5073T0X	S15A(D-Version)
SAMSUNG	CK5073T1	SCT11D
SAMSUNG	CK5073T4X/SSH	SCT13B
SAMSUNG	CK5073T4XEO	SCT13B
SAMSUNG	CK5073T5X	S15A
SAMSUNG	CK5073Z	P1B
SAMSUNG	CK5079T5X	S15A
SAMSUNG	CK5081T	P69SA
SAMSUNG	CK5083ZR1BWX	P69SA1
SAMSUNG	CK5085SEPCX	SCT11B
SAMSUNG	CK5085TB4X	SCT13B
SAMSUNG	CK5085TBR	P1B
SAMSUNG	CK5085VR5S/AWT	S15A
SAMSUNG	CK5085ZR4X/BWT	SCT13B
SAMSUNG	CK508CTR4X	SCT13B
SAMSUNG	CK5099TR	SCT12A
SAMSUNG	CK5099ZR	SCT12A
SAMSUNG	CK512ZSE	P54S
SAMSUNG	CK528Z	P54S
SAMSUNG	CK5312Z	P58SH
SAMSUNG	CK5314XT	P68SA (?) (P68SC-H ?)
SAMSUNG	CK5319Z	Z54
SAMSUNG	CK531FT5X	S15A
SAMSUNG	CK531FZ5X	S15A
SAMSUNG	CK5320T	SCT11B ?
SAMSUNG	CK5320T1	SCT11D
SAMSUNG	CK5320T4X/XSP	SCT13B (?)
SAMSUNG	CK5320T4XEO	SCT13B
SAMSUNG	CK5320T5S(X)	S15A
SAMSUNG	CK5320T5X	S15A
SAMSUNG	CK5320Z	SCT11B (AA41-10443A)
SAMSUNG	CK5320Z5S(X)	S15A
SAMSUNG	CK5322AT	P58AT
SAMSUNG	CK5322T/SGVX	P58T

Brand	model	chassis
SAMSUNG	CK5322XT	P68SC
SAMSUNG	CK5322Z/KAUKX	P58SC
SAMSUNG	CK5322Z/ROMTSX	P58SC
SAMSUNG	CK5326W	P88MH
SAMSUNG	CK5335TRSERX	P69SA1
SAMSUNG	CK5338ZR4X	SCT13B
SAMSUNG	CK5338ZR4X/BWT	SCT13B
SAMSUNG	CK5339	P1B
SAMSUNG	CK5339TB	SCT12A
SAMSUNG	CK5339TR	SCT11D
SAMSUNG	CK5339TR4S/NWT	SCT13B
SAMSUNG	CK5339TR4X	SCT13B
SAMSUNG	CK5339TR4X/BWT	SCT13B
SAMSUNG	CK5339VR5S	S15A
SAMSUNG	CK5339VR5S/AWT	S15A
SAMSUNG	CK5339Z/T/TBR1BWX	SCT11D
SAMSUNG	CK5339ZR/BWX	P1B
SAMSUNG	CK5339ZR1/TBR1	SCT11D
SAMSUNG	CK5339ZR1/TR1BWX	SCT11D
SAMSUNG	CK533CN	S51A ?
SAMSUNG	CK5341 TR1SERX	P69SA1
SAMSUNG	CK5341T	P69SA1
SAMSUNG	CK5342AT	P68AT
SAMSUNG	CK5344N	S51A
SAMSUNG	CK5344N3X	S51A
SAMSUNG	CK5344N3XEW	S13A
SAMSUNG	CK534Z	P58SH
SAMSUNG	CK534Z/PALMX	P58CH
SAMSUNG	CK5361A	P68
SAMSUNG	CK5361A/TTASX	P68SA1
SAMSUNG	CK5361AT	P68AT
SAMSUNG	CK5361AT	P68SA
SAMSUNG	CK5361M	P64SH1
SAMSUNG	CK5362	P68SA1
SAMSUNG	CK5366TR4X	SCT13B

Brand	model	chassis
SAMSUNG	CK5366ZR4X/BWT	SCT13B
SAMSUNG	CK5373SEPCX	SCT11B
SAMSUNG	CK5373T	P1B
SAMSUNG	CK5373T - Ilw.	S15A02
SAMSUNG	CK5373T/SPLP1D	SCT11D ?
SAMSUNG	CK5373T1	SCT11D
SAMSUNG	CK5373T4X/SSH	SCT13B
SAMSUNG	CK5373T4XEO	SCT13B
SAMSUNG	CK5373T5X	S15A
SAMSUNG	CK5379	S15A ?
SAMSUNG	CK5379 TOX/XEH	S15A
SAMSUNG	CK5379T	S15A ?
SAMSUNG	CK5379T	S15A ?
SAMSUNG	CK5379T4XEO	SCT13B
SAMSUNG	CK5379T5X	S15A
SAMSUNG	CK5385SEPCX	SCT11B
SAMSUNG	CK5385TB4S	SCT13B
SAMSUNG	CK5385ZR4X/BWT	SCT13B
SAMSUNG	CK541ZSE	P54S
SAMSUNG	CK542ZSE	P54S
SAMSUNG	CK546BZR1X/BWT	SCT57B
SAMSUNG	CK564BZR1X	SCT57B
SAMSUNG	CK565BSR1X/VWT	SCT57B
SAMSUNG	CK565BST1X	SCT57B
SAMSUNG	CK565BST1X/BWT	SCT57B
SAMSUNG	CK566BSR1X/BWT	SCT57B
SAMSUNG	CK566BST1X	SCT57B
SAMSUNG	CK566BST1X/VWT	SCT57B
SAMSUNG	CK566BT1X	KCT57A-B
SAMSUNG	CK566BT1XEO	SCT57
SAMSUNG	CK566BT3XEO	S51A
SAMSUNG	CK567BSR1X	SCT57B
SAMSUNG	CK567BSR1X/BWT	SCT57B
SAMSUNG	CK567BSR1X/VWT	SCT57B
SAMSUNG	CK568BST1X	SCT57B

Brand	model	chassis
SAMSUNG	CK568BST1X/BWT	SCT57B
SAMSUNG	CK568BT	S51A
SAMSUNG	CK569BGT1X	SCT57B
SAMSUNG	CK569BN3X	S51A
SAMSUNG	CK569BNT1XEO	SCT57B
SAMSUNG	CK569BWT1X	SCT57B
SAMSUNG	CK5913WELTX	S60MT (SM60T, SM60MT)
SAMSUNG	CK5913Z/NORSX	S60MT (SM60T, SM60MT)
SAMSUNG	CK5944N3X/XEH	S51A
SAMSUNG	CK5944N3XEO	S51A
SAMSUNG	CK6202WB/POLS	SCT12B
SAMSUNG	CK6202WTR	SCT12B
SAMSUNG	CK6226W	S60MT (SM60T, SM60MT)
SAMSUNG	CK6226WELTSX	S60MT (SM60T, SM60MT)
SAMSUNG	CK6230W	P72-1
SAMSUNG	CK623CN3X	S51A
SAMSUNG	CK623CN3X/XEH	S51A
SAMSUNG	CK623CNX	SCT12B
SAMSUNG	CK6271	Z68
SAMSUNG	CK6271WP	Z70
SAMSUNG	CK6813Z/STTX	S60MT (SM60T, SM60MT)
SAMSUNG	CK6833SEGX	S60MT (SM60T, SM60MT)
SAMSUNG	CK6833W/SEGX	S60MT (SM60T, SM60MT)
SAMSUNG	CK6840	SCT12B ?
SAMSUNG	CK6844N3XEO	S51A
SAMSUNG	CK685	P61TS
SAMSUNG	CK703CN	SCT12B
SAMSUNG	CK703CN	SCT12B
SAMSUNG	CK703CN3X	S51A
SAMSUNG	CK703CNX	SCT12B
SAMSUNG	CK7202POLSX	SCT12B
SAMSUNG	CK7202WB	SCT12B (?)
SAMSUNG	CK7202WT	SCT57A
SAMSUNG	CK7226W	S60MT (SM60T, SM60MT)
SAMSUNG	CK7226WT	SM60MT

Brand	model	chassis
SAMSUNG	CK7230W	SM60MT
SAMSUNG	CK7230W/BWX	S60MT (SM60T, SM60MT)
SAMSUNG	CK7230Z	S60MT (SM60T, SM60MT)
SAMSUNG	CK7271AW	Z68
SAMSUNG	CK7271AW/WELCX	Z68
SAMSUNG	CK7271WP	Z70
SAMSUNG	CK765DWT2X	SCT57C
SAMSUNG	CK765DWT2X/BWT	SCT57C
SAMSUNG	CL15A8L7X/GSU	KS2A(N)
SAMSUNG	CL15A8L7X/RCL	KS2A(N)
SAMSUNG	CL15A8L7X/STR	KS2A(N)
SAMSUNG	CL15K5MN	K15D(N)
SAMSUNG	CL17K10MJ	KS9A
SAMSUNG	CL17M2MQZX/STR	KS9A(N)
SAMSUNG	CL21A8W7X/DRI	KS2A(N)
SAMSUNG	CL21A8W7X/GSU	KS2A(N)
SAMSUNG	CL21A8W7X/RCL	KS2A(N)
SAMSUNG	CL21A8W7X/STR	KS2A(N)
SAMSUNG	CL21A8W7X/XAP	KS2A(N)
SAMSUNG	CL21A9W	KS2A (?)
SAMSUNG	CL21A9W7X/XAX	KS2A(N)
SAMSUNG	CL21K3WDX/GSU	KS1B
SAMSUNG	CL21M16MN	KS9A
SAMSUNG	CL21M16MNZXGSU	KS9A (21M16)
SAMSUNG	CL21M16MNZXAX	KS9A(N)
SAMSUNG	CL21M21MQUXXAZ	KS7A
SAMSUNG	CL21M21PQUXXAX	KS7A
SAMSUNG	CL21M40MQ	KS9C (?)
SAMSUNG	CL21M40MQGXXAX	KS9C(N)_MI
SAMSUNG	CL21M5	KS9B
SAMSUNG	CL21M5MQ6X/GSU	KS9B
SAMSUNG	CL21M6MQ4X/XAX	K57A
SAMSUNG	CL21M6WKX/RCL	K57A(N)
SAMSUNG	CL21M6WKX/XAX	K57A(N)
SAMSUNG	CL21N11MJZXAX	KS9A(N)

Brand	model	chassis
SAMSUNG	CL21N11MQUXXAZ	KS7A
SAMSUNG	CL21S8W	K57A
SAMSUNG	CL21S8W7X/RCL	KS2A(N_REV.2)
SAMSUNG	CL21S8W7X/XAO	KS2A(N_REV.2)
SAMSUNG	CL21S8WKX/RCL	KS2A(N_REV.2)
SAMSUNG	CL21S8WKX/STR	KS2A(N_REV.2)
SAMSUNG	CL21S8WKX/W7X	KS2A(N) (Rev.2).
SAMSUNG	CL21S8WKX/XAO	KS2A(N_REV.2)
SAMSUNG	CL21S8WKX/XAP	KS2A(N_REV.2)
SAMSUNG	CL21S8WKX/XAX	KS2A(N_REV.2)
SAMSUNG	CL21S8WKX/XAX	KS2A(N_REV.2)
SAMSUNG	CL21T21PQUXGSU	KS7A
SAMSUNG	CL21T21PQUXXAX	KS7A
SAMSUNG	CL21Z43MQ	KS9C
SAMSUNG	CL21Z50MQ3XXAO	KS9C
SAMSUNG	CL25A6P7X/RCL	KS2A(REV.1)
SAMSUNG	CL25A6W7X/RCL	KS2A(N)
SAMSUNG	CL25A6W7X/XAX	KS2A(N)
SAMSUNG	CL25K4W	KS2A (25A6)
SAMSUNG	CL25KW7X/XAP	KS2A(REV.1)
SAMSUNG	CL25M2MQUX	KS7A(N-R2)
SAMSUNG	CL25M5MQUX/GSU	KS7A
SAMSUNG	CL25M5MQUX/RCL	KS7A
SAMSUNG	CL25M5W4X/RCL	K57A
SAMSUNG	CL25M6MQ4X/STR	K57A
SAMSUNG	CL25M6MQ4X/XAO	K57A
SAMSUNG	CL25M6MQ4X/XAP	K57A
SAMSUNG	CL25M6MQ4X/XAX	K57A
SAMSUNG	CL25M6MQUT/XAP	KS7A
SAMSUNG	CL25M6MQUT/XAP	KS7A
SAMSUNG	CL25M6MQUX/XAO	KS7A(N_R2)_Gold Rush
SAMSUNG	CL25M6MQUX/XAP	KS7A(N_R2)_Gold Rush
SAMSUNG	CL25M6MQUX/XAX	KS7A
SAMSUNG	CL29A10PQVXGSU	KS7A
SAMSUNG	CL29D4W7X/DRI	KS2A(N)

Brand	model	chassis
SAMSUNG	CL29D4W7X/STR	KS2A(N)
SAMSUNG	CL29D8BW7X/XAX	KS2A(REV.1)
SAMSUNG	CL29D8WKX/STR	K57A(N)
SAMSUNG	CL29D8WKX/XAP	K57A(N)
SAMSUNG	CL29D9WKX/RCL	K57A(N)
SAMSUNG	CL29K3W8X/STR	KS3A
SAMSUNG	CL29K3WKX/STR	K57A(N)
SAMSUNG	CL29K3WKX/XAP	K57A(N)
SAMSUNG	CL29K3WKX/XAX	K57A(N)
SAMSUNG	CL29K5MQ2X/XAX	K16A (?)
SAMSUNG	CL29K5MQ4X/STR	K57A
SAMSUNG	CL29K5MQ4X/XAO	K57A
SAMSUNG	CL29K5MQ4X/XAX	K57A
SAMSUNG	CL29K5MQUT/XAP	KS7A
SAMSUNG	CL29K5MQUX/STR	--
SAMSUNG	CL29K5MQUX/XAO	KS7A
SAMSUNG	CL29K5MQUX/XAP	KS7A
SAMSUNG	CL29K5MQUX/XAX	KS7A
SAMSUNG	CL29L4MAA	KS2A
SAMSUNG	CL29M16MQUXGSU	KS7A
SAMSUNG	CL29M21MQUXXAZ	KS7A
SAMSUNG	CL29M21PQUXSTR	KS7A
SAMSUNG	CL29M21PQUXXAX	KS7A
SAMSUNG	CL29M40MQ2XXAX	K16A(N)_MI
SAMSUNG	CL29T21FQ2XXAX	K16A(N)_Rhumba
SAMSUNG	CL29T21PQUXXAX	KS7A
SAMSUNG	CL29V10MN3XSTR	K57A
SAMSUNG	CL29V10MNKXXAX	K57A(N)
SAMSUNG	CL29V10MV	K57A
SAMSUNG	CL29V5W	K57A
SAMSUNG	CL29V5WKX/XAO	K57A
SAMSUNG	CL29Z30HSBXXAX	K61C(N)_Corset
SAMSUNG	CL29Z6PQUX/XAZ	KS7A
SAMSUNG	CL32Z40HMRXXAO	K65A(N)_Sting
SAMSUNG	CL34A10PQVXXAP	--

Brand	model	chassis
SAMSUNG	CL34Z6PQUX/XAZ	KS7A
SAMSUNG	CL765DW7X/DRI	KS2A(N)
SAMSUNG	CL766DW7X/RCL	KS2A(N)
SAMSUNG	CL766DW7X/XAP	KS2A(N)
SAMSUNG	CL766DW7X/XAX	KS2A(N)
SAMSUNG	CM32010C/KMT	KS3A(N)
SAMSUNG	CMC13410X/KMT	V17A
SAMSUNG	CMC19410X/KMT	V17A
SAMSUNG	CN3338V	KCT12A (KP 1)
SAMSUNG	CN3339V	KCT12A (KP 1)
SAMSUNG	CN3350	KCT12A (KP 1)
SAMSUNG	CN3366V	KCT12A (KP 1)
SAMSUNG	CN3373	KCT12A (KP 1)
SAMSUNG	CN3373V	KCT12A (KP 1)
SAMSUNG	CN3383	P62SA ?
SAMSUNG	CN3385V	KCT12A (KP 1)
SAMSUNG	CN5038V	KCT12A (KP 1)
SAMSUNG	CN5039B6X/DAY	K15B
SAMSUNG	CN5039V	KCT12A (KP 1)
SAMSUNG	CN5039V	KCT15B
SAMSUNG	CN5051Z/RG6NX	P62SA(N)
SAMSUNG	CN5066V	KCT12A (KP 1)
SAMSUNG	CN5073V	KCT12A (KP 1)
SAMSUNG	CN5085V	KCT12A (KP 1)
SAMSUNG	CN565BWC/XBG	KCT57A
SAMSUNG	CN565BWX/DRI	KCT57A
SAMSUNG	CN565BWZ	K51A
SAMSUNG	CN663A	KCT57A
SAMSUNG	CN7202WB	KCT52A
SAMSUNG	CN7207	KCT52A ?
SAMSUNG	CN722AP	KCT54A
SAMSUNG	CN722AP/SEAX	KCT54A
SAMSUNG	CN7266BP	K56KA1 K56XQH P67
SAMSUNG	CN765DWC/XBG	KCT57A
SAMSUNG	CN765DWX/DRI	KCT57A

Brand	model	chassis
SAMSUNG	CR2173TR	KS1A
SAMSUNG	CS14E1V5X	S15A
SAMSUNG	CS14F10MJ0CDWP	KS1A
SAMSUNG	CS14F2R	KS1A
SAMSUNG	CS14F2V5C	S15A
SAMSUNG	CS14F30S/AST	KS1A
SAMSUNG	CS14H2T6X/SAP	S15A
SAMSUNG	CS14H3X	KS1A
SAMSUNG	CS14H4MJ0X/XSE	--
SAMSUNG	CS14R1C/NWT	KS1A(P)_Rev.1
SAMSUNG	CS14R1R	KS1A albo KS1B
SAMSUNG	CS14R1X/BWT	KS1A(P)_Rev.1
SAMSUNG	CS14S1X	KS1A
SAMSUNG	CS14S1X/SIG	KS1A(P)_Rev.1
SAMSUNG	CS14S1ZX/HAC	KS1A(P)_Rev.1
SAMSUNG	CS14S1ZX/XSG	KS1A(P)_Rev.1
SAMSUNG	CS14S4MK0S/SEN	KS1A
SAMSUNG	CS14S4SV6X/XSE	S15A
SAMSUNG	CS14V10MJ0CDWP	KS1A
SAMSUNG	CS14V10MJ0CHIM	KS1A
SAMSUNG	CS14V10MJ0XELE	KS1A
SAMSUNG	CS14V10MJ0XSIG	KS1A
SAMSUNG	CS14V10MJ0XTAW	KS1A
SAMSUNG	CS14V10MJ0XUMG	KS1A
SAMSUNG	CS14V5MJ0C/DWP	KS1A
SAMSUNG	CS15A8ST7C	KS2A
SAMSUNG	CS15A8W7X	KS2A ?
SAMSUNG	CS15A8W7X/XST	KS2A
SAMSUNG	CS15K10MJ0CABS	--
SAMSUNG	CS15K10MJ0XTAW	KS1A
SAMSUNG	CS15K10MJ0XUMG	--
SAMSUNG	CS15K10MJZXawe	KS9A
SAMSUNG	CS15K10ML0XANB	KS1A
SAMSUNG	CS15K10ML0Xawe	KS1A
SAMSUNG	CS15K2MJQ	KS9A

Brand	model	chassis
SAMSUNG	CS15K2X	KS1A
SAMSUNG	CS15K5MG	KS1A(P)REV.2
SAMSUNG	CS15K5MJ0X/AWE	KS1A
SAMSUNG	CS15K5MJ0X/XSG	KS1A
SAMSUNG	CS15K5ML	KS1A(P)
SAMSUNG	CS15K5ML	KS1A(P)
SAMSUNG	CS15K5ML	KS1A(P)REV.2
SAMSUNG	CS15K8MN	KS9A
SAMSUNG	CS15K8W0X/BWT	KS1A
SAMSUNG	CS15K8WX	KS1A
SAMSUNG	CS15M16MJ0XBWT	KS1A
SAMSUNG	CS15N11MJ0XBWT	--
SAMSUNG	CS17A11MJ0SNWT	--
SAMSUNG	CS17K10ML0XANB	--
SAMSUNG	CS17M16MG0XXSE	--
SAMSUNG	CS17M16ML0XXHK	KS1A
SAMSUNG	CS17N11MJ0SNWT	--
SAMSUNG	CS2039X	KS1A
SAMSUNG	CS2073S	KS1A
SAMSUNG	CS20F10MJ	KS1A(P)REV.2
SAMSUNG	CS20F10MJ0CDWP	KS1A
SAMSUNG	CS20F2V5C	S15A
SAMSUNG	CS20H2T6X/SAP	S15A
SAMSUNG	CS20H2Z6X/SAP	S15A
SAMSUNG	CS20H42TSXBWT	KS1A(P)_Rev.1
SAMSUNG	CS20H42ZSXBWT	KS1A(P)_Rev.1
SAMSUNG	CS20H4MJ	KS1A(P)REV.2
SAMSUNG	CS20H4MJ0X/BWT	KS1A
SAMSUNG	CS20H4MJ0X/XSE	--
SAMSUNG	CS20Q1ML0M/XSE	KS1A
SAMSUNG	CS20R1R	KS1A
SAMSUNG	CS20S12ZSXBWT	KS1A(P)_Rev.1
SAMSUNG	CS20S1V5X	S15A (?)
SAMSUNG	CS20S1V5X/UMG	S15A
SAMSUNG	CS20S4S6X/XSE	S15A

Brand	model	chassis
SAMSUNG	CS20S4WX	KS1A
SAMSUNG	CS20S4ZX/NIK	KS1A
SAMSUNG	CS20V10MJ0XELE	KS1A
SAMSUNG	CS20V10MJ0XSIG	KS1A
SAMSUNG	CS20V10MJ0XUMG	KS1A
SAMSUNG	CS20V10MK0CABS	KS1A
SAMSUNG	CS20V10ML0CDWP	KS1A
SAMSUNG	CS20V5MJ	KS1A(P)REV.2
SAMSUNG	CS20V5MJ0C/DWP	KS1A
SAMSUNG	CS20V5MK0C/ABS	KS1A
SAMSUNG	CS2139TR	KS1A
SAMSUNG	CS2154	KS1A
SAMSUNG	CS2173S	KS1A
SAMSUNG	CS21A0WT7X/BWT	KS2A(P)
SAMSUNG	CS21A0WT7X/NWT	KS2A(P)
SAMSUNG	CS21A0WT7X/VWT	KS2A(P)
SAMSUNG	CS21A11MH3CABS	S56A(P) Rev.1
SAMSUNG	CS21A11MH4SGAR	S56A(P) Rev.1
SAMSUNG	CS21A11MH4XUMG	S56A
SAMSUNG	CS21A8NTA	KS2A(N)
SAMSUNG	CS21A8S7C	KS2A
SAMSUNG	CS21A8W1BX	KS1B
SAMSUNG	CS21A8W7AX	KS2A(N)
SAMSUNG	CS21A8W7C	KS2A(N)
SAMSUNG	CS21A8W7X/MUR	KS2A
SAMSUNG	CS21A8WT7X/TAW	KS2A
SAMSUNG	CS21A8WT7X/VWT	KS2A
SAMSUNG	CS21A8WTQ	KS2A
SAMSUNG	CS21A9GNDX	KS2A
SAMSUNG	CS21A9W2	KS1C(P)
SAMSUNG	CS21A9WT7C	KS2A(N)
SAMSUNG	CS21B2MG0C/HAC	KS1A
SAMSUNG	CS21B8MG0C/DIO	KS1A
SAMSUNG	CS21D8S	KS1A
SAMSUNG	CS21F3MJ0S/ATG	KS1A

Brand	model	chassis
SAMSUNG	CS21F52TSXBWT	KS1A(P)_Rev.1
SAMSUNG	CS21F5X	KS1A
SAMSUNG	CS21H4ML0X/TRI	KS1A
SAMSUNG	CS21H4X	KS1A
SAMSUNG	CS21K10MG6XTAW	KS9B
SAMSUNG	CS21K10ML5Xawe	KS9B
SAMSUNG	CS21K10MLDXTAW	KS1B
SAMSUNG	CS21K10MQ4XSIG	S56A
SAMSUNG	CS21K2MJ5X/NWT	KS9B(P)
SAMSUNG	CS21K30M	KS9A
SAMSUNG	CS21K30MQZXBWT	KS9A
SAMSUNG	CS21K3DX/BWT	KS1B
SAMSUNG	CS21K3MJDX/XSG	KS1B
SAMSUNG	CS21K3ML5X/SML	KS9B
SAMSUNG	CS21K5MH5S/NWT	KS9B(P)
SAMSUNG	CS21K5MH5X/NWT	KS9B(P)
SAMSUNG	CS21K5MLDX/UMG	KS1B
SAMSUNG	CS21K5SPX/XSV	S56A
SAMSUNG	CS21K9DS/ATG	KS1B
SAMSUNG	CS21K9MA	KS9A
SAMSUNG	CS21K9MAZX/XST	KS9A(P)
SAMSUNG	CS21K9ML	KS1B(P)
SAMSUNG	CS21K9MLDC/DWP	KS1B(P)
SAMSUNG	CS21K9MLDC/XFA	KS1B
SAMSUNG	CS21K9MLDS/GAR	KS1B
SAMSUNG	CS21M16M	KS9A(P)
SAMSUNG	CS21M16MJ	KS9A
SAMSUNG	CS21M16MQ	KS9A
SAMSUNG	CS21M20EQVXXST	KS7A
SAMSUNG	CS21M20MHVXXSA	KS7A
SAMSUNG	CS21M20MNVXXST	KS7A
SAMSUNG	CS21M20MQZXBWT	KS9A(P)
SAMSUNG	CS21M21EHVXHAC	KS7A(P)Rev.1
SAMSUNG	CS21M6MQ5X/BWT	--
SAMSUNG	CS21M7EHVX/HAC	KS7A

Brand	model	chassis
SAMSUNG	CS21M7MLDS/GAR	KS1B
SAMSUNG	CS21M7MLDX/UMG	KS1B
SAMSUNG	CS21M7MNAC/HIM	KS2A
SAMSUNG	CS21Q1MNDM/XSE	KS1B
SAMSUNG	CS21S1MK0S/SEN	KS1A
SAMSUNG	CS21S1S	KS1A
SAMSUNG	CS21S1SX/AWE	KS1A(P)_Rev.1
SAMSUNG	CS21S4MK0S/SEN	KS1A
SAMSUNG	CS21S4S	KS1A(P)REV.2
SAMSUNG	CS21S4WX	KS1A
SAMSUNG	CS21S5NT7X/SAP	KS2A
SAMSUNG	CS21S8EHVX/HAC	KS7A
SAMSUNG	CS21S8MH3C/ABS	S56A(P) Rev.1
SAMSUNG	CS21S8N	KS2A(P) REV.2
SAMSUNG	CS21S8NAS/MUR	KS2A(P) (Rev. 2)
SAMSUNG	CS21T3MA	KS7A
SAMSUNG	CS21T3PAVX/XTL	KS7A
SAMSUNG	CS21T4MA	KS7A
SAMSUNG	CS21V10MJ0XTAW	--
SAMSUNG	CS21V10MK0CABS	KS1A
SAMSUNG	CS21V10ML	KS1A(P)REV.2
SAMSUNG	CS21V10ML0CHIM	KS1A
SAMSUNG	CS21V10ML0XELE	KS1A
SAMSUNG	CS21V10ML0XSIG	KS1A
SAMSUNG	CS21Z40ZQ	S16D(P)
SAMSUNG	CS21Z40ZQCXBWT	S16D(P)
SAMSUNG	CS22B47S/AST	KS2A(N)
SAMSUNG	CS22B47S/AST/X	KS2A(N)
SAMSUNG	CS22B5WT7X	KS2A(N)
SAMSUNG	CS22B6W7X	KS2A
SAMSUNG	CS22B6WT7X	KS2A(N)
SAMSUNG	CS22B7W7X	KS2A
SAMSUNG	CS22B7W8X	KS2A(N)
SAMSUNG	CS22B8W7X	KS2A
SAMSUNG	CS22B9NT7X	KS2A

Brand	model	chassis
SAMSUNG	CS25A11MH4XUMG	S56A
SAMSUNG	CS25A11MHUXUMG	KS7A
SAMSUNG	CS25A11MNUX/XST	KS7A(P) REV.1
SAMSUNG	CS25A6GW7C	KS2A
SAMSUNG	CS25A6WAC	KS2A
SAMSUNG	CS25A6WT	KS2A
SAMSUNG	CS25A6WTAX/TAW	KS2A
SAMSUNG	CS25D4BT7X	KS2A(N)
SAMSUNG	CS25D4NT7X	KS2A(N)
SAMSUNG	CS25D4S7X	KS2A(N)
SAMSUNG	CS25D4V3X	S51A
SAMSUNG	CS25D4V3X/XSG	S51A
SAMSUNG	CS25D4WT7X	KS2A
SAMSUNG	CS25D4X3X/TAW	S51A
SAMSUNG	CS25K10K2R	S56A(P)REV.1
SAMSUNG	CS25K10MQ	KS7A
SAMSUNG	CS25K20EQ	KS7A
SAMSUNG	CS25M20EQWXBWT	KS7A
SAMSUNG	CS25M20MHUXXSG	KS7A
SAMSUNG	CS25M6MCRX/XST	KS7A(P) REV.1
SAMSUNG	CS25M6MHUX/XSG	KS7A
SAMSUNG	CS25M6SSQ	K55A
SAMSUNG	CS25V5MH3X/ANB	S56A
SAMSUNG	CS2902WT7X	KS2A
SAMSUNG	CS2951NV	S51A
SAMSUNG	CS2951V	S51A
SAMSUNG	CS29A10HBGXHAC	K55A(P) YOUNGSTAR_Rev.1
SAMSUNG	CS29A10HEGXHAC	K55A
SAMSUNG	CS29A10HU	K55A
SAMSUNG	CS29A10HUGXANB	K55A
SAMSUNG	CS29A10HUGXTAW	K55A
SAMSUNG	CS29A10HW	K55A(P)YOUNGSTAR
SAMSUNG	CS29A10HWGXELE	K55A
SAMSUNG	CS29A11SSGXawe	K55A
SAMSUNG	CS29A11SSGXUMG	K55A

Brand	model	chassis
SAMSUNG	CS29A11SSQ	S61A
SAMSUNG	CS29A2009X/XSA	KS4A(P)
SAMSUNG	CS29A20HUYXXFA	S61A
SAMSUNG	CS29A5MT8X	KS3A
SAMSUNG	CS29A5MTQ	KS3A
SAMSUNG	CS29A6HP2X/ANB	S53A
SAMSUNG	CS29A6HPT	SCT53A
SAMSUNG	CS29A6MT8X	KS3A
SAMSUNG	CS29A6MTRX	SCT55A
SAMSUNG	CS29A6WT8X	KS3A
SAMSUNG	CS29A7HF9X/BWT(S)	KS4A(P)
SAMSUNG	CS29A7HF9X/NWT	KS4A(P)
SAMSUNG	CS29A7HF9X/RAD(R)	KS4A(P)
SAMSUNG	CS29A7HF9X/SAP(R)	KS4A(P)
SAMSUNG	CS29A7HF9X/UMG(R)	KS4A(P)
SAMSUNG	CS29A7HF9X/VWT	KS4A(P)
SAMSUNG	CS29A7HF9X/XSE(R)	KS4A(P)
SAMSUNG	CS29A7HF9X/XSV	KS4A(P)
SAMSUNG	CS29A7HFQ	KS4A(P)REV.1
SAMSUNG	CS29A7HPBX	KS3A
SAMSUNG	CS29D4NX3X	S51A
SAMSUNG	CS29D4NX3X/SAP	S51A
SAMSUNG	CS29D4V	S51A
SAMSUNG	CS29D6WT7X	KS2A
SAMSUNG	CS29D8WT7X	KS2A
SAMSUNG	CS29D9	S51A
SAMSUNG	CS29D9NV	S51A
SAMSUNG	CS29K10MH3XBWT	S56A
SAMSUNG	CS29K10MQ	KS3A_50Hz_R5
SAMSUNG	CS29K10MQWXNWT	KS7A(P) REV.1
SAMSUNG	CS29K3MCRX/XST	KS7A
SAMSUNG	CS29K3MH4X/FAT	S56A
SAMSUNG	CS29K3MHUX/UMG	KS7A
SAMSUNG	CS29K3MHUX/XSG	--
SAMSUNG	CS29K3NTBS/XSE	KS3A(P) 50Hz(REV. 5)

Brand	model	chassis
SAMSUNG	CS29K5MQ	KS7A
SAMSUNG	CS29K5MQ3S/NWT	--
SAMSUNG	CS29M16MA4XTT	S56A
SAMSUNG	CS29M16MGUXXSA	KS7A
SAMSUNG	CS29M16MQUXXSE	KS7A(P) REV.1
SAMSUNG	CS29M16MQWXNWT	KS7A(P) REV.1
SAMSUNG	CS29M16PQVXHAC	KS7A
SAMSUNG	CS29M20MHUXXSG	KS7A
SAMSUNG	CS29M20PQVXHAC	KS7A
SAMSUNG	CS29M20SPNSKLG	S61A
SAMSUNG	CS29M6HP	KS3A
SAMSUNG	CS29M6HPQ	KS3A
SAMSUNG	CS29M6MNUX/XST	KS7A(P) REV.1
SAMSUNG	CS29M6MQRX/BWT	--
SAMSUNG	CS29M6PQ8S/CBM	KS3A
SAMSUNG	CS29M6PQ8X/AWE	KS3A
SAMSUNG	CS29M6PQVX/SAP	KS7A
SAMSUNG	CS29M6SSGS/NWT	K55A
SAMSUNG	CS29T10P	KS7A
SAMSUNG	CS29T10PAVXXTL	KS7A
SAMSUNG	CS29T11MA	KS7A
SAMSUNG	CS29T11MABXXTL	KS3A
SAMSUNG	CS29V10MC	S56A(P) REV.1
SAMSUNG	CS29V10MH3XANB	S56A
SAMSUNG	CS29Z4HF9X	KS4A
SAMSUNG	CS29Z4HPBC/DWP	KS3A
SAMSUNG	CS29Z4HPBX/ELT	KS3A(P)_100Hz(REV. 5)
SAMSUNG	CS29Z4HRGX	K55A
SAMSUNG	CS29Z4HRGX/SAP	K55A(P)
SAMSUNG	CS29Z6HEGX/ANB	K55A
SAMSUNG	CS29Z6HEGX/HAC	K55A(P) YOUNGSTAR_Rev.1
SAMSUNG	CS29Z6HEGX/XFA	K55A
SAMSUNG	CS29Z6HEGX/XST	K55A
SAMSUNG	CS29Z6HP	K55A
SAMSUNG	CS29Z7HF	KS4A(P)REV.1

Brand	model	chassis
SAMSUNG	CS29Z7HF9X/XSE	KS4A(P)REV.1
SAMSUNG	CS301BGNV	S51A
SAMSUNG	CS305DNV	S51A
SAMSUNG	CS305DV	S51A
SAMSUNG	CS30A7HTR	SCT53A
SAMSUNG	CS30A9GNV	S51A
SAMSUNG	CS32A10HE	K55A(P)
SAMSUNG	CS3340A	SCT11C
SAMSUNG	CS3403AMNS/XSH	SCT55A
SAMSUNG	CS3403AMNX	SCT55A
SAMSUNG	CS3403AMNX/XSH	SCT55A
SAMSUNG	CS3403ANPX	SCT55A
SAMSUNG	CS3403ANPX/XSH	SCT55A
SAMSUNG	CS3403APX/XSH	SCT55A
SAMSUNG	CS34A10H	S61A
SAMSUNG	CS34A10HEYXXSG	S61A
SAMSUNG	CS34A10HVTXANB	S58A
SAMSUNG	CS34A10HVTXRCH	S58A
SAMSUNG	CS34A10HWGXELE	K55A
SAMSUNG	CS34A11HPGXawe	K55A
SAMSUNG	CS34A11HPGXTAW	K55A
SAMSUNG	CS34A11HPGXUMG	K55A
SAMSUNG	CS34A11HPYXXSG	S61A
SAMSUNG	CS34A20H	S61A
SAMSUNG	CS34A20HUYXXSG	S61A
SAMSUNG	CS34A7HF9X/BWT(S)	KS4A(P)
SAMSUNG	CS34A7HF9X/NWT	KS4A(P)
SAMSUNG	CS34A7HF9X/SML(R)	KS4A(P)
SAMSUNG	CS34A7HF9X/UMG(R)	KS4A(P)
SAMSUNG	CS34A7HF9X/VWT	KS4A(P)
SAMSUNG	CS34A7HF9X/XSG(R)	KS4A(P)
SAMSUNG	CS34Z4HF9X	KS4A
SAMSUNG	CS34Z4HNGX/SMA	K55A(P)
SAMSUNG	CS34Z4HPBX/ELT	KS3A(P)_100Hz(REV. 5)
SAMSUNG	CS34Z4HPBX/TAW	KS3A(P) 50Hz(REV. 5)

Brand	model	chassis
SAMSUNG	CS34Z6HEGX/ANB	K55A
SAMSUNG	CS34Z6HEGX/XFA	K55A
SAMSUNG	CS34Z6HEGX/XST	K55A
SAMSUNG	CS34Z6HF9M/XST	KS4A(P)_Rev.1
SAMSUNG	CS34Z6HRGX/SMA	K55A(P)
SAMSUNG	CS34Z7HWGX/BWT	K55A(P) YOUNGSTAR
SAMSUNG	CS34Z7HWGX/BWT	K55A(P) YOUNGSTAR
SAMSUNG	CS3703AMNX/XSH	SCT55A
SAMSUNG	CS3703AN1X	SCT55A
SAMSUNG	CS3703AN1X/XSH	SCT55A
SAMSUNG	CS3703ANPX/XSH	SCT55A
SAMSUNG	CS3703APNX/XSH	SCT55A
SAMSUNG	CS5038V	S15A
SAMSUNG	CS503ESM0C/AOI	--
SAMSUNG	CS5051Z	P68SM
SAMSUNG	CS5062Z	P68SM
SAMSUNG	CS5066V5X	S15A (?)
SAMSUNG	CS5073Z6X/UMG	S15A
SAMSUNG	CS5085Z	SCT11C (?)
SAMSUNG	CS5099	S51A
SAMSUNG	CS53380TPS	KS7A
SAMSUNG	CS5339Z6X/TAW	S15A
SAMSUNG	CS5366MG0C/HAC	KS1A
SAMSUNG	CS5366MGS0CHAC	KS1A
SAMSUNG	CS5366V5X	S15A (?)
SAMSUNG	CS5399	S51A
SAMSUNG	CS564B	SCT57B
SAMSUNG	CS565...	SCT57B
SAMSUNG	CS567B	SCT57B
SAMSUNG	CS569B	SCT57B
SAMSUNG	CS6202 NX/EIS	SCT12B
SAMSUNG	CS6202NX/EIX	SCT12B (AA41-10586G)
SAMSUNG	CS6230Z	Z66
SAMSUNG	CS6271	Z68
SAMSUNG	CS6271WP	Z70

Brand	model	chassis
SAMSUNG	CS6272PTR	SCT51A
SAMSUNG	CS6277PF	SCT51A
SAMSUNG	CS6277POLX	SCT51A
SAMSUNG	CS627I WP	Z70
SAMSUNG	CS667APTRX	SCT55A
SAMSUNG	CS667APTRX	SCT55A
SAMSUNG	CS7202 NBX/EIS	SCT12B
SAMSUNG	CS7202NBX/EIS	SCT12B (AA41-10586G)
SAMSUNG	CS7202ZB	SCT12B
SAMSUNG	CS721A	SCT52A
SAMSUNG	CS721APF	KCT51A
SAMSUNG	CS721APRF/BWX	SCT52 ?
SAMSUNG	CS721APT	SCT52A
SAMSUNG	CS721APTR	KCT51A
SAMSUNG	CS724A	S51A
SAMSUNG	CS7271	Z68
SAMSUNG	CS7271WP	Z70
SAMSUNG	CS7272	SCT51A
SAMSUNG	CS7277	SCT51A
SAMSUNG	CS7277...	SCT51A
SAMSUNG	CS7277PT	SCT51A
SAMSUNG	CS7277PT/POLX	SCT51A
SAMSUNG	CS727APFX/XSA	SCT55A
SAMSUNG	CS727I WP	Z70
SAMSUNG	CS72D9	S51A
SAMSUNG	CS761BGN2X	SCT57C
SAMSUNG	CS761BGZ2C	SCT57C
SAMSUNG	CS761BN2C	SCT57C
SAMSUNG	CS761BN2X	SCT57C
SAMSUNG	CS761BNT2X	SCT57C
SAMSUNG	CS761BS2C	SCT57C
SAMSUNG	CS761BT2X	SCT57C
SAMSUNG	CS761BZ2C	SCT57C
SAMSUNG	CS761BZ2X	SCT57C
SAMSUNG	CS762POLX	SCT55A

Brand	model	chassis
SAMSUNG	CS767AMTRX	SCT55A
SAMSUNG	CS7830ZP	Z66P
SAMSUNG	CT13352XT	P68...
SAMSUNG	CT1488BLFX/XAX	K15D
SAMSUNG	CT14F26X/AAU	K15A
SAMSUNG	CT14V10MJFXXAX	K15D
SAMSUNG	CT15K2F	KS9A
SAMSUNG	CT15K9MJZX/XTC	KS9A
SAMSUNG	CT17M16F	KS9A
SAMSUNG	CT17M16MQJXXTC	KS9A
SAMSUNG	CT17N11MJZXXTC	KS9A(N)
SAMSUNG	CT2051B2	K20F ?
SAMSUNG	CT2088BWFY/XAX	K15D
SAMSUNG	CT2094	K54
SAMSUNG	CT20F2	K15A
SAMSUNG	CT20F26X/AAU	K15A
SAMSUNG	CT20F3	K15D
SAMSUNG	CT20F3FNY/XAP	K15D ? (AA41-00625E)
SAMSUNG	CT20F3FNY/XAX	K15D
SAMSUNG	CT20V10MN	K15D
SAMSUNG	CT21D8L6X/XTC	K15A
SAMSUNG	CT21H4LFX/XTC	K15D
SAMSUNG	CT21K3W	KS1B
SAMSUNG	CT21K5MQKX/XAX	K57A(N)
SAMSUNG	CT21M16	KS9A
SAMSUNG	CT21M16MJZXXTC	KS9A(N)
SAMSUNG	CT21M20MQJXXTC	KS9A(N)
SAMSUNG	CT21N11	KS9A
SAMSUNG	CT21V10MNFYSTR	K15D
SAMSUNG	CT21V10MQJXXTC	KS9A(N)
SAMSUNG	CT2565	K56XQH (?)
SAMSUNG	CT2571B	K56XQ2 (?)
SAMSUNG	CT2581	K56
SAMSUNG	CT25D4WZ	K51A
SAMSUNG	CT26F6SWX	K15C

Brand	model	chassis
SAMSUNG	CT26F7SWX/XAP	K15C
SAMSUNG	CT2955P	KCT53A
SAMSUNG	CT29D4WZ	K51A
SAMSUNG	CT29K10MQUXXTW	KS7A
SAMSUNG	CT29K12P	KS7A
SAMSUNG	CT29M6WKX/MAM	K57A(N)
SAMSUNG	CT29Z4HDH	K55A(K)
SAMSUNG	CT29Z7HR	K55A
SAMSUNG	CT29Z7PGX/XAX	K55A
SAMSUNG	CT30A9PZX/XTC	K51A
SAMSUNG	CT30D6PZ	K51A
SAMSUNG	CT32A11HDN	K60A
SAMSUNG	CT32A20HDN	K60A
SAMSUNG	CT32Z7P	K55A (?)
SAMSUNG	CT3312V2	CKC50RM01
SAMSUNG	CT331E	K15A
SAMSUNG	CT331EBZX	K15A
SAMSUNG	CT331H	K15A
SAMSUNG	CT331HBX	K15A
SAMSUNG	CT331HBZX	K15A
SAMSUNG	CT331HX	K15A
SAMSUNG	CT3338VC	K15A
SAMSUNG	CT3338ZX	K15A
SAMSUNG	CT3362V	CKC50HM
SAMSUNG	CT3366BZX	K15A
SAMSUNG	CT3373	K15A
SAMSUNG	CT3373BZ	K15A
SAMSUNG	CT3373CA	K1 (BEKO)
SAMSUNG	CT3373CA	K1 08
SAMSUNG	CT3373J	K1 (BEKO)
SAMSUNG	CT3373V	K1 (BEKO)
SAMSUNG	CT3373VB	K1 (BEKO)
SAMSUNG	CT348Z	K50S
SAMSUNG	CT34D2PX/AAU	K51A
SAMSUNG	CT34D2PX/XAX	K51A

Brand	model	chassis
SAMSUNG	CT34Z7P	K55A (?)
SAMSUNG	CT5012V	K50DC ? (CKC50Z ?)
SAMSUNG	CT5012V2	CKC50V (CKC50R ?)
SAMSUNG	CT501EBZX	K15A
SAMSUNG	CT501HX	K15A
SAMSUNG	CT5025J	K50DC (?)
SAMSUNG	CT5027V2	CKC50R
SAMSUNG	CT5029V	CKC50Z
SAMSUNG	CT5038	K15A
SAMSUNG	CT5038G6X/XAP	K15A
SAMSUNG	CT5038V	K1 08
SAMSUNG	CT5038VCS	K1 ?
SAMSUNG	CT5038ZX	K15A
SAMSUNG	CT5039	K15A
SAMSUNG	CT503E	K15A
SAMSUNG	CT5062V	CKC50HM
SAMSUNG	CT5066	K15A
SAMSUNG	CT5066BFX/XAX	K15D
SAMSUNG	CT5066BZX	K15A
SAMSUNG	CT5072	KCT52A
SAMSUNG	CT5072P	KCT52A
SAMSUNG	CT5073	K1 (BEKO)
SAMSUNG	CT5073CA	K1 08
SAMSUNG	CT5345	KCT52A
SAMSUNG	CT5346W	KCT52A
SAMSUNG	CT5372	KCT52A
SAMSUNG	CT5377	KCT52A
SAMSUNG	CT565BZ	K51A
SAMSUNG	CT566BVX/STR	KCT57A
SAMSUNG	CT566BVX/XAP	KCT57A
SAMSUNG	CT566BWX/STR	KCT57A
SAMSUNG	CT566BWZ	K51A
SAMSUNG	CT566BZ	K51A
SAMSUNG	CT567BPZ	K51A
SAMSUNG	CT567BWX/STR	KCT57A

Brand	model	chassis
SAMSUNG	CT567BW/XAP	KCT57A
SAMSUNG	CT567BWZ	K51A
SAMSUNG	CT568BPZ	K51A
SAMSUNG	CT5915V	K51D
SAMSUNG	CT6202	KCT52A
SAMSUNG	CT6331	K52MD
SAMSUNG	CT6332W	K52MD ?
SAMSUNG	CT6335W	K52A2
SAMSUNG	CT6335W/CT	K52A2
SAMSUNG	CT6335WCX	K52A2
SAMSUNG	CT6335WCX/CX	K52A2
SAMSUNG	CT6336W	K52A2
SAMSUNG	CT6336W/CT	K52A2
SAMSUNG	CT6336WCX	K52A2
SAMSUNG	CT6336WCX	K52A2
SAMSUNG	CT6346P	KCT52A
SAMSUNG	CT6346W	KCT52A
SAMSUNG	CT6831W	K52MD ?
SAMSUNG	CT6835W	K52A2
SAMSUNG	CT6835W	K52A2
SAMSUNG	CT6835WCX	K52A2
SAMSUNG	CT6835WCX	K52A2
SAMSUNG	CT6836W	K52A2
SAMSUNG	CT6836W	K52A2
SAMSUNG	CT6836WCX	K52A2
SAMSUNG	CT6836WCX	K52A2
SAMSUNG	CT6846P	KCT52A
SAMSUNG	CT6846W	KCT52A
SAMSUNG	CT6846WC	KCT52A
SAMSUNG	CT7202	KCT52A
SAMSUNG	CT721AP	KCT53A
SAMSUNG	CT721APX/XAX	K56B
SAMSUNG	CT722AP/ADICX	KCT55A
SAMSUNG	CT722AP/AGECX	KCT55A
SAMSUNG	CT722AP/AINCX	KCT55A

Brand	model	chassis
SAMSUNG	CT722AP/ASPCX	KCT55A
SAMSUNG	CT766...	K51A
SAMSUNG	CT766DW	KCT57A
SAMSUNG	CT766DWX/STR	KCT57A
SAMSUNG	CT766DWX/XAP	KCT57A
SAMSUNG	CT766DWZ	K51A
SAMSUNG	CTC43PRO (SP431JMFx)	SPT52A
SAMSUNG	CTC52PRO (SP521JMFx)	SPT52A
SAMSUNG	CTC6346	KCT52B (?)
SAMSUNG	CV28C7VH6	KS3A ?
SAMSUNG	CV29M066V	K55A
SAMSUNG	CW21443NS8	KS3A
SAMSUNG	CW21443NS8XXEU	KS3A(P) (REV. 2)
SAMSUNG	CW21A113N	S56A(P) REV.1
SAMSUNG	CW21A113N5	KS9B
SAMSUNG	CW21A83N	KS3A
SAMSUNG	CW21C33NS8	KS3A ?
SAMSUNG	CW21C33NS8XXEC	KS3A(P) (REV. 2)
SAMSUNG	CW21C33NS8XXEU	KS3A(P) (REV. 2)
SAMSUNG	CW21C33WS8XXEG	KS3A(P) (REV. 2)
SAMSUNG	CW21C73NS8	KS3A
SAMSUNG	CW21C73NS8XXEC	KS3A(P) (REV. 2)
SAMSUNG	CW21C73W	KS3A (?)
SAMSUNG	CW21M023NFXxEC	S16B(P)_GREEN3
SAMSUNG	CW21M063NFXxEC	S16B(P)_GREEN3
SAMSUNG	CW21M063NSXXEU	KS1A
SAMSUNG	CW21M063NZXXEC	KS9A
SAMSUNG	CW21M163N	S16B
SAMSUNG	CW21M163NZXXEC	KS9A(P)
SAMSUNG	CW21M164N	S16B
SAMSUNG	CW21M63NS8	KS3A
SAMSUNG	CW21M63NS8XXEC	KS3A
SAMSUNG	CW21V53N	KS1A
SAMSUNG	CW21Z403NCXXEC	S16D(P)
SAMSUNG	CW21Z413NCXXEC	S16D(P)_TOMORROW

Brand	model	chassis
SAMSUNG	CW21Z453N(R)--Model Code: CW21Z453NI XXEC--Type NO:	S16C(P)_Narnia
SAMSUNG	CW21Z453NLXXEC	S16C(P)_Narnia
SAMSUNG	CW25C33NS8XXEC	KS3A(P) (REV. 2)
SAMSUNG	CW25C33NS8XXEC	KS3A(P) 50Hz(REV. 5)
SAMSUNG	CW25C33NS8XXEU	KS3A(P) (REV. 2)
SAMSUNG	CW25C33W	KS3A(P)50_R5
SAMSUNG	CW25C33WS8	KS3A
SAMSUNG	CW25C33WS8XXEG	KS3A(P) (REV. 2)
SAMSUNG	CW25C33WS8XXEG	KS3A(P)_50Hz(REV. 4)
SAMSUNG	CW25D83N	S56A(P)
SAMSUNG	CW25D83NS8	KS3A(P)_50Hz_REV. 4
SAMSUNG	CW25D83NS8XXEC	KS3A(P)
SAMSUNG	CW25M064N	KS7A
SAMSUNG	CW25M064N2XXEC	S16A(P) GREEN2
SAMSUNG	CW25M064NRX/XEC	KS7A(P) REV.1
SAMSUNG	CW25S33N	KS3A
SAMSUNG	CW28C33NS8	KS3A
SAMSUNG	CW28C33NS8XXEC	KS3A(P) (REV. 2)
SAMSUNG	CW28C33NS8XXEG	KS3A(P) (REV. 2)
SAMSUNG	CW28C33NS8XXEU	KS3A(P) (REV. 2)
SAMSUNG	CW28C73NS8	KS3A(P)_50Hz_REV. 4
SAMSUNG	CW28C73NS8XXEC	KS3A(P) (REV. 2)
SAMSUNG	CW28C73VS8XXEC	KS3A(P) (REV. 2)
SAMSUNG	CW28C73W	KS3A(P)50_R5
SAMSUNG	CW28C73WS8	KS3A
SAMSUNG	CW28C73WS8XXEG	KS3A(P) (REV. 2)
SAMSUNG	CW28C73WS8XXEG	KS3A(P)_50Hz(REV. 4)
SAMSUNG	CW28C75V	KS3A
SAMSUNG	CW28C75VS8	KS3A
SAMSUNG	CW28C75VS8XXEC	KS3A(P) 50Hz(REV.5)
SAMSUNG	CW28C7HG	KS3A
SAMSUNG	CW28C7VDG	KS3A ?
SAMSUNG	CW28C7VH	S53A ?
SAMSUNG	CW28C7VH2X	S53A
SAMSUNG	CW28C7VH2X/XEC	S53A

Brand	model	chassis
SAMSUNG	CW28C7VH2X/XEE	S53A
SAMSUNG	CW28C7VH2X/XEF	S53A
SAMSUNG	CW28C7VH2X/XEG	S53A
SAMSUNG	CW28C7VH2X/XET	S53A
SAMSUNG	CW28C93WS8XXEG	KS3A(P)_50Hz(REV. 4)
SAMSUNG	CW28C95V	KS3A (100Hz)
SAMSUNG	CW28D83N	S56A(P) REV.1
SAMSUNG	CW28D83NS8	KS3A(P)_50Hz_REV. 4
SAMSUNG	CW28D83NSPXXEU	S56A(P) REV.1
SAMSUNG	CW28V055V	K55A (?)
SAMSUNG	CW28V53NS8XXEC	KS3A(P) 50Hz(REV.5)
SAMSUNG	CW28V55VS8XXEC	KS3A(P) 50Hz(REV.5)
SAMSUNG	CW29A1081GXxEC	K55A
SAMSUNG	CW29A1082GXxEC	--
SAMSUNG	CW29A108T	K55A(P)YOUNGSTAR
SAMSUNG	CW29A114N8XXEC	KS3A
SAMSUNG	CW29A114NRXXEC	KS7A
SAMSUNG	CW29A116TGXXEC	K55A(P)
SAMSUNG	CW29A116VGXXEC	K55A(P)
SAMSUNG	CW29A116VNXXEC	S61A
SAMSUNG	CW29A208PYXXEC	S61A
SAMSUNG	CW29A6HA	SCT53A
SAMSUNG	CW29A6VN8X/XEF	KS3A
SAMSUNG	CW29A8HDE9XXEC	KS4A(P)_Rev.1
SAMSUNG	CW29A8VD	KS3A(P)
SAMSUNG	CW29A8VD	KS3A(P)
SAMSUNG	CW29A8VDE	KS3A
SAMSUNG	CW29A8VDE8XXEU	KS3A(P) Rev.2
SAMSUNG	CW29A8VDE9X	KS4A
SAMSUNG	CW29K84N	KS3A
SAMSUNG	CW29K84NS8	KS3A(P)_50Hz_REV. 4
SAMSUNG	CW29K84V	KS3A(P)50_R5
SAMSUNG	CW29K84VS8XXEC	KS3A(P)_50Hz(REV. 4)
SAMSUNG	CW29K86V	KS3A(P)50_R5
SAMSUNG	CW29K86VS8	KS3A

Brand	model	chassis
SAMSUNG	CW29K86VS8XXEC	KS3A(P)_50Hz(REV. 4)
SAMSUNG	CW29K86VS8XXEC	KS3A29K8
SAMSUNG	CW29K86VS8XXEC	KS3A29K8 !
SAMSUNG	CW29M026	S61B
SAMSUNG	CW29M064N2XXEC	S16A(P)_GREEN2
SAMSUNG	CW29M064NPXXEC	S56A(P) Rev.1
SAMSUNG	CW29M064NRXXEC	KS7A
SAMSUNG	CW29M064VPXXEC	S56A(P) Rev.1
SAMSUNG	CW29M064VR	KS7A
SAMSUNG	CW29M064VRXXEC	KS7A
SAMSUNG	CW29M066TGXXEC	--
SAMSUNG	CW29M066V	KS7A (?)
SAMSUNG	CW29M066VGXXEC	K55A(P) Youngstar_Rev.1
SAMSUNG	CW29M164N2XXEC	S16A(P) GREEN2
SAMSUNG	CW29M164NRXXEC	KS7A
SAMSUNG	CW29M164VRXXEC	--
SAMSUNG	CW29M166V7XXEC	S61B(P)_Negotiator2
SAMSUNG	CW29M166VGXXEC	K55A
SAMSUNG	CW29M204NRXXEC	KS7A(P) Rev.1
SAMSUNG	CW29M206PNXXEC	S61 (ECS - UNITED KINGDOM)
SAMSUNG	CW29M206SN	S61A
SAMSUNG	CW29M206SN/VN	S61A Rev.2
SAMSUNG	CW29M206VNXXEC	S61A
SAMSUNG	CW29M64NS8	KS3A(P)_50Hz_REV. 4
SAMSUNG	CW29M64VSPXXEC	S56A
SAMSUNG	CW29M66TSGXXEC	K55A SPIDER_REV.1
SAMSUNG	CW29M66V	K55A(P)
SAMSUNG	CW29M66VS8	KS3A(P)_50Hz_REV. 4
SAMSUNG	CW29M66VS8XXEC	KS3A
SAMSUNG	CW29M66VSGXXEC	K55A(P) 100Hz
SAMSUNG	CW29Z068P	K55A
SAMSUNG	CW29Z068PGXXEC	K55A
SAMSUNG	CW29Z068TGXXEC	K55A
SAMSUNG	CW29Z30	S62B
SAMSUNG	CW29Z306V	S62B

Brand	model	chassis
SAMSUNG	CW29Z306VB	S62B
SAMSUNG	CW29Z308PXXXEC	S63B(P)_Shine2
SAMSUNG	CW29Z338T	S63B
SAMSUNG	CW29Z404NTX/XEC	KS7C
SAMSUNG	CW29Z408PQ	S63A
SAMSUNG	CW29Z408PQXXEC	S63A(P)_Catch Me
SAMSUNG	CW29Z68P	K55A(P)
SAMSUNG	CW29Z68P	K55A(P)
SAMSUNG	CW29Z68PSG	K55A
SAMSUNG	CW29Z68PSGXXEC	K55A(P)
SAMSUNG	CW29Z68T	K55A
SAMSUNG	CW29Z68TSGXXEC	K55A(P)
SAMSUNG	CW30A80SA	SCT53A
SAMSUNG	CW30A90SD	SCT53A
SAMSUNG	CW30A90SD	SCT53A
SAMSUNG	CW30A90ST	SCT53A
SAMSUNG	CW3351S/TH6MX	P64SM(H,H1)
SAMSUNG	CW3382Z1PN6MCX	P69SA1
SAMSUNG	CW3383Z1M16MX	P695A1
SAMSUNG	CW5012	P54SC
SAMSUNG	CW5012X	P64
SAMSUNG	CW5012Z	P54SC
SAMSUNG	CW5026	CP54SC2 ?
SAMSUNG	CW5027	KC15 ?
SAMSUNG	CW5027Z	P54SC1
SAMSUNG	CW5082Z1IWX	P695A1
SAMSUNG	CW5082Z1NW6HX	P695A1
SAMSUNG	CW5082Z1SR6HX	P695A1
SAMSUNG	CW5082ZB1T06HX	P695A1
SAMSUNG	CW5083V	P69SA
SAMSUNG	CW5083Z1HALCCX	P695A1
SAMSUNG	CW5314X	P64SA
SAMSUNG	CW5322KO6HX	P64SA
SAMSUNG	CW5322X/K06HX	P64SA
SAMSUNG	CW533CNG	KS3A

Brand	model	chassis
SAMSUNG	CW533CNG8XXEC	KS3A (REV. 2)
SAMSUNG	CW533CNG8XXEU	KS3A (REV. 2)
SAMSUNG	CW533CNS8XXEU	KS3A (REV. 2)
SAMSUNG	CW533CWG8XXEG	KS3A (REV. 2)
SAMSUNG	CW5344NG8XXEC	KS3A (REV. 2)
SAMSUNG	CW593CN	KS3A
SAMSUNG	CW593CNG	KS3A ?
SAMSUNG	CW593CNG8XXEC	KS3A
SAMSUNG	CW593CWG	KS3A
SAMSUNG	CW593CWG8	KS3A
SAMSUNG	CW593CWG8XXEG	KS3A
SAMSUNG	CW593CWG8XXEG	KS3A
SAMSUNG	CW5944N	KS4A
SAMSUNG	CW5944N8	KS3A
SAMSUNG	CW5944W8	KS3A
SAMSUNG	CW5944W8XXEG	KS3A
SAMSUNG	CW6271	Z68
SAMSUNG	CW6833WT	Z70
SAMSUNG	CW683CNG	KS3A
SAMSUNG	CW683CNG	KS3A
SAMSUNG	CW683CNG8	KS3A
SAMSUNG	CW683CNG8XXEC	KS3A
SAMSUNG	CW6844N	S51A ?
SAMSUNG	CW6844N8XXEF	KS3A
SAMSUNG	CW7271	Z68
SAMSUNG	CW764AHA	SCT53A
SAMSUNG	CW764AHD	SCT53A
SAMSUNG	CW764AHDX	SCT53A
SAMSUNG	CW767AHD	SCT53A
SAMSUNG	CW767AHP1X	SCT53A
SAMSUNG	CW767AHPT	SCT53A
SAMSUNG	CX28C7VD3X/XEG	S51A
SAMSUNG	CX28C7VD3X/XET	S51A
SAMSUNG	CX28C7VN3X/XEE	S51A
SAMSUNG	CX28C7VW3X/PAR	S51A

Brand	model	chassis
SAMSUNG	CX28C7W3X	S51A
SAMSUNG	CX3312SGX	P54SC
SAMSUNG	CX338RSD	P54
SAMSUNG	CX346ZSE	P54
SAMSUNG	CX386ZSE	P54S
SAMSUNG	CX5012Z	P58SC ?
SAMSUNG	CX5012ZQ	P54SC1
SAMSUNG	CX5013T	P68ST
SAMSUNG	CX5013Z	P58SC ? (pono NIE)
SAMSUNG	CX512ZSE	P54S
SAMSUNG	CX528ZSE	P54S
SAMSUNG	CX5314XT/EUROX	P68T
SAMSUNG	CX5322T	P58SC
SAMSUNG	CX5323W	P88MH
SAMSUNG	CX5324W	P88MT
SAMSUNG	CX5324XT	P68T
SAMSUNG	CX5326SGX	P88MH
SAMSUNG	CX532WT	P88MT (?)
SAMSUNG	CX5330AN	US60A
SAMSUNG	CX5330AN	US60A ?
SAMSUNG	CX5330SGX	US60A
SAMSUNG	CX5344W	S51A
SAMSUNG	CX5344W	SCT12A/B
SAMSUNG	CX5370AW	US60A
SAMSUNG	CX538WT	P88MT
SAMSUNG	CX542ZSE	P54S
SAMSUNG	CX558WT	P58MT ?
SAMSUNG	CX558WT	P88MT
SAMSUNG	CX5839BN	Z70
SAMSUNG	CX5913W	25P88MT
SAMSUNG	CX5933WT	S60MT (SM60T, SM60MT)
SAMSUNG	CX5935T	P70
SAMSUNG	CX5935Z	P70
SAMSUNG	CX5937AN	SCT12B
SAMSUNG	CX5939NP	Z70

Brand	model	chassis
SAMSUNG	CX593CN	SCT12B
SAMSUNG	CX593CW	SCT12B
SAMSUNG	CX5944N	SCT12B
SAMSUNG	CX5944N3X/XEC	S51A
SAMSUNG	CX6202	SCT12B
SAMSUNG	CX6226W	S60MT
SAMSUNG	CX6226WT	S60TOP
SAMSUNG	CX6229MT	P88MS
SAMSUNG	CX6229T	P72
SAMSUNG	CX6229Z/AMRX	P72
SAMSUNG	CX6230ZN	U88MT
SAMSUNG	CX6237AW	SCT12B
SAMSUNG	CX6239BW	Z70
SAMSUNG	CX623CN	SCT12B
SAMSUNG	CX623CW	SCT12B
SAMSUNG	CX6271	Z68
SAMSUNG	CX630W	P61TS
SAMSUNG	CX6335T	P70
SAMSUNG	CX6813W	P88
SAMSUNG	CX6833WT	S60MT (SM60T, SM60MT)
SAMSUNG	CX6835T	P70
SAMSUNG	CX6835Z	P70
SAMSUNG	CX6837AN	SCT12B ?
SAMSUNG	CX6837AN	Z68
SAMSUNG	CX6837AW	Z68
SAMSUNG	CX6839BN	Z70
SAMSUNG	CX6839BNVF7SX	Z70
SAMSUNG	CX6839BW	Z70
SAMSUNG	CX6839BWVT7SX	Z70
SAMSUNG	CX6839NPVF7SX	Z70
SAMSUNG	CX683CN	SCT12B
SAMSUNG	CX683CN8XXEC	KS3A
SAMSUNG	CX683CNG	HA99
SAMSUNG	CX683CNG3XXEC	S51A
SAMSUNG	CX683CW	SCT12B

Brand	model	chassis
SAMSUNG	CX683CW3X/XEG	S51A
SAMSUNG	CX683CWG3XXEG	S51A
SAMSUNG	CX6840	Z68
SAMSUNG	CX6840AW	Z68
SAMSUNG	CX6840AW	Z68
SAMSUNG	CX6840W	S51A
SAMSUNG	CX6840W	SCT12B
SAMSUNG	CX6844N	S51A ?
SAMSUNG	CX6844N3X	S51A
SAMSUNG	CX6844N3X/XEE	S51A
SAMSUNG	CX6844W	SCT12B
SAMSUNG	CX6844W	SCT12B ?
SAMSUNG	CX6844W3X	S51A
SAMSUNG	CX6844W3X/PAR	S51A
SAMSUNG	CX6844W3X/XEG	S51A
SAMSUNG	CX6844W3X/XET	S51A
SAMSUNG	CX685W	P61TS
SAMSUNG	CX7000	S60MT (SM60T, SM60MT)
SAMSUNG	CX7000	S60MT (SM60T, SM60MT)
SAMSUNG	CX7037AW	SCT12B
SAMSUNG	CX703CN	SCT12B
SAMSUNG	CX703CW	SCT12B
SAMSUNG	CX7202	SCT12B
SAMSUNG	CX7226	P88MH
SAMSUNG	CX7226W	S60MT
SAMSUNG	CX7226WT	S60MT (SM60T, SM60MT)
SAMSUNG	CX7226WT	S60MT (SM60T, SM60MT)
SAMSUNG	CX724AHD	SCT53A
SAMSUNG	CX7271	Z68
SAMSUNG	CX8640W	Z68
SAMSUNG	CXJ0932AX	V15B(REV.1)
SAMSUNG	CXJ0933AX	V15B(REV.1)
SAMSUNG	CXJ1331AX	V15A(REV.2)
SAMSUNG	CXJ1352AX	V15A(REV.2)
SAMSUNG	CXJ1364AX	V15A(REV.2)

Brand	model	chassis
SAMSUNG	CXJ1372AX	V15B(REV.1)
SAMSUNG	CXJ1931AX	V15A(REV.2)
SAMSUNG	CXJ1952AX	V15A(REV.2)
SAMSUNG	CXJ1964AX	V15A(REV.2)
SAMSUNG	CXJ1964BX	V15A
SAMSUNG	CZ14F12T	KS1A
SAMSUNG	CZ14V10	KS1A(P)REV.2
SAMSUNG	CZ14Y52TS	KS1A
SAMSUNG	CZ15K2TWX	KS1A
SAMSUNG	CZ20732	KS1A
SAMSUNG	CZ20F12T	KS1A (AA41-00131G)
SAMSUNG	CZ20F12TSX	KS1A
SAMSUNG	CZ20F32T	KS1A
SAMSUNG	CZ20F32TSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ20F32ZSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ20F42TS	KS1A
SAMSUNG	CZ20F42ZSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ20H12TSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ20H32TS	KS1A
SAMSUNG	CZ20H42TSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ20V102T	KS1A ?
SAMSUNG	CZ2122T	KA1A
SAMSUNG	CZ21732TGXXEH	KS1A
SAMSUNG	CZ21792T	KS1A (?)
SAMSUNG	CZ2179T	KS1A
SAMSUNG	CZ21A083N	KS1A
SAMSUNG	CZ21A8VN	KS3A ?
SAMSUNG	CZ21A8VW8X	KS2A(N)
SAMSUNG	CZ21C71NSD	KS1B(P)
SAMSUNG	CZ21D83	KS1A ?
SAMSUNG	CZ21F12T	KS1A
SAMSUNG	CZ21F12TS	KS1A
SAMSUNG	CZ21F32TSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ21F32ZSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ21F52TSXXEH	KS1A(P)_Rev.1

Brand	model	chassis
SAMSUNG	CZ21F62T	KS1A ?
SAMSUNG	CZ21H12T	KS1A(P)
SAMSUNG	CZ21H12TSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ21H42T	KS1A
SAMSUNG	CZ21H42TSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ21K22T	KS1B
SAMSUNG	CZ21K22T	KS1B(P)
SAMSUNG	CZ21K22T	KS1B(P)
SAMSUNG	CZ21K22TSDXXEH	KS1B(P)
SAMSUNG	CZ21K22TSXXEH	KS1A
SAMSUNG	CZ21K5MJ	KS9A
SAMSUNG	CZ21M063N	KS1A
SAMSUNG	CZ21M163NZXXEH	KS9A(P)
SAMSUNG	CZ21M203N	KS9A ?
SAMSUNG	CZ21M63N	KS1A
SAMSUNG	CZ21N112T	KS9A(P)
SAMSUNG	CZ21N112TZXXEH	KS9A(P)
SAMSUNG	CZ21S43NSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ21V53NSXXEH	KS1A(P)_Rev.1
SAMSUNG	CZ25D83	S56A
SAMSUNG	CZ28D83N	S56A(P)
SAMSUNG	CZ28V53N	S56A
SAMSUNG	CZ29A6VD8X/XET	KS3A
SAMSUNG	CZ29A6VN8X/XEC	KS3A
SAMSUNG	CZ29A6VN8X/XEP	KS3A
SAMSUNG	CZ29A6W8X	KS3A
SAMSUNG	CZ29A6W8X/BOB	KS3A
SAMSUNG	CZ29A6W8X/EUP	KS3A
SAMSUNG	CZ29D8W7X	KS2A
SAMSUNG	CZ29M64N	S56A(P)
SAMSUNG	CZ5319Z	Z54W ?
SAMSUNG	CZ593CWG8	KS3A
SAMSUNG	CZ5944N3X	S51A
SAMSUNG	CZ5944W8X	KS3A
SAMSUNG	CZ683CWG8X	KS3A

Brand	model	chassis
SAMSUNG	CZ6844CNX	S51A
SAMSUNG	CZ6844N	KS3A
SAMSUNG	CZ6844N8XXEC	KS3A
SAMSUNG	CZ6844N8XXEH	KS3A
SAMSUNG	CZ6844W8X	KS3A
SAMSUNG	D-CK50132	P58SC
SAMSUNG	DW215VDX	C16A
SAMSUNG	DW21G5VDX	C16A
SAMSUNG	DW21G5VDX/BWT	C16A
SAMSUNG	DW21G5VDX/BWT	C16A
SAMSUNG	DW21G5VDX/NWT	C16A
SAMSUNG	DW21G5VDX/VWT	C16A
SAMSUNG	DW21G5VDX/XEF	C16A
SAMSUNG	DW21G5VDX/XEG	C16A
SAMSUNG	DW21G5VDX/XEN	C16A
SAMSUNG	GB5314AT	P68SA
SAMSUNG	HCH551WX	APT52A
SAMSUNG	HCJ552WX/XAA	P51A
SAMSUNG	HCM553W	ST54T8P-P55A
SAMSUNG	HCN4226WS/XAA	P55A
SAMSUNG	HCN4727W	ST54T8P-P55A
SAMSUNG	HCN5527W	ST54T8P-P55A
SAMSUNG	HCN5527WX/XAA	P55A(N) REV.1
SAMSUNG	HCN553W	ST54T8P-P55A
SAMSUNG	HCN553WX/XAC	P55A(N) REV.1
SAMSUNG	HCP4363WX/XAA	P61A
SAMSUNG	HCP4363WX/XAC	P61A
SAMSUNG	HCP5256WX/XAA	P58B
SAMSUNG	HL-S4266WX/XAA	L64D (?)
SAMSUNG	HLM617W	L62A
SAMSUNG	HLM617W	L62A
SAMSUNG	HLM617WX/XAA	L62A
SAMSUNG	HLM617WX/XAA	L62A
SAMSUNG	K14F1Z5X/XEH	S15A
SAMSUNG	KS32Z48V	KS2A rev 01

Brand	model	chassis
SAMSUNG	KXH1972	K15A
SAMSUNG	LA23R51B	RE23SO
SAMSUNG	LA26R51B	RE26SO
SAMSUNG	LA32M51B	GML32KS
SAMSUNG	LA32M61B	GMN32KS
SAMSUNG	LA32R51B	RE32SO
SAMSUNG	LA40M51B	GML40KS
SAMSUNG	LA40M61B	GMN40KS
SAMSUNG	LA40R51B	RE40SO
SAMSUNG	LA46M51B	GML46KS
SAMSUNG	LE15E31SX/XEC	AE15E
SAMSUNG	LE15S51BP	GPU15KE
SAMSUNG	LE20S51BP	GPU20KE
SAMSUNG	LE23R31S	RE23EO
SAMSUNG	LE23R32B	GRM23HEU
SAMSUNG	LE23R41B	GRO23KE
SAMSUNG	LE23R51B	RE23EO
SAMSUNG	LE23R86BD	GBP23SEN
SAMSUNG	LE23R87BD	GBP23SEN
SAMSUNG	LE23T51B	GTR23KE
SAMSUNG	LE23T51B	GTR23KE
SAMSUNG	LE26M51B	GML26KE
SAMSUNG	LE26R31S	RE26EO
SAMSUNG	LE26R32B	GRM26HEU
SAMSUNG	LE26R41B	GRO26KE
SAMSUNG	LE26R51B	RE26EO
SAMSUNG	LE26R71B	GBD26KE
SAMSUNG	LE26R72B	GBR26KE
SAMSUNG	LE26R73BD	GLY26KE
SAMSUNG	LE26R74BD	GLY26KE
SAMSUNG	LE26R75B	GBD26KE
SAMSUNG	LE26R86BD	GBP26SEN
SAMSUNG	LE26R87BD	GBP26SEN
SAMSUNG	LE26S81BX	GJA26SEU
SAMSUNG	LE26S86BD	GJA26SEU

Brand	model	chassis
SAMSUNG	LE27S73BD	GSD27SEN
SAMSUNG	LE27T51B	GTR27KE
SAMSUNG	LE27T51B	GTR27KE
SAMSUNG	LE32M51B	GML32KE
SAMSUNG	LE32M61B	GML32KE
SAMSUNG	LE32R41B	GRO32KE
SAMSUNG	LE32R51B	RE32EO
SAMSUNG	LE32R52B	RE32EO
SAMSUNG	LE32R53B	RE32EO
SAMSUNG	LE32R71B	GBD32KE
SAMSUNG	LE32R72B	GBR32KE
SAMSUNG	LE32R73BD	GLY32KE
SAMSUNG	LE32R74BD	GLY32KE
SAMSUNG	LE32R75B	GBD32KE
SAMSUNG	LE32R76B	GBD32KE
SAMSUNG	LE32R81BX	GBP32SEN
SAMSUNG	LE32R82BX	GBP32SEN
SAMSUNG	LE32R86BD	GBP32SEN
SAMSUNG	LE32R86BD	GBP32SEN
SAMSUNG	LE32S66BD	GSD32HEU
SAMSUNG	LE32S73BD	GSD32HEU
SAMSUNG	LE32S74BD	GSD32HEU
SAMSUNG	LE32S81BX	GJA32SEU
SAMSUNG	LE32S86BD	GJA32SEU
SAMSUNG	LE32T51B	GTR32KE
SAMSUNG	LE32T51B	GTR32KE
SAMSUNG	LE37M86BDX	GTU37SEN
SAMSUNG	LE37R41B	GRO37KE
SAMSUNG	LE37R72B	GBR37KE
SAMSUNG	LE37R74BD	GLY37KE
SAMSUNG	LE37R81BX	GBP37SEN
SAMSUNG	LE37R86BD	GBP37SEN
SAMSUNG	LE37R87BD	GBP37SEN
SAMSUNG	LE37R88BD	GBP37SEN
SAMSUNG	LE37S73BD	GSD37SEN

Brand	model	chassis
SAMSUNG	LE37S81BX	GJA37SEU
SAMSUNG	LE40M51B	GML40KE
SAMSUNG	LE40M61B	GML40KE
SAMSUNG	LE40M86BDX	GTU40SEN
SAMSUNG	LE40M91B	GMD40SEU
SAMSUNG	LE40R51B	RE40EO
SAMSUNG	LE40R71B	GBD40KE
SAMSUNG	LE40R72B	GBR40KE
SAMSUNG	LE40R73BD	GLY40KE
SAMSUNG	LE40R74BD	GLY40KE
SAMSUNG	LE40R75B	GBD40KE
SAMSUNG	LE40R76B	GBD40KE
SAMSUNG	LE40R82BX	GBP40SEN
SAMSUNG	LE40R86BD	GBP40SEN
SAMSUNG	LE40R87BD	GBP40SEN
SAMSUNG	LE40R88BD	GBP40SEN
SAMSUNG	LE40S73BD	GSD40SEN
SAMSUNG	LE40S81BX	GJA40SEU
SAMSUNG	LE40S86BD	GJA40SEU
SAMSUNG	LE46M51B	GML46KE
SAMSUNG	LE46M53BD	GMT46SE
SAMSUNG	LE46M86BDX	GTU46SEN
SAMSUNG	LE46S81BX	GJA46SEU
SAMSUNG	LE52M86BDX	GTU52SEN
SAMSUNG	LN-T3253H	SN04
SAMSUNG	LS15E33C	AS15SO
SAMSUNG	LS15E33CS/XTT	AS15C
SAMSUNG	LS15M13CX/SHI	MU15S
SAMSUNG	LS15M13CX/XSV	MU15S
SAMSUNG	LS17E34C	AS17SO
SAMSUNG	LT-P266W	NF26UO
SAMSUNG	LT17N23W	VR17JO
SAMSUNG	LT22A13W	PD22JO
SAMSUNG	LTM150XH	L06
SAMSUNG	LTM295W	AL29NO

Brand	model	chassis
SAMSUNG	LTM405W	AL40NO
SAMSUNG	LTN1565X/XAC	--
SAMSUNG	LTN1785WX/XAC	--
SAMSUNG	LTP1795WX/XAC	VR17U
SAMSUNG	LTP2045UX/RCL	VC20U
SAMSUNG	LW15E23CBX/XET	ES15E
SAMSUNG	LW15E33CC/XEC	AS15E
SAMSUNG	LW15M13CS/XEC	MU15E
SAMSUNG	LW15M13CS/XEU	--
SAMSUNG	LW15M23	VE15
SAMSUNG	LW15M23CP	GPL15KE
SAMSUNG	LW15M23CS/XEC	VE15E
SAMSUNG	LW15M25CP	GPL15KE
SAMSUNG	LW17E24CBX/FES	ES17E
SAMSUNG	LW17E34CX/BWT	AS17E
SAMSUNG	LW17M24C	VC17EO
SAMSUNG	LW17M24CP	GPL17KE
SAMSUNG	LW17M24CS/XEC	--
SAMSUNG	LW20M11CS/XEC	MU20E
SAMSUNG	LW20M11CX/XEE	MU20E
SAMSUNG	LW20M21C	VE20EO
SAMSUNG	LW20M21CP	GPL20KE
SAMSUNG	LW20M21CS/XEC	--
SAMSUNG	LW20M25CP	GPL20KE
SAMSUNG	LW22 N23N	VR22EO
SAMSUNG	LW22A13WDS/XEC	P222E
SAMSUNG	LW22A13WX/FES	PD22E
SAMSUNG	LW26A33WS/XEC	NF26E
SAMSUNG	LW29A13W	AL29AO
SAMSUNG	LW29A13WX	AL29AO
SAMSUNG	LW29A15W	AL29A0
SAMSUNG	LW32A23W	VN32EO/VN40EO
SAMSUNG	LW32A23W	VN32EO/VN40EO
SAMSUNG	LW32A23WX/XEE	VN32E
SAMSUNG	LW40A13W	AL40AO

Brand	model	chassis
SAMSUNG	LW40A13W	AL40AO
SAMSUNG	LW40A23W	VN32EO/VN40EO
SAMSUNG	LW40A23W	VN32EO/VN40EO
SAMSUNG	P4241W	P60A ?
SAMSUNG	PCL541RX/XAA	P51A(Rev_1)
SAMSUNG	PCL542RX/XAA	P51A(Rev_1)
SAMSUNG	PCN5425RXSCXAA	P55A(N) REV.1
SAMSUNG	PDP4294	D54B(N)
SAMSUNG	PL42P3S	D54B(N)
SAMSUNG	PL42P3SX/XTW	D54B
SAMSUNG	PL50P3HX/XTW	D56A
SAMSUNG	PL63P3HX/XTW	D57A
SAMSUNG	PLH403WC/XAA	L52A
SAMSUNG	PLH403WX/XAA	L52A
SAMSUNG	PLH403WX/XAC	L52A
SAMSUNG	PPM42M5SSX/XSS	D71B
SAMSUNG	PPM42S3	D61A(N)
SAMSUNG	PPM42S3QX	D61B
SAMSUNG	PPM42S3QX/XEU	D61B
SAMSUNG	PPM42S3X	D61A(N)
SAMSUNG	PPM42S3X/XEU	D61A(N)
SAMSUNG	PPM50H3QX/EDC	D62B
SAMSUNG	PS37S4AX/XEC	D68A
SAMSUNG	PS42D4SKX/XEC	D65C
SAMSUNG	PS42D4STX/XTC	D65C
SAMSUNG	PS42D4SX/XEC	D65C
SAMSUNG	PS42D5S	D72A
SAMSUNG	PS42P2SDX	D53A
SAMSUNG	PS42P2ST	D53A_TTX
SAMSUNG	PS42P3SX	D58A
SAMSUNG	PS42P4A1X/XEC	D68A(P)Europe42”_DNle3
SAMSUNG	PS42P7HDX/XET	D74F(P_Europe_42HD)_Himalaya
SAMSUNG	PS42S4S1X/XEC	D65A
SAMSUNG	PS42S4SS/XEC	D65A
SAMSUNG	PS42V4SKX/XEC	D65C

Brand	model	chassis
SAMSUNG	PS42V6SX/XEH	D73A(P)_Twister
SAMSUNG	PS50C7HX/XEH	D74A(P_Europe_50HD)_Audi
SAMSUNG	PS50D7HDX/XSA	D72B(P_Asia_50HD)_Jaguar
SAMSUNG	PS50P3H	D59A(P)
SAMSUNG	PS50P4H1X/XSA	D68A(P)ASIA50"_DNle3
SAMSUNG	PS50P4H1X/XTL	D68A(P)ASIA50"_DNle3
SAMSUNG	PS50P5HX/RAD	D72C(P)_BACH_50
SAMSUNG	PS63P3H	D60A(P)
SAMSUNG	PS63P3HX/XSA	D60A(P)REV.1
SAMSUNG	PS63P3HX/XSE	D60A(P)REV.1
SAMSUNG	PT4298HD	P55A(N_Rev.1)
SAMSUNG	S15E33CS/XTT	AS15C
SAMSUNG	SAM29Z30	S65A
SAMSUNG	SC5385Z	SCT11A
SAMSUNG	SMC152FP/XEVV	KS5B
SAMSUNG	SP403JHAX	PLT51A
SAMSUNG	SP40J5HAX	M51A
SAMSUNG	SP42W4HBX/XEU	J54A_C2.0
SAMSUNG	SP42W4HLS/XEC	J60A
SAMSUNG	SP42W4HLX/XEC	J60A
SAMSUNG	SP42W5HF	J52A(P)REV.4
SAMSUNG	SP42W5HF1X	J54A
SAMSUNG	SP42W5HFX	P54A/J52A
SAMSUNG	SP434JMFx	SPT52A
SAMSUNG	SP434JMFx/SAP	SPT52A
SAMSUNG	SP43H3HTX	J61A
SAMSUNG	SP43J5HFX	J51A
SAMSUNG	SP43J5HFX/RAD	J51A
SAMSUNG	SP43J5HFX/RAD	J51A(REV. 1)
SAMSUNG	SP43J5HFX/SED	J51A(REV. 1)
SAMSUNG	SP43J5HFX/SED	J51A(REV. 1)
SAMSUNG	SP43J5HP3C	J51A
SAMSUNG	SP43J6HDR	M51A
SAMSUNG	SP43J6HDX	M51A
SAMSUNG	SP43R1HL1X/XEC	J60B

Brand	model	chassis
SAMSUNG	SP43T7HCX/ANB	J54A(P)_C2.0
SAMSUNG	SP43T7HFX/XEC	P55A (AA41-00601B)
SAMSUNG	SP43T7HL1X/HAC	J60B(P)
SAMSUNG	SP43T7HP	J54A(P)C1.5
SAMSUNG	SP43T7HPX	J54A
SAMSUNG	SP43T7HPX/XEG	J54A
SAMSUNG	SP43T7HXX/XTT	J53A(P)
SAMSUNG	SP43T8HEX/HAC	J59A
SAMSUNG	SP43T8HF	J54A_C2.0
SAMSUNG	SP43T8HF	J54A_C2.0
SAMSUNG	SP43T8HL	J60A (?)
SAMSUNG	SP43T8HP	J54A(P)C1.5
SAMSUNG	SP43T8HPX/XEC	J54A
SAMSUNG	SP43W6HF	J54A_C2.0
SAMSUNG	SP43W6HFR	J54A_C2.0
SAMSUNG	SP43W6HFR	J54A_C2.0
SAMSUNG	SP43W6HFX/BOB	J54A(P)_C2.0
SAMSUNG	SP46L5H	J63A
SAMSUNG	SP46L5HRX/XTT	L63A(P)_Rev.1
SAMSUNG	SP46L5HX/XEC	L63A(P)
SAMSUNG	SP46L5HX/XEH	L63A(P)_Rev.1
SAMSUNG	SP47Q5HL1X/XAX	P60B(N)_Omega2
SAMSUNG	SP47Q7HFR	J54A_C2.0
SAMSUNG	SP47W3HF1X/BOB	J54A_C2.0
SAMSUNG	SP47W3HFX	J52A
SAMSUNG	SP47W3HFX/XET	J52A
SAMSUNG	SP48T6HP	J54A(P)C1.5
SAMSUNG	SP50K3HDX/XAX	L64D(N_Rev.1)_ Einstein
SAMSUNG	SP50L6HV1X/XEC	M63A(P)_Nobel_Europe_Rev.1
SAMSUNG	SP524JMFx/MUR	SPT52A
SAMSUNG	SP524JMTRX	SPT52A
SAMSUNG	SP53J5HFX	J51A
SAMSUNG	SP53J5HFX/RAD	J51A
SAMSUNG	SP53J5HFX/RAD	J51A(REV. 1)
SAMSUNG	SP54T6HXX/XTT	J53A(P)

Brand	model	chassis
SAMSUNG	SP54T8HLX/AWE	J60A(P)
SAMSUNG	SP54T8HLX/XSA	J60A(P)
SAMSUNG	SP54T8HLX/XTC	J60A
SAMSUNG	SP55W3HF	J52A(P)REV.4
SAMSUNG	SP55W3HF	J52A(P)REV.4
SAMSUNG	SP55W3HF	J54A_C2.0
SAMSUNG	SP61J5HFX/RAD	J51A
SAMSUNG	SP61J5HFX/RAD	J51A(REV. 1)
SAMSUNG	SP61L2HX	L63A(P)
SAMSUNG	SP61L2HX	L63A(P)
SAMSUNG	SP62T6HXX/XTT	J53A(P)
SAMSUNG	SP62T8HE	J59A
SAMSUNG	SPM4388PTR	SPT51A
SAMSUNG	SPM5288PF	SPT51A v.1
SAMSUNG	SPM5288PTR	SPT51A
SAMSUNG	ST47W3PSX/XAX	P54A (?)
SAMSUNG	ST54T8PCX/XAX	P55A(N) REV.1
SAMSUNG	ST55W3PC	P55A(N_Rev.1)
SAMSUNG	ST61L2HD	L62A(N)
SAMSUNG	ST62T8PCX/GSU	P55A
SAMSUNG	SVP46L5HXN1	L62A(K_Rev.2)
SAMSUNG	SVP481HR	P55A(K)
SAMSUNG	SVP50L2HXN	L62A(K_Rev.2)
SAMSUNG	SVP541HR	P55A(K)
SAMSUNG	SVP56L5HXN1	L62A(K_Rev.2)
SAMSUNG	TB14C52S	S15A
SAMSUNG	TB14C52S/XEC	C15A
SAMSUNG	TB14C5DT2S/XET	C15A
SAMSUNG	TB14C5S2S/XEG	C15A
SAMSUNG	TB14C5T2S	S15A
SAMSUNG	TB14C5T2S/XEC	C15A
SAMSUNG	TB15X5	C17A(P)
SAMSUNG	TB20C52S	S15A
SAMSUNG	TB20C52S/XET	C15A
SAMSUNG	TB20C5DF2S/XEG	C15A

Brand	model	chassis
SAMSUNG	TB20C5DF2S/XET	C15A
SAMSUNG	TB20C5DT2S	S15A
SAMSUNG	TB20C5DT2S/XEC	C15A
SAMSUNG	TB21B5DF2S	S15A
SAMSUNG	TB21B5DF2S/XEC	C15A
SAMSUNG	TB331VBZ1S/XEG	SCV11F
SAMSUNG	TB331VDT1S	SCV11F
SAMSUNG	TB331VDT1S/XEC	SCV11F
SAMSUNG	TB331VDZ1S/XEC	SCV11F
SAMSUNG	TB331VDZ1S/XSA	SCV11F
SAMSUNG	TB501VAT1S	SCV11F
SAMSUNG	TB501VAT1S/XEG	SCV11F
SAMSUNG	TB501VCT1S/XEC	SCV11F
SAMSUNG	TB501VDZ1S/XET	SCV11F
SAMSUNG	TB531VAT1S/XEC	SCV11F
SAMSUNG	TB531VCT1X	SCV11F
SAMSUNG	TB531VCT1X/XSA	SCV11F
SAMSUNG	TC29J6MN	V18B(N)
SAMSUNG	TC29J6MNX	V18B
SAMSUNG	TC3833TB	K50UC ?
SAMSUNG	TCD1341	CKA50ZM
SAMSUNG	TE14N53X/XEU	C15C
SAMSUNG	TF14N34XEF	C17A
SAMSUNG	TF14P64X/XEF	C17A (TS10)
SAMSUNG	TF20C53X/XEF	C15C
SAMSUNG	TF50P1D	C17A(P)
SAMSUNG	TI14N34X/XEU	C17A (TS10)
SAMSUNG	TI14N54X/XEU	C17A (TS10)
SAMSUNG	TI14P1DF4X/XEC	C17A
SAMSUNG	TI14P1DF4X/XEU	C17A (TS10)
SAMSUNG	TI14P74X/XEU	C17A (TS10)
SAMSUNG	TI14P94X/XEU	C17A (TS10)
SAMSUNG	TI20P1DF4X/XEU	C17A (TS10)
SAMSUNG	TI20P5DF4X/XEU	C17A (TS10)
SAMSUNG	TP29J10	V18B(N)

Brand	model	chassis
SAMSUNG	TP29J10XX/AAU	V18B ?
SAMSUNG	TSK2790FX/XAA	KS4A(N)
SAMSUNG	TSK2792FX/XAA	KS4A(N)
SAMSUNG	TSK2792FX/XAC	KS4A(N)
SAMSUNG	TSK3092WFX/XAA	KS4A(N)
SAMSUNG	TSK3092WFX/XAC	KS4A(N)
SAMSUNG	TSK3290FX/XAA	KS4A(N)
SAMSUNG	TSK3292FX/XAA	KS4A(N)
SAMSUNG	TSK3292FX/XAC	KS4A(N)
SAMSUNG	TSL2795HFX/XAA	KS4A(N)
SAMSUNG	TSL3099WF/XAA	K54A(P)
SAMSUNG	TSL3294HFX/XAA	KS4A(N)
SAMSUNG	TSL3295HFX/XAA	KS4A(N)
SAMSUNG	TT14A54X/XAX	V15A
SAMSUNG	TT20A54X/GSU	V15A
SAMSUNG	TT20A54X/RCL	V15A
SAMSUNG	TT20A54X/XAX	V15A
SAMSUNG	TTB1340W	CKA50ZM
SAMSUNG	TV-CX3351	E5
SAMSUNG	TV-CX5051	E5
SAMSUNG	TV486	SCT11B
SAMSUNG	TV6861	SCT12A
SAMSUNG	TVCR4500SGX	P58M
SAMSUNG	TVP3350	SCV11A
SAMSUNG	TVP3360X	SCV11D
SAMSUNG	TVP3370X	PS14A (?)
SAMSUNG	TVP5050	SCV11A
SAMSUNG	TVP5050IST	SCV11A
SAMSUNG	TVP5050X	SCV11
SAMSUNG	TVP5050XST	SCV11
SAMSUNG	TVP5050XT	SCV11
SAMSUNG	TVP5070	PS14
SAMSUNG	TVP5350	SCV11A
SAMSUNG	TVP5350XST	SCV11
SAMSUNG	TW14C52S	C15A

Brand	model	chassis
SAMSUNG	TW14N63/BWT	C15C (Rev2)
SAMSUNG	TW20C5DR	C15A
SAMSUNG	TW20P1DR	C17A(P)
SAMSUNG	TWP5350WR	SCV11A
SAMSUNG	TX-C2515	K52A2
SAMSUNG	TX-C2516	K52A2
SAMSUNG	TX-C2715	K52A2
SAMSUNG	TX-C2716	K52A2
SAMSUNG	TX-R3079WH	S62A
SAMSUNG	TX14B3F3X/SEC	C15C
SAMSUNG	TX14B73X	C15C
SAMSUNG	TX14C32X/AMF	SCV11F ?
SAMSUNG	TX14C9	C15A
SAMSUNG	TX14N34X/XET	C17A (TS10)
SAMSUNG	TX14N3DF3X/XEG	C15C (Rev2)
SAMSUNG	TX14N3DF4X/XET	C17A
SAMSUNG	TX14N3DF4X/XET	C17A (TS10)
SAMSUNG	TX14N3F3X	C15C
SAMSUNG	TX14N3F3X/NSI	C15C (Rev2)
SAMSUNG	TX14N53X	C15C
SAMSUNG	TX14N53X/SEC	C15C (Rev2)
SAMSUNG	TX14N53X/XEE	C15C (Rev2)
SAMSUNG	TX14N5F3X	C15C
SAMSUNG	TX14N5F3X/SEC	C15C (Rev2)
SAMSUNG	TX14N73X/XEN	C15C (Rev2)
SAMSUNG	TX14N7F3X/SEC	C15C (Rev2)
SAMSUNG	TX14P14X	C17A
SAMSUNG	TX14P1DF	C17A ?
SAMSUNG	TX15X5F	C15C
SAMSUNG	TX20C33X/XET	C15C
SAMSUNG	TX20C3DF3X/XET	C15C
SAMSUNG	TX20C53X	C15C
SAMSUNG	TX20C5DF	C15C
SAMSUNG	TX20C5DF3X/SEC	C15C
SAMSUNG	TX20P11	KS9A

Brand	model	chassis
SAMSUNG	TX20P1DF	C17A
SAMSUNG	TX20P1DF4	C17A
SAMSUNG	TX20P1F	C17A(P)
SAMSUNG	TX21B4DF4X/XET	C17A (TS10)
SAMSUNG	TX21B5DF3X	C15C
SAMSUNG	TX21B5DF3X/SEC	C15C
SAMSUNG	TXB2525	K52MA ?
SAMSUNG	TXC2515	K52A2
SAMSUNG	TXC2516	K52A2
SAMSUNG	TXC2715	K52A2
SAMSUNG	TXC2716	K52A2
SAMSUNG	TXD1373	K1 (BEKO)
SAMSUNG	TXD1972	K1 (BEKO)
SAMSUNG	TXD1973	K1 (BEKO)
SAMSUNG	TXD1982	K1 (BEKO)
SAMSUNG	TXD2022	K1 (BEKO)
SAMSUNG	TXE2045	KCT52A
SAMSUNG	TXE2046	KCT52A
SAMSUNG	TXE2545	KCT52A
SAMSUNG	TXE2546	KCT52A
SAMSUNG	TXE2549	KCT52A
SAMSUNG	TXE2745	KCT52A
SAMSUNG	TXE2746	KCT52A
SAMSUNG	TXE2749	KCT52A
SAMSUNG	TXF2899	KCT53A ?
SAMSUNG	TXF2899/UCX	KCT55A
SAMSUNG	TXH1370	K15A
SAMSUNG	TXH1370NX/XAA	K15A (H)
SAMSUNG	TXH1372	K15A
SAMSUNG	TXH1373	K15A
SAMSUNG	TXH1386	K15A
SAMSUNG	TXH1970	K15A
SAMSUNG	TXH1972	K15A
SAMSUNG	TXH1972	K15A
SAMSUNG	TXH1973	K15A

Brand	model	chassis
SAMSUNG	TXH1986	K15A
SAMSUNG	TXH2048	KCT57A
SAMSUNG	TXH2545	KCT57A
SAMSUNG	TXH2555	KCT57A
SAMSUNG	TXH2556	KCT57A
SAMSUNG	TXH2740	KCT57A
SAMSUNG	TXH2755	KCT57A
SAMSUNG	TXH2756	KCT57A
SAMSUNG	TXH2869	KCT57A
SAMSUNG	TXH2879	KCT57A
SAMSUNG	TXJ1366	K15A
SAMSUNG	TXJ1367	K15A
SAMSUNG	TXJ1396	K15A
SAMSUNG	TXJ1966	K15A
SAMSUNG	TXJ1996	K15A
SAMSUNG	TXJ2060	K51A
SAMSUNG	TXJ2066	K51A
SAMSUNG	TXJ2067	K51A
SAMSUNG	TXJ2550X/XAC	K51A
SAMSUNG	TXJ2550XS/XAC	K51A
SAMSUNG	TXJ2554	K51A
SAMSUNG	TXJ2554S/XAC	K51A
SAMSUNG	TXJ2566	K51A
SAMSUNG	TXJ2566T/XAA	K51A
SAMSUNG	TXJ2567	K51A
SAMSUNG	TXJ2567T/XAA	K51A
SAMSUNG	TXJ2567T/XAC	K51A
SAMSUNG	TXJ2750X/XAC	K51A
SAMSUNG	TXJ2754	K51A
SAMSUNG	TXJ2766	K51A
SAMSUNG	TXJ2766T/XAA	K51A
SAMSUNG	TXJ2767	K51A
SAMSUNG	TXJ2767T/XAA	K51A
SAMSUNG	TXJ2768	K51A
SAMSUNG	TXJ2768T/XAA	K51A

Brand	model	chassis
SAMSUNG	TXJ2768T/XAC	K51A
SAMSUNG	TXJ2879	K51A
SAMSUNG	TXJ3276X/XAA	K51A
SAMSUNG	TXJ3278X/XAA	K51A
SAMSUNG	TXJ3278X/XAC	K51A
SAMSUNG	TXJ3676X/XAA	K51A
SAMSUNG	TXJ3678X/XAA	K51A
SAMSUNG	TXJ3678X/XAC	K51A
SAMSUNG	TXK2066X/XAA	KS2A(N)
SAMSUNG	TXM2796HFX/XAA	K55A
SAMSUNG	TXM2797HFX/XAA	K55A
SAMSUNG	TXM2798HFX/XAA	K55A
SAMSUNG	TXM3096WHFXXAA	K55A
SAMSUNG	TXM3097WHFXXAA	K55A
SAMSUNG	TXM3098WHFXXAA	K55A
SAMSUNG	TXM3296HFX/XAA	K55A
SAMSUNG	TXM3297HFX/XAA	K55A
SAMSUNG	TXM3298HFX/XAA	K55A
SAMSUNG	TXN1430FX/XAA	K15D
SAMSUNG	TXN2434FBX/XAC	K57A
SAMSUNG	TXN2670WHFXXAA	K55A
SAMSUNG	TXN2745FP	K55A(N_R.2)
SAMSUNG	TXN2771HFX/XAA	K55A
SAMSUNG	TXN2771HFX/XAC	K55A
SAMSUNG	TXN2798HF	K55A(N_R.1_DVI)
SAMSUNG	TXN3075WHF	K55A(N_R.2)
SAMSUNG	TXN3075WHF	K55A(N_R.2)
SAMSUNG	TXN3271HF	K55A(N_R.2)
SAMSUNG	TXN3271HF	K55A(N_R.2)
SAMSUNG	TXP3066WX/XAC	K61A
SAMSUNG	TXP3235X/XAC	KS7A
SAMSUNG	TXR2728	K61B (?)
SAMSUNG	UCK5013Z	P58SC
SAMSUNG	UW17J11VD	C18A
SAMSUNG	UW21J10VD	C18A

Brand	model	chassis
SAMSUNG	UW28J10VD	C18A
SAMSUNG	UW28J10VD5XXEU	C18A(P)
SAMSUNG	WF24W6VN3X/XEF	S51A
SAMSUNG	WF28W6N3X/XEF	S51A
SAMSUNG	WF28W6VN3X/XEF	S51A
SAMSUNG	WF32V56F	KS3A ?
SAMSUNG	WF32W6VN3X/XEF	S51A
SAMSUNG	WI24W6VD3X/XEU	S51A
SAMSUNG	WS24V53N...	KS3A 100Hz
SAMSUNG	WS24V53NS8XXEC	KS3A(P) 50Hz(REV. 5)
SAMSUNG	WS24W63NS8XXEC	KS3A(P) 50Hz(REV.5)
SAMSUNG	WS24W6VNG8X	KS3A
SAMSUNG	WS2820PP	WZ74
SAMSUNG	WS28A114VWXXEC	KS7A
SAMSUNG	WS28A116VNXXEC	S61A
SAMSUNG	WS28M064N8XXEC	KS3A
SAMSUNG	WS28M064N8XXEU	KS3A(P)_50Hz(REV. 5)
SAMSUNG	WS28M064NWXXEC	KS7A
SAMSUNG	WS28M164NWX	KS7A (?)
SAMSUNG	WS28M164NWXXEC	KS7A
SAMSUNG	WS28M164VWXXEC	--
SAMSUNG	WS28M204D9XXEU	S59B(P) TROY2
SAMSUNG	WS28M204NWXXEC	KS7A(P) Rev.1
SAMSUNG	WS28M64S8	KS3A
SAMSUNG	WS28M64V	KS3A (KS3AP ?)
SAMSUNG	WS28M64VS8XXEC	KS3A
SAMSUNG	WS28V53NS8	KS3A
SAMSUNG	WS28V55VS8	KS3A
SAMSUNG	WS28V55VSG	K55A
SAMSUNG	WS28W5VNS8X	KS3A
SAMSUNG	WS28W65VS8XXEC	KS3A(P) (REV. 2)
SAMSUNG	WS28W6HA	SCT53A
SAMSUNG	WS28W6WG8X	KS3A
SAMSUNG	WS28W73NS8XXEC	KS3A(P)_50Hz(REV.4)
SAMSUNG	WS28W73NS8XXEC	KS3A(P)_50Hz(REV.4)

Brand	model	chassis
SAMSUNG	WS28W75VS8XXEC	KS3A(P)_50Hz(REV.4)
SAMSUNG	WS28W8V	KS3A(P)
SAMSUNG	WS28W8VD	KS3A ?
SAMSUNG	WS28W8VDE	KS4A
SAMSUNG	WS28W8VNE8	KS3A(P)_50Hz_REV. 4
SAMSUNG	WS28Z44VS8XXEC	KS3A(P)_50Hz(REV.4)
SAMSUNG	WS28Z46VS8	KS3A(P)_50Hz_REV. 4
SAMSUNG	WS28Z46VS8XXEC	KS3A(P)_50Hz(REV.4)
SAMSUNG	WS28Z6	K55A
SAMSUNG	WS3220PF	WZ74
SAMSUNG	WS3220PP	WZ74
SAMSUNG	WS32A1081GXEC	K55A(P) YOUNGSTAR_Rev.1
SAMSUNG	WS32A10HW	K55A(P)YOUNGSTAR
SAMSUNG	WS32A114VWXXEC	--
SAMSUNG	WS32A116D	S59A
SAMSUNG	WS32A20SDSXXSA	S59A
SAMSUNG	WS32M066TGXXEC	K55A(P) YOUNGSTAR_Rev.1
SAMSUNG	WS32M066V	K55A
SAMSUNG	WS32M066VGXXEC	--
SAMSUNG	WS32M164VWXXEC	--
SAMSUNG	WS32M204D9XXEU	S59B(P) TROY2
SAMSUNG	WS32M206V	S61A
SAMSUNG	WS32M64NS8XXEC	KS3A(P)_50Hz(REV.4)
SAMSUNG	WS32M66TSGXXEC	K55A(P)
SAMSUNG	WS32M66VS8	KS3A (KS3AP ?)
SAMSUNG	WS32M66VS8XXEC	KS3A
SAMSUNG	WS32V56VSG	K55A ?
SAMSUNG	WS32W66VS8	KS3A
SAMSUNG	WS32W66VS8XXEC	KS3A(P)_50Hz(REV. 4)
SAMSUNG	WS32W68AS9	KS4A
SAMSUNG	WS32W68AS9XXEC	KS4A(P)
SAMSUNG	WS32W6HA	SCT53A
SAMSUNG	WS32W6HAX/XEC	SCT53A (?)
SAMSUNG	WS32W6VNG	KS3A
SAMSUNG	WS32W74NS8XXEC	KS3A(P) 50Hz(REV.5)

Brand	model	chassis
SAMSUNG	WS32W76VS8XXEC	KS3A(P) 50Hz(REV.5)
SAMSUNG	WS32W8HDP9X	KS4A
SAMSUNG	WS32W8HDP9XXEC	KS4A(P)
SAMSUNG	WS32W8HDP9XXET	KS4A(P)
SAMSUNG	WS32W8HDP9XXET	KS4A(P)
SAMSUNG	WS32W8VD	KS3A(P)
SAMSUNG	WS32W8VDE	KS3A
SAMSUNG	WS32W8VDE8XXEC	KS3A
SAMSUNG	WS32W8VH	KS3A(P)
SAMSUNG	WS32W8VHE8XXEC	KS3A (REV. 2)
SAMSUNG	WS32W8VHE8XXET	KS3A (REV. 2)
SAMSUNG	WS32W8VHE8XXEU	KS3A (REV. 2)
SAMSUNG	WS32Z068TGXXEC	K55A
SAMSUNG	WS32Z10HVTQ	S58A(P) REV.1
SAMSUNG	WS32Z30	S62B
SAMSUNG	WS32Z306	S62A
SAMSUNG	WS32Z306T	S62B
SAMSUNG	WS32Z306V	S62B
SAMSUNG	WS32Z306VB	S62B
SAMSUNG	WS32Z308	S62A
SAMSUNG	WS32Z308P	S62A
SAMSUNG	WS32Z308PAXXEC	S62A(P)_OZ
SAMSUNG	WS32Z30HE	S62A
SAMSUNG	WS32Z409	S62A
SAMSUNG	WS32Z409PQXXEC	S63A(P)_Catch Me
SAMSUNG	WS32Z40HNQXXST	S63A(P)_Catch Me
SAMSUNG	WS32Z419D8XXEU	S64A(P)
SAMSUNG	WS32Z419P	S64A
SAMSUNG	WS32Z46V	K55A(P)
SAMSUNG	WS32Z46VS8	K55A
SAMSUNG	WS32Z46VSGXXEC	K55A(P)
SAMSUNG	WS32Z46VSGXXEC/EU	K55A(P)
SAMSUNG	WS32Z46VSGXXEU	K55A(P)
SAMSUNG	WS32Z48DS9XXEC	KS4A(P)_Rev.1
SAMSUNG	WS32Z48DS9XXEC	KS4A(P)_Rev.1

Brand	model	chassis
SAMSUNG	WS32Z4HF9X/BWT	KS4A(P)
SAMSUNG	WS32Z4HF9X/SAP	KS4A(P)
SAMSUNG	WS32Z4HF9X/SED	KS4A(P)
SAMSUNG	WS32Z4HF9X/XSA	KS4A(P)
SAMSUNG	WS32Z4HF9XSBWT	KS4A(P)REV.1
SAMSUNG	WS32Z68PSGXSEC	K55A(P)
SAMSUNG	WS32Z78RSM	S57A
SAMSUNG	WS3674HF9X	KS4A
SAMSUNG	WS36Z4HF9X/BOB	KS4A(P)
SAMSUNG	WS36Z4HF9X/BWT	KS4A(P)
SAMSUNG	WS36Z4HF9X/SED	KS4A(P)
SAMSUNG	WS36Z4HF9X/XEH	KS4A(P)
SAMSUNG	WT32Z10HD	K58A(K)
SAMSUNG	WT32Z10HD	K58A(K)
SAMSUNG	WX24W6VW	S51A
SAMSUNG	WZ28W6VDG8XXET	KS3A (REV. 2)
SANG	29BCT12SXS	20.2 (100Hz) (BEKO)
SANG	29BCT33SXS	20.2 (100Hz) (BEKO)
SANKEY	CT2033BR	MC97A
SANKEY	CTV5490	MC97A
SANKEY	CTV5679	MC97A
SANKEY	CTV5950	MC97A
SANSEI	TVR1418	LA3C
SANSEI	TVR2018	LA3C
SANSUI	SV2960N	M13PF
SANSUI	SV2988N	M13
SANSUI	SV2988N	M13PF
SANSUI	SV3488N	M13PF
SANSUI	TX1446SLV	(X785-43)
SANTEC	RC4221PST	RC4121A
SANTEC	RC4421PST	RC4121A
SANYO		EB2
SANYO	14M1	EC2A
SANYO	14MT1	EC3A
SANYO	21BN1	EB4

Brand	model	chassis
SANYO	21D1	EB4A
SANYO	21DT1	EC5A
SANYO	21EF44	EB4A
SANYO	21MDT2E	11AK30
SANYO	21MT2	EC5A
SANYO	21MT3	EC5A
SANYO	25DN1	EB4A
SANYO	25MT2	EC5A
SANYO	2880TX	EC1
SANYO	28DN1F	EB3A
SANYO	28DN2	EB4A
SANYO	28H1	EH1A
SANYO	28HN1	EH1A
SANYO	28HN1	EH1A
SANYO	28MT2	EC5A
SANYO	29FF-V3	EB9 (?)
SANYO	62C852U	G3E852UO
SANYO	AVM1307	G6C-13070
SANYO	AVM1901S	G6V
SANYO	AVM1908G	G6B ?
SANYO	AVM2053	G2R
SANYO	AVM2504	G3N
SANYO	AVM2505	G3V-25050
SANYO	AVM2559C	G5T
SANYO	AVM2780G	VB7C
SANYO	AVM3259G	G5R-3259G7
SANYO	AVM3651G	G7R3651G0
SANYO	C1461	EC1 LC96 (2094)
SANYO	C1461TX-C	EC4A (2095)
SANYO	C1461TXC	EC4A (2095)
SANYO	C1465	EC1 LC96 (2094)
SANYO	C1471	EC1 LC96 (2094)
SANYO	C1471EE	EC1 V7 (2100)
SANYO	C14EA13EE50	AA7A
SANYO	C14EA13EX00	A7A

Brand	model	chassis
SANYO	C14EA17EX00	F6A
SANYO	C14EA63EX00	A7A
SANYO	C14EA63EXH TXT	A7A
SANYO	C14EA67EX00	F6A
SANYO	C14EA80D00	EC2A
SANYO	C14EA80H	EC2A
SANYO	C14EA85	EC3A
SANYO	C14EA890D	EC2A
SANYO	C14EA90D	EC2A
SANYO	C14EA95	EC3A
SANYO	C14EA96EE	EC3A
SANYO	C14EA97	EC5A
SANYO	C14LT13M	LA3C
SANYO	C14M2	EC5A
SANYO	C14MD2E	11AK20S5
SANYO	C20BC2XN	PT90
SANYO	C20BG2TX	PT11
SANYO	C20DN4AV	PT11I
SANYO	C20DN4AVN	PT92
SANYO	C20EE10	A7-A10
SANYO	C20EE13EX50	A7A
SANYO	C20EE16EE50	A7A
SANYO	C20EE17EV	F6A
SANYO	C20EE17EX00	F6A
SANYO	C20LE90BC	LA3C
SANYO	C20LV23M	LA3C
SANYO	C20LV33M	LA3C
SANYO	C20PE70	A7A
SANYO	C20VT12H	TC3C
SANYO	C20VT12M	TC3C
SANYO	C20VT12S	TC3C
SANYO	C20VT12T	TC3C
SANYO	C2161TX-C	EC4A (2095)
SANYO	C2161TXC	EC4A (2095)
SANYO	C2170TX	EC4A (2095)

Brand	model	chassis
SANYO	C21EF13EE50	A7
SANYO	C21EF13EX	A7A
SANYO	C21EF13EX00	A7A
SANYO	C21EF13EX50	A7A
SANYO	C21EF13EX50	A7A
SANYO	C21EF16EE50	A7A
SANYO	C21EF17EX00	F6
SANYO	C21EF25N	EB2A
SANYO	C21EF27	EC5A
SANYO	C21EF34	EB2A
SANYO	C21EF45NB	EB4
SANYO	C21EF63EX01	A7A
SANYO	C21EF63EXH TXT	A7A
SANYO	C21EF63EXH00	A7A
SANYO	C21EF67EX	EC5A
SANYO	C21EF67EX	F6A !
SANYO	C21EF97EX00	A7A
SANYO	C21EF97EXH00	A7A
SANYO	C21ES35	EC5A
SANYO	C21LF37	LA5A
SANYO	C21MD2E	11AK30
SANYO	C21MDP2E	11AK30A4
SANYO	C21MDT2EP	11AK30-2
SANYO	C21PM81	AC1A
SANYO	C2518	EB2B (2084)
SANYO	C2520TX	EC1 (2087)
SANYO	C2521TX	EC4B
SANYO	C2528	EB2B (2084)
SANYO	C2558	EB2B (2084)
SANYO	C2558N	EB2B (2084)
SANYO	C2580	EC1 TXT 1P (2087)
SANYO	C2580TX	EC1 TXT 1P (2087)
SANYO	C2581TX	EC4B (2092)
SANYO	C25EG25N	EB2A
SANYO	C25EG34	EB2A

Brand	model	chassis
SANYO	C25EG57	AA1A
SANYO	C25EG64	EB4A
SANYO	C25EG65N	EB4A
SANYO	C25EG89N	EB4A
SANYO	C25EG95B	EC3A
SANYO	C25EG97EE	EC3A
SANYO	C25EG98	EC5A
SANYO	C25EP57	EB4A
SANYO	C25EP7	EB4
SANYO	C25ER17EE	EB4A
SANYO	C25PG51	AA1A
SANYO	C27LW33S02	LA3D ?
SANYO	C27LW44SE	LA4A
SANYO	C2820TX	EC1 (2087)
SANYO	C2828	EB2B (2084)
SANYO	C2828N	EB2B (2084)
SANYO	C2858	EB2B (2084)
SANYO	C2880TX	EC1 TXT 1P (2087)
SANYO	C2881TX-P	EC4B
SANYO	C28EH25D	EB3A
SANYO	C28EH25NB	EB3A
SANYO	C28EH27EE	EB3A
SANYO	C28EH34	EB2A (?)
SANYO	C28EH64	BE4A
SANYO	C28EH65N	BE4A
SANYO	C28EH75	EC5A
SANYO	C28EH82F	EC3A
SANYO	C28EH85N	EB2A
SANYO	C28EH89	BE4A
SANYO	C28ER14	EB4A
SANYO	C28ER15N	BE4A
SANYO	C28ER17EE	EB4A
SANYO	C28ER55N	EB4A
SANYO	C28ER57N	EB4A
SANYO	C28ER59	EH1A

Brand	model	chassis
SANYO	C28ER59N	EH1A
SANYO	C28SDP1E	11AK37
SANYO	C28WK1N	A8B
SANYO	C28WN1	WB2B
SANYO	C28WP1	WB2A
SANYO	C29AK86	AA1A
SANYO	C29LF34SM	FA1A
SANYO	C29PK81	AA1A
SANYO	C29PK86	AA1A
SANYO	C29ZK81	AA1A
SANYO	C29ZK86	AA1A
SANYO	CAM2135	A2
SANYO	CB1443	EC2A
SANYO	CB1456	EC3A
SANYO	CB5953	E3A
SANYO	CB6657	EB2
SANYO	CBP2168	EC1B
SANYO	CBP2565	E3A
SANYO	CBP2566	E3A
SANYO	CBP2865	E3A
SANYO	CBP2866	E3A
SANYO	CD14AT2	2112 (EC7A)
SANYO	CE14 SA4	AC5G
SANYO	CE14 SA4R	AC5G
SANYO	CE14A1	EC1 V7 (2100)
SANYO	CE14A1C	EC1 V7 (2100)
SANYO	CE14A1E	EC1 V7 (2100)
SANYO	CE14A2	EC7A
SANYO	CE14A3	EC7A
SANYO	CE14AR2	EC7A
SANYO	CE14AS1	EC1 V7 (2100)
SANYO	CE14AS2	EC7A
SANYO	CE14AS3	EC7A
SANYO	CE14ASR2	EC7A
SANYO	CE14AT2	EC7A

Brand	model	chassis
SANYO	CE14AT2	EC7A (2112)
SANYO	CE14AT2C	EC7A
SANYO	CE14AT2GB	EC7A
SANYO	CE14AT3	2117 (EC7C)
SANYO	CE14AT3	EC7A
SANYO	CE14ATR2	EC7A
SANYO	CE14AX2	EC7A
SANYO	CE14J1	EC1 V7 (2100)
SANYO	CE14MT2SL	EC5A
SANYO	CE14MT4B	EC8A
SANYO	CE14MT4SLB	EC8A
SANYO	CE17A1	EC1 V7 (2100)
SANYO	CE17A1C	EC1 V7 (2100)
SANYO	CE17A1E	EC1 V7 (2100)
SANYO	CE17A2C	EC1 V7 (2100)
SANYO	CE17AS1	EC1 V7 (2100)
SANYO	CE21A2C	EC7B (2113)
SANYO	CE21AT2-E	EC7B
SANYO	CE21B4	EB4A
SANYO	CE21BN5	EB6D
SANYO	CE21C6C	EB6D
SANYO	CE21CM1F	EB7B
SANYO	CE21D3C	EB4A
SANYO	CE21DN5C	EB6A
SANYO	CE21EN6F-C	EB6
SANYO	CE21FN1E	EB5A (2103)
SANYO	CE21FV2	EB5A (2103)
SANYO	CE21FV3	EB5A
SANYO	CE21FV4	2114 (EB5C)
SANYO	CE21FV5	2114 (EB5C)
SANYO	CE21G4	AC5G (?)
SANYO	CE21MT4HB	EC8A
SANYO	CE21P1	EB4A
SANYO	CE21P2C02	EB4A21
SANYO	CE25C6C	EB6D

Brand	model	chassis
SANYO	CE25DN3B	EB4A
SANYO	CE25DN4P	EB4A
SANYO	CE25DN5C	EB6A
SANYO	CE25DN6	EB6
SANYO	CE25DN7	EB6B
SANYO	CE25DN7C	EB6B
SANYO	CE25DN9	EB8
SANYO	CE25FA2	2103 (serie EB5A)
SANYO	CE25FN1	EB5A (2103)
SANYO	CE25FN1E	EB5A (2103)
SANYO	CE25FV2E	EB5C (2114)
SANYO	CE25FV3	2103 (EB5A)
SANYO	CE25FV4	EB5C (2114)
SANYO	CE25FV4	EB5C (2114)
SANYO	CE25FV5	2114 (EB5C)
SANYO	CE25GN3	EB5C (2114)
SANYO	CE28B4C	EB4A (czy? EB5)
SANYO	CE28B5C	EB6D
SANYO	CE28BH2	HA2
SANYO	CE28BH2C	HA2A
SANYO	CE28BN4C	EB4-A28
SANYO	CE28BN5	EB6D
SANYO	CE28CHN4	HB3B
SANYO	CE28CHN5F	HB3B
SANYO	CE28CN7F-C	EB7B
SANYO	CE28CN8F	EB8A
SANYO	CE28CN8F	EB8A28
SANYO	CE28D3C	EB4A
SANYO	CE28DN3B	EB4A
SANYO	CE28DN4P	EB4A
SANYO	CE28DN5C	EB6A
SANYO	CE28DN6	EB6
SANYO	CE28DN7C	EB6B
SANYO	CE28FA4	EB5C (2114)
SANYO	CE28FN1	EB5A (2103)

Brand	model	chassis
SANYO	CE28FN1E	EB5A (2103)
SANYO	CE28FT2	EB5B
SANYO	CE28FV2	EB5A ?
SANYO	CE28FV3	2103 (EB5A)
SANYO	CE28FV4	EB5C (2114)
SANYO	CE28FV4A	EB5C (2114)
SANYO	CE28FV6	2119
SANYO	CE28FWH2F	WB6-A28
SANYO	CE28FWH4B	WB6-A28
SANYO	CE28FWN3	EB6 (czy? EB5W)
SANYO	CE28FWN4F	EB7A
SANYO	CE28FWN6B	EB8A
SANYO	CE28GA1	EB5A (2103)
SANYO	CE28GA1P	EB5A (2103)
SANYO	CE28GN3	EB5C (2114)
SANYO	CE28H1A	EH1A
SANYO	CE28KF8R	FC3A
SANYO	CE28MN7B	EB8A28
SANYO	CE28SW4	PT90 16:9
SANYO	CE28WA3	EB5
SANYO	CE28WA4	2116 (EB5Z)
SANYO	CE28WN3B	EB5W
SANYO	CE28WN5B	EB6-A28
SANYO	CE28WN7	EB8A28
SANYO	CE29FFV1	EB5C (2114)
SANYO	CE29FFV1F	EB5C (2114)
SANYO	CE29FFV1F	EB5C (2114)
SANYO	CE29FFV3F	EB9A
SANYO	CE29FFV3F	EB9A (2119)
SANYO	CE29KF8R	FC3G2
SANYO	CE29ST8R	AC5G2
SANYO	CE30LC3BK-C	UB4B
SANYO	CE30LC3C	UB4B
SANYO	CE32FWH1F	WB5-B32
SANYO	CE32FWH2F	WB6-A32

Brand	model	chassis
SANYO	CE32FWN4F	EB7A
SANYO	CE32FWN6F	EB8A
SANYO	CE32FXH2FC	WB6A
SANYO	CE32LW02	17MB11
SANYO	CE32W1C	WB2B
SANYO	CE32WA4	2116 (EB5Z)
SANYO	CE32WH3F	WB5
SANYO	CE32WN1C	WB2B
SANYO	CE32WN2	WB2B
SANYO	CE32WN3B	EB5W
SANYO	CE32WN4F-C	EB6-A32
SANYO	CE32WN5F	EB6-A32
SANYO	CE32WN5F-C	EB7
SANYO	CE37K1C	EC1 V7 (2100)
SANYO	CED1505PV	EB1273
SANYO	CED2105PV	85P-A21
SANYO	CED3011PV20	A1
SANYO	CEM2108PV	85P
SANYO	CEM2130PV	A1
SANYO	CEM2140P00	A3
SANYO	CEM2140P50	A3C
SANYO	CEM2140PTX50	A3B
SANYO	CEM2141PTX	A3B
SANYO	CEM2141PTX00	A3B
SANYO	CEM2143C	A3
SANYO	CEM2510PTX00	A4A
SANYO	CEM2511PV	A2C
SANYO	CEM2512P	A2C
SANYO	CEM3022	A3A
SANYO	CEM3024F02	F6A
SANYO	CEM6022P00	A3
SANYO	CEM6041PTX00	A3B
SANYO	CEP1497E	EC1 LC (2078)
SANYO	CEP1497E S	EC1 LC (2078)
SANYO	CEP1747PSTX00	E2G

Brand	model	chassis
SANYO	CEP1793	097
SANYO	CEP1797TXT	EC1 LC (2078)
SANYO	CEP2077	2021
SANYO	CEP2147PSTX00	E2G
SANYO	CEP2161PG	E4B
SANYO	CEP2177	2021
SANYO	CEP2180D	A5A
SANYO	CEP2180N	A5
SANYO	CEP2193TXT	097 (?)
SANYO	CEP2557TX00	E3B
SANYO	CEP2559TX00	E3B
SANYO	CEP2564	E3A
SANYO	CEP2566	A2A
SANYO	CEP2570D	2031
SANYO	CEP2572 N00	ED1
SANYO	CEP2573N00	ED1
SANYO	CEP2576A	EB1
SANYO	CEP2576D00	ED0
SANYO	CEP2576DA00	EB1
SANYO	CEP2864	E3A
SANYO	CEP2866	E3A
SANYO	CEP2870D	2031
SANYO	CEP2872 N00	ED1
SANYO	CEP2873N00	ED1
SANYO	CEP2876A	EB1
SANYO	CEP2876D00	ED0
SANYO	CEP2877G	2021
SANYO	CEP2896	ED0 (2031)
SANYO	CEP3011V	A1A
SANYO	CEP3012D00	A3
SANYO	CEP3012PS00	A3
SANYO	CEP3021TX	A3B
SANYO	CEP3022PS	A3
SANYO	CEP3095E	EC1 LC (2078)
SANYO	CEP3358TX	E3

Brand	model	chassis
SANYO	CEP3373	ED2
SANYO	CEP6011VPS	A1B
SANYO	CEP6016	P11A20
SANYO	CEP6022PDS00	A3
SANYO	CF21SD9E	11AK30 A10
SANYO	CF28FWN3B	EB6C
SANYO	CF29SD1EP (HP)	11AK33
SANYO	CF29SD4	(100Hz)
SANYO	CK25D58	FC4A
SANYO	CK25G1A	CA1A ?
SANYO	CK25G5	FC4A
SANYO	CK29F78G	FC4C ?
SANYO	CLP2051C	LA3C
SANYO	CLP6022	A3C
SANYO	CM21AF8VA	MCL437FEX
SANYO	CM21LX8C	AC6A
SANYO	CM25ST5A	AC2-A25
SANYO	CM29KX5N	AC5D
SANYO	CMM2135VR	A2
SANYO	CMX2141RA	A3B ?
SANYO	CP14 SA1	AC5G
SANYO	CP14G1	AC5G
SANYO	CP14KX2	AC5A
SANYO	CP14SR1	AC4A
SANYO	CP14SW1	AC3A
SANYO	CP20SR1	AC4A
SANYO	CP20SW1Z	AC5C
SANYO	CP21AF2	FC1B
SANYO	CP21AF2T	FC1B
SANYO	CP21AF2V	FC3B
SANYO	CP21G1(A)	AC5G
SANYO	CP21KX2	AC5A
SANYO	CP21SA1	AC5A
SANYO	CP21SW1	AC3A
SANYO	CP25AF2T	FA1

Brand	model	chassis
SANYO	CP25ST2	AC2A
SANYO	CP28WP2	WB2A
SANYO	CP28WP3	WB2A
SANYO	CP29AF2T	FA1
SANYO	CP29AF2X	FC3A
SANYO	CP29KX2	AC2A
SANYO	CP29KX2Z	AC5D
SANYO	CP29KX3T	AC2A
SANYO	CP29ST2	AC2A
SANYO	CP29ST2T	AC2A
SANYO	CP29SV2Z	AC5D
SANYO	CP32WP2	WB2A
SANYO	CP32WP3	WB2A
SANYO	CP34ST3T	AB3A
SANYO	CP6055V	83P
SANYO	CPB2151	E4A
SANYO	CPB216	E4A
SANYO	CPP1662	A3A
SANYO	CPP3045	83P
SANYO	CR29AF6T	FA1-29
SANYO	CSM6012	A3
SANYO	CT14SR1G	AC5G
SANYO	CT25AF5	FA1
SANYO	CT2819TN	PT92
SANYO	CTP3132	80P
SANYO	CTP6227	80P ?
SANYO	CTP6230	B5R
SANYO	CTP6278	83P-D20
SANYO	CTP6358	B6Y ?
SANYO	CTP6730A	80P
SANYO	CTP6734	83P
SANYO	CTP7130	80P ?
SANYO	CTP7375	83S-D22 (83S-C21 ?)
SANYO	CTX2500SR	S8C
SANYO	CTX2500SR	SB25 ?

Brand	model	chassis
SANYO	DS19204	19204-01
SANYO	DS20930	20930-00
SANYO	DS25320	25320-00
SANYO	DS25520	CTC203
SANYO	E28DF1	EB3A
SANYO	PLV55WM1	M8J55WM100
SANYO	VCM7321E	EC8A ?
SANYO	VMC7321E	EC8A ?
SATURN	25NF1	M13
SATURN	ST1401	M28
SATURN	ST2939A	5N11
SBR	72TA5213	MD1.2E (LS29SF12W)
SCHAUB-LORENZ	185 6314-35	EUROMONO MULTI110
SCHAUB-LORENZ	5439-01-20	EUROMONO MULTI110
SCHAUB-LORENZ	6126	MONOPRINT B
SCHAUB-LORENZ	6227F	MONOPRINT B
SCHAUB-LORENZ	6327	MONOPRINT B
SCHAUB-LORENZ	6327F	MONOPRINT B
SCHAUB-LORENZ	6578F	DIGITAL B 110° FST
SCHAUB-LORENZ	7018	EURO-DIGI 4/3
SCHAUB-LORENZ	8588PS	COMPACT D2 S4
SCHAUB-LORENZ	SL1404-5T	12.7
SCHAUB-LORENZ	SL2525	F11 R4 (Formenti)
SCHAUB-LORENZ	SL2802-5T	14.2 (U99.190-08)
SCHAUB-LORENZ	SL2810100ST	20.2 (100Hz) (BEKO)
SCHAUB-LORENZ	SL2811100ST	20.2 (100Hz) (BEKO)
SCHAUB-LORENZ	SL2820100	20.2 (100Hz) (BEKO)
SCHAUB-LORENZ	SL2820100ST	20.2 (BEKO)
SCHAUB-LORENZ	SL2910100ST	20.2 (100Hz) (BEKO)
SCHAUB-LORENZ	SL3210100	20.2 (100Hz) (BEKO)
SCHAUB-LORENZ	SL3210100ST	20.2 (100Hz) (BEKO)
SCHAUB-LORENZ	SL3250/100	20.2 (100Hz) ! (7UZ.190-10)
SCHAUB-LORENZ	SL3250100ST	20.2 (100Hz) (BEKO)
SCHAUB-LORENZ	SL3310100ST	20.2 (100Hz) (BEKO)
SCHAUB-LORENZ	ST28-31F1-5	14.5

Brand	model	chassis
SCHNEIDER		STV12
SCHNEIDER		TV18
SCHNEIDER	2000TZ	PT92
SCHNEIDER	21M061	M35-M36B
SCHNEIDER	21M310	TV18 (?)
SCHNEIDER	21M311	TV18
SCHNEIDER	28M021--TV18S.1-70238/M/AS	TV18S.1
SCHNEIDER	28M110	TV1003
SCHNEIDER	29M301	M36
SCHNEIDER	3220	20.2 (BEKO)
SCHNEIDER	33413-38395	DTV2
SCHNEIDER	52TB1452	L6.1 AA
SCHNEIDER	6023M EURO70238	TV9.1
SCHNEIDER	70-100 TV101-70237/M	DTV101
SCHNEIDER	70222M	TV9.1
SCHNEIDER	70TB4417	PT92P-110
SCHNEIDER	CINEMA 28-100-TV17.3	TV17.3
SCHNEIDER	Cinema 2819	14.2 (U99.190-01)
SCHNEIDER	Cinema 3200	11AK19 PRO
SCHNEIDER	CINEMA3220	20.2 (100Hz) (BEKO)
SCHNEIDER	Colorado 55/4	TV4
SCHNEIDER	Colorado 55/7 TV7-5529/P	TV7
SCHNEIDER	CR14300 STEREO	CTU-AA
SCHNEIDER	CR20300 STEREO	CTU-AA
SCHNEIDER	CR20310 STEREO	CTU-AA
SCHNEIDER	CTV2701	TV1
SCHNEIDER	CTV2703	DTV1
SCHNEIDER	CTV2706	DTV2
SCHNEIDER	CTV2767	DTV3
SCHNEIDER	CTV2780	TV8
SCHNEIDER	CTV2790	TV8
SCHNEIDER	CTV2790 TV-8-67131/P	TV8
SCHNEIDER	CTV2790.9	TV9.1
SCHNEIDER	CTV2801	TV3
SCHNEIDER	CTV2802	TV1

Brand	model	chassis
SCHNEIDER	CTV2803	DTV1
SCHNEIDER	CTV2806	DTV3
SCHNEIDER	CTV2807	TV8
SCHNEIDER	CTV2809	TV9.1
SCHNEIDER	CTV2809 TV9.1-70241	TV9.1
SCHNEIDER	CTV2810	TV17.1
SCHNEIDER	CTV2810 TV17.1-70241/P	TV17.1
SCHNEIDER	CTV2810--TV17.3-70453-M/C-AV/D-VSS/S	TV17.3
SCHNEIDER	CTV2820	DTV1
SCHNEIDER	CTV2890	TV9.1
SCHNEIDER	CTV3671	CTU-AA
SCHNEIDER	CTV5181	CTS-AA
SCHNEIDER	CTV7010	TV9.1
SCHNEIDER	CTV7028	TV4
SCHNEIDER	DTV101-70224M	DTV101
SCHNEIDER	DTV6321	DTV1
SCHNEIDER	DTV70237	DTV100
SCHNEIDER	DTW2900ST	DTV100
SCHNEIDER	EURO21 PIP TV9.4-55216.13P	TV9.4
SCHNEIDER	FT810	TV17 (100Hz)
SCHNEIDER	GranPrix STR21-14RC	PT90-90
SCHNEIDER	HERO100--70237/P/DPS	DTV100
SCHNEIDER	LT7109VTS	TV17.1 (pono)
SCHNEIDER	M35-21189	M35-M36
SCHNEIDER	MAXX850	TV9.2
SCHNEIDER	MAXX850 typ: TV9.9-85239/M/SGM	TV9.9
SCHNEIDER	MD7015	TV17XL.6
SCHNEIDER	Scenaro 215	11AK19
SCHNEIDER	Scenaro 216	11AK19-8A
SCHNEIDER	SCENARIO 218PIP	11AK30
SCHNEIDER	Scenaro 2818--28A101	TV17.1 (100Hz)
SCHNEIDER	Scenaro 2819	TV17.7
SCHNEIDER	Scinema TV18S.3-70543/M/DVSS/C-AV/AS	TV18S.3
SCHNEIDER	SILVA STV1280	(97TA027G)
SCHNEIDER	SILVA STV155ST	PT11

Brand	model	chassis
SCHNEIDER	SILVA STV171ST	SM2
SCHNEIDER	SILVA STV2210	PT90-90
SCHNEIDER	SILVA STV2999TF	PT92 (?)
SCHNEIDER	ST6714	DTV1
SCHNEIDER	STV015TPT1	PT11 (?) (97TA012L)
SCHNEIDER	STV1001	DTV101
SCHNEIDER	STV1001 DTV10170224	DTV101
SCHNEIDER	STV1056VT	DTV2
SCHNEIDER	STV1063VT	DTV1
SCHNEIDER	STV1280STI	I2C ?
SCHNEIDER	STV1280STI	PT92 ???
SCHNEIDER	STV1401T	11AK20
SCHNEIDER	STV1697	DTV100
SCHNEIDER	STV1700	DTV101
SCHNEIDER	STV171ST SILVA	SM2 (?)
SCHNEIDER	STV1728	TV17.1 (100Hz)
SCHNEIDER	STV1750	TV17.1 (100Hz)
SCHNEIDER	STV1752	TV17.7 (100Hz)
SCHNEIDER	STV1760	TV17 (100Hz)
SCHNEIDER	STV1760 TV17.1-70241P	TV17
SCHNEIDER	STV1761	TV17.1
SCHNEIDER	STV1780	TV17.6 (?)
SCHNEIDER	STV1785	TV17.1 (100Hz)
SCHNEIDER	STV200	CTU-AA
SCHNEIDER	STV2003T	CTN-BB
SCHNEIDER	STV2003VT	CTN-BB
SCHNEIDER	STV21-200	CTU-AA
SCHNEIDER	STV2106T	ST64H ? (CTS AA ?)
SCHNEIDER	STV2111	TV11
SCHNEIDER	STV21200	CTU AA
SCHNEIDER	STV2201	TV1
SCHNEIDER	STV2802T	TV9.1
SCHNEIDER	STV2803T	DTV1
SCHNEIDER	STV2804T	14.2 (BEKO)
SCHNEIDER	STV321	PT11 (?)

Brand	model	chassis
SCHNEIDER	STV3216DVD	PT92-110°
SCHNEIDER	STV351ST	PT11 (?)
SCHNEIDER	STV355STA	PT92
SCHNEIDER	STV360	11AK20
SCHNEIDER	STV3600	PC04X
SCHNEIDER	STV3630	11AK08
SCHNEIDER	STV3640	CTN-BB
SCHNEIDER	STV365	11AK20SE-2
SCHNEIDER	STV3664	11AK08
SCHNEIDER	STV3666	11AK08
SCHNEIDER	STV3666.1	CTN-AA
SCHNEIDER	STV3666T	CTT-H
SCHNEIDER	STV3667	CTN-BB (?)
SCHNEIDER	STV3671	CTU-AA
SCHNEIDER	STV3671	TV9
SCHNEIDER	STV3672	TV9 ?
SCHNEIDER	STV3682	CTS AB
SCHNEIDER	STV3686	11AK08-13
SCHNEIDER	STV3686	11AK10
SCHNEIDER	STV3800	CTR-AA
SCHNEIDER	STV4270	PT92 ?
SCHNEIDER	STV4270ST	PT92 ?
SCHNEIDER	STV5-5115	TV5.1
SCHNEIDER	STV510	11AK19
SCHNEIDER	STV5100	PC08X8X
SCHNEIDER	STV5100T	PT92
SCHNEIDER	STV5110	PB2001VS
SCHNEIDER	STV5115VT	TV6
SCHNEIDER	STV511PS	TV5.1
SCHNEIDER	STV511PS VT	TV5.1
SCHNEIDER	STV5120	PB2001M
SCHNEIDER	STV512VT	TV6
SCHNEIDER	STV515	11AK19
SCHNEIDER	STV5164	11AK08
SCHNEIDER	STV5181	11AK08CTS ?

Brand	model	chassis
SCHNEIDER	STV5181 (Ilw.?)	CTS-AA
SCHNEIDER	STV5186	11AK10
SCHNEIDER	STV5187	11AK19
SCHNEIDER	STV5197	11AK19
SCHNEIDER	STV5280ST	PT90A ?
SCHNEIDER	STV53-100ST	PT100 (100Hz) (?)
SCHNEIDER	STV550	11AK19
SCHNEIDER	STV5500S	12.3 ?
SCHNEIDER	STV551CKD	TV5.1
SCHNEIDER	STV552	11AK19
SCHNEIDER	STV5525	TV6
SCHNEIDER	STV552VT	TV6
SCHNEIDER	STV5535	TV5.1 Mono
SCHNEIDER	STV553VT	TV6
SCHNEIDER	STV5540M	DTV2
SCHNEIDER	STV5598.5	11AK19
SCHNEIDER	STV55MS	12.7
SCHNEIDER	STV5614	DTV1
SCHNEIDER	STV6000	TV1
SCHNEIDER	STV6050	TV1
SCHNEIDER	STV6056	DTV2
SCHNEIDER	STV6058SAT	DTV2
SCHNEIDER	STV6100	TV2
SCHNEIDER	STV6150	DTV1
SCHNEIDER	STV6156 NICAM	DTV2
SCHNEIDER	STV6200	DTV1
SCHNEIDER	STV6210	TV10
SCHNEIDER	STV6216	DTV2
SCHNEIDER	STV626	TV2
SCHNEIDER	STV630 TV63222P	TV9.1
SCHNEIDER	STV6301	TV4
SCHNEIDER	STV6325	DTV1
SCHNEIDER	STV6500	TV1
SCHNEIDER	STV6550	DTV1
SCHNEIDER	STV6555	DTV2

Brand	model	chassis
SCHNEIDER	STV6556 NICAM	DTV2
SCHNEIDER	STV6566	DTV3
SCHNEIDER	STV670	TV10
SCHNEIDER	STV670	TV9.1
SCHNEIDER	STV6708	TV8
SCHNEIDER	STV6730	TV1
SCHNEIDER	STV6770	DTV3
SCHNEIDER	STV700	TV9.1
SCHNEIDER	STV7000	TV1
SCHNEIDER	STV7001	TV4
SCHNEIDER	STV7002DPL	TV8
SCHNEIDER	STV7010	TV1
SCHNEIDER	STV7010S	TV2
SCHNEIDER	STV7011	TV10
SCHNEIDER	STV7012	STV12
SCHNEIDER	STV7016	STV12
SCHNEIDER	STV7021CKD	DTV1
SCHNEIDER	STV7022CKD	DTV1
SCHNEIDER	STV7022DPL/3D	TV8
SCHNEIDER	STV7023	DTV2
SCHNEIDER	STV7027	DTV2
SCHNEIDER	STV702VT	TV10
SCHNEIDER	STV7033	TV8
SCHNEIDER	STV7050	DTV2
SCHNEIDER	STV7050	TV1
SCHNEIDER	STV7055	DTV1
SCHNEIDER	STV7056 NICAM	DTV2
SCHNEIDER	STV7059	TV1
SCHNEIDER	STV7060	DTV1
SCHNEIDER	STV7060	TV1
SCHNEIDER	STV7090	TV3
SCHNEIDER	STV7095	TV3
SCHNEIDER	STV71-104	PT100 (100Hz)
SCHNEIDER	STV7100FST	TV2
SCHNEIDER	STV7104	TV4

Brand	model	chassis
SCHNEIDER	STV7108	TV8
SCHNEIDER	STV7118	TV8
SCHNEIDER	STV7150	DTV1
SCHNEIDER	STV7156 NICAM	DTV2
SCHNEIDER	STV7157	DTV3
SCHNEIDER	STV7158SAT	DTV2
SCHNEIDER	STV7166 NICAM	DTV2
SCHNEIDER	STV7200	DTV1
SCHNEIDER	STV7201	DTV1
SCHNEIDER	STV722	TV2
SCHNEIDER	STV7226	DTV1
SCHNEIDER	STV725	TV2
SCHNEIDER	STV726	TV2
SCHNEIDER	STV728	TV9.1 ?
SCHNEIDER	STV7300M	DTV1
SCHNEIDER	STV7306M	DTV2
SCHNEIDER	STV736	TV3 ?
SCHNEIDER	STV74-100TF	PT100 (100Hz)
SCHNEIDER	STV750	TV9.1
SCHNEIDER	STV751	TV9
SCHNEIDER	STV761	TV17 (100Hz)
SCHNEIDER	STV7670	TV1
SCHNEIDER	STV8001	TV1
SCHNEIDER	STV8067	TV1
SCHNEIDER	STV8070	DTV1
SCHNEIDER	STV8100	TV2
SCHNEIDER	STV9028	DTV2
SCHNEIDER	STV9163VT	DTV2
SCHNEIDER	STV9425	TV8 ?
SCHNEIDER	STV9428	DTV3
SCHNEIDER	STV9458	TV8
SCHNEIDER	STV9550	TV1
SCHNEIDER	STV9570	TV8
SCHNEIDER	STV9727	TV8
SCHNEIDER	STV9778	TV8

Brand	model	chassis
SCHNEIDER	STV9825	TV8
SCHNEIDER	SVTV1451	(VMA230A)
SCHNEIDER	TV100-70224	DTV100
SCHNEIDER	TV100-70435/P	DTV100
SCHNEIDER	TV100-70525/P	DTV100
SCHNEIDER	TV10070224	DTV100
SCHNEIDER	TV10080525P	DTV100
SCHNEIDER	TV101-70223JM	DTV101
SCHNEIDER	TV17.1-170241	TV17.1 (100Hz)
SCHNEIDER	TV17.1-70231.13 (TV17.1-170231.13 - ?)	TV17.1 (100Hz)
SCHNEIDER	TV17.1-70249.1	TV17.1 (100Hz)
SCHNEIDER	TV17.7-70241/P	TV17.7 (100Hz)
SCHNEIDER	TV17170216	TV17 (100Hz)
SCHNEIDER	TV17170238	TV17 (100Hz)
SCHNEIDER	TV2050T	TV9.6
SCHNEIDER	TV2050T	TV9.6
SCHNEIDER	TV21M061	M35B
SCHNEIDER	TV21M301	M35-M36
SCHNEIDER	TV21M361	M35-M36 ?
SCHNEIDER	TV29M361	M35B
SCHNEIDER	TV4-5529/P	TV4
SCHNEIDER	TV4-70312/P	TV4
SCHNEIDER	TV4870	STV12
SCHNEIDER	TV6-5115	TV6
SCHNEIDER	TV70216	TV17 (100Hz)
SCHNEIDER	TV70224M	DTV101
SCHNEIDER	TV70231	TV17.1
SCHNEIDER	TV70238	TV17.7 (100Hz)
SCHNEIDER	TV70241	TV17.1 (100Hz)
SCHNEIDER	TV70420 SCS28	DTV3
SCHNEIDER	TV9.1-67131.13	TV9.1
SCHNEIDER	TV9.1-70238/N/SGM	TV9.1
SCHNEIDER	TV9.1-70241/p/SGM	TV9.1
SCHNEIDER	TVC2817	TV17.7 (100Hz)
SCHNEIDER	TVP145	11AK08

Brand	model	chassis
SCHNEIDER	TVS7035SKD	TV10 ?
SEELVER	SE36	CTR-AA
SEELVER	SE55 NIC	CTR-AA ?
SEG		11AK28
SEG	1425DVD	11AK46
SEG	CINEMA200	11AK16
SEG	CT1402A	11AK36
SEG	CT1404A	11AK36A8
SEG	CT1404A-GR	11AK36A8
SEG	CT1537/39	11AK20 (?) NIE!!!
SEG	CT1900 - llw.	11AK20
SEG	CT1900 - lw.	11AK08-12
SEG	CT1901 - llw.	11AK20
SEG	CT1901 - lw.	11AK08-12
SEG	CT20VT	11AK30
SEG	CT2101	11AK30
SEG	CT2102A	11AK30 ?
SEG	CT2110VT	11AK30A4
SEG	CT2112A	11AK30-2
SEG	CT2112S	11AK30A4
SEG	CT2500	11AK10
SEG	CT2500	11AK19-8A
SEG	CT2501	11AK10
SEG	CT2501	11AK19
SEG	CT251A	11AK19
SEG	CT2551	11AK10
SEG	CT2551	11AK19
SEG	CT2590ST	11AK10-8 !
SEG	CT2590ST	11AK19
SEG	CT2801	11AK19PRO
SEG	CT2810GR	11AK28-7
SEG	CT2813S	11AK52B6
SEG	CT3050	11AK10
SEG	CT3050	11AK19
SEG	CT3100ST	11AK10

Brand	model	chassis
SEG	CT3190ST	11AK19
SEG	CT3200ST	11AK10
SEG	CT3240BIF	11AK19
SEG	CT3250ST	11AK10
SEG	CT3250ST	11AK19 !
SEG	CT3252ST	11AK19
SEG	CT3290VTS-A	11AK28 (16:9)
SEG	CT362	11AK20
SEG	CT363	11AK20
SEG	CT510	11AK10
SEG	CT511	11AK10
SEG	CT710	11AK12
SEG	CT7227	11AK12
SEG	CT7700	11AK12-9
SEG	CT7700	11AK19-5 (11AK19PRO)
SEG	CT7800	11AK19-8A
SEG	CT7800	11AK19B
SEG	CT7800	11AK19E3 (?)
SEG	CT7800	11AK19P4
SEG	CT7850	11AK19
SEG	CT7900	11AK12
SEG	CT7950	11AK19PRO
SEG	CT8000	11AK12
SEG	CT8050	11AK18
SEG	CT8050	11AK18-6
SEG	CT8050	11AK19 ???
SEG	CT8100	11AK18
SEG	CT8100	11AK19 ???
SEG	CT8500	11AK12
SEG	CT9000	11AK12
SEG	CTV3280VTS-S	11AK37
SEG	CTV3710VT	NM
SEG	CTV5100	11AK10
SEG	CTV5110	11AK10
SEG	CTV5125	11AK10

Brand	model	chassis
SEG	CTV5510VT	NM
SEG	CTV5520VT	NM
SEG	CTV5525	11AK10
SEG	CTV7299	11AK16
SEG	CTV7900	11AK12
SEG	DUBLIN S II	11AK56-4 !
SEG	DUBLIN S III	11AK56-4 !
SEG	Nagano LCD-TV6322s	17MB11-6
SEG	Premium Cinema 2000 16/9	11AK19-8A (16:9)
SEG	Premium Fargo	11AK19PRO--11AK19P5
SELECO	14SE112	BS700
SELECO	14SE119	BS700
SELECO	14SE300	PC010
SELECO	14SM106	CTT-H
SELECO	16SB312	BS700
SELECO	17SM233	BS700
SELECO	17SM622	PC020
SELECO	17SM622TX	PC010,PC020
SELECO	17SM622TX	PC020
SELECO	20SA374	BS665
SELECO	20SB174	BS665
SELECO	20SM622	PC020
SELECO	20SM622TX	PC010,PC020
SELECO	20SM622TX	PC020
SELECO	21SM360	BS800
SELECO	21SM622	PC020
SELECO	21SM622TX	PC010,PC020
SELECO	21SM622TX	PC020
SELECO	21SM624	PC020
SELECO	21SS564	BS950
SELECO	21SS569	BS950.2
SELECO	25SB564	BS800
SELECO	25SM364	BS800
SELECO	25SS360	BS665
SELECO	25SS362	BS665

Brand	model	chassis
SELECO	25SS369	BS950
SELECO	25SS564	BS950
SELECO	25SS569	BS950
SELECO	25SS668	BS950
SELECO	28BS556	BS990
SELECO	28SS366	BS665
SELECO	28SS369E	BS950
SELECO	28SS556	BS990
SELECO	28SS564	BS950
SELECO	28SS569	BS950
SELECO	28SS575	PC220
SELECO	28SS653	BS990
SELECO	29SS687	BS950
SELECO	33SS628	PC04
SELECO	33SS655	PC040S
SELECO	37M12	PC230
SELECO	70SS644	PC170
SELECO	ISKG70S4496	F19 (FORMENTI)
SELECO	ISKK73SB5F0	PC240.0 100Hz
SELECO	ISKR83VA5F6	PC240.0 100Hz
SELECO	ISKS83VA5FE	PC240.0 100Hz
SELECO	ISKS83VA5FF	PC240.0 100Hz
SELECO	ISKS83VA5FG	PC240.0 100Hz
SELECO	ISVV70SB5FD	PC240.0 100Hz
SELECO	ISVV70VA5FD	PC240.0 100Hz
SELECO	ISVV72SB5FD	PC240.0 100Hz
SELECO	ISVV72VA5FD	PC240.0 100Hz
SELECO	ISVV72VA5FM	PC240.0 100Hz
SELECO	ISVV72VA5FN	PC240.0 100Hz
SELECO	KN2119	PC180-90
SELECO	M28SB640	PC170
SELECO	PSNFL37M12X52A	FPC2002
SELECO	S15E222	PC010
SELECO	S25S526	PC040
SELECO	S25S527	PC040

Brand	model	chassis
SELECO	S28S526	PC040
SELECO	S28S527	PC040
SELECO	TANGO PC230.1	PC230
SELECO	UE14-223	PC010
SENACO	SET2101DKT	C520
SERINO	STV2820	K110
SETRO	CTV1480TH	C50
SHARP	13G-M60	SN50
SHARP	13GM60	SN50
SHARP	13K-M100	SN80
SHARP	13K-M150	SN80
SHARP	14A1H	UA1
SHARP	14A2	UA1
SHARP	14A2X	UA1
SHARP	14AG1	UA1
SHARP	14AG2	UA1
SHARP	14AP1	UA1
SHARP	14B-SC	PAL
SHARP	14B2	UA1
SHARP	14BM2	UA1
SHARP	14BM2S	UA1
SHARP	14BN4	21B
SHARP	14BS10	UA1
SHARP	14BSC	PAL-A
SHARP	14D-SC	SP30 (?)
SHARP	14D1	GA1AM
SHARP	14D2	GA1AM
SHARP	14DSC	PAL
SHARP	14E2	UA1
SHARP	14E2RU	GA1AM
SHARP	14GT15	UA1
SHARP	14GT16	GA1
SHARP	14GT20	UA1
SHARP	14HSC	H
SHARP	14JN1	SP51

Brand	model	chassis
SHARP	14LK22	MSA
SHARP	14LM40C	11AK36A11
SHARP	14LSC (14L-SC)	L
SHARP	14LSC (21L-SC)	L
SHARP	14LT45C	11AK36A15
SHARP	14R2	SP70
SHARP	14U-FM1	GA2
SHARP	14V-J80M	SN70B
SHARP	14VJ80M	SN70B
SHARP	15JF25	GA1E
SHARP	15JF25H	GA1E
SHARP	15JF25S	GA1E
SHARP	19N-M100	SN000
SHARP	19N-M100S	SN000
SHARP	19R-M100	NS010
SHARP	19RM100	SN010
SHARP	19RM100S	SN010
SHARP	20A1	UA1
SHARP	20A2	UA1
SHARP	20AG1	UA1
SHARP	20AG2	UA1
SHARP	20AP1	UA1
SHARP	20AR31	MSA
SHARP	20B-SC	PAL
SHARP	20B2	UA1
SHARP	20BM2	UA1
SHARP	20BSC	SP70
SHARP	20CT250	G2
SHARP	20E2	UA1
SHARP	20GT20	UA1
SHARP	20HSC	H
SHARP	20L-S100S	SN80
SHARP	20LK30A	SN70A
SHARP	20LK60A	SN70A
SHARP	20MR10	SN010

Brand	model	chassis
SHARP	20MR15J	SN010
SHARP	20MR5J	SN010
SHARP	20PL83	MSA
SHARP	20SL43	MSA
SHARP	20V-J100M	SN70B
SHARP	20VJ100M	SN70B
SHARP	21A1	UA1
SHARP	21A2	UA1
SHARP	21A2X	UA1
SHARP	21AG1	UA1
SHARP	21AG2	UA1
SHARP	21AP1	UA1
SHARP	21B-SC	PAL ?
SHARP	21B2	UA1
SHARP	21BM2	UA1
SHARP	21BS10	UA1
SHARP	21D-CK1	SP30
SHARP	21D1G	UA1
SHARP	21E2	UA1
SHARP	21E2RU	GA1AM
SHARP	21F-PA18	GA7
SHARP	21F-PD250	GA7
SHARP	21F-PT220	GA7
SHARP	21FL84	GA4
SHARP	21FL90RU	11AK44
SHARP	21FL94	GA4
SHARP	21FN1	SP41 (A8)
SHARP	21GF30	UAF
SHARP	21GF50	UAF
SHARP	21GT20	UA1
SHARP	21HS50C	GA1E
SHARP	21HS50H	GA1E
SHARP	21HS50S	GA1E
SHARP	21HSC	H
SHARP	21HT15	GA1E

Brand	model	chassis
SHARP	21HT15C	GA1E
SHARP	21HT15H	GA1E
SHARP	21HT16C	GA1E
SHARP	21JN1	SP51
SHARP	21KF80S	GA1E
SHARP	21LF90C	11AK44
SHARP	21LS90C	11AK44 (?)
SHARP	21LT45C	11AK36A15 !
SHARP	21LT45S	11AK44
SHARP	21LV1	SP51 (?)
SHARP	21ML50	SN80
SHARP	21N52E1	2IA- M
SHARP	21R-SC	SP70
SHARP	21R2	SP70
SHARP	21SL41	SN80A
SHARP	21SL71	SN80A
SHARP	21VJ100M	SN70B
SHARP	21XF30	UAF ?
SHARP	21YF200	GA2
SHARP	25AK	A200
SHARP	25FN1	SP42M
SHARP	25FX5	SP43M
SHARP	25KN1S	SP61
SHARP	25LC156	25L3
SHARP	25R-M100	SN010
SHARP	25WF30	NFC
SHARP	25WG3	SS1
SHARP	26M-R30L	SN010
SHARP	26MR30	SN010
SHARP	26MR70	SN012
SHARP	26SL71	SN91A
SHARP	27K-S100	SN81
SHARP	27K-S180	SN81
SHARP	27K-S300	SN81
SHARP	27K-S400	SN81

Brand	model	chassis
SHARP	27KS100	SN81
SHARP	27L-S100	SN91
SHARP	27L-S180	SN91
SHARP	27L-S500	SN84
SHARP	27LS500	SN84
SHARP	27N-S300	SN81A
SHARP	27RS480	MS-B
SHARP	28HW53H	DA50W
SHARP	28HW57C	DA100W
SHARP	28HW57E	DA100W
SHARP	28JF73E	GA20
SHARP	28JF76	GA200
SHARP	28JF76E	GA200
SHARP	28JS74	GA200
SHARP	28JS74S	GA200
SHARP	28JS75	GA200
SHARP	28JW73H	GA20
SHARP	28JW74H00	GA20
SHARP	28JW76	GA200
SHARP	28JW76E	GA200
SHARP	28LF92E	11AK45
SHARP	28LF92H	11AK45 B5
SHARP	28LF96EC	11AK45B5 (czy 11AK53?)
SHARP	28LF96EC	11AK53
SHARP	28LS92EC	11AK45-5
SHARP	28SJ74	GA200
SHARP	28SJ74E	GA200
SHARP	28SJ75	GA200
SHARP	29AW4	A100
SHARP	29FL91M	GB3U
SHARP	29FN1	SP42M
SHARP	29H-FG5RU	GB4
SHARP	29JF76	GA200
SHARP	29KN1S	SP61
SHARP	29KX5	SP60

Brand	model	chassis
SHARP	29KX8N	SP60
SHARP	29LF92EC	11AK45 B5
SHARP	29MF96EC	11AK53 (?)
SHARP	29MK70	SN81
SHARP	29RA10	SP71
SHARP	29RN5	SS1
SHARP	29RX10	SP71
SHARP	29RX5	SP71
SHARP	29RX8	SP71
SHARP	29SL80	SN91A ?
SHARP	29SL81	SN91A
SHARP	29WF200	GB1
SHARP	29WF500	GB1
SHARP	29WV30	NFC (?)
SHARP	29XF30	GB1
SHARP	29XF50	GB1
SHARP	32HW53H	DA50W
SHARP	32HW57EDE	DA100W
SHARP	32JF74E	GA200
SHARP	32JF76	GA200
SHARP	32JF76E	GA200
SHARP	32JF76E	GA200
SHARP	32JW73H	GAO20
SHARP	32JW74E	GA200 ?
SHARP	32JW76E	GA200
SHARP	32LF92H	11AK45 B5 (?)
SHARP	32LF96EC	11AK53-1
SHARP	33AW4	A100
SHARP	34RH1	SP71
SHARP	36F830	GB3U
SHARP	37AM12H	5BS-A (?)
SHARP	37AM12SC	5BS
SHARP	37AM23H	5BS
SHARP	37AM23S	5BS
SHARP	37AM24S	5BS

Brand	model	chassis
SHARP	37AT25H	5BS
SHARP	37DM23SC	CA1
SHARP	37DT25H	CA1
SHARP	37DT25S	CA1
SHARP	37EM33	CA1
SHARP	37ET35S	CA1
SHARP	37FM14	CA1
SHARP	37FM14S	CA1
SHARP	37FT16S	CA1
SHARP	37GP20	SQUAD
SHARP	37GQ20S	SQUAD
SHARP	37GQ20S	SQUAD
SHARP	37GQ21S	SQUAD
SHARP	37GQ21S	SQUAD
SHARP	37GT25S	GA1
SHARP	37GT27S	SQUAD-T
SHARP	37VT26H	VP8
SHARP	51AM12S	5BS-A
SHARP	51AT15H	5BS-A
SHARP	51AT15S	5BS-A
SHARP	51DS02H	CA10
SHARP	51DS03H	CA10
SHARP	51DS05H	CA10
SHARP	51DT25H	CA1
SHARP	51ET35	CA1
SHARP	51FS51IR	CA10
SHARP	51GT25S	GA1
SHARP	54AM12S	5BS-A
SHARP	54AT15S	5BS-A
SHARP	54AT16SC	5BS-A
SHARP	54CS03S	CS
SHARP	54CS05S	CS
SHARP	54DM12SC	CA1
SHARP	54DS02S	CA10
SHARP	54DS03S	CA10

Brand	model	chassis
SHARP	54DT25SC	CA1
SHARP	54DT26SC	CA1
SHARP	54FS51S	CA10
SHARP	54FT16S	CA1
SHARP	54GS61S	GA10
SHARP	54GT25SC	CA1
SHARP	54GT25SDE VC	GA1
SHARP	56FW53H	DA50W
SHARP	60FW53E	DA50W
SHARP	63AS03S	4BS-C
SHARP	63AS06	4BS-C
SHARP	63CS03SC	CS
SHARP	63CS05S	CS
SHARP	63CS06S	CS
SHARP	63CT01	CS
SHARP	63DS03S	CA10
SHARP	63DS15S	CA100
SHARP	66AS05H	4BS-C
SHARP	66AS06H	BCTV-A
SHARP	66DW18H	CW100
SHARP	66FW53H	DA50W
SHARP	66FW54H	DA100 50Hz
SHARP	66GF63H	DA50W
SHARP	66GF64S	DA50W
SHARP	66GS62H	GA10
SHARP	66GS62S	GA10
SHARP	70 DS03S	CA10
SHARP	70 DS05S	CA10
SHARP	70 DS15S	CA100
SHARP	70 DS15S	CA100
SHARP	70 DS18S	CA100
SHARP	70AS01S	4BS-C
SHARP	70AS03S	4BS-C
SHARP	70AS05S	4BS-C
SHARP	70AS06S	BCTV-A ?

Brand	model	chassis
SHARP	70AT01SN	5BS-A
SHARP	70CS03S	CS
SHARP	70CS05S	CS
SHARP	70DW15S	CW100
SHARP	70DW15SN	CW100
SHARP	70DW18S	CW100
SHARP	70ES03S	CA10
SHARP	70ES04S	CA10
SHARP	70ES14S	DA100
SHARP	70ES15	CA10
SHARP	70ES16S	DA100
SHARP	70ES18S	CA100
SHARP	70ES18S	CA100
SHARP	70FS57S	DA100
SHARP	70FW53E	DA50W
SHARP	70FW57E	DA100W
SHARP	70GF63E	DA50W
SHARP	70GF66	DA100W
SHARP	70GF66E	DA100W
SHARP	70GF66SC	DA100W
SHARP	70GS01FP	CA10
SHARP	70GS61FP	GA10
SHARP	70GS61SC	GA10
SHARP	70GS62S	GA10
SHARP	70GS63	GA10 ?
SHARP	70GS64S	DA100 (100Hz)
SHARP	70GS65S	DA100 (100Hz)
SHARP	70GS66E	DA100 (100Hz)
SHARP	72AS18SN	BCTV-B
SHARP	72CS03S	CS
SHARP	72DS18S	CA100
SHARP	72FF57E	DA100W
SHARP	72GF66E	DA100W
SHARP	76DW18H	CW100
SHARP	76FW53H	DA50W

Brand	model	chassis
SHARP	76GF63H	DA50W
SHARP	81DW15SN	CW100
SHARP	81EF19E	DA100W - NIE! (EF19 ma dzieloną
SHARP	81FF57E	oktę - na zasilanie+odchylanie i DA100W
SHARP	81FW53E	DA50W
SHARP	81FW57E	DA100W
SHARP	81GF63E	DA50W
SHARP	81GF66E	DA100W
SHARP	C1402S	5P-S1
SHARP	C1410FS	4PSF
SHARP	C1412SS	4PSR
SHARP	C1420F	7P-F
SHARP	C1420F	7P-F
SHARP	C1421H	7P-SR1
SHARP	C1421S	7P-SR1
SHARP	C1440M	8P-S
SHARP	C1441M	8P-S
SHARP	C1451SC	14A ?
SHARP	C2120S	5P-S1
SHARP	C2121S	7P-SR1
SHARP	C2890E(ES)	11AK45
SHARP	C3700	7P-S
SHARP	C3701SS	5P-S1
SHARP	C3702SS	5P-S1
SHARP	C3703S	5P-S1
SHARP	C3704G	8P-S
SHARP	C3704S	8P-S
SHARP	C3720H	14A
SHARP	C5401N	5P-S1
SHARP	C5405F	4PSF
SHARP	C7015S	CA100 (F7209BMN4)
SHARP	CK13M10	SN80
SHARP	CK13M15	SN80
SHARP	CK27S10	SN81
SHARP	CK27S18	SN81

Brand	model	chassis
SHARP	CK27S30	SN81
SHARP	CK27S40	SN81
SHARP	CL20S10	SN80
SHARP	CL27S10	SN91
SHARP	CL27S18	SN91
SHARP	CN19M10	SN000
SHARP	CN27S30	SN81A
SHARP	CS21T70	20S1
SHARP	CS21T900	20S1
SHARP	CT2110S	8P-LS
SHARP	CT2510S	8P-LS
SHARP	CT2810S	8P-LS
SHARP	CU14FM1	GA2
SHARP	CV14RU	SP70
SHARP	CV2021S	7P-SR1
SHARP	CV2031G	7P-SR1 ?
SHARP	CV2031S	7P-SR1
SHARP	CV2121S	7P-SR1
SHARP	CV2132CK1	8P-SR ?
SHARP	CV2132CK1	SP30 ?
SHARP	CV3707SS	5P-SR1 ?
SHARP	CV3707SW	5P-SR1
SHARP	CV3709F	7P-FP
SHARP	CV3709S	7P-SR1
SHARP	CV3710S	8P-SR
SHARP	CV3720G	14A
SHARP	CV3720S	14A
SHARP	CV3730S	14B
SHARP	CV3745S	14B
SHARP	CV4207NW	5P-SR1
SHARP	CV5133SC	14B
SHARP	CV5407SW	5P-SR1
SHARP	CX3451S	14A
SHARP	CX34G3	SP61
SHARP	CX34L3	GA1

Brand	model	chassis
SHARP	CX34N3	GA1AM
SHARP	CX48K4	UA1
SHARP	CX51B2S	14B
SHARP	CX51B4S	14B
SHARP	CX51G3	SP61
SHARP	CX6336	NC6
SHARP	CX6336S	NC6
SHARP	CX68K5	NFC
SHARP	DV1416SN	DECO2
SHARP	DV21071S	D3000
SHARP	DV21081S	D3000
SHARP	DV2110G	4RSR1
SHARP	DV25071S	D3000
SHARP	DV25081S	D3000
SHARP	DV25083S	D3000
SHARP	DV28071S	D3000
SHARP	DV28081S	D3000
SHARP	DV28083S	D3000
SHARP	DV3730SN	DECO2
SHARP	DV3750H	S3B
SHARP	DV3750S	S3B
SHARP	DV3751H	S3B
SHARP	DV3751S	S3B (?)
SHARP	DV3760H	4BS-A
SHARP	DV3760S	4BS-A
SHARP	DV3761H	4BS-A
SHARP	DV3761S	S3B
SHARP	DV3765S	4BS-A
SHARP	DV3770H	4BS-A
SHARP	DV3770S	4BS-A
SHARP	DV4205N	4PSR1
SHARP	DV5101H	EURO-DS1
SHARP	DV5103H	EURO-DS1
SHARP	DV5105H	DECO4
SHARP	DV5107H	DECO5

Brand	model	chassis
SHARP	DV51083H	D3000
SHARP	DV5131H	S3B
SHARP	DV5131H	S3B
SHARP	DV5131S	S3B
SHARP	DV5132H	DECO5
SHARP	DV5135H	DECO5
SHARP	DV5150H	S3B
SHARP	DV5150S	S3B
SHARP	DV5161H	4BS-A
SHARP	DV5165H	4BS-B
SHARP	DV5180H	4BS-B
SHARP	DV5185	COSMOS3
SHARP	DV5401S	EURO-DS1
SHARP	DV5403S	DECO4
SHARP	DV5407S	DECO5
SHARP	DV5431S	DECO5
SHARP	DV5432S	DECO5
SHARP	DV5450SC	S3B
SHARP	DV5451S	S3B
SHARP	DV5451SC	S3B
SHARP	DV5460G	4BS-A ?
SHARP	DV5460SC	4BS-A
SHARP	DV5461SC	4BS-A
SHARP	DV5462SC	4BS-A
SHARP	DV5465S	4BS-B
SHARP	DV5470S	4BS-B
SHARP	DV5480S	4BS-B
SHARP	DV5903H	D3000
SHARP	DV59083H	D3000
SHARP	DV5932H	BCTV-A
SHARP	DV5935H	BCTV-A
SHARP	DV5937H	BCTV-A
SHARP	DV5940H	4BS-C
SHARP	DV6245S	BCTV-A
SHARP	DV6301S	D3000

Brand	model	chassis
SHARP	DV6303FP	D3000
SHARP	DV6303N	D3000
SHARP	DV6303S	D3000
SHARP	DV6311S	D3000
SHARP	DV6313N	D3000
SHARP	DV6313S	D3000
SHARP	DV6324S	D3000
SHARP	DV6332S	BCTV-A
SHARP	DV6336S	D3000
SHARP	DV6336S	D3000
SHARP	DV6340SC	4BS-C
SHARP	DV6345S	BCTV-A
SHARP	DV6355S	D3000
SHARP	DV6603H	D3000
SHARP	DV66083H	D3000
SHARP	DV6632H	4BS-C
SHARP	DV6635H	BCTV-A
SHARP	DV7001S	D3000
SHARP	DV7002S	D3000
SHARP	DV7003S	D3000
SHARP	DV7011S	D3000
SHARP	DV7032SC	4BS-C
SHARP	DV7035S	BCTV-A ?
SHARP	DV7036S	D3000
SHARP	DV7045S	D3000
SHARP	DV7052SC	4BS-C
SHARP	SV-U218	8P-LS
SHARP	SV2044S	9P-SR
SHARP	SV2145S	9P-SR (?)
SHARP	SV2188S	8P-LS
SHARP	SV2189H	8P-LS
SHARP	SV2189H	8P-LS
SHARP	SV2189S	8P-LS
SHARP	SV2577S	NC7
SHARP	SV2587S	8P-LS

Brand	model	chassis
SHARP	SV2588S	8P-LS
SHARP	SV2589S	8P-LS
SHARP	SV2597BK	8P-LS
SHARP	SV2877S	NC7
SHARP	SV2887S	8P-LS
SHARP	SV2888	8P-LS
SHARP	SV2888S	8P-LS
SHARP	SV2889	8P-LS
SHARP	SV2889S	8P-LS
SHARP	SV2897S	8P-LS
SHARP	SV3320S	8P-LS
SHARP	SX51B8	21B
SHARP	SX59E9	SP43M
SHARP	SX68C8	25A ?
SHARP	SX68E9	SP43M
SHARP	SX68JS7	SP60
SHARP	SX68JS9	SP60
SHARP	SX68K7	NFC
SHARP	SX76NF8	GA20X
SHARP	SX80H9S	SP71
SHARP	SX80J9	SP71
SHARP	TV21D-CK1A	PAL-A
SHARP	TV3701	SQUAD
SHARP	VT2118M	VP1
SHARP	VT3700H	VP1
SHARP	VT3705H	VP1
SHARP	XM1446S	9P-SR
SHARP	XM2146S	9P-SR
SHIVAKI	2022T	MC64A
SHIVAKI	212M4	PC04A
SHIVAKI	213M4	PC04A
SHIVAKI	CTV2135NF	(40-TV21AST-KC(N))
SHIVAKI	STV1414	DY300
SHIVAKI	STV1415	11AK20
SHIVAKI	STV141M4	PC04A ?

Brand	model	chassis
SHIVAKI	STV2023	DY300
SHIVAKI	STV2026	11AK19
SHIVAKI	STV2029	T50V
SHIVAKI	STV2033M4	PTXM01
SHIVAKI	STV2059T	TV2K
SHIVAKI	STV2110	DY300
SHIVAKI	STV2113	11AK19
SHIVAKI	STV2119	H501
SHIVAKI	STV2129T	T50V
SHIVAKI	STV2139	S0401
SHIVAKI	STV216M	MC41A ?
SHIVAKI	STV251M4	PC12A
SHIVAKI	STV255	11AK19
SHIVAKI	STV280 MULTI	MC15A
SHIVAKI	STV2802	11AK19
SHIVAKI	STV280M4	MC15A
SHIVAKI	STV281M4	PC12A
SHIVAKI	STV2905	DY900
SHIVAKI	T42M4	PC04A
SHIVAKI	VT14MKIII	CP310
SHOGUN	AX5000	P51-28
SHOGUN	MV5198	MFP5398
SIEMENS	CS9409	FS369
SIEMENS	CTV5653	FM100-30
SIEMENS	CTV6364	FM100-30
SIEMENS	CTV7035	FM100-30
SIEMENS	CTV7053	FM100-30
SIEMENS	FB785	FM100-20
SIEMENS	FB932	FM100-30
SIEMENS	FC143	CM8906
SIEMENS	FC147	CM8906
SIEMENS	FC200M6	CM9205
SIEMENS	FC201K4	CM9112
SIEMENS	FC201R4	CM9103
SIEMENS	FC202K	CM9300

Brand	model	chassis
SIEMENS	FC202K6	CM9300
SIEMENS	FC203R4	CM9103
SIEMENS	FC204R	CM9300
SIEMENS	FC206K6	CM9300
SIEMENS	FC207V4	CM9103
SIEMENS	FC208V4	CM9300
SIEMENS	FC209R4	CM9103
SIEMENS	FC210K6	CM9300
SIEMENS	FC211R4	CM9103
SIEMENS	FC212R6	CM9300
SIEMENS	FC301K6	CM9408
SIEMENS	FC607	FM100-20
SIEMENS	FC630	FM100-20
SIEMENS	FC631	FM100-20
SIEMENS	FC632	FM100-20
SIEMENS	FC634	FM100-20
SIEMENS	FC635	FM100-20
SIEMENS	FC636	FM100-20
SIEMENS	FC639	FM100-20
SIEMENS	FC640	FM100-20
SIEMENS	FC641	FM100-20
SIEMENS	FC643	FM100-20
SIEMENS	FC644	FM100-20
SIEMENS	FC645	FM100-20
SIEMENS	FC646	FM100-20
SIEMENS	FC647	FM100-20
SIEMENS	FC648	FM100-20
SIEMENS	FC650	FM100-20
SIEMENS	FC651	FM100-20
SIEMENS	FC653	FM100-20
SIEMENS	FC654	FM100-20
SIEMENS	FC656	FM100-20
SIEMENS	FC657	FM100-20
SIEMENS	FC658	FM100-20
SIEMENS	FC660	FM100-20

Brand	model	chassis
SIEMENS	FC671	FM100-20
SIEMENS	FC672	FM100-20
SIEMENS	FC674	FM100-20
SIEMENS	FC675	FM100-20
SIEMENS	FC676	FM100-20
SIEMENS	FC677	FM100-20
SIEMENS	FC678	FM100-21
SIEMENS	FC681	FM100-20
SIEMENS	FC683	FM100-20
SIEMENS	FC684	FM100-20
SIEMENS	FC684	FM100-20
SIEMENS	FC690	FM100-20
SIEMENS	FC691	FM100-20
SIEMENS	FC693	FM100-20
SIEMENS	FC694	FM100-20
SIEMENS	FC732	FM100-21
SIEMENS	FC740	FM100-20
SIEMENS	FC742	FM100-20
SIEMENS	FC746	FM100-20
SIEMENS	FC748	FM100-20
SIEMENS	FC752	FM100-20
SIEMENS	FC755	FM100-20
SIEMENS	FC756	FM100-20
SIEMENS	FC758	FM100-20
SIEMENS	FC770	FM100-20
SIEMENS	FC780	FM100-20
SIEMENS	FC800	FM100-21S
SIEMENS	FC820	FM100-21S
SIEMENS	FC821	FM100-21S
SIEMENS	FC830	FM100-21S
SIEMENS	FC832	FM100-21S
SIEMENS	FC833	FM100-21S
SIEMENS	FC835	FM100-21S
SIEMENS	FC837	FM100-21S
SIEMENS	FC840	FM100-20

Brand	model	chassis
SIEMENS	FC842	FM100-20
SIEMENS	FC843	FM100-20
SIEMENS	FC845	FM100-20
SIEMENS	FC846	FM100-20
SIEMENS	FC848	FM100-20
SIEMENS	FC850	FM100-20
SIEMENS	FC851	FM100-20
SIEMENS	FC852	FM100-20
SIEMENS	FC853	FM100-20
SIEMENS	FC855	FM100-20
SIEMENS	FC856	FM100-20
SIEMENS	FC872	FM100-30
SIEMENS	FC882	FM100-30
SIEMENS	FC910V4	CUC340-0
SIEMENS	FC912	FM100-30
SIEMENS	FC922	FM100-30
SIEMENS	FC933	FM100-30
SIEMENS	FC941H4	CM8906
SIEMENS	FC941K4	CM8906
SIEMENS	FC943K4	CM8906
SIEMENS	FC947K4	CM8906
SIEMENS	FC951K4	CM8906
SIEMENS	FC955	CM8905
SIEMENS	FC975	FM100-20
SIEMENS	FS169V4	CS8913
SIEMENS	FS189V4	CS9004
SIEMENS	FS192V4	CS9104
SIEMENS	FS207V4	CS9105
SIEMENS	FS213V4	CM9102
SIEMENS	FS215V4	CM9102
SIEMENS	FS220V4	CS9105
SIEMENS	FS221V6	CS9105
SIEMENS	FS223V4	CS9106
SIEMENS	FS227V6	CS9106
SIEMENS	FS228V4	CS0106

Brand	model	chassis
SIEMENS	FS229V6	CS9101
SIEMENS	FS231M6	CS9111
SIEMENS	FS231V6	CS9101
SIEMENS	FS233V4	CS9106
SIEMENS	FS235V6	CS9111
SIEMENS	FS236V2	CS9206
SIEMENS	FS236V6	CS9211
SIEMENS	FS237V6	CS9106 (CUC5360)
SIEMENS	FS238V6	CS9111
SIEMENS	FS239V6	CS9201
SIEMENS	FS241V6	CS9106
SIEMENS	FS245M5	CS9203
SIEMENS	FS245M6	CS9204
SIEMENS	FS246V6	CS9406
SIEMENS	FS247V6	CS9204
SIEMENS	FS248M6	CS9203
SIEMENS	FS256V6	CS9304
SIEMENS	FS256V6	CS9308
SIEMENS	FS268M6	CS9111
SIEMENS	FS269M4	CS9110
SIEMENS	FS271V6	CS9302
SIEMENS	FS272V6	CS9306
SIEMENS	FS275V6	CS9304
SIEMENS	FS275V6	CS9305 (100Hz)
SIEMENS	FS288M6	CS9307
SIEMENS	FS320	CS9403
SIEMENS	FS321V4	CS9403
SIEMENS	FS330V6	CS9401
SIEMENS	FS333M6	CS9401
SIEMENS	FS337V4	CS9501
SIEMENS	FS337V7	CS9501
SIEMENS	FS338V6	CS9402
SIEMENS	FS340M6	CS9402
SIEMENS	FS343V6	CS9402
SIEMENS	FS351V6	CS9402

Brand	model	chassis
SIEMENS	FS357V6	CUC1852 ?
SIEMENS	FS369M4	CS9409
SIEMENS	FS370M4	CS9410
SIEMENS	FS702	FM100-20
SIEMENS	FS707	FM100-20
SIEMENS	FS746	FM100-20
SIEMENS	FS756	FM100-20
SIEMENS	FS761	FM100-20
SIEMENS	FS764	FM100-20
SIEMENS	FS771	FM100-20
SIEMENS	FS772	FM100-20
SIEMENS	FS774	FM100-20
SIEMENS	FS775	FM100-20
SIEMENS	FS777	FM100-20
SIEMENS	FS778	FM100-20
SIEMENS	FS780	FM100-20
SIEMENS	FS781	FM100-20
SIEMENS	FS782	FM100-20
SIEMENS	FS783	FM100-20
SIEMENS	FS784	FM100-20
SIEMENS	FS785	FM100-20
SIEMENS	FS786	FM100-20
SIEMENS	FS787	FM100-20
SIEMENS	FS788	FM100-20
SIEMENS	FS791	FM100-20
SIEMENS	FS792	FM100-20
SIEMENS	FS793	FM100-20
SIEMENS	FS794	FM100-20
SIEMENS	FS798	FM100-20
SIEMENS	FS801	FM100-20
SIEMENS	FS804	FM100-20
SIEMENS	FS811	FM100-20
SIEMENS	FS812	FM100-20
SIEMENS	FS814	FM100-20
SIEMENS	FS816	FM100-20

Brand	model	chassis
SIEMENS	FS871	FM100-30
SIEMENS	FS874	FM100-30
SIEMENS	FS898	FM100-30
SIEMENS	FS906	CS8901
SIEMENS	FS916	FM100-30
SIEMENS	FS917	FM100-30
SIEMENS	FS921	FM100-20
SIEMENS	FS922	FM100-30
SIEMENS	FS924	FM100-30
SIEMENS	FS931	FM100-30
SIEMENS	FS932	FM100-30
SIEMENS	FS934	FM100-30
SIEMENS	FS940M4	CS8801
SIEMENS	FS948	CUC384-Siemens =CU3840-Grundig
SIEMENS	FS956K4	CS9003
SIEMENS	FS960K4	CS9003
SIEMENS	FS967	CS8901
SIEMENS	FS977	CS8901
SIEMENS	FS985M4	CS8907
SIEMENS	FS987V4	CS8911
SIEMENS	FS988M4	CS8911
SIEMENS	FS989M4	CS8912
SIEMENS	FS991V4	CS8912
SIEMENS	FS997M4	CS9002
SIEMENS	FS998M4	CS9001
SIEMENS	FV607	FM100-20
SIEMENS	FV783	FM100-20
SIEMENS	FV792	FM100-20
SIEMENS	FV812	FM100-20
SIEMENS	FV822	FM100-20
SIEMENS	FV842	FM100-20
SIEMENS	FV852	FM100-20
SIEMENS	FV882	FM100-30
SIEMENS	FV932	FM100-30
SIEMENS	FV936	FM100-30

Brand	model	chassis
SIEMENS	MCM21T1	N3
SIERA	SG1410	CTN-BB
SIERA	SG1420N	CTS-AA
SIERA	ST1403P	CTU AB
Silvercrest	CT2805	11AK49-7 ?
SINGER	S28WIDE	F19 ?
SINGER	S37TXT	PC230
SINGER	S51TXT	PC230
SINUDYNE	21370	CTU-AA
SINUDYNE	21500	PCB010 TMX472
SINUDYNE	34B0A	4400PROFESSIONAL ?
SINUDYNE	TENDER 2001	4300 PROFESSIONAL
SKY	SCRT3204	FPC2001 ?
SKYTRONIC	TV2050	K3720
SKYTRONIC	TV2550	2550
SKYWORTH	2522	5N11
SKYWORTH	2588	5N11
SKYWORTH	25F1	5N11
SKYWORTH	2922	5N11
SKYWORTH	2929	5N11
SKYWORTH	2998	5N11
SKYWORTH	29F1	5N11
SKYWORTH	3423	5N11
SKYWORTH	3498	5N11
SKYWORTH	CE5428	(60-L0549920-01A)
SKYWORTH	D25	5N11
SKYWORTH	D29	5N11
SKYWORTH	L25	5N11
SKYWORTH	L29	5N11
SKYWORTH	L34	5N11
SMARAGD	58618703	COMPACT D-E B1
SMARTVISION	2120	TV2K
SOKOL	51TC6152	A2010Z
SONITRON	S1014TXT	EC7A
SONOLOR	36050SM	MONO PLUS

Brand	model	chassis
SONOLOR	63SN501	EUROMONO2 (6945 0760-27)
SONOLOR	63SN601	EUROSTEREO2
SONOLOR	71SN701	EUROSTEREO2
SonTec	SO2828	SM2
SONY	CKV20 DST1	BA1
SONY	CKV20HX1	BA1
SONY	KCC2570B	AE1C
SONY	KD28DL11U	FE2D
SONY	KD30XS955	DA4
SONY	KD32 NS200	AE6D ?
SONY	KD32 NX100U	AE6D
SONY	KD32 NX200	AE6D
SONY	KD32DX100U	AE6D
SONY	KD32DX150	AE6D ?
SONY	KD32NS100B	AE6D
SONY	KD34XBR2	HA3
SONY	KD34XBR960	DA4
SONY	KD34XS955	DA4
SONY	KD36XS955	DA4
SONY	KDE-P37KS1	XS1
SONY	KDE-P37SX1	SX1
SONY	KDE-P42KS1	XS1
SONY	KDE-P42MRX1D	MRX1D
SONY	KDE-P42SX1	SX1
SONY	KDE-P50MRX1	MRX1
SONY	KDE-P61MRX1D	MRX1
SONY	KDF46E2000	LA4
SONY	KDF46E2010	LA4
SONY	KDF50E2000	LA4
SONY	KDF50E2010	LA4
SONY	KDF55E2000	LA4
SONY	KDF55E2010	LA4
SONY	KDF55WF655	LA3
SONY	KDF55WF655K	LA3
SONY	KDF60WF655K	LA3

Brand	model	chassis
SONY	KDL-L32MRX1D	MRX1
SONY	KDL-V26XBR1	MIX5
SONY	KDL-V32XBR1	MIX5
SONY	KDL-V40XBR1	MIX5
SONY	KDL-W40A11E	AT2X
SONY	KDL26S2000E/U	WAX2
SONY	KDL32S20	WAX2
SONY	KDL32S2000E/U	WAX2
SONY	KDL40S2000E/U	WAX2
SONY	KDL40S2010	WAX2
SONY	KDL40S20L	WAX2
SONY	KDL40S3000	WAX3
SONY	KDL40U2000	SE1
SONY	KDL40V2000	WAX2
SONY	KDL40XBR4	FIX2
SONY	KDL40XBR5	FIX2
SONY	KDL46S2000E/U	WAX2
SONY	KDL46XBR4	FIX2
SONY	KDL46XBR5	FIX2
SONY	KDP51WS550	AX1
SONY	KDP57WS550	AX1
SONY	KDP65WS550	AX1
SONY	KDS-R50XBR1	SP1
SONY	KDS-R60XBR1	SP1
SONY	KE-P42MRX1D	MRX1
SONY	KE-P61MRX1D	MRX1
SONY	KE42XS910	MR2
SONY	KF-E42A10	MIX5
SONY	KF-WE42A1	LG3
SONY	KF-WE42S1	LG3
SONY	KF-WE50A1	LG3
SONY	KF-WS60A1	LG3
SONY	KF42SX300	LE4A
SONY	KF42WE610	LA2
SONY	KF50-60XBR800	LA1A

Brand	model	chassis
SONY	KF50SX100	LE3
SONY	KF50SX200	LE3A
SONY	KF50SX200K	LE3A
SONY	KF50SX200U	LE3A
SONY	KF50SX300	LE4A
SONY	KF50WE610	LA2
SONY	KF60DX100	LA1
SONY	KF60WE610	LA2
SONY	KL37W1K	LE1
SONY	KL37W2K	LE1
SONY	KL40W1K	LE2
SONY	KL40WA1K	LE2
SONY	KL40WA1U	LE2
SONY	KL50W1K	LE1
SONY	KL50W2K	LE1
SONY	KL53XBR300	RA4A
SONY	KL61XBR300	RA4A
SONY	KLV-L32MRX1D	MRX1
SONY	KLV-L42MRX1	MRX1
SONY	KLV-S19A10	WAX
SONY	KLV-S23A10	WAX
SONY	KLV20SR3	WA1
SONY	KLV26HG2	AT2
SONY	KLV27HR3	WA1
SONY	KLV32M1	AT2
SONY	KLV32T200A	CH1
SONY	KLV40T200A	CH1
SONY	KP-E53SN11	RG1 ?
SONY	KP-EF41HK	RG2
SONY	KP-EF41HK2	RG2
SONY	KP-EF41ME	RG2
SONY	KP-EF41ME2	RG2
SONY	KP-EF41MN	RG2
SONY	KP-EF41MN2	RG2
SONY	KP-EF41SN	RG2

Brand	model	chassis
SONY	KP-EF48HK	RG2
SONY	KP-EF48HK2	RG2
SONY	KP-EF48ME	RG2
SONY	KP-EF48MN	RG2
SONY	KP-EF48MN2	RG2
SONY	KP-EF48SN	RG2
SONY	KP-EF53HK	RG2
SONY	KP-EF53HK2	RG2
SONY	KP-EF53ME	RG2
SONY	KP-EF53ME2	RG2
SONY	KP-EF53MN	RG2
SONY	KP-EF53MN2	RG2
SONY	KP-EF53SN	RG2
SONY	KP-EF61HK	RG2
SONY	KP-EF61HK2	RG2
SONY	KP-EF61ME	RG2
SONY	KP-EF61MN	RG2
SONY	KP-EF61MN2	RG2
SONY	KP-EF61MN2	RG2
SONY	KP-EF61SN	RG2
SONY	KP-EFxxxx	RG2
SONY	KP-ER43M31	RG3A
SONY	KP-ER43M61	RG3A
SONY	KP-ER43M90	RG3A
SONY	KP-ER43M90	RG3A
SONY	KP-ER43M91	RG3A
SONY	KP-ER53M31	RG3A
SONY	KP-ER53M61	RG3A
SONY	KP-ER53M90	RG3A
SONY	KP-ER53M90	RG3A
SONY	KP-ER53M91	RG3A
SONY	KP-ES48SN1	RG3 ?
SONY	KP-FR43M31	AX1
SONY	KP-FR43M91	AX1
SONY	KP-FW46M91	AX1

Brand	model	chassis
SONY	KP-S4111K	AP1E
SONY	KP-S4112U	AP1E
SONY	KP-S4113	AP1E
SONY	KP-S4613	AP2
SONY	KP-S4613/2	AP1E
SONY	KP-XA43M31	RG2
SONY	KP-XA43M61	RG2
SONY	KP-XA43M61	RG2
SONY	KP-XA43M91	RG2
SONY	KP-XA43N90J	RA3B
SONY	KP41DS1	RE2D
SONY	KP41EXR96	AP
SONY	KP41P3K	RE1
SONY	KP41PX2	AE6X
SONY	KP41PZ1E	RE2D
SONY	KP41S3	RE1
SONY	KP41S4B	RE2
SONY	KP41S5	RE2
SONY	41S5K/41S5R/41S5U	
SONY	KP41S5B	RE2
SONY	KP41S5G	RE2
SONY	KP41S5K	RE2
SONY	KP41S5R	RE2
SONY	KP41S5U	RE2
SONY	KP41T15	RA1
SONY	KP41T25	RA1
SONY	KP41T35	RA2
SONY	KP41T65K	RA2A
SONY	KP41T65T	RA2A
SONY	KP43HT20 53HS20 53HS30	RA6
SONY	61HS20 61HS30	
SONY	KP43T70C	RA3
SONY	KP43T70K	RA3
SONY	KP43T90	RA3B
SONY	KP44PX2	AE6X
SONY	KP4612U	AP1E
SONY	KP46C36	RA2

Brand	model	chassis
SONY	KP46C65	RA2A
SONY	KP46C70	RA3
SONY	KP46S15	RA1
SONY	KP46S17	RA1
SONY	KP46S25	RA1
SONY	KP46S3K	RX1
SONY	KP46S4K	RX1E
SONY	KP46S55	AP
SONY	KP46V15	AP
SONY	KP46V16	AP
SONY	KP46WT510	RA6A
SONY	KP46WT520	AX1X
SONY	KP46XBR25	AP
SONY	KP46XBR35	AP
SONY	KP48PS1K	RE3
SONY	KP48PS2	RE3
SONY	KP48S35	RA2
SONY	KP48S65R	RA2A
SONY	KP48S70	RA3
SONY	KP48S72	RA3
SONY	KP48V45	RA2
SONY	KP48V75K	RA2A
SONY	KP48V80	RA3
SONY	KP48V85	RA3A
SONY	KP48V90	RA3B
SONY	KP48VS70K	RA3
SONY	KP51DS1	RE2B
SONY	KP51HW40	RA6
SONY	KP51WS500	RA6
SONY	KP51WS505	RA6A ?
SONY	KP51WS520	AX1X
SONY	KP53N74	RA3
SONY	KP53S15	RA1
SONY	KP53S17	RA1
SONY	KP53S25	RA1

Brand	model	chassis
SONY	KP53S35	RA2
SONY	KP53S4K	RX1E
SONY	KP53S55	AP
SONY	KP53S65T	RA2A
SONY	KP53S70	RA3
SONY	KP53SV70C	RA3
SONY	KP53V15	AP
SONY	KP53V16	AP
SONY	KP53V45	RA2
SONY	KP53V75K	RA2A
SONY	KP53V80	RA3
SONY	KP53V90	RA3B
SONY	KP53VS70K	RA3
SONY	KP53XBR200	RA4
SONY	KP53XBR25	AP
SONY	KP53XBR35	AP
SONY	KP57HW40	RA6
SONY	KP57WS500	RA6
SONY	KP57WV600	DA4X
SONY	KP57XBR10W	RA4W
SONY	KP60WV600	DA4X
SONY	KP61PS1K	RE3
SONY	KP61S35	RA2
SONY	KP61S65	RA2A
SONY	KP61S70	RA3
SONY	KP61SV70C	RA3
SONY	KP61V15	AP
SONY	KP61V25	RA1
SONY	KP61V45	RA2
SONY	KP61V80	RA3
SONY	KP61V90	RA3B
SONY	KP61XBR200	RA4
SONY	KP61XBR28	AP
SONY	KP61XBR38	AP
SONY	KP65WS500	RA6

Brand	model	chassis
SONY	KP65WV600	DA4X
SONY	KP65XBR10W	RA4W
SONY	KPEF41HK2	RG2
SONY	KPEF41ME2	RG2
SONY	KPEF41MN2	RG2
SONY	KPEF48HK2	RG2
SONY	KPEF48MN2	RG2
SONY	KPEF48MN2	RG2
SONY	KPEF53HK2	RG2
SONY	KPEF53ME2	RG2
SONY	KPEF53MN2	RG2
SONY	KPEF61HK2	RG2
SONY	KPEF61MN2	RG2
SONY	KPEF61MN2	RG2
SONY	KPR46EXR15	AP
SONY	KPR46XBR15	AP
SONY	KPR53EXR15	AP
SONY	KPR53XBR15	AP
SONY	KS50SX200	LE3A
SONY	KV-A2110B	AE1C
SONY	KV-A2110B	AE1C
SONY	KV-A2111D	AE1C
SONY	KV-A2111D	AE1C
SONY	KV-A2112U	AE1C
SONY	KV-A2112U	AE1C
SONY	KV-A2113E	AE1C
SONY	KV-A2113E	AE1C
SONY	KV-A2120B	AE1C
SONY	KV-A2120B	AE1C
SONY	KV-A2121D	AE1C
SONY	KV-A2121D	AE1C
SONY	KV-A2122U	AE1C
SONY	KV-A2122U	AE1C
SONY	KV-A2123E	AE1C
SONY	KV-A2123E	AE1C

Brand	model	chassis
SONY	KV-A2131D	AE2A
SONY	KV-A2131D	AE2A
SONY	KV-A2132U	AE2A
SONY	KV-A2132U	AE2A
SONY	KV-A2133E	AE2A
SONY	KV-A2133E	AE2A
SONY	KV-A2510B	AE1C
SONY	KV-A2510B	AE1C
SONY	KV-A2511D	AE1C
SONY	KV-A2511D	AE1C
SONY	KV-A2512U	AE1C
SONY	KV-A2512U	AE1C
SONY	KV-A2513B	AE1C
SONY	KV-A2513B	AE1C
SONY	KV-A2520B	AE1C
SONY	KV-A2520B	AE1C
SONY	KV-A2521K	AE1C
SONY	KV-A2522U	AE1C
SONY	KV-A2522U	AE1C
SONY	KV-A2523E	AE1C
SONY	KV-A2531D	AE2A
SONY	KV-A2531D	AE2A
SONY	KV-A2532U	AE2A
SONY	KV-A2532U	AE2A
SONY	KV-A2533E	AE2A
SONY	KV-A2533E	AE2A
SONY	KV-A2541K	AE2B
SONY	KV-A2541K	AE2B
SONY	KV-A2542U	AE2B
SONY	KV-A2542U	AE2B
SONY	KV-A2543B	AE2B
SONY	KV-A2543B	AE2B
SONY	KV-A2910B	AE1C
SONY	KV-A2910B	AE1C
SONY	KV-A2911D	AE1C

Brand	model	chassis
SONY	KV-A2911D	AE1C
SONY	KV-A2912U	AE1C
SONY	KV-A2912U	AE1C
SONY	KV-A2913E	AE1C
SONY	KV-A2913E	AE1C
SONY	KV-A2920B	AE1C
SONY	KV-A2920B	AE1C
SONY	KV-A2921D	AE1C (SCC-F07B-A)
SONY	KV-A2921K	AE1C
SONY	KV-A2921K	AE1C
SONY	KV-A2922U	AE1C
SONY	KV-A2922U	AE1C
SONY	KV-A2923E	AE1C
SONY	KV-A2923E	AE1C
SONY	KV-A2932D	AE2A
SONY	KV-A2932D	AE2A
SONY	KV-A2932U	AE2A
SONY	KV-A2932U	AE2A
SONY	KV-A2933E	AE2A
SONY	KV-A2933E	AE2A
SONY	KV-A2941K	AE2B
SONY	KV-A2941K	AE2B
SONY	KV-A2942U	AE2B
SONY	KV-A2942U	AE2B
SONY	KV-A2943B	AE2B
SONY	KV-A2943B	AE2B
SONY	KV-A29T80C	BY1A (Chiny)
SONY	KV-A3410B	DE2
SONY	KV-A3410B	DE2
SONY	KV-A3411D	DE2
SONY	KV-A3411D	DE2
SONY	KV-A3412U	DE2
SONY	KV-A3412U	DE2
SONY	KV-A3413E	DE2
SONY	KV-A3413E	DE2

Brand	model	chassis
SONY	KV-AR142P52	BX1S
SONY	KV-AR14M80	BX1
SONY	KV-AR14M90	BX1S
SONY	KV-AR21M30	BX1
SONY	KV-AR21M50	BX1
SONY	KV-AR21M61	BX1
SONY	KV-AR21M81	BX1
SONY	KV-AR21M90	BX1
SONY	KV-AR252 N90	BX1
SONY	KV-AR252M50	BX1L
SONY	KV-AR252M61	BX1L
SONY	KV-AR252M81	BX1L
SONY	KV-AR25M80	BG3R
SONY	KV-AR25M90B	BX1
SONY	KV-AR292 N90	BX1
SONY	KV-AR292M61	BX1
SONY	KV-AR292M81	BX1L
SONY	KV-AR29M80A	BG3R
SONY	KV-AR29T80C	BY1A
SONY	KV-B14K3	G3E(D)
SONY	KV-B2511D	AE2
SONY	KV-B2511K	AE2
SONY	KV-B2511K	AE2
SONY	KV-B2512U	AE2
SONY	KV-B2512U	AE2
SONY	KV-B2513E	AE2
SONY	KV-B2513E	AE2
SONY	KV-B2521K	AE2B
SONY	KV-B2523B	AE2B
SONY	KV-B2531D	BE3B
SONY	KV-B2531D	BE3B
SONY	KV-B2533B	BE3B
SONY	KV-B2533B	BE3B
SONY	KV-B2911D	AE2
SONY	KV-B2911K	AE2

Brand	model	chassis
SONY	KV-B2911K	AE2
SONY	KV-B2912U	AE2
SONY	KV-B2912U	AE2
SONY	KV-B2913E	AE2
SONY	KV-B2913E	AE2
SONY	KV-B2921D	AE2B
SONY	KV-B2921D	AE2B
SONY	KV-B2923B	AE2B
SONY	KV-B2923B	AE2B
SONY	KV-B2931D	BE3B
SONY	KV-B2931D	BE3B
SONY	KV-B2933B	BE3B
SONY	KV-B2933B	BE3B
SONY	KV-BM14M10	BX1S
SONY	KV-BM14M40	BX1S
SONY	KV-BM14M70	BX1
SONY	KV-BM14N40	BX1S
SONY	KV-BM14N70	BX1S
SONY	KV-BM14P40	BX1
SONY	KV-BM14P42	BX1
SONY	KV-BM21M70	BX1
SONY	KV-BM21P42	BX1 ?
SONY	KV-BT212 N40	BX1S
SONY	KV-BT212 N50	BX1S
SONY	KV-BT212M80	BX1S
SONY	KV-BT212M81	BX1S
SONY	KV-BT212P40	BX1S
SONY	KV-BT212P52	BX1S
SONY	KV-BT212P52	BX1S ?
SONY	KV-BT212P52/L	BX1S
SONY	KV-BT212P52/N	BX1S
SONY	KV-BT21M40	BX1
SONY	KV-BT21M50	BX1S
SONY	KV-BT21M80	BX1S
SONY	KV-BT21M81	BX1S

Brand	model	chassis
SONY	KV-BT21M90	BX1S
SONY	KV-BT21P40	BX1
SONY	KV-BT21P52	BX1
SONY	KV-C2120B	AE1C
SONY	KV-C2120B	AE1C
SONY	KV-C2121D	AE1C
SONY	KV-C2121D	AE1C
SONY	KV-C2122U	AE1C
SONY	KV-C2122U	AE1C
SONY	KV-C2123E	AE1C
SONY	KV-C2123E	AE1C
SONY	KV-C2160B	AE1C
SONY	KV-C2160B	AE1C
SONY	KV-C2161D	AE1C
SONY	KV-C2161D	AE1C
SONY	KV-C2163E	AE1C
SONY	KV-C2163E	AE1C
SONY	KV-C2171K	BE3B
SONY	KV-C2171K	BE3B
SONY	KV-C2173B	BE3B
SONY	KV-C2173B	BE3B
SONY	KV-C2501A	BE3C
SONY	KV-C2501D	BE3C
SONY	KV-C2501D	BE3C
SONY	KV-C2503B	BE3C
SONY	KV-C2503B	BE3C
SONY	KV-C2508D	BE3C
SONY	KV-C2508D	BE3C
SONY	KV-C2509K	BE3C
SONY	KV-C2509K	BE3C
SONY	KV-C2520B	AE1B
SONY	KV-C2520B	AE1B
SONY	KV-C2521K	AE1B
SONY	KV-C2522U	AE1C
SONY	KV-C2522U	AE1C

Brand	model	chassis
SONY	KV-C2523D	AE1B
SONY	KV-C2530B	AE1B
SONY	KV-C2530B	AE1B
SONY	KV-C2531D	AE1B
SONY	KV-C2531D	AE1B
SONY	KV-C2533D	AE1B
SONY	KV-C2533D	AE1B
SONY	KV-C2540B	AE1C
SONY	KV-C2540B	AE1C
SONY	KV-C2543E	AE1C
SONY	KV-C2543E	AE1C
SONY	KV-C2550B	AE1C
SONY	KV-C2550B	AE1C
SONY	KV-C2551D	AE1C
SONY	KV-C2551D	AE1C
SONY	KV-C2553E	AEC
SONY	KV-C2553E	AEC
SONY	KV-C2560B	AE1C
SONY	KV-C2560B	AE1C
SONY	KV-C2561D	AE1C
SONY	KV-C2561D	AE1C
SONY	KV-C2563E	AE1C
SONY	KV-C2563E	AE1C
SONY	KV-C2569D	AE1C
SONY	KV-C2569D	AE1C
SONY	KV-C2571D	AE1C
SONY	KV-C2571D	AE1C
SONY	KV-C2573E	AE1C
SONY	KV-C2573E	AE1C
SONY	KV-C2580B	BE3B
SONY	KV-C2580B	BE3B
SONY	KV-C2581D	BE3B
SONY	KV-C2581D	BE3B
SONY	KV-C2583E	BE3B
SONY	KV-C2583E	BE3B

Brand	model	chassis
SONY	KV-C2591A	BE3B
SONY	KV-C2591A	BE3B
SONY	KV-C25TD	AE1
SONY	KV-C2721D	AE1 (SCC-B14X-A)
SONY	KV-C2723D	AE1
SONY	KV-C27M	AE1 ? (SCC-C13A)
SONY	KV-C27TD	AE1
SONY	KV-C2901K	BE3C
SONY	KV-C2902U	BE3C
SONY	KV-C2903B	BE3C
SONY	KV-C2908D	BE3C
SONY	KV-C2908E	BE3C
SONY	KV-C2909E	BE3C
SONY	KV-C2909K	BE3C
SONY	KV-C2910B	AE1
SONY	KV-C2911D	AE1
SONY	KV-C2913D	AE1
SONY	KV-C2920B	AE1
SONY	KV-C2921D	AE1B
SONY	KV-C2921K	AE1B
SONY	KV-C2923E	AE1B
SONY	KV-C2930B	AE1B
SONY	KV-C2931D	AE1B
SONY	KV-C2933E	AE1B
SONY	KV-C2941D	AE1C
SONY	KV-C2949D	AE1C
SONY	KV-C2950B	AE1C
SONY	KV-C2951D	AE1C
SONY	KV-C2953E	AE1C
SONY	KV-C2960B	AE1C
SONY	KV-C2961D	AE1C
SONY	KV-C2963E	AE1C
SONY	KV-C2969D	AE1C
SONY	KV-C2970B	AE1C
SONY	KV-C2971D	AE1C

Brand	model	chassis
SONY	KV-C2973E	AE1C
SONY	KV-C2980B	BE3B
SONY	KV-C2981D	BE3B
SONY	KV-C2983E	BE3B
SONY	KV-C2991D	BE3B
SONY	KV-D2510B	AE1A
SONY	KV-D2511D	AE1A
SONY	KV-D2512U	AE1A
SONY	KV-D2513E	AE1A
SONY	KV-D2531A	AE1C
SONY	KV-D2533E	AE1C
SONY	KV-D2910B	AE1A
SONY	KV-D2911D	AE1A
SONY	KV-D2912U	AE1A
SONY	KV-D2913E	AE1A
SONY	KV-D2921D	AE1A
SONY	KV-D2931A	AE1C
SONY	KV-D2933E	AE1C
SONY	KV-D3410B	DE1
SONY	KV-D3411D	DE1
SONY	KV-D3412U	DE1
SONY	KV-D3413D	DE1
SONY	KV-D3421D	DE1
SONY	KV-D3431D	DE2
SONY	KV-D3432U	DE2
SONY	KV-D3433E	DE2
SONY	KV-DA29M81	CX1
SONY	KV-DA34M61	CX1
SONY	KV-DA34M61	CX1
SONY	KV-DA34M80	CX1
SONY	KV-DA34M81	CX1
SONY	KV-DA34X80	CX1
SONY	KV-DR29M39	AG3E
SONY	KV-DR29M61	AG3E
SONY	KV-DR29M81	AG3E

Brand	model	chassis
SONY	KV-DR34M97	AG3E
SONY	KV-DW36K9H	DX1J
SONY	KV-DX2112U	AE1
SONY	KV-DX21TD	AE1
SONY	KV-DX271TU	AE1
SONY	KV-DX27TD	AE1
SONY	KV-DX29K9H	DX1J
SONY	KV-E2510B	AE1A
SONY	KV-E2511D	AE1A
SONY	KV-E2512U	AE1A
SONY	KV-E2513E	AE1A
SONY	KV-E2521D	AE1C
SONY	KV-E2522U	AE1C
SONY	KV-E2522U	AE1C
SONY	KV-E2523E	AE1C
SONY	KV-E2531D	AE2
SONY	KV-E2532U	AE2
SONY	KV-E2533E	AE2
SONY	KV-E2541D	AE2A
SONY	KV-E2542U	AE2A
SONY	KV-E2543E	AE2A
SONY	KV-E2551D	AE2B
SONY	KV-E2553E	AE2B
SONY	KV-E2561K	AE2F
SONY	KV-E2563B	AE2F
SONY	KV-E2563D	AE2F
SONY	KV-E2910B	AE1A
SONY	KV-E2911D	AE1A
SONY	KV-E2912U	AE1A
SONY	KV-E2913E	AE1A
SONY	KV-E2921D	AE1C
SONY	KV-E2922U	AE1C
SONY	KV-E2923E	AE1C
SONY	KV-E2925U	AE1C
SONY	KV-E2931D	AE2

Brand	model	chassis
SONY	KV-E2932U	AE2
SONY	KV-E2932U	AE2
SONY	KV-E2933E	AE2
SONY	KV-E2941D	AE2A
SONY	KV-E2942U	AE2A
SONY	KV-E2943E	AE2A
SONY	KV-E2951D	AE2B
SONY	KV-E2953E	AE2B
SONY	KV-E2961A	AE2F
SONY	KV-E2961B	AE2F
SONY	KV-E2961D	AE2F
SONY	KV-E2961K	AE2F
SONY	KV-E2963E	AE2F
SONY	KV-E29MF8	BG1L
SONY	KV-E29MH8	BG1L
SONY	KV-E29MH81	BG1L
SONY	KV-E29MN1	BG1L
SONY	KV-E29MN81	BG1L
SONY	KV-E29SN81	BG1L
SONY	KV-E3431D	AE2
SONY	KV-E3431D	AE2
SONY	KV-E3431D	AE2F
SONY	KV-E3433B	AE2B
SONY	KV-EF29M31	BG1L
SONY	KV-EF29M61	BG1L
SONY	KV-EF29M80	BG1L
SONY	KV-EF29M90	BG1L
SONY	KV-EF29M91	BG1L
SONY	KV-EF29N6A	BG1L
SONY	KV-EF29N9P	BG1L
SONY	KV-EF34M31	BG3S
SONY	KV-EF34M61	BG3S
SONY	KV-EF34M80	BG3S (SCC-U28D-A)
SONY	KV-EF34M90	BG3S
SONY	KV-EF34M91	BG3S

Brand	model	chassis
SONY	KV-EF34N90	BG3S
SONY	KV-ES29M31	AG3
SONY	KV-ES29M61	AG3
SONY	KV-ES29M80	AG3
SONY	KV-ES29M81	AG3
SONY	KV-ES29M90	AG3
SONY	KV-ES34K9H	DX1J
SONY	KV-ES34M31	AG3
SONY	KV-ES38K9H	DX1J
SONY	KV-EX29M87	AG3E
SONY	KV-EX34M67	AG3E
SONY	KV-EX34M97	AG3E
SONY	KV-F25MF1	G3F
SONY	KV-FX2913E	FX
SONY	KV-FX2921B	FX
SONY	KV-FX29TD	FX
SONY	KV-G14L2J	BG2S
SONY	KV-G14M1	BG1S
SONY	KV-G14MD1	BG1S
SONY	KV-G14P1	BG1S
SONY	KV-G14P11	BG1S
SONY	KV-G14Q1	BG1S
SONY	KV-G14S1	BG1S
SONY	KV-G21L3	BG1S
SONY	KV-G21M1	BG1S
SONY	KV-G21M2J	BG2S
SONY	KV-G2515U	AE2B
SONY	KV-G2515U	AE2B
SONY	KV-G25M1	BG1S
SONY	KV-G2915D	AE2B
SONY	KV-HA21M50	BG2T
SONY	KV-HA21M60	BG2T
SONY	KV-HA21M80	BG2T
SONY	KV-HA21M80/H	BG2T
SONY	KV-HA21M81	BG2T

Brand	model	chassis
SONY	KV-HA21M83A	BG2T
SONY	KV-HA21P52	BG2T
SONY	KV-HD3215	EH1
SONY	KV-HF21M80	BG3S
SONY	KV-HF21N70	BG3S
SONY	KV-HF51P50	BG3S
SONY	KV-HR36M61	AX1
SONY	KV-HS29M61	AG3F
SONY	KV-HS29M90	AG3F
SONY	KV-HS29M91	AG3F
SONY	KV-HW212M81	BX1S
SONY	KV-HW212M83	BX1S
SONY	KV-HW212P52	BX1S
SONY	KV-HW21M30	BX1S
SONY	KV-HW21M50	BX1
SONY	KV-HW21M50	BX1S
SONY	KV-HW21M53	BX1S
SONY	KV-HW21M60	BX1
SONY	KV-HW21M63	BX1
SONY	KV-HW21M80	BX1 (czy? BX1S)
SONY	KV-HW21M83	BX1
SONY	KV-HW21M85	BX1S
SONY	KV-HW21N63	BX1S
SONY	KV-HW21P20A	BG2T
SONY	KV-HW21P80A	BG2T
SONY	KV-HZ29M55	AX1
SONY	KV-J14M1	BG2S
SONY	KV-J21MF1AK	BG1S(D)
SONY	KV-J21MF2J	BG2S
SONY	KV-J21MF3	BG1S(D)
SONY	KV-J21MN1AK	BG1S(D)
SONY	KV-J21PF1	BG1S(D)
SONY	KV-J25MF8	BG1L
SONY	KV-J25MF8J	BG1L
SONY	KV-J29MF1	BG1L (?)

Brand	model	chassis
SONY	KV-J29MF8	BG1L
SONY	KV-J29MF87J	BG1L
SONY	KV-J29MF8J	BG1L
SONY	KV-K21MF1	G3F
SONY	KV-K25MF1	G3F
SONY	KV-K25SN21	G3F
SONY	KV-K29CF1	G3F
SONY	KV-K29MF1	G3F
SONY	KV-K29SN21	G3F
SONY	KV-L34MF1	G3F
SONY	KV-L34MH11	G3F
SONY	KV-L34MN11	G3F
SONY	KV-L34MS1	G3F
SONY	KV-M1100B	EE1
SONY	KV-M1100D	EE1
SONY	KV-M1120D	EE1A
SONY	KV-M1400D	BE2A
SONY	KV-M1401D	BE2A
SONY	KV-M1420D	BE2A
SONY	KV-M1421D	BE2A
SONY	KV-M1430D	BE2A
SONY	KV-M1431D	BE2A
SONY	KV-M1440D	BE4
SONY	KV-M1440V	BE4 (?)
SONY	KV-M1441D	BE4
SONY	KV-M1450D	BE4
SONY	KV-M1451D	BE4
SONY	KV-M14D	BE1
SONY	KV-M1620D	BE2A
SONY	KV-M16D	BE1
SONY	KV-M1920D	BE2A
SONY	KV-M1921U	BE2A
SONY	KV-M19D	BE1
SONY	KV-M2100D	BE2A
SONY	KV-M2101M	BE2A

Brand	model	chassis
SONY	KV-M2120B	BE1
SONY	KV-M2130B	BE1
SONY	KV-M2130D	BE1
SONY	KV-M2131D	BE1
SONY	KV-M2140D	BE2A
SONY	KV-M2140K	(SCC-E50B)
SONY	KV-M2141D	BE2A
SONY	KV-M2141K	(SCC-E50A)
SONY	KV-M2150D	BE2A
SONY	KV-M2150K	BE2A
SONY	KV-M2151D	BE2A
SONY	KV-M2151KR	BE2A
SONY	KV-M2155K	BE2A
SONY	KV-M2155K	BE2A
SONY	KV-M2161K	BE2A (?)
SONY	KV-M2170A	BE4A (SCC-J05B-A)
SONY	KV-M2170K	BE4A (SCC-J03B-A)
SONY	KV-M2171A	BE4A (SCC-J05A-A)
SONY	KV-M2171K	BE4A (SCC-J03A-A)
SONY	KV-M2180D	BE4
SONY	KV-M2181D	BE4
SONY	KV-M21BE	AE1
SONY	KV-M21BE	AE1
SONY	KV-M2510B	AE1
SONY	KV-M2511A	AE1
SONY	KV-M2520K	AE1C
SONY	KV-M2521K	AE1C (SCC-E38A)
SONY	KV-M2530K	AE1C
SONY	KV-M2531K	AE1C
SONY	KV-M2540B	BE3B (SCC-G85F-A)
SONY	KV-M2540D	BE3B (SCC-G77G-A)
SONY	KV-M2540E	BE3B (SCC-G82F-A)
SONY	KV-M2540K	BE3B (SCC-G86E-A)
SONY	KV-M2541A	BE3B (SCC-G81F-A)
SONY	KV-M2541D	BE3B (SCC-G77F-A)

Brand	model	chassis
SONY	KV-M2541E	BE3B (SCC-G82E-A)
SONY	KV-M2541K	BE3B (SCC-G86D-A)
SONY	KV-M2541L	BE3B (SCC-G83D-A)
SONY	KV-M2541U	BE3B (SCC-G87D-A)
SONY	KV-M2901E	AE1C
SONY	KV-M2921E	BE3B
SONY	KV-M2921E	BE3B
SONY	KV-MT2000	BA2
SONY	KV-P14D	BE1
SONY	KV-P14D	BE1
SONY	KV-PF21L70	BG3S
SONY	KV-PF21M40	BG3S
SONY	KV-PF21M70	BG3S
SONY	KV-PF21N70	BG3S (?)
SONY	KV-PF21P10	BG3S
SONY	KV-PF21P40	BG3S
SONY	KV-PF21P41	BG3S
SONY	KV-PF21Q70	BG3S
SONY	KV-PG14L70	BG2T
SONY	KV-PG14M40	BG2T
SONY	KV-PG14N70	BG2T
SONY	KV-PG14P10	BG2T
SONY	KV-PG14P40	BG2T
SONY	KV-PG14P70	BG2T
SONY	KV-PG21M10	BG2T
SONY	KV-PG21M70	BG2T
SONY	KV-PG21N70	BG2T
SONY	KV-PG21P10	BG2T
SONY	KV-PG21P40	BG2T
SONY	KV-PG21P70	BG2T
SONY	KV-S2911D	AE2
SONY	KV-S2911D	AE2
SONY	KV-S2912U	AE2
SONY	KV-S2913E	AE2
SONY	KV-S2921D	AE2A

Brand	model	chassis
SONY	KV-S2922U	AE2A
SONY	KV-S2923E	AE2A
SONY	KV-S2941K	AE2F
SONY	KV-S2942U	AE2F
SONY	KV-S2943B	AE2F
SONY	KV-S2951K	AE3
SONY	KV-S2952U	AE3
SONY	KV-S2953B	AE3
SONY	KV-S29CX1	G1 (100Hz)
SONY	KV-S29MH1.1	G1
SONY	KV-S29MN1	G1 ?
SONY	KV-S29RN1	G1 (czy? G3F)
SONY	KV-S32MH1	GI (czy? G3F)
SONY	KV-S3411D	AE2
SONY	KV-S3411D	AE2A
SONY	KV-S3412U	AE2
SONY	KV-S3412U	AE2A
SONY	KV-S3413E	AE2
SONY	KV-S3413E	AE2A
SONY	KV-S3431K	AE2B
SONY	KV-S3432U	AE2B
SONY	KV-S3433B	AE2B
SONY	KV-S34MH1	GI
SONY	KV-S34MN1	G1 ?
SONY	KV-S34RN1	GI
SONY	KV-SA32M36	BX1L
SONY	KV-SJ29M80	BG3R
SONY	KV-ST2050	BA2
SONY	KV-SW292M80	BX1L ?
SONY	KV-SW29M31	BX1L
SONY	KV-SW29M50	BX1L
SONY	KV-SW29M50	BX1L
SONY	KV-SW29M60K	BX1L
SONY	KV-SW29M61	BX1L
SONY	KV-SW29M61	BX1L

Brand	model	chassis
SONY	KV-SW29M80	BX1L
SONY	KV-SW29M81	BX1L
SONY	KV-SW29M90	BX1L
SONY	KV-SW29M91	BX1L
SONY	KV-SW29N60	BX1L
SONY	KV-SW29N90	BX1L
SONY	KV-SW34M50	BX1L
SONY	KV-SW34M80	BX1L
SONY	KV-SW34M81	BX1L
SONY	KV-SW34N60	BX1L
SONY	KV-SZ29M80	BX1L (?)
SONY	KV-T21MF1	BG1S
SONY	KV-T21MN1	BG1S
SONY	KV-T21MN11	BG1S
SONY	KV-T25MN1	BG1S
SONY	KV-T25MN11	BG1S
SONY	KV-T25SF1	BG1S
SONY	KV-T25SF11	BG1S
SONY	KV-T29CF1	BG1S
SONY	KV-TF21M50	BG3S
SONY	KV-TF21M60	BG3S
SONY	KV-TG21L70	BG2T
SONY	KV-TG21M20	BG2T
SONY	KV-TG21M61	BG2T
SONY	KV-TG21M80	BG2T
SONY	KV-TG21M81	BG2T
SONY	KV-TG21M90	BG2T
SONY	KV-V1410K	BC2
SONY	KV-V1420K	BC2
SONY	KV-V1430K	TE1
SONY	KV-V20MF2	BG1S
SONY	KV-V2110	TE1
SONY	KV-V2110D	TE1
SONY	KV-V2110E	TE1
SONY	KV-V2110K	TE1

Brand	model	chassis
SONY	KV-V2120K	BC2
SONY	KV-VF14M40	BC4A
SONY	KV-VF14M70	BC4A
SONY	KV-VF14M77	BC4A
SONY	KV-VF21M40	BC4A
SONY	KV-VF21M70	BC4A
SONY	KV-VF21M77	BC4A
SONY	KV-W22813B	AE2F
SONY	KV-W2812U	AE2F
SONY	KV-W2813B	AE2F
SONY	KV-W2813D	AE2F
SONY	KV-W28MH2	AG1
SONY	KV-W3212U	AE2F
SONY	KV-W3213B	AE2F
SONY	KV-W32MH11	AG1
SONY	KV-X2100B	BE3B
SONY	KV-X2101K	BE3B
SONY	KV-X2102U	BE3B
SONY	KV-X2103E	BE3B
SONY	KV-X2120B	AE1
SONY	KV-X2121D	AE1
SONY	KV-X2129U	AE1
SONY	KV-X2130B	AE1B
SONY	KV-X2131D	AE1B
SONY	KV-X2132U	AE1B
SONY	KV-X2132U	AE1B
SONY	KV-X2133D	AE1B
SONY	KV-X2140B	AE1C
SONY	KV-X2141D	AE1C
SONY	KV-X2142U	AE1C
SONY	KV-X2150B	AE1C
SONY	KV-X2151D	AE1C
SONY	KV-X2152U	AE1C
SONY	KV-X2153E	AE1C
SONY	KV-X2160B	AE2

Brand	model	chassis
SONY	KV-X2161D	AE2
SONY	KV-X2162U	AE2
SONY	KV-X2163E	AE2
SONY	KV-X2171D	AE2B
SONY	KV-X2172U	AE2B
SONY	KV-X2173B	AE2B
SONY	KV-X2180B	BE3B
SONY	KV-X2181D	BE3B
SONY	KV-X2182U	BE3B
SONY	KV-X2183B	BE3B
SONY	KV-X21TD	AE1
SONY	KV-X2500B	BE3B
SONY	KV-X2501K	BE3B
SONY	KV-X2502U	BE3B
SONY	KV-X2503E	BE3B
SONY	KV-X2520B	AE1
SONY	KV-X2521D	AE1
SONY	KV-X2529U	AE1
SONY	KV-X2530B	AE1B
SONY	KV-X2531K	AE1B (SCC-E38D)
SONY	KV-X2532U	AE1B
SONY	KV-X2533E	AE1B
SONY	KV-X2539B	AE1C
SONY	KV-X2540B	AE1C
SONY	KV-X2541K	AE1C
SONY	KV-X2542U	AE1C
SONY	KV-X2545U	AE1C
SONY	KV-X2550B	AE1C
SONY	KV-X2551D	AE1C (SCC-E18XA)
SONY	KV-X2551K	AE1C
SONY	KV-X2552U	AE1C ?
SONY	KV-X2553E	AE1C
SONY	KV-X2553E	AE1C
SONY	KV-X2560B	AE2
SONY	KV-X2560B	AE2

Brand	model	chassis
SONY	KV-X2561K	AE2
SONY	KV-X2562U	AE2
SONY	KV-X2563E	AE2
SONY	KV-X2571K	AE2B
SONY	KV-X2572U	AE2B
SONY	KV-X2573E	AE2B
SONY	KV-X2581K	BE3B
SONY	KV-X2582U	BE3B
SONY	KV-X2583B	BE3B
SONY	KV-X25TD	AE1
SONY	KV-X2900B	BE3B
SONY	KV-X2901K	BE3B
SONY	KV-X2902U	BE3B
SONY	KV-X2903E	BE3B
SONY	KV-X2930B	AE1B
SONY	KV-X2931D	AE1B
SONY	KV-X2931K	AE1C (SCC-E38C)
SONY	KV-X2932U	AE1B
SONY	KV-X2933E	AE1B
SONY	KV-X2940B	AE1C
SONY	KV-X2941D	AE1C
SONY	KV-X2942U	AE1C
SONY	KV-X2950B	AE1C
SONY	KV-X2951K	AE1C
SONY	KV-X2952U	AE1C
SONY	KV-X2953E	AE1C
SONY	KV-X2960B	AE2
SONY	KV-X2961K	AE2
SONY	KV-X2962U	AE2
SONY	KV-X2963E	AE2
SONY	KV-X2971K	AE2B
SONY	KV-X2972U	AE2B
SONY	KV-X2973B	AE2B
SONY	KV-X2973E	AE2B
SONY	KV-X2981K	BE3B

Brand	model	chassis
SONY	KV-X2982U	BE3B
SONY	KV-X2983B	BE3B
SONY	KV-X2991A	AE2F
SONY	KV-X2991D	AE2F
SONY	KV-X2993B	AE2F
SONY	KV-X2993E	AE2F
SONY	KV-XA21M80	BG3R
SONY	KV-XA21M81	BG3R
SONY	KV-XA21M83	BG3R
SONY	KV-XF21M80	BG3S
SONY	KV-XF21M83	BG3S
SONY	KV-XF21N90	BG3S
SONY	KV-XF24M80	BG3S
SONY	KV-XF25M50	BG3S
SONY	KV-XF29M80	BG3S
SONY	KV-XF34M67	BG3S (SCC-U22A)
SONY	KV-XF51M65	BG3S
SONY	KV-XG29M61	BG3R
SONY	KV-XG29M61	BG3S
SONY	KV-XG29M85	BG3S
SONY	KV-XJ29M31	BG3R
SONY	KV-XJ29M50	BG3R
SONY	KV-XJ29M60	BG3R
SONY	KV-XJ29M80	BG3R
SONY	KV-XJ29M81	BG3R
SONY	KV-XJ29N90	BG3R
SONY	KV-XR25M31	BX1
SONY	KV-XR25M50	BX1L
SONY	KV-XR25M80	BX1L
SONY	KV-XR29M50	BX1
SONY	KV-XR29M61	BX1
SONY	KV-XR29M80	BX1
SONY	KV-XR34M31	BX1
SONY	KV-XR34M61	BX1
SONY	KV-XS29M80	BG3S

Brand	model	chassis
SONY	KV-XS29M97	BG3S
SONY	KV1207	30P
SONY	KV1363R	P3
SONY	KV1367	P3
SONY	KV13FM12	BA5
SONY	KV13FM13	BA5
SONY	KV13FM14	BA5
SONY	KV13M20	BA3
SONY	KV13M30	BA3
SONY	KV13M31	BA3
SONY	KV13TR24	P3B
SONY	KV13TR27	P3B
SONY	KV13TR28	BA1
SONY	KV13TR29	BA1
SONY	KV1412ET	XE3
SONY	KV1430R	BA1
SONY	KV1432ME3	(SCC501B-A)
SONY	KV1434M3B	(SCC-D06S)
SONY	KV1435M3	F21G (SCC-F21G-A)
SONY	KV1435ME3	G3E
SONY	KV1440EM2	(SCC689A)
SONY	KV1440UB	XE5
SONY	KV1440WR	BA1
SONY	KV1442E2	XE5
SONY	KV1442EC	XE5
SONY	KV1442FE	XE5
SONY	KV1442MR	(SCC791A)
SONY	KV1450B	BA3 (?)
SONY	KV1485MT	G3E
SONY	KV1485MT	G3E (F21D-A)
SONY	KV1485MTJ	G3E (SCC-F21D-A)
SONY	KV1487MT	G3E
SONY	KV14CT1	BX1
SONY	KV14CT1K	BX1
SONY	KV14DK2	G3E

Brand	model	chassis
SONY	KV14FM12	BA5
SONY	KV14FM12A	BA5
SONY	KV14FM12C	BA5
SONY	KV14FM14	BA5
SONY	KV14FV1	BC5
SONY	KV14FV1B	BC5
SONY	KV14FV1D	BC5
SONY	KV14FV1E	BC5
SONY	KV14FV1U	BC5
SONY	KV14FV300	BA6
SONY	KV14LM1	FE2
SONY	KV14LM1B	FE2
SONY	KV14LM1E	FE2
SONY	KV14LM1K	FE2
SONY	KV14LM1U	FE2
SONY	KV14LT1B	FE2
SONY	KV14LT1E	FE2
SONY	KV14LT1K	FE2
SONY	KV14LT1U	FE2
SONY	KV14M1A	BE4
SONY	KV14M1B	BE4
SONY	KV14M1D	BE4
SONY	KV14M1E	BE4
SONY	KV14M1K	BE4 ?
SONY	KV14PM1	BA3
SONY	KV14R20	BA3
SONY	KV14RD1	BA3
SONY	KV14T1A	BE4
SONY	KV14T1B	BE4
SONY	KV14T1D	BE4
SONY	KV14T1E	BE4
SONY	KV14V1K	BC3 (czy BC2 ?)
SONY	KV14V4A	TE1
SONY	KV14V4B	TE1
SONY	KV14V4D	TE1

Brand	model	chassis
SONY	KV14V4E	TE1
SONY	KV14V4U	TE1
SONY	KV14V5D	BC4
SONY	KV14V6D	BC4
SONY	KV14VM1	BC2
SONY	KV14VM1	BC2
SONY	KV14VM2	BC2 ?
SONY	KV14VM5	BC3
SONY	KV1602M7	(SCC-A88C)
SONY	KV1614E	(SCC275A-A)
SONY	KV1665	P3
SONY	KV16WS1B	BE5
SONY	KV16WS1D	BE5
SONY	KV16WT1K	BE4
SONY	KV16XMB	GP2
SONY	KV1882EC	XE3
SONY	KV1902M3A	GP2 ? (SCC-B21F)
SONY	KV1945RS	(SCC265L-A)
SONY	KV1970R	(SCC584A)
SONY	KV1972R	P3
SONY	KV1973R	P3
SONY	KV1982M9	(SCC-B21L)
SONY	KV1984MT	GP1A
SONY	KV1993R	P3
SONY	KV1997R	P3
SONY	KV19HMD	GP2
SONY	KV2022UB	(SCC217A-A)
SONY	KV2056	P2E
SONY	KV2056EC	XE2
SONY	KV2062EC	XE3
SONY	KV2062MR	P2
SONY	KV2064EC	XE3
SONY	KV2068EC	XE3
SONY	KV2072MET	XE3 ?
SONY	KV2080R	P3

Brand	model	chassis
SONY	KV2090E	XE4
SONY	KV2092E	XE4
SONY	KV2092EC	XE4
SONY	KV2092EI	XE4
SONY	KV2092ESP	XE4
SONY	KV2092ET	XE4
SONY	KV2092FE	XE4
SONY	KV2092ME2B	(SCC-B21G)
SONY	KV2092MR	XE4
SONY	KV2092PT	XE4
SONY	KV2092UB	XE4
SONY	KV2096EC	XE4
SONY	KV2096UB	XE4
SONY	KV20EXR20	ANU2
SONY	KV20FS10	BA6
SONY	KV20FS100	BA6
SONY	KV20FS12	BA5
SONY	KV20FS120	BA6
SONY	KV20FV10	BA4C
SONY	KV20FV12	BA5
SONY	KV20FV300	BA6
SONY	KV20M10	BA2
SONY	KV20M20	BA3
SONY	KV20S10	BA2
SONY	KV20S20	BA3
SONY	KV20S21	BA3
SONY	KV20S30	BA3
SONY	KV20TR22	P3B
SONY	KV20TR23	BA1
SONY	KV20TS20	P3B ?
SONY	KV20TS28	P3B
SONY	KV20TS29	BA1
SONY	KV20TS32	BA1
SONY	KV20V60	BA3
SONY	KV20WS1B	BE5

Brand	model	chassis
SONY	KV20WS1D	BE5
SONY	KV20WS1K	BE5
SONY	KV20XTR30	GP1A (?)
SONY	KV2100WX	GP2 (?)
SONY	KV2113GE	GP1S (?)
SONY	KV211XMTU	AE1
SONY	KV2121D	AE1
SONY	KV2127R	P3B (SCC-D41E-A)
SONY	KV2134M3	(SCC-D06J)
SONY	KV2137RS	P3B (SCC-D41D-A)
SONY	KV2140RWP	P3A
SONY	KV2150R	BA1
SONY	KV2153MT	(SCC-D06P)
SONY	KV2160WR	BA1
SONY	KV2165MT	G3E
SONY	KV2165MTJ	(SCC-F21J)
SONY	KV2167MT	G3E
SONY	KV2167MT	G3EN
SONY	KV2168MT	ME
SONY	KV2170	GP1A
SONY	KV2170B	BA3 (?)
SONY	KV2170RS	BA1
SONY	KV2172S	BA3 (?)
SONY	KV2173S	BA3 (?)
SONY	KV2180R	BA2 (SCC-G92B-A)
SONY	KV2182	GP1A
SONY	KV2182GE	(SCC-A93E)
SONY	KV2182MR	GP1 (SCC-B52A)
SONY	KV2184MT	GP1A
SONY	KV2185MK	G3E (SCC-F40A)
SONY	KV2185MT	G3E
SONY	KV2185MTJ	G3E
SONY	KV2190RS	BA2
SONY	KV2194MT	(SCC-D06Y)
SONY	KV2199M5J	BG2S

Brand	model	chassis
SONY	KV2199M5T	BG2S
SONY	KV2199M70	BG3S
SONY	KV2199XDK	BG3S (SCC-U30J-A)
SONY	KV21C1D	BE5
SONY	KV21C1K	BE5?
SONY	KV21C4D	BE5
SONY	KV21C5D	FE1
SONY	KV21CL1	BX1
SONY	KV21CL10	BX1
SONY	KV21CL10E	BX1
SONY	KV21CL5K	BX1
SONY	KV21CT1	BX1
SONY	KV21CT1E	BX1 ?
SONY	KV21CX5D	FE1
SONY	KV21DK1	G3E
SONY	KV21DK2	G3E
SONY	KV21F-A30	GA4
SONY	KV21FA210	BA6
SONY	KV21FA310	BA6
SONY	KV21FA340	BA6
SONY	KV21FA540	BA6
SONY	KV21FE12	BA5
SONY	KV21FE12A	BA5
SONY	KV21FE12C	BA5
SONY	KV21FM100	BA6
SONY	KV21FM12	BA5
SONY	KV21FM120	BA6
SONY	KV21FQ1	BX1S
SONY	KV21FQ10	BX1
SONY	KV21FQ10K	BX1
SONY	KV21FS100	BA6
SONY	KV21FS105	BA5
SONY	KV21FS120	BA6
SONY	KV21FS140	BX1S
SONY	KV21FT1K	FE2

Brand	model	chassis
SONY	KV21FT2K	FE2 (inaczej: BEAB)
SONY	KV21FV10	BA4C
SONY	KV21FV12	BA5
SONY	KV21FV12C	BA5
SONY	KV21FV1B	BC5
SONY	KV21FV1D	BC5
SONY	KV21FV1E	BC5
SONY	KV21FV1U	BC5
SONY	KV21FV300	BA6
SONY	KV21FV300	BA6
SONY	KV21FX20D	FE1A
SONY	KV21FX30K	FE1
SONY	KV21GMR1 MKII	BG2S ?
SONY	KV21GMR1MKII	BG3S-6 (?)
SONY	KV21LS30K	FE2
SONY	KV21LT1E	FE2
SONY	KV21LT1K	FE2 (SCC-Q51C-A)
SONY	KV21M1A	BE4A
SONY	KV21M1B	BE4A
SONY	KV21M1D	BE4A
SONY	KV21M1E	BE4A
SONY	KV21M1K	BE4A
SONY	KV21M1L	BE4A
SONY	KV21M1U	BE4A
SONY	KV21M3K	BE4A
SONY	KV21M5D	FE1
SONY	KV21MB42P	BA4D (?) (SCC-S27A-A)
SONY	KV21ME40	BA4 ?
SONY	KV21PM1	BA3
SONY	KV21PM2	BA3
SONY	KV21PS1	BA3
SONY	KV21PS2	BA3
SONY	KV21R10C	BA2
SONY	KV21R1D	BE5
SONY	KV21R20	BA3

Brand	model	chassis
SONY	KV21R22	BA3
SONY	KV21R22C	BA3
SONY	KV21RD1	BA3
SONY	KV21RD2	BA3
SONY	KV21RS10	BA2
SONY	KV21RS20	BA3
SONY	KV21RS22C	BA3
SONY	KV21RS50	BA3
SONY	KV21RS50/8	BA3 ? (SCC-J94P)
SONY	KV21RS50C	BA3
SONY	KV21SD1	BA3
SONY	KV21SD2	BA3
SONY	KV21SE40	BA4
SONY	KV21SE43C	BA4D
SONY	KV21STR2	BA1
SONY	KV21T1B	BE4A
SONY	KV21T1D	BE4A
SONY	KV21T1E	BE4A
SONY	KV21T1K	BE4A
SONY	KV21T1L	BE4A
SONY	KV21T1R	BE4A
SONY	KV21T1U	BE4A
SONY	KV21T3D	BE4A
SONY	KV21T3K	BE4A
SONY	KV21T3R	BE4A
SONY	KV21T5D	FE1
SONY	KV21T5K	FE1
SONY	KV21T5K	FE1
SONY	KV21V46	TE1
SONY	KV21V4D	TE1
SONY	KV21V4D	TE1
SONY	KV21V5A	BC4
SONY	KV21V5B	BC4
SONY	KV21V5D	BC4
SONY	KV21V5E	BC4

Brand	model	chassis
SONY	KV21V5K	BC4
SONY	KV21V5K	DC4
SONY	KV21V5U	BC4
SONY	KV21V6A	BC4
SONY	KV21V6B	BC4
SONY	KV21V6D	BC4
SONY	KV21V6E	BC4
SONY	KV21V6U	BC4
SONY	KV21VX1MT	VX
SONY	KV21X1D	BE5
SONY	KV21X1K	BE5
SONY	KV21X4K	BE5
SONY	KV21X5K	FE1
SONY	KV21XMTA	AE1
SONY	KV21XR	SX
SONY	KV21XR	SX ?
SONY	KV21XRB	SX
SONY	KV21XRTD	SX
SONY	KV21XRTU	SX
SONY	KV21XRTU	SX
SONY	KV21XRU	SX
SONY	KV2204ET	(SCC216B-A)
SONY	KV2212E	YE2
SONY	KV2230	PE3
SONY	KV2252	PE3
SONY	KV2256	PE3
SONY	KV24FS100	BA6
SONY	KV24FS120	BA6
SONY	KV24FV10	BA4C
SONY	KV24FV12	BA5
SONY	KV24WS1D	BE3B
SONY	KV24WS2K	BE3D
SONY	KV24WX1K	BE3D
SONY	KV2531D	BE3B
SONY	KV2533K	BE3B

Brand	model	chassis
SONY	KV2552	-- (SCC-B78B-A)
SONY	KV2552M9	GP1S (?)
SONY	KV2553MT	GP1A
SONY	KV2565MTJ	(SCC-E64L)
SONY	KV2584MT	GP1A
SONY	KV2585MT	GP1A
SONY	KV25B5E	FE1
SONY	KV25C1D	BE3D
SONY	KV25C1K	FE1 ? (raczej BE3D)
SONY	KV25C1L	BE3D ?
SONY	KV25C2D	BE3D
SONY	KV25C3D	AE4
SONY	KV25C59D	FE1 ?
SONY	KV25C5K	FE1
SONY	KV25C5K	FE1
SONY	KV25E1D	AE3
SONY	KV25F1D	BE3D
SONY	KV25F2D	BE3D
SONY	KV25F3D	BE3D
SONY	KV25FS100	BA6
SONY	KV25FS120	BA6
SONY	KV25FV10	BA4C
SONY	KV25FV10C	BA4C
SONY	KV25FV300	BA6
SONY	KV25FX20A	FE1A
SONY	KV25FX20B	FE1A
SONY	KV25FX20D	FE1A
SONY	KV25FX20E	FE1A
SONY	KV25FX20K	FE1
SONY	KV25FX20K	FE1A
SONY	KV25FX20R	FE1A
SONY	KV25FX30B	FE2
SONY	KV25FX30E	FE2
SONY	KV25FX30K	FE2
SONY	KV25K1K	AE4

Brand	model	chassis
SONY	KV25K5D	FE1
SONY	KV25M1A	BE3B
SONY	KV25M1D	BE3B
SONY	KV25M1E	BE3B
SONY	KV25M1K	BE3B
SONY	KV25M1K	BE3B
SONY	KV25M2D	FE1
SONY	KV25R1D	BE5
SONY	KV25R1E	BE5
SONY	KV25R1K	BE5
SONY	KV25R1R	BE5
SONY	KV25R2A	FE1
SONY	KV25R2D	FE1
SONY	KV25R2E	FE1
SONY	KV25R2K	FE1
SONY	KV25R2R	FE1
SONY	KV25T1A	BE3B
SONY	KV25T1B	BE3B
SONY	KV25T1D	BE3B
SONY	KV25T1E	BE3B
SONY	KV25T1K	BE3B (BEAB)
SONY	KV25T1L	BE3B
SONY	KV25T1R	BE3B
SONY	KV25T1U	BE3B
SONY	KV25T2A	FE1
SONY	KV25T2D	BE3B
SONY	KV25T2K	FE1
SONY	KV25X1D	BE3D
SONY	KV25X3D	AE4
SONY	KV25X5K	FE1
SONY	KV25XBR	P2B ?
SONY	KV25XSTD	AE1
SONY	KV2705EC	QE1
SONY	KV2720EC	QEX
SONY	KV2720EC2	PE3

Brand	model	chassis
SONY	KV2730	RX
SONY	KV2730EC	RX
SONY	KV2752	PE3
SONY	KV2756	PE3
SONY	KV2764EC	PE3
SONY	KV2780R	(SCC552V-A)
SONY	KV2782R	P3
SONY	KV27EXR95	ANU2
SONY	KV27EXTD	AE1
SONY	KV27FA310	BA6
SONY	KV27FS100	BA5D
SONY	KV27FS12	BA5
SONY	KV27FS120	BA6
SONY	KV27FS13	BA5
SONY	KV27FS16	BA5
SONY	KV27FS200	BA5D
SONY	KV27HFR	P3A ?
SONY	KV27HS420	DA4
SONY	KV27RB/TB	SX
SONY	KV27S10	AA1
SONY	KV27S15	AA1
SONY	KV27S20	AA2
SONY	KV27S40	BA4
SONY	KV27S45	BA4
SONY	KV27S65	BA4
SONY	KV27TS27	LN1
SONY	KV27TS29	AA1
SONY	KV27TS30	P3A
SONY	KV27TS35	LN1
SONY	KV27TS36	AA1
SONY	KV27TW77	AA1
SONY	KV27V10	AA1
SONY	KV27V22	AA2D
SONY	KV27V22T	AA2D
SONY	KV27V40	BA4

Brand	model	chassis
SONY	KV27V42	BA4D
SONY	KV27V45	BA4
SONY	KV27V55	AA1
SONY	KV27V55	AA1 (SCC-F84H-A)
SONY	KV27V55M	AA1 (SCC-F89D-A)
SONY	KV27V65	BA4D
SONY	KV27VX1MT	(SCC793C)
SONY	KV27XBR10	ANU1A
SONY	KV27XBR15	ANU1A
SONY	KV27XBR26	FN
SONY	KV27XBR35	FN
SONY	KV27XBR36	FN
SONY	KV27XBR50	ANU1A
SONY	KV27XBR51	ANU1A
SONY	KV27XBR55	ANU1A
SONY	KV27XBR60	ANU1A
SONY	KV27XBR65	ANU1A
SONY	KV27XBR95S	FN
SONY	KV27XR	SX
SONY	KV27XR-TD	SX ? (SCC784B-A)
SONY	KV27XRB	SX
SONY	KV27XRTU	SX
SONY	KV27XSB	RX2
SONY	KV27XSC	RX2
SONY	KV27XSD	RX2
SONY	KV27XSTC	RX2
SONY	KV27XSTD	RX2
SONY	KV2832DS65	GE1A
SONY	KV28CL10B	FE2
SONY	KV28CS70	AE6B
SONY	KV28DS20U	BE3E
SONY	KV28DS20U	BE3E
SONY	KV28DS60U	GE1A
SONY	KV28DS65U	GE1A
SONY	KV28DX20U	BE3E

Brand	model	chassis
SONY	KV28DX30	BE3E
SONY	KV28FC60K	AE5
SONY	KV28FD1E	GE1
SONY	KV28FQ75	AE5A
SONY	KV28FQ86E	AE6BA
SONY	KV28FS20U	BE3E
SONY	KV28FX201D	BE3E
SONY	KV28FX20D	BE3E
SONY	KV28FX20U	BE3E
SONY	KV28FX20U	FE1A ?
SONY	KV28FX60B	AE5
SONY	KV28FX60K	AE5
SONY	KV28FX65D	AE5
SONY	KV28FX66E	AE6B
SONY	KV28HX15U	FE2
SONY	KV28LS35U	FE2
SONY	KV28LS36B	FE2
SONY	KV28LS36U	FE2
SONY	KV28LS36V	FE2
SONY	KV28LS60	AE6B
SONY	KV28LS60E	AE6B
SONY	KV28LS65E	AE6B
SONY	KV28WF1D	BE3D
SONY	KV28WF1V	BE3D
SONY	KV28WF3D	AE5
SONY	KV28WF3K	AE4
SONY	KV28WS1B	BE3B
SONY	KV28WS1D	BE3B
SONY	KV28WS2K	BE3D
SONY	KV28WS2U	BE3D
SONY	KV28WS3K	AE3
SONY	KV28WS4E	AE4
SONY	KV28WS4K	AE4
SONY	KV28WX10D	AE4
SONY	KV28WX1D	BE3D

Brand	model	chassis
SONY	KV28WX2D	AE4
SONY	KV2900	SCC-C29A
SONY	KV2902U	BE3B
SONY	KV2964MT	GP1A
SONY	KV2965MT	GP1A
SONY	KV2970M	AA1
SONY	KV2970RS	AA1
SONY	KV2975M	AA1
SONY	KV2991A	BE3B ?
SONY	KV29AL40A	BA4
SONY	KV29AL42	BA4D
SONY	KV29AL42C	BA4D
SONY	KV29AL66	BA4D
SONY	KV29AL66C	BA4D
SONY	KV29C1D	BE3D
SONY	KV29C1K	BE3D
SONY	KV29C2K	DE3D
SONY	KV29C3D	AE4
SONY	KV29C3K	AE4
SONY	KV29C5D	FE1
SONY	KV29C5K	FE1
SONY	KV29CL10K	FE2
SONY	KV29CL11	FE2
SONY	KV29CS60K	AE6B !
SONY	KV29DRC420	DA4
SONY	KV29E1K	AE3
SONY	KV29F1K	BE3D
SONY	KV29F1U	BE3D
SONY	KV29F2A	BE3D
SONY	KV29F2B	BE3D
SONY	KV29F2D	BE3D
SONY	KV29F2E	BE3D
SONY	KV29F2K	BE3D
SONY	KV29F2R	BE3D
SONY	KV29F2U	BE3D

Brand	model	chassis
SONY	KV29F3D	BE3D
SONY	KV29F3U	BE3D
SONY	KV29FA210	BA5D (?)
SONY	KV29FA310	BA6
SONY	KV29FA340	BA6
SONY	KV29FA540	BA6
SONY	KV29FC20E	FE1A
SONY	KV29FQ65K	AE5
SONY	KV29FQ75K	AE5A
SONY	KV29FQ76K	AE6A
SONY	KV29FQ85E	AE6BAD
SONY	KV29FS100	BA6 ? (BA5D ?)
SONY	KV29FS12	BA5
SONY	KV29FS120	BA6
SONY	KV29FS12C	BA5
SONY	KV29FS150	BX1L
SONY	KV29FS60K	AE5 (100Hz)
SONY	KV29FV10	AA2W
SONY	KV29FV15	AA2W
SONY	KV29FV17	BA5
SONY	KV29FV305	BA5D
SONY	KV29FX11D	BE3D
SONY	KV29FX11K	BE3D
SONY	KV29FX201D	FE1A
SONY	KV29FX201E	FE1A
SONY	KV29FX20A	FE1A
SONY	KV29FX20B	FE1A
SONY	KV29FX20D	FE1A
SONY	KV29FX20E	FE1A
SONY	KV29FX20K	FE1A
SONY	KV29FX20R	FE1A
SONY	KV29FX20U	FE1A
SONY	KV29FX30B	FE2
SONY	KV29FX30E	FE2
SONY	KV29FX30K	FE2

Brand	model	chassis
SONY	KV29FX60D	AE5
SONY	KV29FX64E	AE6B
SONY	KV29FX64K	AE6B ?
SONY	KV29FX65K	AE5
SONY	KV29FX66	AE6B
SONY	KV29FX66E	AE5
SONY	KV29FX66K	AE6B
SONY	KV29K1D	AE4
SONY	KV29K5D	FE1
SONY	KV29K5K	FE1
SONY	KV29LS30E	FE2
SONY	KV29LS30K	FE2
SONY	KV29LS35K	FE2 (BEAB)
SONY	KV29LS40	FE2
SONY	KV29LS40K	FE2
SONY	KV29LS60K	AE6B (SCC-Q42B-A)
SONY	KV29LX70	AE6B
SONY	KV29M50	BX1L
SONY	KV29M53	BX1L
SONY	KV29M80	BX1L
SONY	KV29M83	BX1L
SONY	KV29PS1	AA2
SONY	KV29RS10	AA1
SONY	KV29RS15	AA1
SONY	KV29RS20	AA2
SONY	KV29RS20C	AA2
SONY	KV29RS22/8	AA2D (SCC-K98C-A)
SONY	KV29RS25	AA2
SONY	KV29RS25C	AA2
SONY	KV29S42	BA4D
SONY	KV29S46	BA4D
SONY	KV29SD1	AA2
SONY	KV29SL40	BA4
SONY	KV29SL42	BA4D
SONY	KV29SL42C	BA4D

Brand	model	chassis
SONY	KV29SL43	BA4D
SONY	KV29SL45	BA4
SONY	KV29SL46	BA4D
SONY	KV29SL65	BA4
SONY	KV29T75	AA2F
SONY	KV29V10	AA1
SONY	KV29V36K	AA2D
SONY	KV29V55M	AA1
SONY	KV29V65C	AA2
SONY	KV29V76T	AA2D
SONY	KV29VL40	BA4
SONY	KV29VL65	BA4
SONY	KV29VL65A	BA4
SONY	KV29VL85	BA4
SONY	KV29VL95	BA4
SONY	KV29VTR10	AA1 (?)
SONY	KV29X1D	BE3D
SONY	KV29X2D	AE3
SONY	KV29X5D	FE1
SONY	KV29X5K	FE1
SONY	KV29XBR85	AA1A
SONY	KV29XL40	BA4
SONY	KV29XL42M	BA4D
SONY	KV29XL42T	BA4D
SONY	KV29XL70K	AE6B
SONY	KV29XTR10	AA1 ?
SONY	KV29XTR2	GP1A
SONY	KV29XTR3	GP1A (?)
SONY	KV30HS420	DA4
SONY	KV32CS70	AE6B
SONY	KV32CS71	AE6B
SONY	KV32CS75	AE6B
SONY	KV32CS76	AE6B
SONY	KV32DS20U	BE3E
SONY	KV32DS60U	GE1A

Brand	model	chassis
SONY	KV32DS65U	GE1A
SONY	KV32FC60Z	AE5
SONY	KV32FD1E	GE1
SONY	KV32FD1K	GE1
SONY	KV32FQ70	AE6B
SONY	KV32FQ70B	AE6B ?
SONY	KV32FQ75D	AE5A
SONY	KV32FQ75E	AE5A
SONY	KV32FQ80K	AE6A
SONY	KV32FQ80K	AE6A
SONY	KV32FQ85K	AE6BAD (100Hz)
SONY	KV32FQ86	AE6BA
SONY	KV32FQ86B	AE6BA
SONY	KV32FQ86E	AE6BA
SONY	KV32FQ86U	AE6BA
SONY	KV32FS10	AA2W
SONY	KV32FS12GRAY	BA5
SONY	KV32FS60B	AE5
SONY	KV32FV1	AA2H
SONY	KV32FV15	AA2W
SONY	KV32FV16	AA2U
SONY	KV32FV26	AA2U
SONY	KV32FV300	BA5D ?
SONY	KV32FX20A	BE3E
SONY	KV32FX20B	BE3E
SONY	KV32FX20D	BE3E
SONY	KV32FX20E	BE3E
SONY	KV32FX20U	BE3E
SONY	KV32FX60K	AE5
SONY	KV32FX65K	AE5
SONY	KV32FX66B	AE6BMW
SONY	KV32FX66K	AE6B
SONY	KV32FX68K	AE6B
SONY	KV32HQ100	AE7A
SONY	KV32HQ100E	AE7A

Brand	model	chassis
SONY	KV32HS20	DX1A
SONY	KV32HS420	DA4
SONY	KV32HS500	DA4
SONY	KV32HV600	DA4
SONY	KV32HX15	FE2
SONY	KV32LS36	FE2
SONY	KV32LS36B	FE2
SONY	KV32LS36E	FE2
SONY	KV32LS36U	FE2
SONY	KV32LS60	AE6B (100Hz)
SONY	KV32LS60K	AE6B
SONY	KV32LS65E	AE6B
SONY	KV32S10	AA1
SONY	KV32S12	AA1
SONY	KV32S15	AA1
SONY	KV32S16	AA1
SONY	KV32S20	AA2
SONY	KV32S22	AA2D
SONY	KV32S25	AA2
SONY	KV32S26	AA2D
SONY	KV32S40	AA2D
SONY	KV32S42	AA2D
SONY	KV32S45	AA2D
SONY	KV32S66	AA2D
SONY	KV32TS29	AA1
SONY	KV32TS36	AA1
SONY	KV32TS46	AA1
SONY	KV32V15	AA1
SONY	KV32V26	AA2D
SONY	KV32V36	AA2D
SONY	KV32V36C	AA2D
SONY	KV32V40	AA2D
SONY	KV32V65	AA2D
SONY	KV32WD4S	AE4
SONY	KV32WF1	BE3D

Brand	model	chassis
SONY	KV32WF1D	BE3D
SONY	KV32WF1K	BE3D
SONY	KV32WF3K	AE3
SONY	KV32WS2D	BE3D
SONY	KV32WS3D	AE3
SONY	KV32WS3K	AE3
SONY	KV32WS4D	AE4
SONY	KV32WS4K	AE4
SONY	KV32WX10D	AE4
SONY	KV32WX20	AE4 (?)
SONY	KV32WX2K	AE4
SONY	KV32XBR250	AA2W
SONY	KV32XBR26	FN
SONY	KV32XBR35	FN
SONY	KV32XBR36	FN
SONY	KV32XBR37	AA1
SONY	KV32XBR400	DX1A
SONY	KV32XBR450	DX1A
SONY	KV32XBR48	AA2C
SONY	KV32XBR95S	FN
SONY	KV32XBR96S	FN
SONY	KV32XL90B	AE6BA
SONY	KV32XL90E	AE6BA
SONY	KV3400D	SCC-C29A
SONY	KV34DRC500	DA4
SONY	KV34FQ75K	AE5A
SONY	KV34FS110	BA6
SONY	KV34FS13	BA5
SONY	KV34FS17	BA5
SONY	KV34FV1	AA2H
SONY	KV34FV10	AA2W
SONY	KV34FV15	AA2W
SONY	KV34FV15C	AA2W
SONY	KV34FV15K	AA2W
SONY	KV34FV15T	AA2W

Brand	model	chassis
SONY	KV34FV16	AA2U (SCC-S50A-A)
SONY	KV34FV16C	AA2U (SCC-S50B-A)
SONY	KV34FX250C	AA2W
SONY	KV34FX260	AA2U (SCC-S50C-A)
SONY	KV34FX260C	AA2U (SCC-S50D-A)
SONY	KV34HS420	DA4
SONY	KV34RS20C	AA2
SONY	KV34SL40	AA2D
SONY	KV34SL40C	AA2D
SONY	KV34SL40T	AA2D
SONY	KV34SL45	AA2D
SONY	KV34V36K	AA2D
SONY	KV34VL65	AA2D
SONY	KV34VL65C	AA2D
SONY	KV34XBR800	DA4
SONY	KV35S26	AA2D ?
SONY	KV35S40	AA2D
SONY	KV35S45	AA2D
SONY	KV35S65	AA2D
SONY	KV35S66	AA2D
SONY	KV35V36	AA2D
SONY	KV35V36M	AA2D
SONY	KV35V65	AA2D
SONY	KV35V76	AA2D
SONY	KV36FQ80K	AE6A
SONY	KV36FS10	AA2W
SONY	KV36FS100	BA5D
SONY	KV36FS12	AA2U
SONY	KV36FS16	AA2U
SONY	KV36FS26	AA2U
SONY	KV36FS70K	AE5A
SONY	KV36FS76B	AE6A
SONY	KV36FS76E	AE6A
SONY	KV36FS76U	AE6A
SONY	KV36FV1	AA2H

Brand	model	chassis
SONY	KV36FV15	AA2W
SONY	KV36FV16	AA2U
SONY	KV36FV26	AA2U
SONY	KV36HQ100	AE7A
SONY	KV36HQ100E	AE7A
SONY	KV36HS20	DX1A
SONY	KV36HS20H	DX1A
SONY	KV36HS420	DA4
SONY	KV36HS500	DA4
SONY	KV36XBR250	AA2W
SONY	KV36XBR400	DX1A
SONY	KV36XBR450	DX1A
SONY	KV36XBR450H	DX1A
SONY	KV36XBR800	DA4
SONY	KV37SL45	AA2D
SONY	KV37V36T	AA2D
SONY	KV37VL65	AA2D
SONY	KV37VL65C	AA2D
SONY	KV38DRC500	DA4
SONY	KV38FS17	AA2U
SONY	KV38FV15K	AA2W
SONY	KV38FV16	AA2U
SONY	KV38FX250C	AA2W
SONY	KV38FX250T	AA2W
SONY	KV40XBR700	DX1A
SONY	KV40XBR800	DA4
SONY	KV42DRC700	DX1A
SONY	KV42DRC800	DA4
SONY	KV42SX200	LE3A
SONY	KV9PT50	BN1
SONY	KV9PT60	BN1
SONY	KW34HD1	HA1
SONY	KX-M21SP	AE1
SONY	KX-M21SP2	BE1
SONY	KX1410QM	BE2A

Brand	model	chassis
SONY	KX2110QM	BE2A
SONY	KX2910	AE1
SONY	KX2920QM	AE2A
SONY	KXM21SP	AE1
SONY	KXM21SP2	BE1
SONY	V38FX250	AA2W
SONY	VX14MW1UE	CP082S
SONY	VX21MW1UE	CP082S
SONY	XF29M93 (czy? KV-XF29M93)	CXP8846
Soundcolour	1410	PT92J
STASSFURT	TV57-05001	LP800
STASSFURT	TV57-5001	LP800
STASSFURT	TV70-1000	LP
STASSFURT	TV70-1000SAT	LP
STASSFURT	TV70-343 (czy? T70-343)	TV520
SUNKAI	T28S1	CTG-AA
SUNKAI	T28S1	CTG-AA
SUPERTECH	CTV2632	K3910
SUPERTECH	CTV5100	11AK10
SUPRA	ST20P10	11AK19P
SUPRA	ST21AA70B	CHSS
SUPRA	ST28P10	11AK19P5
SUPRA	STR1401	CP310
SUPRA	STV1449	PTXM01
SUPRA	STV1452FS	C500
SUPRA	STV1454	C41
SUPRA	STV1494	P64SA
SUPRA	STV1494	P64SA
SUPRA	STV1495W	MC34A
SUPRA	STV2026W	C51
SUPRA	STV2027WM	CP320
SUPRA	STV2029W	PTXM01
SUPRA	STV2052FS	C500
SUPRA	STV2054	C41
SUPRA	STV2054DK	PC04X

Brand	model	chassis
SUPRA	STV2064	P54SA
SUPRA	STV2072	P54SA
SUPRA	STV2074	P54SC
SUPRA	STV2084	PC05X2
SUPRA	STV2084DK	PC04A
SUPRA	STV2094	P64SA
SUPRA	STV2095W	MC34A
SUPRA	STV20P10	11AK17P5
SUPRA	STV2100	PC32A
SUPRA	STV2126W	C51
SUPRA	STV2152FS	C500
SUPRA	STV2191	PTXM01
SUPRA	STV21B55	H704V
SUPRA	STV2500MX	Z56
SUPRA	STV2528MS	CM805
SUPRA	STV2530MS	CM805
SUPRA	STV2620MS	P72
SUPRA	STV2900X	SM60MT
SUPRA	STV2910MS	Z66
SUPRA	STV2926MS	PC33J
SUPRA	STV2928MS	CM805
SUPRA	STV2930MS	CM805
SUPRA	STV5186	11AK10
SUPRA	STV5565	11AK10
SUPRA	STV6392	11AK10
SZYMMAR	TVS7035	TV10
Tandberg	28TM94	PC200
TATUNG		180S
TATUNG	CT2C51	C
TATUNG	D14RFG5	F1, lub F1W, lub F2W, lub F4W
TATUNG	D14TFG5	F1, lub F1W, lub F2W, lub F4W
TATUNG	D20TFG5	F1, lub F1W, lub F2W, lub F4W
TATUNG	D21NAE5	A4 (TATUNG)
TATUNG	D21TFG5	F1, lub F1W, lub F2W, lub F4W
TATUNG	DVT466S	Orion chassis

Brand	model	chassis
TATUNG	DYN9B02	B1
TATUNG	DYN9B51T	B1
TATUNG	G02C53	C
TATUNG	G37RD40	D
TATUNG	G37RD50	D
TATUNG	G37TD40	D
TATUNG	G37TD50	D
TATUNG	G51RD30	D
TATUNG	G51RD50	D
TATUNG	GBX8802	170
TATUNG	GBX9802M	170
TATUNG	GBX9807	170
TATUNG	GBX9B02	B
TATUNG	GN0901	190
TATUNG	GN2C20	C
TATUNG	GN2C50	C
TATUNG	GN8901	190
TATUNG	GN8904	190
TATUNG	GO8903	190
TATUNG	GT8906	190
TATUNG	GUS8705DK	180
TATUNG	GUX9705	180
TATUNG	GUX9B01P	B
TATUNG	T14RF70	F1, lub F1W, lub F2W, lub F4W
TATUNG	T14TF70	F1, lub F1W, lub F2W, lub F4W
TATUNG	T20TF70	F1, lub F1W, lub F2W, lub F4W
TATUNG	T25N440	4400 PROFESSIONAL (PCB: 4410)
TATUNG	T28N440	4400 PROFESSIONAL (PCB: 4410)
TATUNG	T28NG80S	G
TATUNG	T32 N440	440
TATUNG	TT9206	120/130
TATUNG	TVC565	(VMA230A)
TAURAS	1426	TV2KF
TAURAS	14CX3	TV2KF
TAURAS	14CX7	TV2K

Brand	model	chassis
TAURAS	14CX7T	TV2K
TAURAS	14R1	TV2KF
TAURAS	2021	TV2KF
TAURAS	20CX7	TV2KF
TAURAS	2121	TV2KF
TAURAS	2122	TV3KF
TAURAS	2126	TV2KF
TAURAS	2163	TV3KF
TAURAS	2165	TV3KF
TAURAS	21CX7	TV2KF
TAURAS	2522	TV4KF
TAURAS	2822	TV4KF
TAURAS	L2103T	TV85
TCL		(40-3418ME)
TCL		M65
TCL	2027U	(40-2111SG-MAL1X)
TCL	H6L	TDA12029_UOCIII
TCL (Chiny)	97-2159M1-BG45	M35
TCM	10502	20.2 (100Hz) (BEKO)
TCM	68868	TV17.1
TEAC	8411	11AK19
TEC	3031VR	C38 ?
TEC	30PR/100	BS950.1
TEC	3612ME	C34
TEC	3622VR	C34
TEC	3623	C38
TEC	3631V	C38
TEC	3652ME	C34
TEC	3713VR	11AK03
TEC	3719VT	11AK03
TEC	3781VR	INDIANA
TEC	3782VR	INDIANA
TEC	4081VR	INDIANA
TEC	4082VR	INDIANA
TEC	5119VT	11AK03

Brand	model	chassis
TEC	5130VR	C36
TEC	5133	C38
TEC	5133	C38
TEC	5165DK	P51-28 ?
TEC	5169	CORE2
TEC	5172VR	C38
TEC	5173VR-M	C41
TEC	5175	3900
TEC	5520DVS	BS950
TEC	5586SV	C40
TEC	6320DVS	BS950
TEC	7120DVS	BS950
TEC	8050...	11AK18
TECCO	R2050VR	C36P
TECHLINE	55V	11AK19P
TECHLINE	CTV82	11AK28-7 (100Hz)
TechLine	FFS71SVT	11AK12
TECHNIC	CTV2101R	PB2001VS
TECHNICA	2122T	TV2K
TECHNICA	2842T	PT90PBG
TECHNICA	ST1411	TV2K
Technisson	T71/100	(BEKO ZA9.190-01)
TECHNISSON	T71100BK	20.2 (BEKO)
TECHNISSON	T71100BKST	20.2 (100Hz) (BEKO)
Technosonic	TDV1405	TMC565A
TECHNOVISION	TV777	8500 PROFESSIONAL (PCB8500)
TECNIMAGEN	14TXN	CTS-AA
Tecnimagen	14TXN	CTS-AA
TECNIMAGEN	14TXS	(ET2AEJ)
TECNIMAGEN	14TXS	CTS-AB
Tecnimagen	25 TX N	4400 Professional
TEDELEX	EC1418	M5
TEDELEX	EC1438	M5
TEDELEX	EC1439BM	M5
TEDELEX	EC1701	M5

Brand	model	chassis
TEDELEX	EC2009	M5
TEDELEX	EC2010BM	M5
TEDELEX	EC2089	M5
TEDELEX	EC2109	M5
TEDELEX	EC2129	M5
TEDELEX	EC2139	M5
TEDELEX	EC2189	M5
TEDELEX	EC2970	M13PF
TELEAVIA	TA6327	ICC7301
TELEAVIA	TA7027	ICC7301
TELEFUNKEN		DY300
TELEFUNKEN	383R	ICC19
TELEFUNKEN	619A	IDC2
TELEFUNKEN	967	715
TELEFUNKEN	A110M	318A
TELEFUNKEN	A111MC	TX805
TELEFUNKEN	A112MC	TX805
TELEFUNKEN	A114MC	TX805
TELEFUNKEN	A115M	TX805
TELEFUNKEN	A121MC	TX91
TELEFUNKEN	A125M	TX91
TELEFUNKEN	A125P	417
TELEFUNKEN	A130MV	TX90
TELEFUNKEN	A131 MV	TX90
TELEFUNKEN	A135MF	TX91
TELEFUNKEN	A225P	417
TELEFUNKEN	A231 MV	TX90
TELEFUNKEN	A301M	TX91
TELEFUNKEN	A314MT	TX91
TELEFUNKEN	A344M	TX91
TELEFUNKEN	A430PV	617
TELEFUNKEN	A440PV	617
TELEFUNKEN	A520V	ICC8
TELEFUNKEN	A530NV	418B
TELEFUNKEN	A530PV	617

Brand	model	chassis
TELEFUNKEN	A540PV	617
TELEFUNKEN	A540V	615C2
TELEFUNKEN	A550SV	617
TELEFUNKEN	A560SV	617
TELEFUNKEN	A590SV	617
TELEFUNKEN	AV302T	CP350
TELEFUNKEN	BS351V	ICC8
TELEFUNKEN	BS440V	618
TELEFUNKEN	BS450V	618
TELEFUNKEN	BS470V	618
TELEFUNKEN	BS540K	618A1
TELEFUNKEN	BS540V	618A1
TELEFUNKEN	BS550DV	619
TELEFUNKEN	BS550V	618B
TELEFUNKEN	BS570DV	IDC2
TELEFUNKEN	BS570DV	IDC2 (619)
TELEFUNKEN	BS570V	618
TELEFUNKEN	BS590	618
TELEFUNKEN	BS590V	618B
Telefunken	BS8500	619S
TELEFUNKEN	BS920D	619
TELEFUNKEN	BS9500	620
TELEFUNKEN	BS9500D	620
TELEFUNKEN	Cinema701	TV9.1
TELEFUNKEN	CINEVISION WS2868N	ICC11DM
TELEFUNKEN	CINEVISION WS3268N	ICC11DM
TELEFUNKEN	CINEVISION1	IDC2.2
TELEFUNKEN	CINEVISION10	ICC9
TELEFUNKEN	CINEVISION2	IDC2.2
TELEFUNKEN	CINEVISION20	ICC9
TELEFUNKEN	CINEVISION280	ICC11DM
TELEFUNKEN	CINEVISION280D	ICC10DM
TELEFUNKEN	CINEVISION28M	ICC9-100
TELEFUNKEN	CINEVISION30	IDC2.HP
TELEFUNKEN	CINEVISION320PL	ICC11DM

Brand	model	chassis
TELEFUNKEN	CINEVISION32M	ICC9-107
TELEFUNKEN	DF222C	ICC17
TELEFUNKEN	DF223C	ICC17
TELEFUNKEN	DF316ET	ICC17
TELEFUNKEN	DF321C	ICC17
TELEFUNKEN	DF322C	ICC17
TELEFUNKEN	DF416ET	ICC17
TELEFUNKEN	DF421C	ICC17
TELEFUNKEN	DF422C	ICC17
TELEFUNKEN	DF440E	ICC19 (100Hz)
TELEFUNKEN	DF442E	ICC19 (100Hz)
TELEFUNKEN	DF452E	ICC20 (100Hz)
TELEFUNKEN	DF455E	ICC20 (100Hz)
TELEFUNKEN	DF540KE	ICC19 (100Hz)
Telefunken	DF55B60	16.1 (ZA4.190-09)
TELEFUNKEN	DH540KE	ICC19 (100Hz)
TELEFUNKEN	DM5400	ICC10 ?
TELEFUNKEN	DS2868	ICC11
TELEFUNKEN	DS2868L	ICC11
TELEFUNKEN	DS2878M	ICC19 (100Hz)
TELEFUNKEN	DS521E	ICC17
TELEFUNKEN	DS522EF	ICC17
TELEFUNKEN	DS540V1	ICC20 (100Hz)
TELEFUNKEN	DS540VS	ICC19 (100Hz)
TELEFUNKEN	DS560E	ICC19 (100Hz)
TELEFUNKEN	DS570E	ICC19 (100Hz)
TELEFUNKEN	DS574E	ICC19 (100Hz)
TELEFUNKEN	DX540ME3	ICC19 (100Hz)
TELEFUNKEN	F426MT	ICC6
TELEFUNKEN	F428MT	TX92
TELEFUNKEN	F430	TX92
TELEFUNKEN	F431	ICC9
TELEFUNKEN	F434M	TX92
TELEFUNKEN	F436M	ICC9
TELEFUNKEN	F522T	TX92

Brand	model	chassis
TELEFUNKEN	F526MT	ICC6
TELEFUNKEN	F528MT	TX92
TELEFUNKEN	F530	TX92
TELEFUNKEN	F531	ICC9
TELEFUNKEN	F531C	ICC11
TELEFUNKEN	F531CA	ICC10
TELEFUNKEN	F534M	TX92
TELEFUNKEN	F536M	ICC9
TELEFUNKEN	F840M	ICC9-100
TELEFUNKEN	FS425MV	ICC8
TELEFUNKEN	FS430V	418C
TELEFUNKEN	FS433	TX92
TELEFUNKEN	FS435MV	ICC8
TELEFUNKEN	FS525MV	ICC8
TELEFUNKEN	FS530V	418C
TELEFUNKEN	FS532M	TX92
TELEFUNKEN	FS533	TX92
TELEFUNKEN	FS535MC	ICC9 16:9
TELEFUNKEN	FS535MV	ICC8
TELEFUNKEN	MA110C	TX807
TELEFUNKEN	MA111E	TX808C/CS
TELEFUNKEN	MA115GT	TX807
TELEFUNKEN	MA116ET	TX807C/CS
TELEFUNKEN	MA211E	TX807C/CS
TELEFUNKEN	MA215GT	TX91G
TELEFUNKEN	MA216ET	TX807C/CS
TELEFUNKEN	MA216GT	TX807
TELEFUNKEN	MF210A	TX807
TELEFUNKEN	MF211E	TX807C/CS
TELEFUNKEN	MF215GT	TX807
TELEFUNKEN	MF216FT	TX807C/CS
TELEFUNKEN	MF220E	TX807C/CS
TELEFUNKEN	MF221C	ICC17
TELEFUNKEN	MF222C	ICC17
TELEFUNKEN	MF622C	ICC17

Brand	model	chassis
TELEFUNKEN	MF640E	ICC19 (100Hz)
TELEFUNKEN	MF644E	ICC19 (100Hz)
TELEFUNKEN	MG1476CT	TX91G
TELEFUNKEN	MG3375H	TX92F
TELEFUNKEN	MP141	TX86 ?
TELEFUNKEN	MP142S	418A1 (IKC2)
TELEFUNKEN	MP163VT	318A
TELEFUNKEN	MP175	IKC2
TELEFUNKEN	MP202	IKC2
TELEFUNKEN	MP202S	IKC2 ?
TELEFUNKEN	MP206	TX91 ?
TELEFUNKEN	MP211	IKC2
TELEFUNKEN	MP215	IKC2
TELEFUNKEN	MP216	ICC8
TELEFUNKEN	MP254	ICC8
TELEFUNKEN	MR212S	IKC2
TELEFUNKEN	MR253	ICC7
TELEFUNKEN	MRX28	617
TELEFUNKEN	MS2176CT	TX91G
TELEFUNKEN	MS284	ICC8
TELEFUNKEN	MX256	ICC7
TELEFUNKEN	P150C	417
TELEFUNKEN	P150MV	TX90
TELEFUNKEN	P150N	418A1
TELEFUNKEN	P151MT	TX90
TELEFUNKEN	P152MT	TX90
TELEFUNKEN	P155MT	TX91
TELEFUNKEN	P250MV	ICC6
TELEFUNKEN	P251MT	ICC6
TELEFUNKEN	P320C	418A
TELEFUNKEN	P324MT	TX91
TELEFUNKEN	P325MT	TX91
TELEFUNKEN	P330M	IKC2
TELEFUNKEN	P331 MV	ICC6
TELEFUNKEN	P331M	418 (IKC2)

Brand	model	chassis
TELEFUNKEN	P332MT	ICC6 B76
TELEFUNKEN	P332MTA	TX91
TELEFUNKEN	P350NV	418A
TELEFUNKEN	P354M	TX91
TELEFUNKEN	P355M	TX91
TELEFUNKEN	P356M	ICC9
TELEFUNKEN	P440NV	618A
TELEFUNKEN	P450DV	618A1
TELEFUNKEN	P460DV	618A1
TELEFUNKEN	P540DV	618A
TELEFUNKEN	P550CV	618B
TELEFUNKEN	P550DV	618B
TELEFUNKEN	P560CV	618
TELEFUNKEN	P570 DP	618B
TELEFUNKEN	P570S	617
TELEFUNKEN	P570SV	617
TELEFUNKEN	P590CV	618
TELEFUNKEN	P590DV	618B
TELEFUNKEN	P590NV	617
TELEFUNKEN	P8500MV	618
TELEFUNKEN	PALCOLOR 1420	615A1
TELEFUNKEN	Palcolor 2300	514
TELEFUNKEN	PALcolor A130M	418A
TELEFUNKEN	PR740	ICC19 (czy? PRC19 100Hz)
TELEFUNKEN	RP740	ICC19 (100Hz)
TELEFUNKEN	RP744E	ICC19 (100Hz)
TELEFUNKEN	RP844	ICC19
TELEFUNKEN	RW734E	PLT51A
TELEFUNKEN	RW734E	RLT51A
TELEFUNKEN	S1540	ICC8
TELEFUNKEN	S238	IKC2
TELEFUNKEN	S255	ICC7
TELEFUNKEN	S258A	ICC8
TELEFUNKEN	S259N	ICC9
TELEFUNKEN	S290	517

Brand	model	chassis
TELEFUNKEN	S295	ICC7
TELEFUNKEN	S298	ICC8
TELEFUNKEN	S299	ICC8
TELEFUNKEN	S352M	ICC9
TELEFUNKEN	S439	ICC9
TELEFUNKEN	S4400DM	ICC11
TELEFUNKEN	S4400DMD	ICC10
TELEFUNKEN	S4400SAT	ICC9
TELEFUNKEN	S440C	ICC9
TELEFUNKEN	S440E	ICC9
TELEFUNKEN	S470SL	ICC9
TELEFUNKEN	S480	ICC9
TELEFUNKEN	S485	IDC2.1
TELEFUNKEN	S490	ICC10
TELEFUNKEN	S539	ICC9
TELEFUNKEN	S540	618A1
TELEFUNKEN	S5400	ICC9
TELEFUNKEN	S5400DM	ICC11
TELEFUNKEN	S5400DMD	ICC10
TELEFUNKEN	S5400SAT	ICC9
TELEFUNKEN	S540C	ICC9
TELEFUNKEN	S540DM	ICC10
TELEFUNKEN	S540EF	ICC9
TELEFUNKEN	S550M	ICC10
TELEFUNKEN	S570SL	ICC9
TELEFUNKEN	S580	IDC2.1
TELEFUNKEN	S585	IDC2.1
TELEFUNKEN	S590	ICC10
TELEFUNKEN	S590DM	ICC11
TELEFUNKEN	SM213	ICC7
TELEFUNKEN	SM214	ICK2
TELEFUNKEN	SM215	ICC7
TELEFUNKEN	SM218	ICC8
TELEFUNKEN	SM253	618A
TELEFUNKEN	SM256	ICC7

Brand	model	chassis
TELEFUNKEN	SM258	ICC8
TELEFUNKEN	SM293	ICC5
TELEFUNKEN	SM296	ICC7
TELEFUNKEN	SM298	ICC8
TELEFUNKEN	SMX215	ICC5
TELEFUNKEN	SMX258	ICC8
TELEFUNKEN	SN252AVT	617
TELEFUNKEN	SP9001AD	ICC5
TELEFUNKEN	SP9402	ICC5
TELEFUNKEN	SP9451	ICC5
TELEFUNKEN	SP9461	ICC5
TELEFUNKEN	SP9501	ICC5
TELEFUNKEN	SP9502	ICC5
TELEFUNKEN	SP9551	ICC5
TELEFUNKEN	SP9561	ICC5
TELEFUNKEN	SR253	ICC7
TELEFUNKEN	SR255	ICC8
TELEFUNKEN	SR285	ICC8
TELEFUNKEN	TF2150TXG	PT91 ?
TELEFUNKEN	TK1469	MC58A (?)
TELEFUNKEN	TTV740	(190-932912-P1)
TELEFUNKEN	TX14SE	TX89
TELEFUNKEN	V2010	415A
TELEFUNKEN	VS444E	ICC19 (100Hz)
TELEFUNKEN	VS674E	ICC19 (100Hz)
TELEFUNKEN	WS460E	ICC19 (100Hz)
TELEFUNKEN	WS660E	ICC19 (100Hz)
TELEFUNKEN	WS671E	ICC19 (100Hz)
TELEMAISTER	EC64203	SCC103 (ELBIT)
TELEMAISTER	EC70203	SCC103 (ELBIT)
TELEMAISTER	EC70302	SCC103 (ELBIT)
TELEMAISTER	EC70403QT	SCC103 (ELBIT)
TELERENT	470T2100S	TV2
TELESONIC	70303SAT	SCC103 (ELBIT)
TELESTAR		PT90A (v. K) (99TA028K)

Brand	model	chassis
TELESTAR		PT90A (v. S) (99TA028S)
TELESTAR		PT99H--03 (TA098-4)
TELESTAR	1155T (7155T ?)	PT11
TELESTAR	2151 DELTA	PT11
TELESTAR	2155T DELTA	PT11 ?
TELESTAR	2168TXT	PC04A
TELESTAR	2551 DELTA	PT11
TELESTAR	2970DWH	PT90A
TELESTAR	2970DWH Aura	PT90P6DK
TELESTAR	3155FS	PTV7
TELESTAR	4051	SM1 MONO
TELESTAR	4055	SM1 MONO
TELESTAR	4055T	SM1 ?
TELESTAR	4055T	SM1 MONO
TELESTAR	4063T	PTV7
TELESTAR	4063T Profilo	SM1 ? (95TA006B)
TELESTAR	4072T Profilo	SM1 (czy? SM2)
TELESTAR	4155T	PT11
TELESTAR	4855T	PT92
TELESTAR	5055	SM1
TELESTAR	5055T	SM1
TELESTAR	5063T	SM1
TELESTAR	5063TXST	SM1
TELESTAR	5575A	PT90 ?
TELESTAR	5870DW	PT92DVD
TELESTAR	6055T	SM1 MONO ?
TELESTAR	6855	PT92
TELESTAR	6870	PT92
TELESTAR	6870 TN MEGA	PT92
TELESTAR	6870DW	PT92DVD
TELESTAR	7155	STEREO PLUS ?
TELESTAR	7155TN	PT11
TELESTAR	7469TA	SM2
TELESTAR	7469TA BETA	SM2
TELESTAR	7869TN BETA	PT92

Brand	model	chassis
TELESTAR	8070	SM2 ?
TELESTAR	8155TA	PT11
TELESTAR	8355TS	SM2
TELESTAR	8470TA	SM2 (97TA010I)
TELESTAR	8837T	PT92
TELESTAR	8837T ULTRA	PT92
TELESTAR	8937 ULTRA	PT90
TELESTAR	8937T	PT90J
TELESTAR	8937T	PT90J
TELESTAR	8937T ULTRA	PT90J BDK
TELESTAR	8937T ULTRA	PT92
TELESTAR	8970TN	PT90A
TELESTAR	8970TN	PT90A
TELESTAR	8970TN ULTRA	PT90A
TELESTAR	9155T	PT11
TELESTAR	9470TN	SM2
TELESTAR	9822	PC91A
TELESTAR	9855T	PT92
TELESTAR	9855TN	PT92
TELESTAR	9870TN	PT92 ?
TELESTAR	9870TN	PT92 ?
TELESTAR	9880 CROMA	PT92
TELESTAR	9880TW	PT92
TELESTAR	9880WS	PT92
TELESTAR	9880WS CROMA	PT92
TELESTAR	9955T	PT90-90 (czy? PT90A)
TELESTAR	9955T Croma	PT90A
TELESTAR	9955TN	PT90A
TELESTAR	9970 2 Croma	PT90A
TELESTAR	9970 DWA	PT90A
TELESTAR	9970 DWA Croma	PT90A (02TA058H)
TELESTAR	9970DWA	PT90A
TELESTAR	9980 Dwa	PT90A
TELESTAR	9980 Dwa Croma	PT90
TELESTAR	AURA928	PT90

Brand	model	chassis
TELESTAR	Croma 032HW	SM2
TELESTAR	Croma 332W	PT200
TELESTAR	CROMA 921N	PT90 (?)
TELESTAR	CTV2001	PB2001VS
TELESTAR	CTV2003	PB2103V...
TELESTAR	CTV2003TXT	PB2103V...
TELESTAR	CTV2103	PB2103V...
TELESTAR	CTV2103TXT	PB2103V...
TELESTAR	CTV2503	PB2103V...
TELESTAR	CTV2503T	PB2103V...
TELESTAR	CTV4037	SM1
TELESTAR	CV8970	PT90 ?
TELESTAR	LIRA 929	PT90 (?)
TELESTAR	LYRA515	PT90B (?)
TELESTAR	PROFILI 4063T	SM1 Stereo
TELESTAR	Profilo 5055	SM1
TELESTAR	Profilo 6070TXT ST	SM1-28
TELESTAR	Smart 8151T	PT11
TELESTAR	T2975SPTX	PT200
TELESTAR	TF072TNZ	PT100
TELESTAR	TF872TN	PT92
TELESTAR	TF872TN	PT92SDGN
TELESTAR	ULTRA 914	PT90JEBDKG
TELESTAR	ULTRA 928N	PT90V4E
TELETECH	3745	11AK20SE
TELETECH	5199	11AK10
TELETECH	5559	11AK10
TELETECH	7202	11AK19
TELETECH	BERLIN	11AK19
TELETECH	CT2500	11AK10
TELETECH	CT2501	11AK10
TELETECH	CT2551	11AK10
TELETECH	CT2590ST	11AK10
TELETECH	CT3050	11AK10
TELETECH	CT3100ST	11AK10

Brand	model	chassis
TELETECH	CT3200ST	11AK10
TELETECH	CT3245	11AK19
TELETECH	CT3250ST	11AK10
TELETECH	CT360	11AK20
TELETECH	CT360	11AK20SE1
TELETECH	CT3604	11AK36A15
TELETECH	CT361	11AK20
TELETECH	CT362	11AK20 ?
TELETECH	CT510	11AK10
TELETECH	CT510/A	11AK19
TELETECH	CT511	11AK19
TELETECH	CT511A	11AK19
TELETECH	CT550	11AK19
TELETECH	CT555/A	11AK19
TELETECH	CT555A	11AK19P4
TELETECH	CT560	11AK19
TELETECH	CTV2155 TX SI	11AK30 (?)
TELETECH	CTV2155 TXP	Chiny ...
TELETECH	CTV5100	11AK10
TELETECH	CTV5110	11AK10
TELETECH	CTV5125	11AK10
TELETECH	CTV5525	11AK10
TELETECH	CTV7292	11AK19
TELETECH	ST5196VT	11AK10
TELETECH	SYDNEY	11AK19
TELETECH	TVD1421	11AK46
TELETON	CT20	BS665
TELETON	TC200D	BS700
TELEVIEW	TV51110T	TV95
TELEVIEW	TV55520TS	E9
TELEVIEW	TV70520TS	E9
TENSAI	TCT100BG	K3911
TENSAI	TCT2010PX	12.1 ?
TENSAI	TCT2181FB	C40
TENSAI	TCT253	F9

Brand	model	chassis
TENSAI	TCT282BG	F9-00
TENSAI	TCT282BK	F9
TENSAI	TCT289PX	F16R2 (FORMENTI)
TENSAI	TCT362B	(G01-A819A / G01A819A)
TENSAI	TCT3645	P54
TENSAI	TCT524BG	C41
TENSAI	TCT524BK	C41M
TENSAI	TCT524P	C43M
TENSAI	TCTP5139	PC91A
TENSAI	TST254KXN	F8
TESLA	S633TSP2	E6
TESLA	TTV-M1415TM	11AK36
TESLA	TTVS2810TS	11AK19
TESLA	TV-S55TS	E5
TESLA	TVS7051TS	TV17
TEVION	5505RF	K1 (KX1.190-04) (KX5 LEN)
TEVION	MD2822A	TV17XL4 PIP
TEVION	MD3731VT	11AK20M6
TEVION	MD3751VT-S	11AK20SE2
TEVION	MD3751VTB	11AK20S
TEVION	MD3761VT	11AK20S
TEVION	MD3761VTS	11AK20 SE-5
TEVION	MD40222	11AK52
TEVION	MD5535	PT11 ?
TEVION	MD5540VT	PT92
TEVION	MD5560	16.1 (BEKO)
TEVION	MD7066	11AK52
TEVION	MD7078VTS	TV9.6PAL
TEVION	MD7085VTS	TV9.6
TEVION	MD7110VTS	TV17.1 (100Hz)
TEVION	MD7110VTS-A	TV17XL (100Hz)
TEVION	MD7110VTS-S	TV17.6 (100Hz)
TEVION	MD7115VTS-S	TV17XL.6
TEVION	MD8205	TV17H
TEVION	MD8209VTS	TV17.6 (100Hz)

Brand	model	chassis
TEVION	T1413	PM2TV2K (TV2K)
TEVION	TEV66SIL	PT92 16:9
TEVION	TV5530VT	PT2
TEVION	TV5535VT	PT11 ? (99TA017C)
TEVION	TV5540VT	PT92-90
TEVION	TV5560VT	16.1 ?
TEVION	TV7004-2	22.1 (ZA1.190-12) (BEKO)
TEVION	TV7004-2	22.1 (ZA1.190-13) (BEKO)
THOMSON	10MG79B	TX91
THOMSON		ETC012
THOMSON		TX91SA
THOMSON	...650S	ICC21
THOMSON	10MG70B	TX91
THOMSON	10MH70B	TX91
THOMSON	10MH80BT	TX91
THOMSON	10MK15FP	TX807
THOMSON	10MK15FT	TX807
THOMSON	10MK15GP	TX807
THOMSON	10MK15GT	TX807
THOMSON	10MK15RP	TX807
THOMSON	10MK15RT	TX807
THOMSON	10MK15UF	TX807
THOMSON	10MK16FT	TX807C
THOMSON	10MK16GT	TX807C
THOMSON	10MK16RT	TX807C
THOMSON	10MK16UF	TX807C
THOMSON	10MK16UG	TX807C
THOMSON	10MK16UR	TX807C
THOMSON	14CB10C	EUROCOMBO2
THOMSON	14CB15FT	EUROCOMBO2
THOMSON	14CB25CT	EUROCOMBO2
THOMSON	14CB26EN	EUROCOMBO2
THOMSON	14CD25CG	EUROCOMBO2
THOMSON	14CT180	ITC008EU
THOMSON	14GP AQUA	TX807

Brand	model	chassis
THOMSON	14MF10C	418b/TX807
THOMSON	14MF10E	TX807C
THOMSON	14MF110G	TX807C
THOMSON	14MG10C	TX807
THOMSON	14MG10E	TX807C
THOMSON	14MG10F	TX807
THOMSON	14MG10G	TX807
THOMSON	14MG10U	TX807
THOMSON	14MG110G	TX807C
THOMSON	14MG110R	TX807C
THOMSON	14MG120B	TX807C
THOMSON	14MG13063	TX807C
THOMSON	14MG130G	TX807C
THOMSON	14MG130G2	TX807C
THOMSON	14MG130G3	TX807C
THOMSON	14MG131G	TX807C
THOMSON	14MG13KN	TX807C ?
THOMSON	14MG15CG	TX807
THOMSON	14MG15CL	TX807
THOMSON	14MG15ES	TX807C
THOMSON	14MG15ET	TX807C/CS
THOMSON	14MG15US	TX807C
THOMSON	14MG56F	TX91
THOMSON	14MG70	TX91
THOMSON	14MG70C	TX91G
THOMSON	14MG73	TX91
THOMSON	14MG73C	TX91G
THOMSON	14MG76C	TX91G
THOMSON	14MG77C	TX91G
THOMSON	14MG79C	TX91
THOMSON	14MH10C	TX807EU
THOMSON	14MK10E	TX807C
THOMSON	14MK130G	TX807C
THOMSON	14MK140G	TX807C
THOMSON	14MK141G	TX807C

Brand	model	chassis
THOMSON	14MK15ET	TX807C
THOMSON	14MK15FT	TX807
THOMSON	14MK15U1	TX807C
THOMSON	14MK16ET	TX807C/CS
THOMSON	14MK16UT	TX807C
THOMSON	14MK66BC	TX91
THOMSON	14ML10C	TX807
THOMSON	14ML10E	TX807C
THOMSON	14ML110G	TX807C
THOMSON	14MS10C	TX807
THOMSON	14MS15CX	TX807
THOMSON	14MS15FT	TX807
THOMSON	14MS15GT	TX807
THOMSON	14MS15UT	TX807
THOMSON	14MS70CT	TX91G
THOMSON	14MS74CT	TX91
THOMSON	14MS76CT	TX91G
THOMSON	14MT8DR	TX91EM16
THOMSON	15MH182T	ETC009
THOMSON	15MK15ET	TX807C
THOMSON	15MK51BT	TX91
THOMSON	17MS51BT	TX91
THOMSON	20CB20C	EUROCOMBO2
THOMSON	20CB25FT	EUROCOMBO2
THOMSON	20DG10E	TX807C
THOMSON	20DG130G	TX807C
THOMSON	20DG15ES	TX807C/CS
THOMSON	20DG15ET	TX807C/CS
THOMSON	20DG17E	TX807CS
THOMSON	20DG17VSTH	TX807C
THOMSON	20DG76C	TX91G
THOMSON	20DG76CT	TX91G
THOMSON	20LB020S4	LCD02TC
THOMSON	20MF10C	TX807
THOMSON	20MF15CL	TX807

Brand	model	chassis
THOMSON	20MF15ET	TX807C
THOMSON	20MF15GT	TX807
THOMSON	20MG10C	TX807
THOMSON	20MG10E	TX807C
THOMSON	20MG110R	TX807C
THOMSON	20MG130G	TX807C
THOMSON	20MG15CG	TX807
THOMSON	20MG15CL	TX807
THOMSON	20MG15CX	TX807
THOMSON	20MG15ET	TX807 (A.M.: raczej: TX807CS)
THOMSON	20MG15GT	TX807
THOMSON	20MG76B	TX91G
THOMSON	20MG76C	TX91G
THOMSON	20MG77C	TX91G
THOMSON	20MG79CL	TX91G ?
THOMSON	20MH10C	TX807
THOMSON	20MH15CL	TX807
THOMSON	20MH15GT	TX807
THOMSON	20ML110R	TX807CS
THOMSON	2180RI	AK30
THOMSON	21CB25FT	EUROCOMBO2
THOMSON	21CB26UN	EUROCOMBO2
THOMSON	21CH22E	EUROCOMBO2
THOMSON	21CT17E	EUTVD2001 (TVD EU2001)
THOMSON	21CT17ES	TVD EU 2001
THOMSON	21CT180S	EUTVD2001
THOMSON	21CT181S	EUTVD2001
THOMSON	21DC150S	ITC008
THOMSON	21DC220S	ITC008
THOMSON	21DC320	ITC008
THOMSON	21DC320BT	ETC009
THOMSON	21DC320T	ETC009
THOMSON	21DG130G	TX807C
THOMSON	21DG130G2	TX807C
THOMSON	21DG15CE	TX807C

Brand	model	chassis
THOMSON	21DG15CH	TX807
THOMSON	21DG15ES	TX807C
THOMSON	21DG15ET	TX807C
THOMSON	21DG170G	TX807CS
THOMSON	21DG17E	TX807C/CS
THOMSON	21DG22E	ICC17
THOMSON	21DK15CH	TX807
THOMSON	21DK170G	TX807CS
THOMSON	21DK24E	ICC17
THOMSON	21DK24U	ICC17
THOMSON	21DM182	ITC008EN
THOMSON	21DM182T	ETC009
THOMSON	21DM182T2	ETC009
THOMSON	21DP130G	TX807C
THOMSON	21DP135KG	ITC008
THOMSON	21DP170G	TX807CS
THOMSON	21DP210G	ICC17
THOMSON	21DR220G	ITC008
THOMSON	21DS70H	TX92
THOMSON	21DS74H	TX92F
THOMSON	21DS76H	TX92
THOMSON	21DU21C	ICC17
THOMSON	21DU21E	ICC17
THOMSON	21DU22C	ICC17
THOMSON	21DU22E	ICC17
THOMSON	21DV21C	ICC17
THOMSON	21DX170S	TX807CS
THOMSON	21DX171S	TX807CS
THOMSON	21DX175S	ITC008
THOMSON	21DX17E	TX807CS
THOMSON	21DX205S	ITC008
THOMSON	21DX210S	ICC17
THOMSON	21DX25E	ICC17
THOMSON	21DX35E	ICC17
THOMSON	21EX170S	TX807CS

Brand	model	chassis
THOMSON	21EX215S	ITC008
THOMSON	21L0602	ETC009
THOMSON	21MC77C	TX91G
THOMSON	21MF10C	TX807
THOMSON	21MF10E	TX807C
THOMSON	21MF130G	TX807C
THOMSON	21MF15CL	TX807
THOMSON	21MF15ET	TX807C (CS ?)
THOMSON	21MF15GT	TX807
THOMSON	21MG10E	TX807C
THOMSON	21MG110R	TX807C
THOMSON	21MG130G	TX807C
THOMSON	21MG131G	TX807C
THOMSON	21MG132	ITC008
THOMSON	21MG15ES	TX807C
THOMSON	21MG15ET	TX807CEX
THOMSON	21MG15UT	TX807C
THOMSON	21MG172T	ETC009
THOMSON	21MG17E	TX807
THOMSON	21MG17U	TX807CS
THOMSON	21MG17UG	TX807CS
THOMSON	21MG18EG	TX807CS
THOMSON	21MG51F	TX91
THOMSON	21MG76C	TX91G
THOMSON	21MG79CL	TX91G
THOMSON	21MH10C	TX807
THOMSON	21MH10CL	TX807
THOMSON	21MH15CL	TX807
THOMSON	21MH182	ITC008
THOMSON	21MH76C	TX91G
THOMSON	21ML15ET	TX807C
THOMSON	21MS56BT	TX91
THOMSON	21MS70CT	TX91G
THOMSON	21MS73CT	TX91G
THOMSON	21MS74CT	TX91G

Brand	model	chassis
THOMSON	21MS76CT	TX91G
THOMSON	21MS76G	TX91G
THOMSON	21MS90G	TX91G
THOMSON	21MT10C	TX807
THOMSON	21MT10E	TX807C/CS
THOMSON	21MT10F	TX807
THOMSON	21MT130G	TX807C
THOMSON	21MT15CG	TX807C
THOMSON	21MT15CL	TX807
THOMSON	21MT15CL	TX807C/CS
THOMSON	21MT15CX	TX807C/CS ?
THOMSON	21MT15ET	TX807C
THOMSON	21MT15FT	TX807
THOMSON	21MT15GT	TX807
THOMSON	21MT21C	ICC17
THOMSON	21MT21E	ICC17
THOMSON	21MT22C	ICC17
THOMSON	21MT22E	ICC17
THOMSON	21MX130S	TX807C
THOMSON	21MX135S	TX807C
THOMSON	21MX15E	TX807C
THOMSON	21MX170S	TX807CS
THOMSON	21MX171S	TX807CS
THOMSON	21MX172	ITC008
THOMSON	21MX17E	TX807CS
THOMSON	23LB020S4	LCD02TC
THOMSON	24VS65J	ICC9-107
THOMSON	24WK21E	ICC17
THOMSON	24WK22E	ICC17
THOMSON	24WK23U	ICC17
THOMSON	24WK24U	ICC17
THOMSON	24WK25EG	ICC17
THOMSON	24WK25UG	ICC17
THOMSON	24WK25US	ICC17
THOMSON	24WT25EG	ICC17 (DVD)

Brand	model	chassis
THOMSON	24WT25ES	ICC17
THOMSON	24WT25UG	ICC17
THOMSON	24WT25US	ICC17
THOMSON	25CT25ES	ICC17
THOMSON	25DC128	ITC008EN
THOMSON	25DC182	ITC008
THOMSON	25DC222KG	ITC008
THOMSON	25DF21E	ICC17
THOMSON	25DF22E	ICC17
THOMSON	25DG15ET	TX807C
THOMSON	25DG16E	ICC17
THOMSON	25DG16ET	ICC17
THOMSON	25DG170G	TX807CS
THOMSON	25DG17E	TX807
THOMSON	25DG17U	TX807CS
THOMSON	25DG17UG	TX807CS
THOMSON	25DG21C	ICC17
THOMSON	25DG21E	ICC17
THOMSON	25DG21U	ICC17
THOMSON	25DG22C	ICC17
THOMSON	25DG22E	ICC17
THOMSON	25DG24U	ICC17
THOMSON	25DG25EG	ICC17
THOMSON	25DG25ES	ICC17
THOMSON	25DG64H	TX92F
THOMSON	25DG74DT	TX92F
THOMSON	25DH21E	ICC17
THOMSON	25DH55N	ICC11
THOMSON	25DH65J	ICC9-100
THOMSON	25DH79J	ICC9
THOMSON	25DH89HL	TX92F
THOMSON	25DS55J	ICC9
THOMSON	25DT21E	ICC17
THOMSON	25DT22E	ICC17
THOMSON	25DT64J	TX92F

Brand	model	chassis
THOMSON	25DT66H	TX92F
THOMSON	25DT66J	ICC9-100
THOMSON	25DU21E	ICC17
THOMSON	25DU24E	ICC17
THOMSON	25DU40E	ICC19 (100Hz)
THOMSON	25DU78K	ICC19
THOMSON	25DU78M	ICC19 (100Hz)
THOMSON	25DX175S	ITC008
THOMSON	25DX210S	ICC17
THOMSON	25DX25ES	ICC17
THOMSON	25GD16ET	ICC17
THOMSON	25MH21E	ICC17
THOMSON	25MN15ET	TX807CS
THOMSON	25MN16ET	ICC17
THOMSON	25MN44H	TX92F
THOMSON	25MN79DL	TX92F
THOMSON	25MS56J	ICC9
THOMSON	26LB040S5	EFC031E
THOMSON	27LCDB03B	LCD03B
THOMSON	27LM051B6	Trident
THOMSON	28DF170G	TX807CS
THOMSON	28DF170R	TX807CS
THOMSON	28DF170S	TX807CS
THOMSON	28DF171G	TX807CS
THOMSON	28DF171S	TX807CS
THOMSON	28DF17E	TX807CS
THOMSON	28DF21E	ICC17
THOMSON	28DF22E	ICC17
THOMSON	28DF40E	ICC19 (100Hz)
THOMSON	28DF42E	ICC19 (100Hz)
THOMSON	28DG15CL	TX92F
THOMSON	28DG15ET	TX807C
THOMSON	28DG16ET	ICC17
THOMSON	28DG170G	TX807CS
THOMSON	28DG17E	TX807

Brand	model	chassis
THOMSON	28DG17U	TX807CS
THOMSON	28DG17UG	TX807CS
THOMSON	28DG21C	ICC17
THOMSON	28DG21E	ICC17
THOMSON	28DG21U	ICC17
THOMSON	28DG22C	ICC17
THOMSON	28DG22E	ICC17
THOMSON	28DG22E	ICC17
THOMSON	28DG24U	ICC17
THOMSON	28DG35UD	ICC19
THOMSON	28DG40E	ICC19 (100Hz)
THOMSON	28DG42E	ICC19 (100Hz)
THOMSON	28DG74DT	TX92F
THOMSON	28DGH17E	TX807CS
THOMSON	28DI400R	ICC20 (100Hz)
THOMSON	28DI42E	ICC20 (100Hz)
THOMSON	28DK24E	ICC17
THOMSON	28DK25ES	ICC17
THOMSON	28DK26ED	ICC17
THOMSON	28DK35ES	ICC17
THOMSON	28DK42E	ICC20 (100Hz)
THOMSON	28DK44E	ICC19 (100Hz)
THOMSON	28DK44ES	ICC19
THOMSON	28DK45ES	ICC20 (100Hz)
THOMSON	28DN20E	ICC17
THOMSON	28DN400G	ICC20 (100Hz)
THOMSON	28DN40E	ICC20 (100Hz)
THOMSON	28DN420E	ETC210 (cyfr.) (100Hz)
THOMSON	28DN420G	ETC210 (cyfr.) (100Hz)
THOMSON	28DP171G	TX807CS
THOMSON	28DP175G	ITC008
THOMSON	28DP182	ITC008
THOMSON	28DP182T	ETC010
THOMSON	28DP25EG	ICC17
THOMSON	28DP35EG	ICC17

Brand	model	chassis
THOMSON	28DP420G	ETC210 (cyfr.) (100Hz)
THOMSON	28DP42E	ICC20 (100Hz)
THOMSON	28DP42EG	ICC17
THOMSON	28DP45EG	ICC17
THOMSON	28DR220G	ITC008
THOMSON	28DR430G	ICC20 (100Hz)
THOMSON	28DS40E	ICC20 (100Hz)
THOMSON	28DT21E	ICC17
THOMSON	28DT22E	ICC17
THOMSON	28DT41E	ICC19
THOMSON	28DT64J	TX92F
THOMSON	28DT65J	ICC9
THOMSON	28DT66H	TX92F
THOMSON	28DT66J	ICC9
THOMSON	28DT68L	ICC11
THOMSON	28DT78ME	ICC19 (100Hz)
THOMSON	28EX22E	ICC17
THOMSON	28EX250G	ITC008
THOMSON	28EX42E	ICC20 (100Hz)
THOMSON	28EX55EB	ICC20 (100Hz)
THOMSON	28M856J	ICC9
THOMSON	28MN20E	TX92F
THOMSON	28MN79DL	TX92F
THOMSON	28VK24U	ICC17
THOMSON	28VK25E	ICC17
THOMSON	28VK25EG	ICC17
THOMSON	28VK25ES	ICC17
THOMSON	28VK25UG	ICC17
THOMSON	28VK25US	ICC17
THOMSON	28VK26UW	ICC17
THOMSON	28VK27WS	ICC17
THOMSON	28VK35ES	ICC17
THOMSON	28VK35US	ICC17
THOMSON	28VK44E	ICC19 (100Hz)
THOMSON	28VK44ES	ICC19 (100Hz)

Brand	model	chassis
THOMSON	28VK45E	ICC20 (100Hz)
THOMSON	28VK45EG	ICC20 (100Hz)
THOMSON	28VK45ES	ICC20 (100Hz)
THOMSON	28VT60E	ICC19 (100Hz)
THOMSON	28VT62J	ICC9
THOMSON	28VT65J	ICC9
THOMSON	28VT68N	ICC11
THOMSON	28WD210S	ICC17 (DVD)
THOMSON	28WD211S	ICC17 (DVD)
THOMSON	28WF200G	ICC17
THOMSON	28WF201G	ICC17
THOMSON	28WF25EG	ICC17
THOMSON	28WF25ES	ICC17
THOMSON	28WF25UG	ICC17
THOMSON	28WF25US	ICC17
THOMSON	28WF400G	ICC20 (100Hz)
THOMSON	28WF401G	ICC20GB (100Hz)
THOMSON	28WF45EG	ICC20 (100Hz)
THOMSON	28WF45ES	ICC20 (100Hz)
THOMSON	28WF45UG	ICC20 (100Hz)
THOMSON	28WF55ES	ICC20 (100Hz)
THOMSON	28WF64EB	ICC19
THOMSON	28WF64EL	ICC19
THOMSON	28WF64ER	ICC19
THOMSON	28WF64ES	ICC19 (100Hz)
THOMSON	28WF64US	ICC19
THOMSON	28WH101	ITC008
THOMSON	28WH200S	ICC17
THOMSON	28WH201S	ICC17
THOMSON	28WH402S	ETC210 (cyfr.) (100Hz)
THOMSON	28WH403S	ETC210 (cyfr.) (100Hz)
THOMSON	28WH412S	ETC210 (cyfr.) (100Hz)
THOMSON	28WM100T	ETC010
THOMSON	28WN22C	ICC17
THOMSON	28WN22E	ICC17

Brand	model	chassis
THOMSON	28WN22U	ICC17
THOMSON	28WO43E	ICC20 (100Hz)
THOMSON	28WR22E	ICC17
THOMSON	28WR22U	ICC17
THOMSON	28WR23EG	ICC17
THOMSON	28WR23UG	ICC17
THOMSON	28WR25UG	ICC17
THOMSON	28WR45EG	ICC20 (100Hz)
THOMSON	28WS100	ITC008 (?)
THOMSON	28WS21E	ICC17
THOMSON	28WS22E	ICC17
THOMSON	28WS22U	ICC17
THOMSON	28WS23E	ICC17
THOMSON	28WS23U	ICC17
THOMSON	28WS24E	ICC17
THOMSON	28WS24E	ITC008
THOMSON	28WS26EW	ICC17
THOMSON	28WS42E	ICC19 (100Hz)
THOMSON	28WS43E	ICC19 (100Hz)
THOMSON	28WS45ED	ICC19 (100Hz)
THOMSON	28WS72J	ICC9
THOMSON	28WS78KE	ICC19
THOMSON	28WS78M	ICC19 (100Hz)
THOMSON	28WS78MP	ICC19
THOMSON	28WT25ES	ICC17
THOMSON	28WX210S	ICC17
THOMSON	28WX211S	ICC17
THOMSON	28WX35ES	ICC17
THOMSON	28WX35US	ICC17
THOMSON	28WX410S	ICC20 (100Hz)
THOMSON	28WX410T	ICC20 (100Hz)
THOMSON	28WX411S	ICC20 (100Hz)
THOMSON	28WX411T	ICC20 (100Hz)
THOMSON	28WX55ES	ICC20 (100Hz)
THOMSON	28WX65ES	ICC19MM

Brand	model	chassis
THOMSON	28WX65US	ICC19
THOMSON	28WZ210S	ICC17
THOMSON	28WZ400S	ICC20 (100Hz)
THOMSON	28WZ412S	ETC210 (cyfr.) (100Hz)
THOMSON	28WZ413S	ETC210 (cyfr.) (100Hz)
THOMSON	28WZ510S	ICC20 (100Hz)
THOMSON	28WZ610S	ICC21
THOMSON	28WZ611S	ICC21
THOMSON	29DC220S	ITC008
THOMSON	29DC410 DS	ETC210 (cyfr.) (100Hz)
THOMSON	29DC410S	ETC210 (cyfr.) (100Hz)
THOMSON	29DC630S	ICC21
THOMSON	29DC830	ITC222
THOMSON	29DC850	ITC222
THOMSON	29DF170G	ICC20 (100Hz)
THOMSON	29DF172	ITC008
THOMSON	29DF25EB	ICC17
THOMSON	29DF25EG	ICC17
THOMSON	29DF25ES	ICC17
THOMSON	29DF400EN	ETC210EN !
THOMSON	29DF400G	ICC20 (100Hz)
THOMSON	29DF42E	ICC20 (100Hz)
THOMSON	29DF42ES	ICC20 (100Hz)
THOMSON	29DF45CS	ICC20 (100Hz)
THOMSON	29DF45EB	ICC20 (100Hz)
THOMSON	29DF45EG	ICC20 (100Hz)
THOMSON	29DF45ES	ICC20 (100Hz)
THOMSON	29DF55N	ICC11
THOMSON	29DF65J	ICC9
THOMSON	29DH21E	ICC17
THOMSON	29DH22C	ICC17
THOMSON	29DH40E	ICC19 (100Hz)
THOMSON	29DH42E	ICC19 (100Hz)
THOMSON	29DH50N	ICC10
THOMSON	29DH50ND	ICC11

Brand	model	chassis
THOMSON	29DH55N	ICC11
THOMSON	29DH58NE	ICC9
THOMSON	29DH78K	ICC19
THOMSON	29DH79J	ICC9
THOMSON	29DJ24E	ICC17
THOMSON	29DJ25EG	ICC17
THOMSON	29DJ35ES	ICC17
THOMSON	29DJ42E	ICC20 (100Hz)
THOMSON	29DJ44E	ICC19 (100Hz)
THOMSON	29DJ45EG	ICC21
THOMSON	29DJ45ES	ICC20 (100Hz)
THOMSON	29DJ55ES	ICC20 (100Hz)
THOMSON	29DJ74E	ICC19 (100Hz)
THOMSON	29DL200G	ICC17
THOMSON	29DL21C	ICC17
THOMSON	29DL21E	ICC17
THOMSON	29DL22C	ICC17
THOMSON	29DL22E	ICC17
THOMSON	29DL25ED	ICC17
THOMSON	29DL40E	ICC19
THOMSON	29DL42E	ICC19
THOMSON	29DM182KG	ITC008
THOMSON	29DM182T	ETC010
THOMSON	29DM400	ETC210 (cyfr.) (100Hz)
THOMSON	29DM400KG	ETC210 (cyfr.) (100Hz)
THOMSON	29DU21E	ICC17
THOMSON	29DU22E	ICC17
THOMSON	29DU40E	ICC19
THOMSON	29DU43E	ICC19 (100Hz)
THOMSON	29DU45ED	ICC19 (100Hz)
THOMSON	29DU60E	ICC19 (100Hz)
THOMSON	29DU70E	ICC19 (100Hz)
THOMSON	29DU78K	ICC19
THOMSON	29DU78NE	ICC11
THOMSON	29DU78NV	ICC11

Brand	model	chassis
THOMSON	29DU88M	ICC19
THOMSON	29DU88NE	ICC19 (100Hz)
THOMSON	29DU98MP	ICC19
THOMSON	29DX170S	TX807CS EN
THOMSON	29DX172	ITC008
THOMSON	29DX175S	ICC9 (pono)
THOMSON	29DX175S	ITC008
THOMSON	29DX175S	ITC008
THOMSON	29DX210S	ICC17
THOMSON	29DX25ES	ICC17
THOMSON	29DX35ES	ICC17
THOMSON	29DX400S	ETC210 (cyfr.) (100Hz)
THOMSON	29DX410S	ICC20 (100Hz)
THOMSON	29DX45	ICC21 (?)
THOMSON	29DX45ES	ICC20 (100Hz)
THOMSON	29DX55ES	ICC20 (100Hz)
THOMSON	29DX610S	ICC21
THOMSON	29DX640S	ICC21
THOMSON	29DX640Z	ICC21
THOMSON	29DZ210S	ICC17
THOMSON	29DZ220S	ITC008
THOMSON	29DZ510S	ICC20 (100Hz)
THOMSON	29DZ610S	ICC21
THOMSON	29DZ612S	ICC21
THOMSON	29DZ640S	ICC21
THOMSON	29DZ840W	ICC21
THOMSON	29EF400S	ICC20 (100Hz)
THOMSON	29EX170S	TX807CS
THOMSON	29EX42E	ICC20 (100Hz)
THOMSON	29EX450S	ICC20 (100Hz)
THOMSON	29EX510T	ITC222
THOMSON	29EX510T	ITC222
THOMSON	29L0603	ETC010
THOMSON	29MH21E	ICC17
THOMSON	29MH50N	ICC11

Brand	model	chassis
THOMSON	29MN20C	TX92F
THOMSON	30LB020S4	LCD02TC
THOMSON	32EX450S	ICC20 (100Hz)
THOMSON	32EX45ES	ICC20 (100Hz)
THOMSON	32LB040S5/U	EFC031E
THOMSON	32LB220B4	IFC228LCD
THOMSON	32VK24U	ICC17
THOMSON	32VK25E	ICC17
THOMSON	32VK25EG	ICC17
THOMSON	32VK25ES	ICC17
THOMSON	32VK26UW	ICC17
THOMSON	32VK27WS	ICC17
THOMSON	32VK35US	ICC17
THOMSON	32VK44E	ICC19 (100Hz)
THOMSON	32VK44ES	ICC19
THOMSON	32VK45E	ICC20 (100Hz)
THOMSON	32VK45EG	ICC20 (100Hz)
THOMSON	32VK45ES	ICC20 (100Hz)
THOMSON	32VK55ES	ICC20 (100Hz)
THOMSON	32VK66EW	ICC19
THOMSON	32VK66NW	ICC19
THOMSON	32VK74E	ICC19 (100Hz)
THOMSON	32VT62J	ICC9
THOMSON	32VT65J	ICC9
THOMSON	32VT68N	ICC11
THOMSON	32VT68ND	ICC11
THOMSON	32VT68NE	ICC11
THOMSON	32VT68NV	ICC11
THOMSON	32VT75ED	ICC19 (100Hz)
THOMSON	32VT88NP	ICC19 (100Hz)
THOMSON	32WB642S	ITC222
THOMSON	32WB643S	ITC222
THOMSON	32WB842S	ITC222
THOMSON	32WB843S	ITC222
THOMSON	32WBCANAL	ITC222

Brand	model	chassis
THOMSON	32WD610S	ICC21
THOMSON	32WD611S	ICC21
THOMSON	32WD810B	ICC21
THOMSON	32WD811B	ICC21
THOMSON	32WE612	ITC222
THOMSON	32WE612B	ITC222
THOMSON	32WF200G	ICC17
THOMSON	32WF25EG	ICC17
THOMSON	32WF25ES	ICC17
THOMSON	32WF25UG	ICC17
THOMSON	32WF25US	ICC17
THOMSON	32WF35	ICC17 (?)
THOMSON	32WF400G	ICC20 (100Hz)
THOMSON	32WF401G	ICC20 (100Hz)
THOMSON	32WF402G	ETC210 (cyfr.) (100Hz)
THOMSON	32WF45EG	ICC20 (100Hz)
THOMSON	32WF45ES	ICC20 (100Hz)
THOMSON	32WF45UG	ICC20 (100Hz)
THOMSON	32WF55ES	ICC20 (100Hz)
THOMSON	32WF64E	ICC19MM-100Hz
THOMSON	32WF64EB	ICC19
THOMSON	32WF64EL	ICC19
THOMSON	32WF64ER	ICC19
THOMSON	32WF64ES	ICC19 (100Hz)
THOMSON	32WF64US	ICC19
THOMSON	32WF66NW	ICC19
THOMSON	32WF66WB	ICC19 (100Hz)
THOMSON	32WF66WL	ICC19
THOMSON	32WF66WR	ICC19
THOMSON	32WF66WS	ICC19
THOMSON	32WF74ES	ICC19 (100Hz)
THOMSON	32WF84F	ICC19
THOMSON	32WF84G	ICC19
THOMSON	32WH210S	ICC17
THOMSON	32WH211S	ICC17

Brand	model	chassis
THOMSON	32WH402S	ETC210 (cyfr.) (100Hz)
THOMSON	32WH403S	ETC210 (cyfr.) (100Hz)
THOMSON	32WH412S	ETC210 (cyfr.) (100Hz)
THOMSON	32WM402	ETC210
THOMSON	32WM492	ETC210
THOMSON	32WN22E	ICC17
THOMSON	32WN36	ICC20 (100Hz)
THOMSON	32WN42E	ICC20 (100Hz)
THOMSON	32WO43E	ICC20 (100Hz)
THOMSON	32WR22E	ICC17
THOMSON	32WR22U	ICC17
THOMSON	32WR23EG	ICC17
THOMSON	32WR25UG	ICC17
THOMSON	32WR402S	ETC210 (cyfr.) (100Hz)
THOMSON	32WR45E	ICC20 (100Hz)
THOMSON	32WR45EG	ICC20 (100Hz)
THOMSON	32WS22U	ICC17
THOMSON	32WS23E	ICC17
THOMSON	32WS23U	ICC17
THOMSON	32WS24E	ICC17
THOMSON	32WS26EW	ICC17
THOMSON	32WS42E	ICC19 (100Hz)
THOMSON	32WS43E	ICC19 (100Hz)
THOMSON	32WS45ED	ICC19
THOMSON	32WS65EW	ICC19 (100Hz)
THOMSON	32WS65UD	ICC19
THOMSON	32WS88KE	ICC19
THOMSON	32WS88ME	ICC19 (100Hz)
THOMSON	32WS98MP	ICC19
THOMSON	32WT210S	ICC17
THOMSON	32WT45ES	ICC20 (100Hz)
THOMSON	32WX210S	ICC17
THOMSON	32WX211S	ICC17
THOMSON	32WX35ES	ICC17
THOMSON	32WX35US	ICC17

Brand	model	chassis
THOMSON	32WX401T	ICC20 (100Hz)
THOMSON	32WX410S	ICC20 (100Hz)
THOMSON	32WX410T	ICC20 (100Hz)
THOMSON	32WX410X	ICC20 (100Hz)
THOMSON	32WX411S	ICC20 (100Hz)
THOMSON	32WX411T	ICC20 (100Hz)
THOMSON	32WX55ES	ICC20 (100Hz)
THOMSON	32WX610S	ICC21
THOMSON	32WX65ES	ICC19
THOMSON	32WX65ES	ICC19 (100Hz)
THOMSON	32WX65US	ICC19
THOMSON	32WX66EW	ICC19 (100Hz)
THOMSON	32WX66NW	ICC19
THOMSON	32WX84F	ICC19
THOMSON	32WX84G	ICC19
THOMSON	32WZ410B	ICC20 (100Hz)
THOMSON	32WZ410S	ICC20 (100Hz)
THOMSON	32WZ412S	ETC210 (cyfr.) (100Hz) (100Hz)
THOMSON	32WZ413S	ETC210 (cyfr.) (100Hz)
THOMSON	32WZ510S	ICC20 (100Hz)
THOMSON	32WZ610S	ICC21
THOMSON	32WZ611S	ICC21
THOMSON	32WZ840W	ICC21
THOMSON	32WZ841	ICC21
THOMSON	32WZ841W	ICC21
THOMSON	33MF170G	TX807CS
THOMSON	33MF220G	ITC008
THOMSON	33MF22E	ICC17
THOMSON	33MF22EG	ICC17
THOMSON	33MS21E	ICC17
THOMSON	33MS24E	ICC17
THOMSON	33MS24EG	ICC17
THOMSON	33MS24U	ICC17
THOMSON	33MS24UG	ICC17
THOMSON	33MS25UD	ICC17

Brand	model	chassis
THOMSON	33MS35UD	ICC19
THOMSON	33MS40E	ICC19 (100Hz)
THOMSON	33MS44E	ICC19 (100Hz)
THOMSON	33MS44EG	ICC19
THOMSON	34DC650	ICC21
THOMSON	34DC650S	ICC21
THOMSON	34DC850	ITC222
THOMSON	34DF400G	ICC20 (100Hz)
THOMSON	34DF410G	ICC20 (100Hz)
THOMSON	34DF45EG	ICC20 (100Hz)
THOMSON	34DF640G	ICC21
THOMSON	36100R	TX807C
THOMSON	36100RS	TX807C
THOMSON	36130RI	TX807C
THOMSON	36200M1	TX807C
THOMSON	3670MB	TX91G
THOMSON	36DC650	ICC21
THOMSON	36MK10U	TX91
THOMSON	36MK48CRU	TX91
THOMSON	36MK48U	TX91
THOMSON	36MKL15	TX90
THOMSON	36MKL15V	TX90
THOMSON	36ML45	TX90
THOMSON	36ML47P	TX90
THOMSON	36MT11TX	TX91
THOMSON	36MT16	TX91
THOMSON	36MT19	TX91
THOMSON	36MT40N	TX91
THOMSON	36WT610S	ICC21
THOMSON	36WT611S	ICC21
THOMSON	36WT611T	ICC21
THOMSON	36WX642S	ITC222
THOMSON	36WX87ES	ICC21
THOMSON	36WX87UT	ICC21
THOMSON	37DF640G	ICC21

Brand	model	chassis
THOMSON	37DF850	ITC222
THOMSON	37MG55J	ICC9
THOMSON	37MG75J	ICC9
THOMSON	37MH40E	ICC19 (100Hz)
THOMSON	37MH40U	ICC19
THOMSON	37MH44E	ICC19 (100Hz)
THOMSON	37MH44U	ICC19
THOMSON	40KW610S	RPC21
THOMSON	40KW611S	RPC21
THOMSON	40KW612S	ITC222
THOMSON	40KW613S	ITC222
THOMSON	40TW610S	RPC21
THOMSON	40TW611S	RPC21
THOMSON	42JH67E	RPC21 (ETC221)
THOMSON	42JH67EB	RPC21
THOMSON	42JH68E	RPC21
THOMSON	42JH68US	RPC21
THOMSON	42KH412--476X	ETC210GR (cyfr.) (100Hz)
THOMSON	42KH412S	ETC210
THOMSON	44DLP540	ITC250 ?
THOMSON	44DLY644	ITC250
THOMSON	44DLY645	ITC250
THOMSON	44JW610S	RPC21
THOMSON	44JW611S	RPC21
THOMSON	44MV11	IKC2 ?
THOMSON	44RW65ES	ICC19 (100Hz)
THOMSON	44RW65US	ICC19
THOMSON	44RW67ES	RPC21
THOMSON	44RW67US	RPC21
THOMSON	44TW610S	RPC21
THOMSON	44TW611S	RPC21
THOMSON	44WR67ES	ICC21
THOMSON	46JH67E	ICC21
THOMSON	46JH67EB	RPC21
THOMSON	46JH68E	RPC21

Brand	model	chassis
THOMSON	46JH68US	RPC21
THOMSON	46RG75J	ICC9
THOMSON	46RH40E	ICC19 (100Hz)
THOMSON	46RH40U	ICC19
THOMSON	46RH44E	ICC19 (100Hz)
THOMSON	46RH44U	ICC19
THOMSON	50DLX648	ITC251
THOMSON	50DLY644	ITC250
THOMSON	50DLY645	ITC250
THOMSON	50DSZ644	ITC250
THOMSON	50DSZ645	ITC250
THOMSON	51011	A01
THOMSON	51100M	TX807
THOMSON	51100M1	TX807C
THOMSON	51100R	TX807C
THOMSON	51130RH	TX807C
THOMSON	51130RI	TX807C
THOMSON	51ML11	IKC2
THOMSON	51ML14	ICC6
THOMSON	51ML15P	ICC6
THOMSON	51ML16TX	TX90
THOMSON	51MT11X	TX91
THOMSON	52JW640S	RPC21
THOMSON	52JW641S	RPC21
THOMSON	52RG72J	ICC9
THOMSON	52RH40E	ICC19 (100Hz)
THOMSON	52RH40U	ICC19
THOMSON	52RH44E	ICC19 (100Hz)
THOMSON	52RH44U	ICC19
THOMSON	52RW610S	RPC21
THOMSON	52RW611S	RPC21
THOMSON	52RW64E	ICC19
THOMSON	52RW65ES	ICC19 (100Hz)
THOMSON	52RW76EW	ICC19 (100Hz)
THOMSON	52RW76UW	ICC19

Brand	model	chassis
THOMSON	52RW77NW	ICC19
THOMSON	52RW77UW	ICC19
THOMSON	52RW77WS	ICC19 (100Hz)
THOMSON	52RW87ES	RPC21
THOMSON	52TW610S	RPC21
THOMSON	52WR87ES	ICC21
THOMSON	55100M	TX807
THOMSON	55170R	TX807CS
THOMSON	55170RH	TX807CS
THOMSON	55170RI	TX807CS
THOMSON	55200M	TX807C
THOMSON	55200S	TX807CS
THOMSON	55210S	ICC17
THOMSON	55DP81	ICC7
THOMSON	55DS60TX	TX91
THOMSON	55MC16	ICC6
THOMSON	55MC16TX	TX91
THOMSON	55MC16TX-A	TX91
THOMSON	55MC16x	TX91 ?
THOMSON	55MK10TX	TX91
THOMSON	55MK11	TX91
THOMSON	55MK18	TX91
THOMSON	55MK18U	TX91
THOMSON	55MK48	TX91
THOMSON	55MK48U	TX91
THOMSON	55ML10	IKC2
THOMSON	55ML11	IKC2
THOMSON	55ML15	ICC6
THOMSON	55MN55	ICC8
THOMSON	55MN81	ICC7
THOMSON	55MP45	IKC2
THOMSON	55MP60	ICC9
THOMSON	55MP70	ICC7
THOMSON	55MS11TX	IKC2
THOMSON	55MT10	TX91

Brand	model	chassis
THOMSON	55MT15	ICC6
THOMSON	55MT16TX	TX91MB
THOMSON	55MT18	ICC6 ?
THOMSON	55MT41	TX91
THOMSON	55MT50	ICC8
THOMSON	55MT60TX	ICC9
THOMSON	55MV11	IKC2
THOMSON	55MV21TX	IKC2
THOMSON	55MV71TX	ICC7
THOMSON	55MX50TX	ICC8
THOMSON	60DXC68U	ICC9
THOMSON	61DLW616	ITC250
THOMSON	61DLX648	ITC251
THOMSON	61DLY644	ITC250
THOMSON	61DLY645	ITC250
THOMSON	61DSZ644	ITC250
THOMSON	61DSZ645	ITC250
THOMSON	61TW610S	RPC21
THOMSON	61TW611S	RPC21
THOMSON	63AP71	ICC7
THOMSON	63DC68	ICC6
THOMSON	63DE32TX	TX92
THOMSON	63DE48N	TX92
THOMSON	63DE58N	TX92
THOMSON	63DF68	ICC9
THOMSON	63DF88L	ICC10
THOMSON	63DF89L	ICC11
THOMSON	63DK30	ICC6
THOMSON	63DK60TX	ICC9
THOMSON	63DK68	ICC9
THOMSON	63DO50	ICC8
THOMSON	63DO58	ICC8
THOMSON	63DP40	ICC7
THOMSON	63DP51	ICC5 CMOS
THOMSON	63DP81	ICC7

Brand	model	chassis
THOMSON	63DP92	ICC7
THOMSON	63DR50 NIC	ICC8
THOMSON	63DR68	ICC9
THOMSON	63DS30TX	ICC6
THOMSON	63DS30TX	ICC7
THOMSON	63DS50TX	ICC8
THOMSON	63MC60	ICC9
THOMSON	63MK69DU	ICC9
THOMSON	63MK88L	ICC9
THOMSON	63MN32 N	ICC5 IMC
THOMSON	63MP41	ICC7
THOMSON	63MP42	ICC9
THOMSON	63MP49	ICC9
THOMSON	63MP50	ICC8
THOMSON	63MP51	ICC5 CMOS
THOMSON	63MP55	ICC8
THOMSON	63MP58	ICC8
THOMSON	63MP81	ICC7
THOMSON	63MS30	ICC6
THOMSON	63MS32	TX92
THOMSON	63MS70TX	ICC7
THOMSON	63MT60TX	ICC94D
THOMSON	63MT68L	ICC9
THOMSON	69011	A01
THOMSON	70 DP29	ICC7
THOMSON	70 DS30TX	ICC6974
THOMSON	70 DS30TX	ICC7
THOMSON	70 DS50	ICC8
THOMSON	70 DS70TX	ICC8
THOMSON	70170RI	TX807CS
THOMSON	70172RI	ITC008
THOMSON	70200S	TX807CS
THOMSON	70200S2	TX807CS
THOMSON	70201RI	ICC17
THOMSON	70201S	ICC17

Brand	model	chassis
THOMSON	70210S	ICC17
THOMSON	70220S	ICC17
THOMSON	70DC60TX	ICC9
THOMSON	70DE32TX	TX92
THOMSON	70DK28	TX92
THOMSON	70DK58	TX92
THOMSON	70DK60 DPL	ICC9
THOMSON	70DK68	ICC9
THOMSON	70DK78L	ICC10
THOMSON	70DK78LCY	ICC10
THOMSON	70DXC68U	ICC9
THOMSON	70MK30	ICC6
THOMSON	70MK68	ICC9
THOMSON	70MS50	ICC8
THOMSON	70PS29	ICC7
THOMSON	70W212S	ICC17
THOMSON	72 NM32E	ICC5 IMC
THOMSON	72DF60TX	ICC9
THOMSON	72DF68	ICC9
THOMSON	72DF69	ICC9
THOMSON	72DF88L	ICC9
THOMSON	72DF88N	ICC10
THOMSON	72DF89L	ICC11
THOMSON	72DN31E	ICC5 IMC
THOMSON	72DP40	ICC7
THOMSON	72DP50	ICC7
THOMSON	72DP51	ICC5 CMOS
THOMSON	72DP81TX	ICC7
THOMSON	72DR47	ICC8
THOMSON	72DR49	ICC9
THOMSON	72DR50 NIC	ICC8
THOMSON	72DR58	ICC8
THOMSON	72DR59	ICC9
THOMSON	72DR60	ICC9
THOMSON	72MK88L	ICC10

Brand	model	chassis
THOMSON	72MK89D	ICC11
THOMSON	72MK89DU	ICC11
THOMSON	72MP42	ICC9
THOMSON	72MP49	ICC9
THOMSON	72MP50	ICC8
THOMSON	72MP51	ICC5 CMOS
THOMSON	72MP58	ICC8
THOMSON	72MP81	ICC7
THOMSON	72MT60TX	ICC94G
THOMSON	72MT68L	ICC9
THOMSON	81201RI	ICC17
THOMSON	81220S	ICC17
THOMSON	81DXC69DLU	ICC9
THOMSON	81DXC89DY	ICC11
THOMSON	81MX68N	ICC9
THOMSON	85170RI	TX807CS
THOMSON	85210S	ICC17
THOMSON	85210SI	ICC17
THOMSON	85MX69L	ICC9
THOMSON	94MX68N	ICC9
THOMSON	AQUA 14GP	TX807
THOMSON	AQUA14G	TX807
THOMSON	AQUA14G2	TX807C
THOMSON	AQUA14G3	TX807C
THOMSON	AQUA14GP	TX807
THOMSON	AQUA14GU	TX807
THOMSON	AQUA14W	TX807
THOMSON	AQUA14W2	TX807C
THOMSON	AQUA14W3	TX807C
THOMSON	AQUA14WP	TX807
THOMSON	AQUA14WU	TX807
THOMSON	AQUA14Y	TX807
THOMSON	AQUA14YP	TX807
THOMSON	AQUA14YU	TX807
THOMSON	B14C	TX90

Brand	model	chassis
THOMSON	B14R	TX80
THOMSON	B39F	TX90
THOMSON	B49F	TX90
THOMSON	BLUE1	TX807
THOMSON	BLUE2	TX807C
THOMSON	BLUE3	TX807C
THOMSON	DF316ET2	ICC17
THOMSON	DF321E	ICC17
THOMSON	DF322E	ICC17
THOMSON	DF325E	ICC17
THOMSON	DF416ET2	ICC17
THOMSON	DF421E	ICC17
THOMSON	DF422E	ICC17
THOMSON	DF425E	ICC17
THOMSON	DF426E	ICC17
THOMSON	DF428ES	TX807CS
THOMSON	DF454E	ICC19
THOMSON	DF458ES	ICC20 (100Hz)
THOMSON	DF540ME	ICC19
THOMSON	DF540ME2	ICC19
THOMSON	DF540ME3	ICC19
THOMSON	DG2560H	TX92
THOMSON	DG2566H	TX92F
THOMSON	DG2855H	TX92F
THOMSON	DG2866H	TX92F
THOMSON	DG2874DT	TX92F (?)
THOMSON	DH540ME	ICC19
THOMSON	DH540ME2	ICC19
THOMSON	DH540ME3	ICC19
THOMSON	DIGITAL	EUTVD2001
THOMSON	DIGITAL2	EUTVD2001
THOMSON	DS2170H	TX92
THOMSON	DS2176H	TX92F
THOMSON	DS2560H	TX92F
THOMSON	DS2565H	TX92F

Brand	model	chassis
THOMSON	DS2566H	TX92F
THOMSON	DS2865H	TX92F
THOMSON	DS2866H	TX92F
THOMSON	DS521EF	ICC17
THOMSON	DS522EF	ICC17
THOMSON	DS522G	ICC17
THOMSON	DS540M	ICC19
THOMSON	DS540V	ICC19
THOMSON	DS540VS1	ICC20 (100Hz)
THOMSON	DS560E2	ICC19
THOMSON	DS574ES	ICC19
THOMSON	F2180RI	AK30
THOMSON	GARDEN	TX807C
THOMSON	GD2580D	TX92
THOMSON	GD2880D	TX92
THOMSON	HALOP	TX807C
THOMSON	HALOW	TX807C
THOMSON	HTM14017	TX91G
THOMSON	HTM14117	TX807C
THOMSON	HTM14117B	TX807C
THOMSON	HTM17017	TX91G
THOMSON	HTM20117	TX807C
THOMSON	HTM21017	TX91
THOMSON	HTM21117	TX807C
THOMSON	M25FF	B3/B10
THOMSON	M3610C	TX807
THOMSON	M3610F	TX807
THOMSON	M3610G	TX807
THOMSON	M3611E	TX807C
THOMSON	M36120R	TX807C
THOMSON	M36120RS	TX807C
THOMSON	M36121R	TX807C
THOMSON	M36121RS	TX807C
THOMSON	M36130RH	TX807C
THOMSON	M36130RI	TX807C

Brand	model	chassis
THOMSON	M36131RI	TX807C
THOMSON	M3615CG	TX807
THOMSON	M3670GC	TX91G
THOMSON	M3670GCT	TX91G
THOMSON	M3676GC	TX91G
THOMSON	M5110C	TX807
THOMSON	M5110F	TX807
THOMSON	M5110G	TX807
THOMSON	M51130R	TX807C
THOMSON	M51130RI	TX807C
THOMSON	M51131R	TX807C
THOMSON	M51131RH	TX807C
THOMSON	M5115CG	TX807
THOMSON	M5115FT	TX807
THOMSON	M5115GT	TX807
THOMSON	M5115GTI	TX807
THOMSON	M5115UT1	TX807C
THOMSON	M5140RI	AK30
THOMSON	M5176HC	TX91G
THOMSON	M5176SF	TX91G
THOMSON	M5510F	TX807
THOMSON	M5515GT	TX807
THOMSON	M5516ET	TX807C
THOMSON	M5516UT	TX807C
THOMSON	M55170R	TX807CS
THOMSON	M55170RH	TX807CS
THOMSON	M55170RI	TX807CS
THOMSON	M55171R	TX807CS
THOMSON	M55171RH	TX807CS
THOMSON	M55171RI	TX807CS
THOMSON	M55171RS	TX807CS
THOMSON	M55175T	ETC009
THOMSON	M5517U1	TX807CS
THOMSON	M5518C	ICC17
THOMSON	M5570GCT	TX91G

Brand	model	chassis
THOMSON	M5570GF	TX91G
THOMSON	M5576GF	TX91G
THOMSON	M63170RI	TX807CS
THOMSON	M63171R	TX807CS
THOMSON	M63171RI	TX807CS
THOMSON	M6317U	TX807CS
THOMSON	M6322E	ICC17
THOMSON	M6322U	ICC17
THOMSON	M7017U	TX807CS
THOMSON	M7022E	ICC17
THOMSON	M85170RI	TX807CS
THOMSON	M85200S	ICC17
THOMSON	M8521E	ICC17
THOMSON	M8522E	ICC17
THOMSON	MA115CG	TX807
THOMSON	MA116ES	TX807C
THOMSON	MA211C	TX807
THOMSON	MA216CG	TX807
THOMSON	MF210C	TX807
THOMSON	MF215CG	TX807
THOMSON	MF216ET	TX807C
THOMSON	MF622E	ICC17
THOMSON	MF744E	ICC19
THOMSON	MG1470CT	TX91G
THOMSON	MG1476C	TX91G
THOMSON	MG1480AT	TX807
THOMSON	MS2170CT	TX91G
THOMSON	NATURE1	TX807
THOMSON	NATURE2	TX807
THOMSON	NATURE3	TX807
THOMSON	ORANGE1	TX807
THOMSON	ORANGE2	TX807C
THOMSON	ORANGE3	TX807C
THOMSON	PALCOLOR S4400DM	ICC11
THOMSON	PALCOLOR S5400DM	ICC11

Brand	model	chassis
THOMSON	PALCOLOR S5400DMD	ICC10
THOMSON	PALCOLOR S590 NIC	ICC10
THOMSON	Prestige 2000	ICC8
THOMSON	PRESTIGE 63KH	ICC10
THOMSON	PRESTIGE 72KH	ICC10
THOMSON	RP46N	ICC9
THOMSON	RP46TH	ICC9
THOMSON	RP52TH	ICC9
THOMSON	RP844E	ICC19
THOMSON	S2010	TX807
THOMSON	S2011	TX807C
THOMSON	S2014	TX807
THOMSON	S2014B	TX807
THOMSON	S2014BC	TX807
THOMSON	S2014BU	TX807
THOMSON	S2014C	TX807
THOMSON	S2014G	TX807
THOMSON	S2014GC	TX807
THOMSON	S2014U	TX807
THOMSON	S2021	ICC17
THOMSON	S2021G	ICC17
THOMSON	S2029	ICC19 (100Hz)
THOMSON	S7022E	ICC17
THOMSON	S70400RI	ICC20 (100Hz)
THOMSON	S70410RI	ICC20 (100Hz)
THOMSON	S7044C	ICC20 (100Hz)
THOMSON	SD36ML00	TX805
THOMSON	SMOOTH	TX807C
THOMSON	SMOOTH2	TX807C
THOMSON	SPACESYSTEMSL70D	ICC11
THOMSON	SPECTRASC63TH	ICC10
THOMSON	STYLE	TX807C
THOMSON	STYLE2	TX807C
THOMSON	SUGAR	TX807C
THOMSON	SUGAR2	TX807C

Brand	model	chassis
THOMSON	SW2028	ICC19
THOMSON	SW2032	ICC19
THOMSON	T4207PI4	ICC4104M (90°)
THOMSON	T5106PI4	ICC4104M (90°)
THOMSON	T5150PI4	ICC4104M (90°)
THOMSON	T5560RI	AK30
THOMSON	T5570SF	TX91G
THOMSON	T59NB	TX92
THOMSON	T63K30	ICC9
THOMSON	T68NB	TX92
THOMSON	T70170RI	TX807CS
THOMSON	T70171R	TX807CS
THOMSON	T70171RI	TX807CS
THOMSON	T70172RI	ITC008
THOMSON	T70173RI	ITC008
THOMSON	T7017E	TX807CS
THOMSON	T7017ES	TX807CS
THOMSON	T7017U	TX807CS
THOMSON	T7021E	ICC17
THOMSON	T7022E	ICC17
THOMSON	T78N	TX92
THOMSON	TF5557	IKC2
THOMSON	TF5570	ICC5
THOMSON	TF5571	IKC2
THOMSON	TF5573	IKC2
THOMSON	TF6353	IKC2
THOMSON	TF6353PSK	ICC5 NMOS
THOMSON	TF6357	IKC2
THOMSON	TF6450PSN	ICC5
THOMSON	TF6456PSN/NIC	ICC5 (?)
THOMSON	TF7253	IKC2
THOMSON	TF7254	ICC5
THOMSON	TF7257	IKC2
THOMSON	TF7350ESN	ICC5
THOMSON	TF7352PSN	ICC5

Brand	model	chassis
THOMSON	TF7354	ICC5
THOMSON	TF7356PSN	ICC5
THOMSON	TREK	TX807C
THOMSON	TROPHY	TX807C
THOMSON	TS3654	ICC4
THOMSON	TS5116	IKC1 (?)
THOMSON	TS5125	IKC2
THOMSON	TS5171	IKC2
THOMSON	TS5575	IKC2
THOMSON	TV25ST	ICC17
THOMSON	TV28ST	ICC17
THOMSON	TVP100L	VP2001
THOMSON	TVP500D	VP2001
THOMSON	URBAN	TX807C
THOMSON	V51N	TX91
THOMSON	V51NB	TX91G
THOMSON	VS644E	ICC19
THOMSON	W70200RI	ICC17
THOMSON	W70201RI	ICC17
THOMSON	W70201S	ICC17
THOMSON	W7021E	ICC17
THOMSON	W7022S	ICC17
THOMSON	W81200RI	ICC17
THOMSON	W81201RI	ICC17
THOMSON	W81201S	ICC17
THOMSON	W8122S	ICC17
THOMSON	W8123U	ICC17
THOMSON	WF70401G	ICC20 (100Hz)
THOMSON	WS3268N	ICC11
THOMSON	WS460E2	ICC19
THOMSON	X51F	TX91
THOMSON	X51FB	TX91G
THOMSON	XINOX	TX807C
THOMSON	XINOX2	TX807C
THOMSON	XINOXTV	TX807C

Brand	model	chassis
THOMSON	ZEO	TX807C
TOKAI	LTV3620	11AK03
TOKAI	LTV4020PS	11AK03
TOKAI	LTV5120	11AK03
TOKAI	LTV5520	11AK03
TOPLINE	2163	TV3KF
TOPLINE	5159	11AK10
TOPLINE	5559	11AK10
TOPLINE	CT2500	11AK10
TOPLINE	CT2501	11AK10
TOPLINE	CT2551	11AK10
TOPLINE	CT2590ST	11AK10
TOPLINE	CT3050	11AK10
TOPLINE	CT3100ST	11AK10
TOPLINE	CT3200ST	11AK10
TOPLINE	CT3250ST	11AK10
TOPLINE	CT510	11AK10
TOPLINE	CTV4809	11AK19
TOPLINE	CTV5100	11AK10
TOPLINE	CTV5110	11AK10
TOPLINE	CTV5125	11AK10
TOPLINE	CTV5525	11AK10
TOPLINE	ST5196VT	11AK10
TOSHIBA	1022DAV	U10
TOSHIBA	1450TB	C4E-R
TOSHIBA	1450XSH	S5E
TOSHIBA	1457EXL	S5E
TOSHIBA	1458XNE	S5E
TOSHIBA	1460XSH	S6E
TOSHIBA	1468BAV	U10
TOSHIBA	1478BAV	U10
TOSHIBA	1478XR	S7E
TOSHIBA	1480TB	C80
TOSHIBA	1483BAV	U10
TOSHIBA	14A3E	S1E

Brand	model	chassis
TOSHIBA	14A3H	S1E
TOSHIBA	14A3M	S1E
TOSHIBA	14A3MJ	S1E
TOSHIBA	14A3R	S1E
TOSHIBA	14AR21	MSA
TOSHIBA	14CS2R	S3E
TOSHIBA	14N1XE	S9E
TOSHIBA	14N1XT	S9E
TOSHIBA	14N21B2	TMC571A
TOSHIBA	14N31	TMC571A
TOSHIBA	14N31B	TMC571A
TOSHIBA	14N31DY	TMC571A
TOSHIBA	14N31F	TMC571A
TOSHIBA	14N5XM	MCL437F
TOSHIBA	14R01	KS1A
TOSHIBA	14S3	S3E
TOSHIBA	14T01	KS1A
TOSHIBA	14V2T	S2E
TOSHIBA	1752TB	C4E-R
TOSHIBA	184T3EN	TLC134
TOSHIBA	19A10	N0ES (TAC007)
TOSHIBA	19A20	N0E (TAC0001)
TOSHIBA	19A24	M3M28
TOSHIBA	19A30	N0ES (TAC005)
TOSHIBA	2035XMJ	MCL437F
TOSHIBA	2050XS	S5E
TOSHIBA	2068BAV	U10
TOSHIBA	2068BS	U10
TOSHIBA	2078(F)M	U10
TOSHIBA	2078BAV	U10
TOSHIBA	2079BS	U10
TOSHIBA	2083BAV	U10
TOSHIBA	20A3E	S1E
TOSHIBA	20AR20	SN70A
TOSHIBA	20AR30	SN70A

Brand	model	chassis
TOSHIBA	20AS22	TMB535A
TOSHIBA	20C3T	S5E
TOSHIBA	20E97M	U17 (?)
TOSHIBA	20V2T	S2E
TOSHIBA	2132DB	C3SR
TOSHIBA	2140TS	C4E
TOSHIBA	2150RE	S5E
TOSHIBA	2150TD	(PB5859-1)
TOSHIBA	2150TS	CCP3400 ?
TOSHIBA	2150XS	S5E
TOSHIBA	2151DB	C5S
TOSHIBA	2151RB	C4E-R
TOSHIBA	2151TB	C4E-R
TOSHIBA	2152RB	C4E-R
TOSHIBA	215R8W	(PB0882)
TOSHIBA	2162TR	C4E-R
TOSHIBA	2163DB	C6S
TOSHIBA	2163DD	C6S
TOSHIBA	2165XR	S6E
TOSHIBA	2170RE	S7E
TOSHIBA	2173DB	C7S (C7SR ?)
TOSHIBA	2175BS	U10
TOSHIBA	2178XR	S7E
TOSHIBA	2180TD	C80
TOSHIBA	2181TB	C80
TOSHIBA	218D7S1	S5E (?)
TOSHIBA	219R6F	AP08K
TOSHIBA	21A3E	S1E
TOSHIBA	21BM91	CN18EA
TOSHIBA	21CS2R	S3E
TOSHIBA	21CS2TR	S3E
TOSHIBA	21CS3R	PD1561
TOSHIBA	21CSZ5TR	S3ES
TOSHIBA	21CSZ7DR	S3ES
TOSHIBA	21CV1R	CN18EA

Brand	model	chassis
TOSHIBA	21CVZ7DR	MCL437F
TOSHIBA	21CZ5T	S5E
TOSHIBA	21D3TXE	S0E
TOSHIBA	21D3XRT	S0E (MCL437F)
TOSHIBA	21D7	S0ES
TOSHIBA	21D7DXE	S0ES
TOSHIBA	21D7XRT	MCL437F
TOSHIBA	21G3XHE	S8E
TOSHIBA	21G3XR	S8E
TOSHIBA	21G5DE	S8S
TOSHIBA	21G5SXH	S8S
TOSHIBA	21G5XRT	S8S
TOSHIBA	21N21D2	TMC572 (?)
TOSHIBA	21N3XM	MCL437F
TOSHIBA	21N3XMJ	MCL437F
TOSHIBA	21N5XM	F7S
TOSHIBA	21R01	KS1A
TOSHIBA	21S1E	S3E
TOSHIBA	21S1ES	S3E
TOSHIBA	21S1H	S3E
TOSHIBA	21S2M	S3E
TOSHIBA	21S2MJ	S3E
TOSHIBA	21S2MQ	S3E
TOSHIBA	21S3	S3E
TOSHIBA	21SZ2	S3ES
TOSHIBA	21SZ2E	S3ES
TOSHIBA	21SZ2ES	S3ES
TOSHIBA	21SZ2M	S3ES
TOSHIBA	21SZ2M	S3ES
TOSHIBA	21SZ2MJ	S3ES
TOSHIBA	21SZ2T	S3ES
TOSHIBA	21SZ3E	S3ES
TOSHIBA	21SZ3ES	S3ES
TOSHIBA	21SZ3M	S3ES
TOSHIBA	21SZ3T	S3ES

Brand	model	chassis
TOSHIBA	21SZ5M	S3ES
TOSHIBA	21SZ5TM	S3ES
TOSHIBA	21SZ5VX	S3ES
TOSHIBA	21SZ7DE	S3ES
TOSHIBA	21SZ7SH	S3ES
TOSHIBA	21SZ7ST	S3ES
TOSHIBA	21SZ7VX	S3ES
TOSHIBA	21T01D	KS1A
TOSHIBA	21V1E	S2E
TOSHIBA	21V1M	S2E
TOSHIBA	21V1R	S2E
TOSHIBA	21V27DE	MCL437F (?)
TOSHIBA	21V2T	S2E
TOSHIBA	21V33D2	TMC572C
TOSHIBA	21V53G	11AK30
TOSHIBA	21VZ2	S2ES
TOSHIBA	21VZ3	S2ES
TOSHIBA	21VZ3E	S2ES
TOSHIBA	21VZ3M	S2ES
TOSHIBA	21VZ3MJ	S2ES
TOSHIBA	21VZ3T	S2ES
TOSHIBA	21VZ5	S2ES
TOSHIBA	21VZ5E	S2ES
TOSHIBA	21VZ5T	S2ES
TOSHIBA	21VZ5T	S2ES
TOSHIBA	21VZ7	S0ES
TOSHIBA	21VZ7ST	S0ES
TOSHIBA	24W33B	11AK37
TOSHIBA	2512DDT	(PB1948)
TOSHIBA	2529TL	F2SB ?
TOSHIBA	2535DB	C3SS
TOSHIBA	2539DB	C2DB
TOSHIBA	2545DD	C3SSR
TOSHIBA	2550TB	C4E-R
TOSHIBA	2563DB	C6SR

Brand	model	chassis
TOSHIBA	2573DB	C7SR
TOSHIBA	2573DD	C7SR
TOSHIBA	258S7G	TLC134
TOSHIBA	25AF6C	D1ES
TOSHIBA	25AF6SH	D1ES
TOSHIBA	25CSZ5TR	S3ES
TOSHIBA	25D2XC	D0ES
TOSHIBA	25D6XC	D0ES
TOSHIBA	25SZ5ST	S3ES
TOSHIBA	25SZ5VX	S3ES
TOSHIBA	27A32	M3L571 ?
TOSHIBA	27A41C	M3K171
TOSHIBA	27A60	N0S (TAC0020)
TOSHIBA	27AF41	N1N (TAC0116)
TOSHIBA	27AF42	(TAC202)
TOSHIBA	27AF61	N1N (TAC0115)
TOSHIBA	2805DBT	C90D (?)
TOSHIBA	2829TL	F2SB ?
TOSHIBA	2857DB	C5SS
TOSHIBA	2857DD	C5SS
TOSHIBA	2863DB	C6SR
TOSHIBA	2863DD	C6SR ?
TOSHIBA	2863DR	C6SR
TOSHIBA	2866DF	C6SS
TOSHIBA	2870DD	C6SS
TOSHIBA	2873DB	C7SR
TOSHIBA	2873DD	C7SR (PB7319, PB7320)
TOSHIBA	2876DD	C7SS
TOSHIBA	2877DB	C7SS
TOSHIBA	2878DG	C7SS
TOSHIBA	2896DD	C7SS (100Hz)
TOSHIBA	289R6F	AP08K
TOSHIBA	28H14D	CUC1837 (DIGI100)
TOSHIBA	28H14G	CUC1837 (DIGI100)
TOSHIBA	28MW7DB	C7SS

Brand	model	chassis
TOSHIBA	28N13D	11AK19Y11
TOSHIBA	28N14D	CUC2130M
TOSHIBA	28N14G	CUC2130M
TOSHIBA	28N33B	11AK37 ?
TOSHIBA	28N33D	11AK37
TOSHIBA	28W7DD	C7SS
TOSHIBA	28W8DB	C8SS
TOSHIBA	28WD8	C8SS
TOSHIBA	28YT56	11AK49
TOSHIBA	28YT56B	11AK49
TOSHIBA	28Z13B	Z13B
TOSHIBA	28Z13G	Z13B
TOSHIBA	28Z23B	Z23B
TOSHIBA	28Z23G	Z23B
TOSHIBA	28Z27B	Z23G ?
TOSHIBA	28ZD06B	C00S
TOSHIBA	28ZD26P	ZD26
TOSHIBA	2927DB	C2D
TOSHIBA	2987DB	C8SS
TOSHIBA	2988DG	C8SS
TOSHIBA	2998DG	C8SS
TOSHIBA	29A3DE	S1ES
TOSHIBA	29AX9UM	F1DS
TOSHIBA	29AZ5DE	S9ES
TOSHIBA	29AZ5TR	S9ES
TOSHIBA	29AZ5TR	S9ES
TOSHIBA	29AZ8UR	S1DS
TOSHIBA	29CJZ5SR	S3ES
TOSHIBA	29CZ5DE	S5ES
TOSHIBA	29CZ5T	S5ES
TOSHIBA	29CZ5T	S5ES
TOSHIBA	29CZ6SI	S5ES
TOSHIBA	29CZ8URB	S5SS
TOSHIBA	29CZ8URS	S5SS
TOSHIBA	29CZ8UT	S5SS

Brand	model	chassis
TOSHIBA	29CZ9UE	S5SS
TOSHIBA	29CZ9UES	S5SS
TOSHIBA	29D2XC	D0ES
TOSHIBA	29D3DXE	S9ES
TOSHIBA	29D7DXE	S0E
TOSHIBA	29G3SHC	S8ES
TOSHIBA	29G3XE	S8ES
TOSHIBA	29G5DE	S8ES
TOSHIBA	29G5XE	S8ES
TOSHIBA	29G6UX3	D8SS
TOSHIBA	29G9UXC	F7SS
TOSHIBA	29JF8UC	D4SS
TOSHIBA	29JX5SH	S3ES
TOSHIBA	29JZ5DA	S3ES
TOSHIBA	29JZ5DE	S3ES
TOSHIBA	29JZ5DM	S3ES
TOSHIBA	29JZ5DMJ	S3ES
TOSHIBA	29JZ5DMQ	S3ES
TOSHIBA	29JZ5MQ	S3ES
TOSHIBA	29JZST	S3ES
TOSHIBA	29N23G	11AK37
TOSHIBA	29N3SXH	S9ES
TOSHIBA	29N5DRT	S9E
TOSHIBA	29N5DXE	S9ES
TOSHIBA	29N5DXH	S9E
TOSHIBA	29N9UE	F9DS
TOSHIBA	29SF6C	D3ES
TOSHIBA	29SF6KC	D3ES
TOSHIBA	29SF6SC	D3ES
TOSHIBA	29SF6ZC	D3ES
TOSHIBA	29SZ5	S3ES
TOSHIBA	29SZ5DA	S3ES
TOSHIBA	29SZ5DE	S3ES
TOSHIBA	29SZ5SH	S3ES
TOSHIBA	29SZ5ST	S3ES

Brand	model	chassis
TOSHIBA	29V13P	KS2A/KS3A
TOSHIBA	29V24E1	11AK37-11
TOSHIBA	29V24E2	11AK37
TOSHIBA	29VH27E	11AK52B6
TOSHIBA	29VH37GP	11AK53 (?)
TOSHIBA	29VZ6T	S2ES
TOSHIBA	32A30	N0S (TAC0009)
TOSHIBA	32A41	N1ES (TAC0101)
TOSHIBA	32A60	N0S (TAC0021)
TOSHIBA	32A61	N1S (TAC0111)
TOSHIBA	32AF41	N1F
TOSHIBA	32AF41	N1F (TAC0116)
TOSHIBA	32AFX61	N1NS (TAC0126)
TOSHIBA	32HFX71	N1PS (TAC0132)
TOSHIBA	32HFX71	N1PS (TAC0132)
TOSHIBA	32MW7DG	C7SS
TOSHIBA	32W6DB	C6SS
TOSHIBA	32W6DG	C6SS
TOSHIBA	32W8DB	C8SS
TOSHIBA	32WD98G	C9SS
TOSHIBA	32WH37G	11AK41
TOSHIBA	32WL36P	F3LW
TOSHIBA	32YT56	11AK49
TOSHIBA	32YT56	11AK49
TOSHIBA	32Z23B	Z23B
TOSHIBA	32Z23G	Z23B
TOSHIBA	32ZD06BG	C00S
TOSHIBA	32ZD06G	C00S
TOSHIBA	32ZD08BG	C00S
TOSHIBA	32ZD08G	C00S
TOSHIBA	32ZD26P	ZD26
TOSHIBA	32ZD36P	ZD36
TOSHIBA	32ZD98B	C9SS
TOSHIBA	32ZP18	C00S
TOSHIBA	32ZP38B	ZP38

Brand	model	chassis
TOSHIBA	3357DB	C5SS
TOSHIBA	3357DF	C5SS
TOSHIBA	3378DG	C7SS
TOSHIBA	3387DB	C8SS
TOSHIBA	3388DG	C8SS
TOSHIBA	33H24G	11AK41
TOSHIBA	349P9D	C4E-R ?
TOSHIBA	34AS41	N1ES (TAC0101)
TOSHIBA	34AX9UA	F1DS
TOSHIBA	34AX9UM	F1DS
TOSHIBA	34AX9UR	F1DS
TOSHIBA	34D9UXE	F0DS
TOSHIBA	34HF81	N1WS (TAC0135)
TOSHIBA	34HF81	N1WS (TAC0135)
TOSHIBA	34N9UXC	F9DS
TOSHIBA	34SZ6	S3ES
TOSHIBA	34VH9UR	F2DB
TOSHIBA	36A11	N1S (TAC0109)
TOSHIBA	36A41	N1ES (TAC0102)
TOSHIBA	36A60	N0S (TAC0022)
TOSHIBA	36A61	N1N (TAC0112)
TOSHIBA	36AF41	N1N (TAC0119)
TOSHIBA	36AF60	N0PS (TAC0033)
TOSHIBA	36AF61	N1F (TAC0120)
TOSHIBA	36AFX60	N0PS (TAC0032)
TOSHIBA	36AFX61	N1NS (TAC0125)
TOSHIBA	36AX61	N1N (TAC0113)
TOSHIBA	36HF70	N0PS
TOSHIBA	36HF71	N1PS (TAC0131)
TOSHIBA	36HF71	N1PS (TAC0131)
TOSHIBA	36HFX70	N0PS
TOSHIBA	36HFX71	N1PS (TAC0130)
TOSHIBA	36HFX71	N1PS (TAC0130)
TOSHIBA	36ZD36P	ZD36
TOSHIBA	36ZP18	C00S

Brand	model	chassis
TOSHIBA	36ZP38B	ZP38
TOSHIBA	38D9UXE	S0LCD
TOSHIBA	38VL14G	F0LP
TOSHIBA	38VL14G	F0LP
TOSHIBA	40PL93B	F9LP
TOSHIBA	40PL93G	F9LP
TOSHIBA	40PW13	C9PJ
TOSHIBA	40WH08 TEXT	C00P
TOSHIBA	40WH08B	C00P
TOSHIBA	40WH08G	C00P
TOSHIBA	42H81	N1PSP
TOSHIBA	42PW33P	C03P
TOSHIBA	42WH46P	WH4
TOSHIBA	43A10	N0NSP (TAC0054)
TOSHIBA	43A61	N1PSP
TOSHIBA	43A7DE	A7PJ (N7SS)
TOSHIBA	43A9	A9PJ
TOSHIBA	43A9UE	A9PJ (N7SS)
TOSHIBA	43AX60	N0NSP (TAC0057)
TOSHIBA	43AX60A	N0NSP (TAC0057)
TOSHIBA	43CR9UT	CR9PJ
TOSHIBA	43CVR9UR	VR9PJ
TOSHIBA	43D9UXE	S0SS
TOSHIBA	43H70	N0PSP (TAC0070)
TOSHIBA	43HX70	N0PSP (TAC0074)
TOSHIBA	43HX71	N1PSP
TOSHIBA	43PJ93B	C9SS
TOSHIBA	43V9UE	VR9PJ (?)
TOSHIBA	43VJ22	VJ13
TOSHIBA	43VJ33Q	VJ13
TOSHIBA	44G9	F8LP
TOSHIBA	44N9UXA	F9LP
TOSHIBA	44N9UXE	F9LP
TOSHIBA	44N9UXH	F9LP
TOSHIBA	44N9UXM	F9LP

Brand	model	chassis
TOSHIBA	44PL93G	F9LP
TOSHIBA	48PJ5UE	F5SS ?
TOSHIBA	48PJ6DG	C5SS
TOSHIBA	50A11	N1NSP
TOSHIBA	50A50	(TAC0051)
TOSHIBA	50A50	N0NSP (TAC0051)
TOSHIBA	50A60	N0NSP (TAC0050)
TOSHIBA	50A61	N1NSP
TOSHIBA	50A9	A9PJ
TOSHIBA	50A9UE	A9PJ
TOSHIBA	50CVR9UR	VR9PJ
TOSHIBA	50H71	N1PSP (TAC0162)
TOSHIBA	50H81	N1PSP (TAC0151)
TOSHIBA	50HX70	N0PSP (TAC0067)
TOSHIBA	50N9UXA	S9SS
TOSHIBA	50PJ98B	C9SS
TOSHIBA	50PJ98G	C9SS ?
TOSHIBA	50V9UE	V9PJ
TOSHIBA	50V9UM	V9PJ
TOSHIBA	50VH9UA	V9PJ
TOSHIBA	50VJ33Q	VJ13
TOSHIBA	50WT29B	C01P (?)
TOSHIBA	51H83	N3PSP (TAC0352)
TOSHIBA	51WH46P	WH4
TOSHIBA	53H71	N1PSP
TOSHIBA	55A60	N0NSP (TAC0052)
TOSHIBA	55H70	N0PSP (TAC0069)
TOSHIBA	55HX70	N0PSP (TAC0066)
TOSHIBA	55M21D	TMC572 (?)
TOSHIBA	55PJ6DG	C5SS
TOSHIBA	55T23D	TMC572B
TOSHIBA	57H83	N3PSP (TAC0351)
TOSHIBA	61A60	N0NSP (TAC0053)
TOSHIBA	61A61	N1NSP
TOSHIBA	61A9	A9PJ

Brand	model	chassis
TOSHIBA	61A9UE	A9PJ
TOSHIBA	61H70	N0PSP (TAC0068)
TOSHIBA	61HX70	N0PSP (TAC0065)
TOSHIBA	62HM84	(TAC490 czy? TAC0490)
TOSHIBA	65H83	N3PSP (TAC0353)
TOSHIBA	65HDX82	N2PSP (TAC0270)
TOSHIBA	7063DD	C6SR (?)
TOSHIBA	7073DD	C7SR
TOSHIBA	7086DD	C7SS ?
TOSHIBA	70H14D	CUC1837 (DIGI100)
TOSHIBA	82MW8S	C7SS (100Hz) - ?
TOSHIBA	C21TF330A	V3AR
TOSHIBA	CB21T01D2GXTSB	KS1A
TOSHIBA	CF1311J	(TAC8930)
TOSHIBA	CF1313A	X90E
TOSHIBA	CF1910K	(TAC8923)
TOSHIBA	CF1921J	(TAC8920) ?
TOSHIBA	CF19F22	(TAC9610)
TOSHIBA	CF19F30	N5ES (TAC9623)
TOSHIBA	CF19F32	N5ES (TAC9625)
TOSHIBA	CF19G32	(TAC9725)
TOSHIBA	CF2033J	(TAC8901)
TOSHIBA	CF2036	(TAC8630)
TOSHIBA	CF20363	(TAC9118)
TOSHIBA	CF2044	(TAC8900)
TOSHIBA	CF2052A	X90E
TOSHIBA	CF2055A	(TAC9141)
TOSHIBA	CF2055J	X90E
TOSHIBA	CF2077A	X90E
TOSHIBA	CF2655J	X90E
TOSHIBA	CF2655R	X90E
TOSHIBA	CF2665K	X90E
TOSHIBA	CF2666A	X90E
TOSHIBA	CF2666R	X90E
TOSHIBA	CF26C30	(TAC9360)

Brand	model	chassis
TOSHIBA	CF2750K	(TAC9011)
TOSHIBA	CF2761A	X90E
TOSHIBA	CF2762B	X90E
TOSHIBA	CF2765	(TAC9010)
TOSHIBA	CF2765K	X90E
TOSHIBA	CF2767A	X90E
TOSHIBA	CF2768B	X90E
TOSHIBA	CF2770K	X90E
TOSHIBA	CF2772B	X90E
TOSHIBA	CF27C30	(TAC9350)
TOSHIBA	CF27F30	(TAC9620)
TOSHIBA	CF3062A	X90E
TOSHIBA	CF3063K	X90E
TOSHIBA	CF3064K	X90E
TOSHIBA	CF3066A	X90E
TOSHIBA	CF3072B	(TAC9231)
TOSHIBA	CF3262B	X90E
TOSHIBA	CF3264K	X90E
TOSHIBA	CF3266A	X90E
TOSHIBA	CF3268K	X90E
TOSHIBA	CF3273A	X90E
TOSHIBA	CF3275K	X90E
TOSHIBA	CF3275K	X90E
TOSHIBA	CF3278K	X90E
TOSHIBA	CF3279K	X90E
TOSHIBA	CF3298K	X90E
TOSHIBA	CF3566A	X90E
TOSHIBA	CF35E50	N5SS
TOSHIBA	CL20R31	(TAC9936)
TOSHIBA	CL20T31	(TAC9906)
TOSHIBA	CL21F40	(TAC9617)
TOSHIBA	CL29G30	(TAC9620)
TOSHIBA	CL29V51	(TAC9911)
TOSHIBA	CN27E90	N5SS
TOSHIBA	CN32E90	N5SS

Brand	model	chassis
TOSHIBA	CN35E15	N5SS
TOSHIBA	CN35E90	N5SS
TOSHIBA	CN35E95	N5SS
TOSHIBA	CT19G32	(TAC9725)
TOSHIBA	CX2088K	X90E
TOSHIBA	CX2657J	X90E
TOSHIBA	CX2767J	X90E
TOSHIBA	CX2769J	X90E
TOSHIBA	CX2779K	X90E
TOSHIBA	CX2780A	X90E
TOSHIBA	CX2786A	X90E
TOSHIBA	CX2789K	X90E
TOSHIBA	CX29801	X90E
TOSHIBA	CX29862	X90E
TOSHIBA	CX3285A	X90E
TOSHIBA	CX3286A	X90E
TOSHIBA	CX3298K	X90E
TOSHIBA	CX32E60	(TAC9530)
TOSHIBA	CX32E70	N5SS
TOSHIBA	CX3583A	X90E
TOSHIBA	CX3586A	X90E
TOSHIBA	CX35E60	N5SS
TOSHIBA	CX35E70	N5SS
TOSHIBA	CX35E81	N5SS
TOSHIBA	CZ19M21	(TAC9900)
TOSHIBA	TE50T11	(TAC9955)
TOSHIBA	TN50X81	(TAC9960)
TOSHIBA	TP4880A	X90E
TOSHIBA	TP4881A	X90E
TOSHIBA	TP50G60	(TAC9750)
TOSHIBA	TP5580A	X90E
TOSHIBA	TP5581A	X90E
TOSHIBA	TP55902	(TAC9181)
TOSHIBA	TP55F81	(TAC9678)
TOSHIBA	TV32C50	(TAC9307)

Brand	model	chassis
TOSHIBA	TW40F80	N5SS
TOSHIBA	VTV1400	(VMA240A)
TOTANIC	20LX600	PTXM01
TOTANIC	CTV3700M	PTXM01
TOTANIC	CTV5000	PTXM01
TOTANIC	CTV500SX	PTXM01
TOTANIC	CTV5300SX	PTXM01
TOTANIC	CTV5301KEC	PTXM01
TransContinental	TR3612si	CTR-AB
Transcontinents	32HFBTR16932	8500 PROFESSIONAL (PCB8500)
Transcontinents	32HFBTR16932	8500 PROFESSIONAL (PCB8500) (Sinudyne Orion)
Transcontinents	TR2121LTXT	CTU-AB
TRANSONIC	GTH3766	P37-13
TRILUX	TAP140V	11AK20M3
TRILUX	TAP140VT	11AK20
TRILUX	TAP274?	PB410
TRILUX	TAP200VT	11AK19
TRILUX	TAP2106	PB212
TRILUX	TAP2107T	CP375
TRILUX	TAP2108TN	CP380(A)
TRILUX	TAP2131	PB310
TRILUX	TAP2134	PB310
TRILUX	TAP2145	PB4101
TRILUX	TAP2531	PB310
TRILUX	TAP2534	PB310
TRILUX	TAP2536	PB310
TRILUX	TAP2831	PB310
TRILUX	TAP2834	PB310
TRILUX	TAP2836	PB310
UHER	CTU2890	C9001
UHER	N70TXS	10.3
UHER	UC267	TV1
ULTRAVOX	CTV-S7096	990
ULTRAVOX	CTV556VT	TESI4
ULTRAVOX	CTVM371VT	TESI4

Brand	model	chassis
ULTRAVOX	S550VT	TESI4
ULTRAVOX	S556VT	TESI4
UNIMOR	M448TS	SIESTA2 (a fakt.: ch. 10.3 - BEKO)
UNIMOR	M449TS	SIESTA3
UNIMOR	M459TS	SIESTA3
UNIMOR	M459TSO	SIESTA3
UNIMOR	M646TSO	SIESTA3
UNIMOR	M651TSO	SIESTA3
UNIMOR	M652TSO	SIESTA3(A)
UNIMOR	M845TS	SIESTA2
UNIMOR	M846TSO	SIESTA3
UNIMOR	M851TSO	SIESTA3(A)
UNIMOR	M852TSO	SIESTA3
UNITED	NR UTV20X42	E1
United	UTV1028XNS	14.1 ?
UNITED	UTV14X42	12.6 (?)
UNITED	UTV14X61	11AK36
UNITED	UTV2028H	20.2 (100Hz) (BEKO)
UNITED	UTV20X30	12.7 ?
UNITED	UTV20X43	TV2K (40F-TV2K00-0M0)
UNITED	UTV3028H	20.2 (100Hz) (BEKO)
UNITED	UTV4028H	20.2 (BEKO)
UNITED	UTV4028XAS	14.5 (ZX8.190-11)
UNITED	UTV4028XAS	14.5 (ZX8.190-11)
UNITED	UTV4028XASA	C7 (czy? 14.5) (Beko ZX8.190-09)
UNITED	UTV4028XASH	20.2 (100Hz) (BEKO)
UNITED	UTV4028XNS	14.2 (U99.190-08)
UNITED	UTV8028	11.1 ?
UNITED	WTV1028B	14.1 (BEKO 7SZ.190-12)
UNITED	WTV1028BNS	14.1 (BEKO)
UNITED	WTV3032XAS	20.2 (BEKO)
UNITED	WTV3032XASH	20.2 (100Hz) (BEKO)
UNITED	WTV3032XASHP	20.2 (100Hz) (BEKO)
UNIVERSUM		11AK12-19
UNIVERSUM		E9 (S9 P/B STP KD Sz FS110PH1Q)

Brand	model	chassis
UNIVERSUM	0114041	5000
UNIVERSUM	1062231	11AK20
UNIVERSUM	1063726	11AK20
UNIVERSUM	1063833	11AK20
UNIVERSUM	1063841	11AK20
UNIVERSUM	1063916	11AK20
UNIVERSUM	1413621	11AK16
Universum	CTV7027	F991
UNIVERSUM	FK-LCD8153	17MB08P (Vestel)
UNIVERSUM	FK1008	CTV1501 (PB1501VS-M)
UNIVERSUM	FK1009	(PB1401PAV1)
UNIVERSUM	FK1050VT	(PB-MAIN1405V8)
UNIVERSUM	FK211	CUC220
UNIVERSUM	FK226	CUC50
UNIVERSUM	FK4356	(110-375A) (LG)
UNIVERSUM	FK4356	(110-375B) (LG)
UNIVERSUM	FK4356	PC04X
UNIVERSUM	FK4357	(110-375C) (LG)
UNIVERSUM	FK4366	(110-375? SECAM6082) (LG)
UNIVERSUM	FK4366	(110-395H) (LG)
UNIVERSUM	FK4375	PC04X (110-804C) (LG)
UNIVERSUM	FK5930	PC010 (czy? PC020)
UNIVERSUM	FK5937	PC010
UNIVERSUM	FK5937	PC010 (SELECO)
UNIVERSUM	FK5938	PC020 SELECO
UNIVERSUM	FK5940	PC010
UNIVERSUM	FK5940	PC010 (SELECO)
UNIVERSUM	FK707	GR1AX
UNIVERSUM	FK7136	BG/P NN SC (NOKIA)
UNIVERSUM	FK81011	20SE0211X121123 (VESTEL)
UNIVERSUM	FK81011	20SE0211X121143 (VESTEL)
UNIVERSUM	FK8105	11AK03
UNIVERSUM	FK8105	11AK03
UNIVERSUM	FK8106	11AK03
UNIVERSUM	FK8120	11AK36

Brand	model	chassis
UNIVERSUM	FK8120	11AK36-1
UNIVERSUM	FK8125	11AK03
UNIVERSUM	FK8126VT	11AK03
UNIVERSUM	FK8150 (CTV95016)	11AK08
UNIVERSUM	FK8150T	11AK12
UNIVERSUM	FK8165	11AK18
UNIVERSUM	FK8170	11AK16-2
UNIVERSUM	FK8170T	11AK08
UNIVERSUM	FK8171T	11AK08-13
UNIVERSUM	FK8185	11AK20
UNIVERSUM	FK8185	11AK20
UNIVERSUM	FK8186T	EC4A (2095)
UNIVERSUM	FK8186T	EC4A (2095)
UNIVERSUM	FK8190	11AK20M6
UNIVERSUM	FK8191	11AK19
UNIVERSUM	FKDVD8125	11AK46
UNIVERSUM	FT 8151A	11AK10 ?
UNIVERSUM	FT-HDD8123	11AK33 (HDD)
UNIVERSUM	FT1002	PB2101VS
UNIVERSUM	FT1040	PB2103V1 TW
UNIVERSUM	FT1040A	PB2103V1 ?
UNIVERSUM	FT202	CUC2030
UNIVERSUM	FT203	CUC2051N
UNIVERSUM	FT262	CUC2600
UNIVERSUM	FT4200	E9
UNIVERSUM	FT42005	E9
UNIVERSUM	FT4201	E9A
UNIVERSUM	FT4202	E9
UNIVERSUM	FT4204	E9
UNIVERSUM	FT4205	E9
UNIVERSUM	FT4206	E9
UNIVERSUM	FT4207	E9
UNIVERSUM	FT4208	E9
UNIVERSUM	FT4209	09
UNIVERSUM	FT4209 (Gorenje E9)	E9

Brand	model	chassis
UNIVERSUM	FT4210	E9
UNIVERSUM	FT42101	E9
UNIVERSUM	FT42102	E9
UNIVERSUM	FT42103	E9
UNIVERSUM	FT42104	E9
UNIVERSUM	FT4211	G2
UNIVERSUM	FT4212	G2
UNIVERSUM	FT42150	E9
UNIVERSUM	FT42151	E9
UNIVERSUM	FT4222	960 ?
UNIVERSUM	FT42220	E12 (EVELUX)
UNIVERSUM	FT42221	E12 (EVELUX)
UNIVERSUM	FT42222	E9
UNIVERSUM	FT42223	E12 (EVELUX)
UNIVERSUM	FT42224	E9
UNIVERSUM	FT42225	E12 (EVELUX)
UNIVERSUM	FT42226	E12 (EVELUX)
UNIVERSUM	FT42227	E12 (EVELUX)
UNIVERSUM	FT42228	E12A (EVELUX)
UNIVERSUM	FT42228	E9A
UNIVERSUM	FT42230	E10 ???
UNIVERSUM	FT42230	E12A (EVELUX) (?)
UNIVERSUM	FT42230A	E10/A (VALENJE)
UNIVERSUM	FT4240	E5
UNIVERSUM	FT4241	E5
UNIVERSUM	FT4241A	E5
UNIVERSUM	FT4242	E5
UNIVERSUM	FT4242A	E5
UNIVERSUM	FT4243	E5
UNIVERSUM	FT4243A	E5
UNIVERSUM	FT4246	E5
UNIVERSUM	FT4246A	E5
UNIVERSUM	FT4250	E5
UNIVERSUM	FT4261	E6
UNIVERSUM	FT4261A	E6

Brand	model	chassis
UNIVERSUM	FT42641	E5
UNIVERSUM	FT42641	E5
UNIVERSUM	FT42642	E5
UNIVERSUM	FT42643	E5
UNIVERSUM	FT4265	E5
UNIVERSUM	FT4270	E6
UNIVERSUM	FT4271	E7
UNIVERSUM	FT4275	E6
UNIVERSUM	FT4276	E5
UNIVERSUM	FT4281	E6
UNIVERSUM	FT4282	06
UNIVERSUM	FT4283	E6
UNIVERSUM	FT4285	E9
UNIVERSUM	FT42851	E9
UNIVERSUM	FT4286	E9
UNIVERSUM	FT4286	E9 (plyta: 09P/B ST)
UNIVERSUM	FT4287	E9
UNIVERSUM	FT4288	E9
UNIVERSUM	FT4289	E9
UNIVERSUM	FT4290	E9
UNIVERSUM	FT4295	E9
UNIVERSUM	FT4296	E9 ?
UNIVERSUM	FT4296	E9A
UNIVERSUM	FT4301	PC91
UNIVERSUM	FT4306	PC04A
UNIVERSUM	FT4308	(110N65F) (LG)
UNIVERSUM	FT431	PC07X2
UNIVERSUM	FT4310	PC04A
UNIVERSUM	FT4330	ML024B
UNIVERSUM	FT43330	E12 (EVELUX)
UNIVERSUM	FT4367	(110-375F) (LG)
UNIVERSUM	FT4367	(110-375G) (LG)
UNIVERSUM	FT4367	(110A64C CBT9225C) (LG)
UNIVERSUM	FT4367	(110A64E CBT9225S) (LG)
UNIVERSUM	FT4376	PC08X8 ? (110-956A) (LG)

Brand	model	chassis
UNIVERSUM	FT4381	(309-188K) (LG)
UNIVERSUM	FT43866	(110C54G) (LG)
UNIVERSUM	FT4396	(110D48F) (LG)
UNIVERSUM	FT4397	KOMPLETT (309-794X) (LG)
UNIVERSUM	FT4397	PC08X8
UNIVERSUM	FT44230A	E10/A ?
UNIVERSUM	FT45642	E5
UNIVERSUM	FT4601	P88MT
UNIVERSUM	FT4610	(3T30-01720A60) (SAMSUNG)
UNIVERSUM	FT4610	P58SC (?)
UNIVERSUM	FT4681	P54S
UNIVERSUM	FT4681A	P54S
UNIVERSUM	FT4695	P88MS
UNIVERSUM	FT5915	BS990
UNIVERSUM	FT5916	BS990
UNIVERSUM	FT5917	BS990
UNIVERSUM	FT5940VT	PC020
UNIVERSUM	FT5941VT	PC020
UNIVERSUM	FT5942	PC010
UNIVERSUM	FT5942VT	PC020
UNIVERSUM	FT71001	100Hz 16:9 32" (MZPMAGG) (PCE)
UNIVERSUM	FT7103	AB537 (EAB537)
UNIVERSUM	FT7106	3000 !
UNIVERSUM	FT7108	3000
UNIVERSUM	FT7109	3000
UNIVERSUM	FT7116	5000
UNIVERSUM	FT7117	5000
UNIVERSUM	FT7118	5000
UNIVERSUM	FT7119	5000
UNIVERSUM	FT7120	5000
UNIVERSUM	FT7120	5000
UNIVERSUM	FT7120	MC2B ! (100Hz)
UNIVERSUM	FT7120A	5000
UNIVERSUM	FT7120PIP	5000 ? - NIE! (100Hz)
UNIVERSUM	FT7125	5000

Brand	model	chassis
UNIVERSUM	FT7125	C9003
UNIVERSUM	FT7126	5100 !
UNIVERSUM	FT71261	EURO-DIGI
UNIVERSUM	FT71262	5100
UNIVERSUM	FT71263	5100 (FINLUX)
UNIVERSUM	FT7127	5000
UNIVERSUM	FT7128	5100
UNIVERSUM	FT7128A	5100
UNIVERSUM	FT7129	5100
UNIVERSUM	FT7130	AB532 (EAB532) (NOKIA DISPLAY PROD. OY)
UNIVERSUM	FT7131	AB535 (EAB535) (NOKIA DISPLAY PROD. OY)
UNIVERSUM	FT7132	5000
UNIVERSUM	FT7134	AB539 (EAB539X) (NOKIA DISPLAY PROD. OY)
UNIVERSUM	FT7135	AB53 --> EURODIGI 16/9
UNIVERSUM	FT7137	AB53HS (EAB53HS) (NOKIA DISP LAY PROD. OY)
UNIVERSUM	FT7138	AC53PA(TOS) (EAB53PA) (NOKIA DISP LAY PROD. OY)
UNIVERSUM	FT7140	MONO+BG (E58641570) (NOKIA DISP LAY PROD. OY)
UNIVERSUM	FT71402	(0132456) (FG ELEKTRONIK)
UNIVERSUM	FT71402	EASG2DM (0132456) (NOKIA DISP LAY PROD. OY)
UNIVERSUM	FT71402	FS ? (50Hz)
UNIVERSUM	FT71402	FX (100Hz) ?
UNIVERSUM	FT71403	FS (NOKIA) = 6000 100Hz 4:3 (EAXGCVM)
UNIVERSUM	FT71403	FX71U1GUGKV (100Hz)
UNIVERSUM	FT7141	MONO PLUS
UNIVERSUM	FT7142	STEREO PLUS
UNIVERSUM	FT7144	MC2B (Loewe) ?
UNIVERSUM	FT7147	(1405V6) (TAIWAN TV)
UNIVERSUM	FT7150	STEREO PLUS
UNIVERSUM	FT71500	6000 = chassis FX - NOKIA
UNIVERSUM	FT71501	(5864 4650) (NOKIA DISPLAY PROD. OY)
UNIVERSUM	FT7151	STEREO PLUS
UNIVERSUM	FT71510	6000 (EASG8JA) (NOKIA DISPLAY PROD. OY)
UNIVERSUM	FT71510 FS71Y2G	FS
UNIVERSUM	FT7155	6000 (EASG6DA) (NOKIA DISPLAY PROD. OY)
UNIVERSUM	FT7155	E5

Brand	model	chassis
UNIVERSUM	FT7155	FS
UNIVERSUM	FT7157A	CH M+ST P-BG VT8 NN (E58647032) (NOKIA CONSUMER
UNIVERSUM	FT7162	(PS71Y1GU5HJ) (EASGCJM) (NOKIA DISPLAY PROD. OY)
UNIVERSUM	FT7172	3000
UNIVERSUM	FT7173	3000
UNIVERSUM	FT7174	3000
UNIVERSUM	FT7175	SP/BG/DPL/N110G (5864 4838) (GEHADO)
UNIVERSUM	FT7176	3000
UNIVERSUM	FT7176	STEREO PLUS ? (SP71D1GUFHJ)
UNIVERSUM	FT7177	3000 ?
UNIVERSUM	FT7178	MX (100Hz 16:9) (5863 1353) (GEHADO)
UNIVERSUM	FT7179	(100Hz 16:9) (EASZSS37) (NOKIA DISPLAY PROD. OY)
UNIVERSUM	FT7180	MZPEAKG (E58631394) (SEMI- TECH)
UNIVERSUM	FT7182	11AK12
UNIVERSUM	FT7186	FS
UNIVERSUM	FT7186	MX
UNIVERSUM	FT7187	MX
UNIVERSUM	FT7188	3000 (BGAF2AA SP2 (E5863443) (NOKIA CONSUMER ELECTRONICS))
UNIVERSUM	FT7189	STEREO PLUS2 (inaczej: SP2)
UNIVERSUM	FT7191	3000 (AC530A (EAB530A) (NOKIA DISPLAY PROD. OY))
UNIVERSUM	FT7194A	3000-FINLUX ?
UNIVERSUM	FT7195	MZEBBC2 (5863 1625) (SEMI-TECH)
UNIVERSUM	FT71955	4:3 28 SUBW. (MXPMALG) (SEMI- TECH)
UNIVERSUM	FT71955	MXPMAFG (5863 1623) (SEMI- TECH)
UNIVERSUM	FT71956	100Hz 16:9 28 (MZPBBH2) (PARTS CONS.)
UNIVERSUM	FT7196	MZ (100Hz)
UNIVERSUM	FT7198	MXEKCLG (5863 1618) (SEMI-TECH)
UNIVERSUM	FT7199	MXPKCLG (5863 1622) (SEMI-TECH)
UNIVERSUM	FT7225	AB53NS (?)
UNIVERSUM	FT81011	11AK20S
UNIVERSUM	FT81012	11AK28
UNIVERSUM	FT81013	11AK28-10
UNIVERSUM	FT81014	11AK18
UNIVERSUM	FT81015	11AK28-7
UNIVERSUM	FT81017	11AK28-7

Brand	model	chassis
UNIVERSUM	FT81020	E9
UNIVERSUM	FT81021	11AK19P4
UNIVERSUM	FT81022	11AK28A007
UNIVERSUM	FT81026	11AK33
UNIVERSUM	FT81027	11AK30 ?
UNIVERSUM	FT81031	11AK41 (100Hz)
UNIVERSUM	FT81032	11AK37-11
UNIVERSUM	FT8108	11AK03
UNIVERSUM	FT81125	11AK33J3
UNIVERSUM	FT8121	11AK30 ?
UNIVERSUM	FT81228	11AK41
UNIVERSUM	FT8126	11AK03
UNIVERSUM	FT8127	11AK03 ?
UNIVERSUM	FT8131	11AK52B
UNIVERSUM	FT8132	11AK52B4
UNIVERSUM	FT8136	11AK52
UNIVERSUM	FT8141	11AK30
UNIVERSUM	FT8145	11AK10-2
UNIVERSUM	FT8150	11AK16
UNIVERSUM	FT8151A	11AK10-5
UNIVERSUM	FT8152	11AK12
UNIVERSUM	FT8166T	11AK12
UNIVERSUM	FT8167T	11AK10 (?)
UNIVERSUM	FT8168T	11AK12
UNIVERSUM	FT8170	11AK16
UNIVERSUM	FT8170	11AK16A
UNIVERSUM	FT8172	11AK12
UNIVERSUM	FT8172T	11AK12-9
UNIVERSUM	FT81801	11AK19-8A
UNIVERSUM	FT81802	11AK19
UNIVERSUM	FT81803	11AK19E
UNIVERSUM	FT81804	11AK19B
UNIVERSUM	FT81805	11AK19-5
UNIVERSUM	FT81805	11AK19E
UNIVERSUM	FT81806	11AK19-5

Brand	model	chassis
UNIVERSUM	FT81806	11AK19-8A
UNIVERSUM	FT81806	11AK19E3
UNIVERSUM	FT81808	11AK19B12
UNIVERSUM	FT81808	11AK19B12
UNIVERSUM	FT81808	11AK19P4
UNIVERSUM	FT8182	11AK16
UNIVERSUM	FT8182	11AK16
UNIVERSUM	FT8183	11AK18
UNIVERSUM	FT8184	11AK18
UNIVERSUM	FT8186	11AK19
UNIVERSUM	FT8186/100Hz	11AK18
UNIVERSUM	FT8187	11AK19B1
UNIVERSUM	FT8188	11AK18
UNIVERSUM	FT8189	11AK19
UNIVERSUM	FT8189	11AK19-5
UNIVERSUM	FT8189	11AK19-8A
UNIVERSUM	FT8190	11AK19
UNIVERSUM	FT8194	11AK19P4
UNIVERSUM	FT8195	11AK19B1
UNIVERSUM	FT8196	11AK19B
UNIVERSUM	FT8197	11AK19P
UNIVERSUM	FT8197	11AK19P5 (11AK19B, 11AK19P)
UNIVERSUM	FT8198	11AK12
UNIVERSUM	FT8198	11AK19B
UNIVERSUM	FT885	DTV1 (czy? PC170) (SELECO)
UNIVERSUM	FT886	DTV1
UNIVERSUM	FTHDD8123	11AK18
UNIVERSUM	TV5055	E9
UNIVERSUM	TV70242	TV17.1
UNIVERSUM	TV7090 CTI	(31MB0001SE) (ELBIT)
UNIVERSUM	TW82X6	MC2B
UNIVERSUM	XT3781MS	(FJ708TV)
VALENJE		E9 ?
VENUS	CTV55 TXT	11AK30A4
VENUS	CTV74ST TXT	11AK37-11

Brand	model	chassis
VESTEL		11AK20M4
VESTEL		11AK20M6
VESTEL		11AK20S-E
VESTEL		11AK20S-M6
VESTEL		11AK20S2
VESTEL		11AK49-7
VESTEL	1423DVD	11AK46-7
VESTEL	2151T	11AK30-1
VESTEL	2186	11AK30
VESTEL	2851	11AK19P5
VESTEL	2851NST	11AK19P4
VESTEL	3716T	11AK20SE
VESTEL	5126	11AK19P4
VESTEL	5158	11AK06
VESTEL	5166	11AK10
VESTEL	5565	11AK30-2
VESTEL	5571S	11AK19PRO
VESTEL	5596HF	11AK36
VESTEL	CTV3771M	11AK36
VESTEL	CTV5155	11AK19
VESTEL	CTV5511TXT	11AK19P
VESTEL	CTV5571TXT	11AK19P4
VESTEL	CTV7292 N	11AK19B1
VESTEL	VMS5596	11AK21H-1
VESTEL	VR1406TS	11AK36
VESTEL	VR2106TF	11AK30A11
VESTEL	VR54FTS2115	11AK30
VESTEL	VR54TF2145	11AK30A4
Videoseven	L17.4A	RX174T
VISION	14EK-E	PT11
VOGEL	25M11	PH02 ?
WATSON	FA2170	C41
WATSON	FA2620	F6
WATSON	FA2801	11AK19 PRO
WATSON	FA2801TS	11AK19 PRO

Brand	model	chassis
WATSON	FA2840	F9-01
WATSON	FA2845	F9.01
WATSON	FA2851TS	11AK28
WATSON	FA2875TS	(V99.190-07)
WATSON	FA2876	F9
WATSON	FA2877	F9
WATSON	FA3201	11AK19 PRO
WATSON	FA3201TS	11AK19 PRO
WATSON	FA3619	11AK20SE4
WATSON	FA3621	11AK36-1
WATSON	FA3621	11AK36A2
WATSON	FA3622	11AK36
WATSON	FA3622	11AK36A6
WATSON	FA3627T	11AK36
WATSON	FA3628	11AK36A2
WATSON	FA3628T	11AK36
WATSON	FA3629	11AK20S
WATSON	FA3630	11AK20SE5
WATSON	FA3651	TELRA ?
WATSON	FA5112	SM1
WATSON	FA5112	SM1
WATSON	FA5113	PT11
WATSON	FA5116	PT11
WATSON	FA5119	11AK19
WATSON	FA5129	11AK19PRO
WATSON	FA5139	11AK19
WATSON	FA5149	11AK19
WATSON	FA5151	11AK30-2
WATSON	FA5329	11AK19
WATSON	FA5330	11AK19
WATSON	FA5339	11AK19PRO
WATSON	FA5339/STEREO	11AK19-8A
WATSON	FA5430T	11AK30-2
WATSON	FA5432T	11AK30-A11
WATSON	FA5439TS	11AK30

Brand	model	chassis
WATSON	FA5440T	11AK30
WATSON	FA5440TSF	11AK19 PRO
WATSON	FA5441T	11AK30
WATSON	FA5470	SM1 Stereo
WATSON	FA5471	SM1 Stereo
WATSON	FA5472	PT11
WATSON	FA5473	F10 (Formenti)
WATSON	FA6302	F9
WATSON	FA6329	11AK19 PRO
WATSON	FA6329	11AK19E3
WATSON	FA6329	11AK19P4
WATSON	FA7008	TV8
WATSON	FA7020	11AK18
WATSON	FA7039	11AK19B
WATSON	FA7039	11AK19E3
WATSON	FA7039/STEREO110	11AK19B
WATSON	FA7040	11AK19 PRO
WATSON	FA7040	11AK19B1
WATSON	FA7040	11AK19E3
WATSON	FA7040	11AK19P4
WATSON	FA7151	11AK28-6
WATSON	FA7151TS	11AK28-6
WATSON	FA7151VT	11AK28
WATSON	FA7800	11AK19 E3
WATSON	FA8310	F9
WATSON	FA8400	11AK19
WATSON	FA8400/STEREO	11AK19-5
WELLTECH	40375	E1 ?
WEST	21C70	SS
Wharfedale	M2126	TV2KP
WHITE-WESTINGHOUSE	W2337	F24 (Formenti) - ?
WILSON		SM7A (CTS-AA ?)
WILSON	28FFEW70SI	2550
WITJAZ	54CTV6623-3	MSZ93S
WITJAZ	54CTV6643-4	MSZ93S

Brand	model	chassis
XANTRAX	TC1466	ST208
XANTRAX	TC2066S	ST208
XANTRAX	TC2068S	ST209
XANTRAX	TC2166S	ST208
XANTRAX	TC2168C	ST209
XANTRAX	TC2172S	TD18
XIRON	1421	11AK46
YOKO	RC4221PST	RC4121A
YOKO	RC4421PST	RC4121A
YOKO	VCT20	PW1644
YOKO	YTC20	PW1644
ZANUSSI	22ZT907	BS400
ZENITH	B25A02Z	CA
ZENITH	C19A02D	XO
ZENITH	C19A02D8	XO
ZENITH	C19A02DF	XO
ZENITH	C19A02DF8	XO
ZENITH	C19A21D	XO
ZENITH	C19A21D8	XO
ZENITH	C19A21DF	XO
ZENITH	C19A21DF8	XO
ZENITH	H20H52DT	FCH50
ZENITH	H20H52DT8	FCH50
ZENITH	H27E55DT	FC
ZENITH	HW20H52DT	FCH50
ZENITH	HW20H52DT11	FCH50
ZENITH	IQC50H94W	ZP94/ZP95
ZENITH	IQC50H95W	ZP94/ZP95
ZENITH	IQC60H94W	ZP94/ZP95
ZENITH	IQC60H95W	ZP94/ZP95
ZENITH	L15V36	ML012C
ZENITH	LGB29A11ZM	CA
ZENITH	LGC20A02DM	XO
ZENITH	LGC20A02DM8	XO
ZENITH	LGC20A02GM	XO ?

Brand	model	chassis
ZENITH	LGC20A21DM	XO
ZENITH	LGC20A21DM8	XO
ZENITH	PVY4665RK	GZ
ZENITH	TVBR1342Z	CC002
ZENITH	TVBR1942Z	CC002
ZENITH	TVBR2542Z	CC002
ZENITH	Z19A11S	GA
ZENITH	Z56Z83R	GZ
ZENITH	Z60Z83D	GZ