




5.2L

POWERTRAIN
CONTROL
MODULE (PCM)



BATTERY
JUNCTION
BOX (BJB)





POWERTRAIN
CONTROL
MODULE (PCM)


Hot in Start or Run
with Fuel Pump Relay engaged
ELECTRONIC ENGINE CONTROLS





CBB41 BU























POWERTRAIN
CONTROL
MODULE (PCM)





POWERTRAIN
CONTROL
MODULE (PCM)







FUEL PUMP CONTROL MODULE









MANUAL TRANSMISSION

